

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfl=1.00; nt=0.01; nx=1.33

TUB registration: 20091101-GE16/GE16L0NP.PDF /.PS TUB material: code=rh4ta
application for evaluation and measurement of printer or monitor systems

[illegible]

TUB-test chart GE16; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: *w setgray*
output: no change compared to input

[illegible]

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009716	-00100	000205	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$
009203	-00261	-00412	0875	0937	1000	0125	0062	0000	0000	%0163	S02 \$
008760	-00689	-00985	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$
007948	-00703	-01804	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$
007699	-00685	-02561	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$
006388	-00708	-03179	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$
005627	-00919	-03993	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$
005078	-01120	-04437	0125	0562	1000	0875	0250	0000	0000	%0169	S08 \$
004654	-01111	-04751	0000	0500	1000	1000	0500	0000	0000	%0170	S09 \$
009438	-00256	-001483	1000	0937	0875	0000	0062	0125	0000	%0171	T01 \$
009353	-00889	-000223	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$
008856	-00244	-00659	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$
008244	-00345	-01378	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$
007506	-00568	-02159	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$
006679	-00646	-02889	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$
005804	-00883	-03728	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$
005130	-00933	-04293	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$
004487	-00834	-04765	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$
009165	-00249	-002447	1000	0875	0750	0000	0125	0250	0000	%0180	U01 \$
008987	-00025	-001389	0875	0812	0750	0125	0187	0250	0000	%0181	U02 \$
008589	-00067	-000193	0750	0750	0750	0250	0250	0250	0000	%0182	U03 \$
007996	-00166	-00736	0625	0687	0750	0375	0312	0250	0000	%0183	U04 \$
007294	-00244	-01421	0500	0625	0750	0500	0375	0250	0000	%0184	U05 \$
006439	-00522	-02239	0375	0562	0750	0625	0437	0250	0000	%0185	U06 \$
005720	-00676	-02890	0250	0500	0750	0750	0500	0250	0000	%0186	U07 \$
005128	-00868	-03550	0125	0437	0750	0875	0562	0250	0000	%0187	U08 \$
004406	-00676	-04745	0000	0375	0750	1000	0625	0250	0000	%0188	U09 \$
008703	-00065	-003166	1000	0812	0625	0000	0187	0375	0000	%0189	V01 \$
008553	-00081	-002544	0875	0750	0625	0125	0250	0375	0000	%0190	V02 \$
008291	-00015	-001200	0750	0687	0625	0250	0312	0375	0000	%0191	V03 \$
007787	-00054	-000150	0625	0625	0625	0375	0375	0375	0000	%0192	V04 \$
007143	-00156	-00094	0500	0750	0625	0500	0437	0375	0000	%0193	V05 \$
006339	-00238	-01698	0375	0562	0625	0625	0500	0375	0000	%0194	V06 \$
005587	-00521	-02474	0250	0437	0625	0750	0562	0375	0000	%0195	V07 \$
004986	-00679	-03080	0125	0375	0625	0875	0625	0375	0000	%0196	V08 \$
004039	-00563	-04422	0000	0312	0625	1000	0687	0375	0000	%0197	V09 \$
008401	-00031	-004164	1000	0750	0500	0000	0250	0500	0000	%0198	W01 \$
008220	-00301	-003370	0875	0687	0500	0125	0312	0500	0000	%0199	W02 \$
007905	-00015	-002623	0750	0625	0500	0250	0375	0500	0000	%0200	W03 \$
007496	-00061	-001189	0625	0562	0500	0375	0437	0500	0000	%0201	W04 \$
006882	-00046	-000096	0500	0500	0500	0500	0500	0500	0000	%0202	W05 \$
006190	-00086	-01179	0375	0437	0500	0625	0562	0500	0000	%0203	W06 \$
005312	-00366	-02094	0250	0375	0500	0750	0625	0500	0000	%0204	W07 \$
004757	-00492	-02788	0125	0312	0500	0875	0687	0500	0000	%0205	W08 \$
003649	-00367	-04077	0000	0250	0500	1000	0750	0500	0000	%0206	W09 \$
008041	-000719	-004727	1000	0687	0375	0000	0312	0625	0000	%0207	X01 \$
007968	-000589	-004186	0875	0625	0375	0125	0375	0625	0000	%0208	X02 \$
007573	-000395	-0030404	0750	0562	0375	0250	0437	0625	0000	%0209	X03 \$
007137	-000182	-002575	0625	0500	0375	0375	0500	0625	0000	%0210	X04 \$
006546	-000015	-001364	0500	0437	0375	0500	0562	0625	0000	%0211	X05 \$
005862	-00028	-000063	0375	0375	0375	0625	0625	0625	0000	%0212	X06 \$
005125	-00271	-01365	0250	0312	0375	0750	0687	0625	0000	%0213	X07 \$
004550	-00435	-02273	0125	0250	0375	0875	0750	0625	0000	%0214	X08 \$
003332	-00385	-03689	0000	0187	0375	1000	0812	0625	0000	%0215	X09 \$
007673	-001161	-005558	1000	0625	0250	0000	0375	0750	0000	%0216	Y01 \$
007593	-001013	-004796	0875	0562	0250	0125	0437	0750	0000	%0217	Y02 \$
007150	-000643	-004101	0750	0500	0250	0250	0500	0750	0000	%0218	Y03 \$
006654	-000346	-003536	0625	0437	0250	0375	0500	0750	0000	%0219	Y04 \$
006076	-000314	-002612	0500	0375	0250	0500	0625	0750	0000	%0220	Y05 \$
005380	-000096	-001471	0375	0312	0250	0625	0687	0750	0000	%0221	Y06 \$
004584	-00007	-000035	0250	0250	0250	0750	0750	0750	0000	%0222	Y07 \$
004000	-00339	-01734	0125	0187	0250	0875	0812	0750	0000	%0223	Y08 \$
003096	-00499	-03268	0000	0125	0250	1000	0875	0750	0000	%0224	Y09 \$
007362	-001545	-006649	1000	0562	0125	0000	0437	0875	0000	%0225	Z01 \$
007283	-001411	-006440	0875	0500	0125	0125	0125	0800	0875	%0226	Z02 \$
006744	-001150	-005481	0750	0437	0125	0250	0562	0875	0000	%0227	Z03 \$
006140	-001009	-004790	0625	0375	0125	0375	0625	0875	0000	%0228	Z04 \$
005588	-000593	-003919	0500	0312	0125	0500	0687	0875	0000	%0229	Z05 \$
004905	-000472	-003018	0375	0250	0125	0625	0750	0875	0000	%0230	Z06 \$
004344	-000145	-001900	0250	0187	0125	0750	0812	0875	0000	%0231	Z07 \$
002923	-000010	-000022	0125	0125	0125	0875	0875	0875	0000	%0232	Z08 \$
002870	-00731	-02174	0000	0062	0125	1000	0937	0875	0000	%0233	Z09 \$
007074	-002024	-007186	1000	0500	0000	0000	0500	1000	0000	%0234	A01 \$
006921	-001974	-007032	0875	0437	0000	0125	0562	1000	0000	%0235	A02 \$
006413	-001728	-006384	0750	0375	0000	0250	0625	1000	0000	%0236	A03 \$
005443	-001584	-005268	0625	0312	0000	0375	0687	1000	0000	%0237	A04 \$
004544	-001420	-004060	0500	0250	0000	0500	0750	1000	0000	%0238	A05 \$
003911	-001282	-003319	0375	0187	0000	0625	0812	1000	0000	%0239	A06 \$
003225	-001097	-002335	0250	0125	0000	0750	0875	1000	0000	%0240	A07 \$
002600	-000801	-001317	0125	0062	0000	0875	0937	1000	0000	%0241	A08 \$
001902	-000041	-000087	0000	0000	0000	1000	1000	1000	0000	%0242	A09 \$
009705	-00105	-000231	1000	1000	1000	0000	0000	0000	0000	%0486	S10 \$
009159	-000523	-00208	0937	0875	1000	0062	0125	0000	0000	%0487	S11 \$
008452	-001145	-00665	0875	0750	1000	0125	0250	0000	0000	%0488	S12 \$
007638	-002012	-01829	0812	0625	1000	0187	0375	0000	0000	%0489	S13 \$
006663	-002817	-01521	0750	0500	1000	0250	0500	0000	0000	%0490	S14 \$
005589	-003559	-01981	0687	0375	1000	0312	0625	0000	0000	%0491	S15 \$
004620	-004208	-02423	0625	0250	1000	0375	0750	0000	0000	%0492	S16 \$
004099	-004873	-02531	0562	0250	1000	0875	0875	0000	0000	%0493	S17 \$
003622	-005168	-02435	0500	0000	1000	0500	1000	0000	0000	%0494	S18 \$
009546	-00705	-001367	0937	1000	0875	0062	0000	0125	0000	%0495	T10 \$
009473	-00091	-000226	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$
008745	-000664	-00524	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$
008017	-001294	-00979	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$
007933	-002216	-01453	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$
005975	-003180	-01911	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$
004863	-003975	-02455	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$
003983	-004772	-02587	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$
003444	-004946	-02455	0437	0000	0875	0562	1000	0125	0000	%0503	T18 \$
009366	-01207	-02362	0875	1000	0750	0125	0000	0250	0000	%0504	T19 \$
009221	-00745	-001325	0812	0875	0750	0187	0125	0250	0000	%0505	U11 \$
008708	-00071	-000210	0750	0750	0750	0250	0250	0250	0000	%0506	U12 \$
007889	-000779	-00598	0687	0625	0750	0312	0375	0250	0000	%0507	U13 \$
007030	-001528	-01107	0625	0500	0750	0375	0500	0250	0000	%0508	U14 \$
006142	-002336	-									

009709	-00104	000220	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
009136	-00085	-00426	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008571	-00195	-01027	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
007542	-00020	-01909	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
006526	-00039	-02632	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
005534	-00076	-03262	0375	0531	1000	0625	0488	0000	0000	%0248	b06	\$
004713	000914	-03857	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
004076	000782	-04344	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$
003653	000749	-04543	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
003056	-00445	-001552	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
003063	-00093	000235	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
008770	-00021	-00653	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
007948	-00038	-01474	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
007082	-00188	-02211	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
005948	-00034	-03096	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
004841	-00058	-03892	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
004158	-00094	-04382	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
003635	-00057	-04506	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
003018	-00017	-002665	1000	0937	0750	0000	062	0250	0000	%0261	d01	\$
001948	-00256	-001475	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
008614	-00064	-000176	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$
007920	-00025	-000833	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
006963	000281	-01554	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
005997	000243	-02463	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
005223	-000436	-03287	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
004490	-000457	-04037	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
003490	-000625	-04357	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
009105	-00489	-003539	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
009002	-00423	-002838	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
008541	-00173	-001353	0750	0718	0875	0625	0259	0281	0375	%0272	e03	\$
007847	-00055	-000139	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
007003	-000171	-01023	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
005962	-000204	-01867	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$
005123	-000383	-02580	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$
004546	-000323	-03187	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
003272	-000718	-04154	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
008872	-00366	-004317	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
008732	-00345	-003721	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
008364	-00404	-002795	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
007753	-00207	-001441	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
006937	-00047	-000084	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
006009	-000191	-01280	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
005118	-000161	-02094	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
004429	-000397	-02836	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
003073	-000735	-03917	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
008691	-00274	-005011	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
008500	-00294	-004625	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
008081	-00327	-003809	0750	0566	0375	0250	0343	0625	0000	%0290	g03	\$
007524	-00333	-002891	0625	0562	0375	0375	0437	0625	0000	%0291	g04	\$
006835	-00301	-001585	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
005863	-00028	-000070	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
004913	-000148	-01597	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
004202	-000183	-02401	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
003287	-000558	-03616	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
008536	-00186	-005729	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
008321	-00248	-005367	0875	0718	0500	0125	0250	0187	0500	%0298	h02	\$
007930	-00328	-004823	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
007288	-00358	-004141	0625	0531	0250	0375	0406	0750	0000	%0300	h04	\$
006573	-00415	-003083	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
005701	-00269	-001669	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
004615	-00012	-000037	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
003803	-000163	-01823	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
002655	-00320	-02958	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
008409	-00164	-006827	1000	0781	0125	0000	0218	0875	0000	%0306	i01	\$
008146	-00054	-007215	0875	0687	0125	0125	0312	0875	0000	%0307	i02	\$
007669	-00114	-006644	0750	0593	0125	0250	0406	0875	0000	%0308	i03	\$
007027	-00225	-005823	0625	0500	0125	0375	0500	0875	0000	%0309	i04	\$
006231	-00286	-004577	0500	0406	0125	0500	0593	0875	0000	%0310	i05	\$
005473	-00302	-003507	0375	0312	0125	0625	0687	0875	0000	%0311	i06	\$
004649	-00288	-002160	0250	0218	0125	0750	0781	0875	0000	%0312	i07	\$
002996	-00012	-000019	0125	0125	0125	0875	0875	0875	0000	%0313	i08	\$
002507	-00016	-02168	0000	0031	0125	1000	0968	0875	0000	%0314	i09	\$
008243	-000463	-008035	1000	0750	0000	0000	0250	1000	0000	%0315	j01	\$
008099	-00222	-008325	0875	0656	0000	0125	0343	1000	0000	%0316	j02	\$
007516	-00186	-007584	0750	0562	0000	0250	0437	1000	0000	%0317	j03	\$
006449	-000141	-006477	0625	0406	0000	0375	0531	1000	0000	%0318	j04	\$
005332	-000070	-005168	0500	0375	0000	0500	0625	1000	0000	%0319	j05	\$
004493	-000095	-004124	0375	0281	0000	0625	0718	1000	0000	%0320	j06	\$
003655	-000109	-003109	0250	0187	0000	0750	0812	1000	0000	%0321	j07	\$
002705	-000344	-001760	0125	0093	0000	0875	0906	1000	0000	%0322	j08	\$
001930	-000035	-000082	0000	0000	0000	1000	1000	1000	0000	%0323	j09	\$
009705	-00097	-000202	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
009224	-000621	-00123	0968	0875	1000	0031	0125	0000	0000	%0568	b11	\$
008573	-001481	-00448	0937	0750	1000	0062	0250	0000	0000	%0569	b12	\$
007942	-000209	-000677	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$
007126	-000369	-01032	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
006200	-000388	-01413	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
005427	-004892	-01625	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
004816	-000781	-01658	0781	0250	1000	0218	0875	0000	0000	%0574	b17	\$
004145	-0006145	-01571	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
004018	-000799	-001053	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$
0039463	-000088	-000211	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$
008817	-000783	-004046	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
008182	-001575	-00720	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
007345	-002550	-01055	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
006354	-0003591	-01461	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
005477	-004602	-01686	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$
004626	-000598	-01706	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
003971	-005854	-01625	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
002947	-012244	-001924	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$
002964	-00872	-001126	0781	0875	0750	0218	0125	0250	0000			

See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

```
%BEG GE06_22_REM.TXT, Separation cmyn62*, D65, not adapted S
%100 x LAB*      %1000 x (r g b c m y 0)      %nr.   pos $
%Z004556 006162 004041 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009153 -01490 008657 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005814 -06136 003809 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005429 -03138 -03864 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003181 002722 -04035 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004629 007225 -00821 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001574 000044 000110 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009685 -00103 000214 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W1 7 $
%S
%Z004556 006162 004041 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009153 -01490 008657 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005814 -06136 003809 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005429 -03138 -03864 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003181 002722 -04035 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004629 007225 -00821 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001574 000044 000110 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009685 -00103 000214 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W2 7 $
%S
%Z004556 006162 004041 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009153 -01490 008657 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005814 -06136 003809 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005429 -03138 -03864 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003181 002722 -04035 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004629 007225 -00821 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001574 000044 000110 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009685 -00103 000214 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W001 7 $
%S
%Z005899 004261 006082 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z009006 -02207 008912 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005871 -05484 001543 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005360 -02555 -04552 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003166 004217 -03222 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004478 006829 000049 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001682 000045 000098 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009691 -00106 000227 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %W251 7 $
%S
%Z007074 002024 007186 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007674 -03577 006764 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005982 -04698 -00096 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004664 -01111 -04751 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003620 005168 -02436 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004430 006288 001582 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001786 000043 000099 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009708 -00101 000212 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %W501 7 $
%S
%Z008243 000003 008035 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006653 -04810 005144 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005989 -04035 -01574 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003653 000749 -04553 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004145 006145 -01571 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004484 006049 002790 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001760 000041 000096 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009793 -00101 000212 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %W751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

%BEG GE06_22_REM.TXT, Separation cmyn62*, D65, not adapted S
%100 x LAB* 1000 x (r g b c m y θ) %nrr. pos \$
001527 000025 000100 0000 0000 0000 1000 1000 1000 0000 %0972 k01 \$
002674 000000 000033 0125 0125 0125 0875 0875 0875 0000 %0973 k02 \$
004526 -000021 000017 0250 0250 0250 0750 0750 0750 0000 %0974 k03 \$
005786 -000034 000051 0375 0375 0375 0625 0625 0625 0000 %0975 k04 \$
006965 -000046 000076 0500 0500 0500 0500 0500 0500 0000 %0976 k05 \$
007932 -000054 000135 0625 0625 0625 0375 0375 0375 0000 %0977 k06 \$
008725 -000065 000181 0750 0750 0750 0250 0250 0250 0000 %0978 k07 \$
009473 -000088 000204 0875 0875 0875 0125 0125 0125 0000 %0979 k08 \$
010161 -000101 000208 1000 1000 1000 0000 0000 0000 0000 %0980 k09 \$
011498 000028 000101 0000 0000 0000 1000 1000 1000 0000 %0981 l01 \$
002625 000006 000027 0125 0125 0125 0875 0875 0875 0000 %0982 l02 \$
004510 -000015 000014 0250 0250 0250 0750 0750 0750 0000 %0983 l03 \$
005767 -000032 000045 0375 0375 0375 0625 0625 0625 0000 %0984 l04 \$
006939 -000044 000073 0500 0500 0500 0500 0500 0500 0000 %0985 l05 \$
007931 -000054 000137 0625 0625 0625 0375 0375 0375 0000 %0986 l06 \$
008686 -000066 000184 0750 0750 0750 0250 0250 0250 0000 %0987 l07 \$
009469 -000089 000210 0875 0875 0875 0125 0125 0125 0000 %0988 l08 \$
009728 -000100 000207 1000 1000 1000 0000 0000 0000 0000 %0989 l09 \$
010362 000030 000104 0000 0000 0000 1000 1000 1000 0000 %0990 m01 \$
002552 000006 000052 0125 0125 0125 0875 0875 0875 0000 %0991 m02 \$
004468 -000014 000026 0250 0250 0250 0750 0750 0750 0000 %0992 k03 \$
005744 -000029 000064 0375 0375 0375 0625 0625 0625 0000 %0993 k04 \$
006923 -000043 000090 0500 0500 0500 0500 0500 0500 0000 %0994 m05 \$
007896 -000056 000148 0625 0625 0625 0375 0375 0375 0000 %0995 m06 \$
008701 -000066 000189 0750 0750 0750 0250 0250 0250 0000 %0996 m07 \$
009467 -000090 000216 0875 0875 0875 0125 0125 0125 0000 %0997 m08 \$
009717 -000106 000225 1000 1000 1000 0000 0000 0000 0000 %0998 m09 \$
010322 000029 000092 0000 0000 0000 1000 1000 1000 0000 %0999 n01 \$
002578 000005 000052 0125 0125 0125 0875 0875 0875 0000 %1000 n02 \$
004468 -000013 000044 0250 0250 0250 0750 0750 0750 0000 %1001 n03 \$
005737 -000029 000078 0375 0375 0375 0625 0625 0625 0000 %1002 n04 \$
006905 -000042 000087 0500 0500 0500 0500 0500 0500 0000 %1003 n05 \$
007865 -000049 000042 0625 0625 0625 0375 0375 0375 0000 %1004 n06 \$
008690 -000063 000191 0750 0750 0750 0250 0250 0250 0000 %1005 n07 \$
009472 -000091 000218 0875 0875 0875 0125 0125 0125 0000 %1006 n08 \$
009721 -000094 000199 1000 1000 1000 0000 0000 0000 0000 %1007 n09 \$
011906 000037 000082 0000 0000 0000 1000 1000 1000 0000 %1008 k10 \$
002129 000034 000065 0066 0066 0066 0933 0933 0933 0000 %1009 k11 \$
003056 000008 000003 0133 0133 0133 0866 0866 0866 0000 %1010 k12 \$
004075 -000002 -000002 0200 0200 0200 0800 0800 0800 0000 %1011 k13 \$
004799 -000010 000031 0266 0266 0266 0733 0733 0733 0000 %1012 k14 \$
005538 -000021 000033 0333 0333 0333 0666 0666 0666 0000 %1013 k15 \$
006236 -000028 000056 0400 0400 0400 0600 0600 0600 0000 %1014 k16 \$
006854 -000041 000077 0466 0466 0466 0533 0533 0533 0000 %1015 k17 \$
007298 -000051 000108 0533 0533 0533 0466 0466 0466 0000 %1016 k18 \$
007789 -000058 000143 0600 0600 0600 0399 0399 0399 0000 %1017 k19 \$
008205 -000057 000169 0666 0666 0666 0333 0333 0333 0000 %1018 k20 \$
008629 -000062 000187 0733 0733 0733 0266 0266 0266 0000 %1019 k21 \$
009031 -000072 000201 0800 0800 0800 0199 0199 0199 0000 %1020 k22 \$
009328 -000080 000202 0866 0866 0866 0133 0133 0133 0000 %1021 k23 \$
009677 -000095 000194 0933 0933 0933 0066 0066 0066 0000 %1022 k24 \$
009700 -000096 000196 1000 1000 1000 0000 0000 0000 0000 %1023 k25 \$
0101867 000038 000090 0000 0000 0000 1000 1000 1000 0000 %1024 l10 \$
012054 000035 000078 0066 0066 0066 0933 0933 0933 0000 %1025 l11 \$
013015 000008 000013 0133 0133 0133 0866 0866 0866 0000 %1026 l12 \$
014071 -000004 000005 0200 0200 0200 0800 0800 0800 0000 %1027 l13 \$
014824 -000018 000034 0266 0266 0266 0733 0733 0733 0000 %1028 l14 \$
015573 -000029 000039 0333 0333 0333 0666 0666 0666 0000 %1029 l15 \$
016237 -000028 000058 0400 0400 0400 0600 0600 0600 0000 %1030 l16 \$
016824 -000035 000071 0466 0466 0466 0533 0533 0533 0000 %1031 l17 \$
017289 -000041 000090 0533 0533 0533 0466 0466 0466 0000 %1032 l18 \$
017738 -000046 000121 0600 0600 0600 0399 0399 0399 0000 %1033 l19 \$
018141 -000051 000156 0666 0666 0666 0333 0333 0333 0000 %1034 l20 \$
018574 -000057 000176 0733 0733 0733 0266 0266 0266 0000 %1035 l21 \$
018985 -000069 000196 0800 0800 0800 0199 0199 0199 0000 %1036 l22 \$
019299 -000075 000194 0866 0866 0866 0133 0133 0133 0000 %1037 l23 \$
019678 -000093 000197 0933 0933 0933 0066 0066 0066 0000 %1038 l24 \$
019716 -000098 000201 1000 1000 1000 0000 0000 0000 0000 %1039 l25 \$
0101670 000040 000092 0000 0000 0000 1000 1000 1000 0000 %1040 m10 \$
011946 000033 000083 0066 0066 0066 0933 0933 0933 0000 %1041 m11 \$
012986 000012 000014 0133 0133 0133 0866 0866 0866 0000 %1042 m12 \$
014019 000000 000019 0200 0200 0200 0800 0800 0800 0000 %1043 m13 \$
014774 -000003 000040 0266 0266 0266 0733 0733 0733 0000 %1044 m14 \$
015510 -000017 000050 0333 0333 0333 0666 0666 0666 0000 %1045 m15 \$
016203 -000023 000063 0400 0400 0400 0600 0600 0600 0000 %1046 m16 \$
016765 -000032 000084 0466 0466 0466 0533 0533 0533 0000 %1047 m17 \$
017271 -000039 000101 0533 0533 0533 0466 0466 0466 0000 %1048 m18 \$
017732 -000046 000132 0600 0600 0600 0399 0399 0399 0000 %1049 m19 \$
018114 -000050 000160 0666 0666 0666 0333 0333 0333 0000 %1050 m20 \$
018595 -000059 000187 0733 0733 0733 0266 0266 0266 0000 %1051 m21 \$
018986 -000071 000202 0800 0800 0800 0199 0199 0199 0000 %1052 m22 \$

TUB-test chart GE16; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: ->olv* setrgbcolor

TUB registration: 20091101-GE16/GE16L0NP.PDF /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

TUB registration: 20091101-GE16/GE16L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IUB material: code=rha4ta

TUB-test chart GE16; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NP.PDF> / <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009716	000001	-000007	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$	009705	-000004	000019	1000	1000	1000	0000	0000	0000	%0486	S10 \$	009702	000003	-000011	1000	1000	1000	0000	0000	0000	0000	0000	%0810	S19 \$	
009203	-00169	-00618	0875	0937	1000	0125	0062	0000	0000	%0163	S02 \$	009159	-000614	-00413	0937	0875	1000	0062	0125	0000	0000	%0487	S11 \$	009190	000740	-000663	1000	0875	0937	0000	0125	0062	0000	%0811	S20 \$	
000876	-00605	-01184	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$	000452	-001223	-00859	0875	0750	1000	0125	0250	0000	0000	%0488	S12 \$	000854	001462	-000125	1000	0750	0875	0000	0250	0125	0000	%0812	S21 \$	
0007948	-00634	-01992	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$	0007638	-002075	-01212	0812	0625	1000	0187	0375	0000	0000	%0489	S13 \$	0007948	002149	-000409	1000	0625	0812	0000	0375	0187	0000	%0813	S22 \$	
0007699	-00632	-02736	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$	0006663	-002863	-01691	0750	0500	1000	0250	0500	0000	0000	%0490	S14 \$	0007317	002905	-000754	1000	0500	0750	0000	0500	0250	0000	%0814	S23 \$	
0006388	-00607	-03344	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$	0005689	-003687	-02136	0687	0375	1000	0312	0625	0000	0000	%0491	S15 \$	0006523	004023	-001141	1000	0375	0687	0000	0625	0312	0000	%0815	S24 \$	
0005627	-00893	-04057	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$	0004619	-004219	-02565	0625	0250	1000	0375	0750	0000	0000	%0492	S16 \$	0005653	005412	-001420	1000	0250	0625	0000	0750	0375	0000	%0816	S25 \$	
0005870	-01104	-04503	0125	0562	1000	0875	0507	0000	0000	%0169	S08 \$	0004459	-004670	-02663	0562	0250	1000	0875	0500	0000	0000	%0493	S17 \$	0004937	006639	-001552	1000	0125	0562	0000	0875	0437	0000	%0817	S26 \$	
0004654	-01102	-04892	0000	0500	1000	1000	0507	0000	0000	%0170	S09 \$	0003620	-005157	-02562	0500	0000	1000	0500	1000	0000	0000	%0494	S18 \$	0004430	002292	-001445	1000	0000	0500	0000	1000	0500	0000	%0818	S27 \$	
0004348	-00160	-001274	1000	0937	0875	0000	0062	0125	0000	%0171	T01 \$	0009546	-006087	-001157	0937	1000	0875	0062	0000	0125	0000	%0495	T10 \$	0009325	-005070	-000887	0875	1000	0937	0125	0000	0062	0000	%0819	T19 \$	
0009353	000005	000016	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$	0009473	000004	000017	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$	0009426	000012	000000	0875	0875	0875	0125	0125	0125	0000	%0820	T20 \$	
0008856	-00139	-00860	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$	0008745	000747	-00722	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$	0008602	000900	-000103	0875	0750	0812	0125	0250	0187	0000	%0821	T21 \$	
0008244	-00271	-01562	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$	0008917	-001364	-01168	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$	0008041	-001566	-000373	0875	0625	0750	0125	0375	0250	0000	%0822	T22 \$	
0007506	-00507	-02332	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$	0007933	-002268	-01627	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$	0007367	-002472	-000548	0875	0500	0687	0125	0500	0312	0000	%0823	T23 \$	
0006679	-00601	-03058	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$	0005975	-003213	-02070	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$	0006645	-003546	-001082	0875	0375	0625	0125	0625	0375	0000	%0824	T24 \$	
0005804	-00853	-03885	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$	0004863	-003987	-02599	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$	0005835	-004773	-001375	0875	0250	0562	0125	0750	0437	0000	%0825	T25 \$	
0005130	-00196	-04440	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$	0003983	-004769	-02718	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$	0004952	-006250	-001613	0875	0125	0500	0125	0875	0500	0000	%0826	T26 \$	
0004487	-00829	-04904	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$	0003444	-004933	-02578	0437	0000	0875	0562	1000	0125	0000	%0503	T18 \$	0004176	-005929	-001335	0875	0000	0437	0125	1000	0562	0000	%0827	T27 \$	
0009165	-00157	-002242	1000	0875	0750	0000	0125	0250	0000	%0180	T01 \$	0009366	-011122	-002154	0875	1000	0750	0125	0000	0250	0000	%0504	T19 \$	0008886	-011226	-000930	0750	1000	0875	0250	0000	0125	0000	%0828	T28 \$	
0008987	000112	001187	0875	0812	0750	0125	0187	0250	0000	%0181	U02 \$	0009221	-006653	-001119	0812	0875	0750	0187	0125	0250	0000	%0505	U11 \$	0009150	-008662	-000156	0750	0875	0812	0250	0125	0187	0000	%0829	U20 \$	
0008589	000013	-000002	0750	0750	0750	0250	0250	0250	0000	%0182	U03 \$	0008708	000011	000012	0750	0750	0750	0250	0250	0250	0000	%0506	U12 \$	0008611	000015	000002	0750	0750	0750	0250	0250	0250	0000	%0830	U21 \$	
0007996	-00097	-00924	0625	0687	0750	0375	0312	0250	0000	%0183	U04 \$	0007889	000847	-00785	0687	0625	0750	0312	0375	0250	0000	%0507	U13 \$	0007814	000967	-000051	0750	0625	0687	0250	0375	0312	0000	%0831	U22 \$	
0007294	-00187	-01599	0500	0625	0750	0500	0375	0250	0000	%0184	U05 \$	0007030	-001580	-01281	0625	0500	0750	0375	0500	0250	0000	%0508	U14 \$	0007106	-001651	-000360	0750	0500	0625	0250	0500	0375	0000	%0832	U23 \$	
0006439	-00481	-02405	0375	0562	0750	0625	0437	0250	0000	%0185	U06 \$	0006142	-002371	-01717	0562	0375	0750	0437	0625	0250	0000	%0509	U15 \$	0006347	-002484	-000601	0750	0375	0562	0250	0625	0437	0000	%0833	U24 \$	
0005720	-00648	-03046	0250	0500	0750	0750	0500	0250	0000	%0186	U07 \$	0005172	-003317	-02200	0500	0250	0750	0500	0750	0250	0000	%0510	U16 \$	0005470	-003561	-000973	0750	0375	0500	0500	0250	0750	0500	0000	%0834	U25 \$
0005128	-00851	-03697	0125	0437	0750	0875	0562	0250	0000	%0187	U08 \$	0004126	-004614	-02588	0437	0125	0750	0562	0875	0250	0000	%0511	U17 \$	0004568	-004906	-001282	0750	0125	0437	0250	0875	0562	0000	%0835	U26 \$	
0004406	-00672	-04882	0000	0375	0750	1000	0625	0250	0000	%0188	U09 \$	0003240	-004585	-02495	0375	0000	0750	0625	1000	0250	0000	%0512	U18 \$	0003857	-005381	-001240	0750	0000	0375	0250	1000	0625	0000	%0836	U27 \$	
0008703	-00247	-002967	1000	0812	0625	0000	0187	0375	0000	%0189	V01 \$	0009143	-01543	-002964	0812	1000	0625	0187	0000	0375	0000	%0513	V10 \$	0008491	-01449	-00271	0625	1000	0812	0375	0000	0187	0000	%0837	V19 \$	
0008553	-000161	-002347	0875	0750	0625	0125	0250	0375	0000	%0190	V02 \$	0009140	-01273	-002398	0750	0875	0625	0250	0125	0375	0000	%0514	V11 \$	0008452	-01404	-000397	0625	0875	0750	0375	0125	0250	0000	%0838	V20 \$	
0008291	-000990	-001008	0750	0687	0625	0250	0312	0375	0000	%0191	V03 \$	0008599	-00686	-000941	0687	0750	0625	0312	0250	0375	0000	%0515	V12 \$	0008453	-000970	-000163	0625	0750	0687	0375	0250	0312	0000	%0839	V19 \$	
0007787	000011	-00034	0625	0625	0625	0375	0375	0375	0000	%0192	V04 \$	0007905	-000913	-000837	0625	0625	0625	0375	0375	0375	0000	%0516	V13 \$	0007823	-000816	-000335	0625	0625	0625	0375	0375	0375	0000	%0840	V22 \$	
0007143	-00102	-01081	0500	0625	0562	0500	0437	0375	0000	%0193	V05 \$	0006976	-000861	-000925	0562	0500	0625	0437	0500	0375	0000	%0517	V14 \$	0007017	-000986	-000709	0625	0500	0562	0375	0500	0437	0000	%0841	V23 \$	
0006339	-00190	-01862	0375	0562	0625	0625	0625	0375	0000	%0194	V06 \$	0006103	-001648	-01381	0500	0375	0625	0500	0625	0375	0000	%0518	V15 \$	0006251	-001777	-000434	0625	0375	0500	0375	0625	0500	0000	%0842	V24 \$	
0005587	-00495	-02626	0250	0437	0625	0750	0562	0375	0000	%0195	V07 \$	0005144	-002589	-01838	0437	0250	0625	0562	0750	0375	0000	%0519	V16 \$	0005272	-002707	-000759	0625	0500	0437	0375	0750	0562	0000	%0843	V25 \$	
0004986	-00664	-03226	0125	0375	0625	0875	0625	0375	0000	%0196	V08 \$	0004127	-003698	-02276	0375	0125	0625	0625	0875	0375	0000	%0520	V17 \$	0004215	-004008	-001073	0625	0125	0375	0375	0875	0625	0000	%0844	V26 \$	
0004039	-00566	-04554	0000	0312	0625	1000	0687	0375	0000	%0197	V09 \$	0002994	-0042																							

009709	-00003	000008	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$	009705	000003	-00009	1000	1000	1000	0000	0000	%0567	b10	\$	009694	000000	000001	1000	1000	1000	0000	0000	0000	0000	%0891	b19	\$			
009136	000005	-00630	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$	009224	0000713	-00329	0868	0875	1000	0031	0125	0000	%0568	b11	\$	009150	000604	000349	1000	0875	0906	0000	0125	0093	0000	%0892	b20	\$		
008571	-00115	-01222	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$	008573	001561	-00644	0937	0750	1000	0062	0250	0000	%0569	b12	\$	008650	001095	000725	1000	0750	0812	0000	0250	0187	0000	%0893	b21	\$		
007542	000082	-02090	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$	007942	002278	-00864	0936	0625	1000	0093	0375	0000	%0570	b13	\$	008021	001763	001174	1000	0625	0718	0000	0375	0281	0000	%0894	b22	\$		
006526	000383	-02798	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$	007126	003124	-01206	0875	0500	1000	0125	0500	0000	%0571	b14	\$	007325	002557	001795	1000	0500	0625	0000	0500	0375	0000	%0895	b23	\$		
005534	000786	-03413	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$	006200	004026	-01574	0843	0375	1000	0156	0625	0000	%0572	b15	\$	006465	003825	002200	1000	0375	0531	0000	0625	0468	0000	%0896	b24	\$		
004713	000925	-03997	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$	005427	004917	-01775	0812	0250	1000	0187	0750	0000	%0573	b16	\$	005638	005139	002762	1000	0250	0437	0000	0750	0562	0000	%0897	b25	\$		
004076	000792	-04475	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$	004616	005790	-01797	0781	0125	1000	0217	0875	0000	%0574	b17	\$	004928	006363	002981	1000	0125	0343	0000	0875	0556	0000	%0898	b26	\$		
003653	000742	-04677	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$	004145	006146	-01782	0750	0000	1000	0250	1000	0000	%0575	b18	\$	004484	006057	002653	1000	0000	0250	0000	1000	0750	0000	%0899	b27	\$		
009565	-00347	-001342	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$	009418	-00704	-000845	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$	009308	-00515	-00283	0875	1000	0968	0125	0000	0031	0000	%0900	c19	\$	
009363	000001	000027	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$	009463	000007	-000002	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$	009418	000002	000020	0875	0875	0875	0125	0125	0125	0000	%0901	c20	\$	
009740	000062	-00852	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$	008817	000868	-00605	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$	008559	000750	000458	0875	0750	0781	0125	0250	0218	0000	%0902	c21	\$	
008798	000299	-01660	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$	008182	001649	-00910	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$	008027	001273	000946	0875	0625	0687	0125	0375	0312	0000	%0903	c22	\$	
007082	000242	-02385	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$	007345	002608	-01233	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$	007442	002034	001529	0875	0500	0593	0125	0500	0406	0000	%0904	c23	\$	
005940	000398	-03253	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$	006354	003632	-01625	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$	006671	003141	002010	0875	0375	0500	0125	0625	0500	0000	%0905	c24	\$	
004841	000572	-04033	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$	005477	004627	-01837	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$	005833	004502	002580	0875	0250	0406	0125	0750	0593	0000	%0906	c25	\$	
004158	000595	-04514	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$	004626	005608	-01844	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$	004977	005920	002877	0875	0125	0312	0125	0875	0687	0000	%0907	c26	\$	
003635	000669	-04630	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$	003971	005852	-01754	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$	004238	005635	002451	0875	0000	0218	0125	1000	0781	0000	%0908	c27	\$	
009318	-00423	002458	1000	0937	0750	0000	0602	0250	0000	%0261	d01	\$	009247	-01151	-00717	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$	008832	-00893	-00828	0750	1000	0937	0250	0000	0062	0000	%0909	d19	\$	
009148	-00165	001271	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$	009264	-00779	-000920	0781	0875	0750	0218	0125	0250	0000	%0586	d11	\$	009096	-00708	-00483	0750	0875	0843	0250	0125	0156	0000	%0910	d20	\$	
008614	000016	-00019	0500	0750	0750	0250	0250	0250	0000	%0263	d03	\$	008742	000013	-00002	0750	0750	0750	0250	0250	0250	0000	%0587	d12	\$	008668	000019	-00012	0750	0750	0750	0250	0250	0250	0000	%0911	d21	\$	
007920	000093	-01020	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$	008011	000929	-00714	0718	0625	0750	0281	0375	0250	0000	%0588	d13	\$	007893	000771	000442	0750	0625	0656	0250	0375	0343	0000	%0912	d22	\$	
006963	000333	-01726	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$	007243	001779	-00990	0687	0500	0750	0312	0500	0250	0000	%0589	d14	\$	007213	001300	001179	0750	0500	0562	0250	0500	0437	0000	%0913	d23	\$	
005997	000277	-02621	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$	006400	002699	-01312	0656	0375	0750	0343	0625	0250	0000	%0590	d15	\$	006421	002078	001554	0750	0375	0468	0250	0625	0531	0000	%0914	d24	\$	
005223	000456	-03434	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$	005524	003754	-01562	0625	0250	0750	0375	0750	0250	0000	%0591	d16	\$	005520	003261	001928	0750	0250	0375	0250	0750	0625	0000	%0915	d25	\$	
004490	000465	-04173	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$	004575	005013	-01765	0503	0125	0750	0406	0875	0250	0000	%0592	d17	\$	004653	004612	002286	0750	0125	0281	0250	0875	0718	0000	%0916	d26	\$	
003490	000615	-04479	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$	003713	005055	-01708	0562	0000	0750	0437	1000	0250	0000	%0593	d18	\$	003899	005077	002122	0750	0000	0187	0250	1000	0812	0000	%0917	d27	\$	
009105	-00339	003336	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$	008830	-01174	-002100	0718	1000	0625	0281	0000	0375	0000	%0594	e10	\$	008366	-01343	-01003	0625	1000	0906	0375	0000	0093	0000	%0918	e19	\$	
009002	-00334	002636	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$	008902	-01524	-001955	0687	0875	0625	0312	0125	0375	0000	%0595	e11	\$	008607	-01142	-00799	0625	0875	0812	0375	0125	0187	0000	%0919	e20	\$	
008531	-00093	001158	0750	0718	0875	0625	0250	0281	0375	0000	%0272	e03	\$	008589	-00845	-000845	0656	0750	0625	0343	0250	0375	0000	%0596	e12	\$	008456	-00783	-00435	0625	0750	0718	0375	0250	0281	0000	%0920	e21	\$
007847	000012	-00045	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$	007943	000016	-00055	0625	0625	0625	0375	0375	0375	0000	%0597	e13	\$	007854	000016	-00045	0625	0625	0625	0375	0375	0375	0000	%0921	e22	\$	
007003	000224	-01196	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$	007007	001037	-00759	0531	0500	0625	0406	0500	0375	0000	%0598	e14	\$	007107	000819	000417	0625	0500	0531	0375	0600	0468	0000	%0922	e23	\$	
005962	000238	-02025	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$	006279	002073	-01805	0562	0375	0625	0437	0625	0375	0000	%0599	e15	\$	006217	001458	001208	0625	0375	0437	0375	0625	0562	0000	%0923	e24	\$	
005123	000232	-02726	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$	005334	003220	-01409	0531	0250	0625	0468	0750	0375	0000	%0600	e16	\$	005178	002646	001639	0625	0250	0343	0375	0750	0656	0000	%0924	e25	\$	
004546	000332	-03325	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$	004303	004549	-01697	0500	0100	0125	0625	0500	0875	0375	0000	%0601	e17	\$	004273	003866	00202										

```
%BEG GE06_22_REM.TXT, Separation cmyn62*, D65, adapted S
%100 x LAB*a      %1000 x (r g b c m y o)      %nr. pos S
%Z004556 006172 003892 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009153 -01396 008449 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005814 -06103 003645 %1000 1000 0000 0000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005429 -03113 -04023 %1000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003181 002707 -04166 %1000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004629 007236 -00970 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001574 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009685 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004556 006172 003892 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009153 -01396 008449 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005814 -06103 003645 %1000 1000 0000 0000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005429 -03113 -04023 %1000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003181 002707 -04166 %1000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004629 007236 -00970 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001574 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009685 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004556 006172 003892 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009153 -01396 008449 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005814 -06103 003645 %1000 1000 0000 0000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005429 -03113 -04023 %1000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003181 002707 -04166 %1000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004629 007236 -00970 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001574 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009685 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005899 004295 005916 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z009006 -02114 008695 %1000 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005871 -05450 001377 %1000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005360 -02531 -04710 %1000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003166 004200 -03344 %1000 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004478 006836 -00093 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001682 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009691 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z007074 002077 007011 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007674 -03514 006581 %1000 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005982 -04665 -00256 %1000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004664 -01102 -04892 %1000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003620 005157 -02562 %1000 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004430 006292 001445 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001786 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009708 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z008243 000078 007844 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006653 -04764 004976 %1000 0000 0750 0000 1000 0000 0000 %0639 j10 %Y75L 1 $
%Z005989 -04001 -01732 %1000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003653 000742 -04677 %1000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004145 006146 -01702 %1000 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004484 006057 002653 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001760 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009793 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```


See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

```
%BEG GE06_22_REM.TXT, Separation cmyn62*, D65, adapted S
%100 x LAB*a      1000 x (r g b   c m y 0)      %nr. pos $
001527 -00012 -00022 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002674 -00019 -00061 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
004526 -00010 -00106 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
005786 -00002 -00091 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
006965 -00004 -00084 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
007932 -00012 -00048 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
008725 -00014 -00006 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
009473 -00004 -00005 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009726 -00004 -00005 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
001498 -00010 -00023 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002625 -00014 -00067 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
004510 -00005 -00109 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
005767 -00000 -00097 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
006939 -00005 -00087 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
007931 -00012 -00038 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
008686 -00013 -00002 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
009469 -00003 -00011 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009728 -00002 -00004 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
001362 -00010 -00028 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002552 -00015 -00041 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
004468 -00004 -00096 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
005744 -00001 -00078 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
006923 -00006 -00069 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
007896 -00009 -00026 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
008701 -00013 -00002 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
009467 -00001 -00017 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009717 -00009 -00023 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
001322 -00013 -00017 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002578 -00015 -00041 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
004468 -00003 -00078 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
005737 -00001 -00063 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
006906 -00007 -00072 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
007865 -00016 -00032 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
008690 -00015 -00009 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
009472 -00001 -00019 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009721 -00001 -00003 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
001906 -00005 -00002 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
002129 -00005 -00021 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
003056 -00005 -00098 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
004075 -00001 -00119 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
004799 -00004 -00096 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
005538 -00006 -00105 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
006236 -00010 -00093 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
006854 -00007 -00081 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
007298 -00005 -00057 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
007789 -00006 -00029 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
008205 -00013 -00010 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
008629 -00016 -00001 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
009031 -00012 -00009 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
009328 -00009 -00005 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
009677 -00000 -00007 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009700 -00000 -00005 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
001867 -00005 -00006 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
002054 -00005 -00008 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
003015 -00005 -00007 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
004071 -00001 -00111 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
004824 -00005 -00004 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
005573 -00007 -00100 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
006237 -00010 -00091 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
006824 -00013 -00086 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
007289 -00015 -00075 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
007738 -00017 -00059 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
008141 -00019 -00022 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
008574 -00020 -00009 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
008985 -00014 -00004 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
009299 -00014 -00001 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
009678 -00002 -00004 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009716 -00001 -00001 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
001670 -00003 -00011 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
001946 -00001 -00001 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002986 -00001 -00085 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
004019 -00002 -00096 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
004774 -00011 -00087 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
005510 -00010 -00088 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
006203 -00014 -00085 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
006765 -00015 -00073 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
007271 -00016 -00063 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
007732 -00017 -00040 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
008114 -00019 -00018 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
008595 -00018 -00001 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
008986 -00013 -00010 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE16; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: ->olv* setrgbcolor

TUB registration: 20091101-GE16/GE16L0NP.PDF /.PS
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart GE16; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```

TUB registration: 20091101-GE16/GE16L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/kliaus.richter/GE16/GE16L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.01; nx=1.3

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009705	-00076	000224	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009323	-00519	-00313	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008822	-00960	-00975	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
008240	-01230	-01676	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
007627	-01536	-02359	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
007150	-01866	-02918	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006388	-02151	-03672	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
005689	-02731	-04229	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005193	-03400	-04804	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
009276	-00074	001211	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
009352	-00252	000209	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
009075	-00594	-00582	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
008436	-00850	-01349	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
007835	-01288	-02089	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
007185	-01656	-02754	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
006350	-02022	-03347	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
005645	-02458	-03914	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
005125	-03358	-04811	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
008922	-00058	002040	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
008795	000393	001250	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
008615	-00037	000129	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
008269	-00540	-00670	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
007696	-00826	-01365	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
006900	-01397	-02308	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
006171	-01709	-02984	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
005492	-02182	-03479	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
004971	-03328	-04572	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
008475	-00108	002917	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
008349	000830	002307	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
008086	-000454	001103	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
007826	-00037	000168	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
007331	-00511	-00868	0500	0593	0625	0500	0406	0375	0000	00112	M05	\$
006660	-00972	-01696	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
005883	-01414	-02538	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
005299	-01877	-03194	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
004690	-03802	-04487	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007910	001756	003436	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
007891	001357	002958	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
007641	000838	002039	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
007291	000559	001388	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
006896	-00033	000096	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
006349	-00448	-01077	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
005555	-01075	-02082	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
004989	-01544	-02834	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
004201	-02469	-04267	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
007399	002500	004148	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
007397	002037	003628	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
007085	001381	002880	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
006787	000979	002285	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
006358	000552	001269	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
005889	-00017	000067	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
005314	-00727	-01387	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
004732	-01201	-02368	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003741	-02126	-03775	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
006897	003284	005130	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
006906	002933	004522	0875	0406	0500	0125	0593	0750	0000	00136	P02	\$
006526	002107	003534	0750	0375	0250	0250	0625	0750	0000	00137	P03	\$
006125	001718	002946	0625	0343	0250	0375	0625	0750	0000	00138	P04	\$
005699	001228	002239	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
005239	000601	001338	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
004648	-00003	000053	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
004231	-00859	-01744	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
003416	-02051	-03361	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
006463	004014	006001	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
006372	003876	005729	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
005927	003047	004432	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
005428	002734	004033	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
004972	002131	003302	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
004504	001549	002500	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
004071	000905	001700	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
002979	000018	000019	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
002974	-01664	-02749	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
006049	004797	006191	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
006003	004511	006099	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
005506	004231	005461	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
004692	004001	004458	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
003944	003440	003531	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
003447	002969	002861	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
002914	002368	002015	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
002435	001587	001157	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
001764	000055	000090	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009684	-00073	000210	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
009080	000370	-00248	0800	0875	1000	0093	0125	0000	0000	00406	J11	\$
008339	000829	-00869	0812	0750	1000	0818	0250	0000	0000	00407	J12	\$
007331	001454	-01448	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
006327	001981	-02056	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
005245	002573	-02636	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
004253	003334	-03016	0437	0250	1000	0562	0750	0000	0000	00411	J16	\$
003676	003701	-03081	0530	0250	1000	0875	0875	0000	0000	00412	J17	\$
003202	003556	-03303	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
009649	-00418	001474	0968	1000	0875	0031	0000	0125	0000	00414	J19	\$
009483	-00062	000222	0875	0875	0875	0125	0125	0125	0000	00415	K10	\$
008700	000433	-00610	0781	0750	0875	0218	0250	0125	0000	00416	K11	\$
007842	000965	-01218	0687	0625	0875	0312	0375	0125	0000	00417	K12	\$
006679	001721	-01870	0593	0500	0875	0406	0500	0125	0000	00418	K13	\$
005446	002318	-02607	0500	0375	0875	0500	0625	0125	0000	00419	K14	\$
004390	003091	-03101	0406	0250	0875	0593	0750	0125	0000	00420	K15	\$
003614	003732	-03170	0312	0125	0875	0687	0875	0125	0000	00421	K16	\$
002996	003817	-03141	0218	0000	0875	0781	1000	0125	0000	00422	K17	\$
009551	-00722	002704	0937	1000	0750	0062	0000	0250	0000	00423	K18	\$
0092												

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009717	-000071	000197	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$
009190	-00295	-00442	0875	0937	1000	0125	0062	0000	0000	%0163	S02 \$
008728	-00797	-01054	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$
007899	-00904	-01901	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$
007633	-00885	-02687	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$
006305	-01107	-03335	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$
005518	-01408	-04109	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$
004937	-01848	-04689	0125	0562	1000	0875	0312	0000	0000	%0169	S08 \$
004517	-01929	-05031	0000	0500	1000	1000	0500	0000	0000	%0170	S09 \$
004542	-00058	001466	1000	0937	0875	0000	0062	0125	0000	%0171	T01 \$
009355	-00058	000217	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$
008839	-00280	-00694	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$
008212	-00478	-01434	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$
007452	-00804	-02254	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$
006606	-00992	-03028	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$
005701	-01402	-03922	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$
005007	-01598	-04525	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$
004345	-01638	-05033	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$
009191	-00062	002425	1000	0875	0750	0000	0125	0250	0000	%0180	U01 \$
009005	-000225	001384	0875	0812	0750	0125	0187	0250	0000	%0181	U02 \$
008590	-00048	000109	0750	0750	0750	0250	0250	0250	0000	%0182	U03 \$
007979	-00278	-00770	0625	0687	0750	0375	0312	0250	0000	%0183	U04 \$
007262	-00319	-01481	0500	0625	0750	0500	0375	0250	0000	%0184	U05 \$
006384	-00774	-02344	0375	0562	0750	0625	0437	0250	0000	%0185	U06 \$
005644	-01039	-03033	0250	0500	0750	0750	0500	0250	0000	%0186	U07 \$
005028	-01374	-03736	0125	0437	0750	0875	0562	0250	0000	%0187	U08 \$
004268	-01467	-05003	0000	0375	0750	1000	0625	0250	0000	%0188	U09 \$
008744	-00054	003157	1000	0812	0625	0000	0187	0375	0000	%0189	V01 \$
008586	-000415	002536	0875	0750	0625	0125	0250	0375	0000	%0190	V02 \$
008307	-000189	001196	0750	0687	0625	0250	0312	0375	0000	%0191	V03 \$
007788	-00033	000147	0625	0625	0625	0375	0375	0375	0000	%0192	V04 \$
007123	-00237	-00942	0500	0562	0625	0500	0437	0375	0000	%0193	V05 \$
006302	-00400	-01767	0375	0562	0625	0625	0625	0375	0000	%0194	V06 \$
005525	-00812	-02590	0250	0437	0625	0750	0562	0375	0000	%0195	V07 \$
004904	-01089	-03234	0125	0375	0625	0875	0625	0375	0000	%0196	V08 \$
003911	-01290	-04657	0000	0312	0625	1000	0687	0375	0000	%0197	V09 \$
008454	-000796	004151	1000	0750	0500	0000	0250	0500	0000	%0198	W01 \$
008266	-000719	003366	0875	0687	0500	0125	0312	0500	0000	%0199	W02 \$
007939	-000443	002616	0750	0625	0500	0250	0375	0500	0000	%0200	W03 \$
007513	-000234	001188	0625	0562	0500	0375	0437	0500	0000	%0201	W04 \$
006883	-000362	000093	0500	0500	0500	0500	0500	0500	0000	%0202	W05 \$
006166	-00192	-01213	0375	0437	0500	0625	0562	0500	0000	%0203	W06 \$
005462	-00599	-02186	0250	0375	0500	0750	0625	0500	0000	%0204	W07 \$
004286	-00844	-02919	0125	0312	0500	0875	0687	0500	0000	%0205	W08 \$
003536	-01019	-04283	0000	0250	0500	1000	0750	0500	0000	%0206	W09 \$
008107	-001249	004720	1000	0687	0375	0000	0312	0625	0000	%0207	X01 \$
008027	-001078	004182	0875	0625	0375	0125	0375	0625	0000	%0208	X02 \$
007619	-000718	003397	0750	0562	0375	0250	0437	0625	0000	%0209	X03 \$
007172	-000513	002571	0625	0500	0375	0375	0500	0625	0000	%0210	X04 \$
006564	-000205	001361	0500	0437	0375	0500	0562	0625	0000	%0211	X05 \$
005963	-000019	000062	0375	0375	0375	0625	0625	0625	0000	%0212	X06 \$
005092	-00402	-01427	0250	0312	0375	0750	0687	0625	0000	%0213	X07 \$
004493	-00708	-02377	0125	0250	0375	0875	0750	0625	0000	%0214	X08 \$
003238	-00966	-03876	0000	0187	0375	1000	0812	0625	0000	%0215	X09 \$
007753	-001741	005548	1000	0625	0250	0000	0375	0750	0000	%0216	Y01 \$
007664	-001546	004798	0875	0562	0250	0125	0437	0750	0000	%0217	Y02 \$
007208	-001112	004998	0750	0500	0250	0250	0500	0750	0000	%0218	Y03 \$
006713	-000660	003532	0625	0437	0250	0375	0500	0750	0000	%0219	Y04 \$
006113	-000641	002614	0500	0375	0250	0500	0625	0750	0000	%0220	Y05 \$
005401	-000297	001471	0375	0312	0250	0625	0687	0750	0000	%0221	Y06 \$
004584	-000802	000036	0250	0250	0250	0750	0750	0750	0000	%0222	Y07 \$
003957	-00518	-01814	0125	0187	0250	0875	0812	0750	0000	%0223	Y08 \$
003044	-01095	-03440	0000	0125	0250	1000	0875	0750	0000	%0224	Y09 \$
007456	-002164	006618	1000	0562	0125	0000	0437	0875	0000	%0225	Z01 \$
007372	-002018	006409	0875	0500	0125	0125	0125	0800	0875	%0226	Z02 \$
006851	-001696	005463	0750	0437	0125	0250	0562	0875	0000	%0227	Z03 \$
006208	-001500	004779	0625	0375	0125	0375	0625	0875	0000	%0228	Z04 \$
005641	-001013	003908	0500	0312	0125	0500	0687	0875	0000	%0229	Z05 \$
004948	-000816	003018	0375	0250	0125	0625	0750	0875	0000	%0230	Z06 \$
004369	-000382	001000	0250	0187	0125	0750	0812	0875	0000	%0231	Z07 \$
002924	-000014	000024	0125	0125	0125	0875	0875	0875	0000	%0232	Z08 \$
002806	-01045	-02296	0000	0062	0125	1000	0937	0875	0000	%0233	Z09 \$
007180	-002647	007157	1000	0500	0000	0000	0500	1000	0000	%0234	A01 \$
007024	-002585	007002	0875	0437	0000	0125	0562	1000	0000	%0235	A02 \$
006506	-002294	003600	0750	0375	0000	0250	0625	1000	0000	%0236	A03 \$
005525	-002071	005265	0625	0312	0000	0375	0687	1000	0000	%0237	A04 \$
004613	-001824	004078	0500	0250	0000	0500	0750	1000	0000	%0238	A05 \$
003971	-001630	003346	0375	0187	0000	0625	0812	1000	0000	%0239	A06 \$
003274	-001372	002368	0250	0125	0000	0750	0875	1000	0000	%0240	A07 \$
002633	-000985	001348	0125	0062	0000	0875	0937	1000	0000	%0241	A08 \$
001904	-000053	000090	0000	0000	0000	1000	1000	1000	0000	%0242	A09 \$
009706	-00073	000224	1000	1000	1000	0000	0000	0000	0000	%0486	S10 \$
009166	-000540	-00195	0937	0875	1000	0062	0125	0000	0000	%0487	S11 \$
008464	-001147	-00632	0875	0750	1000	0125	0250	0000	0000	%0488	S12 \$
007664	-002017	-00963	0812	0625	1000	0187	0375	0000	0000	%0489	S13 \$
006699	-002802	-01427	0750	0500	1000	0250	0500	0000	0000	%0490	S14 \$
005735	-003513	-01861	0687	0375	1000	0312	0625	0000	0000	%0491	S15 \$
004847	-004115	-02278	0625	0250	1000	0375	0750	0000	0000	%0492	S16 \$
004111	-004765	-02735	0562	0250	1000	0875	0875	0000	0000	%0493	S17 \$
003705	-005035	-02219	0500	1000	0500	1000	0500	0000	0000	%0494	S18 \$
009550	-00536	001330	0937	1000	0875	0062	0000	0125	0000	%0495	T10 \$
009475	-00061	000220	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$
008749	-000658	-00511	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$
008027	-001275	-00949	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$
007056	-002188	-01389	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$
006011	-003134	-01810	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$
004909	-003876	-02326	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$
004051	-004643	-02409	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$
003522	-004804	-02251	0437	0000	0750	0562	1000	0125	0000	%0503	T18 \$
009372	-00930	002296	0875	1000	0750	0125	0000	0250	0000	%0504	T19 \$
009223	-00580	001284	0812	0875	0750	0187	0125	0250	0000	%0505	U11 \$
008710	-00042	000206	0750	0750	0750	0250	0250	0250	0000	%0506	U12 \$
007895	-000769	-00581	0687	0625	0750	0312	0375	0250	0000	%0507	U13 \$
007043	-001504	-01066	0625	0500	0750	0375	0500	0250	0000	%0508	U14 \$
006165											

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009710	-00073	000212	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
009127	-00112	-00448	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008548	-00285	-01072	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
007506	-00154	-01974	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
006481	000089	-02710	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
005481	000434	-03347	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$
004643	004075	-03967	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
003985	000210	-04494	0125	0343	1000	0875	0562	0000	0000	%0250	b08	\$
003550	000075	-04724	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
009576	-00249	-001528	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
009365	-00061	000228	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
008757	-00067	-00678	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
007917	000115	-01513	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
007042	-00102	-01280	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
005883	000046	-03194	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
004762	000094	-04023	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
004061	-00097	-04545	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
003531	000008	-04680	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
003041	-00196	-002633	1000	0937	0750	0000	0602	0250	0000	%0261	d01	\$
009162	-00060	-001459	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
008615	-00040	000172	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$
007906	-00038	-000660	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
006940	-000158	-01592	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
005952	000007	-02539	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
005161	000083	-03393	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
004403	-00058	-04184	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
003390	-00021	-04526	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
009138	-00082	003502	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
009028	-00080	-002808	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
008545	-00009	001341	0750	0718	0875	0625	0250	0281	0375	%0272	e03	\$
007848	-00036	-000635	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
006988	000094	-01048	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
005930	000043	-01021	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$
005075	000009	-02661	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$
004481	-00035	-03297	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
003180	-00109	-04307	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
008913	000109	-004275	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
008769	000081	-003686	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
008390	-00070	-002766	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
007767	-00016	-001428	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
006938	-00035	-000082	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
005989	000088	-01313	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
005080	-00041	-02160	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
004375	000091	-02923	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
002988	000168	-04055	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
008740	000252	-004961	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
008545	000202	-004579	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
008118	000100	-003771	0750	0656	0375	0250	0343	0625	0000	%0290	g03	\$
007551	000007	-002862	0625	0562	0375	0375	0437	0625	0000	%0291	g04	\$
006849	-00100	-001568	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
005863	-00019	-000068	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
004885	-00004	-01643	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
004155	-00072	-02480	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
002806	000029	-03749	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
008591	000386	-005605	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
008373	000297	-005608	0875	0718	0500	0125	0281	0750	0000	%0298	h02	\$
007975	000100	-004769	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
007325	000070	-004054	0625	0531	0250	0375	0437	0750	0000	%0300	h04	\$
006600	-00070	-003048	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
005717	-00061	-001653	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
004615	-00007	-000037	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
003769	-00015	-01880	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
002590	-00087	-03068	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
008472	000459	-006732	1000	0781	0125	0000	0218	0875	0000	%0306	i01	\$
008212	000578	-007106	0875	0687	0125	0125	0312	0875	0000	%0307	i02	\$
007729	000478	-006545	0750	0593	0125	0250	0406	0875	0000	%0308	i03	\$
007078	000309	-005738	0625	0500	0125	0375	0500	0875	0000	%0309	i04	\$
006272	000160	-004517	0500	0406	0125	0500	0593	0875	0000	%0310	i05	\$
005505	000061	-003466	0375	0312	0125	0625	0687	0875	0000	%0311	i06	\$
004669	-00041	-002139	0250	0218	0125	0750	0781	0875	0000	%0312	i07	\$
002996	000015	-000021	0125	0125	0125	0875	0875	0875	0000	%0313	i08	\$
002461	-00122	-02246	0000	0031	0125	1000	0968	0875	0000	%0314	i09	\$
008314	000664	-007902	1000	0750	0000	0000	0250	1000	0000	%0315	j01	\$
008176	000886	-008189	0875	0656	0000	0125	0343	1000	0000	%0316	j02	\$
007587	000805	-007465	0750	0562	0000	0250	0437	1000	0000	%0317	j03	\$
006509	000682	-006381	0625	0468	0000	0375	0531	1000	0000	%0318	j04	\$
005382	-00020	-005102	0500	0375	0000	0500	0625	1000	0000	%0319	j05	\$
004535	-000473	-004084	0375	0281	0000	0625	0718	1000	0000	%0320	j06	\$
003689	000413	-003990	0250	0187	0000	0750	0812	1000	0000	%0321	j07	\$
002757	000553	-001768	0125	0093	0000	0875	0906	1000	0000	%0322	j08	\$
001907	000047	-000085	0000	0000	0000	1000	1000	1000	0000	%0323	j09	\$
009706	-00069	-000195	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
009234	000649	-00103	0968	0875	1000	0031	0125	0000	0000	%0568	b11	\$
008597	0001514	-00393	0937	0750	1000	0602	0250	0000	0000	%0569	b12	\$
007978	0002252	-00591	0968	0625	1000	0093	0375	0000	0000	%0570	b13	\$
007177	003107	-00909	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
006267	004010	-01250	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
005515	004900	-01414	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
004791	005769	-01389	0781	0250	1000	0237	0875	0000	0000	%0574	b17	\$
004276	006117	-01267	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
004045	-00664	-000108	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$
003945	-00059	-000059	00205	0875	0875	0125	0125	0125	0000	%0577	c11	\$
003826	000792	-00385	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
003820	001591	-00666	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
007382	002571	-00961	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
006410	003602	-01323	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
005556	004602	-01496	0781	0250	0875	0281	0750	0125	0000	%0582	c16	\$
004736	005583	-01449	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
004093	005817	-01340	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
009246	-01009	-001855	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$
009261	-00727	-001076	0781	0875	0750	0218	0125	0250</				

%BEG GE06_22_REM.TXT, Separation cmyn62*, D50, not adapted S
%100 x LAB* %1000 x (r g b c m y o) %nr. pos S
%Z004748 006516 004326 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 \$
%Z009202 -00822 008457 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 \$
%Z005739 -05672 003424 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 \$
%Z005272 -03854 -04198 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 \$
%Z003146 002277 -04054 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 \$
%Z004805 007258 -00429 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 \$
%Z001577 000060 000113 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 \$
%Z009686 -00073 000207 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 \$
%S
%Z004748 006516 004326 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 \$
%Z009202 -00822 008457 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 \$
%Z005739 -05672 003424 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 \$
%Z005272 -03854 -04198 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 \$
%Z003146 002277 -04054 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 \$
%Z004805 007258 -00429 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 \$
%Z001577 000060 000113 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 \$
%Z009686 -00073 000207 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 \$
%S
%Z004748 006516 004326 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 \$
%Z009202 -00822 008457 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 \$
%Z005739 -05672 003424 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 \$
%Z005272 -03854 -04198 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 \$
%Z003146 002277 -04054 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 \$
%Z004805 007258 -00429 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 \$
%Z001577 000060 000113 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 \$
%Z009686 -00073 000207 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 \$
%S
%Z006049 004797 006191 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 \$
%Z009042 -01544 008666 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 \$
%Z005782 -05243 001216 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 \$
%Z005193 -03409 -04894 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 \$
%Z003202 003956 -03098 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 \$
%Z004655 006935 000425 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 \$
%Z001685 000059 000101 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 \$
%Z009692 -00074 000220 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 \$
%S
%Z007180 002647 007157 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 \$
%Z007667 -02977 006474 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 \$
%Z005882 -04684 -00392 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 \$
%Z004517 -01929 -05031 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 \$
%Z003705 005035 -02219 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 \$
%Z004609 006518 001920 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 \$
%Z001789 000058 000103 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 \$
%Z009709 -00071 000205 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 \$
%S
%Z008314 000664 007902 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 \$
%Z006611 -04272 004811 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 \$
%Z005873 -04270 -01864 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 \$
%Z003550 000075 -04724 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 \$
%Z004276 006117 -01267 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 \$
%Z004666 006356 003098 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 \$
%Z001762 000055 000100 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 \$
%Z009704 -00071 000204 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 \$
%S

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cf1=1.00; nt=

KDEG GE06_22_REM.TXT, Separation cmyn62*, D50, not adapted \$																			
100 x LAB	1000 x (r g b c m y o)								%nr.	pos \$									
001529 000339 000183 0000 0800 1000 1000 0000	000972	k01	\$	000335	-00053	000206	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$			
002675 000005 000035 0125 0125 0125 0875 0875 0875	000967	k02	\$	000677	-00071	000206	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$			
004526 -00019 000017 0250 0250 0250 0750 0750 0750	000970	k03	\$	000970	-00075	000208	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$			
005486 -00026 000050 0375 0375 0375 0625 0625 0625	000974	k04	\$	001537	000050	000102	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$			
006965 -00036 000073 0500 0500 0500 0500 0500 0500	000976	k05	\$	001917	000054	000089	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$			
007933 -00035 000132 0625 0625 0625 0375 0375 0375	000977	k06	\$	002959	000014	000029	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$			
008726 -00041 000176 0750 0750 0750 0250 0250 0250	000978	k07	\$	004067	000008	000029	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$			
009474 -00060 000198 0875 0875 0875 0125 0125 0125	000979	k08	\$	004779	000004	000009	0266	0266	0266	0733	0733	0733	0000	%1060	n14	\$			
009727 -00072 000200 1000 1000 1000 0000 0000 0000	000980	k09	\$	005516	-00009	000005	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$			
001500 000043 000184 0000 0000 0000 1000 1000 0000	000981	l01	\$	006184	-00012	000008	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$			
002625 000010 000028 0125 0125 0125 0875 0875 0875	000982	l02	\$	006747	-00022	000103	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$			
004510 -00013 000014 0250 0250 0250 0750 0750 0750	000983	l03	\$	007267	-00028	000616	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$			
005697 -00025 000044 0375 0375 0375 0625 0625 0625	000984	l04	\$	007722	-00030	000146	0600	0600	0600	0399	0399	0399	0000	%1065	n19	\$			
006339 -00034 000070 0500 0500 0500 0500 0500 0500	000985	l05	\$	008100	-00028	000167	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$			
007932 -00035 000133 0625 0625 0625 0375 0375 0375	000986	l06	\$	008528	-00034	000180	0733	0733	0733	0266	0266	0266	0000	%1067	n21	\$			
008688 -00040 000180 0750 0750 0750 0250 0250 0250	000987	l07	\$	008996	-00041	000202	0800	0800	0800	0199	0199	0199	0000	%1068	n22	\$			
009470 -00060 000203 0875 0875 0875 0125 0125 0125	000988	l08	\$	009308	-00051	000212	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$			
009729 -00071 000200 1000 1000 1000 0000 0000 0000	000989	l09	\$	009662	-00065	000187	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$			
001365 000045 000086 0000 0000 0000 1000 1000 0000	000990	m01	\$	009716	-00069	000191	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$			
002553 000013 000053 0125 0125 0125 0875 0875 0875	000991	m02	\$	001615	000049	000083	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$			
003688 -00028 000028 0250 0250 0250 0750 0750 0750	000992	m03	\$	000706	-00068	000195	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$			
005746 -00020 000029 0375 0375 0375 0625 0625 0625	000993	m04	\$	004729	006437	004153	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$			
006924 -00031 000088 0500 0500 0500 0500 0500 0500	000994	m05	\$	005325	-04097	-03955	0000	1000	1000	1000	0000	0000	0000	%1075	l27	\$			
007897 -00036 000144 0625 0625 0625 0375 0375 0375	000995	m06	\$	000199	-00790	008662	1000	1000	0000	0000	0000	1000	0000	%1076	m26	\$			
008783 -00040 000185 0750 0750 0750 0250 0250 0250	000996	m07	\$	003131	002297	-04167	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$			
009468 -00061 000209 0875 0875 0875 0125 0125 0125	000997	m08	\$	005664	-05925	003539	1000	1000	0000	1000	0000	1000	0000	%1078	n26	\$			
009718 -00075 000218 1000 1000 1000 0000 0000 0000	000998	m09	\$	004747	007306	-00542	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$			
001324 000042 000095 0100 0000 0000 1000 1000 0000	000999	n01	\$																
002579 000013 000054 0125 0125 0125 0875 0875 0875	001000	n02	\$	%004729	006437	004153	%#1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$			
004468 -00066 000044 0125 0250 0250 0750 0750 0750	001001	n03	\$	%0009199	-00790	008662	%#1000	1000	0000	0000	0000	1000	0000	%1076	m26	\$			
005737 -00018 000077 0375 0375 0375 0625 0625 0625	001002	n04	\$	%005664	-05925	003539	%#0000	1000	0000	1000	0000	1000	0000	%1078	n26	\$			
006906 -00030 000085 0500 0500 0500 0500 0500 0500	001003	n05	\$	%005325	-04097	-03955	%#0000	1000	1000	1000	0000	0000	0000	%1075	l26	\$			
007867 -00030 000138 0625 0625 0625 0375 0375 0375	001004	n06	\$	%0003131	002297	-04167	%#0000	0000	1000	1000	1000	0000	0000	%1077	m26	\$			
008692 -00037 000186 0750 0750 0750 0250 0250 0250	001005	n07	\$	%0004747	007306	-00542	%#1000	0000	1000	0000	1000	0000	0000	%1079	n26	\$			
009473 -00061 000212 0875 0875 0875 0125 0125 0125	001006	n08	\$	%0001615	000049	000083	%#0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$			
009721 -00067 000192 1000 1000 1000 0000 0000 0000	001007	n09	\$	%0009706	-00068	000195	%#1000	1000	1000	0000	0000	0000	0000	%1073	k26	\$			
001908 000049 000085 0000 0000 0000 1000 1000 0000	001008	k10	\$																
002121 000043 000068 0066 0066 0066 0933 0933 0933	001009	k11	\$	%0001719	000044	000094	%#0000	0000	0000	1000	1000	1000	0000	%0972	k09	\$			
003057 000009 000004 0133 0133 0133 0866 0866 0866	001010	k12	\$	%0009714	-00071	000195	%#1000	1000	1000	0000	0000	0000	0000	%0980	k08	\$			
004075 -00002 -00001 0200 0200 0200 0800 0800 0800	001011	k13	\$																
004799 -00006 000031 0266 0266 0266 0733 0733 0733	001012	k14	\$	%0001685	000047	000099	%#0000	0266	0733	1000	1000	1000	0000	%0981	l06	\$			
005538 -00016 000033 0333 0333 0333 0666 0666 0666	001013	k15	\$	%0009723	-00070	000197	%#1000	1000	1000	0000	0000	0000	0000	%0989	l06	\$			
006236 -00020 000055 0400 0400 0400 0600 0600 0600	001014	k16	\$																
006854 -00031 000075 0466 0466 0466 0533 0533 0533	001015	k17	\$	%0001518	000049	000101	%#0000	0000	0000	1000	1000	1000	0000	%0990	m06	\$			
007298 -00036 000105 0533 0533 0533 0466 0466 0466	001016	k18	\$	%0009714	-00075	000213	%#1000	1000	1000	0000	0000	0000	0000	%0998	k08	\$			
008010 -00038 000140 0600 0600 0600 0399 0399 0399	001017	k19	\$																
008248 -00045 000064 0666 0666 0666 0333 0333 0333	001018	k20	\$	%0001431	000046	000099	%#0000	0000	0000	1000	1000	1000	0000	%0999	n06	\$			
008631 -00036 000183 0733 0733 0733 0266 0266 0266	001019	k21	\$	%0009719	-00068	000191	%#1000	1000	1000	0000	0000	0000	0000	%1007	n06	\$			
009032 -00044 000196 0800 0800 0800 0199 0199 0199	001020	k22	\$																
009329 -00052 000197 0866 0866 0866 0133 0133 0133	001021	k23	\$																
009678 -00067 000187 0933 0933 0933 0066 0066 0066	001022	k24	\$																
009701 -00069 000189 1000 1000 1000 0000 0000 0000	001023	k25	\$																
001069 000052 000093 0000 0000 0000 1000 1000 0000	001024	l10	\$																
002056 000046 000081 0066 0066 0066 0933 0933 0933	001025	l11	\$																
003015 000010 000015 0133 0133 0133 0866 0866 0866	001026	l12	\$																
004071 -00003 000006 0200 0200 0200 0800 0800 0800	001027	l13	\$																
004825 -00005 000034 0266 0266 0266 0733 0733 0733	001028	l14	\$																
005573 -00014 000038 0333 0333 0333 0666 0666 0666	001029	l15	\$																
006237 -00019 000056 0400 0400 0400 0600 0600 0600	001030	l16	\$																
006825 -00025 000069 0466 0466 0466 0533 0533 0533	001031	l17	\$																
007289 -00028 000087 0533 0533 0533 0466 0466 0466	001032	l18	\$																
007738 -00029 000118 0600 0600 0600 0399 0399 0399	001033	l19	\$																
008142 -00029 000152 0666 0666 0666 0333 0333 0333	001034	l20	\$																
008575 -00033 000172 0733 0733 0733 0266 0266 0266	001035	l21	\$																
008987 -00042 000191 0800 0800 0800 0199 0199 0199	001036	l22	\$																
009300 -00048 000189 0866 0866 0866 0133 0133 0133	001037	l23	\$																
009679 -00065 000190 0933 0933 0933 0066 0066 0066	001038	l24	\$																
009717 -00070 000194 1000 1000 1000 0000 0000 0000	001039	l25	\$																
001672 000053 000095 0000 0000 0000 1000 1000 0000	001040	m10	\$																
001948 000045 000086 0066 0066 0066 0933 0933 0933	001041	m11	\$																
002087 000015 000013 0133 0133 0133 0866 0866 0866	001042	m12	\$																
002090 000020 0200 0200 0200 0800 0800 0800	001043	m13	\$																
004774 000002 000040 0266 0266 0266 0733 0733 0733	001044	m14	\$																
005511 -00009 000049 0333 0333 0333 0666 0666 0666	001045	m15	\$																
006203 -00014 000062 0400 0400 0400 0600 0600 0600	001046	m16	\$																
006766 -00021 000082 0466 0466 0466 0533 0533 0533	001047	m17	\$																
007271 -00025 000099 0533 0533 0533 0466 0466 0466	001048	m18	\$																
007733 -00028 000126 0600 0600 0600 0399 0399 0399	001049	m19	\$																
008116 -00028 000159 0666 0666 0666 0333 0333 0333	001050	m20	\$																
008597 -00033 000183 0733 0733 0733 0266 0266 0266	001051	m21	\$																
008988 -00043 000197 0800 0800 0800 0199 0199 0199	001052	m22	\$																

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009705	000000	000004	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009323	-00451	-00528	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008822	-00899	-01182	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
008240	-01179	-01874	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
007627	-01496	-02548	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
007150	-01834	-03101	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006388	-02132	-03843	0250	0810	1000	0750	0187	0000	0000	00087	J07	\$
005689	-02723	-04390	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005193	-03410	-05047	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
004276	-03832	-06097	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
003932	-00016	-00905	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
009075	-00529	-00793	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
008436	-00796	-01559	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
007835	-01245	-02282	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
007180	-01624	-02937	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
006350	-02093	-03517	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
005645	-02451	-04074	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
005125	-03360	-04964	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
004922	-000620	-001831	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
008795	-000453	-001043	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
008615	-000019	-00011	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
008269	-00489	-00870	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
007696	-00784	-01556	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
006900	-01369	-02487	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
006171	-01694	-03152	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
005492	-02177	-03637	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
004971	-03333	-04722	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
008475	-001063	-002715	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
008349	-000882	-002107	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
008086	-000502	-000907	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
007825	-000905	-00204	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
007331	-00476	-01053	0500	0593	0625	0500	0406	0375	0000	00112	M05	\$
006660	-00948	-01878	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
005883	-01493	-02702	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
005299	-01875	-03349	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
004690	-03831	-04633	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007910	-001801	-003242	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
007891	-001401	-002766	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
007641	-000879	-002120	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
007291	-000593	-000853	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
006896	-00905	-00082	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
006349	-00429	-01248	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
005555	-01070	-02241	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
004989	-01548	-02984	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
004201	-02486	-04406	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
007399	-002536	-003961	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
007397	-002073	-003442	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
007085	-001412	-002698	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
006787	-001006	-002108	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
006358	-000571	-001098	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
005889	-00006	-00096	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
005314	-00726	-01542	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
004732	-01209	-02515	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003741	-02151	-03907	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
006897	-003312	-004951	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
006906	-002961	-004343	0875	0406	0500	0125	0593	0750	0000	00136	P02	\$
006526	-002129	-003361	0750	0375	0250	0250	0625	0750	0000	00137	P03	\$
006125	-001723	-002778	0625	0343	0250	0375	0656	0750	0000	00138	P04	\$
005690	-001236	-002077	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
005239	-000601	-001184	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
004648	-00012	-00092	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
004231	-00676	-01884	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
003416	-02832	-03488	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
006463	-004035	-005828	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
006372	-003896	-005558	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
005927	-003059	-004268	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
005428	-002738	-003846	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
004972	-002126	-003151	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
004504	-001537	-002357	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
004071	-000885	-001563	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
002979	-00019	-00101	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
002974	-01702	-02870	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
006049	-004811	-006025	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
006003	-004524	-005933	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
005506	-004236	-005303	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
004692	-003992	-004312	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
003944	-003419	-003396	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
003447	-002939	-002733	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
002914	-002329	-001895	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
002435	-001540	-001044	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
001766	-00012	-00012	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009684	000003	-00009	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
009080	000435	-00559	0875	1000	0093	0125	0000	0000	0000	00406	J11	\$
008339	000882	-01069	0812	0750	1000	0812	0250	0000	0000	00407	J12	\$
007331	001489	-01634	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
006327	001999	-02226	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
005245	002573	-02790	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
004253	003317	-03155	0437	0250	1000	0562	0750	0000	0000	00411	J16	\$
003676	003765	-03265	0343	0250	1000	0875	0875	0000	0000	00412	J17	\$
003202	003822	-03222	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
002449	-00344	-001254	0068	1000	0875	0031	0000	0125	0000	00414	K10	\$
009483	000008	000005	0875	0875	0875	0125	0125	0125	0000	00415	K11	\$
008700	000491	-00816	0781	0750	0875	0218	0250	0125	0000	00416	K12	\$
007842	001008	-01411	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
006679	001746	-02046	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
005446	002322	-02764	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
004390	003076	-03242	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
003614	003705	-03309	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
002996	003780	-03262	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
009551	-00649	-002486	0937	1000	0750	0062	0000	0250	0000	00423	L10	\$
009295												

009717	000000	-00007	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$	009706	-00002	000019	1000	1000	1000	0000	0000	0000	%0486	S10 \$	009703	000001	-000011	1000	1000	1000	0000	0000	0000	0000	0000	%0810	S19 \$
009190	-00232	-00641	0875	0937	1000	0125	0062	0000	0000	%0163	S02 \$	009166	-000603	-00393	0937	0875	1000	0062	0125	0000	0000	%0487	S11 \$	009205	000778	-00035	1000	0875	0937	0000	0125	0062	0000	%0811	S20 \$
008728	-00741	-01246	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$	008464	-001198	-00821	0875	0750	1000	0125	0250	0000	0000	%0488	S12 \$	008587	001567	-000185	1000	0750	0875	0000	0250	0125	0000	%0812	S21 \$
007899	-00862	-02083	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$	007664	-002054	-01142	0812	0625	1000	0187	0375	0000	0000	%0489	S13 \$	008080	002319	000503	1000	0625	0812	0000	0375	0187	0000	%0813	S22 \$
007633	-00958	-02858	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$	006699	-002824	-01594	0750	0500	1000	0250	0500	0000	0000	%0490	S14 \$	007392	003137	000885	1000	0500	0750	0000	0500	0250	0000	%0814	S23 \$
006305	-01092	-03496	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$	005735	-003519	-02015	0687	0375	1000	0312	0625	0000	0000	%0491	S15 \$	006630	004306	001329	1000	0375	0687	0000	0625	0312	0000	%0815	S24 \$
005518	-01477	-04260	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$	004847	-004107	-02421	0625	0250	1000	0375	0750	0000	0000	%0492	S16 \$	005801	005698	001688	1000	0250	0625	0000	0750	0375	0000	%0816	S25 \$
004937	-01847	-04823	0125	0562	1000	0875	0500	0000	0000	%0169	S08 \$	004111	-005784	-02478	0562	0125	1000	0500	0875	0000	0000	%0493	S17 \$	005124	006881	001903	1000	0125	0562	0000	0875	0437	0000	%0817	S26 \$
004517	-01943	-05169	0000	0500	1000	1000	0500	0000	0000	%0170	S09 \$	003705	-005008	-02347	0500	1000	1000	0500	1000	0000	0000	%0494	S18 \$	004609	006505	001730	1000	0000	0500	0000	1000	0500	0000	%0818	S27 \$
003452	-000609	-001264	1000	0937	0875	0000	0062	0125	0000	%0171	T01 \$	009550	-00467	-001127	0937	1000	0875	0062	0000	0125	0000	%0495	T10 \$	009312	-00575	-00125	0875	1000	0937	0125	0000	0062	0000	%0819	T19 \$
003355	-000607	-000017	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$	009475	-000066	-000017	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$	009427	000011	-000001	0875	0875	0875	0125	0125	0125	0000	%0820	T20 \$
008839	-00223	-00888	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$	008749	-000713	-00704	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$	008622	000971	000138	0875	0750	0812	0125	0250	0187	0000	%0821	T21 \$
008212	-00431	-01628	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$	008029	-001319	-01132	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$	008080	001707	000439	0875	0625	0750	0125	0375	0250	0000	%0822	T22 \$
007452	-00770	-02439	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$	007056	-002216	-01560	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$	006729	002668	000658	0875	0500	0687	0125	0500	0312	0000	%0823	T23 \$
006606	-00972	-03193	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$	006011	-003145	-01968	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$	006739	003819	001246	0875	0375	0625	0125	0625	0375	0000	%0824	T24 \$
005701	-01396	-04076	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$	004909	-003869	-02470	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$	005965	005064	001605	0875	0250	0562	0125	0750	0437	0000	%0825	T25 \$
005007	-01603	-04670	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$	004051	-004622	-02541	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$	005128	006504	001937	0875	0125	0500	0125	0875	0500	0000	%0826	T26 \$
004345	-01655	-05170	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$	003522	-004774	-02377	0437	0000	0875	0562	1000	0125	0000	%0503	T18 \$	004343	006131	001651	0875	0000	0437	0125	1000	0562	0000	%0827	T27 \$
009191	-00025	-002227	1000	0875	0750	0000	0125	0250	0000	%0180	U01 \$	009372	-008664	-002095	0875	1000	0750	0125	0000	0250	0000	%0504	T19 \$	008862	-01106	-00044	0750	1000	0875	0250	0000	0125	0000	%0828	U19 \$
009005	-000285	-001188	0875	0812	0750	0125	0187	0250	0000	%0181	U02 \$	009223	-00517	-001885	0812	0875	0750	0187	0125	0250	0000	%0505	U11 \$	009134	-00833	-000101	0750	0875	0812	0250	0125	0187	0000	%0829	U20 \$
008590	-000012	-00001	0750	0750	0750	0250	0250	0250	0000	%0182	U03 \$	008710	-000012	-000013	0750	0750	0750	0250	0250	0250	0000	%0506	U12 \$	008613	000015	000004	0750	0750	0750	0250	0250	0250	0000	%0830	U21 \$
007979	-00185	-00952	0625	0687	0750	0375	0312	0250	0000	%0183	U04 \$	007895	-000811	-00762	0687	0625	0750	0312	0375	0250	0000	%0507	U13 \$	007836	001033	000090	0750	0625	0687	0250	0375	0312	0000	%0831	U22 \$
007262	-00348	-01655	0500	0625	0750	0500	0375	0250	0000	%0184	U05 \$	007043	-001532	-01237	0625	0500	0750	0375	0500	0250	0000	%0508	U14 \$	007147	001791	000432	0750	0500	0625	0250	0500	0375	0000	%0832	U23 \$
006384	-00757	-02506	0375	0562	0750	0625	0437	0250	0000	%0185	U06 \$	006165	-002309	-01647	0562	0375	0750	0437	0625	0250	0000	%0509	U15 \$	006411	002678	000713	0750	0375	0562	0250	0625	0437	0000	%0833	U24 \$
005644	-01034	-03186	0250	0500	0750	0750	0500	0250	0000	%0186	U07 \$	005209	-003229	-02094	0500	0250	0750	0500	0750	0250	0000	%0510	U16 \$	005565	003802	001140	0750	0250	0500	0250	0750	0500	0000	%0834	U25 \$
005028	-01380	-03882	0125	0437	0750	0875	0562	0250	0000	%0187	U08 \$	004191	-004486	-02417	0437	0125	0750	0562	0875	0250	0000	%0511	U17 \$	004703	000544	001526	0750	0125	0437	0250	0875	0562	0000	%0835	U26 \$
004268	-01485	-05138	0000	0375	0750	1000	0625	0250	0000	%0188	U09 \$	003310	-004428	-02312	0375	0000	0750	0625	1000	0250	0000	%0512	U18 \$	004008	005574	001524	0750	0000	0375	0250	1000	0625	0000	%0836	U27 \$
008744	-006026	-02964	1000	0812	0625	0000	0187	0375	0000	%0189	V01 \$	009148	-01215	-002877	0812	1000	0625	0187	0000	0375	0000	%0513	V10 \$	008456	-01460	-00374	0625	1000	0812	0375	0000	0187	0000	%0837	V19 \$
008586	-000468	-002345	0875	0750	0625	0125	0250	0375	0000	%0190	V02 \$	009145	-00999	-002327	0875	0875	0625	0250	0125	0375	0000	%0514	V11 \$	008595	-01378	-00957	0625	0875	0750	0375	0125	0250	0000	%0838	V20 \$
008307	-000238	-001009	0750	0687	0625	0250	0312	0375	0000	%0191	V03 \$	008599	-00569	-000903	0687	0750	0625	0312	0250	0375	0000	%0515	V12 \$	008435	-00937	-000109	0625	0750	0687	0375	0250	0312	0000	%0839	V21 \$
007788	-000066	-00032	0625	0625	0625	0375	0375	0375	0000	%0192	V04 \$	007906	-000907	-00835	0625	0625	0625	0375	0375	0375	0000	%0516	V13 \$	007824	-000011	-00093	0625	0625	0625	0375	0375	0375	0000	%0840	V22 \$
007123	-00208	-01114	0500	0812	0625	0500	0437	0375	0000	%0193	V05 \$	006980	-000811	-00905	0562	0500	0625	0437	0500	0375	0000	%0517	V14 \$	007048	-001055	-000111	0625	0500	0562	0375	0500	0437	0000	%0841	V23 \$
006302	-00384	-01928	0375	0562	0625	0625	0625	0375	0000	%0194	V06 \$	006116	-001580	-01336	0500	0375	0625	0500	0625	0375	0000	%0518	V15 \$	006286	-001928	-000512	0625	0375	0500	0375	0625	0500	0000	%0842	V24 \$
005525	-00809	-02741	0250	0437	0625	0750	0562	0375	0000	%0195	V07 \$	005171	-000811	-01759	0437	0250	0625	0562	0750	0375	0000	%0519	V16 \$	005346	003003	000887	0625	0500	0437	0375	0750	0562	0000	%0843	V25 \$
004904	-01096	-03378	0125	0375	0625	0875	0625	0375	0000	%0196	V08 \$	004174	-003590	-02148	0375	0125	0625	0625	0875	0375	0000	%0520	V17 \$	004327	-004316	-001273	0625	0125	0375	0375	0875	0625	0000	%0844	V26 \$
003911	-01314	-04788	0000	0312	0625	1000	0687	0375	0000	%0197	V09 \$	003061	-004143	-02088	0312	0000	0625	0687	1000	0375	0000	%0521	V18 \$	003601	-004075										

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-GE16/GE16L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IOB material: code=rha4ta

TUB-test chart GE16; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NP.PDF> / .PS
 Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=

[illegible]

See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

```
%BEG GE06_22_REM.TXT, Separation cmyn62*, D50, adapted S
%100 x LAB*a          %1000 x (r g b c m y o)          %nr.   pos $
%z004748 006507 004175 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z009202 -00757 008256 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z005739 -05664 003262 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005272 -03853 -04355 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z003146 002242 -04185 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z004805 007250 -00580 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z001577 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009686 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W1 7 $
%S
%z004748 006507 004175 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z009202 -00757 008256 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z005739 -05664 003262 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005272 -03853 -04355 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z003146 002242 -04185 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z004805 007250 -00580 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z001577 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009686 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W2 7 $
%S
%z004748 006507 004175 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z009202 -00757 008256 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z005739 -05664 003262 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005272 -03853 -04355 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z003146 002242 -04185 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z004805 007250 -00580 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z001577 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009686 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W001 7 $
%S
%z006049 004811 006025 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z009042 -01480 008455 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005782 -05234 001054 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z005193 -03410 -05047 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003202 003922 -03222 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z004655 006925 000280 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z001685 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009692 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %W251 7 $
%S
%z007180 002677 006984 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z007667 -02939 006295 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005882 -04675 -00548 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z004517 -01943 -05169 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z003705 005008 -02347 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004609 006505 001780 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z001789 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009709 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %W501 7 $
%S
%z008314 000713 007715 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z006611 -04250 004647 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005873 -04260 -02019 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z003550 000048 -04848 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z004276 006102 -01400 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004666 006346 002960 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z001762 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009704 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %W751 7 $
%S
```


See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

```
%BEG GE06_22_REM.TXT, Separation cmyn62*, D50, adapted S
%100 x LAB*a      1000 x (r g b   c m y 0)      %nr. pos $
001529 -00010 000021 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002675 -00028 -00062 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
004526 -00026 -00106 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
005786 -00015 -00090 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
006965 -00007 -00083 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
007933 000006 -00038 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
008726 000013 -00005 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
009474 000004 000006 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
008727 -00004 000006 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
001500 -00002 000023 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002625 -00024 -00068 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
004510 -00020 -00108 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
005767 -00014 -00096 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
006939 -00006 -00086 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
007932 000006 -00036 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
008688 000012 000000 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
009470 000004 000011 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009729 -00002 000004 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
001365 -00006 000027 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002553 -00021 -00042 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
004468 -00018 -00095 0250 0250 0250 0750 0750 0750 0000 %0992 k03 $
005744 -00009 -00077 0375 0375 0375 0625 0625 0625 0000 %0993 k04 $
006924 -00003 -00068 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
007897 000005 -00025 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
008703 000013 000003 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
009468 000003 000017 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009718 -00006 000022 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
001324 -00011 000016 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002579 -00021 -00042 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
004468 -00014 -00078 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
005737 -00007 -00062 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
006905 -00002 -00071 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
007867 000011 -00030 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
008692 000015 000005 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
009473 000003 000020 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009721 000001 -00003 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
001908 000005 -00001 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
002121 000002 -00021 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
003057 -00019 -00098 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
004075 -00015 -00119 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
004799 -00009 -00095 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
005538 -00008 -00104 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
006236 -00002 -00091 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
006854 -00004 -00080 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
007298 -00003 -00056 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
007790 000001 -00028 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
008206 000012 -00009 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
008631 000016 000003 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
009032 000013 000010 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
009329 000010 000006 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
009678 000000 -00007 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009701 000000 -00005 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
001869 000006 000007 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
002056 000004 -00007 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
003015 -00017 -00087 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
004071 -00016 -00110 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
004825 -00008 -00093 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
005573 000009 000003 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
006237 -00001 -00090 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
006825 000001 -00085 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
007289 000004 -00074 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
007738 000010 -00049 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
008142 000016 -00020 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
008575 000018 -00007 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
008987 000015 000005 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
009309 000013 000000 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
009679 000002 -00004 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009717 -00001 -00001 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
001672 000005 000011 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
001948 000001 000000 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002987 -00013 -00085 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
004019 -00011 -00095 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
004774 000000 -00086 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
005511 -00002 -00087 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
006203 000003 -00084 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
006766 000004 -00071 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
007271 000008 -00062 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
007733 000011 -00038 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
008116 000016 -00016 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
008597 000018 000003 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
008988 000014 000011 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE16; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: ->olv* setrgbcolor

TUB registration: 20091101-GE16/GE16L0NP.PDF /.PS
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta