
TUB registration: 20091101-GE18/GE18L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rh4ta

See original or copy: <http://web.me.com/klaus.richter/GE18/GE18L0NA.TXT> / .PSS
 Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0, cfi=1.00; nt=0

X(BEG	GE08(7, 22	REM.TXT	Separation	olvp,	D65,	not adapted	
"100 x LAB"		1000	x (g b c m y g)				%nnr
009272	000010	-060605	1000	1000	0000	0000	0000
009238	-000705	006518	0875	1000	0000	0125	0000
008829	008700	011551	0750	1000	0000	0250	0000
008261	-01619	-017558	0625	1000	0000	0375	0000
007705	-02152	-022700	0500	1000	0000	0500	0000
007201	-02491	-02673	0375	1000	0000	0625	0000
006680	-02777	-03035	0250	1000	0000	0750	0000
006006	-02938	-032423	0125	1000	0000	0875	0000
005272	-02873	-03731	0000	1000	0000	1000	0000
009226	000051	-00549	1000	0875	0875	0000	0125
009170	-00026	-00593	0875	0875	0875	0125	0125
008783	-00843	-01076	0750	0875	0875	0250	0125
008218	-01602	-01696	0625	0875	0875	0375	0125
007684	-02138	-02198	0500	0875	0875	0500	0125
007173	-02492	-02616	0375	0875	0875	0625	0125
006631	-02750	-03004	0250	0875	0875	0750	0125
005974	-02926	-03381	0125	0875	0875	0875	0125
005249	-02875	-03684	0000	0875	0875	1000	0125
005013	000962	-00499	1000	0750	0750	0000	0250
004789	000872	-00511	0875	0750	0750	0125	0250
004714	000872	-00511	0875	0750	0750	0125	0250
007591	-00813	-01579	0625	0750	0750	0375	0250
007114	-01492	-02058	0500	0750	0750	0500	0250
006705	-01959	-02462	0375	0750	0750	0625	0250
006221	-02358	-02825	0250	0750	0750	0750	0250
005640	-02669	-03193	0125	0750	0750	0875	0250
004979	-02747	-03479	0000	0750	0750	1000	0250
007724	001839	-00178	1000	0625	0625	0000	0375
007686	001761	-00182	0875	0625	0625	0125	0375
007349	000887	-00611	0750	0625	0625	0250	0375
006863	-00082	-01192	0625	0625	0625	0375	0375
006430	-00875	-01661	0500	0625	0625	0500	0375
006063	-01465	-02055	0375	0625	0625	0625	0375
005651	-01986	-02422	0250	0625	0625	0750	0375
005132	-02434	-02782	0125	0625	0625	0875	0375
004558	-02629	-03070	0000	0625	0625	1000	0375
006929	002681	-000263	1000	0500	0500	0000	0500
006912	002583	-000277	0875	0500	0500	0125	0500
006565	001709	-00111	0750	0500	0500	0250	0500
006096	000641	-00693	0625	0500	0500	0375	0500
005682	-00238	-01156	0500	0500	0500	0500	0500
005347	-00913	-01573	0375	0500	0500	0625	0500
004966	-01541	-01949	0250	0500	0500	0750	0500
004166	-02103	-02313	0125	0500	0500	0875	0500
003919	-02399	-02607	0000	0500	0500	1000	0500
006100	-003681	-006638	1000	0375	0375	0000	0625
006072	-003534	-006639	0875	0375	0375	0125	0625
005650	-002679	-006231	0750	0375	0375	0250	0625
005252	-001573	-00335	06				

090247	000020	-06622	1000	1000	1000	0000	0000	0000	0000	00324	A10	\$	090241	000009	-06611	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	00648	A19	\$
090183	000002	-06707	0875	0875	1000	0125	0125	0000	0000	00325	A11	\$	090208	000078	-06660	1000	0875	1000	0000	0125	0000	0000	0000	0000	0000	00649	A20	\$
090170	000387	-01867	0750	0750	1000	0250	0250	0000	0000	00326	A11	\$	090525	001276	-01407	1000	0750	1000	0000	0250	0000	0000	0000	0000	0000	00650	A21	\$
090702	000784	-02995	0625	0625	1000	0375	0375	0000	0000	00327	A13	\$	090780	002539	-02138	1000	0625	1000	0000	0375	0000	0000	0000	0000	0000	00651	A22	\$
090581	001316	-03934	0500	0500	1000	0500	0500	0000	0000	00328	A14	\$	090704	003771	-02774	1000	0500	1000	0000	0500	0000	0000	0000	0000	0000	00652	A23	\$
090474	002117	-04758	0375	0375	1000	0625	0625	0000	0000	00329	A15	\$	090617	005048	-03336	1000	0375	1000	0000	0625	0000	0000	0000	0000	0000	00653	A24	\$
0903652	002973	-05509	0250	0250	1000	0750	0750	0000	0000	00330	A16	\$	0905425	006122	-03722	1000	0250	1000	0000	0750	0000	0000	0000	0000	0000	00654	A25	\$
0902403	001452	-06180	0125	0125	1000	0875	0875	0000	0000	00331	A17	\$	0904551	007215	-04001	1000	0125	1000	0000	0875	0000	0000	0000	0000	0000	00655	A26	\$
0901337	005233	-06394	0000	0000	1000	1000	1000	0000	0000	00332	A18	\$	0903710	007910	-03961	1000	0000	1000	0000	1000	0000	0000	0000	0000	0000	00656	A27	\$
0909212	000027	-09536	1000	1000	0875	0000	0000	0125	0000	00333	B10	\$	0909190	-00111	-09533	0875	1000	0875	0125	0000	0125	0000	0000	0000	0000	00657	B19	\$
0909135	000025	-09624	0875	0875	0875	0125	0125	0125	0000	00334	B11	\$	0909152	-00037	-09580	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	00658	B20	\$
0908164	000345	-01752	0750	0750	0875	0250	0250	0125	0000	00335	B12	\$	0908496	001132	-01322	0875	0750	0875	0125	0250	0125	0000	0000	0000	0000	00659	B21	\$
0907008	000735	-02900	0625	0625	0875	0375	0375	0125	0000	00336	B13	\$	0907756	002396	-02061	0875	0625	0875	0125	0375	0125	0000	0000	0000	0000	00660	B22	\$
0905884	001247	-03854	0500	0500	0875	0500	0500	0125	0000	00337	B14	\$	0909885	003631	-02713	0875	0500	0875	0125	0500	0125	0000	0000	0000	0000	00661	B23	\$
0904773	002040	-04697	0375	0375	0875	0625	0625	0125	0000	00338	B15	\$	0906151	004918	-03294	0875	0375	0875	0125	0625	0125	0000	0000	0000	0000	00662	B24	\$
0903669	002922	-05461	0250	0250	0875	0750	0750	0125	0000	003																		

TUB-test chart GE18; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

input: w *setgray*
output: no change compared to input

See original or copy: <http://web.me.com/klaus.richter/GE18/GE18L0NA.TXT> / .PS
 Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

TUB registration: 20091101-GE18/GE18L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

TUB-test chart GE18; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE18/GE18L0NA.TXT> / .PS
 Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=

099274	-006024	-00618	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$
099232	000443	-00668	0875	0937	1000	0125	0062	0000	0000	%0163	S02 \$
008806	-00789	-01184	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$
007964	-01009	-02181	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$
007182	-01073	-02804	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$
006489	-01011	-03381	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$
005795	-00978	-03878	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$
005025	-00999	-04340	0125	0652	1000	0875	0437	0000	0000	%0169	S08 \$
004226	-00596	-04999	0000	0500	1000	1000	0500	0000	0000	%0170	S09 \$
009262	-00015	-00511	1000	0937	0875	0000	0062	0125	0000	%0171	T01 \$
009190	-00026	-00587	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$
009499	-00252	-01422	0750	0812	0875	0250	0187	0250	0000	%0173	T03 \$
007686	-00486	-02295	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$
006806	-00556	-03014	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$
005525	-00583	-04062	0250	0562	0875	0625	0375	0125	0000	%0176	T06 \$
005525	-00583	-04062	0250	0562	0875	0625	0375	0125	0000	%0177	T07 \$
004756	-00397	-04524	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$
003940	-00035	-04893	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$
009186	-00189	-008287	1000	0875	0750	0000	0125	0250	0000	%0180	T09 \$
008842	000272	-0125	0875	0812	0750	0125	0187	0250	0000	%0181	U02 \$
008129	000053	-01003	0750	0750	0750	0250	0250	0250	0000	%0182	U03 \$
007310	-00208	-01923	0625	0687	0750	0375	0312	0250	0000	%0183	U04 \$
006510	-00344	-02682	0500	0625	0750	0500	0375	0250	0000	%0184	U05 \$
005282	-00338	-03295	0375	0562	0750	0625	0437	0250	0000	%0185	U06 \$
005023	-00268	-03856	0250	0500	0750	0750	0500	0250	0000	%0186	U07 \$
004417	-00110	-04393	0125	0437	0750	0875	0562	0250	0000	%0187	U08 \$
003597	000312	-04814	0000	0375	0750	1000	0625	0250	0000	%0188	U09 \$
008802	000052	-001115	1000	0812	0625	0000	0187	0375	0000	%0189	V01 \$
008446	000512	-000696	0875	0750	0625	0125	0250	0375	0000	%0190	V02 \$
007732	-00268	-00206	0750	0687	0625	0250	0312	0375	0000	%0191	V03 \$
006913	-00114	-01144	0625	0625	0625	0375	0375	0375	0000	%0192	V04 \$
006170	-00299	-01986	0500	0562	0625	0500	0437	0375	0000	%0193	V05 \$
005504	-00302	-02679	0375	0500	0625	0625	0500	0375	0000	%0194	V06 \$
004792	-00222	-03346	0250	0437	0625	0750	0562	0375	0000	%0195	V07 \$
003989	-00002	-03985	0125	0375	0625	0875	0625	0375	0000	%0196	V08 \$
003203	000413	-04558	0000	0312							

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

```

009308 000006 -006010 1000 1000 1000 0000 0000 0000 0000 %0243 b01 $
009253 -000059 -006056 0875 0906 1000 0125 0093 0000 0000 %0244 b02 $
008542 -002028 -015099 0750 0812 1000 0250 0187 0000 0000 %0245 b03 $
007550 -00143 -02521 0625 0718 1000 0375 0281 0000 0000 %0246 b04 $
006640 000059 -03331 0500 0625 1000 0500 0375 0000 0000 %0247 b05 $
005807 000346 -03992 0375 0531 1000 0625 0468 0000 0000 %0248 b06 $
004914 000763 -04640 0250 0437 1000 0750 0562 0000 0000 %0249 b07 $
003895 001379 -05279 0125 0343 1000 0875 0556 0000 0000 %0250 b08 $
002844 002175 -05732 0000 0250 1000 1000 0750 0000 0000 %0251 b09 $
009301 -00229 -00504 1000 0968 0875 0000 0031 0125 0000 %0252 c01 $
009224 -00042 -00584 0875 0875 0875 0125 0125 0125 0000 %0253 c02 $
008380 000931 -01579 0750 0781 0875 0250 0218 0125 0000 %0254 c03 $
007398 000061 -02584 0625 0687 0875 0375 0312 0125 0000 %0255 c04 $
006485 000268 -03395 0500 0593 0875 0500 0406 0125 0000 %0256 c05 $
005631 000606 -04077 0375 0500 0875 0625 0500 0125 0000 %0257 c06 $
004723 001064 -04739 0250 0406 0875 0750 0593 0125 0000 %0258 c07 $
003735 001664 -05360 0125 0312 0875 0875 0687 0125 0000 %0259 c08 $
002761 002518 -05816 0000 0218 0875 1000 0781 0125 0000 %0260 c09 $
009247 -00262 -000334 1000 0937 0750 0000 0662 0250 0000 %0261 d01 $
009037 -000038 -000088 0875 0843 0750 0125 0156 0250 0000 %0262 d02 $
008172 000032 -000088 0750 0750 0750 0250 0250 0250 0000 %0263 d03 $
007180 000090 -02092 0625 0656 0750 0375 0343 0250 0000 %0264 d04 $
006273 000229 -02066 0500 0562 0750 0500 0437 0250 0000 %0265 d05 $
005425 000583 -03733 0375 0468 0750 0625 0531 0250 0000 %0266 d06 $
004493 001111 -04495 0250 0375 0750 0750 0625 0250 0000 %0267 d07 $
003517 001725 -05169 0125 0281 0750 0875 0718 0250 0000 %0268 d08 $
002560 002579 -05645 0000 0187 0750 1000 0812 0250 0000 %0269 d09 $
009167 -00529 001584 1000 0906 0625 0000 0093 0375 0000 %0270 e01 $
008798 -000054 001137 0875 0812 0625 0125 0187 0375 0000 %0271 e02 $
007926 -000055 000041 0750 0718 0625 0250 0281 0375 0000 %0272 e03 $
006943 -00126 -01130 0625 0625 0625 0375 0375 0375 0000 %0273 e04 $
006038 -00028 -02125 0500 0531 0625 0500 0468 0375 0000 %0274 e05 $
005160 000349 -03025 0375 0437 0625 0625 0625 0375 0000 %0275 e06 $
004227 000889 -03907 0250 0343 0625 0750 0566 0375 0000 %0276 e07 $
003238 001556 -04697 0125 0250 0625 0875 0750 0375 0000 %0277 e08 $
002292 002457 -05250 0000 0156 0625 1000 0843 0375 0000 %0278 e09 $
009034 -00673 002943 1000 0875 0500 0000 0125 0500 0000 %0279 f01 $
008548 -00934 002338 0875 0781 0500 0125 0218 0500 0000 %0280 f02 $
007679 -00112 -001194 0750 0687 0500 0250 0312 0500 0000 %0281 f03 $
006760 -00330 000001 0625 0593 0500 0375 0406 0500 0000 %0282 f04 $
005761 -00266 -01106 0500 0500 0500 0500 0500 0500 0000 %0283 f05 $
004868 000076 -02122 0375 0406 0500 0625 0593 0500 0000 %0284 f06 $
003963 000510 -03072 0250 0312 0500 0750 0687 0500 0000 %0285 f07 $
002937 001184 -03972 0125 0218 0500 0875 0781 0500 0000 %0286 f08 $
001986 002105 -04599 0000 0125 0500 1000 0875 0500 0000 %0287 f09 $
008796 -00576 004128 1000 0843 0375 0000 0156 0625 0000 %0288 g01 $
008295 000057 003473 0875 0750 0375 0125 0250 0625 0000 %0289 g02 $
007422 -000070 002316 0750 0656 0375 0250 0343 0625 0000 %0290 g03 $
006430 -00403 001109 0625 0562 0375 0375 0437 0625 0000 %0291 g04 $
005500 -00422 -00062 0500 0468 0375 0500 0531 0625 0000 %0292 g05 $
004577 -00146 -01162 0375 0375 0375 0625 0625 0625 0000 %0293 g06 $
003635 000213 -02208 0250 0281 0375 0750 0718 0625 0000 %0294 g07 $
002647 000770 -03163 0125 0187 0375 0875 0781 0625 0000 %0295 g08 $
001678 001738 -03903 0000 0093 0375 1000 0906 0625 0000 %0296 g09 $
008564 -00382 005239 1000 0812 0250 0000 0187 0750 0000 %0297 h01 $
008055 000226 -004553 0875 0718 0250 0125 0281 0750 0000 %0298 h02 $
007214 000000 003472 0750 0625 0250 0250 0375 0750 0000 %0299 h03 $
006221 -00411 002406 0625 0531 0250 0500 0437 0750 0000 %0300 h04 $
005234 -00478 000959 0500 0437 0250 0500 0562 0750 0000 %0301 h05 $
004289 -00284 -00201 0375 0343 0250 0625 0656 0750 0000 %0302 h06 $
003360 -00031 -01315 0250 0250 0250 0750 0750 0750 0000 %0303 h07 $
002358 000490 -02385 0125 0156 0250 0875 0843 0750 0000 %0304 h08 $
001378 001462 -03257 0000 0062 0250 1000 0937 0750 0000 %0305 h09 $
008308 00139 006739 1000 0781 0125 0000 0218 0875 0000 %0306 i01 $
007807 000435 006075 0875 0687 0125 0125 0312 0875 0000 %0307 i02 $
006981 000137 004963 0750 0593 0125 0250 0406 0875 0000 %0308 i03 $
005953 -00303 003600 0625 0500 0125 0375 0500 0875 0000 %0309 i04 $
004939 -00453 002269 0500 0406 0125 0500 0593 0875 0000 %0310 i05 $
004014 -00411 001046 0375 0312 0125 0625 0687 0875 0000 %0311 i06 $
003040 -00188 -00230 0250 0218 0125 0750 0781 0875 0000 %0312 i07 $
002042 000177 -01379 0125 0125 0125 0875 0875 0875 0000 %0313 i08 $
001091 000999 -02366 0000 0031 0125 1000 0968 0875 0000 %0314 i09 $
008011 000223 009274 1000 0750 0000 0000 0250 1000 0000 %0315 j01 $
007533 000739 008602 0875 0656 0000 0125 0343 1000 0000 %0316 j02 $
006731 000415 007465 0750 0562 0000 0250 0437 1000 0000 %0317 j03 $
005655 -00120 005941 0625 0468 0000 0375 0531 1000 0000 %0318 j04 $
004614 -00346 004432 0500 0375 0000 0500 0625 1000 0000 %0319 j05 $
003668 -00415 003110 0375 0281 0000 0625 0718 1000 0000 %0320 j06 $
002721 -00443 001764 0250 0187 0000 0750 0812 1000 0000 %0321 j07 $
001716 -00237 000392 0125 0093 0000 0875 0906 1000 0000 %0322 j08 $
000867 000136 -00749 0000 0000 0000 1000 1000 1000 0000 %0323 j09 $
009259 000031 -00628 1000 1000 0000 0000 0000 0000 %0567 b10 $
009210 000103 -00680 0800 0875 1000 0031 0125 0000 0000 %0568 b11 $
008060 001169 -01361 0937 0750 1000 0062 0250 0000 0000 %0569 b12 $
007883 002396 -02070 0906 0625 1000 0093 0375 0000 0000 %0570 b13 $
006785 003550 -02736 0875 0500 1000 0125 0500 0000 0000 %0571 b14 $
006240 004653 -03356 0843 0375 1000 0156 0625 0000 0000 %0572 b15 $
005411 005648 -03860 0812 0250 1000 0187 0750 0000 0000 %0573 b16 $
004419 006588 -04296 0781 0250 1000 0249 0875 0000 0000 %0574 b17 $
003458 007417 -04419 0750 0000 1000 0250 1000 0000 0000 %0575 b18 $
002422 -00004 -00526 0906 1000 0875 0093 0000 0125 0000 %0576 c10 $
009180 -00005 -00607 0875 0875 0875 0125 0125 0125 0000 %0577 c11 $
008508 000878 -01370 0843 0750 0875 0156 0250 0125 0000 %0578 c12 $
007724 001936 -01784 0812 0625 0875 0187 0375 0125 0000 %0579 c13 $
006886 002990 -02910 0781 0500 0875 0218 0500 0125 0000 %0580 c14 $
006001 004069 -03584 0750 0375 0875 0250 0625 0125 0000 %0581 c15 $
005133 005089 -04143 0718 0250 0875 0281 0750 0125 0000 %0582 c16 $
004140 006179 -04629 0687 0125 0875 0312 0875 0125 0000 %0583 c17 $
003145 007028 -04778 0656 0000 0875 0343 1000 0125 0000 %0584 c18 $
008998 -00712 000082 0812 1000 0750 0187 0000 0250 0000 %0585 d10 $
008857 -00853 -00111 0781 0875 0750 0218 0125 0250 0000 %0586 d11 $
008194 -00023 -00934 0750 0750 0750 0250 0250 0250 0000 %0587 d12 $
007384 001010 -01817 0718 0625 0750 0281 0375 0250 0000 %0588 d13 $
006559 002033 -02635 0687 0500 0750 0312 0500 0250 0000 %0589 d14 $
005656 003187 -03424 0656 0375 0750 0343 0625 0250 0000 %0590 d15 $
004775 004288 -04085 0625 0250 0750 0375 0750 0250 0000 %0591 d16 $
003791 005510 -04665 0593 0125 0750 0406 0875 0250 0000 %0592 d17 $
002817 006484 -04923 0562 0000 0750 0437 1000 0250 0000 %0593 d18 $
008560 -01695 000888 0718 1000 0625 0281 0000 0375 0000 %0594 e10 $
008394 -01855 000644 0687 0875 0625 0312 0125 0375 0000 %0595 e11 $
007746 -01102 -00166 0656 0750 0625 0343 0250 0375 0000 %0596 e12 $
006968 -00129 -01111 0625 0625 0625 0375 0375 0375 0000 %0597 e13 $
006163 000887 -01939 0593 0500 0625 0406 0500 0375 0000 %0598 e14 $
005267 002085 -02869 0562 0375 0625 0437 0625 0375 0000 %0599 e15 $
004396 003325 -03657 0531 0250 0625 0468 0750 0375 0000 %0600 e16 $
003420 004657 -04362 0500 0125 0625 0500 0875 0375 0000 %0601 e17 $
002477 005760 -04754 0468 0000 0625 0531 1000 0375 0000 %0602 e18 $
008007 -02654 001722 0625 1000 0500 0375 0000 0500 0000 %0603 f10 $
007847 -02790 001482 0593 0875 0500 0406 0125 0500 0000 %0604 f11 $
007229 -02179 000713 0562 0750 0500 0437 0250 0500 0000 %0605 f12 $
006534 -01282 -00186 0531 0625 0500 0468 0375 0500 0000 %0606 f13 $
005751 -00309 -01062 0500 0500 0500 0500 0500 0500 0000 %0607 f14 $
004900 000922 -02009 0468 0375 0500 0531 0625 0500 0000 %0608 f15 $
004040 002208 -02913 0437 0250 0500 0562 0750 0500 0000 %0609 f16 $
003072 003638 -03760 0406 0125 0500 0593 0875 0500 0000 %0610 f17 $
002125 004887 -04329 0375 0000 0500 0625 1000 0500 0000 %0611 f18 $
007456 -03443 -00249 0531 1000 0375 0468 0000 0625 0000 %0612 g10 $
007283 -03589 002286 0500 0875 0375 0500 0125 0625 0000 %0613 g11 $
006767 -03063 001590 0468 0750 0375 0531 0250 0625 0000 %0614 g12 $
006120 -02266 000739 0437 0625 0375 0562 0375 0625 0000 %0615 g13 $
005390 -01353 -00140 0406 0500 0375 0593 0500 0625 0000 %0616 g14 $
004534 -00174 -01117 0375 0375 0375 0625 0625 0625 0000 %0617 g15 $
003679 00117 -02096 0343 0250 0375 0656 0750 0625 0000 %0618 g16 $
002708 002548 -03033 0312 0125 0375 0687 0875 0625 0000 %0619 g17 $
001783 003895 -03753 0281 0000 0375 0718 1000 0625 0000 %0620 g18 $
008928 -04091 003235 0437 1000 0250 0562 0000 0750 0000 %0621 h10 $
006782 -04214 003031 0406 0875 0250 0593 0125 0750 0000 %0622 h11 $
006329 -03002 002438 0375 0750 0250 0625 0250 0750 0000 %0623 h12 $
005731 -03126 001622 0343 0625 0250 0656 0375 0750 0000 %0624 h13 $
005031 -02332 000747 0312 0500 0250 0687 0500 0750 0000 %0625 h14 $
004185 -01216 -00285 0281 0375 0250 0718 0625 0750 0000 %0626 h15 $
003318 -00010 -01318 0250 0250 0250 0750 0750 0750 0000 %0627 h16 $
002323 001040 -02367 0218 0125 0250 0875 0875 0750 0000 %0628 h17 $
001436 002869 -03183 0187 0000 0250 0812 1000 0750 0000 %0629 h18 $
006393 -04628 004218 0343 1000 0125 0656 0000 0875 0000 %0630 i10 $
006257 -04760 004022 0312 0875 0125 0687 0125 0875 0000 %0631 i11 $
005826 -04506 003477 0281 0750 0125 0718 0250 0875 0000 %0632 i12 $
005245 -04049 002667 0250 0625 0125 0750 0375 0875 0000 %0633 i13 $
004550 -03393 001789 0218 0500 0125 0781 0500 0875 0000 %0634 i14 $
003765 -02372 000772 0187 0375 0125 0812 0625 0875 0000 %0635 i15 $
002921 -01228 -00307 0156 0250 0125 0843 0750 0875 0000 %0636 i16 $
001989 000208 -01390 0125 0125 0125 0875 0875 0875 0000 %0637 i17 $
001118 001666 -02283 0093 0000 0125 0900 1000 0875 0000 %0638 i18 $
000543 -05064 005754 0250 1000 0000 0750 0000 1000 0000 %0639 j10 $
005462 -05250 005492 0218 0875 0000 0781 0125 1000 0000 %0640 j11 $
005147 -05110 005060 0877 0750 0000 0812 0250 1000 0000 %0641 j12 $
004655 -04794 004384 0156 0625 0000 0843 0375 1000 0000 %0642 j13 $
004034 -04258 003560 0125 0500 0000 0875 0500 1000 0000 %0643 j14 $
003277 -03429 002535 0093 0375 0000 0906 0625 1000 0000 %0644 j15 $
002472 -02440 001432 0062 0250 0000 0937 0750 1000 0000 %0645 j16 $
001592 -01168 000286 0031 0125 0000 0968 0875 1000 0000 %0646 j17 $
000818 000144 -00729 0000 0000 0000 1000 1000 1000 0000 %0647 j18 $
009250 000020 -006028 1000 1000 0000 0000 0000 0000 %0891 b19 $
009221 000087 -006667 1000 0875 0906 0000 0125 0093 0000 %0892 b20 $
008544 001069 -009026 1000 0750 0812 0000 0250 0187 0000 %0893 b21 $
007779 002081 -010206 1000 0625 0718 0000 0375 0281 0000 %0894 b22 $
006982 003031 -009663 1000 0500 0625 0000 0500 0375 0000 %0895 b23 $
006122 004047 -00856 1000 0375 0531 0000 0625 0468 0000 %0896 b24 $
005333 004979 -00748 1000 0250 0437 0000 0750 0562 0000 %0897 b25 $
004419 005954 -00534 1000 0125 0343 0000 0875 0656 0000 %0898 b26 $
003563 006615 -00210 1000 0000 0250 0000 1000 0750 0000 %0899 b27 $
009219 -00053 -00668 0875 1000 0968 0125 0000 0031 0000 %0900 c19 $
009185 -00035 -00576 0875 0875 0875 0125 0125 0125 0000 %0901 c20 $
008516 000906 -00733 0875 0750 0781 0125 0250 0218 0000 %0902 c21 $
007747 001877 -00727 0875 0625 0687 0125 0375 0312 0000 %0903 c22 $
006958 002828 -00612 0875 0500 0593 0125 0500 0406 0000 %0904 c23 $
006108 003862 -00572 0875 0375 0500 0125 0625 0500 0000 %0905 c24 $
005296 004819 -00427 0875 0250 0406 0125 0750 0593 0000 %0906 c25 $
004398 005802 -00202 0875 0125 0312 0125 0875 0687 0000 %0907 c26 $
003538 006487 000135 0875 0000 0218 0125 1000 0781 0000 %0908 c27 $
008833 -00841 -01148 0750 1000 0937 0250 0000 0062 0000 %0909 d19 $
008760 -00894 -00897 0750 0875 0843 0250 0125 0156 0000 %0910 d20 $
008132 000012 -00933 0750 0750 0750 0250 0250 0250 0000 %0911 d21 $
007372 000942 -00845 0750 0625 0656 0250 0375 0343 0000 %0912 d22 $
006586 001915 -00710 0750 0500 0562 0250 0500 0437 0000 %0913 d23 $
005764 002956 -00684 0750 0375 0468 0250 0625 0531 0000 %0914 d24 $
004931 003975 -00527 0750 0250 0375 0250 0750 0625 0000 %0915 d25 $
004023 005059 -00387 0750 0125 0281 0250 0875 0718 0000 %0916 d26 $
003197 005803 000020 0750 0000 0187 0250 1000 0812 0000 %0917 d27 $
008297 -01596 -01725 0625 1000 0906 0375 0000 0093 0000 %0918 e19 $
008219 -01734 -01323 0625 0875 0812 0375 0125 0187 0000 %0919 e20 $
007606 -00968
```

See original or copy: <http://web.me.com/klaus.richter/GE18/GE18L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE08(7)_22.REM.TXT, Separation olv*, D65, not adapted S
%100 x LAB*      %1000 x (r g b c m y 0)      %nr.   pos $
%Z003523 006007 003423 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008414 -00455 009838 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z004366 -06169 003964 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005272 -02873 -03731 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z001337 005233 -06394 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z003710 007910 -03961 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z000838 000144 -00724 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009253 000013 -00613 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W1 7 $
%S
%Z003523 006007 003423 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008414 -00455 009838 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z004366 -06169 003964 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005272 -02873 -03731 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z001337 005233 -06394 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z003710 007910 -03961 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z000838 000144 -00724 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009253 000013 -00613 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W2 7 $
%S
%Z003523 006007 003423 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008414 -00455 009838 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z004366 -06169 003964 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005272 -02873 -03731 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z001337 005233 -06394 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z003710 007910 -03961 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z000838 000144 -00724 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009253 000013 -00613 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W001 7 $
%S
%Z005105 004122 005342 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z007963 -01438 009261 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z004718 -05665 000822 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005831 -02348 -03959 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z001930 005723 -06171 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z003695 007771 -03692 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z000807 000140 -00705 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009238 000043 -00636 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %W251 7 $
%S
%Z006725 001921 007509 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006750 -03569 007447 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z004990 -04607 -01311 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004226 -00596 -04699 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z002648 006425 -05419 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z003625 007206 -02307 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z000821 000129 -00678 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009246 000037 -00632 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %W501 7 $
%S
%Z008011 000223 009274 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z005643 -05064 005754 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005232 -03291 -03202 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z002944 002175 -05732 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003458 007447 -04410 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z003563 006615 -00210 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z000843 000138 -00715 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009273 000019 -00622 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %W751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE18/GE18L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG GE08(7)_22.REM.TXT, Separation olv*, D65, not adapted S																										
%100 x LAB*																										
1000 x (r g b c m y o)																										
nrr. pos \$																										
000925	000109	-00712	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$	0009139	-00070	-00549	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$	
0002093	000173	-01380	0125	0125	0125	0875	0875	0875	0000	%0973	k02	\$	0009259	000004	-00600	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$	
0003402	000025	-01357	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$	0009253	000019	-00606	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$	
0004604	-00138	-01166	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$	000847	000133	-00758	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$	
0005806	-00261	-01113	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	001389	000266	-01215	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$	
0007007	-00139	-01127	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$	002096	000188	-01443	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$	
0008203	-00028	-00936	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$	002790	000010	-01384	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$	
0009216	-00041	-00578	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$	003493	-00035	-01288	0266	0266	0266	0733	0733	0733	0000	%1060	n14	\$	
0009272	000022	-00627	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$	004157	-00087	-01161	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$	
0009523	000100	-00703	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$	004812	-00187	-01179	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$	
0020996	000164	-01380	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$	005449	-00254	-01148	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$	
0003391	000026	-01355	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$	006092	-00291	-01060	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$	
0004590	-00131	-01178	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$	006701	-00180	-01082	0600	0600	0600	0399	0399	0399	0000	%1065	n19	\$	
0005794	-00243	-01148	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	007344	-00040	-01090	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$	
0006993	-00141	-01126	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$	007996	-00001	-00960	0733	0733	0733	0266	0266	0266	0000	%1067	n21	\$	
0008186	-00023	-00944	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$	008580	000012	-00799	0800	0800	0800	0199	0199	0199	0000	%1068	n22	\$	
0009212	-00040	-00583	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$	009134	-00067	-00548	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$	
0009275	000019	-00623	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$	009252	000004	-00601	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$	
0009912	000102	-00707	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$	009242	000022	-00609	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$	
0002075	000178	-01388	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$	000843	000138	-00665	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$	
0003370	000022	-01346	0250	0250	0250	0750	0750	0750	0000	%0992	m03	\$	009211	000016	-00597	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$	
0004561	-00110	-01211	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$	003496	000061	003512	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$	
0005777	-00240	-01154	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$	005298	-02884	-03714	0000	1000	1000	0000	0000	0000	0000	%1075	l27	\$	
0006969	-00133	-01140	0625	0625	0625	0375	0375	0375	0000	%0995	m06	\$	008430	-00423	010056	1000	1000	0000	0000	0000	1000	0000	%1076	m26	\$	
0008187	-00018	-00956	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$	001374	005236	-06418	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$	
0009213	-00044	-00576	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$	004374	-06169	004053	0000	1000	0000	0000	1000	0000	0000	%1078	n26	\$	
0009274	000018	-00619	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$	003735	007909	-03978	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$	
0009914	000101	-00713	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$														
0002061	000186	-01394	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$	%003496 006061 003512 ##1000 0000 0000 0000 1000 1000 0000													
0003358	000031	-01372	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$	%0008430 -00423 010056 ##1000 1000 0000 0000 0000 1000 0000													
0004569	-00120	-01204	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$	%0004374 -06169 004053 ##0000 1000 0000 0000 0000 1000 0000													
0005778	-00245	-01150	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$	%0005298 -02884 -03714 ##0000 1000 1000 1000 0000 0000 0000													
0006974	-00141	-01132	0625	0625	0625	0375	0375	0375	0000	%1004	n06	\$	%0001374 005236 -06418 ##0000 0000 1000 1000 1000 0000 0000													
0008193	-00017	-00955	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$	%00003735 007909 -03978 ##1000 0000 1000 0000 1000 0000 0000													
0009209	-00041	-00582	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$	%0000843 000138 -00665 ##0000 0000 0000 1000 1000 1000 0000													
0009272	000019	-00626	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$	%0009211 000016 -00597 ##1000 1000 1000 0000 0000 0000 0000													
000857	000129	-00749	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$														
0009142	000260	-01224	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$	%0000891 000119 -00730 ##0000 0000 0000 1000 1000 1000 0000													
0002118	000168	-01426	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$	%0009262 000021 -00615 ##1000 1000 1000 0000 0000 0000 0000													
0002834	-00019	-01348	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$														
0003548	-00037	-01282	0266	0266	0266	0733	0733	0733	0000	%1012	k14	\$	%0000897 000117 -00726 ##0000 0000 0000 1000 1000 1000 0000													
0004196	-00106	-01124	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$	%0009261 000018 -00613 ##1000 1000 1000 0000 0000 0000 0000													
0004841	-00202	-01134	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$														
0005471	-00265	-01125	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$	%0000880 000118 -00735 ##0000 0000 0000 1000 1000 1000 0000													
0006116	-00283	-01062	0533	0533	0533	0666	0666	0666	0000	%1016	k18	\$	%0009264 000019 -00613 ##1000 1000 1000 0000 0000 0000 0000													
0007028	-00101	-01074	0600	0600	0600	0399	0399	0399	0000	%1017	k19	\$														
0008177	-00075	-00866	0666	0666	0666	0333	0333	0333	0000	%1018	k20	\$	%0000881 000117 -00735 ##0000 0000 0000 1000 1000 0000 0000													
0008001	-00007	-00959	0733	0733	0733	0266	0266	0266	0000	%1019	k21	\$	%0009257 000020 -00617 ##1000 1000 1000 0000 0000 0000 0000													
0008590	000010	-00800	0800	0800	0800	0199	0199	0199	0000	%1020	k22	\$														
0009144	-00068	-00545	0866	0866	0866	0133	0133	0133	0000	%1021	k23	\$														
0009262	000004	-00600	0933	0933	0933	0066	0066	0066	0000	%1022	k24	\$														
0009253	000019	-00602	1000	1000	1000	0000	0000	0000	0000	%1023	k25	\$														
0008071	000134	-00749	0000	0000	0000	1000	1000	1000	0000	%1024	l10	\$														
0001409	000269	-01225	0066	0066	0066	0933	0933	0933	0000	%1025	l11	\$														
0002118	000169	-01418	0133	0133	0133	0866	0866	0866	0000	%1026	l12	\$														
0002814	000005	-01382	0200	0200	0200	0800	0800	0800	0000	%1027	l13	\$														
0003528	-00044	-01269	0266	0266	0266	0733	0733	0733	0000	%1028	l14	\$														
0004179	-00089	-01147	0333	0333	0333	0666	0666	0666	0000	%1029	l15	\$														
0004827	-00178	-01168	0400	0400	0400	0600	0600	0600	0000	%1030	l16	\$														
0005476	-00257	-01130	0466	0466	0466	0533	0533	0533	0000	%1031	l17	\$														
0006104	-00281	-01071	0533	0533	0533	0666	0666	0666	0000	%1032	l18	\$														
0006723	-00176	-01084	0600	0600	0600	0399	0399	0399	0000	%1033	l19	\$														
0007358	-00047	-01083	0666	0666	0666	0333	0333	0333	0000	%1034	l20	\$														
0008001	-00007	-00961	0733	0733	0733	0266	0266	0266	0000	%1035	l21	\$														
0008585	000016	-00821	0800	0800	0800	0199	0199	0199	0000	%1036	l22	\$														
0009138	-00067	-00554	0866	0866	0866	0133	0133	013																		

TUB registration: 20091101-GE18/GE18L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rh4ta

See original or copy: <http://web.me.com/klaus.richter/GE18/GE18L0NA.TXT/.PSS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfi=1.00; nt=

BEG		E08(7) 22 REM.TXT										Separation olv", D65, adapted \$																											
%100 x	LAB*(a	1000 x (r g b c m y o)										%nr.	pos																										
009272	-00002	000007	1000	1000	1000	0000	0000	0000	0000	0000	0000	%0000	A01 \$	009247	000006	-00009	1000	1000	1000	0000	0000	0000	0000	%0324	A10 \$	009241	-00003	000002	1000	1000	1000	0000	0000	0000	0000	0000	0000	%0648	A19 \$
009238	-00089	-00038	0875	1000	1000	0000	0125	0000	0000	0000	0000	%0001	A02 \$	009183	-00011	-00093	0875	0875	1000	0125	0125	0000	0000	%0325	A11 \$	009208	000063	-00046	1000	0875	1000	0000	0125	0000	0000	0000	0000	%0649	A20 \$
008829	-00891	-00532	0750	1000	1000	0000	0250	0000	0000	0000	0000	%0002	A03 \$	008170	000366	-01239	0750	0750	1000	0250	0250	0000	0000	%0326	A12 \$	008525	001251	-00784	1000	0750	1000	0000	0250	0000	0000	0000	0000	%0650	A21 \$
008261	-01649	-01131	0625	1000	1000	0000	0375	0000	0000	0000	0000	%0003	A04 \$	007012	000736	-02352	0625	0625	1000	0375	0375	0000	0000	%0327	A13 \$	007780	002503	-01505	1000	0625	1000	0000	0375	0000	0000	0000	0000	%0651	A22 \$
007705	-02190	-01636	0500	1000	1000	0000	0500	0000	0000	0000	0000	%0004	A05 \$	005881	001250	-03276	0500	0500	1000	0500	0500	0000	0000	%0328	A14 \$	007004	003723	-02130	1000	0500	1000	0000	0500	0000	0000	0000	0000	%0652	A23 \$
007201	-02536	-02033	0375	1000	1000	0000	0625	0000	0000	0000	0000	%0005	A06 \$	004774	002634	-04086	0375	0375	1000	0625	0625	0000	0000	%0329	A15 \$	006167	004986	-02682	1000	0375	1000	0000	0625	0000	0000	0000	0000	%0653	A24 \$
006680	-02831	-02388	0250	1000	1000	0000	0750	0000	0000	0000	0000	%0006	A07 \$	003652	004872	-04822	0250	0250	1000	0750	0750	0000	0000	%0330	A16 \$	005425	006049	-03058	1000	0250	1000	0000	0750	0000	0000	0000	0000	%0654	A25 \$
006006	-03002	-02767	0125	1000	1000	0000	0875	0000	0000	0000	0000	%0007	A08 \$	002403	000323	-05476	0125	0125	1000	0875	0875	0000	0000	%0331	A17 \$	004551	007128	-03325	1000	0125	1000	0000	0875	0000	0000	0000	0000	%0655	A26 \$
005272	-02948	-03065	0000	1000	1000	0000	1000	0000	0000	0000	0000	%0008	A09 \$	001337	005096	-05676	0000	0000	1000	1000	1000	0000	0000	%0332	A18 \$	003710	007810	-03274	1000	0000	1000	0000	1000	0000	0000	0000	0000	%0656	A27 \$
009226	000037	000064	1000	0875	0875	0000	0125	0125	0125	0000	0000	%0009	B01 \$	009212	000013	000077	1000	1000	0875	0000	0000	0125	0000	%0333	B10 \$	009190	-00126	000080	0875	1000	0875	0125	0000	0125	0000	0000	0000	%0657	B19 \$
009170	-00041	000020	0875	0875	0875	0875	0125	0125	0125	0000	0000	%0010	B02 \$	009135	000009	-00009	0875	0875	0875	0125	0125																		

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-GE18/GE18L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rh4ta

TUB-test chart GE18; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

```
input: w setgray
output: -> oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE18/GE18L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfl=1.00; nt=0.18; nx=1.00

099223	00016	000020	1000	1000	1000	0000	0000	0000	0000	#0081	J01 \$	009215	000222	-00022	1000	1000	1000	0000	0000	0000	0000	0000	#0405 J10 \$	009237	-00006	000002	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	#0729 J19 \$
099267	-00086	-00028	0875	0968	1000	0125	0031	0000	0000	#0082	J02 \$	009169	000102	-00071	0906	0875	1000	0903	0125	0000	0000	#0406 J11 \$	009199	000068	-00042	1000	0875	0968	0000	0125	0031	0000	0000	0000	0000	#0730 J20 \$		
008840	-00893	-00512	0750	0937	1000	0250	0062	0000	0000	#0083	J03 \$	008387	000748	-00965	0812	0750	1000	0817	0250	0000	0000	#0407 J12 \$	008529	001227	-00776	1000	0750	0937	0000	0250	0062	0000	0000	0000	0000	#0731 J21 \$		
008271	-01657	-01108	0625	0906	1000	0375	0093	0000	0000	#0084	J04 \$	007357	001364	-01191	0718	0625	1000	0281	0375	0000	0000	#0408 J13 \$	007787	002472	-01494	1000	0625	0906	0000	0375	0093	0000	0000	0000	0000	#0732 J22 \$		
007682	-02150	-01643	0500	0875	1000	0500	0125	0000	0000	#0085	J05 \$	006310	001941	-02911	0625	0500	1000	0375	0500	0000	0000	#0409 J14 \$	006994	003658	-02046	1000	0500	0875	0000	0500	0125	0000	0000	0000	0000	#0733 J23 \$		
007103	-02327	-02123	0375	0843	1000	0625	0156	0000	0000	#0086	J06 \$	005226	002742	-03730	0331	0375	1000	0468	0625	0000	0000	#0410 J15 \$	006175	004848	-02491	1000	0375	0843	0000	0625	0156	0000	0000	0000	0000	#0734 J24 \$		
006486	-02450	-02567	0250	0812	1000	0750	0187	0000	0000	#0087	J07 \$	004191	003618	-04440	0347	0250	1000	0562	0750	0000	0000	#0411 J16 \$	005427	005894	-02810	1000	0250	0812	0000	0750	0187	0000	0000	0000	0000	#0735 J25 \$		
005773	-02527	-02980	0125	0871	1000	0875	0218	0000	0000	#0088	J08 \$	003060	004697	-05082	0343	0125	1000	0656	0875	0000	0000	#0412 J17 \$	004561	006956	-03062	1000	0125	0871	0000	0875	0218	0000	0000	0000	0000	#0736 J26 \$		
005031	-02440	-03288	0000	0750	1000	1000	0250	0000	0000	#0089	J09 \$	001930	005955	-05475	0250	0000	1000	0750	1000	0000	0000	#0413 J18 \$	003695	007664	-03010	1000	0000	0750	0000	1000	0250	0000	0000	0000	0000	#0737 J27 \$		
009257	-00048	000121	1000	0906	0875	0000	0093	0125	0000	#0090	K01 \$	009209	-00010	-000092	0968	1000	0875	0031	0000	0125	0000	#0414 K10 \$	009200	-00082	-00039	0875	1000	0906	0500	0125	0000	0093	0000	0000	0000	#0738 K19 \$		
009182	-00063	000039	0875	0875	0875	0125	0125	0125	0000	#0091	K02 \$	009123	-00009	-000087	0875	0875	0875	0125	0125	0125	0000	#0415 K11 \$	009150	-00053	000041	0875	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	#0739 K20 \$	
008650	-00618	000601	0750	0843	0875	0250	0156	0125	0000	#0092	K03 \$	008273																										

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-GE18/GE18L0NA.TXT /.PS
 application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

009274	-00012	000013	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$	009232	000018	-00016	1000	1000	1000	0000	0000	0000	%0486	S10 \$	009234	-00005	000002	1000	1000	1000	0000	0000	0000	0000	%0810	S19 \$		
009232	-00080	-00036	0875	0937	1000	0125	0062	0000	0000	%0163	S02 \$	009185	000099	-00064	0937	0875	1000	0062	0125	0000	0000	%0487	S11 \$	009192	000069	-00046	1000	0875	0937	0000	0125	0062	0000	%0811	S20 \$	
008806	-00831	-00549	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$	008541	001096	-00780	0875	0750	1000	0125	0250	0000	0000	%0488	S12 \$	008527	001184	-00664	1000	0750	0875	0000	0250	0125	0000	%0812	S21 \$	
007964	-01060	-01442	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$	007668	002006	-01665	0812	0625	1000	0187	0375	0000	0000	%0489	S13 \$	007766	002309	-01093	1000	0625	0812	0000	0375	0187	0000	%0813	S22 \$	
007182	-01133	-02160	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$	006744	002807	-02477	0750	0500	1000	0250	0500	0000	0000	%0490	S14 \$	006977	003386	-01398	1000	0500	0750	0000	0500	0250	0000	%0814	S23 \$	
006489	-01879	-02734	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$	005754	003657	-03247	0687	0375	1000	0312	0625	0000	0000	%0491	S15 \$	006151	004483	-01622	1000	0375	0687	0000	0625	0312	0000	%0815	S24 \$	
005795	-01053	-03227	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$	004752	004519	-03923	0625	0250	1000	0375	0750	0000	0000	%0492	S16 \$	005377	005431	-01719	1000	0250	0625	0000	0750	0375	0000	%0816	S25 \$	
005925	-00982	-03684	0125	0500	1000	0875	0507	0000	0000	%0169	S08 \$	003667	005528	-04500	0507	0125	1000	0875	0500	0000	0000	%0493	S17 \$	004483	006441	-01771	1000	0125	0500	0000	0875	0437	0000	%0817	S26 \$	
004226	-00968	-04939	0000	0500	1000	1000	0507	0000	0000	%0170	S09 \$	002548	006215	-04750	0500	0000	1000	0500	1000	0000	0000	%0494	S18 \$	003625	007187	-01644	1000	0000	0500	0000	1000	0500	0000	%0818	S27 \$	
009262	-00062	000120	1000	0937	0875	0000	0062	0125	0000	%0171	T01 \$	009226	-00017	000094	0937	1000	0875	0062	0000	0125	0000	%0495	T10 \$	009205	-00083	-00035	0875	1000	0937	0125	0000	0062	0000	%0819	T19 \$	
009190	-00654	000044	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$	009154	-00016	000005	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$	009155	-00054	000039	0875	0875	0875	0125	0125	0125	0000	%0820	T10 \$	
008499	-02998	-00785	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$	008402	000673	-00851	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$	008484	000968	-00329	0875	0750	0812	0125	0250	0187	0000	%0821	T21 \$	
007668	-00540	-01654	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$	007484	001520	-01788	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$	007728	002040	-00651	0875	0625	0750	0125	0375	0250	0000	%0822	T22 \$	
006886	-00619	-02369	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$	006541	002303	-02623	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$	006941	003111	-00900	0875	0500	0687	0125	0500	0312	0000	%0823	T23 \$	
006212	-00619	-02912	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$	005525	003214	-03414	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$	006105	004201	-01107	0875	0375	0625	0125	0625	0375	0000	%0824	T24 \$	
005525	-00581	-03409	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$	004550	004139	-04079	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$	005310	005182	-01182	0875	0250	0562	0125	0750	0437	0000	%0825	T25 \$	
004756	-00484	-03867	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$	003488	005219	-04660	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$	004446	006200	-01312	0875	0125	0500	0125	0875	0500	0000	%0826	T26 \$	
003940	-00131	-04232	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$	002454	006103	-04944	0437	0000	0875	0562	1000	0125	0000	%0503	T18 \$	003593	006884	-01203	0875	0000	0437	0125	1000	0562	0000	%0827	T27 \$	
009186	-00227	-000919	1000	0875	0750	0000	0125	0250	0000	%0180	T09 \$	009140	-00340	000911	0875	1000	0750	0125	0000	0250	0000	%0504	T10 \$	008802	-00918	-00403	0750	1000	0875	0250	0000	0125	0000	%0828	T28 \$	
008842	000231	000509	0875	0812	0750	0125	0187	0250	0000	%0181	U02 \$	008932	-00648	000637	0812	0875	0750	0187	0125	0250	0000	%0505	U11 \$	008744	-00983	-00090	0750	0875	0812	0250	0125	0187	0000	%0829	U20 \$	
008129	000093	-00365	0750	0750	0750	0250	0250	0250	0000	%0182	U03 \$	008162	-00044	-00313	0750	0750	0750	0250	0250	0250	0000	%0506	U12 \$	008115	-00026	-00303	0750	0750	0750	0250	0250	0250	0000	%0830	U21 \$	
007310	-00267	-01280	0625	0687	0750	0375	0312	0250	0000	%0183	U04 \$	0067235	000735	-01316	0687	0625	0750	0312	0375	0250	0000	%0507	U13 \$	007374	001008	-00518	0750	0625	0687	0250	0375	0312	0000	%0831	U22 \$	
006550	-00410	-02035	0500	0625	0750	0500	0375	0250	0000	%0184	U05 \$	006297	001536	-02238	0625	0500	0750	0375	0500	0250	0000	%0508	U14 \$	006592	002077	-00725	0750	0500	0625	0250	0500	0375	0000	%0832	U23 \$	
005882	-00412	-02644	0375	0562	0750	0625	0437	0250	0000	%0185	U06 \$	005316	002516	-03111	0562	0375	0750	0437	0625	0250	0000	%0509	U15 \$	005771	003172	-00896	0750	0375	0562	0250	0625	0437	0000	%0833	U24 \$	
005203	-00349	-03202	0250	0500	0750	0750	0500	0250	0000	%0186	U07 \$	004357	003517	-03843	0500	0250	0750	0500	0750	0250	0000	%0510	U16 \$	004960	004260	-01082	0750	0250	0500	0250	0750	0500	0000	%0834	U25 \$	
004417	-00209	-03734	0125	0437	0750	0875	0562	0250	0000	%0187	U08 \$	003309	004719	-04509	0437	0125	0750	0562	0875	0250	0000	%0511	U17 \$	004033	005380	-01228	0750	0125	0437	0250	0875	0562	0000	%0835	U26 \$	
003597	000213	-04151	0000	0375	0750	1000	0625	0250	0000	%0188	U09 \$	002287	005707	-04899	0375	0000	0750	0625	1000	0250	0000	%0512	U18 \$	003244	006143	-01066	0750	0000	0375	0250	1000	0625	0000	%0836	U27 \$	
008802	000009	001749	1000	0812	0625	0000	0187	0375	0000	%0189	V01 \$	008894	-01016	001930	0812	1000	0625	0187	0000	0375	0000	%0513	V10 \$	008235	-01822	-00666	0625	1000	0812	0375	0000	0187	0000	%0837	V19 \$	
008446	000466	001332	0875	0750	0625	0125	0250	0375	0000	%0190	V02 \$	008629	-01412	001581	0750	0875	0625	0250	0125	0375	0000	%0514	V11 \$	008163	-01953	-00229	0625	0875	0750	0375	0125	0250	0000	%0838	V20 \$	
007732	000431	000433	0750	0687	0625	0250	0312	0375	0000	%0191	V03 \$	007836	-00912	000599	0687	0750	0625	0312	0250	0375	0000	%0515	V12 \$	007570	-01142	-00302	0625	0750	0687	0375	0250	0312	0000	%0839	V19 \$	
006913	-00177	-00503	0625	0625	0625	0375	0375	0375	0000	%0192	V04 \$	006942	-00196	-00469	0625	0625	0625	0375	0375	0375	0000	%0516	V13 \$	006859	-00170	-00472	0625	0625	0625	0375	0375	0375	0000	%0840	V22 \$	
006170	-00370	-01337	0500	0125	0562	0875	0500	0437	0375	%0193	V05 \$	006933	000612	-01408	0500	0500	0625	0437	0500	0375	0000	%0517	V14 \$	006103	000793	-00891	0625	0500	0500	0500	0375	0500	0437	0000	%0841	V23 \$
005504	-00381	-02026	0375	0500	0625	0625	0625	0375	0000	%0194	V06 \$	005975	001645	-02436	0500	0375	0625	0500	0625	0375	0000	%0518	V15 \$	005278	001951	-00891	0625	0375	0500	0375	0625	0500	0000	%0842	V24 \$	
004792	-00308	-02689	0250	0437	0625	0750	0562	0375	0000	%0195	V07 \$	004141	002711	-03273	0437	0250	0625	0562	0750	0375	0000	%0519	V16 \$	004456	003094	-01112	0625	0250	0437	0375	0750	0562	0000	%0843	V25 \$	
003989	-00092	-03324	0125	0375	0625	0875	0625	0375	0000	%0196	V08 \$	003998	004002	-04063	0375	0125	0625	0625	0875	0375	0000	%0520	V17 \$	003545	004264	-01256	0625	0125	0375	0375	0875	0625	0000	%0844	V26 \$	
003203	000318	-03792	0000	0312	0625	1000	0687	0375	0000	%0197	V09 \$	002872	005010	-04574	0312	0000	0625																			

See original or copy: <http://web.me.com/klaus.richter/GE18/GE18L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE08(7)_22_REM.TXT, Separation olv*, D65, adapted $
%100 x LAB*a          %1000 x (r g b c m y o)          %nr. pos $
%Z003523 005904 004112 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008414 -00482 010463 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z004366 -06259 004642 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005272 -02948 -03065 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z001337 005096 -05676 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z003710 007810 -03274 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z000838 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009253 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W1 7 $
%$
%Z003523 005904 004112 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008414 -00482 010463 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z004366 -06259 004642 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005272 -02948 -03065 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z001337 005096 -05676 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z003710 007810 -03274 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z000838 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009253 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W2 7 $
%$
%Z003523 005904 004112 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008414 -00482 010463 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z004366 -06259 004642 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005272 -02948 -03065 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z001337 005096 -05676 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z003710 007810 -03274 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M00 5 $
%Z000838 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009253 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W001 7 $
%$
%Z005105 004031 006012 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z007963 -01496 009908 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z004718 -05761 001495 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005831 -02440 -03288 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z001930 005595 -05475 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z003695 007664 -03010 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z000807 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009238 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %W251 7 $
%$
%Z006725 001856 008155 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006750 -03634 008093 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z004990 -04691 -00656 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004226 -00688 -04039 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z002648 006315 -04750 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z003625 007107 -01644 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z000821 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009246 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %W501 7 $
%$
%Z008011 000186 009910 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z005643 -05134 006416 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005232 -03367 -02535 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z002944 002066 -05039 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003458 007345 -03723 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z003563 006515 000474 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z000843 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009273 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %W751 7 $
%$
```

See original or copy: <http://web.me.com/klaus.richter/GE18/GE18L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE08(7)_22.REM.TXT, Separation olv*, D65, adapted S
%100 x LAB*a      1000 x (r g b      %nr. pos $
000925 -00027 -00047 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002093 000053 -00725 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003402 -00075 -00712 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004604 -00222 -00531 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005806 -00327 -00488 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
007007 -00187 -00162 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
008203 -00059 -00330 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
009210 -00058 000019 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009272 -00007 -00030 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
009293 -00036 -00038 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002096 000044 -00725 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003391 -00074 -00710 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004590 -00214 -00543 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005794 -00309 -00522 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006993 -00189 -00511 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
008186 -00054 -00338 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
009212 -00056 000013 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009275 -00004 -00026 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
009912 -00034 -00042 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002075 000058 -00732 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003370 -00078 -00701 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004561 -00194 -00576 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
005777 -00306 -00529 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006969 -00182 -00524 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
008187 -00050 -00349 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
009213 -00060 000021 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009274 000003 -00022 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
009914 -00036 -00048 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002061 000066 -00738 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003358 -00069 -00726 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004569 -00204 -00569 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005778 -00311 -00525 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006974 -00190 -00516 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
008193 -00048 -00349 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
009209 -00057 000014 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009272 000004 -00028 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
008057 -00008 -00083 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
001412 000130 -00563 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002118 000049 -00771 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
002834 -00129 -00699 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
003548 -00136 -00638 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
004196 -00195 -00486 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
004841 -00282 -00501 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005471 -00335 -00497 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
006116 -00345 -00439 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006728 -00243 -00456 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
007361 -00099 -00462 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
008001 -00041 -00351 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
008590 -00014 -00197 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
009144 -00085 000053 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
009262 -00010 -00002 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009253 000003 -00005 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
008071 -00003 -00083 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
001409 000139 -00564 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
002118 000049 -00762 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
002814 -00103 -00732 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
003528 -00143 -00626 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
004179 -00193 -00509 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
004827 -00258 -00535 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005476 -00328 -00501 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
006104 -00342 -00448 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006723 -00229 -00466 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
007358 -00090 -00470 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
008001 -00041 -00354 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
008585 -00009 -00218 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
009138 -00084 000044 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
009262 -00009 -00002 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009247 000002 -00005 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
008048 -00003 -00096 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
001392 000143 -00563 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002104 000070 -00787 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
002794 -00104 -00718 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
003504 -00126 -00648 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
004173 -00171 -00529 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
004819 -00269 -00534 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005443 -00334 -00504 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
006089 -00354 -00438 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006714 -00225 -00466 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
007351 -00093 -00470 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007998 -00037 -00352 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
008581 -00007 -00208 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE18; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: ->olv* setrgbcolor

TUB registration: 20091101-GE18/GE18L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

%BEG GE08(7) 22 REM.TXT, Separation olv*, D50, not adapted S																																								
%100 x LAB*																																								
1000 x (r g b c m y o)																																								
nmr. pos. \$																																								
0092237	-00046	-00628	1000	1000	0000	0000	0000	0000	0000	%0001	A01	\$	0099237	-00038	-00645	1000	1000	0000	0000	0000	0000	%0324	A10	\$	0099231	-00048	-00634	1000	1000	0000	0000	0000	0000	0000	0000	%0648	A19	\$		
0092263	-00144	-00679	0875	1000	0000	0125	0000	0000	0000	0000	A02	\$	0091771	-00069	-00732	0875	0875	1000	0125	0125	0000	0000	%0325	A11	\$	0091909	000017	-00681	1000	0875	1000	0000	0125	0000	0000	0000	0000	%0649	A20	\$
008791	-01056	-01222	0750	1000	1000	0250	0000	0000	0000	0000	A03	\$	008145	000172	-01894	0750	0750	1000	0250	0250	0000	0000	%0326	A12	\$	008528	010177	-01386	1000	0750	1000	0000	0250	0000	0000	0000	0000	%0650	A21	\$
008196	-01947	-01873	0625	1000	1000	0375	0000	0000	0000	0000	A04	\$	006971	000379	-03028	0625	0625	1000	0375	0375	0000	0000	%0327	A13	\$	007798	002398	-02068	1000	0625	1000	0000	0375	0000	0000	0000	0000	%0651	A22	\$
007619	-02609	-02420	0500	1000	1000	0500	0000	0000	0000	0000	A05	\$	005828	000740	-03970	0500	0500	1000	0500	0500	0000	0000	%0328	A14	\$	007039	003590	-02651	1000	0500	1000	0000	0500	0000	0000	0000	0000	%0652	A23	\$
007099	-03059	-02849	0375	1000	1000	0625	0000	0000	0000	0000	A06	\$	004712	001385	-04791	0375	0375	1000	0625	0625	0000	0000	%0329	A15	\$	006225	004826	-03152	1000	0375	1000	0000	0625	0000	0000	0000	0000	%0653	A24	\$
005653	-03460	-03236	0250	1000	1000	0750	0000	0000	0000	0000	A07	\$	003577	002073	-05547	0250	0250	1000	0750	0750	0000	0000	%0330	A16	\$	005505	005864	-03478	1000	0250	1000	0000	0750	0000	0000	0000	0000	%0654	A25	\$
006575	-03748	-03647	0125	1000	1000	0875	0000	0000	0000	0000	A08	\$	002311	003095	-06230	0125	0125	1000	0875	0875	0000	0000	%0331	A17	\$	004661	006912	-03682	1000	0125	1000	0000	0875	0000	0000	0000	0000	%0655	A26	\$
005131	-03780	-03971	0000	1000	1000	1000	0000	0000	0000	0000	A09	\$	001233	004137	-06448	0000	0000	1000	1000	1000	0000	0000	%0332	A18	\$	003853	007574	-03565	1000	0000	1000	0000	1000	0000	0000	0000	0000	%0656	A27	\$
009218	000003	-00568	1000	0875	0875	0000	0125	0125	0000	0000	B01	\$	009204	-00019	-00556	1000	1000	0875	0000	0000	0125	0000	%0333	B10	\$	009179	-00167	-00558	0875	1000	0875	0125	0000	0125	0000	0000	0000	%0657	B19	\$
009160	-00085	-00616	0750	0875	0875	0125	0125	0125	0000	0000	B02	\$	009126	-00034	-00646	0875	0875	0125	0125	0125	0125	0000	%0334	B11	\$	009142	-00095	-00603	0875	0875	0875	0125	0125	0125	0000	0000	%0658	B20	\$	
008748	-01017	-01143	0750	0875	0875	0250	0125	0125	0000	0000	B03	\$	008141	-000136	-01779	0750	0750	0875	0250	0250	0125	0000	%0335	B12	\$	008498	010336	-01305	0875	0750	0875	0125	0250	0125	0000	0000	%0659	B21	\$	
008155	-01918	-01808	0625	0875	0875	0375	0125	0125	0000	0000	B04	\$	006968	000344	-02933	0625	0625	0875	0375	0375	0125	0000	%0336	B13	\$	007773	002258	-01996	0875	0625	0875	0125	0375	0125	0000	0000	%0660	B22	\$	
007600	-02981	-02345	0500	0875	0875	0500	0125	0125	0000	0000	B05	\$	005831	000684	-03891	0500	0500	0875	0500	0500	0125	0000	%0337	B14	\$	007018	003452	-02596	0875	0500	0875	0125	0500	0125	0000	0000	%0661	B23	\$	
007073	-03051	-02791	0375	0875	0875	0625	0125	0125	0000	0000	B06	\$	004711	001316	-04730	0375	0375	0875	0625	0625	0125	0000	%0338	B15	\$	006206	004697	-03116	0875	0375	0875	0125	0625	0125	0000	0000	%0662	B24	\$	
006175	-03426	-03202	0250	0875	0875	0750	0125	0125	0000	0000	B07	\$	003594	002031	-05499	0250	0250	0875	0750	0750	0125	0000	%0339	B16	\$	005475	005760	-03465	0875	0250	0875	0125	0750	0125	0000	0000	%0663	B25	\$	
005844	-03726	-03603	0125	0875	0875	0875	0125	0125	0000	0000	B08	\$	002334	003047	-06188	0125	0125	0875	0875	0875	0125	0000	%0340	B17	\$	004641	006814	-03691	0875	0125	0875	0125	0875	0125	0000	0000	%0664	B26	\$	
005109	-03773	-03921	0000	0875	0875	1000	0125	0125	0000	0000	B09	\$	001242	-004102	-06420	0000	0000	0875	1000	1000	0125	0000	%0341	B18	\$	003818	007505	-03591	0875	0000	0875	0125	1000	0125	0000	0000	%0665	B27	\$	
008525	000969	-00472	1000	0750	0750	0000	0250	0250	0000	0000	C01	\$	009157	-00164	-00309	1000	1000	0750	0000	0000	0250	0000	%0342	C10	\$	008695	-01241	-00228	0750	1000	0750	0250	0000	0250	0000	0000	0000	%0666	C19	\$
008489	000872	-00488	0875	0750	0750	0125	0250	0250	0000	0000	C02	\$	009071	-00178	000217	0875	0875	0750	0125	0125	0250	0000	%0343	C11	\$	008656	-01169	-00288	0750	0875	0750	0250	0125	0250	0000	0000	%0667	C20	\$	
008080	-00047	-01037	0750	0750	0750	0250	0250	0250	0000	0000	C03	\$	008090	-00062	-01006	0750	0750	0250	0250	0250	0250	0000	%0344	C12	\$	008060	-00067	-00966	0750	0750	0750	0250	0250	0250	0000	0000	%0668	C21	\$	
007545	-01069	-01650	0625	0750	0750	0375	0250	0250	0000	0000	C04	\$	006926	000109	-02269	0625	0625	0750	0375	0375	0250	0000	%0345	C13	\$	007364	001145	-01697	0750	0625	0750	0250	0375	0250	0000	0000	%0669	C22	\$	
007045	-01876	-02169	0500	0750	0750	0500	0250	0250	0000	0000	C05	\$	005801	000418	-03335	0500	0500	0750	0500	0500	0250	0000	%0346	C14	\$	006637	002379	-02372	0750	0500	0750	0250	0500	0250	0000	0000	%0670	C23	\$	
006104	-02978	-02996	0250	0750	0750	0750	0250	0250	0000	0000	C07	\$	004676	001067	-04297	0375	0375	0750	0625	0625	0250	0000	%0347	C15	\$	005843	003671	-02996	0750	0375	0750	0250	0625	0250	0000	0000	%0671	C24	\$	
005520	-03420	-03933	0125	0750	0750	0875	0250	0250	0000	0000	C08	\$	003574	001791	-05161	0250	0250	0750	0750	0750	0250	0000	%0348	C16	\$	005095	004872	-03463	0750	0250	0750	0250	0750	0250	0000	0000	%0672	C25	\$	
004847	-03599	-03699	0000	0750	0750	1000	0250	0250	0000	0000	C09	\$	002317	002821	-05928	0125	0125	0750	0875	0875	0250	0000	%0349	C17	\$	004253	006049	-03795	0750	0125	0750	0250	0875	0250	0000	0000	%0673	C26	\$	
007760	-001927	-00101	1000	0625	0625	0000	0375	0375	0000	0000	D01	\$	001220	003904	-06212	0000	0000	0750	1000	1000	0250	0000	%0350	C18	\$	003462	006856	-03785	0750	0000	0750	0250	1000	0250	0000	0000	%0674	C27	\$	
007720	001845	-00108	0875	0625	0625	0125	0375	0375	0000	0000	D02	\$	009082	-00315	-001552	1000	1000	0625	0000	0000	0375	0000	%0351	D10	\$	008028	-02427	-000274	0625	1000	0625	0375	0000	0375	0000	0000	%0675	D19	\$	
007357	000869	-00583	0750	0625	0625	0250	0375	0375	0000	0000	D03	\$	009005	-00340	-001487	0875	0875	0625	0125	0125	0375	0000	%0																	

009264	-00034	-00640	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
009220	-00113	-00694	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
008769	-00976	-01251	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
007905	-01356	-02176	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
007106	-01566	-02920	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
006400	-01634	-03512	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
005692	-01735	-04026	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
004806	-01798	-04510	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$
004096	-01863	-04895	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
003253	-00063	-00532	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
001800	-00065	-00610	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
008470	-00445	-01469	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
007616	-00840	-02371	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
006816	-01059	-03111	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
006127	-01182	-03676	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
005426	-01272	-04196	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
004641	-01310	-04681	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
003813	-01058	-05066	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
001817	-00147	-000276	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
008845	000289	-00122	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
008112	-00062	-01024	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
007271	-00485	-01973	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
006491	-00774	-02757	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
005808	-00905	-03399	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
005114	-00978	-03970	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
004311	-00978	-04530	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
003477	-00674	-04968	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
008819	000196	-001131	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
008466	000638	000726	0875	0750	0625	0125	0250	0375	0000	%0190	V02	\$
007733	000170	-00199	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
006890	-00265	-01173	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
006127	-00603	-02037	0500	0562	0625	0500	0437	0375	0000	%0193	V05	\$
005445	-00746	-02749	0375	0500	0625	0625	0500	0375	0000	%0194	V06	\$
004716	-00822	-03436	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
003895	-00768	-04098	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
003095	-00490	-04589	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
008440	000577	002117	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
008060	001851	-001631	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
007350	000592	-000762	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
006495	-00227	-00242	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
005715	-00418	-01159	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
005015	-00599	-01962	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$
004239	-00651	-02749	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
003453	-00679	-03472	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
002653	-00391	-04023	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
008043	001012	003022	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
007669	000458	002591	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
006966	001974	001713	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
006089	000285	000679	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
005272	-00148	-00286	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
004529	-00419	-01886	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
003782	-00375	-02031	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
002973	-00502	-02844	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
002211	-00299	-03411	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
007649	001465	003966	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
007287	001890	003500	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
006576	001400	002627	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
005651	000700	001529	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
004808	000301	000447	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
004084	000207	-00469	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
003316	-00297	-01336	0250	0250	0250	0750	0750	0750	0000	%0222	Y07	\$
002510	-00283	-02199	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
001740	-00011	-02878	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
007261	001234	005241	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
006887	002355	-004780	0875	0500	0125	0125	0500	0875	0000	%0226	Z02	\$
006146	001901	003864	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
005201	001213	002668	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
004377	000712	001580	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
003597	000388	000551	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
002823	000099	-00406	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
001990	-00016	-01390	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
001233	000181	-02165	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$
006833	002428	007595	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
006435	002867	007087	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
005663	002513	006020	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
004708	001742	-004699	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
003816	001224	003419	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
003053	000774	002348	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
002249	004067	001222	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
001451	000206	000136	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$
008833	000128	-00698	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009223	-00005	-00669	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
009176	-00073	-00715	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
008541	-00103	-01402	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
007671	-001862	-02262	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
006749	002574	-03855	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
005762	003328	-03805	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
004763	004095	-04460	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
003687	005014	-05005	0562	0250	1000	0875	0500	0000	0000	%0493	S17	\$
002583	005731	-05215	0500	1000	1000	0500	1000	0000	0000	%0494	S18	\$
009217	-00028	-00557	0937	1000	0875	0062	0100	0125	0000	%0495	T01	\$
009144	-00039	-00648	0875	0875	0875	0125	0125	0125	0000	%0496	T11	\$
008392	000574	-01492	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
007474	-001327	-02412	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
006531	-002012	-03232	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
005516	002823	-04803	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
004545	003656	-04647	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
003491	004646	-05199	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
002471	005458	-05444	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
009138	-00267	-00262	0875	1000	0750	0125	0000	0250	0000	%0504	U10	\$
008919	-00624	-00028	0812	0875	0750	0187	0125	0250	0000	%0505	U11	\$

See original or copy: <http://web.me.com/klaus.richter/GE18/GE18L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE08(7)_22_REM.TXT, Separation olv*, D50, not adapted S
%100 x LAB*          %1000 x (r g b c m y o)          %nr.   pos S
%Z003714 006286 003790 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008493 000057 009812 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z004305 -06046 003745 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005131 -03780 -03971 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z001233 004137 -06448 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z003853 007574 -03565 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z000825 000044 -00710 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009244 -00044 -00636 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z003714 006286 003790 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008493 000057 009812 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z004305 -06046 003745 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005131 -03780 -03971 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z001233 004137 -06448 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z003853 007574 -03565 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z000825 000044 -00710 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009244 -00044 -00636 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z003714 006286 003790 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008493 000057 009812 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z004305 -06046 003745 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005131 -03780 -03971 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z001233 004137 -06448 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z003853 007574 -03565 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z000825 000044 -00710 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009244 -00044 -00636 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005250 004552 005560 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008018 -00973 009194 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z004628 -05858 000624 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004893 -03280 -04185 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z001888 004766 -06107 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z003840 007476 -03297 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z000795 006043 -00690 %#0000 0000 0000 1000 1000 0000 0000 %0161 R09 %N251 6 $
%Z009229 -00017 -00657 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z006833 002428 007595 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006754 -03215 007302 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z004878 -05119 -01522 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004096 -01603 -04885 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z002683 005731 -05215 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z003784 007090 -01911 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z000809 000036 -00664 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009237 -00023 -00653 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z008098 000741 009279 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z005610 -04820 005565 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005098 -04112 -03433 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z002825 001078 -05860 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003570 007017 -04068 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z003739 006707 000187 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z000830 000039 -00700 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009263 -00041 -00644 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE18/GE18L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG GE08(7)_22.REM.TXT, Separation olv*, D50, not adapted S													
%100 x LAB*		1000 x (r g b		c m y θ		nmr.		pos \$					
000912	000011	-00699	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$	
002068	-00031	-01382	0125	0125	0125	0875	0875	0875	0000	%0973	k02	\$	
003375	-00167	-01368	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$	
004579	-00302	-01183	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$	
005780	-00419	-01139	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	
006984	-00288	-01153	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$	
008186	-00139	-00960	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$	
009209	-00108	-00691	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$	
010262	-00038	-00650	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$	
000909	000002	-00690	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$	
002070	-00039	-01383	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$	
003364	-00166	-01366	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$	
004565	-00296	-01195	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$	
005768	-00406	-01173	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	
006970	-00299	-01152	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$	
008169	-00135	-00967	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$	
009202	-00100	-00607	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$	
009265	-00041	-00646	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$	
000899	000004	-00694	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$	
002050	-00027	-01390	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$	
003343	-00168	-01357	0250	0250	0250	0750	0750	0750	0000	%0992	m03	\$	
004535	-00280	-01228	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$	
005750	-00403	-01180	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$	
006945	-00284	-01166	0625	0625	0625	0375	0375	0375	0000	%0995	m06	\$	
008170	-00132	-00979	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$	
009203	-00102	-00599	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$	
009264	-00042	-00641	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$	
000901	000001	-00700	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$	
002035	-00019	-01396	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$	
003331	-00164	-01382	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$	
004543	-00289	-01221	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$	
005752	-00408	-01176	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$	
006951	-00292	-01158	0625	0625	0625	0375	0375	0375	0000	%1004	n06	\$	
008176	-00130	-00978	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$	
009199	-00100	-00606	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$	
009263	-00041	-00648	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$	
000844	000023	-00735	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$	
001391	000080	-01216	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$	
002091	-00044	-01430	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$	
002805	-00220	-01359	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$	
003522	-00220	-01294	0266	0266	0266	0733	0733	0733	0000	%1012	k14	\$	
004172	-00262	-01137	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$	
004814	-00363	-01154	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$	
005444	-00426	-01150	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$	
006090	-00434	-01088	0533	0533	0533	0466	0466	0466	0000	%1016	k18	\$	
006704	-00336	-01099	0600	0600	0600	0399	0399	0399	0000	%1017	k19	\$	
007340	-00191	-01097	0666	0666	0666	0333	0333	0333	0000	%1018	k20	\$	
007984	-00120	-00980	0733	0733	0733	0266	0266	0266	0000	%1019	k21	\$	
008576	-00077	-00821	0800	0800	0800	0199	0199	0199	0000	%1020	k22	\$	
009134	-00124	-00568	0866	0866	0866	0133	0133	0133	0000	%1021	k23	\$	
009252	-00053	-00622	0933	0933	0933	0066	0066	0066	0000	%1022	k24	\$	
009244	-00039	-00624	1000	1000	1000	0000	0000	0000	0000	%1023	k25	\$	
000857	000029	-00736	0000	0000	0000	1000	1000	1000	0000	%1024	l10	\$	
001388	000089	-01217	0066	0066	0066	0933	0933	0933	0000	%1025	l11	\$	
002091	-00042	-01421	0133	0133	0133	0866	0866	0866	0000	%1026	l12	\$	
002786	-00199	-01392	0200	0200	0200	0800	0800	0800	0000	%1027	l13	\$	
003501	-00225	-01281	0266	0266	0266	0733	0733	0733	0000	%1028	l14	\$	
004154	-00249	-01160	0333	0333	0333	0666	0666	0666	0000	%1029	l15	\$	
004800	-00344	-01188	0400	0400	0400	0600	0600	0600	0000	%1030	l16	\$	
005449	-00419	-01154	0466	0466	0466	0533	0533	0533	0000	%1031	l17	\$	
006078	-00433	-01097	0533	0533	0533	0466	0466	0466	0000	%1032	l18	\$	
006699	-00322	-01108	0600	0600	0600	0399	0399	0399	0000	%1033	l19	\$	
007337	-00183	-01106	0666	0666	0666	0333	0333	0333	0000	%1034	l20	\$	
007984	-00121	-00983	0733	0733	0733	0266	0266	0266	0000	%1035	l21	\$	
008571	-00074	-00842	0800	0800	0800	0199	0199	0199	0000	%1036	l22	\$	
009127	-00124	-00577	0866	0866	0866	0133	0133	0133	0000	%1037	l23	\$	
009252	-00052	-00622	0933	0933	0933	0066	0066	0066	0000	%1038	l24	\$	
009237	-00040	-00625	1000	1000	1000	0000	0000	0000	0000	%1039	l25	\$	
000834	000027	-00749	0000	0000	0000	1000	1000	1000	0000	%1040	m10	\$	
001371	000094	-01216	0066	0066	0066	0933	0933	0933	0000	%1041	m11	\$	
002077	-00024	-01445	0133	0133	0133	0866	0866	0866	0000	%1042	m12	\$	
002766	-00196	-01379	0200	0200	0200	0800	0800	0800	0000	%1043	m13	\$	
003478	-00211	-01304	0266	0266	0266	0733	0733	0733	0000	%1044	m14	\$	
004148	-00244	-01181	0333	0333	0333	0666	0666	0666	0000	%1045	m15	\$	
004792	-00355	-01187	0400	0400	0400	0600	0600	0600	0000	%1046	m16	\$	
005416	-00426	-01157	0466	0466	0466	0533	0533	0533	0000	%1047	m17	\$	
006063	-00444	-01088	0533	0533	0533	0466	0466	0466	0000	%1048	m18	\$	
006690	-00319	-01109	0600	0600	0600	0399	0399	0399	0000	%1049	m19	\$	
007330	-00186	-01105	0666	0666	0666	0333	0333	0333	0000	%1050	m20	\$	
007982	-00117	-00981	0733	0733	0733	0266	0266	0266	0000	%1051	m21	\$	
008567	-00071	-00832	0800	0800	0800	0199	0199	0199	0000	%1052	m22	\$	

See original or copy: <http://web.me.com/klaus.richter/GE18/GE18L0NA.TXT/.PSS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1, Cx=0, cfi=1.00, nt=0

TUB registration: 20091101-GE18/GE18L0NA.TXT /PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

[illegible]

TUB-test chart GE18; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> oly* setrgbcolor
```


009264	-00011	000013	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
009220	-00090	-00040	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
008769	-00956	-00597	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
007905	-01343	-01521	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
007106	-01558	-02263	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
006400	-01631	-02855	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
005692	-01737	-03368	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
004806	-01806	-03851	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$
004086	-01617	-04225	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
009253	-00039	000120	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
009180	-00062	000042	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
008470	-00427	-00814	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
007616	-00829	-01715	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
006816	-01053	-02454	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
006127	-01181	-03018	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
005426	-01276	-03537	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
004641	-01320	-04021	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
003813	-01074	-04405	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
009187	-00124	000930	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
008845	003039	000531	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
008112	-00046	-00369	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
007271	-00476	-01317	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
006491	-00770	-02100	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
005808	-00906	-02731	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
005114	-00984	-03311	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
004311	-00990	-03870	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
003477	-00692	-04307	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
008819	000218	001785	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
008466	000654	001380	0875	0750	0625	0125	0250	0375	0000	%0190	V02	\$
007733	000263	000455	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
006890	-00258	-00516	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
006127	-00601	-01379	0500	0437	0562	0625	0500	0437	0000	%0193	V05	\$
005445	-00750	-02081	0375	0500	0625	0625	0625	0375	0000	%0194	V06	\$
004716	-00831	-02777	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
003895	-00782	-03438	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
003095	-00510	-03928	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
008440	000595	002772	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
008060	001866	002286	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
007350	000602	001418	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
006495	-00223	-000414	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
005715	-00420	-00501	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
005015	-00606	-01303	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$
004239	-00664	-02089	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
003453	-00697	-02811	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
002653	-00415	-03361	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
008043	001027	003677	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
007669	001470	003246	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
006966	000981	002370	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
006089	000266	001337	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
005272	-00153	-000372	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
004529	-00329	-00526	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
003782	-00491	-01371	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
002973	-00523	-02182	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
002211	-00326	-02748	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
007649	001477	004621	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
007287	001900	004156	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
006576	001487	003284	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
005651	000687	002187	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
004808	000293	001106	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
004084	000013	000190	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
003316	-00226	-00075	0250	0250	0250	0750	0750	0750	0000	%0222	Y07	\$
002510	-00308	-01536	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
001740	-00482	-02215	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
007261	001933	005897	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
006887	002361	005437	0875	0500	0125	0125	0500	0875	0000	%0226	Z02	\$
006146	001202	004522	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
005201	001907	003326	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
004377	000700	002240	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
003597	000371	001211	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
002823	000076	000254	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
001990	-00045	-00727	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
001233	000147	-01501	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$
008633	002434	008251	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
006435	002870	007744	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
005663	002511	006678	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
004708	001733	005359	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
003816	001208	004079	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
003253	000753	003010	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
002949	000448	001885	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
001451	000174	000799	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$
008433	-00008	-000033	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009223	000017	-00016	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
009176	000096	-00061	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
008541	001051	-00747	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
007671	001874	-01607	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
006749	002579	-02398	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
005762	003326	-03147	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
004763	004068	-03801	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
003687	004906	-04543	0562	0250	1000	0875	0875	0000	0000	%0493	S17	\$
002583	005787	-04553	0500	1000	1000	0500	1000	0000	0000	%0494	S18	\$
009217	-00005	000096	0937	1000	0875	0062	0100	0125	0000	%0495	T01	\$
009144	-00016	000004	0875	0875	0875	0125	0125	0125	0000	%0496	T11	\$
008392	000591	-00838	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
007474	001337	-01756	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
006531	002016	-02575	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
005516	002820	-03345	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
004545	003646	-03988	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
003491	004628	-04538	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
002471	005433	-04782	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
009138	-00245	000916	0875	1000	0750	0125	0000	0250	0000	%0504	T19	\$
008919	-00603	000625	0812	0875	0750	0187	0125	0250	0000	%0505		



See original or copy: <http://web.me.com/klaus.richter/GE18/GE18L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE08(7)_22_REM.TXT, Separation olv*, D50, adapted $
%100 x LAB*a          %1000 x (r g b c m y o)          %nr. pos $
%Z003714 006272 004475 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008493 000094 010455 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z004305 -06054 004425 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005131 -03779 -03298 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z001233 004097 -05741 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z003853 007562 -02881 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z000825 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009244 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z003714 006272 004475 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008493 000094 010455 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z004305 -06054 004425 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005131 -03779 -03298 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z001233 004097 -05741 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z003853 007562 -02881 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z000825 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009244 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z003714 006272 004475 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008493 000094 010455 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z004305 -06054 004425 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005131 -03779 -03298 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z001233 004097 -05741 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z003853 007562 -02881 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z000825 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009244 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005250 004541 006233 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008018 -00964 009857 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z004628 -05874 001299 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004893 -03294 -03510 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z001888 004730 -05421 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z003840 007454 -02618 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z000795 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009229 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z006833 002434 008251 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006754 -03210 007959 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z004878 -05127 -00863 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004096 -01617 -04225 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z002683 005707 -04553 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z003784 007075 -01250 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z000809 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009237 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z008098 000771 009932 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z005610 -04814 006234 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005098 -04110 -02760 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z002825 001058 -05173 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003570 007004 -03386 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z003739 006695 000869 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z000830 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009263 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE18/GE18L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE08(7)_22_REM.TXT, Separation olv*, D50, adapted S
%100 x LAB*a      1000 x (r g b      c m y θ)      %nr. pos $
000912 -00035 -00049 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002068 -00065 -00737 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003375 -00188 -00727 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004579 -00310 -00546 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005780 -00414 -00507 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006984 -00270 -00525 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
008186 -00108 -00336 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
009208 -00058 -00017 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
010262 -00004 -00030 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
009099 -00044 -00040 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002070 -00073 -00738 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003364 -00187 -00725 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004565 -00304 -00559 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005768 -00401 -00541 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006970 -00272 -00524 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
008169 -00104 -00344 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
009202 -00058 -00012 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009265 -00001 -00026 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
008099 -00042 -00045 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002050 -00062 -00745 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003343 -00189 -00716 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004535 -00288 -00592 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
005750 -00398 -00548 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006945 -00266 -00538 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
008170 -00101 -00355 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
009203 -00061 -00020 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009264 -00000 -00022 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
009091 -00044 -00051 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002035 -00054 -00750 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003331 -00185 -00742 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004543 -00297 -00585 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005752 -00403 -00544 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006954 -00274 -00530 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
008176 -00089 -00355 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
009199 -00059 -00013 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009263 -00000 -00028 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
009844 -00023 -00085 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
001391 -00038 -00568 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002091 -00078 -00785 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
002805 -00246 -00717 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
003522 -00239 -00654 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
004172 -00274 -00500 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
004814 -00368 -00519 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005444 -00425 -00517 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
006090 -00426 -00457 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006704 -00321 -00471 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
007340 -00169 -00471 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007984 -00092 -00356 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
008576 -00042 -00199 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
009134 -00083 -000051 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
009252 -00011 -00003 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009244 -00002 -00005 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
008057 -00017 -00086 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
001388 -00047 -00570 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
002091 -00076 -00776 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
002786 -00226 -00750 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
003501 -00244 -00641 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
004154 -00232 -00622 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
004800 -00349 -00552 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005449 -00417 -00521 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
006078 -00424 -00466 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006699 -00307 -00480 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
007337 -00162 -00479 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007984 -00092 -00359 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
008571 -00039 -00220 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
009127 -00083 -00042 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
009252 -00010 -00002 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009237 -00001 -00005 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
008034 -00020 -00099 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
001371 -00052 -00568 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002077 -00059 -00800 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
002766 -00223 -00736 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
003478 -00231 -00663 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
004148 -00256 -00543 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
004792 -00360 -00552 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005416 -00425 -00524 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
006063 -00436 -00457 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006690 -00304 -00480 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
007330 -00164 -00479 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007982 -00088 -00357 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
008567 -00036 -00210 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE18; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: ->olv* setrgbcolor

TUB registration: 20091101-GE18/GE18L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta