

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE51/GE51L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.95; nt=0.18; nx=1.00

TUB registration: 20091101-GE51/GE51L0NP.PDF /.PS TUB material: code=rha4ta
- application for evaluation and measurement of printer or monitor systems

S		B6E		G41		22.TXT		Separation		cmlyb*		cf1=0.90		D65		not		adapted		S	
x100 x LAB		1000		x (r g b		x m y b		pos s		x m y b		pos s		x m y b		pos s		x m y b		pos s	
009743	-00999	000199	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
009812	-00532	000482	0875	1000	0000	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
008638	-00846	-01053	0750	1000	0000	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
007973	-01163	-01327	0625	1000	0000	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
007436	-01735	-01490	0500	1000	0000	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
006878	-01971	-02139	0375	1000	0000	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
006296	-02474	-02742	0250	1000	0000	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005840	-02921	-03191	0125	1000	0000	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005367	-03412	-03741	0000	1000	0000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
000921	-000832	000627	1000	0875	0000	0000	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
008769	000063	000148	0875	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
008273	-00393	-00337	0750	0875	0875	0875	0250	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
007530	-00803	-00947	0625	0875	0875	0875	0375	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
007028	-01231	-01380	0500	0875	0875	0875	0500	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
006519	-01613	-01811	0375	0875	0875	0875	0625	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005906	-01937	-02481	0250	0875	0875	0875	0750	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005482	-02242	-02751	0125	0875	0875	0875	0875	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005022	-02712	-03111	0000	0875	0875	0875	1000	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
004800	001347	000976	1000	0750	0750	0000	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
008145	000583	000608	0875	0750	0750	0125	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
007905	000990	000995	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
007293	-00411	-00455	0625	0750	0750	0375	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
006701	-00788	-00922	0500	0750	0750	0500	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
006276	-00902	-01028	0000	0750	0750	0875	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005670	-01672	-01860	0250	0750	0750	0750	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005131	-01985	-02361	0125	0750	0750	0875	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
004754	-02249	-02693	0000	0750	0750	1000	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
007658	002196	001469	1000	0625	0625	0000	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
007587	001418	001066	0875	0625	0625	0125	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
007352	000763	000500	0750	0625	0625	0250	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
006848	000126	000025	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
006357	-00314	-00293	0500	0625	0625	0500	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005930	-00792	-00832	0375	0625	0625	0625	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005309	-01303	-01400	0250	0625	0625	0875	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
004867	-01705	-01825	0125	0625	0625	0750	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
004451	-01759	-02270	0000	0625	0625	1000	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
007019	003050	001872	1000	0500	0500	0000	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
006961	002220	001457	0875	0500	0500	0125	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
006734	001467	000268	0750	0500	0500	0250	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
006306	000821	000458	0625	0500	0500	0375	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005962	000086	000138	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005590	-00280	-00356	0375	0500	0500	0625	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005227	-00895	-00970	0250	0500	0500	0750	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
004646	-01270	-01501	0125	0500	0500	0875	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
004148	-01464	-01797	0000	0500	0500	1000	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
006515	003719	002435	1000	0375	0375	0000	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
006379	002860	001985	0875	0375	0375	0125	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
006145	000006	000000	0875	0375	0375	0250	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005745	001423	001116	0625	0375	0375	0375	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005580	000834	000483	0500	0375	0375	0500	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005233	000613	000004	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
004888	-00432	-00489	0250	0375	0375	0750	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
004450	-00978	-00941	0125	0375	0375	0875	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
003848	-01181	-01507	0000	0375	0375	1000	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
006022	004424	003080	0000	0250	0250	0000	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005691	003554	002475	0875	0250	0250	0125	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005400	002820	002029	0750	0250	0250	0250	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
005114	002130	001532	0625	0250	0250	0375	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
004975	001432	001102	0500	0250	0250	0500	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
004846	000825	000430	0375	0250	0250	0625	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
004462	000182	-00072	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	
004215	-00458	-00540	0125	0250	0250</																

TUB-test chart GE51; Relative Device Colour System
1080 spectral reflexions R → LAB* for D65 and D50

input: w *setgray*
output: no change compared to input

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE51/GE51L0NP.PDF> / <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.95, nt=

TUB registration: 20091101-GE51/GE51L0NP.PDF /.PS TUB material application for evaluation and measurement of printer or monitor systems

IUB material: code=rha4ta

TUB-test chart GE51; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

[illegible]

009738	-00097	000192	1000	1000	1000	0000	0000	0000	0000	%0162	S01		009728	-00104	000217	1000	1000	1000	0000	0000	0000	%0486	S10		009719	-00094	0000191	1000	1000	1000	0000	0000	0000	0000	%0810	S19		
009905	-00077	-00608	0875	0937	1000	0125	0062	0000	0000	%0163	S02		008952	000447	-00391	0937	0875	1000	0062	0125	0000	0000	%0487	S11		009061	000772	0001113	1000	0875	0937	0000	0125	0062	0000	%0811	S20	
008414	-01336	-01055	0750	0875	1000	0250	0125	0000	0000	%0164	S03		008460	000822	-00796	0875	0750	1000	0125	0250	0000	0000	%0488	S12		008459	001445	000526	1000	0750	0875	0000	0250	0125	0000	%0812	S21	
007740	-00204	-01364	0625	0812	1000	0375	0187	0000	0000	%0165	S04		007833	001281	-01169	0812	0625	1000	0187	0375	0000	0000	%0489	S13		007809	002295	000575	1000	0625	0812	0000	0375	0187	0000	%0813	S22	
006882	-00164	-01713	0500	0750	1000	0500	0250	0000	0000	%0166	S05		007022	001769	-01392	0750	0500	1000	0250	0500	0000	0000	%0490	S14		007237	003093	000658	1000	0500	0750	0000	0500	0250	0000	%0814	S23	
006319	-00268	-02291	0375	0687	1000	0625	0312	0000	0000	%0167	S06		006095	002495	-01714	0687	0375	1000	0312	0625	0000	0000	%0491	S15		006567	004013	001063	1000	0375	0687	0000	0625	0312	0000	%0815	S24	
005564	-00319	-02826	0250	0625	1000	0750	0375	0000	0000	%0168	S07		005241	002978	-02026	0625	0250	1000	0375	0750	0000	0000	%0492	S16		005955	004925	001301	1000	0250	0625	0000	0750	0375	0000	%0816	S25	
004844	-00383	-03299	0125	0500	1000	0875	0500	0000	0000	%0169	S08		004516	003355	-02359	0500	0125	1000	0500	0875	0000	0000	%0493	S17		005360	005762	001472	1000	0125	0500	0000	0875	0437	0000	%0817	S26	
004365	-00375	-03784	0000	0500	1000	1000	0500	0000	0000	%0170	S09		003732	004172	-03025	0500	0000	1000	0500	1000	0000	0000	%0494	S18		004584	006759	001740	1000	0000	0500	0000	1000	0500	0000	%0818	S27	
009224	000279	000761	1000	0937	0875	0000	0062	0125	0000	%0171	T01		000416	-00309	000642	0937	1000	0875	0062	0000	0125	0000	%0495	T10		009197	-00728	-00114	0875	1000	0937	0125	0000	0062	0000	%0819	T19	
008751	000060	000136	0875	0875	0875	0125	0125	0125	0000	%0172	T02		008887	000036	000145	0875	0875	0875	0125	0125	0125	0000	%0496	T11		008836	000090	000104	0875	0875	0875	0125	0125	0125	0000	%0820	T20	
008124	-00014	-00363	0750	0812	0875	0250	0187	0125	0000	%0173	T03		008183	000431	-00431	0812	0750	0875	0187	0250	0125	0000	%0497	T12		008162	000678	000333	0875	0750	0812	0125	0250	0187	0000	%0821	T21	
007376	-00175	-00887	0625	0750	0875	0375	0250	0125	0000	%0174	T04		007596	000842	-00629	0750	0625	0875	0250	0375	0125	0000	%0498	T13		007648	001427	000568	0875	0625	0750	0125	0375	0250	0000	%0822	T22	
006668	-00166	-01339	0500	0687	0875	0500	0312	0125	0000	%0175	T05		006743	001342	-00992	0687	0500	0875	0312	0500	0125	0000	%0499	T14		006956	002408	000479	0875	0500	0687	0125	0500	0312	0000	%0823	T23	
006055	-00192	-01811	0375	0625	0875	0625	0375	0125	0000	%0176	T06		005783	001915	-01306	0625	0375	0875	0375	0625	0125	0000	%0500	T15		006361	002995	000779	0875	0375	0625	0125	0625	0375	0000	%0824	T24	
005398	-00292	-02415	0250	0562	0875	0750	0437	0125	0000	%0177	T07		005084	002549	-01694	0562	0250	0875	0437	0750	0125	0000	%0501	T16		005628	003978	001018	0875	0250	0562	0125	0750	0437	0000	%0825	T25	
004648	-00200	-03008	0125	0500	0875	0875	0500	0125	0000	%0178	T08		004393	003026	-02108	0500	0125	0875	0500	0875	0125	0000	%0502	T17		004993	004508	001146	0875	0125	0500	0125	0875	0500	0000	%0826	T26	
004095	-00219	-03403	0000	0437	0875	1000	0562	0125	0000	%0179	T09		003605	003607	-02648	0437	0000	0875	0562	1000	0125	0000	%0503	T18		004168	005738	001316	0875	0000	0437	0125	1000	0562	0000	%0827	T27	
008886	000563	001337	1000	0875	0750	0000	0125	0250	0000	%0180	U01		009241	-01076	001376	0875	1000	0750	0125	0000	0250	0000	%0504	U10		008804	-01250	-00149	0750	1000	0875	0250	0000	0125	0000	%0828	U19	
008421	000104	000921	0875	0812	0750	0125	0187	0250	0000	%0181	U02		008554	-00434	000829	0812	0875	0750	0187	0125	0250	0000	%0505	U11		008261	-00412	-00077	0750	0875	0812	0250	0125	0187	0000	%0829	U20	
007944	000181	000097	0750	0750	0750	0250	0250	0250	0000	%0182	U03		008007	000075	000114	0750	0750	0250	0250	0250	0000	%0506	U12		007960	000093	000106	0750	0750	0750	0250	0250	0250	0000	%0830	U21		
007186	-00037	-00360	0625	0687	0750	0375	0312	0250	0000	%0183	U04		007381	000397	-00322	0687	0625	0750	0312	0375	0250	0000	%0507	U13		007376	000791	000226	0750	0625	0687	0250	0375	0312	0000	%0831	U22	
006492	-00121	-00874	0500	0625	0750	0500	0375	0250	0000	%0184	U05		006455	-001056	-00710	0625	0500	0750	0375	0500	0250	0000	%0508	U14		006769	001504	000424	0750	0500	0625	0250	0500	0375	0000	%0832	U23	
005893	-00203	-01468	0375	0562	0750	0625	0437	0250	0000	%0185	U06		005705	-001595	-01111	0562	0375	0750	0437	0625	0250	0000	%0509	U15		006044	002219	000538	0750	0375	0562	0250	0625	0437	0000	%0833	U24	
005248	-00290	-01994	0250	0500	0875	0750	0500	0250	0000	%0186	U07		004977	002076	-01474	0500	0250	0750	0500	0750	0250	0000	%0510	U16		005272	003073	000811	0750	0250	0500	0250	0750	0500	0000	%0834	U25	
004598	-00277	-02504	0125	0437	0750	0875	0562	0250	0000	%0187	U08		004305	002526	-01819	0437	0125	0750	0562	0875	0250	0000	%0511	U17		004622	003811	000957	0750	0125	0437	0250	0875	0562	0000	%0835	U26	
003955	-00167	-02914	0000	0375	0750	1000	0625	0250	0000	%0188	U09		003501	003061	-02310	0375	0000	0750	0625	1000	0250	0000	%0512	U18		003877	004686	001131	0750	0000	0375	0250	1000	0625	0000	%0836	U27	
008479	000803	002194	1000	0812	0625	0000	0187	0375	0000	%0189	V01		008971	-01663	002638	0812	1000	0625	0187	0000	0375	0000	%0513	V10		008198	-01905	-00207	0625	1000	0812	0375	0000	0187	0000	%0837	V19	
008053	000535	001510	0875	0750	0625	0125	0250	0375	0000	%0190	V02		008344	-00924	001242	0750	0875	0625	0250	0125	0375	0000	%0514	V11		007577	-01128	-00082	0625	0875	0750	0375	0125	0250	0000	%0838	V20	
007647	000228	000762	0750	0687	0625	0250	0312	0375	0000	%0191	V03		007694	-00338	000598	0687	0750	0625	0312	0250	0375	0000	%0515	V12		007296	-00480	-00097	0625	0750	0687	0375	0250	0312	0000	%0839	V21	
006881	000116	000031	0625	0625	0625	0375	0375	0375	0000	%0192	V04		007918	000808	000046	0625	0625	0625	0375	0375	0375	0000	%0516	V13		006890	000142	000018	0625	0625	0625	0375	0375	0375	0000	%0840	V22	
006174	-00001	-00240	0500	0562	0625	0500	0437	0375	0000	%0193	V05		006249	000482	-00418	0562	0500	0625	0437	0500	0375	0000	%0517	V14		006270	000866	000222	0625	0500	0562	0375	0500	0437	0000	%0841	V23	
005704	-00150	-00975	0375	0500	0625	0625	0625	0375	0000	%0194	V06		005610	-001051	-00731	0500	0375	0625	0500	0625	0375	0000	%0518	V15		005518	001547	000508	0625	0375	0500	0375	0625	0500	0000	%0842	V24	
004933	-00180	-01617	0250	0437	0625	0750	0562	0375	0000	%0195	V07		004836	001587	-01162	0437	0250	0625	0562	0750	0375	0000	%0519	V16		004808	002209	000761	0625	0500	0437	0375	0750	0562	0000	%0843	V25	
004482	-00294	-02086	0125	0375	0625	0875	0625	0375	0000	%0196	V08		004201	002030	-01427	0375	0125	0625	0625	0875	0375	0000	%0520	V17		004180												

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-GE51/GE51L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rh4ta

TUB-test chart GE51; Relative Device Colour System CIE
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE51/GE51L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.95; nt=0.18; nx=1.00

009744	-00103	000211	1000	1000	1000	0000	0000	0000	0000	00243	b01
008993	000109	-00649	0875	0906	1000	0125	0093	0000	0000	00244	b02
008365	000222	-01066	0750	0812	1000	0250	0187	0000	0000	00245	b03
007725	000328	-01476	0625	0718	1000	0375	0281	0000	0000	00246	b04
006712	000444	-01864	0500	0625	1000	0500	0375	0000	0000	00247	b05
006099	000520	-02314	0375	0531	1000	0625	0468	0000	0000	00248	b06
005367	000530	-02831	0250	0437	1000	0750	0562	0000	0000	00249	b07
004608	000656	-03374	0125	0343	1000	0875	0656	0000	0000	00250	b08
003902	000942	-03786	0000	0250	1000	1000	0750	0000	0000	00251	b09
003398	000106	-000793	1000	0968	0875	0000	0031	0125	0000	00252	c01
008738	000070	-000140	0875	0875	0875	0125	0125	0125	0000	00253	c02
008064	000098	-00363	0750	0781	0875	0250	0218	0125	0000	00254	c03
007353	000096	-00092	0625	0687	0875	0375	0312	0125	0000	00255	c04
006474	000302	-01358	0500	0593	0875	0500	0366	0125	0000	00256	c05
005900	000324	-01358	0500	0593	0875	0500	0366	0125	0000	00257	c06
005097	000474	-02400	0250	0406	0875	0750	0593	0125	0000	00258	c07
004333	000802	-03106	0125	0312	0875	0875	0687	0125	0000	00259	c08
003612	001321	-03351	0000	0218	0875	1000	0781	0125	0000	00260	c09
009105	000171	-001563	1000	0937	0750	0000	0062	0250	0000	00261	d01
008505	000050	-001054	0875	0843	0750	0125	0156	0250	0000	00262	d02
007911	000081	-000093	0750	0750	0750	0250	0250	0250	0000	00263	d03
007160	000146	-00379	0625	0656	0750	0375	0343	0250	0000	00264	d04
006358	000251	-00859	0500	0562	0750	0500	0437	0250	0000	00265	d05
005713	000322	-01470	0375	0468	0750	0625	0531	0250	0000	00266	d06
004858	000558	-02123	0250	0375	0750	0750	0625	0250	0000	00267	d07
004124	000708	-02707	0125	0281	0750	0875	0718	0250	0000	00268	d08
003485	000944	-02942	0000	0187	0750	1000	0812	0250	0000	00269	d09
008825	000196	-002625	1000	0906	0625	0000	0093	0375	0000	00270	e01
008323	000096	-001667	0875	0812	0625	0125	0187	0375	0000	00271	e02
007799	000042	-000956	0750	0718	0625	0250	0281	0375	0000	00272	e03
006912	000096	-000034	0625	0625	0625	0375	0375	0375	0000	00273	e04
006176	000124	-02063	0500	0531	0625	0500	0468	0375	0000	00274	e05
005585	000225	-00934	0375	0437	0625	0625	0562	0375	0000	00275	e06
004716	000411	-01666	0250	0343	0625	0750	0656	0375	0000	00276	e07
004089	000457	-02194	0125	0250	0625	0875	0590	0375	0000	00277	e08
003400	000771										

009738	-000981	011399	1000	1000	1000	0000	0000	0000	0000	00567
008986	000591	-00382	0968	0875	1000	0031	0125	0000	0000	00568
008436	001182	-06634	0937	0750	1000	0062	0250	0000	0000	00569
007808	001686	-00678	0906	0625	1000	0093	0375	0000	0000	00570
007139	002383	-00982	0875	0500	1000	0125	0500	0000	0000	00571
006447	002979	-11196	0843	0375	1000	0156	0625	0000	0000	00572
005706	003735	-11476	0812	0250	1000	0187	0750	0000	0000	00573
004998	004466	-01770	0781	0125	1000	0218	0875	0000	0000	00574
004049	005678	-02093	0750	0000	1000	0250	1000	0000	0000	00575
003936	-000269	000532	0906	1000	0875	0093	0000	0125	0000	00576
008858	000059	000128	0875	0875	0875	0125	0125	0125	0000	00577
008198	000153	-00318	0843	0750	0875	0156	0250	0125	0000	00578
007549	001115	-00539	0812	0625	0875	0187	0375	0125	0000	00579
006699	000189	-00779	0781	0500	0875	0218	0500	0125	0000	00580
005230	-002350	000000	0750	0000	0875	0250	0500	0125	0000	00581
005423	003244	-01212	0718	0250	0875	0281	0575	0125	0000	00582
004648	003798	-00636	0687	0125	0875	0312	0875	0125	0000	00583
003781	004862	-01188	0656	0000	0875	0343	1000	0125	0000	00584
009058	-01320	00100	0812	1000	0750	0187	0000	0250	0000	00585
008522	-00559	000678	0781	0875	0750	0218	0125	0250	0000	00586
008058	000066	000124	0750	0750	0750	0250	0250	0250	0000	00587
007476	000572	-00293	0718	0625	0750	0281	0375	0250	0000	00588
006768	001209	-00338	0687	0500	0750	0312	0500	0250	0000	00589
005871	-001818	-00080	0656	0375	0750	0343	0625	0250	0000	00590
005199	002547	-01025	0625	0250	0750	0375	0575	0250	0000	00591
004466	003136	-01336	0593	0125	0750	0406	0875	0250	0000	00592
003741	003928	-01605	0562	0000	0750	0437	1000	0250	0000	00593
008628	-01961	001764	0718	1000	0625	0281	0000	0375	0000	00594
008182	-01337	001170	0687	0875	0625	0312	0125	0375	0000	00595
007539	-00541	000524	0656	0750	0625	0343	0250	0375	0000	00596
007028	000007	000083	0625	0625	0625	0375	0375	0375	0000	00597
006286	000685	-00363	0593	0500	0625	0406	0500	0375	0000	00598
005677	001263	-00589	0562	0375	0625	0437	0625	0375	0000	00599
005004	001393	-00942	0531	0250	0625	0468	0750	0375	0000	00600
004343	002665	-01046	0500	0125	0625	0500	0875	0375	0000	00601
003534	003320	-01448	0468	0000	0625	0531	1000	0375	0000	00602
007994	-00829	002521	0625	1000	0500	0375	0000	0500	0000	00603
007582	-01286	001763	0593	0875	05					

[illegible][illegible]

XBBE GAL4.22.TXT, Separation cmy0*, cf1=0.90, D65, not adapted \$												
%100 x LAB*	%1000 x (r g b c m y 0)				%nrr.		pos \$					
%004632	006414	004140	%#1000	0000	0000	0000	1000	1000	0000	%0072	T01	%01 0 \$
%009070	-01341	008695	%#1000	1000	0000	0000	0000	1000	0000	%0396	T10	%Y1 1 \$
%005698	-06212	003344	%#0000	1000	0000	1000	0000	1000	0000	%0720	T19	%L1 2 \$
%005367	-03412	-03741	%#0000	1000	1000	1000	0000	0000	0000	%0008	A09	%C1 3 \$
%003336	002556	-04169	%#0000	0000	1000	1000	1000	0000	0000	%0332	A18	%V1 4 \$
%004583	006832	-01261	%#1000	0000	1000	0000	1000	0000	0000	%0656	A27	%M1 5 \$
%002753	000080	-00167	%#0000	0000	0000	1000	1000	1000	0000	%0080	T09	%M1 6 \$
%009737	-00097	000196	%#1000	1000	1000	0000	0000	0000	0000	%0000	A01	%M1 7 \$
%%\$												
%004632	006414	004140	%#1000	0000	0000	0000	1000	1000	0000	%0072	T01	%02 0 \$
%009070	-01341	008695	%#1000	1000	0000	0000	0000	1000	0000	%0396	T10	%Y2 1 \$
%005698	-06212	003344	%#0000	1000	0000	1000	0000	1000	0000	%0720	T19	%L2 2 \$
%005367	-03412	-03741	%#0000	1000	1000	1000	0000	0000	0000	%0008	A09	%C2 3 \$
%003336	002556	-04169	%#0000	0000	1000	1000	1000	0000	0000	%0332	A18	%V2 4 \$
%004583	006832	-01261	%#1000	0000	1000	0000	1000	0000	0000	%0656	A27	%M2 5 \$
%002753	000080	-00167	%#0000	0000	0000	1000	1000	1000	0000	%0080	T09	%M2 6 \$
%009737	-00097	000196	%#1000	1000	1000	0000	0000	0000	0000	%0000	A01	%M2 7 \$
%%\$												
%004632	006414	004140	%#1000	0000	0000	0000	1000	1000	0000	%0072	T01	%000Y 0 \$
%009070	-01341	008695	%#1000	1000	0000	0000	0000	1000	0000	%0396	T10	%Y00L 1 \$
%005698	-06212	003344	%#0000	1000	0000	1000	0000	1000	0000	%0720	T19	%00C 2 \$
%005367	-03412	-03741	%#0000	1000	1000	1000	0000	0000	0000	%0008	A09	%000V 3 \$
%003336	002556	-04169	%#0000	0000	1000	1000	1000	0000	0000	%0332	A18	%000V 4 \$
%004583	006832	-01261	%#1000	0000	1000	0000	1000	0000	0000	%0656	A27	%M00 5 \$
%002753	000080	-00167	%#0000	0000	0000	1000	1000	1000	0000	%0080	T09	%M001 6 \$
%009737	-00097	000196	%#1000	1000	1000	0000	0000	0000	0000	%0000	A01	%M01 7 \$
%%\$												
%005747	004545	005188	%#1000	0250	0000	0000	0750	1000	0000	%0153	R01	%Y25Y 0 \$
%008160	-02886	007660	%#0750	1000	0000	0250	0000	1000	0000	%0477	R10	%C25L 1 \$
%005610	-05082	000753	%#0000	1000	0250	1000	0000	0750	0000	%0801	R19	%L25C 2 \$
%004728	-01387	-03746	%#0000	0750	1000	1000	0250	0000	0000	%0089	J09	%C25V 3 \$
%003366	003342	-0										

TUB-test chart GE51; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

TUB registration: 20091101-GE51/GE51L0NP.PDF /.PS
application for evaluation and measurement of printer or

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/GE51/GE51L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.95; nt=0.18; nx=1.0

```
%BEG GE41.22.TXT, Separation cmy0*, cfi=0.90, D65, not adapted $
%100 x LAB*          1000 x (r g b c m y 0)      %nr. pos $
002541 000073 -00117 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
003358 000047 -00014 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
004214 000176 -00050 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
005015 000165 000015 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005942 000064 000129 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006994 000102 000021 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
008018 000070 000094 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008877 000063 000123 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009756 000097 000193 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
002485 000081 -00127 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
003309 000049 -00021 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
004130 000182 -00068 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004988 000188 -00023 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005884 000081 000090 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006948 000103 000026 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
008018 000085 000087 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
008866 000079 000119 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009752 -00101 000206 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
002511 000082 -00125 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
003310 000054 -00007 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
004159 000194 -00058 0250 0250 0250 0750 0750 0750 0000 %0992 k03 $
004939 000193 -00005 0375 0375 0375 0625 0625 0625 0000 %0993 k04 $
005876 000079 000105 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006910 000097 000043 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
008005 000073 000106 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
008868 000049 000134 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009758 -00101 000204 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
002572 000078 -00118 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
003372 000050 000001 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
004174 000173 -00046 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004998 000174 000011 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005916 000072 000101 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006909 000095 000033 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
008030 000071 000098 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008919 000049 000139 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009748 -00092 000183 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
002853 000077 -00176 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
003289 000101 -00094 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
003625 000034 000001 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
004092 000122 -00084 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
004395 000158 -00042 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
004857 000091 000052 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
005277 000149 000065 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005688 000179 000057 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
006206 000096 000106 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006707 000134 000089 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
007384 000084 000084 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007883 000098 000106 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
008184 000066 000129 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
008630 000000 000167 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
009170 000074 -00044 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009749 -00093 000183 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
002830 000075 -00166 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
003266 000114 -00091 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
003650 000030 000021 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
004111 000127 -00078 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
004396 000170 -00037 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
004880 000112 000044 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
005265 000158 000059 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005722 000189 000027 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
006210 000109 000053 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006698 000154 000029 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
007353 000063 000079 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007835 000085 000096 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
008159 000049 000132 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
008603 000094 000161 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
009204 000066 -00035 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009752 -00091 000186 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
002808 000095 -00160 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
003273 000109 -00075 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
003609 000037 000030 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
004072 000135 -00075 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
004368 000185 -00038 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
004849 000110 000064 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
005250 000160 000051 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005712 000189 000052 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
006169 000102 000071 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006654 000146 000065 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
007376 000072 000074 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007834 000085 000104 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
008159 000059 000127 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE51; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: ->olv* setrgbcolor

TUB registration: 20091101-GE51/GE51L0NP.PDF /.PS
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart GE51; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```

TUB registration: 20091101-GE51/GE51L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IUB material: code=rh4ta

See original or copy: <http://web.me.com/klaus.richter/GE51/GE51L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.95; nt=0.18; nx=1.00

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009738	000001	-000008	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
009905	000001	-007770	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
008414	-00073	-01184	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
007740	-00159	-01457	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
006882	-00142	-01760	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
006319	-00252	-02306	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
005564	-00332	-02801	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
004844	-00412	-03240	0125	0625	1000	0875	0507	0000	0000	%0169	S08	\$
004365	-00419	-03684	0000	0625	1000	1000	0500	0000	0000	%0170	S09	\$
009224	-000364	-000588	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
008751	-00313	-00011	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
008124	-00041	-00476	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
007376	-00199	-00960	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
006668	-00149	-01365	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
006055	-00191	-01813	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
005398	-00309	-02381	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
004648	-00237	-02934	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
004095	-00271	-03299	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
008886	-00639	-001182	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
008421	-000247	-000791	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
007944	-000152	-00006	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
007186	-00007	-00423	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
006492	-00109	-00899	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
005893	-00207	-01461	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
005248	-00311	-01952	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
004598	-00316	-02426	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
003955	-00222	-02802	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
008479	-000868	-002061	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
008053	-000589	-001401	0875	0750	0625	0125	0250	0375	0000	%0190	V02	\$
007647	-000271	-006074	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
006881	-000139	-00014	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
006174	-00002	-00248	0500	0562	0625	0500	0437	0375	0000	%0193	V05	\$
005704	-00159	-00957	0375	0500	0625	0625	0625	0375	0000	%0194	V06	\$
004933	-00210	-01550	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
004482	-00335	-02002	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
003866	-00308	-02383	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
008154	-00182	-002806	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
007727	-000821	-002144	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
007264	-000537	-001443	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
006500	-000319	-000755	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
006011	-000047	-000134	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
005435	-000049	-00243	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$
004798	-00104	-00991	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
004187	-00261	-01508	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
003605	-00281	-01890	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
007687	-001565	-003550	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
007339	-001197	-002832	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
006850	-000881	-002184	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
006204	-000630	-001548	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
005769	-000353	-000709	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
005201	-000140	-000030	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
004703	-00014	-00478	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
004049	-00135	-01109	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
003448	-00281	-01330	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
007324	-002009	-004194	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
006855	-001608	-003612	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
006388	-001227	-002916	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
005814	-000906	-002208	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
005399	-000679	-001556	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
005046	-000371	-000767	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
004405	-000149	-000013	0250	0250	0250	0500	0750	0750	0000	%0222	Y07	\$
004009	-00003	-00584	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
003261	-00148	-01094	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
006953	-002478	-005052	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
006511	-001831	-004291	0875	0500	0125	0125	0625	0875	0000	%0226	Z02	\$
005891	-001609	-003625	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
005406	-001269	-002963	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
004987	-000976	-002292	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
004582	-000617	-001481	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
004272	-000245	-000729	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
003694	-000000	-000081	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
003176	-00017	-00411	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$
006642	-002918	-005915	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
006043	-002121	-005120	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
005527	-001946	-004261	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
005070	-001588	-003546	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
004691	-001353	-002922	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
004111	-000892	-002081	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
003891	-000690	-001379	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
003540	-000247	-000682	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$
002954	-00010	-00004	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009728	-00005	-000016	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
008952	-000525	-00549	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
008460	-000886	-00927	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
007833	-001329	-01267	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
007022	-001796	-01446	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
006095	-002497	-01717	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
005241	-002957	-01984	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
004516	-003264	-02278	0562	0250	1000	0875	0500	0000	0000	%0493	S17	\$
003732	-00411	-0281	0500	0000	1000	0500	1000	0000	0000	%0494	S18	\$
000416	-003009	-000459	0937	1000	0875	0062	0100	0125	0000	%0495	T10	\$
008887	-000112	-00009	0875	0875	0125	0125	0125	0000	0000	%0496	T11	\$
008183	-000488	-00548	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
007506	-000881	-00709	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
006743	-001361	-01830	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
005783	-001909	-01293	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
005084	-002524	-01643	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
004393	-002983	-02020	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
003605	-003542	-02517	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
002941	-000991	-001202	0875	1000	0750	0125	0000	0250	0000	%0504	T19	\$
008554	-003637	-000692	0812	0875	0750	0187	0125	0250				

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-GE51/GE51L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IUB material: code=rha4ta

TUB-test chart GE51; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE51/GE51L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.95; nt=0.18; nx=1.0

[illegible]

See original or copy: <http://web.me.com/klaus.richter/GE51/GE51L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.95; nt=0.18; nx=1.0

```
%BEG GE41_22.TXT, Separation cmy0*, cfi=0.90, D65, adapted S
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr.   pos $
%z004632 006381 004210 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z009070 -01261 008533 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z005698 -06218 003358 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005367 -03426 -03710 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z003336 002490 -04032 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z004583 006798 -01189 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z002753 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009737 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W1 7 $
%S
%z004632 006381 004210 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z009070 -01261 008533 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z005698 -06218 003358 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005367 -03426 -03710 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z003336 002490 -04032 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z004583 006798 -01189 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z002753 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009737 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W2 7 $
%S
%z004632 006381 004210 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z009070 -01261 008533 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z005698 -06218 003358 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005367 -03426 -03710 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z003336 002490 -04032 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z004583 006798 -01189 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z002753 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009737 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W001 7 $
%S
%z005747 004536 005194 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z008160 -02828 007534 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005610 -05095 000767 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z004728 -01425 -03683 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003366 003266 -03563 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z004647 006728 000121 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z002799 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009739 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %W251 7 $
%S
%z006642 002918 005915 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z007215 -04155 005930 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005616 -04546 -00675 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z004365 -00419 -03694 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z003732 004110 -02901 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004584 006720 001819 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z002817 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009728 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %W501 7 $
%S
%z007548 001278 006955 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z006448 -05234 004508 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005484 -04471 -02167 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z003902 000888 -03689 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z004049 005236 -02003 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004653 006584 003018 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z002678 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009738 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %W751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE51/GE51L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.95; nt=0.18; nx=1.0

```
%BEG GE41_22.TXT, Separation cmy0*, cfi=0.90, D65, adapted S
%100 x LAB*a      1000 x (r g b      c m y 0)      %nrr. pos $
002541 -00004 000053 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
003358 -00010 000115 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
004214 000139 000036 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
005015 000148 000060 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005942 000069 000127 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006994 000134 -00034 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
008018 000127 -00013 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008777 000140 -00028 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009756 000161 00003 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
002485 000001 000046 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
003309 000001 000110 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
004130 000144 000022 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004988 000170 000022 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005884 000085 000091 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006948 000133 -00026 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
008018 000141 -00020 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
008866 000157 -00032 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009752 000002 000009 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
002511 000003 000047 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
003310 -00004 000124 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
004159 000156 000030 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004939 000174 000043 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
005876 000083 000107 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006910 000127 -00008 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
008005 000129 000000 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
008868 000127 -00017 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009758 -00001 000008 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
002572 000001 000051 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
003372 -00007 000130 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
004174 000136 000042 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004998 000157 000057 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005916 000177 000100 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006909 000127 -00022 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
008030 000128 -00010 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008919 000128 -00014 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009748 000007 -00012 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
002853 000007 -00020 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
003289 000042 000039 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
003625 000016 000117 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
004092 000082 000008 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
004395 000126 000034 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
004857 000070 000106 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
005277 000139 000097 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005688 000179 000068 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
006206 000108 000090 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006707 000159 000048 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
007384 000125 000008 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007883 000152 000005 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
008184 000127 000012 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
008630 000072 000028 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
009170 000159 -00211 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009749 000006 -00012 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
002830 000004 -00009 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
003266 000054 000042 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
003650 -00019 000136 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
004111 000088 000012 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
004306 000138 000039 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
004800 000092 000006 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
005265 000147 000092 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005722 000189 000037 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
006210 000122 000037 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006698 000179 -00011 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
007353 000103 000005 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007835 000137 -00002 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
008159 000109 000017 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
008603 000066 000023 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
009204 000152 -00204 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009752 000007 -00010 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
002808 000024 -00003 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
003273 000049 000058 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
003609 -00013 000147 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
004072 000095 000017 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
004368 000152 000039 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
004849 000089 000118 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
005250 000149 000084 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005712 000189 000061 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
006169 000114 000057 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006654 000169 000027 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
007376 000113 000000 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007834 000138 000006 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
008159 000119 000011 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart GE51; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

TUB registration: 20091101-GE51/GE51LONP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/GE51/GE51L0NP.PDF> / <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.95, nt=

TUV registration: 20091101-GE51/GE51L0NP.PDF/.PS
application for evaluation and measurement of printer or

TUB material: code=rha4ta

TUB-test chart GE51; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE51/GE51L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfl=0.95; nt=0.18; nx=1.00

[illegible]

009739	-00069	000185	1000	1000	1000	0000	0000	0000	0000	%0162	S01	009729	-00073	000209	1000	1000	1000	0000	0000	0000	%0486	S10	009719	-00066	000183	1000	1000	1000	0000	0000	0000	0000	%0810	S19	\$	
008992	-00122	-00635	0875	0937	1000	0125	0062	0000	0000	%0163	S02	008954	00045	-00386	0937	0875	1000	0062	0125	0000	0000	%0487	S11	009078	000843	000140	1000	0875	0937	0000	0125	0062	0000	%0811	S20	\$
008392	-00227	-01897	0750	0875	1000	0250	0125	0000	0000	%0164	S03	008463	000798	-00783	0875	0750	1000	0125	0250	0000	0000	%0488	S12	008496	001608	000583	1000	0750	0875	0000	0250	0125	0000	%0812	S21	\$
007710	-00332	-01420	0625	0812	1000	0375	0187	0000	0000	%0165	S04	007839	001243	-01144	0812	0625	1000	0187	0375	0000	0000	%0489	S13	007886	002498	000674	1000	0625	0812	0000	0375	0187	0000	%0813	S22	\$
006846	-00332	-01779	0500	0750	1000	0500	0250	0000	0000	%0166	S05	007035	001729	-01349	0750	0500	1000	0250	0500	0000	0000	%0490	S14	007314	003327	000797	1000	0500	0750	0000	0500	0250	0000	%0814	S23	\$
006267	-00507	-02383	0375	0687	1000	0625	0312	0000	0000	%0167	S06	006119	002448	-01643	0687	0375	1000	0312	0625	0000	0000	%0491	S15	006672	004299	001250	1000	0375	0687	0000	0625	0312	0000	%0815	S24	\$
005498	-00652	-02947	0250	0625	1000	0750	0375	0000	0000	%0168	S07	005271	002905	-01939	0625	0250	1000	0375	0750	0000	0000	%0492	S16	005997	005224	001541	1000	0250	0625	0000	0750	0375	0000	%0816	S25	\$
004861	-00916	-03448	0125	0562	1000	0875	0507	0000	0000	%0169	S08	004547	003106	-02265	0562	0125	1000	0507	0875	0000	0000	%0493	S17	005518	006045	001764	1000	0125	0562	0000	0875	0507	0000	%0817	S26	\$
004266	-00916	-03952	0000	0562	1000	1000	0507	0000	0000	%0170	S09	003771	003777	-02383	0500	0000	1000	0500	1000	0000	0000	%0494	S18	004778	006094	002107	1000	0000	0500	0000	1000	0500	0000	%0818	S27	\$
009239	000414	000766	1000	0937	0875	0000	0062	0125	0000	%0171	T01	000416	-00314	000619	0937	1000	0875	0062	0000	0125	0000	%0495	T10	009179	-00731	-00168	0875	1000	0937	0125	0000	0062	0000	%0819	T10	\$
008754	000088	000136	0875	0875	0875	0125	0125	0125	0000	%0172	T02	008890	000064	-000144	0875	0875	0875	0125	0125	0125	0000	%0496	T11	008839	000015	000104	0875	0875	0875	0125	0125	0125	0000	%0820	T10	\$
008117	-00935	-00378	0750	0812	0875	0250	0187	0125	0000	%0173	T03	008185	000422	-00427	0812	0750	0875	0187	0250	0125	0000	%0497	T12	008181	000773	000357	0875	0750	0812	0125	0250	0187	0000	%0821	T21	\$
007356	-00525	-00925	0625	0750	0875	0375	0250	0125	0000	%0174	T04	007513	000831	-00609	0750	0625	0875	0250	0375	0125	0000	%0498	T13	007686	001591	000626	0875	0625	0750	0125	0375	0250	0000	%0822	T22	\$
006640	-00292	-01382	0500	0687	0875	0500	0312	0125	0000	%0175	T05	006754	001318	-00956	0687	0500	0875	0312	0500	0125	0000	%0499	T14	007014	002597	000585	0875	0500	0687	0125	0500	0312	0000	%0823	T23	\$
006915	-00787	-01882	0375	0625	0875	0625	0375	0125	0000	%0176	T06	005802	001884	-01251	0625	0375	0875	0375	0625	0125	0000	%0500	T15	006437	003229	000915	0875	0375	0625	0125	0625	0375	0000	%0824	T24	\$
005342	-00564	-02516	0250	0562	0875	0750	0437	0125	0000	%0177	T07	005110	002495	-01818	0562	0250	0875	0437	0750	0125	0000	%0501	T16	005732	004239	001207	0875	0250	0562	0125	0750	0437	0000	%0825	T25	\$
004577	-00566	-03136	0125	0500	0875	0875	0500	0125	0000	%0178	T08	004422	002937	-02620	0500	0125	0875	0500	0875	0125	0000	%0502	T17	005113	004764	001368	0875	0125	0500	0125	0750	0500	0000	%0826	T26	\$
004010	-00676	-03556	0000	0437	0875	1000	0562	0125	0000	%0179	T09	003637	003451	-02546	0437	0000	0875	0562	1000	0125	0000	%0503	T18	004328	005951	001620	0875	0000	0437	0125	1000	0562	0000	%0827	T27	\$
008916	000787	001353	1000	0875	0875	0000	0125	0250	0000	%0180	T09	009236	-00900	001313	0875	1000	0750	0125	0000	0250	0000	%0504	T19	008773	-01250	-00239	0750	1000	0875	0250	0000	0125	0000	%0828	T28	\$
008437	000333	000923	0875	0812	0750	0125	0187	0250	0000	%0181	U02	008556	-00327	000804	0812	0875	0750	0187	0125	0250	0000	%0505	U11	008251	-00415	-00107	0750	0875	0812	0250	0125	0187	0000	%0829	U20	\$
007948	000124	000099	0750	0750	0750	0250	0250	0250	0000	%0182	U03	008010	000099	000115	0750	0750	0750	0250	0250	0250	0000	%0506	U12	007963	000117	001008	0750	0750	0750	0250	0250	0250	0000	%0830	U21	\$
007179	-00063	-00374	0625	0687	0750	0375	0312	0250	0000	%0183	U04	007384	000395	-00315	0687	0625	0750	0312	0375	0250	0000	%0507	U13	007396	000876	000256	0750	0625	0687	0250	0375	0312	0000	%0831	U22	\$
006473	-00200	-00908	0500	0625	0750	0500	0375	0250	0000	%0184	U05	006465	001044	-00680	0625	0500	0750	0375	0250	0500	0000	%0508	U14	006806	001649	000488	0750	0500	0625	0250	0500	0375	0000	%0832	U23	\$
005861	-00350	-01526	0375	0562	0750	0625	0437	0250	0000	%0185	U06	005718	001474	-01870	0562	0375	0750	0437	0625	0250	0000	%0509	U15	006099	002402	000636	0750	0375	0562	0250	0625	0437	0000	%0833	U24	\$
005202	-00510	-02077	0250	0500	0750	0750	0500	0250	0000	%0186	U07	004996	002030	-01416	0500	0250	0750	0500	0750	0250	0000	%0510	U16	005351	003297	000954	0750	0375	0500	0250	0750	0500	0000	%0834	U25	\$
004539	-00575	-02610	0125	0437	0750	0875	0562	0250	0000	%0187	U08	004328	002452	-01747	0437	0125	0750	0562	0875	0250	0000	%0511	U17	004723	004041	001141	0750	0125	0437	0250	0875	0562	0000	%0835	U26	\$
003885	-00538	-03037	0000	0375	0750	1000	0625	0250	0000	%0188	U09	003527	002934	-02227	0375	0000	0750	0625	1000	0250	0000	%0512	U18	004005	004896	001370	0750	0000	0375	0250	1000	0625	0000	%0836	U27	\$
008523	001134	002219	1000	0812	0625	0000	0187	0375	0000	%0189	V01	008962	-01408	0001939	0812	1000	0625	0187	0000	0375	0000	%0513	V10	008152	-01901	-00342	0625	1000	0812	0375	0000	0187	0000	%0837	V19	\$
008083	000777	001525	0875	0750	0625	0125	0250	0375	0000	%0190	V02	008341	-00764	0001188	0750	0875	0625	0250	0125	0375	0000	%0514	V11	007550	-01119	-00162	0625	0875	0750	0375	0125	0250	0000	%0838	V20	\$
007662	000356	000767	0750	0687	0625	0250	0312	0375	0000	%0191	V03	007696	-00060	0000579	0687	0750	0625	0312	0250	0375	0000	%0515	V12	007283	-00484	-00131	0625	0750	0687	0375	0250	0312	0000	%0839	V21	\$
006884	000131	000035	0625	0625	0625	0375	0375	0375	0000	%0192	V04	007020	-00099	0000685	0625	0625	0625	0375	0375	0375	0000	%0516	V13	006893	000156	000023	0625	0625	0625	0375	0375	0375	0000	%0840	V22	\$
006166	-00017	-00248	0500	0437	0875	0625	0500	0437	0000	%0193	V05	006252	000472	-00406	0562	0500	0625	0437	0500	0375	0000	%0517	V14	006291	000952	000257	0625	0500	0562	0375	0500	0437	0000	%0841	V23	\$
005682	-00240	-01014	0375	0562	0625	0625	0625	0375	0000	%0194	V06	005519	001034	-00700	0500	0375	0625	0500	0625	0375	0000	%0518	V15	005557	001698	000576	0625	0375	0500	0375	0625	0500	0000	%0842	V24	\$
004897	-00345	-01681	0250	0437	0625	0750	0562	0375	0000	%0195	V07	004849	001550	-01117	0437	0250	0625	0562	0750	0375	0000	%0519	V16	004869	002406	000866	0625	0500	0437	0375	0750	0562	0000	%0843	V25	\$
004433	-00535	-02173	0125	0375	0625	0875	0625	0375	0000	%0196	V08	004220	001981	-01368	0375	0125	0625	0625	0875	0375	0000	%0520	V17	004262	003259	001156	0625	0125	0375	0375	0875	0625	0000	%0844	V26	\$
003806	-00563	-02606	0000	0312	0625	1000	0687	0375	0000	%0197	V09	003340	002563	-02010	0312	0000	0625	0687																		

009745	-00073	000203	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
008894	000068	-00667	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008351	000146	-01091	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
007705	000215	-01509	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
006686	000292	-01905	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
006064	000315	-02368	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$
005319	000249	-02908	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
004546	000282	-03472	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$
003832	000484	-03896	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
003411	000236	-000781	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
008741	000100	000140	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
008059	000082	-00373	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
007339	000028	-00916	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
006455	000196	-01387	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
005772	000207	-01933	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
005057	000247	-02462	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
004281	000479	-03186	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
003554	000968	-03419	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
001913	000404	-001561	1000	0937	0750	0000	0662	0250	0000	%0261	d01	\$
008520	000210	001050	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
007914	000102	000094	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$
007157	000126	-00385	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
006348	000190	-00873	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
005692	000204	-01502	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
004827	000374	-02170	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
004080	000445	-02775	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
003438	000642	-03012	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
008861	000549	0026219	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
008346	000336	-001662	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
007813	000186	-000953	0750	0718	0625	0250	0281	0375	0000	%0272	e03	\$
006914	000118	-000837	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
006174	000118	-00266	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
005573	000153	-00051	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$
004692	000271	-01701	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$
004053	000251	-02251	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
003358	000502	-02714	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
008604	000766	-00372	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
008143	000564	-002618	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
007551	000322	-001821	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
006716	000272	-000883	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
006048	000101	-000128	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
005410	000128	-00327	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
004709	000162	-01210	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
003988	000137	-01744	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
003265	000245	-02135	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
008370	000945	004364	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
007830	000762	-003350	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
007235	000609	-002550	0750	0656	0375	0250	0343	0625	0000	%0290	g03	\$
006454	000437	-001903	0625	0562	0375	0375	0437	0625	0000	%0291	g04	\$
005918	000200	-000869	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
005218	000179	-000001	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
004673	000115	-00081	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
003944	000154	-01217	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
003179	000164	-01716	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
008116	001215	-005332	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
007558	000928	-004421	0875	0718	0500	0125	0281	0750	0000	%0298	h02	\$
006921	000709	-003613	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
006294	000652	-002680	0625	0531	0250	0375	0750	0750	0000	%0300	h04	\$
005618	000429	-001877	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
005091	000303	-000845	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
004366	000175	-00051	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
003891	000133	-00703	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
003158	000964	-01234	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
007783	001515	-006274	1000	0781	0125	0000	0218	0875	0000	%0306	i01	\$
007262	001105	-004896	0875	0687	0125	0125	0312	0875	0000	%0307	i02	\$
006602	000974	-004182	0750	0593	0125	0250	0406	0875	0000	%0308	i03	\$
005868	000792	-003526	0625	0500	0125	0375	0500	0875	0000	%0309	i04	\$
005275	000714	-002507	0500	0406	0125	0500	0593	0875	0000	%0310	i05	\$
004867	000458	-001737	0375	0312	0125	0625	0687	0875	0000	%0311	i06	\$
004261	000179	-000739	0250	0218	0125	0750	0781	0875	0000	%0312	i07	\$
003632	000061	-000031	0125	0125	0125	0875	0875	0875	0000	%0313	i08	\$
003029	000126	-00570	0000	0031	0125	1000	0968	0875	0000	%0314	i09	\$
002637	000172	-006988	1000	0750	0000	0000	0250	1000	0000	%0315	j01	\$
006935	001421	-006249	0875	0656	0000	0125	0343	1000	0000	%0316	j02	\$
006346	001149	-005121	0750	0562	0000	0250	0437	1000	0000	%0317	j03	\$
005661	001047	-004051	0625	0468	0000	0375	0531	1000	0000	%0318	j04	\$
005054	000913	-003387	0500	0375	0000	0500	0625	1000	0000	%0319	j05	\$
004479	000643	-002581	0375	0281	0000	0625	0718	1000	0000	%0320	j06	\$
004073	000580	-001532	0250	0187	0000	0750	0812	1000	0000	%0321	j07	\$
003513	000208	-000648	0125	0093	0000	0875	0906	1000	0000	%0322	j08	\$
002810	000072	-001719	0000	0000	0000	1000	1000	1000	0000	%0323	j09	\$
009734	-00068	0000202	1000	1000	1000	0000	0000	0000	0000	%0891	b19	\$
009041	000864	000230	1000	0875	0906	0000	0125	0093	0000	%0892	b20	\$
008437	001632	000832	1000	0750	0812	0000	0250	0187	0000	%0893	b21	\$
007782	002541	001030	1000	0625	0718	0000	0375	0281	0000	%0894	b22	\$
007173	003385	001610	1000	0500	0625	0000	0500	0375	0000	%0895	b23	\$
006634	004199	002019	1000	0375	0531	0000	0625	0468	0000	%0896	b24	\$
006062	005116	002493	1000	0250	0437	0000	0750	0562	0000	%0897	b25	\$
005504	006034	002388	1000	0125	0343	0000	0875	0656	0000	%0898	b26	\$
004852	006925	003303	1000	0000	0250	0000	1000	0750	0000	%0899	b27	\$
009068	-00631	-00410	0875	1000	0968	0125	0000	0031	0000	%0900	c10	\$
008800	000124	000112	0875	0875	0875	0125	0125	0125	0000	%0901	c19	\$
008182	000767	000492	0875	0750	0781	0125	0250	0218	0000	%0902	c21	\$
007620	001685	000871	0875	0625	0687	0125	0375	0312	0000	%0903	c22	\$
006967	002558	001113	0875	0500	0593	0125	0500	0406	0000	%0904	c23	\$
006363	003316	001587	0875	0375	0500	0125	0625	0500	0000	%0905	c24	\$
005667	004149	001939	0875	0250	0406	0125	0750	0593	0000	%0906	c25	\$
004983	004783	002338	0875	0125	0312	0125	0875	0687	0000	%0907	c26	\$
004183	005967	002788	0875	0000	0218	0125	1000	0781	0000	%0908	c27	\$
008756	-01155	-00706	0750	1000	0937	0250	0000	0062	0000	%0909	d19	\$
008318	-00463	-00255	075									

```
%BEG GE41.22.TXT, Separation cmy0*, cf1=0.90, D50, not adapted $
%100 x LAB*      %#1000 x (r g b c m y 0)      %nr.      pos $
%Z004832 006769 004441 0000 0000 0000 0000 0000 0000 0000 0072 I01 %01 0 $
%Z009122 -00670 008498 0000 0000 0000 0000 0000 0000 0000 0000 0396 I10 %Y1 1 $
%Z005617 -05783 002960 0000 0000 0000 0000 0000 0000 0000 0000 0720 I19 %L1 2 $
%Z005208 -04123 -04085 0000 0000 0000 0000 0000 0000 0000 0000 0008 A09 %C1 3 $
%Z003293 002095 -04207 0000 0000 0000 0000 0000 0000 0000 0000 0332 A18 %V1 4 $
%Z004739 006836 -00908 0000 0000 0000 0000 0000 0000 0000 0000 0656 A27 %M1 5 $
%Z002752 000072 -00167 0000 0000 0000 0000 0000 0000 0000 0000 0080 I09 %N1 6 $
%Z009738 -00068 000189 0000 0000 0000 0000 0000 0000 0000 0000 0000 A01 %M1 7 $
%$
%Z004832 006769 004441 0000 0000 0000 0000 0000 0000 0000 0000 0072 I01 %02 0 $
%Z009122 -00670 008498 0000 0000 0000 0000 0000 0000 0000 0000 0396 I10 %Y2 1 $
%Z005617 -05783 002960 0000 0000 0000 0000 0000 0000 0000 0000 0720 I19 %L2 2 $
%Z005208 -04123 -04085 0000 0000 0000 0000 0000 0000 0000 0000 0008 A09 %C2 3 $
%Z003293 002095 -04207 0000 0000 0000 0000 0000 0000 0000 0000 0332 A18 %V2 4 $
%Z004739 006836 -00908 0000 0000 0000 0000 0000 0000 0000 0000 0656 A27 %M2 5 $
%Z002752 000072 -00167 0000 0000 0000 0000 0000 0000 0000 0000 0080 I09 %N2 6 $
%Z009738 -00068 000189 0000 0000 0000 0000 0000 0000 0000 0000 0000 A01 %M2 7 $
%$
%Z004832 006769 004441 0000 0000 0000 0000 0000 0000 0000 0000 0072 I01 %000Y 0 $
%Z009122 -00670 008498 0000 0000 0000 0000 0000 0000 0000 0000 0396 I10 %Y00L 1 $
%Z005617 -05783 002960 0000 0000 0000 0000 0000 0000 0000 0000 0720 I19 %L00C 2 $
%Z005208 -04123 -04085 0000 0000 0000 0000 0000 0000 0000 0000 0008 A09 %C00V 3 $
%Z003293 002095 -04207 0000 0000 0000 0000 0000 0000 0000 0000 0332 A18 %V00M 4 $
%Z004739 006836 -00908 0000 0000 0000 0000 0000 0000 0000 0000 0656 A27 %M000 5 $
%Z002752 000072 -00167 0000 0000 0000 0000 0000 0000 0000 0000 0080 I09 %N001 6 $
%Z009738 -00068 000189 0000 0000 0000 0000 0000 0000 0000 0000 0000 A01 %M001 7 $
%$
%Z005900 005052 005338 0000 0000 0000 0000 0750 0000 0000 0000 0153 R01 %025Y 0 $
%Z008173 -02259 007390 0000 0000 0000 0000 0250 0000 0000 0000 0477 R10 %Y25L 1 $
%Z005517 -04948 000446 0000 0000 0000 0000 0250 0000 0750 0000 0080 R19 %L25C 2 $
%Z004610 -01999 -03973 0000 0000 0000 0000 0250 0000 0000 0000 0089 J09 %C25V 3 $
%Z003361 003009 -03663 0000 0000 0000 0000 0750 0000 0000 0000 0413 J18 %V25M 4 $
%Z004821 006887 000420 0000 0000 0000 0000 0000 0000 0250 0000 0737 J27 %M250 5 $
%Z002798 006083 -00168 0000 0000 0000 0000 0000 0000 0000 0000 0161 R09 %N251 6 $
%Z009740 -00071 000205 0000 0000 0000 0000 0000 0000 0000 0000 0081 J01 %M251 7 $
%$
%Z006761 003483 005995 0000 0000 0000 0000 0500 0000 0000 0000 0234 a01 %050Y 0 $
%Z007191 -03608 005679 0000 0000 0000 0000 0500 0000 0000 0000 0558 a10 %Y50L 1 $
%Z005509 -04628 -00993 0000 0000 0000 0000 0500 0000 0000 0000 0082 a19 %L50C 2 $
%Z004266 -00916 -03963 0000 0000 0000 0000 0500 0000 0000 0000 0170 S09 %C50V 3 $
%Z003771 003977 -02903 0000 0000 0000 0000 0500 0000 0000 0000 0494 S18 %V50M 4 $
%Z004778 006994 002107 0000 0000 0000 0000 0000 0000 0500 0000 0018 S27 %M500 5 $
%Z002816 000076 -00174 0000 0000 0000 0000 0000 0000 0000 0000 0242 a09 %N501 6 $
%Z009729 -00069 000192 0000 0000 0000 0000 0000 0000 0000 0000 0162 S01 %M501 7 $
%$
%Z007637 001872 006988 0000 0000 0000 0000 0750 0000 0000 0250 0000 0315 j01 %075Y 0 $
%Z006394 -04731 004189 0000 0000 0000 0000 0750 0000 0000 0000 0639 j10 %Y75L 1 $
%Z005347 -04857 -02514 0000 0000 0000 0000 0750 0000 0000 0250 0000 0963 j19 %L75C 2 $
%Z003832 000484 -03896 0000 0000 0000 0000 0250 0000 0000 0000 0251 b09 %C75V 3 $
%Z004143 005214 -01864 0000 0000 0000 0000 0250 0000 0000 0000 0575 b18 %V75M 4 $
%Z004852 006925 003303 0000 0000 0000 0000 0000 0000 0750 0000 0089 b27 %M750 5 $
%Z002677 000078 -00161 0000 0000 0000 0000 0000 0000 0000 0000 0323 j09 %N751 6 $
%Z009739 -00070 000199 0000 0000 0000 0000 0000 0000 0000 0000 0243 b01 %M751 7 $
%$
```

See original or copy: <http://web.me.com/klaus.richter/GE51/GE51L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.95; nt=0.18; nx=1.0

```
%BEG GE41.22.TXT, Separation cmy0*, cfi=0.90, D50, not adapted $
%100 x LAB*          1000 x (r g b c m y 0)      %nr. pos $
002541 000070 -00117 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
003359 000050 -00012 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
004217 000183 -00043 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
005019 000179 000021 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005945 000090 000131 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006996 000114 000024 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
008020 000091 000095 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008880 000089 000123 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009756 000070 000195 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
002484 000075 -00127 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
003309 000051 -00019 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
004133 000187 -00061 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004991 000198 -00016 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005887 000102 000093 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006951 000116 000029 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
008013 000106 000089 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
008869 000106 000119 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009752 -00072 -000198 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
002510 000077 -00125 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
003311 000059 -00005 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
004162 000200 -00051 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004943 000205 000001 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
005879 000102 000108 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006913 000112 000046 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
008008 000096 000108 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
008871 000076 000133 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009758 -00072 000197 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
002571 000075 -00117 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
003373 000055 000003 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
004177 000180 -00039 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
005802 000188 000018 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
006919 000094 000193 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
007802 000188 000036 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
008033 000092 000099 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008922 000077 000138 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009749 -00065 000176 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
002851 000066 -00176 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
003290 000099 -00091 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
003626 000036 000003 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
004093 000122 -00080 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
004397 000165 -00036 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
004860 000106 000056 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
005281 000170 000071 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005692 000201 000064 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
006209 000120 000109 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006711 000158 000093 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
007387 000104 000086 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007887 000123 000108 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
008187 000092 000130 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
008632 000028 000165 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
009170 000087 -00048 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009750 -00066 000176 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
002829 000065 -00166 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
003267 000112 -00088 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
003651 000035 000023 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
004112 000128 -00074 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
004399 000178 -00030 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
004883 000127 000049 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
005269 000178 000066 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005726 000207 000035 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
006213 000126 000056 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006702 000171 000034 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
007355 000080 000080 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007839 000106 000098 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
008162 000073 000132 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
008605 000021 000159 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
009205 000079 -00039 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009753 -00065 000179 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
002807 000087 -00160 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
003274 000109 -00072 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
003610 000044 000033 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
004074 000137 -00071 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
004371 000193 -00031 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
004852 000127 000069 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
005254 000179 000057 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005717 000210 000059 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
006173 000121 000074 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006658 000167 000070 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
007379 000090 000076 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007838 000108 000106 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
008162 000084 000127 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE51; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: ->olv* setrgbcolor

TUB registration: 20091101-GE51/GE51L0NP.PDF /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart GE51; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

TUB registration: 20091101-GE51/GE51LONP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/GE51/GE51L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cf1=0.95; nt=

009739	000000	-000008	1000	1000	1000	0000	0000	0000	0000	%0162	S01	009729	-000003	-000016	1000	1000	1000	0000	0000	0000	%0486	S10	009719	000002	-000008	1000	1000	1000	0000	0000	0000	0000	0000	%0810	S19	\$
008992	-000668	-007888	0875	0937	1000	0125	0062	0000	0000	%0163	S02	008954	000499	-00537	0937	0875	1000	0062	0125	0000	0000	%0487	S11	009078	000899	-000018	1000	0875	0937	0000	0125	0062	0000	%0811	S20	\$
008392	-001815	-01219	0750	0875	1000	0250	0125	0000	0000	%0164	S03	008463	000841	-00908	0875	0750	1000	0125	0250	0000	0000	%0488	S12	008496	001652	-000456	1000	0750	0875	0000	0250	0125	0000	%0812	S21	\$
007710	-00305	-01505	0625	0812	1000	0375	0187	0000	0000	%0165	S04	007839	001272	-01237	0812	0625	1000	0187	0375	0000	0000	%0489	S13	007866	002528	-000580	1000	0625	0812	0000	0375	0187	0000	%0813	S22	\$
006846	-003223	-01819	0500	0750	1000	0500	0250	0000	0000	%0166	S05	007035	001742	-01399	0750	0500	1000	0250	0500	0000	0000	%0490	S14	007314	003346	-000733	1000	0500	0750	0000	0500	0250	0000	%0814	S23	\$
006267	-005018	-02393	0375	0687	1000	0625	0312	0000	0000	%0167	S06	006119	002442	-01644	0687	0375	1000	0312	0625	0000	0000	%0491	S15	006672	004304	-001220	1000	0375	0687	0000	0625	0312	0000	%0815	S24	\$
005498	-00672	-02915	0250	0625	1000	0750	0375	0000	0000	%0168	S07	005271	002880	-01895	0625	0250	1000	0375	0750	0000	0000	%0492	S16	006097	005217	-001541	1000	0250	0625	0000	0750	0375	0000	%0816	S25	\$
004861	-00842	-03383	0125	0625	1000	0875	0507	0000	0000	%0169	S08	004547	003157	-02183	0507	0125	1000	0507	0875	0000	0000	%0493	S17	005518	006826	-001794	1000	0125	0507	0000	0875	0507	0000	%0817	S26	\$
004266	-00951	-03866	0000	0625	1000	1000	0507	0000	0000	%0170	S09	003771	003211	-02789	0500	0000	1000	0500	1000	0000	0000	%0494	S18	004778	006959	-002177	1000	0000	0500	0000	1000	0500	0000	%0818	S27	\$
009239	000474	000599	1000	0937	0875	0000	0062	0125	0000	%0171	T01	000416	-00251	-000442	0937	1000	0875	0062	0000	0125	0000	%0495	T10	0009179	-00673	-00031	0875	1000	0937	0125	0000	0062	0000	%0819	T10	\$
008754	000137	-000085	0875	0875	0875	0125	0125	0125	0000	%0172	T02	008890	000116	-00004	0875	0875	0125	0125	0125	0000	0000	%0496	T11	008839	000166	-00040	0875	0875	0875	0125	0125	0125	0000	%0820	T10	\$
008117	-000008	-00486	0750	0812	0875	0250	0187	0125	0000	%0173	T03	008185	000459	-00538	0812	0750	0875	0187	0250	0125	0000	%0497	T12	008181	000810	-000246	0875	0750	0812	0125	0250	0187	0000	%0821	T21	\$
007356	-00236	-00992	0625	0750	0875	0375	0250	0125	0000	%0174	T04	007513	000854	-00684	0750	0625	0875	0250	0375	0125	0000	%0498	T13	007686	001618	-000542	0875	0625	0750	0125	0375	0250	0000	%0822	T22	\$
006640	-00288	-01411	0500	0687	0875	0500	0312	0125	0000	%0175	T05	006754	001325	-00991	0687	0500	0875	0312	0500	0125	0000	%0499	T14	007014	002609	-000536	0875	0500	0687	0125	0500	0312	0000	%0823	T23	\$
006015	-00384	-01878	0375	0625	0875	0625	0375	0125	0000	%0176	T06	005802	001871	-01236	0625	0375	0875	0375	0625	0125	0000	%0500	T15	006437	003229	-000897	0875	0375	0625	0125	0625	0375	0000	%0824	T24	\$
005342	-00587	-02476	0250	0562	0875	0750	0437	0125	0000	%0177	T07	005110	002467	-01566	0562	0250	0875	0437	0750	0125	0000	%0501	T16	005732	004224	-001226	0875	0250	0562	0125	0750	0437	0000	%0825	T25	\$
004577	-00605	-03055	0125	0500	0875	0875	0500	0125	0000	%0178	T08	004422	002894	-01931	0500	0125	0875	0500	0875	0125	0000	%0502	T17	005113	004736	-001420	0875	0125	0500	0125	0875	0500	0000	%0826	T26	\$
004010	-00727	-03445	0000	0437	0875	1000	0562	0125	0000	%0179	T09	003637	003392	-02415	0437	0000	0875	0562	1000	0125	0000	%0503	T18	004328	005907	-001714	0875	0000	0437	0125	1000	0562	0000	%0827	T27	\$
008916	000840	001204	1000	0875	0750	0000	0125	0250	0000	%0180	T01	009236	-00840	-00814	1000	0750	0125	0000	0250	0250	0000	%0504	T19	008773	-01200	-00381	0750	1000	0875	0250	0000	0125	0000	%0828	T28	\$
008437	000376	000798	0875	0812	0750	0125	0187	0250	0000	%0181	T02	008556	-00282	-000674	0812	0875	0750	0187	0125	0250	0000	%0505	T11	008251	-00377	-00221	0750	0875	0812	0250	0125	0187	0000	%0829	T29	\$
007948	000157	000001	0750	0750	0750	0250	0250	0250	0000	%0182	T03	008010	000133	-000073	0750	0750	0250	0250	0250	0250	0000	%0506	T12	007963	000150	-000008	0750	0750	0250	0250	0250	0250	0000	%0830	T21	\$
007179	-00047	-00432	0625	0687	0750	0375	0312	0250	0000	%0183	T04	007384	000415	-00383	0687	0625	0750	0312	0375	0250	0000	%0507	T13	007396	000896	-000187	0750	0625	0687	0250	0375	0312	0000	%0831	T22	\$
006473	-00199	-00928	0500	0625	0750	0500	0375	0250	0000	%0184	T05	006465	001044	-00699	0625	0500	0750	0375	0250	0500	0000	%0508	T14	006806	001657	-000450	0750	0500	0625	0250	0500	0375	0000	%0832	T23	\$
005861	-00362	-01514	0375	0562	0750	0625	0437	0250	0000	%0185	T06	005718	001459	-01050	0562	0375	0750	0437	0625	0250	0000	%0509	T15	006099	002395	-000636	0750	0375	0562	0250	0625	0437	0000	%0833	T24	\$
005202	-00536	-02029	0250	0500	0750	0750	0500	0250	0000	%0186	T07	004996	002000	-01357	0500	0250	0750	0500	0750	0250	0000	%0510	T16	005351	003274	-000993	0750	0375	0500	0250	0750	0500	0000	%0834	T25	\$
004539	-00615	-02527	0125	0437	0750	0875	0562	0250	0000	%0187	T08	004328	002408	-01654	0437	0125	0750	0562	0875	0250	0000	%0511	T17	004723	004005	-001214	0750	0125	0437	0250	0875	0562	0000	%0835	T26	\$
003885	-00592	-02920	0000	0375	0750	1000	0625	0250	0000	%0188	T09	003527	002873	-02099	0375	0000	0750	0625	1000	0250	0000	%0512	T18	004005	004844	-001481	0750	0000	0375	0250	1000	0625	0000	%0836	T27	\$
005823	001178	002090	1000	0812	0625	0000	0187	0375	0000	%0189	T01	008962	-01354	-00178	0812	1000	0625	0187	0000	0375	0000	%0513	T19	008152	-01865	-00451	0625	1000	0812	0375	0000	0187	0000	%0837	T28	\$
008083	000012	001420	0875	0750	0625	0125	0250	0375	0000	%0190	T02	008341	-00724	-001068	0750	0875	0625	0250	0125	0375	0000	%0514	T11	007550	-01095	-00239	0625	0875	0750	0375	0125	0250	0000	%0838	T29	\$
007662	000363	000684	0750	0687	0625	0250	0312	0375	0000	%0191	T03	007696	-00233	-000494	0687	0750	0625	0312	0250	0375	0000	%0515	T12	007283	-00466	-00195	0625	0750	0687	0375	0250	0312	0000	%0839	T30	\$
006884	000141	-00006	0625	0625	0625	0375	0375	0375	0000	%0192	T04	007020	000108	-000009	0625	0625	0625	0375	0375	0375	0000	%0516	T13	006893	000166	-00019	0625	0625	0625	0625	0375	0375	0000	%0840	T31	\$
006168	-00022	-00252	0500	0687	0625	0500	0437	0375	0000	%0193	T05	006252	000469	-00414	0500	0500	0625	0437	0500	0375	0000	%0517	T14	006291	00049	-00049	0625	0500	0500	0500	0625	0437	0000	%0841	T32	\$
005682	-00258	-00992	0375	0500	0625	0625	0625	0375	0000	%0194	T06	005519	-001017	-00675	0500	0375	0625	0500	0625	0375	0000	%0518	T15	005557	001680	-000605	0625	0375	0500	0375	0625	0500	0000	%0842	T33	\$
004897	-00377	-01617	0250	0437	0625	0750	0562	0375	0000	%0195	T07	004849	001517	-01051	0437	0250	0625	0562	0750	0375	0000	%0519	T16	004869	002463	-000931	0625	0250	0437	0375	0750	0562	0000	%0843	T34	\$
004433	-00577	-02085	0125	0375	0625	0875	0625	0375	0000	%0196	T08	004220	001935	-01269	0375	0125	0625	0625	0875	0375	0000	%0520	T17	004262	003214	-001254	0625	0125	0375	0750	0875	0625	0000	%0844	T35	\$
003806	-00619	-02484	0000	0312	0625	1000	0687	0375	0000	%0197	T09	003340	002498	-01864	0312	0000	0625	0687	1000	0375																

See original or copy: <http://web.me.com/klaus.richter/GE51/GE51L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.95; nt=0.18; nx=1.0

```
%BEG GE41 22.TXT, Separation cmy0*, cfi=0.90, D50, adapted S
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr.   pos $
%Z004832 006739 004502 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009122 -00613 008340 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005617 -05797 002981 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005208 -04145 -04043 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003293 002034 -04067 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004739 006804 -00842 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z002752 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009738 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004832 006739 004502 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009122 -00613 008340 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005617 -05797 002981 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005208 -04145 -04043 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003293 002034 -04067 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004739 006804 -00842 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z002752 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009738 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004832 006739 004502 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009122 -00613 008340 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005617 -05797 002981 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005208 -04145 -04043 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003293 002034 -04067 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004739 006804 -00842 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z002752 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009738 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005900 005038 005339 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008173 -02222 007268 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005517 -04970 000468 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004610 -02041 -03902 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003361 002937 -03525 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004821 006849 000480 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z002798 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009740 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z006761 003490 005960 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007191 -03592 005621 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005509 -04647 -00962 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004266 -00961 -03866 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003771 003921 -02780 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004778 006959 002177 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z002816 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009729 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z007637 001899 006896 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006394 -04731 004160 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005347 -04879 -02489 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003832 000430 -03794 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004143 005166 -01778 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004852 006893 003353 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z002677 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009739 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE51/GE51L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.95; nt=0.18; nx=1.0

```
%BEG GE41.22.TXT, Separation cmy0*, cfi=0.90, D50, adapted S
%100 x LAB*a      1000 x (r g b      c m y 0)      %nrr. pos $
002541 000001 000054 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
003359 -00002 000119 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
004217 000147 000044 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
005019 000158 000069 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005945 000087 000133 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006996 000132 -00026 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
008020 000129 -00006 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008800 000143 -00022 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009756 000061 00002 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
002484 000006 000047 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
003309 -00001 000114 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
004133 000149 000031 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004991 000177 000033 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005887 000098 000097 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006951 000133 -00019 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
008013 000143 -00012 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
008869 000160 -00025 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009752 -00001 000009 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
002510 000008 000048 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
003311 000005 000128 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
004162 000163 000039 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004943 000183 000053 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
005879 000098 000113 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006913 000129 000000 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
008008 000134 000006 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
008871 000130 -00011 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009758 000000 000008 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
002571 000006 000052 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
003373 000002 000134 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
004177 000143 000050 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
005802 000167 000066 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
006919 000091 000106 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
007902 000126 -00015 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
008033 000130 -00003 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008922 000132 -00008 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009749 000005 -00012 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
002851 000003 -00019 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
003290 000044 000043 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
003626 000010 000121 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
004093 000083 000013 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
004397 000132 000042 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
004860 000082 000112 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
005281 000155 000106 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005692 000193 000078 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
006209 000122 000098 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006711 000171 000056 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
007387 000129 000015 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007887 000158 000013 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
008187 000133 000019 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
008632 000077 000032 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
009170 000147 -00208 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009750 000004 -00012 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
002829 000002 -00009 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
003267 000058 000047 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
003651 -00011 000140 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
004112 000090 000018 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
004399 000145 000048 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
004883 000104 000093 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
005269 000162 000101 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005726 000200 000047 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
006213 000129 000045 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006702 000183 -00001 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
007355 000105 000011 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007839 000141 000004 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
008162 000114 000023 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
008605 000070 000027 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
009205 000140 -00201 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009753 000006 -00009 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
002807 000024 -00001 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
003274 000055 000062 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
003610 -00003 000152 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
004074 000098 000024 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
004371 000160 000049 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
004852 000104 000125 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
005254 000163 000093 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005717 000203 000072 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
006173 000123 000064 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006658 000179 000036 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
007379 000115 000006 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007838 000143 000013 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
008162 000124 000018 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```