

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

%BEG	HE01	22.TXT	Separation	cmY0*	D65,	not adapted	S	%nr.	pos	A01	\$	%BEG	HE01	22.TXT	Separation	cmY0*	D65,	not adapted	S	%nr.	pos	A01	\$
009716	-00101	000204	1000	1000	1000	0000	0000	0000	0000	0000	0000	009705	-00095	000192	1000	1000	1000	0000	0000	0000	0000	0000	0000
009900	-00790	-00433	0875	1000	1000	0125	0000	0000	0000	0000	0000	009928	-00508	-00684	0875	0875	1000	0125	0000	0000	0000	0000	0000
008061	-01125	-00891	0750	1000	1000	0250	0000	0000	0000	0000	0000	008536	-00846	-01284	0750	0750	1000	0250	0000	0000	0000	0000	0000
008634	-01655	-01236	0625	1000	1000	0375	0000	0000	0000	0000	0000	007566	-00959	-02260	0625	0625	1000	0375	0000	0000	0000	0000	0000
007486	-02081	-01644	0500	1000	1000	0500	0000	0000	0000	0000	0000	006746	-00910	-02983	0500	0500	1000	0500	0000	0000	0000	0000	0000
007608	-02555	-01867	0375	1000	1000	0625	0000	0000	0000	0000	0000	005932	-00904	-03634	0375	0375	1000	0625	0000	0000	0000	0000	0000
006409	-03286	-01892	0250	1000	1000	0750	0000	0000	0000	0000	0000	005261	-00959	-04217	0250	0250	1000	0750	0000	0000	0000	0000	0000
005936	-03856	-02071	0125	1000	1000	0875	0000	0000	0000	0000	0000	004855	-00885	-04511	0125	0125	1000	0875	0000	0000	0000	0000	0000
005642	-04327	-02112	0000	1000	1000	1000	0000	0000	0000	0000	0000	004568	-01040	-04890	0000	1000	1000	0000	0000	0000	0000	0000	0000
009155	000463	000647	1000	0875	0875	0000	0125	0125	0000	0000	0000	009640	-00718	-001901	1000	1000	0875	0000	0000	0125	0000	0000	0000
008479	000036	000260	0875	0875	0875	0125	0125	0125	0000	0000	0000	008700	000037	000228	0875	0875	0875	0125	0125	0125	0000	0000	0000
008203	-00844	-00149	0750	0875	0875	0250	0125	0125	0000	0000	0000	007891	-00239	-00713	0750	0750	0875	0250	0250	0125	0000	0000	0000
007764	-01262	-00482	0625	0875	0875	0375	0125	0125	0000	0000	0000	007284	-00439	-01371	0625	0625	0875	0375	0375	0125	0000	0000	0000
007289	-01978	-01090	0500	0875	0875	0500	0125	0125	0000	0000	0000	006424	-00457	-02188	0500	0500	0875	0500	0500	0125	0000	0000	0000
006877	-02406	-01391	0375	0875	0875	0625	0125	0125	0000	0000	0000	005830	-00667	-02731	0375	0375	0875	0625	0625	0125	0000	0000	0000
006387	-03066	-01430	0250	0875	0875	0750	0125	0125	0000	0000	0000	005243	-00880	-03312	0250	0250	0875	0750	0750	0125	0000	0000	0000
006082	-03898	-01571	0125	0875	0875	0875	0125	0125	0000	0000	0000	004910	-01042	-03682	0125	0125	0875	0875	0875	0125	0000	0000	0000
005546	-04636	-01877	0000	0875	0875	1000	0125	0125	0000	0000	0000	004540	-01072	-04592	0000	0000	0875	1000	1000	0125	0000	0000	0000
008603	001054	000942	1000	0750	0750	0000	0250	0250	0000	0000	0000	009485	-00891	-002991	1000	1000	0750	0000	0000	0250	0000	0000	0000
007823	000710	000760	0875	0750	0750	0125	0250	0250	0000	0000	0000	008569	-00171	-001523	0875	0875	0750	0125	0125	0250	0000	0000	0000
007419	000230	000322	0750	0750	0750	0250	0250	0250	0000	0000	0000	007594	000223	000288	0750	0750	0250	0250	0250	0250	0000	0000	0000
007065	-00406	-00117	0625	0750	0750	0375	0250	0250	0000	0000	0000	006899	-00071	-00557	0625	0625	0750	0375	0375	0250	0000	0000	0000
006735	-01363	-00522	0500	0750	0750	0500	0250	0250	0000	0000	0000	006248	-00298	-01384	0500	0500	0750	0500	0500	0250	0000	0000	0000
006297	-01846	-01040	0375	0750	0750	0625	0250	0250	0000	0000	0000	005527	-00474	-02083	0375	0375	0750	0625	0625	0250	0000	0000	0000
005883	-02424	-01226	0250	0750	0750	0750	0250	0250	0000	0000	0000	005094	-00699	-02528	0250	0250	0750	0750	0250	0250	0000	0000	0000
005637	-03295	-01448	0125	0750	0750	0875	0250	0250	0000	0000	0000	004760	-00871	-02958	0125	0125	0750	0875	0875	0250	0000	0000	0000
005424	-05019	-01650	0000	0750	0750	1000	0250	0250	0000	0000	0000	004371	-01110	-03656	0000	0000	0750	1000	1000	0250	0000	0000	0000
007934	001811	001316	1000	0625	0625	0000	0375	0375	0000	0000	0000	009310	-00885	-003776	1000	1000	0625	0000	0000	0375	0000	0000	0000
007344	001268	001232	0875	0625	0625	0125	0375	0375	0000	0000	0000	008553	-00455	-002798	0875	0875	0625	0125	0125	0375	0000	0000	0000
006887	000835	000730	0750	0625	0625	0250	0375	0375	0000	0000	0000	007614	-00158	-001424	0750	0750	0625	0250	0250	0375	0000	0000	0000
006450	000259	000270	0625	0625	0625	0375	0375	0375	0000	0000	0000	006564	000224	000241	0625	0625	0625	0375	0375	0375	0000	0000	0000
006073	-00318	-00065	0500	0625	0625	0500	0375	0375	0000	0000	0000	005880	000099	-00452	0500	0500	0625	0500	0500	0375	0000	0000	0000
005784	-01228	-00671	0375	0625	0625	0625	0125	0125	0000	0000	0000	005231	-01211	-01464	0375	0375	0625	0625	0625	0125	0000	0000	0000
005430	-01938	-00947	0250	0625	0625	0750	0375	0375	0000	0000	0000	004799	-00502	-02040	0250	0250	0625	0750	0750	0375	0000	0000	0000
005074	-02611	-01258	0125	0625	0625	0875	0375	0375	0000	0000	0000	004549	-00789	-02487	0125	0125	0625	0875	0875	0375	0000	0000	0000
005060	-04584	-01442	0000	0625	0625	1000	0375	0375	0000	0000	0000	004187	-01006	-02934	0000	0000	0625	1000	1000	0375	0000	0000	0000
007311	002534	001894	1000	0500	0500	0000	0500	0500	0000	0000	0000	009200	-00939	-004617	1000	1000	0500	0000	0000	0500	0000	0000	0000
006839	001877	001545	0875	0500	0500	0125	0500	0500	0000	0000	0000	008494	-00516	-003546	0875	0875	0500	0125	0125	0500	0000	0000	0000
006351	001390	001133	0750	0500	0500	0000	0250	0250	0000	0000	0000	007501	-00287	-002472	0750	0750	0500	0250	0250	0500	0000	0000	0000
005917	000923	000634	0625	0500	0500	0375	0500	0500	0000	0000	0000	006546	-00600	-001334	0625	0625	0500	0375	0375	0500	0000	0000	0000
005448	000206	000364	0500	0500	0500	0500	0500	0500	0000	0000	0000	005527	-00192	-003635	0500	0500	0500	0500	0500	0500	0000	0000	0000
005153	-00318	-00038	0375	0500	0500	0625	0500	0500	0000	0000	0000	004963	000041	-00416	0375	0375	0500	0625	0625	0500	0000	0000	0000
004860	-01337	-00625	0250	0500	0500	0500	0750	0500	0000	0000	0000	004433	-00418	-01286	0250	0250	0500	0750	0750	0500	0000	0000	0000
004713	-02100	-00854	0125	0500	0500	0875	0500	0500	0000	0000	0000	004191	-00769	-01902	0125	0125	0500	0875	0875	0500	0000	0000	0000
004450	-03144	-01046	0000	0500	0500	1000	0500	0500	0000	0000	0000	003873	-00976	-02397	0000	0000	0500	1000	1000	0500	0000	0000	0000
006439	003877	002148	1000	0375	0375	0000	0625	0625	0000	0000	0000	009132	-01031	-005480	1000	1000	0375	0000	0000	0625	0000	0000	0000
006212	002857	001489	0875	0375	0375	0125	0625	0625	0000	0000	0000	008447	-00666	-004642	0875	0875	0375	0125	0125	0625	0000	0000	0000
005822	002004	001813	0750	0375	0375	0250	0625	0625	0000	0000	0000	007496	-00467	-003469	0750	0750	0375	0250	0250	0625	0000	0000	0000
005422	001564	000989	0625	0375	0375	0375	0625	0625	0000	0000	0000	006522	-00222	-002305	0625	0625	0375	0375	0375	0625	0000	0000	0000
005021	000941	000484	0500	0375	0375	0500	0625	0625	0000	0000	0000	005496	000003	001239	0500	0500	0375	0500	0500	0625	0000	0000	0000
004581	000233	000235	0375	0375	0375	0625	0625	0625	0000	0000	0000	004580	000263	000254	0375	0375	0375	0625	0625	0625	0000	0000	0000
004341	-00385	-00062	0250	0375	0375	0750	0625	0625	0000	0000	0000	004135	000022	-00529	0250	0250	0375	0750	0750	0625	0000	0000	0000
004062	-0147																						

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009706	-00104	000233	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009912	-00803	-00597	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008545	-01155	-01144	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
008009	-01514	-01605	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
007440	-01801	-02352	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
006892	-02252	-02702	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006226	-02828	-03030	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
005709	-03293	-03291	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005427	-03944	-03124	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
009188	000197	001186	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
008430	000954	000227	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
008156	-05746	-00474	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
007717	-01260	-01045	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
007261	-01887	-01652	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
006779	-02339	-01988	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
006266	-02683	-02378	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
005901	-03435	-02471	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
005412	-04173	-02820	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
008734	000588	001726	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
007884	000554	001128	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
007425	000237	000311	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
007060	-00540	-00353	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
006733	-01264	-00920	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
006322	-01783	-01423	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
005848	-02200	-01870	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
005611	-03110	-01979	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
005431	-04521	-02379	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
008106	001150	002552	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
007457	000878	001980	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
006958	000622	001101	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
006450	000235	000317	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
006056	-00341	-00217	0500	0593	0625	0500	0406	0375	0000	00112	M05	\$
005795	-01198	-00816	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
005385	-01787	-01475	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
005100	-02283	-01747	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
005099	-04175	-02069	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007392	002082	003028	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
006899	001526	002258	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
006423	001093	001698	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
005968	000725	000992	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
005540	000191	000366	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
005204	-00362	-00273	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
004838	-01292	-00976	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
004732	-01849	-01378	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
004400	-02979	-01486	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
006659	000314	003764	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
006381	002192	002781	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
005941	001744	002066	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
005540	001381	001374	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
005046	000794	000817	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
004569	000262	000212	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
004347	-00423	-00178	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
004196	-01444	-00935	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
004024	-02097	-01153	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
003813	003966	004666	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
003634	003147	004356	0875	0406	0500	0125	0593	0750	0000	00136	P02	\$
005443	002554	002387	0750	0375	0250	0250	0625	0750	0000	00137	P03	\$
005064	001910	001774	0625	0343	0250	0375	0656	0750	0000	00138	P04	\$
004649	001386	001156	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
004278	000989	000598	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
003872	000373	000091	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
003903	-00530	-00304	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
003631	-01667	-00787	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
005501	004986	005182	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
005247	004173	004052	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
004866	003316	002818	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
004512	002827	002140	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
004168	002231	001540	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
003842	001675	000897	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
003494	001057	000467	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
003145	000213	000047	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
003339	-00683	-00390	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
004913	006207	005109	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
004548	005599	004486	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
004184	004856	003523	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
003957	003898	002414	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
003739	003046	001747	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
003536	002484	001216	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
003155	001788	000627	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
002880	000953	000255	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
002671	000046	-00183	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
0099688	-00095	000200	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
0089901	-00398	-00766	0800	0875	1000	0093	0125	0000	0000	00406	J11	\$
008311	-00451	-01365	0812	0750	1000	0187	0250	0000	0000	00407	J12	\$
0077231	-00364	-02327	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
0062550	-00804	-03814	0250	0500	1000	0375	0500	0000	0000	00409	J14	\$
005255	-00285	-03669	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
004455	-00529	-04184	0437	0250	1000	0562	0750	0000	0000	00411	J16	\$
003910	-00498	-04591	0343	0250	1000	0875	0875	0000	0000	00412	J17	\$
003563	-00528	-04745	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
009570	-00763	-001630	0968	1000	0875	0031	0000	0125	0000	00414	J19	\$
008629	000042	000239	0875	0875	0875	0125	0125	0125	0000	00415	K11	\$
007668	-00031	-00770	0781	0750	0875	0218	0250	0125	0000	00416	K12	\$
006920	000095	-01526	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
006108	000011	-02331	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
005346	000133	-02976	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
004812	000125	-03592	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
004423	-00033	-04104	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
003737	000482	-04725	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
009438	-01201	002861	0937	1000	0750	0062	0000	0250	0000	00423	L10	\$
008												

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009714	-00092	000193	1000	1000	1000	0000	0000	0000	0000	00162	S01	\$
009042	-00725	-00707	0875	0937	1000	0125	0062	0000	0000	00163	S02	\$
008586	-01033	-01219	0750	0875	1000	0250	0125	0000	0000	00164	S03	\$
008012	-01384	-01978	0625	0812	1000	0375	0187	0000	0000	00165	S04	\$
007465	-01656	-02579	0500	0750	1000	0500	0250	0000	0000	00166	S05	\$
007029	-01917	-03020	0375	0687	1000	0625	0312	0000	0000	00167	S06	\$
006428	-02145	-03571	0250	0625	1000	0750	0375	0000	0000	00168	S07	\$
005797	-02781	-03962	0125	0562	1000	0875	0500	0000	0000	00169	S08	\$
005373	-03106	-04132	0000	0500	1000	1000	0500	0000	0000	00170	S09	\$
004930	-00063	001326	1000	0937	0875	0000	0062	0125	0000	00171	T01	\$
0048478	00022	000270	0875	0875	0875	0125	0125	0125	0000	00172	T02	\$
008075	-00602	-00610	0750	0812	0875	0250	0187	0125	0000	00173	T03	\$
007583	-00964	-01237	0625	0750	0875	0375	0250	0125	0000	00174	T04	\$
007091	-01066	-01835	0500	0687	0875	0500	0312	0125	0000	00175	T05	\$
006629	-01888	-02343	0375	0625	0875	0625	0375	0125	0000	00176	T06	\$
006037	-02108	-02802	0250	0562	0875	0750	0437	0125	0000	00177	T07	\$
005609	-02689	-03107	0125	0500	0875	0875	0500	0125	0000	00178	T08	\$
005357	-03557	-03731	0000	0437	0875	1000	0562	0125	0000	00179	T09	\$
009017	-00041	002395	1000	0875	0750	0000	0125	0250	0000	00180	U01	\$
008049	000203	001269	0875	0812	0750	0125	0187	0250	0000	00181	U02	\$
007465	000190	000367	0750	0750	0750	0250	0250	0250	0000	00182	U03	\$
006992	-00300	-00530	0625	0687	0750	0375	0312	0250	0000	00183	U04	\$
006627	-01006	-01146	0500	0625	0750	0500	0375	0250	0000	00184	U05	\$
006159	-01511	-01667	0375	0562	0750	0625	0437	0250	0000	00185	U06	\$
005631	-01750	-02257	0250	0500	0750	0750	0500	0250	0000	00186	U07	\$
005282	-02216	-02602	0125	0437	0750	0875	0562	0250	0000	00187	U08	\$
005135	-03332	-03114	0000	0375	0750	1000	0625	0250	0000	00188	U09	\$
008525	000425	003005	1000	0812	0625	0000	0187	0375	0000	00189	V01	\$
007797	000378	002273	0875	0750	0625	0125	0250	0375	0000	00190	V02	\$
007081	000374	001126	0750	0687	0625	0250	0312	0375	0000	00191	V03	\$
006455	000237	000274	0625	0625	0625	0375	0375	0375	0000	00192	V04	\$
006022	-00271	-00367	0500	0562	0625	0500	0437	0375	0000	00193	V05	\$
005692	-00991	-01071	0375	0500	0625	0625	0500	0375	0000	00194	V06	\$
005261	-01448	-01664	0250	0437	0625	0750	0562	0375	0000	00195	V07	\$
004961	-01876	-02147	0125	0375	0625	0875	0625	0375	0000	00196	V08	\$
004761	-02703	-03246	0000	0312	0625	1000	0687	0375	0000	00197	V09	\$
008103	000816	003801	1000	0750	0500	0000	0250	0500	0000	00198	W01	\$
007390	000713	002759	0875	0687	0500	0125	0312	0500	0000	00199	W02	\$
006792	000590	001962	0750	0625	0500	0250	0375	0500	0000	00200	W03	\$
006173	000459	001165	0625	0562	0500	0375	0437	0500	0000	00201	W04	\$
005468	000186	000341	0500	0500	0500	0500	0500	0500	0000	00202	W05	\$
005095	-00247	-00443	0375	0437	0500	0625	0562	0500	0000	00203	W06	\$
004657	-01115	-01165	0250	0375	0500	0750	0625	0500	0000	00204	W07	\$
004528	-01554	-01581	0125	0312	0500	0875	0687	0500	0000	00205	W08	\$
004313	-02203	-01974	0000	0250	0500	1000	0750	0500	0000	00206	W09	\$
007641	001403	004338	1000	0687	0375	0000	0312	0625	0000	00207	X01	\$
006974	001166	003232	0875	0625	0375	0125	0375	0625	0000	00208	X02	\$
006383	000936	002481	0750	0562	0375	0250	0437	0625	0000	00209	X03	\$
005722	000870	001662	0625	0500	0375	0375	0500	0625	0000	00210	X04	\$
005145	000481	000971	0500	0437	0375	0500	0562	0625	0000	00211	X05	\$
004580	000242	000199	0375	0375	0375	0625	0625	0625	0000	00212	X06	\$
004261	-00280	-00309	0250	0312	0375	0750	0687	0625	0000	00213	X07	\$
004065	-01261	-01073	0125	0250	0375	0875	0750	0625	0000	00214	X08	\$
003923	-01741	-01486	0000	0187	0375	1000	0812	0625	0000	00215	X09	\$
007218	001989	005952	1000	0625	0250	0000	0375	0750	0000	00216	Y01	\$
006682	001584	003826	0875	0562	0250	0125	0437	0750	0000	00217	Y02	\$
006058	001381	002914	0750	0500	0250	0250	0500	0750	0000	00218	Y03	\$
005500	001162	002179	0625	0437	0250	0375	0500	0750	0000	00219	Y04	\$
004889	000928	001373	0500	0375	0250	0500	0625	0750	0000	00220	Y05	\$
004381	000660	000728	0375	0312	0250	0625	0687	0750	0000	00221	Y06	\$
003833	000370	000809	0250	0250	0250	0750	0750	0750	0000	00222	Y07	\$
003764	-00353	-00454	0125	0187	0250	0875	0812	0750	0000	00223	Y08	\$
003431	-01424	-01043	0000	0125	0250	1000	0875	0750	0000	00224	Y09	\$
006760	002645	006177	1000	0562	0125	0000	0437	0875	0000	00225	Z01	\$
006160	002729	004835	0875	0500	0125	0125	0125	0800	0875	00226	Z02	\$
005650	001913	003568	0750	0437	0125	0250	0562	0875	0000	00227	Z03	\$
005180	001534	002745	0625	0375	0125	0375	0625	0875	0000	00228	Z04	\$
004559	001399	001991	0500	0312	0125	0500	0687	0875	0000	00229	Z05	\$
004041	001131	001156	0375	0250	0125	0625	0750	0875	0000	00230	Z06	\$
003627	000738	000524	0250	0187	0125	0750	0812	0875	0000	00231	Z07	\$
003138	000210	000052	0125	0125	0125	0875	0875	0875	0000	00232	Z08	\$
003230	-00614	-00404	0000	0062	0125	1000	0937	0875	0000	00233	Z09	\$
006439	003218	006548	1000	0500	0000	0000	0500	1000	0000	00234	Z10	\$
005822	003262	005935	0875	0437	0000	0125	0562	1000	0000	00235	a02	\$
005153	002800	004772	0750	0375	0000	0250	0625	1000	0000	00236	a03	\$
004785	002204	003360	0625	0312	0000	0375	0687	1000	0000	00237	a04	\$
004350	001881	002376	0500	0250	0000	0500	0750	1000	0000	00238	a05	\$
003861	001504	001672	0375	0187	0000	0625	0812	1000	0000	00239	a06	\$
003389	001221	000899	0250	0125	0000	0750	0875	1000	0000	00240	a07	\$
003019	000564	000417	0125	0062	0000	0875	0937	1000	0000	00241	a08	\$
002666	000052	000176	0000	0000	0000	1000	1000	1000	0000	00242	a09	\$
009706	-00104	000218	1000	1000	1000	0000	0000	0000	0000	00486	S10	\$
008846	-00099	-00720	0937	0875	1000	0062	0125	0000	0000	00487	S11	\$
008000	000093	-01468	0875	0750	1000	0125	0250	0000	0000	00488	S12	\$
006947	000282	-02305	0812	0625	1000	0187	0375	0000	0000	00489	S13	\$
005792	000768	-03051	0750	0500	1000	0250	0500	0000	0000	00490	S14	\$
004740	001370	-03637	0687	0375	1000	0312	0625	0000	0000	00491	S15	\$
004008	001694	-04053	0625	0250	1000	0375	0750	0000	0000	00492	S16	\$
003304	000937	-04283	0562	0250	1000	0437	0875	0000	0000	00493	S17	\$
003260	001341	-04409	0500	0000	1000	0500	1000	0000	0000	00494	S18	\$
009339	-00956	001164	0937	1000	0875	0062	0000	0125	0000	00495	T10	\$
008644	000037	000222	0875	0875	0875	0125	0125	0125	0000	00496	T11	\$
007572	000250	-00865	0812	0750	0875	0187	0250	0125	0000	00497	T12	\$
006782	000458	-01647	0750	0625	0875	0250	0375	0125	0000	00498	T13	\$
005853	000685	-02541	0687	0500	0875	0312	0500	0125	0000	00499	T14	\$
005078	001087	-03247	0625	0375	0875	0375	0625	0125	0000	00500	T15	\$
004319	001496	-03866	0562	0250	0875	0437	0750	0125	0000	00501	T16	\$
003770	001733	-04152	0500	0125	0875	0500	0875	0125	0000	00502	T17	\$
003322	001816	-04382	0437	0000	0875	0562	1000	0125	0000	00503	T18	\$
009113	-01493	002194	0875	1000	0750	0125	0000	0250	0000	00504		

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009713	-00104	000222	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
009953	-00611	-00672	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008543	-00907	-01249	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
007934	-01125	-01968	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
007303	-01393	-02633	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
006678	-01538	-03272	0375	0531	1000	0625	0488	0000	0000	%0248	b06	\$
006087	-01728	-03862	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
005408	-01915	-04460	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$
005264	-02362	-04697	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
004985	-00345	-001546	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
008514	000302	000243	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
007900	-00394	-00714	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
007338	-00642	-01278	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
006744	-01043	-02033	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
006265	-01257	-02509	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
005609	-01420	-03074	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
005196	-01699	-03441	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
004985	-02520	-04191	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
002335	-00423	-002709	1000	0937	0750	0000	0062	0250	0000	%0261	d01	\$
008359	-00030	-001399	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
007497	-000221	-000309	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$
006897	-00195	-00532	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
006439	-00618	-01253	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
005876	-00989	-01866	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
005386	-01227	-02413	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
004978	-01529	-02865	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
004631	-01967	-03422	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
008890	-00147	-003551	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
008143	-00002	-002577	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
007317	-000142	-001238	0750	0718	0625	0250	0281	0375	0000	%0272	e03	\$
006509	-000239	-000258	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
005957	-00008	-00342	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
005497	-00621	-01287	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$
005098	-01004	-01857	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$
004758	-01411	-02284	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
004440	-01766	-02868	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
008672	-00950	-004101	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
007853	-007137	-003041	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
007093	-000211	-002183	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
006342	-000315	-001134	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
005506	-000208	-000383	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
005062	-00606	-00428	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
004676	-00753	-01211	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
004395	-01123	-01806	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
004262	-01632	-02164	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
008476	-000030	-004972	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
007671	-000139	-003938	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
006932	-000136	-003006	0750	0656	0375	0250	0343	0625	0000	%0290	g03	\$
006103	-000288	-002018	0625	0562	0375	0375	0437	0625	0000	%0291	g04	\$
005280	-000320	-001055	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
004560	-000227	-000193	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
004130	-00105	-00439	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
003878	-00952	-01248	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
003729	-01353	-01685	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
008209	-000273	-005792	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
007468	-000342	-004589	0875	0718	0250	0125	0281	0750	0000	%0298	h02	\$
006677	-000305	-003642	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
005938	-000416	-002731	0625	0531	0250	0500	0468	0750	0000	%0300	h04	\$
005155	-000392	-001741	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
004444	-000365	-000885	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
003793	-000362	-000099	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
003649	-00244	-00540	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
003312	-01036	-01220	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
007892	-000641	-006827	1000	0781	0125	0000	0218	0875	0000	%0306	i01	\$
007222	-000654	-006078	0875	0687	0125	0125	0312	0875	0000	%0307	i02	\$
006445	-000665	-004400	0750	0593	0125	0250	0406	0875	0000	%0308	i03	\$
005748	-000630	-003381	0625	0500	0125	0375	0500	0875	0000	%0309	i04	\$
004957	-000504	-002378	0500	0406	0125	0500	0593	0875	0000	%0310	i05	\$
004304	-000589	-001503	0375	0312	0125	0625	0687	0875	0000	%0311	i06	\$
003755	-000436	-000712	0250	0218	0125	0750	0781	0875	0000	%0312	i07	\$
003133	-000218	-000058	0125	0125	0125	0875	0875	0875	0000	%0313	i08	\$
003093	-00406	-00630	0000	0031	0125	1000	0968	0875	0000	%0314	i09	\$
007620	-001048	-007787	1000	0750	0000	0000	0250	1000	0000	%0315	j01	\$
006889	-001099	-007049	0875	0656	0000	0125	0343	1000	0000	%0316	j02	\$
005967	-001282	-006025	0750	0562	0000	0250	0437	1000	0000	%0317	j03	\$
005432	-000973	-004509	0625	0468	0000	0375	0531	1000	0000	%0318	j04	\$
004847	-000761	-003200	0500	0375	0000	0500	0625	1000	0000	%0319	j05	\$
004135	-000695	-002209	0375	0281	0000	0625	0718	1000	0000	%0320	j06	\$
003578	-000658	-001191	0250	0187	0000	0750	0812	1000	0000	%0321	j07	\$
003093	-000262	-000574	0125	0093	0000	0875	0906	1000	0000	%0322	j08	\$
002656	-000955	-00194	0000	0000	0000	1000	1000	1000	0000	%0323	j09	\$
009704	-000099	-000199	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
008912	-000173	-00579	0800	0875	1000	0031	0125	0000	0000	%0568	b11	\$
008069	-000555	-01257	0937	0750	1000	0062	0250	0000	0000	%0569	b12	\$
007817	-001072	-01915	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$
005895	-001519	-02643	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
004883	-002122	-03185	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
003923	-002852	-03584	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
003441	-003212	-03589	0781	0250	1000	0248	0875	0000	0000	%0574	b17	\$
003045	-003435	-03729	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
002920	-01034	-000853	0906	1000	0875	0093	0000	0125	0000	%0576	c01	\$
008675	-000040	-000212	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$
007645	-000458	-006090	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
006916	-000841	-01392	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
006025	-001398	-02139	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
005062	-002181	-02867	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
004195	-002750	-03426	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$
003540	-003167	-03642	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
002993	-003401	-03676	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
008884	-01599	-001558	0812	1000	0750	0187	0000	0250	0000	%0585	d01	\$
008244	-00713	-000781	0781	0875	0750	0218	0125	0250	0000			

See original or copy: <http://web.me.com/klaus.richter/HE11/HE11L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG HE01_22.TXT, Separation cmy0*, D65, not adapted S
%100 x LAB*      %1000 x (r g b c m y 0)      %nr.   pos $
%Z004394 006110 002569 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008910 -01080 008032 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005542 -06514 002412 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005642 -04327 -02112 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z004568 -01040 -04800 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z003192 004697 -02825 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z002643 000055 -00184 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009704 -00099 000200 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004394 006110 002569 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008910 -01080 008032 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005542 -06514 002412 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005642 -04327 -02112 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z004568 -01040 -04800 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z003192 004697 -02825 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z002643 000055 -00184 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009704 -00099 000200 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004394 006110 002569 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008910 -01080 008032 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005542 -06514 002412 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005642 -04327 -02112 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z004568 -01040 -04800 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z003192 004697 -02825 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z002643 000055 -00184 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009704 -00099 000200 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z004913 006207 005109 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008801 -02444 008884 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005635 -05773 000815 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005427 -03944 -03124 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003563 000628 -04746 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z003877 005887 -01953 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z002613 000063 -00175 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009696 -00103 000222 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z006439 003218 006548 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006943 -04522 005768 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005711 -05262 -00123 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z005371 -03196 -04132 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003290 001941 -04409 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004493 007004 -00816 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z002658 000047 -00185 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009709 -00100 000203 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z007620 001048 007787 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z005795 -06300 004020 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005734 -04727 -01193 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z005264 -02362 -04697 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003045 003436 -03720 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004445 006421 001116 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z002602 000056 -00186 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009706 -00103 000211 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/HE11/HE11L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG HE01 22.TXT, Separation cmy0*, D65, not adapted S																			
%100 x LAB*																			
1000 x (r g b c m y 0)																			
%nr. pos \$																			
002456	000055	-00140	0000	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002897	000199	000074	0125	0125	0125	0125	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003629	000372	000125	0250	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004372	000247	000248	0375	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005469	000174	000361	0500	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006512	000238	000267	0625	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007551	000232	000311	0750	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008642	000054	000239	0875	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009728	000097	000181	1000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002414	000059	00152	0000	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002815	000201	000058	0125	0125	0125	0875	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003613	000392	000072	0250	0250	0250	0750	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004389	000256	000201	0375	0375	0375	0625	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005404	000202	000316	0500	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006519	000250	000221	0625	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007564	000240	000271	0750	0750	0750	0250	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008661	000061	000224	0875	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009723	-00101	000196	1000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002399	000069	-00150	0000	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002800	000213	000065	0125	0125	0125	0875	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003597	000411	000081	0250	0250	0250	0750	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004404	000266	000211	0375	0375	0375	0625	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005412	000211	000321	0500	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006477	000274	000224	0625	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007544	000243	000288	0750	0750	0750	0250	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008648	000077	000225	0875	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009715	-000099	000189	1000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002396	000049	-00133	0000	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002824	000198	000069	0125	0125	0125	0875	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003623	000357	000100	0250	0250	0250	0750	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004413	000255	000202	0375	0375	0375	0625	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005423	000196	000234	0500	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006541	000234	000251	0625	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007532	000239	000290	0750	0750	0750	0250	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008664	000052	000242	0875	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009718	-000096	000192	1000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002624	000047	-00200	0000	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002965	000140	-00085	0066	0066	0066	0066	0933	0933	0933	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003232	000199	000040	0133	0133	0133	0866	0866	0866	0866	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003569	000287	000062	0200	0200	0200	0800	0800	0800	0800	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003966	000406	000098	0266	0266	0266	0733	0733	0733	0733	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004375	000343	000164	0333	0333	0333	0666	0666	0666	0666	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004749	000284	000264	0400	0400	0400	0600	0600	0600	0600	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005344	000300	000324	0466	0466	0466	0533	0533	0533	0533	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005844	000245	000300	0533	0533	0533	0466	0466	0466	0466	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006377	000269	000259	0600	0600	0600	0600	0399	0399	0399	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006873	000228	000340	0666	0666	0666	0666	0333	0333	0333	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007356	000254	000355	0733	0733	0733	0733	0266	0266	0266	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007872	000159	000325	0800	0800	0800	0800	0199	0199	0199	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008403	000005	000355	0866	0866	0866	0866	0133	0133	0133	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009027	-00066	000189	0933	0933	0933	0066	0066	0066	0066	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009715	-00083	000184	1000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002660	000050	-00171	0000	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002977	000144	-00078	0066	0066	0066	0066	0933	0933	0933	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003196	000210	000032	0133	0133	0133	0866	0866	0866	0866	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003583	000291	000059	0200	0200	0200	0800	0800	0800	0800	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003907	000437	000006	0266	0266	0266	0733	0733	0733	0733	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004358	000367	000153	0333	0333	0333	0666	0666	0666	0666	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004734	000299	000252	0400	0400	0400	0600	0600	0600	0600	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005341	000304	000279	0466	0466	0466	0533	0533	0533	0533	0000	0000	0000	0						

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/HE11/HE11L0NA.TXT> / PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

TUB registration: 20091101-HE11/HE11L0NA.TXT/.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

[illegible]

TUB-test chart HE11; Relative Elementary Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/HE11/HE11L0NA.TXT> / .PS
 Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart HE11; Relative Elementary Colour System O
1080 spectral reflexions R $\rightarrow$ LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

TUB registration: 20091101-HE11/HE11L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/HE11/HE11L0NA.TXT> / .PS
Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=

input: w *setgray*
output: $\rightarrow olv^*$ *setrgbcolor*

See original or copy: <http://web.me.com/klaus.richter/HE11/HE11L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG HE01_22.TXT, Separation cmy0*, D65, adapted S
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr.    pos $
%Z004394 006093 002658 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008910 -00999 007874 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005542 -06506 002438 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005642 -04317 -02091 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z004568 -01053 -04721 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z003192 004653 -02671 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z002643 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009704 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004394 006093 002658 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008910 -00999 007874 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005542 -06506 002438 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005642 -04317 -02091 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z004568 -01053 -04721 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z003192 004653 -02671 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z002643 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009704 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004394 006093 002658 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008910 -00999 007874 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005542 -06506 002438 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005642 -04317 -02091 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z004568 -01053 -04721 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z003192 004653 -02671 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z002643 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009704 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z004913 006198 005155 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008801 -02362 008712 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005635 -05765 000821 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005427 -03941 -03107 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003563 000587 -04624 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z003877 005854 -01848 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z002613 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009696 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z006439 003249 006524 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006943 -04488 005717 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005711 -05245 -00106 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z005371 -03186 -04097 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003290 001907 -04258 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004493 006995 -00732 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z002658 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009709 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z007620 001104 007693 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z005795 -06285 004028 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005734 -04713 -01182 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z005264 -02359 -04660 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003045 003389 -03558 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004445 006405 001200 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z002602 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009706 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```


%BEG HE01 22.TXT, Separation cmy0*, D50, not adapted S																								
%100 x LAB*																								
1000 x (r g b c m y o)																								
%nrr. pos \$																								
009706	-00068	000185	1000	1000	1000	0000	0000	0000	0000	%0000	A01 \$	009706	-00068	000185	1000	1000	1000	0000	0000	0000	0000	%0324	A10 \$	
009905	-00834	-00495	0875	1000	0000	0125	0000	0000	0000	%0001	A02 \$	009905	-00578	000734	0875	0875	1000	0125	0125	0000	0000	%0325	A11 \$	
008594	-01223	-00985	0750	1000	1000	0250	0000	0000	0000	%0002	A03 \$	008495	-00994	-01370	0750	0750	1000	0250	0250	0000	0000	%0326	A12 \$	
008903	-01797	-01373	0625	1000	1000	0375	0000	0000	0000	%0003	A04 \$	007501	-01232	-02387	0625	0625	1000	0375	0375	0000	0000	%0327	A13 \$	
007410	-02282	-01821	0500	1000	1000	0500	0000	0000	0000	%0004	A05 \$	006664	-01288	-03140	0500	0500	1000	0500	0500	0000	0000	%0328	A14 \$	
006917	-02799	-02080	0375	1000	1000	0625	0000	0000	0000	%0005	A06 \$	005832	-01404	-03823	0375	0375	1000	0625	0625	0000	0000	%0329	A15 \$	
006301	-03552	-02151	0250	1000	1000	0750	0000	0000	0000	%0006	A07 \$	005140	-01604	-04444	0250	0250	1000	0750	0750	0000	0000	%0330	A16 \$	
005806	-04193	-02367	0125	1000	1000	0875	0000	0000	0000	%0007	A08 \$	004712	-01849	-04836	0125	0125	1000	0875	0875	0000	0000	%0331	A17 \$	
005508	-04693	-02434	0000	1000	1000	1000	0000	0000	0000	%0008	A09 \$	004420	-01873	-05079	0000	0000	1000	1000	1000	0000	0000	%0332	A18 \$	
009173	000592	000660	1000	0875	0875	0000	0125	0125	0000	%0009	B01 \$	009650	-00490	001862	1000	1000	0875	0000	0000	0125	0000	%0333	B10 \$	
008483	000081	000259	0875	0875	0875	0875	0125	0125	0125	%0010	B02 \$	008704	000077	000227	0875	0875	0875	0125	0125	0125	0000	%0334	B11 \$	
008182	-00848	-00210	0750	0875	0875	0875	0250	0125	0125	%0011	B03 \$	007873	-00302	-00749	0750	0750	0875	0250	0250	0125	0000	%0335	B12 \$	
007727	-01303	-00578	0625	0875	0875	0375	0125	0125	0000	%0012	B04 \$	007249	-00581	-01439	0625	0625	0875	0375	0375	0125	0000	%0336	B13 \$	
007226	-02097	-01246	0500	0875	0875	0500	0125	0125	0000	%0013	B05 \$	006371	-00699	-02288	0500	0500	0875	0500	0500	0125	0000	%0337	B14 \$	
006800	-02556	-01490	0375	0875	0875	0875	0625	0125	0125	%0014	B06 \$	005759	-01002	-02866	0375	0375	0875	0625	0625	0125	0000	%0338	B15 \$	
006293	-03247	-01661	0250	0875	0875	0750	0125	0125	0000	%0015	B07 \$	005151	-01339	-03487	0250	0250	0875	0750	0750	0125	0000	%0339	B16 \$	
005959	-04124	-01855	0125	0875	0875	0875	0125	0125	0000	%0016	B08 \$	004802	-01599	-03886	0125	0125	0875	0875	0875	0125	0000	%0340	B17 \$	
005412	-04970	-02209	0000	0875	0875	1000	0125	0125	0000	%0017	B09 \$	004399	-01859	-04857	0000	0000	0875	1000	1000	0125	0000	%0341	B18 \$	
008638	001251	000983	1000	0750	0750	0000	0250	0250	0000	%0018	C01 \$	009504	-00550	002939	1000	1000	0750	0000	0000	0250	0000	%0342	C10 \$	
007848	000864	000786	0875	0750	0750	0125	0250	0250	0000	%0019	C02 \$	008586	000035	001509	0875	0875	0750	0125	0125	0250	0000	%0343	C11 \$	
007452	000936	000329	0750	0750	0750	0250	0250	0250	0000	%0020	C03 \$	007602	000284	000295	0750	0750	0250	0250	0250	0000	%0344	C12 \$		
006428	-01467	-00511	0625	0750	0750	0375	0500	0250	0000	%0021	C04 \$	006887	-00117	-00578	0625	0625	0750	0375	0250	0375	0250	0000	%0345	C13 \$
006661	-00622	-00437	0500	0500	0500	0250	0250	0000	0000	%0022	C05 \$	006216	-00437	-01444	0500	0500	0750	0500	0500	0250	0000	%0346	C14 \$	
008237	01982	01185	0375	0750	0750	0625	0250	0250	0000	%0023	C06 \$	005475	-00710	-02180	0375	0375	0750	0625	0625	0250	0000	%0347	C15 \$	
006207	-02573	-01411	0250	0750	0750	0750	0250	0250	0000	%0024	C07 \$	005026	-01018	-02657	0250	0250	0750	0750	0250	0500	0000	%0348	C16 \$	
005539	-03497	-01691	0125	0750	0750	0875	0250	0250	0000	%0025	C08 \$	004677	-01281	-03116	0125	0125	0750	0875	0875	0250	0000	%0349	C17 \$	
005288	-05328	-01994	0000	0750	0750	1000	0250	0250	0000	%0026	C09 \$	004260	-01694	-03867	0000	0000	0750	1000	1000	0250	0000	%0350	C18 \$	
007990	002082	001392	1000	0625	0625	0000	0375	0375	0000	%0027	D01 \$	009337	-00469	003716	1000	1000	0625	0000	0000	0375	0000	%0351	D10 \$	
007386	001504	001284	0875	0625	0625	0125	0375	0375	0000	%0028	D02 \$	008578	-00119	002765	0875	0875	0625	0125	0125	0375	0000	%0352	D11 \$	
006915	000989	000764	0750	0625	0625	0250	0375	0375	0000	%0029	D03 \$	007629	000033	000142	0750	0750	0625	0250	0250	0375	0000	%0353	D12 \$	
006459	000319	000280	0625	0625	0625	0375	0375	0375	0000	%0030	D04 \$	006572	000278	000249	0625	0625	0625	0375	0375	0375	0000	%0354	D13 \$	
006065	-00321	-00087	0500	0625	0625	0500	0375	0375	0000	%0031	D05 \$	005874	000067	-00460	0500	0500	0625	0500	0500	0375	0000	%0355	D14 \$	
005745	-01297	-00767	0375	0625	0625	0625	0375	0375	0000	%0032	D06 \$	005190	-00352	-01525	0375	0375	0625	0625	0625	0375	0000	%0356	D15 \$	
005370	-02043	-01095	0250	0625	0625	0875	0375	0375	0000	%0033	D07 \$	004747	-00740	-02137	0250	0250	0625	0750	0750	0375	0000	%0357	D16 \$	
004994	-02777	-01455	0125	0625	0625	0750	0375	0375	0000	%0034	D08 \$	004479	-01120	-02619	0125	0125	0625	0875	0875	0375	0000	%0358	D17 \$	
004937	-04847	-01754	0000	0625	0625	1000	0375	0375	0000	%0035	D09 \$	004099	-01439	-03101	0000	0000	0625	1000	1000	0375	0000	%0359	D18 \$	
007390	002881	002004	1000	0500	0500	0000	0500	0500	0000	%0036	E01 \$	009233	-00455	-00454	1000	1000	0500	0000	0000	0500	0000	%0360	E10 \$	
006899	002165	001626	0875	0500	0500	0125	0500	0500	0000	%0037	E02 \$	008526	-00111	003502	0875	0875	0500	0125	0125	0500	0000	%0361	E11 \$	
006395	001613	001193	0750	0500	0500	0500	0250	0500	0000	%0038	E03 \$	007525	000015	002449	0750	0750	0500	0250	0250	0500	0000	%0362	E12 \$	
005944	001066	000673	0625	0500	0500	0375	0500	0500	0000	%0039	E04 \$	006562	000122	001328	0625	0625	0500	0375	0375	0500	0000	%0363	E13 \$	
005547	000275	000372	0500	0500	0500	0500	0500	0500	0000	%0040	E05 \$	005536	000260	000373	0500	0500	0500	0500	0500	0500	0000	%0364	E14 \$	
005146	-00318	-00060	0375	0500	0500	0500	0625	0500	0000	%0041	E06 \$	004957	000009	-00426	0375	0375	0500	0625	0625	0500	0000	%0365	E15 \$	
004820	-01401	-00726	0250	0500	0500	0500	0750	0500	0000	%0042	E07 \$	004399	-00546	-01353	0250	0250	0500	0750	0750	0500	0000	%0366	E16 \$	
004652	-02198	-01009	0125	0500	0500	0500	0875	0500	0000	%0043	E08 \$	004136	-01007	-02010	0125	0125	0500	0875	0875	0500	0000	%0367	E17 \$	
004363	-03293	-01266	0000	0500	0500	0500	1000	0500	0000	%0044	E09 \$	003800	-01315	-02538	0000	0000	0500	1000	1000	0500	0000	%0368	E18 \$	
004039	-00725	-00070	0375	0375	0375	0625	0625	0625	0000	%0045	F01 \$	009170	-00491	-00538	1000	03								

009707	-00071	000226	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009894	-00868	-00662	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
009850	-01249	-01242	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
009746	-01753	-01744	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
009735	-02119	-02531	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
009678	-02642	-02923	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006101	-03309	-03302	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
005555	-03978	-03608	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005275	-04539	-03465	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
009207	-000383	001187	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
008434	-000095	000226	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
008131	-00785	-00536	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
007671	-01380	-01151	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
007189	-02094	-01815	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
006690	-02605	-02191	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
006160	-03032	-02615	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
005777	-03833	-02756	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
005264	-04706	-03161	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
008768	-000588	001744	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
007910	-000748	001147	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
007434	-000302	000319	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
007042	-00573	-00397	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
006689	-01367	-01023	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
006257	-01959	-01573	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
005764	-02458	-02058	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
005505	-03410	-02227	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
005287	-04971	-02720	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
008162	-001525	002593	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
007509	-001182	002011	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
006498	-000812	001125	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
006459	-000308	000325	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
006044	-00359	-00244	0500	0593	0625	0500	0406	0375	0000	00112	M05	\$
005757	-01284	-00913	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
005318	-01980	-01626	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
005016	-02532	-01937	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
004969	-04556	-02378	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007472	-002516	003109	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
006958	-001873	-002318	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
006467	-001365	-001742	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
005956	-000903	-001022	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
005449	-002359	-000374	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
005192	-00368	-00303	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
004792	-04202	-01084	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
004666	-01631	-01530	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
004307	-03208	-01710	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
006769	-003168	-003883	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
006467	-002591	-002867	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
006003	-002067	-002138	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
005487	-001622	-001434	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
005073	-000950	-000851	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
004577	-000312	-000223	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
004334	-00438	-00210	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
004147	-01552	-01051	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003957	-02259	-01314	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
006239	-004477	-004804	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
005937	-003575	-003380	0875	0406	0250	0125	0593	0750	0000	00136	P02	\$
005527	-002908	-002493	0750	0375	0250	0250	0625	0750	0000	00137	P03	\$
005128	-002239	-001854	0625	0343	0250	0375	0625	0750	0000	00138	P04	\$
004624	-001598	-001216	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
004307	-001123	-000647	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
003881	-000411	-000197	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
003886	-00553	-00347	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
003580	-01756	-00913	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
005705	-005472	-005356	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
005343	-004612	-004209	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
004972	-003686	-002956	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
004600	-003142	-002263	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
004236	-002488	-001639	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
003890	-001859	-000973	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
003523	-001173	-000514	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
003150	-000233	-000057	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
003317	-00717	-00447	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
005111	-006616	-005363	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
004725	-005981	-004715	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
004336	-005204	-003731	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
004075	-004204	-002591	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
003829	-003311	-001887	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
003607	-002703	-001331	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
003203	-001939	-000718	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
002904	-001036	-000199	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
002669	-000034	-000186	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
0099689	-000066	-000193	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
0098879	-00471	-00813	0906	0875	1000	0093	0125	0000	0000	00406	J11	\$
008276	-00587	-01434	0812	0750	1000	0187	0250	0000	0000	00407	J12	\$
007177	-00613	-02427	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
006191	-00416	-03131	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
005179	-00145	-03791	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
004365	-00015	-04334	0347	0250	1000	0562	0750	0000	0000	00411	J16	\$
003402	-00109	-04763	0343	0250	1000	0875	0875	0000	0000	00412	J17	\$
002401	-00105	-04839	0250	0500	1000	0750	1000	0000	0000	00413	J18	\$
009576	-00564	-001588	0968	1000	0875	0031	0000	0125	0000	00414	K10	\$
008634	-000084	-000238	0875	0875	0875	0125	0125	0125	0000	00415	K11	\$
007653	-00092	-00797	081	0750	0875	0218	0250	0125	0000	00416	K12	\$
006894	-00634	-01573	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
006061	-00221	-02414	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
005285	-00189	-03083	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
004732	-00316	-03731	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
004322	-00610	-04282	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
003621	-00249	-04922	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
009449	-00876	-002793	0937	1000	0750	0062	0000	0250	0000	00423	L10	\$
008504	-00133</											

009714	-00064	000185	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
009914	-00806	-00769	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
008542	-01179	-01313	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
007945	-01641	-02116	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
007379	-02012	-02756	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
006917	-02359	-03231	0315	0687	1000	0625	0312	0000	0000	%0167	S06	\$
006305	-02718	-03823	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
005647	-03400	-04274	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$
005204	-04002	-04482	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
009346	000127	001317	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
008482	000068	000268	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
008051	-00655	-00667	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
007540	-01111	-01328	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
007022	-01840	-01985	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
006542	-02210	-02528	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
005933	-02527	-03020	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
005484	-03207	-03373	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
005195	-04284	-04080	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
009046	000275	002382	1000	0875	0875	0000	0125	0250	0000	%0180	T10	\$
008071	000481	001275	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
007474	000261	000373	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
006974	-00427	-00570	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
006584	-01141	-01238	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
006095	-01720	-01807	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
005548	-02074	-02430	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
005180	-02624	-02818	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
004995	-03913	-03410	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
008570	000020	002010	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
007833	000693	003779	0875	0750	0625	0125	0250	0375	0000	%0190	V02	\$
007104	000559	001139	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
006464	000293	000282	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
006010	-00307	-00303	0500	0562	0625	0500	0437	0375	0000	%0193	V05	\$
005651	-01110	-01163	0375	0500	0625	0625	0500	0375	0000	%0194	V06	\$
005198	-01604	-01800	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
004877	-02187	-02327	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
004649	-03136	-02789	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
008163	001283	003815	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
007437	001086	002779	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
006829	000873	001982	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
006198	000646	001182	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
005476	002050	000348	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
005082	-00286	-00471	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$
004611	-01249	-01268	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
004463	-01769	-01721	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
004226	-02507	-02168	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
007717	001919	004369	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
007035	001585	003265	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
006433	001277	002512	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
005761	001126	001696	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
005167	000642	000991	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
004588	000288	000299	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
004249	-00306	-00335	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
004017	-01387	-01182	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
003856	-01949	-01636	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
007304	002546	005909	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
006757	002049	003867	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
006120	001765	002959	0500	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
005551	001604	002223	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
004925	001149	001411	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
004404	000797	000757	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
003842	000407	001015	0250	0250	0250	0500	0750	0750	0000	%0222	Y07	\$
003748	-00392	-00489	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
003380	-01549	-01163	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
006874	003237	006204	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
006256	002793	004879	0875	0500	0125	0125	0125	0800	0875	%0226	Z02	\$
005729	002342	003625	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
005243	001892	002797	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
004612	001685	002045	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
004079	001328	001206	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
003650	000850	000557	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
003143	000231	000061	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
003208	-00656	-00538	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$
006567	003802	006589	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
005946	003796	005990	0750	0437	0000	0125	0562	1000	0000	%0235	A02	\$
005259	003269	004834	0875	0300	0000	0250	0625	1000	0000	%0236	A03	\$
004868	002598	003430	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
004418	002200	002448	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
003913	001755	001734	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
003428	001388	000954	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
003036	000652	000443	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$
002664	000041	-00178	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009707	-00073	000210	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
008831	-00154	-00751	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
007975	-00028	-01514	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
006908	000073	-02372	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
005745	000478	-03126	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
004688	001000	-03710	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
003949	001241	-04133	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
003321	001423	-04363	0562	0250	1000	0437	0875	0000	0000	%0493	S17	\$
003222	001375	-04509	0500	0000	1000	0500	1000	0000	0000	%0494	S18	\$
009335	-00804	001107	0937	1000	0875	0062	0100	0125	0000	%0495	T10	\$
008448	000077	000221	0875	0875	0875	0125	0125	0125	0000	%0496	T11	\$
007561	000192	-00882	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
006760	000333	-01680	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
005816	000464	-02598	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
005031	000776	-03315	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
004262	001079	-03945	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
003708	001248	-04236	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
003250	001246	-04478	0437	0000	0750	0562	1000	0125	0000	%0503	T18	\$
009110	-01225	002106	0875	1000	0750	0125	0000	0250	0000	%0504	T19	\$
008362	-00427	000982	0812	0875	0750	0187	0125	0250	0000			

009714	-00072	000215	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
009028	-00684	-00727	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008501	-01051	-01337	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
007873	-01367	-02092	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
007220	-01743	-02799	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
006576	-02007	-03475	0735	0531	1000	0625	0468	0000	0000	%0248	b06	\$
005963	-02335	-04107	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
005257	-02701	-04753	0125	0343	1000	0875	0562	0000	0000	%0250	b08	\$
005097	-03258	-05032	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
004949	-00143	-001525	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
008518	000075	000242	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
007879	-00461	-00759	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
007301	-00784	-01353	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
006683	-01296	-02156	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
006187	-01597	-02662	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
005512	-01874	-03262	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
005082	-02249	-03666	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
004830	-03320	-04507	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
004260	-00091	-002679	1000	0937	0750	0000	0602	0250	0000	%0261	d01	\$
008377	000168	001392	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
007506	000285	000316	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$
006883	-00245	-00558	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
006403	-00760	-01324	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
005818	-01221	-01981	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
005310	-01553	-02564	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
004884	-01964	-03053	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
004510	-02556	-03665	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
008127	000256	003329	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
008175	000329	002566	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
007336	000326	001241	0750	0718	0625	0250	0281	0375	0000	%0272	e03	\$
006517	000296	000266	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
005948	-00109	-00357	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
005459	-00763	-01362	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$
005039	-01242	-01919	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$
004681	-01727	-02411	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
004344	-01293	-02884	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
008718	000419	004075	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
007892	000515	003032	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
007124	000503	002185	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
006363	000491	001145	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
005514	000268	000311	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
005053	-00098	-00444	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
004636	-00890	-01293	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
004334	-01366	-01928	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
004182	-01952	-02331	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
008530	000562	004935	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
007718	000590	003918	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
006969	000502	002997	0750	0566	0375	0250	0343	0625	0000	%0290	g03	\$
006134	000560	002024	0625	0652	0375	0375	0437	0625	0000	%0291	g04	\$
005300	000484	001067	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
004568	000272	000203	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
004120	-00145	-00457	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
003833	-01099	-01344	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
003665	-01592	-01817	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
008274	000856	005744	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
007523	000842	004563	0875	0718	0250	0125	0281	0750	0000	%0298	h02	\$
006725	000806	003633	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
006078	000756	002735	0625	0531	0250	0375	0468	0750	0000	%0300	h04	\$
005184	000633	001753	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
004463	000507	000900	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
003802	000400	000115	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
003634	-00290	-00572	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
003265	-01181	-01322	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
007970	001270	006759	1000	0781	0125	0000	0218	0875	0000	%0306	i01	\$
007293	001231	006023	0875	0687	0125	0125	0312	0875	0000	%0307	i02	\$
006504	001138	004386	0750	0593	0125	0250	0406	0875	0000	%0308	i03	\$
005798	001023	003383	0625	0500	0125	0375	0500	0875	0000	%0309	i04	\$
004997	000897	002392	0500	0406	0125	0500	0593	0875	0000	%0310	i05	\$
004334	000806	001526	0375	0312	0125	0625	0687	0875	0000	%0311	i06	\$
003773	000558	000731	0250	0218	0125	0750	0781	0875	0000	%0312	i07	\$
003138	000240	000068	0125	0125	0125	0875	0875	0875	0000	%0313	i08	\$
003070	-00541	-00680	0000	0031	0125	1000	0968	0875	0000	%0314	i09	\$
007709	001698	007698	1000	0750	0000	0000	0250	1000	0000	%0315	j01	\$
006974	001698	006975	0875	0566	0000	0125	0343	1000	0000	%0316	j02	\$
006047	001813	005984	0750	0562	0000	0250	0437	1000	0000	%0317	j03	\$
005497	001428	004497	0625	0468	0000	0375	0531	1000	0000	%0318	j04	\$
004897	001124	003208	0500	0375	0000	0500	0625	1000	0000	%0319	j05	\$
004175	000973	002228	0375	0281	0000	0625	0718	1000	0000	%0320	j06	\$
003607	000839	001219	0250	0187	0000	0750	0812	1000	0000	%0321	j07	\$
003106	000356	000586	0125	0093	0000	0875	0906	1000	0000	%0322	j08	\$
002654	000042	-00196	0000	0000	0000	1000	1000	1000	0000	%0323	j09	\$
009705	-00071	000191	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
008995	000142	-00592	0808	0875	1000	0031	0125	0000	0000	%0568	b11	\$
008058	000476	-01272	0937	0750	1000	0062	0250	0000	0000	%0569	b12	\$
007004	000950	-01927	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$
005875	001326	-02660	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
004863	001870	-03194	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
003909	002544	-03571	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
003433	000872	-03857	0781	0250	1000	0281	0875	0000	0000	%0574	b17	\$
003042	003065	-03872	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
002918	-00916	000790	0906	1000	0875	0093	0000	0125	0000	%0576	c01	\$
008679	000078	000210	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$
007642	000427	-00691	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
006988	000761	-01396	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
006014	001262	-02143	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
005952	001979	-02858	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
004183	002471	-03410	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$
003533	002841	-03611	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
002990	003027	-03627	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
008870	-01392	001461	0812	1000	0750	0187	0000	0250	0000	%0585	d01	\$
008239	-00608	000739	0781	0875	0750	0218	0125	0250	0000	%058		

See original or copy: <http://web.me.com/klaus.richter/HE11/HE11L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG HE01_22.TXT, Separation cmy0*, D50, not adapted S
%100 x LAB*      %#1000 x (r g b c m y 0)      %nr.   pos $
%z004575 006397 002883 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008962 -00423 007864 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z005447 -06180 002028 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005508 -04693 -02434 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z004420 -01873 -05079 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z003254 004497 -02650 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z002641 000044 -00186 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009705 -00070 000193 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%z004575 006397 002883 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008962 -00423 007864 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z005447 -06180 002028 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005508 -04693 -02434 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z004420 -01873 -05079 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z003254 004497 -02650 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z002641 000044 -00186 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009705 -00070 000193 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%z004575 006397 002883 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008962 -00423 007864 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z005447 -06180 002028 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005508 -04693 -02434 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z004420 -01873 -05079 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z003254 004497 -02650 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z002641 000044 -00186 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009705 -00070 000193 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%z005111 006616 005363 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z008831 -01776 008606 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005531 -05640 000474 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z005275 -04539 -03465 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003449 -00105 -04939 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z003994 005814 -01674 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z002611 000054 -00177 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009698 -00071 000215 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%z006567 003802 006589 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z006910 -03950 005430 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005600 -05270 -00448 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z005204 -04002 -04482 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z003220 001375 -04500 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004663 007034 -00436 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z002655 000036 -00188 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009710 -00071 000196 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%z007709 001698 007698 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z005719 -05821 003618 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005613 -04916 -01511 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z005097 -03258 -05032 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z003042 003066 -03672 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004622 006618 001467 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z002600 000045 -00188 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009707 -00073 000203 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/HE11/HE11L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG HE01 22.TXT, Separation cmy0*, D50, not adapted S																			
%100 x LAB*																			
1000 x (r g b c m y θ)																			
%nr. pos \$																			
002455	000049	-00141	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$							
002902	000223	000084	0125	0125	0125	0875	0875	0875	0000	%0993	k02	\$						%1053	m23 \$
003639	000414	000142	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$						%1054	m24 \$
004380	000301	000258	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$						%1055	m25 \$
005478	000241	000368	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$						%1056	n10 \$
006521	000296	000275	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$						%1057	n11 \$
007560	000297	000318	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$						%1058	n12 \$
008646	000098	000238	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$						%1059	n13 \$
009721	000071	000174	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$						%1060	n14 \$
002413	000050	00153	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$						%1061	n15 \$
002820	000222	000067	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$						%1062	n16 \$
003622	000427	000089	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$						%1063	n17 \$
004397	000303	000212	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$						%1064	n18 \$
005412	000264	000325	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$						%1065	n19 \$
006527	000302	000230	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$						%1066	n20 \$
007573	000299	000279	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$						%1067	n21 \$
008666	000103	000224	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$						%1068	n22 \$
009723	-00073	000189	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$						%1069	n23 \$
002398	000061	-00151	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$						%1070	n24 \$
002806	000235	000075	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$						%1071	n25 \$
003606	000449	000098	0250	0250	0250	0750	0750	0750	0000	%0992	m03	\$						%1072	k26 \$
004413	000315	000222	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$						%1073	k27 \$
005421	000274	000330	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$						%1074	l26 \$
006485	000328	000234	0625	0625	0625	0375	0375	0375	0000	%0995	m06	\$						%1075	l27 \$
007553	000305	000295	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$						%1076	m26 \$
008653	000119	000225	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$						%1077	m27 \$
009716	-00072	000181	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$						%1078	n26 \$
002395	000042	-00134	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$						%1079	n27 \$
002829	000220	000078	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$						%1074	l26 %03 0 \$
003632	000395	000116	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$						%1076	m26 %Y3 1 \$
004421	000302	000213	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$						%1078	n26 %L3 2 \$
005432	000261	000350	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$						%1075	l27 %C3 3 \$
006484	000290	000260	0625	0625	0625	0375	0375	0375	0000	%1004	n06	\$						%1077	m27 %V3 4 \$
007541	000383	000305	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$						%1079	n27 %M3 5 \$
008669	000096	000242	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$						%1072	k26 %M3 6 \$
009719	-00069	000185	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$						%1073	k27 %W3 7 \$
002621	000032	-00203	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$						%0972	k01 %N4 6 \$
002967	000141	-00081	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$						%0980	k09 %W4 7 \$
003237	000218	000049	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$						%0981	l01 %N5 6 \$
003575	000315	000075	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$						%0989	l09 %W5 7 \$
003976	000446	000115	0266	0266	0266	0733	0733	0733	0000	%1012	k14	\$						%0990	m01 %N6 6 \$
004385	000390	000179	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$						%0998	m09 %W6 7 \$
004759	000342	000276	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$						%0999	n01 %N7 6 \$
005355	000368	000336	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$						%1007	n09 %W7 7 \$
005853	000307	000309	0533	0533	0533	0466	0466	0466	0000	%1016	k18	\$							
006386	000328	000269	0600	0600	0600	0399	0399	0399	0000	%1017	k19	\$							
006883	000297	000348	0666	0666	0666	0333	0333	0333	0000	%1018	k20	\$							
007366	000327	000363	0733	0733	0733	0266	0266	0266	0000	%1019	k21	\$							
007880	000222	000328	0800	0800	0800	0199	0199	0199	0000	%1020	k22	\$							
008408	000062	000353	0866	0866	0866	0133	0133	0133	0000	%1021	k23	\$							
009028	-00038	000184	0933	0933	0933	0066	0066	0066	0000	%1022	k24	\$							
009716	-00056	000177	1000	1000	1000	0000	0000	0000	0000	%1023	k25	\$							
002658	000039	-00173	0000	0000	0000	1000	1000	1000	0000	%1024	l10	\$							
002979	000147	-00073	0066	0066	0066	0933	0933	0933	0000	%1025	l11	\$							
003200	000228	000041	0133	0133	0133	0866	0866	0866	0000	%1026	l12	\$							
003589	000318	000072	0200	0200	0200	0800	0800	0800	0000	%1027	l13	\$							
003917	000477	000105	0266	0266	0266	0733	0733	0733	0000	%1028	l14	\$							
004369	000413	000169	0333	0333	0333	0666	0666	0666	0000	%1029	l15	\$							
004744	000357	000265	0400	0400	0400	0600	0600	0600	0000	%1030	l16	\$							
005351	000366	000291	0466	0466	0466	0533	0533	0533	0000	%1031	l17	\$							
005836	000319	000261	0533	0533	0533	0466	0466	0466	0000	%1032	l18	\$							
006344	000342	000216	0600	0600	0600	0399	0399	0399	0000	%1033	l19	\$							
006821	000315	000300	0666	0666	0666	0333	0333	0333	0000	%1034	l20	\$							
007358	000364	000305	0733	0733	0733	0266	0266	0266	0000	%1035	l21	\$							
007876	000230	000301	0800	0800	0800	0199	0199	0199	0000	%1036	l22	\$							
008447	000049	000320	0866	0866	0866	0133	0133	0133	0000	%1037	l23	\$							
009040	-00040	000182	0933	0933	0933	0066	0066	0066	0000	%1038	l24	\$							
009717	-00064	000182	1000	1000	1000	0000	0000	0000	0000	%1039	l25	\$							
002617	000045	-00171	0000	0000	0000	1000	1000	1000	0000	%1040	m10	\$							
002928	000167	-00071	0066	0066	0066	0933	0933	0933	0000	%1041	m11	\$							
003162	000239	000043	0133	0133	0133	0866	0866	0866	0000	%1042	m12	\$							
003571	000347	000081	0200	0200	0200	0800	0800	0800	0000	%1043	m13	\$							
003900	000496	000100	0266	0266	0266	0733	0733	0733	0000	%1044	m14	\$							

%BEG HE01.22.TXT, Separation cmy0*, D50, adapted S																			
%100 x LAB*a																			
1000 x (r g b c m y o)																			
nmr. pos \$																			
009706	000002	-00008	1000	1000	1000	0000	0000	0000	0000	009706	000002	-00008	1000	1000	1000	0000	0000	0000	0000
009905	-00519	-00899	0875	0875	1000	0125	0000	0000	0000	009905	-00519	-00899	0875	0875	1000	0125	0000	0000	0000
008495	-00943	-01498	0750	0750	1000	0250	0250	0000	0000	008495	-00943	-01498	0750	0750	1000	0250	0250	0000	0000
007501	-01197	-02462	0625	0625	1000	0375	0375	0000	0000	007501	-01197	-02462	0625	0625	1000	0375	0375	0000	0000
006664	-01267	-03170	0500	0500	1000	0500	0500	0000	0000	006664	-01267	-03170	0500	0500	1000	0500	0500	0000	0000
005932	-01397	-03808	0375	0375	1000	0625	0625	0000	0000	005932	-01397	-03808	0375	0375	1000	0625	0625	0000	0000
005140	-01608	-04392	0250	0250	1000	0750	0750	0000	0000	005140	-01608	-04392	0250	0250	1000	0750	0750	0000	0000
004712	-01769	-04761	0125	0125	1000	0875	0875	0000	0000	004712	-01769	-04761	0125	0125	1000	0875	0875	0000	0000
004420	-01898	-04893	0000	0000	1000	1000	1000	0000	0000	004420	-01898	-04893	0000	0000	1000	1000	1000	0000	0000
003630	-02121	-05162	0000	0000	1000	0125	0125	0000	0000	003630	-02121	-05162	0000	0000	1000	0125	0125	0000	0000
002850	-02421	-05687	0875	0875	1000	0125	0125	0000	0000	002850	-02421	-05687	0875	0875	1000	0125	0125	0000	0000
002074	-02721	-06212	0750	0750	1000	0250	0250	0000	0000	002074	-02721	-06212	0750	0750	1000	0250	0250	0000	0000
001304	-03012	-06737	0625	0625	1000	0375	0375	0000	0000	001304	-03012	-06737	0625	0625	1000	0375	0375	0000	0000
000518	-03302	-07262	0500	0500	1000	0500	0500	0000	0000	000518	-03302	-07262	0500	0500	1000	0500	0500	0000	0000
000000	-03592	-07792	0375	0375	1000	0625	0625	0000	0000	000000	-03592	-07792	0375	0375	1000	0625	0625	0000	0000
000000	-03882	-08282	0250	0250	1000	0750	0750	0000	0000	000000	-03882	-08282	0250	0250	1000	0750	0750	0000	0000
000000	-04172	-08782	0125	0125	1000	0875	0875	0000	0000	000000	-04172	-08782	0125	0125	1000	0875	0875	0000	0000
000000	-04462	-09282	0000	0000	1000	1000	1000	0000	0000	000000	-04462	-09282	0000	0000	1000	1000	1000	0000	0000
000000	-04752	-09782	0875	0875	1000	0125	0125	0000	0000	000000	-04752	-09782	0875	0875	1000	0125	0125	0000	0000
000000	-05042	-10282	0750	0750	1000	0250	0250	0000	0000	000000	-05042	-10282	0750	0750	1000	0250	0250	0000	0000
000000	-05332	-10782	0625	0625	1000	0375	0375	0000	0000	000000	-05332	-10782	0625	0625	1000	0375	0375	0000	0000
000000	-05622	-11282	0500	0500	1000	0500	0500	0000	0000	000000	-05622	-11282	0500	0500	1000	0500	0500	0000	0000
000000	-05912	-11782	0375	0375	1000	0625	0625	0000	0000	000000	-05912	-11782	0375	0375	1000	0625	0625	0000	0000
000000	-06202	-12282	0250	0250	1000	0750	0750	0000	0000	000000	-06202	-12282	0250	0250	1000	0750	0750	0000	0000
000000	-06492	-12782	0125	0125	1000	0875	0875	0000	0000	000000	-06492	-12782	0125	0125	1000	0875	0875	0000	0000
000000	-06782	-13282	0000	0000	1000	1000	1000	0000	0000	000000	-06782	-13282	0000	0000	1000	1000	1000	0000	0000
000000	-07072	-13782	0875	0875	1000	0125	0125	0000	0000	000000	-07072	-13782	0875	0875	1000	0125	0125	0000	0000
000000	-07362	-14282	0750	0750	1000	0250	0250	0000	0000	000000	-07362	-14282	0750	0750	1000	0250	0250	0000	0000
000000	-07652	-14782	0625	0625	1000	0375	0375	0000	0000	000000	-07652	-14782	0625	0625	1000	0375	0375	0000	0000
000000	-07942	-15282	0500	0500	1000	0500	0500	0000	0000	000000	-07942	-15282	0500	0500	1000	0500	0500	0000	0000
000000	-08232	-15782	0375	0375	1000	0625	0625	0000	0000	000000	-08232	-15782	0375	0375	1000	0625	0625	0000	0000
000000	-08522	-16282	0250	0250	1000	0750	0750	0000	0000	000000	-08522	-16282	0250	0250	1000	0750	0750	0000	0000
000000	-08812	-16782	0125	0125	1000	0875	0875	0000	0000	000000	-08812	-16782	0125	0125	1000	0875	0875	0000	0000
000000	-09102	-17282	0000	0000	1000	1000	1000	0000	0000	000000	-09102	-17282	0000	0000	1000	1000	1000	0000	0000
000000	-09392	-17782	0875	0875	1000	0125	0125	0000	0000	000000	-09392	-17782	0875	0875	1000	0125	0125	0000	0000
000000	-09682	-18282	0750	0750	1000	0250	0250	0000	0000	000000	-09682	-18282	0750	0750	1000	0250	0250	0000	0000
000000	-09972	-18782	0625	0625	1000	0375	0375	0000	0000	000000	-09972	-18782	0625	0625	1000	0375	0375	0000	0000
000000	-10262	-19282	0500	0500	1000	0500	0500	0000	0000	000000	-10262	-19282	0500	0500	1000	0500	0500	0000	0000
000000	-10552	-19782	0375	0375	1000	0625	0625	0000	0000	000000	-10552	-19782	0375	0375	1000	0625	0625	0000	0000
000000	-10842	-20282	0250	0250	1000	0750	0750	0000	0000	000000	-10842	-20282	0250	0250	1000	0750	0750	0000	0000
000000	-11132	-20782	0125	0125	1000	0875	0875	0000	0000	000000	-11132	-20782	0125	0125	1000	0875	0875	0000	0000
000000	-11422	-21282	0000	0000	1000	1000	1000	0000	0000	000000	-11422	-21282	0000	0000	1000	1000	1000	0000	0000
000000	-11712	-21782	0875	0875	1000	0125	0125	0000	0000	000000	-11712	-21782	0875	0875	1000	0125	0125	0000	0000
000000	-12002	-22282	0750	0750	1000	0250	0250	0000	0000	000000	-12002	-22282	0750	0750	1000	0250	0250	0000	0000
000000	-12292	-22782	0625	0625	1000	0375	0375	0000	0000	000000	-12292	-22782	0625	0625	1000	0375	0375	0000	0000
000000	-12582	-23282	0500	0500	1000	0500	0500	0000	0000	000000	-12582	-23282	0500	0500	1000	0500	0500	0000	0000
000000	-12872	-23782	0375	0375	1000	0625	0625	0000	0000	000000	-12872	-23782	0375	0375	1000	0625	0625	0000	0000
000000	-13162	-24282	0250	0250	1000	0750	0750	0000	0000	000000	-13162	-24282	0250	0250	1000	0750	0750	0000	0000
000000	-13452	-24782	0125	0125	1000	0875	0875	0000	0000	000000	-13452	-24782	0125	0125	1000	0875	0875	0000	0000
000000	-13742	-25282	0000	0000	1000	1000	1000	0000	0000	000000	-13742	-25282	0000	0000	1000	1000	1000	0000	0000
000000	-14032	-25782	0875	0875	1000	0125	0125	0000	0000	000000	-14032	-25782	0875	0875	1000	0125	0125	0000	0000
000000	-14322	-26282	0750	0750	1000	0250	0250	0000	0000	000000	-14322	-26282	0750	0750	1000	0250	0250	0000	0000
000000	-14612	-26782	0625	0625	1000	0375	0375	0000	0000	000000	-14612	-26782	0625	0625	1000	0375	0375	0000	0000
000000	-14902	-27282	0500	0500	1000	0500	0500	0000	0000	000000	-14902	-27282	0500	0500	1000	0500	0500	0000	0000
000000	-15192	-27782	0375	0375	1000	0625	0625	0000	0000	000000	-15192	-27782	0375	0375	1000	0625	0625	0000	0000
000000	-15482	-28282	0250	0250	1000	0750	0750	0000	0000	000000	-15482	-28282	0250	0250	1000	0750	0750	0000	0000
000000	-15772	-28782	0125	0125	1000	0875	0875	0000	0000	000000	-15772	-28782	0125	0125	1000	0875	0875	0000	0000
000000	-16062	-29282	0000	0000	1000	1000	1000	0000	0000	000000	-16062	-29282	0000	0000	1000	1000	1000	0000	0000
000000	-16352	-29782	0875	0875	1000	0125	0125	0000	0000	000000	-16352	-29782	0875	0875	1000	0125	0125	0000	0000
000000	-16642	-30282	0750	0750	1000	0250	0250	0000	0000	000000	-16642	-30282	0750	0750	100				

See original or copy: <http://web.me.com/klaus.richter/HE11/HE11L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfi=1.00; nt=

TUB registration: 20091101-HE11/HE11L0NA.TXT/.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

[illegible]

TUB-test chart HE11; Relative Elementary Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

009714	000006	-00010	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
009914	-00745	-00927	0875	0937	1000	0125	0662	0000	0000	%0163	S02	\$
008542	-01125	-01446	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
007945	-01597	-02216	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
007379	-01977	-02825	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
006917	-02331	-03275	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
006305	-02691	-03833	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
005647	-03408	-04249	0125	0562	1000	0875	0250	0000	0000	%0169	S08	\$
005204	-03909	-04433	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
009346	000192	001141	1000	0937	0875	0000	0662	0125	0000	%0171	T01	\$
008482	000121	000139	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
008951	-00609	-00773	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
007540	-01873	-01406	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
007022	-01810	-02035	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
006542	-02187	-02552	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
005933	-02514	-03010	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
005484	-03200	-03339	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
005195	-04282	-04031	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
009046	000336	002222	1000	0875	0750	0000	0125	0250	0000	%0180	T10	\$
008071	000527	001168	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
007474	000298	000298	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
006974	-00397	-00617	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
006584	-01117	-01264	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
006095	-01704	-01807	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
005548	-02067	-02400	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
005180	-02622	-02767	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
004995	-03913	-03357	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
008570	000873	002876	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
007833	000736	002185	0875	0750	0625	0125	0250	0375	0000	%0190	V02	\$
007104	000590	001095	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
006464	000314	000263	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
006010	-00292	-00387	0500	0427	0625	0500	0437	0375	0000	%0193	V05	\$
005651	-01101	-01139	0375	0500	0625	0625	0500	0375	0000	%0194	V06	\$
005198	-01662	-01718	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
004877	-02190	-02280	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
004649	-03142	-02710	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
008163	001333	003703	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
007437	001119	002706	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
006829	000900	001943	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
006198	000663	001177	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
005476	000257	000382	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
005082	-00286	-00415	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$
004611	-01256	-01186	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
004463	-01778	-01632	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
004226	-02519	-02065	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
007717	001960	004281	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
007035	001616	003215	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
006433	001298	002494	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
005761	001137	001715	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
005167	000644	001042	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
004588	000281	000292	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
004249	-00318	-00233	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
004017	-01402	-01068	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
003856	-01967	-01513	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
007304	002581	005025	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
006757	002075	003832	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
006120	001782	002958	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
005551	001512	002254	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
004925	001147	001476	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
004404	000787	000850	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
003842	000389	000229	0250	0250	0250	0250	0750	0750	0000	%0222	Y07	\$
003748	-05412	-03681	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
003380	-00174	-01015	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
006874	002865	006163	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
006256	002811	004871	0875	0500	0125	0125	0125	0800	0875	%0226	Z02	\$
005729	002352	003645	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
005243	001895	002844	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
004612	001679	002127	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
004079	001314	001316	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
003650	000829	000691	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
003143	000202	000223	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
003208	-00684	-00380	0000	0662	0125	1000	0937	0875	0000	%0233	Z09	\$
005657	003825	005564	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
005246	003809	005999	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
005599	003272	004880	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
004868	002595	003497	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
004418	002190	002540	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
003913	001738	001854	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
003428	001364	001100	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
003036	000622	000610	0125	0662	0000	0875	0937	1000	0000	%0241	A08	\$
002664	000005	000000	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009707	-00002	-000014	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
008831	-00096	-00899	0937	0875	1000	0662	0125	0000	0000	%0487	S11	\$
007975	000016	-01616	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
006908	000102	-02416	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
005745	000488	-03106	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
004688	000995	-03633	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
003949	001224	-04015	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
003521	001399	-04252	0562	0250	1000	0437	0875	0000	0000	%0493	S17	\$
003222	001348	-04342	0500	0000	1000	0500	1000	0000	0000	%0494	S18	\$
009335	-00739	000931	0937	1000	0875	0662	0000	0125	0000	%0495	T10	\$
008648	000132	000082	0875	0875	0875	0125	0125	0125	0000	%0496	T11	\$
007561	000231	-00961	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
006760	000359	-01715	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
005816	000476	-02582	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
005031	000776	-03257	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
004262	001067	-03844	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
003708	001228	-04105	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
003250	001219	-04323	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
009110	-01163	001943	0875	1000	0750	0125	0000	0250	0000	%0504	T10	\$
008362	-00376	000829	0812	0875	0750	0187	0125	0250	00			

See original or copy: <http://web.me.com/klaus.richter/HE11/HE11L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG HE01_22.TXT, Separation cmy0*, D50, adapted S
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr.   pos $
%z004575 006384 002966 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008962 -00365 007711 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z005447 -06178 002063 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005508 -04691 -02402 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z004420 -01888 -04988 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z003254 004463 -02496 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z002641 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009705 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%z004575 006384 002966 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008962 -00365 007711 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z005447 -06178 002063 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005508 -04691 -02402 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z004420 -01888 -04988 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z003254 004463 -02496 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z002641 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009705 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%z004575 006384 002966 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008962 -00365 007711 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z005447 -06178 002063 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005508 -04691 -02402 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z004420 -01888 -04988 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z003254 004463 -02496 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z002641 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009705 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%z005111 006606 005402 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z008831 -01729 008438 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005531 -05642 000489 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z005275 -04546 -03435 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003449 -00145 -04808 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z003994 005784 -01573 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z002611 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009698 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%z006567 003825 006564 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z006910 -03922 005386 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005600 -05262 -00420 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z005204 -03999 -04433 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z003220 001348 -04342 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004663 007028 -00358 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z002655 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009710 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%z007709 001737 007605 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z005719 -05814 003635 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005613 -04911 -01489 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z005097 -03262 -04982 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z003042 003027 -03508 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004622 006606 001544 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z002600 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009707 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/HE11/HE11L0NA.TXT> / PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

TUB registration: 20091101-HE11/HE11L0NA.TXT/.PS TUB material: code=rh4ta
application for evaluation and measurement of printer or monitor systems

BBEG H001.22.TXT, Separation cmY0*, D50, adapted \$					
%100 x LAB*a	1000 x (r g b	c m y 0)	%nrr.	pos \$	
002455 000014	000057	0000	0000	1000	1000 0000 %00972 k01 \$
002902 000193	000259	0125	0125	0125 0875	0875 0875 0000 %00973 k02 \$
003639 000394	000278	0250	0250	0250 0750	0750 0750 0000 %00974 k03 \$
004380 000290	000355	0375	0375	0375 0625	0625 0625 0000 %00975 k04 \$
005478 000244	000406	0500	0500	0500 0500	0500 0500 0000 %00976 k05 \$
006521 000313	000258	0625	0625	0625 0375	0375 0375 0000 %00977 k06 \$
007560 000327	000246	0750	0750	0750 0250	0250 0250 0000 %00978 k07 \$
008646 000141	000108	0875	0875	0875 0125	0125 0125 0000 %00979 k08 \$
009721 -00014	-00013	1000	1000	1000 0000	0000 0000 0000 %00980 k09 \$
002413 000015	000047	0000	0000	1000	1000 0000 %00981 l01 \$
002820 000192	000247	0125	0125	0125 0875	0875 0875 0000 %00982 l02 \$
003622 000407	000226	0250	0250	0250 0750	0750 0750 0000 %00983 l03 \$
004397 000292	000308	0375	0375	0375 0625	0625 0625 0000 %00984 l04 \$
005412 000266	000368	0500	0500	0500 0500	0500 0500 0000 %00985 l05 \$
006527 000319	000212	0625	0625	0625 0375	0375 0375 0000 %00986 l06 \$
007573 000329	000205	0750	0750	0750 0250	0250 0250 0000 %00987 l07 \$
008666 000146	000092	0875	0875	0875 0125	0125 0125 0000 %00988 l08 \$
009723 000106	000001	1000	1000	1000 0000	0000 0000 0000 %00989 l09 \$
000925 000205	000105	0000	0000	1000	1000 0000 %00990 m01 \$
002806 000305	000205	0125	0125	0125 0875	0875 0875 0000 %00991 m02 \$
003606 000429	000236	0250	0250	0250 0750	0750 0750 0000 %00992 m03 \$
004413 000305	000317	0375	0375	0375 0625	0625 0625 0000 %00993 m04 \$
005421 000277	000371	0500	0500	0500 0500	0500 0500 0000 %00994 m05 \$
006485 000344	000219	0625	0625	0625 0375	0375 0375 0000 %00995 m06 \$
007553 000335	000223	0750	0750	0750 0250	0250 0250 0000 %00996 m07 \$
008653 000163	000094	0875	0875	0875 0125	0125 0125 0000 %00997 m08 \$
009716 -00015	-00006	1000	1000	1000 0000	0000 0000 0000 %00998 m09 \$
002395 000006	000067	0000	0000	1000	1000 0000 %00999 n01 \$
002829 000190	000257	0125	0125	0125 0875	0875 0875 0000 %00999 n02 \$
003632 000375	000252	0250	0250	0250 0750	0750 0750 0000 %00999 n03 \$
004421 000292	000307	0375	0375	0375 0625	0625 0625 0000 %00999 n04 \$
005432 000264	000390	0500	0500	0500 0500	0500 0500 0000 %00999 n05 \$
006549 000306	000241	0625	0625	0625 0375	0375 0375 0000 %00999 n06 \$
007541 000332	000233	0750	0750	0750 0250	0250 0250 0000 %00999 n07 \$
008669 000139	000110	0875	0875	0875 0125	0125 0125 0000 %00999 n08 \$
009719 -00012	-00002	1000	1000	1000 0000	0000 0000 0000 %00999 n09 \$
002621 000000	-00012	0000	0000	1000	1000 0000 %00999 k10 \$
002967 000113	000000	0066	0066	0066 0933	0933 0933 0000 %00999 k11 \$
003237 000099	000206	0133	0133	0133 0866	0866 0866 0000 %00999 k12 \$
003575 000294	000214	0200	0200	0200 0800	0800 0800 0000 %00999 k13 \$
003976 000430	000233	0266	0266	0266 0733	0733 0733 0000 %00999 k14 \$
004385 000379	000275	0333	0333	0333 0666	0666 0666 0000 %00999 k15 \$
004759 000336	000352	0400	0400	0400 0600	0600 0600 0000 %00999 k16 \$
005092 000336</					

TUB-test chart HE11; Relative Elementary Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```