

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-HE16/HE16LONA.TXT / .PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/HE16/HE16L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.01; nx=1.33

X86E HE06 22.TXT, Separation (r, g, b) D65, not adapted \$											
Wavelength	LAB	1000	1000	1000	1000	1000	1000	1000	1000	nmr	pos \$
009701	001000	000200	0000	1000	0000	0000	0000	0000	0000	00000	A01 \$
009004	007083	002414	0875	1000	0000	0125	0000	0000	0000	00001	A02 \$
008644	011109	008909	0750	1000	1000	0250	0000	0000	0000	00002	A03 \$
008069	016466	012221	0625	1000	1000	0375	0000	0000	0000	00003	A04 \$
007495	020663	016300	0500	1000	1000	0500	0000	0000	0000	00004	A05 \$
007015	025212	018664	0375	1000	1000	0625	0000	0000	0000	00005	A06 \$
006429	032553	018772	0250	1000	1000	0750	0000	0000	0000	00006	A07 \$
005979	038279	019777	0125	1000	1000	0875	0000	0000	0000	00007	A08 \$
005687	043237	020771	0000	1000	1000	1000	0000	0000	0000	00008	A09 \$
009164	006040	006209	1000	0875	0875	0000	0125	0125	0000	00009	B01 \$
009228	000804	000218	0875	0875	0875	0125	0125	0125	0000	00010	B02 \$
008859	010105	005153	0750	0875	0875	0250	0125	0125	0000	00011	B03 \$
008326	015100	000897	0625	0875	0875	0375	0125	0125	0000	00012	B04 \$
007607	020909	013801	0500	0875	0875	0500	0125	0125	0000	00013	B05 \$
007101	024808	017000	0375	0875	0875	0625	0125	0125	0000	00014	B06 \$
006560	031878	016563	0250	0875	0875	0750	0125	0125	0000	00015	B07 \$
006042	038442	012823	0125	0875	0875	0875	0125	0125	0000	00016	B08 \$
005536	04570	020663	0000	0875	0875	1000	0125	0125	0000	00017	B09 \$
008550	001122	000954	1000	0750	0750	0000	0250	0250	0000	00018	C01 \$
008390	000662	000720	0875	0750	0750	0125	0250	0250	0000	00019	C02 \$
008398	000506	000179	0750	0750	0750	0250	0250	0250	0000	00020	C03 \$
008143	010208	000470	0625	0750	0750	0375	0250	0250	0000	00021	C04 \$
007593	017123	009222	0500	0750	0750	0500	0250	0250	0000	00022	C05 \$
007105	020500	010502	0400	0750	0750	0625	0250	0250	0000	00023	C06 \$
006413	028182	010182	0250	0750	0750	0750	0250	0250	0000	00024	C07 \$
005977	036265	017775	0125	0750	0750	0875	0250	0250	0000	00025	C08 \$
005415	046808	021777	0000	0750	0750	1000	0250	0250	0000	00026	C09 \$
007906	001856	001333	1000	0625	0625	0000	0375	0375	0000	00027	D01 \$
007875	001288	001708	0875	0625	0625	0125	0375	0375	0000	00028	D02 \$
007703	008075	000517	0750	0625	0625	0250	0375	0375	0000	00029	D03 \$
007645	000408	000137	0625	0625	0625	0375	0375	0375	0000	00030	D04 \$
007211	000972	006405	0500	0625	0625	0500	0375	0375	0000	00031	D05 \$
006648	017336	011886	0375	0625	0625	0625	0375	0375	0000	00032	D06 \$
005962	021600	017774	0250	0625							

009700	-009974	000186	1000	1000	1000	0000	0000	0000	0000	%0324	A10	9
009045	-000527	-006582	0875	0875	1000	0125	0125	0000	0000	%0325	A11	9
008556	-008662	-012772	0750	0750	1000	0250	0250	0000	0000	%0326	A12	9
007605	-009935	-022119	0625	0625	1000	0375	0375	0000	0000	%0327	A13	9
006787	-009311	-029508	0500	0500	1000	0500	0500	0000	0000	%0328	A14	9
005973	-009290	-036002	0375	0375	1000	0625	0625	0000	0000	%0329	A15	9
005296	-009887	-042082	0250	0250	1000	0750	0750	0000	0000	%0330	A16	9
004865	-010090	-045883	0125	0125	1000	0875	0875	0000	0000	%0331	A17	9
004579	-010509	-047908	0000	0000	1000	1000	1000	0000	0000	%0332	A18	9
009640	-007166	-008178	1000	1000	0875	0000	0000	0125	0000	%0333	B10	9
009361	-000806	000211	0875	0875	0875	0125	0125	0125	0000	%0334	B11	9
008630	-004943	-008008	0750	0750	0875	0250	0250	0125	0000	%0335	B12	9
007922	-006468	-018008	0625	0625	0875	0375	0375	0125	0000	%0336	B13	9
007044	-007899	-026463	0500	0500	0875	0500	0500	0125	0000	%0337	B14	9
006263	-009924	-034349	0375	0375	0875	0625	0625	0125	0000	%0338	B15	9
005466	-010503	-040363	0250	0250	0875	0750	0750	0125	0000	%0339	B16	9
004907	-010899	-045005	0125	0125	0875	0875	0875	0125	0000	%0340	B17	9
004489	-009389	-047908	0000	0000	0875	1000	1000	0125	0000	%0341	B18	9
009471	-008889	003624	1000	1000	0750	0000	0000	0250	0000	%0342	C10	9
009237	-004995	0001862	0875	0875	0750	0125	0125	0250	0000	%0343	C11	9
008527	-009060	000189	0750	0750	0750	0250	0250	0250	0000	%0344	C12	9
007778	-004311	-016132	0625	0625	0750	0375	0375	0250	0000	%0345	C13	9
006883	-004486	-018105	0500	0500	0750	0500	0500	0250	0000	%0346	C14	9
006074	-007173	-021803	0375	0375	0750	0625	0625	0250	0000	%0347	C15	9
005328	-008744	-032222	0250	0250	0750	0750	0750	0250	0000	%0348	C16	9
004777	-009667	-038552	0125	0125	0750	0875	0875	0250	0000	%0349	C17	9
004317	-007838	-048306	0000	0000	0750	1000	1000	0250	0000	%0350	C18	9
009321	-009119	003840	1000	1000	0625	0000	0000	0375	0000	%0351	D10	9
009157	-006882	003054	0875	0875	0625	0125	0125	0375	0000	%0352	D11	9
008555	-003991	001534	0750	0750	0625	0250	0250	0375	0000	%0353	D12	9
007731	-000404	0001622	0625	0625	0625	0375	0375	0375	0000	%0354	D13	9
006862	-003032	-012090	0500	0500	0625	0500	0500	0375	0000	%0355	D14	9
005870	-004488	-021608	0375	0375	0625	0625	0625	0375	0000	%0356	D15	9
005139	-007299	-028117	0250	0250	0625	07						

009680	-00095	000188	1000	1000	1000	0000	0000	0000	0000	00648	A19	5
008964	000327	-00491	1000	0875	1000	0000	0125	0000	0000	00649	A20	5
008170	001000	-01005	1000	0750	1000	0000	0250	0000	0000	00650	A21	5
007362	001790	-01360	1000	0625	1000	0000	0375	0000	0000	00651	A22	5
006319	002565	-01895	1000	0500	1000	0000	0500	0000	0000	00652	A23	5
005226	003187	-02516	1000	0375	1000	0000	0625	0000	0000	00653	A24	5
004192	004014	-02902	1000	0250	1000	0000	0750	0000	0000	00654	A25	5
003624	004440	-02999	1000	0125	1000	0000	0875	0000	0000	00655	A26	5
003235	004636	-02787	1000	0000	1000	0000	1000	0000	0000	00656	A27	5
009117	-010623	000483	0875	1000	0875	0125	0000	0125	0000	00657	B19	5
009311	-000801	000201	0875	0875	0875	0125	0125	0125	0000	00658	B20	5
008457	000459	-00849	0875	0750	0875	0125	0250	0125	0000	00659	B21	5
007687	001137	-01363	0875	0625	0875	0125	0375	0125	0000	00660	B22	5
006681	002037	-01827	0875	0500	0875	0125	0500	0125	0000	00661	B23	5
005473	002880	-02488	0875	0375	0875	0125	0625	0125	0000	00662	B24	5
004391	003636	-02985	0875	0250	0875	0125	0750	0125	0000	00663	B25	5
003584	004457	-03079	0875	0125	0875	0125	0875	0125	0000	00664	B26	5
003088	004489	-02834	0875	0000	0875	0125	1000	0125	0000	00665	B27	5
008723	-01577	000723	0750	1000	0750	0250	0000	0250	0000	00666	C19	5
008859	-01393	000628	0750	0875	0750	0250	0125	0250	0000	00667	C20	5
008442	-00051	000177	0750	0750	0750	0250	0250	0250	0000	00668	C21	5
007439	000623	-00940	0750	0625	0750	0250	0375	0250	0000	00669	C22	5
006518	001360	-01486	0750	0500	0750	0250	0500	0250	0000	00670	C23	5
005593	002174	-02061	0750	0375	0750	0250	0625	0250	0000	00671	C24	5
004548	002956	-02613	0750	0250	0750	0250	0750	0250	0000	00672	C25	5
003588	004145	-03009	0750	0125	0750	0250	0875	0250	0000	00673	C26	5
002775	004137	-02750	0750	0000	0750	0250	1000	0250	0000	00674	C27	5
008130	-02377	001182	0625	1000	0625	0375	0000	0375	0000	00675	D19	5
008397	-02063	001176	0625	0875	0625	0375	0125	0375	0000	00676	D20	5
008053	-01338	000477	0625	0750	0625	0375	0250	0375	0000	00677	D21	5
007643	-00041	000144	0625	0625	0625	0375	0375	0375	0000	00678	D22	5
006478	000635	-01108	0625	0500	0625	0375	0500	0375	0000	00679	D23	5
005388	001570	-01623	0625	0375	0625	0375	0625	0375	0000	00680	D24	5
004355	002321	-02163	0625	0250	0625	037						

TUB-test chart HE16; Relative Elementary Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

input: w *setgray*
output: no change compared to input

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009709	-00102	000217	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009903	-00754	-00555	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008615	-01039	-01091	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
008065	-01460	-01585	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
007511	-01715	-02279	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
006946	-02173	-02661	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006283	-02752	-03016	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
005753	-03208	-03308	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005481	-03308	-03084	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
009199	000153	001229	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
009221	-00075	000194	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
008872	-00861	-00834	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
008282	-01321	-01472	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
007602	-01795	-02005	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
007079	-02065	-02603	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
006480	-02656	-02769	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
005888	-03256	-03126	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
005368	-04049	-03128	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
008699	000606	001801	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
008491	000420	001166	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
008443	-00057	0010181	0750	0750	0750	0250	0312	0250	0000	00101	L03	\$
008151	-00946	-00807	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
007642	-01616	-01388	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
006983	-02044	-02016	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
006381	-02452	-02483	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
005885	-03182	-02715	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
005343	-04185	-03048	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
008102	001156	002590	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
008017	000799	002122	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
007789	000147	001076	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
007631	-00052	000147	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
007244	-00018	-00043	0500	0593	0593	0625	0500	0406	0375	00112	M05	\$
006637	-01971	-01595	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
005943	-01921	-02340	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
005515	-02705	-02713	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
005276	-04251	-02948	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007408	002046	003066	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
007470	001483	002615	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
007224	000884	002019	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
006985	000584	000971	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
006715	-00040	-00080	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
006233	-00947	-01153	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
005528	-01615	-01822	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
005064	-02169	-02515	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
005039	-04046	-02748	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
006723	002992	003900	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
006811	002308	003307	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
006526	001613	002473	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
006291	001039	001924	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
006010	000565	001048	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
005603	-00026	000046	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
005044	-01094	-01405	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
004409	-01668	-02194	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
004602	-03101	-02897	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
006090	003966	004739	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
006184	003574	004032	0875	0406	0500	0125	0593	0750	0000	00136	P02	\$
005836	002587	003050	0750	0375	0250	0250	0625	0625	0000	00137	P03	\$
005601	001971	002496	0625	0343	0250	0500	0687	0750	0000	00138	P04	\$
005121	001383	001937	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
004791	000801	001058	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
004480	-00015	-00023	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
004068	-01155	-01653	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
003732	-02320	-02628	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
005517	005008	005176	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
005509	004907	005084	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
005075	003662	003796	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
004646	003088	003251	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
004175	002548	002717	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
003834	001857	002082	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
003476	001143	001376	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
002670	000016	000016	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
002984	-01859	-02180	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
004932	006174	005131	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
004669	006102	004918	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
004267	005754	004352	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
003363	005203	003725	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
003351	004360	003088	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
002936	003512	002429	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
002511	002561	001655	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
002105	001699	000812	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
001396	000053	000099	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009696	-00097	000195	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
008894	-00337	-00761	0800	0875	1000	0093	0125	0000	0000	00406	J11	\$
008357	-00444	-01315	0812	0750	1000	0818	0250	0000	0000	00407	J12	\$
007245	-00346	-02291	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
006315	-00070	-02956	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
005265	000313	-03638	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
004464	000586	-04153	0437	0250	1000	0562	0750	0000	0000	00411	J16	\$
003656	000649	-04572	0343	0250	1000	0875	0875	0000	0000	00412	J17	\$
003055	000668	-04764	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
009562	-00761	001618	0968	1000	0875	0031	0000	0125	0000	00414	K10	\$
009347	-00087	000214	0875	0875	0875	0125	0125	0125	0000	00415	K11	\$
008486	-00249	-00994	0781	0750	0875	0218	0250	0125	0000	00416	K12	\$
007641	-00142	-01882	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
006688	-00139	-02685	0503	0500	0875	0406	0500	0125	0000	00418	K14	\$
005633	-00025	-03503	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
004703	000220	-04104	0306	0250	0875	0593	0750	0125	0000	00420	K16	\$
004023	000374	-04604	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
003510	000508	-04718	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
009439	-01215	002958	0377	1000	0750	0062	0000	0250	0000	00423	L10	\$
009095	-0											

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009710	-00088	000189	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$
009028	-00739	-00725	0875	0937	1000	0125	0062	0000	0000	%0163	S02 \$
008595	-01033	-01194	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$
007994	-01386	-01988	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$
007468	-01633	-02570	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$
007618	-01908	-02992	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$
006395	-02135	-03804	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$
005775	-02767	-05952	0125	0500	1000	0875	0500	0000	0000	%0169	S08 \$
005360	-03238	-04081	0000	0500	1000	1000	0500	0000	0000	%0170	S09 \$
009305	-00040	001352	1000	0937	0875	0000	0062	0125	0000	%0171	T01 \$
009202	-00979	000208	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$
008800	-00834	-00899	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$
008188	-01214	-01728	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$
007606	-01620	-02334	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$
007041	-01919	-02780	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$
006410	-02210	-03372	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$
005698	-02692	-03693	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$
005295	-03299	-04072	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$
008981	000000	002408	1000	0875	0750	0000	0125	0250	0000	%0180	U01 \$
008706	000169	001329	0875	0812	0750	0125	0187	0250	0000	%0181	U02 \$
008398	-00055	000185	0750	0750	0750	0250	0250	0250	0000	%0182	U03 \$
008058	-00833	-00951	0625	0687	0750	0375	0312	0250	0000	%0183	U04 \$
007520	-01337	-01650	0500	0625	0750	0500	0375	0250	0000	%0184	U05 \$
006857	-01664	-02409	0375	0562	0750	0625	0437	0250	0000	%0185	U06 \$
006194	-01921	-02913	0250	0500	0750	0750	0500	0250	0000	%0186	U07 \$
005561	-02412	-03395	0125	0437	0750	0875	0562	0250	0000	%0187	U08 \$
005295	-03407	-03840	0000	0375	0750	1000	0625	0250	0000	%0188	U09 \$
008528	000417	003056	1000	0812	0625	0000	0187	0375	0000	%0189	V01 \$
008321	000291	002466	0875	0750	0625	0125	0250	0375	0000	%0190	V02 \$
008103	000076	001239	0750	0687	0625	0250	0312	0375	0000	%0191	V03 \$
007654	-00051	000136	0625	0625	0625	0375	0375	0375	0000	%0192	V04 \$
007141	-00772	-01085	0500	0512	0625	0500	0437	0375	0000	%0193	V05 \$
006513	-01387	-01906	0375	0500	0625	0625	0500	0375	0000	%0194	V06 \$
005787	-01594	-02668	0250	0437	0625	0750	0562	0375	0000	%0195	V07 \$
005283	-02034	-03026	0125	0375	0625	0875	0625	0375	0000	%0196	V08 \$
005059	-03225	-03756	0000	0312	0625	1000	0687	0375	0000	%0197	V09 \$
008110	000789	003847	1000	0750	0500	0000	0250	0500	0000	%0198	W01 \$
007961	000587	003135	0875	0687	0500	0125	0312	0500	0000	%0199	W02 \$
007683	000338	002463	0750	0625	0500	0250	0375	0500	0000	%0200	W03 \$
007259	000201	001072	0625	0562	0500	0375	0437	0500	0000	%0201	W04 \$
006700	-00043	-00082	0500	0500	0500	0500	0500	0500	0000	%0202	W05 \$
006111	-00754	-01372	0375	0437	0500	0625	0562	0500	0000	%0203	W06 \$
005386	-01388	-02084	0250	0375	0500	0750	0625	0500	0000	%0204	W07 \$
004872	-01690	-02850	0125	0312	0500	0875	0687	0500	0000	%0205	W08 \$
004575	-02623	-03659	0000	0250	0500	1000	0750	0500	0000	%0206	W09 \$
007654	001357	004388	1000	0687	0375	0000	0312	0625	0000	%0207	X01 \$
007534	001091	003761	0875	0625	0375	0125	0375	0625	0000	%0208	X02 \$
007151	000729	002980	0750	0562	0375	0250	0437	0625	0000	%0209	X03 \$
006754	000425	002315	0625	0500	0375	0375	0500	0625	0000	%0210	X04 \$
006256	000197	001287	0500	0437	0375	0500	0562	0625	0000	%0211	X05 \$
005609	-00027	000045	0375	0375	0375	0625	0625	0625	0000	%0212	X06 \$
005039	-00969	-01530	0250	0312	0375	0750	0687	0625	0000	%0213	X07 \$
004500	-01363	-02351	0125	0250	0375	0875	0750	0625	0000	%0214	X08 \$
004015	-02262	-03257	0000	0187	0375	1000	0812	0625	0000	%0215	X09 \$
007255	001877	005259	1000	0625	0250	0000	0375	0750	0000	%0216	Y01 \$
007111	001646	004449	0875	0562	0250	0125	0437	0750	0000	%0217	Y02 \$
006706	001208	003677	0750	0500	0250	0500	0500	0750	0000	%0218	Y03 \$
006212	000926	003076	0625	0437	0250	0375	0500	0750	0000	%0219	Y04 \$
005657	000577	002355	0500	0375	0250	0500	0625	0750	0000	%0220	Y05 \$
005186	000196	001371	0375	0312	0250	0625	0687	0750	0000	%0221	Y06 \$
004503	-00011	000023	0250	0500	0250	0750	0750	0750	0000	%0222	Y07 \$
003985	-01025	-01824	0125	0187	0250	0875	0812	0750	0000	%0223	Y08 \$
003532	-01777	-03056	0000	0125	0250	1000	0875	0750	0000	%0224	Y09 \$
006801	002547	006175	1000	0562	0125	0000	0437	0875	0000	%0225	Z01 \$
006641	002458	005896	0875	0500	0125	0125	0500	0875	0000	%0226	Z02 \$
006148	001857	004898	0750	0437	0125	0250	0562	0875	0000	%0227	Z03 \$
005653	001487	004211	0625	0375	0125	0375	0625	0875	0000	%0228	Z04 \$
005057	001158	003443	0500	0312	0125	0500	0687	0875	0000	%0229	Z05 \$
004466	000833	002706	0375	0250	0125	0625	0750	0875	0000	%0230	Z06 \$
003923	000454	001711	0250	0187	0125	0750	0812	0875	0000	%0231	Z07 \$
002730	000012	000031	0125	0125	0125	0875	0875	0875	0000	%0232	Z08 \$
002940	-01590	-02361	0000	0062	0125	1000	0937	0875	0000	%0233	Z09 \$
005059	003083	006645	1000	0500	0000	0000	0500	1000	0000	%0234	A01 \$
006344	002947	006472	0875	0437	0000	0125	0562	1000	0000	%0235	A02 \$
005822	002744	005861	0750	0375	0000	0250	0625	1000	0000	%0236	A03 \$
004967	002500	004852	0625	0312	0000	0375	0687	1000	0000	%0237	A04 \$
004014	002271	003740	0500	0250	0000	0500	0750	1000	0000	%0238	A05 \$
003454	001944	002959	0375	0187	0000	0625	0812	1000	0000	%0239	A06 \$
002783	001669	002002	0250	0125	0000	0750	0875	1000	0000	%0240	A07 \$
002232	001056	001145	0125	0062	0000	0875	0937	1000	0000	%0241	A08 \$
001314	000045	000100	0000	0000	0000	1000	1000	1000	0000	%0242	A09 \$
009703	-00104	000223	1000	1000	1000	0000	0000	0000	0000	%0486	S10 \$
008811	-00067	-00755	0937	0875	1000	0062	0125	0000	0000	%0487	S11 \$
008003	000091	-01466	0875	0750	1000	0125	0250	0000	0000	%0488	S12 \$
006898	000280	-02336	0812	0625	1000	0187	0375	0000	0000	%0489	S13 \$
005746	000777	-03084	0750	0500	1000	0250	0500	0000	0000	%0490	S14 \$
004683	001380	-03692	0687	0375	1000	0312	0625	0000	0000	%0491	S15 \$
003934	001748	-04087	0625	0250	1000	0375	0750	0000	0000	%0492	S16 \$
003188	001242	-04268	0562	0250	1000	0437	0875	0000	0000	%0493	S17 \$
002416	000844	-04397	0500	0250	1000	0500	1000	0000	0000	%0494	S18 \$
009350	-00977	001226	0937	1000	0875	0062	0100	0125	0000	%0495	T10 \$
009359	-00084	000207	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$
008442	-00081	-01035	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$
007355	000285	-01955	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$
006178	000656	-02786	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$
004919	001219	-03550	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$
004005	001727	-04050	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$
003424	002092	-04245	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$
003052	002108	-04440	0437	0000	0875	0562	1000	0125	0000	%0503	T18 \$
009129	-01504	002228	0875	1000	0750	0125	0000	0250	0000	%0504	T19 \$
008993	-00978	000124	0812	0875	0750	0187	0125	0250	0000	%0505	U11 \$
008526	-00063	000196	0750	0750	0750	0250	0250	0250	0000	%0506	U12 \$
007467	000130	-01143	0687	0625	0750	0312	0375	0250	0000	%0507	U13 \$
006339	000469	-02099	0625	0500	0750	0375	0500	0250	0000	%0508	U14 \$
005390	000759										

TUB registration: 20091101-HE16/HE16L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

TUB-test chart HE16; Relative Elementary Colour System O
1080 spectral reflexions R $\rightarrow$ LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/HE16/HE16L0NA.TXT> /PS
Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0, cfl=1.00; nt=0.01; nx=1.3

09699	09099	090271	10800	1000	1000	0000	0000	0000	0000	%2043	b01 \$
09921	-06049	-07712	0875	0906	1000	0125	0093	0000	0000	%2044	b02 \$
08050A	-09048	-01317	0750	0812	1000	0250	0187	0000	0000	%2045	b03 \$
07875	-01173	-02029	0625	0718	1000	0375	0281	0000	0000	%2046	b04 \$
07284	-01400	-02668	0500	0625	1000	0500	0375	0000	0000	%2047	b05 \$
06663	-01559	-03286	0375	0531	1000	0625	0468	0000	0000	%2048	b06 \$
06024	-01744	-03918	0250	0437	1000	0750	0562	0000	0000	%2049	b07 \$
05352	-01939	-04486	0125	0343	1000	0875	0656	0000	0000	%2050	b08 \$
05195	-02338	-04759	0000	0250	1000	1000	0750	0000	0000	%2051	b09 \$
099485	-06357	-081575	1000	0968	0875	0900	0031	0125	0000	%2052	c01 \$
099223	-08086	-080220	0875	0875	0875	0125	0125	0125	0000	%2053	c02 \$
08728	-08667	-08854	0750	0781	0875	0250	0128	0125	0000	%2054	c03 \$
090014	-08950	-01724	0625	0687	0875	0375	0312	0125	0000	%2055	c04 \$
07739	-01261	-02563	0500	0593	0875	0500	0406	0125	0000	%2056	c05 \$
07587	-01364	-02594	0406	0500	0875	0625	0437	0125	0000	%2057	c06 \$
09066	-01596	-03643	0250	0406	0875	0750	0593	0125	0000	%2058	c07 \$
05308	-01793	-04105	0125	0312	0875	0875	0687	0125	0000	%2059	c08 \$
05090	-02261	-04701	0000	0218	0875	1000	0781	0125	0000	%2060	c09 \$
09299	-02689	-02679	1000	0937	0875	0900	0662	0250	0000	%2061	d01 \$
08959	-09121	-09143	0875	0843	0750	0125	0156	0250	0000	%2062	d02 \$
08448	-09057	-090166	0750	0750	0750	0250	0250	0250	0000	%2063	d03 \$
07789	-09555	-09065	0625	0656	0750	0375	0343	0250	0000	%2064	d04 \$
07201	-08845	-01778	0500	0562	0750	0500	0437	0250	0000	%2065	d05 \$
06512	-01228	-02459	0375	0468	0750	0625	0531	0250	0000	%2066	d06 \$
05571	-01383	-03144	0250	0375	0750	0750	0625	0250	0000	%2067	d07 \$
05142	-01696	-03527	0125	0281	0750	0875	0718	0250	0000	%2068	d08 \$
04907	-02143	-04609	0000	0187	0750	1000	0812	0250	0000	%2069	d09 \$
08890	-09138	-09337	1000	0906	0625	0000	0093	0375	0000	%2070	e01 \$
08728	-09213	-02660	0875	0812	0625	0125	0187	0375	0000	%2071	e02 \$
08307	-09068	-091269	0750	0718	0625	0250	0281	0375	0000	%2072	e03 \$
07723	-09050	-090122	0625	0625	0625	0375	0371	0375	0000	%2073	e04 \$
07049	-09505	-01090	0500	0531	0625	0500	0468	0375	0000	%2074	e05 \$
06300	-09967	-02009	0375	0437	0625	0625	0562	0375	0000	%2075	e06 \$
05512	-01225	-02744	0250	0343	0625	0750	0566	0375	0000	%2076	e07 \$
04909	-01404	-03288	0125	0250	0625	0875	0759	0375	0000	%2077	e08 \$
04545	-01793	-04421	0000	0156	0625	1000	0843	0375	0000</		

See original or copy: <http://web.me.com/klaus.richter/HE16/HE16L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

```
%BEG HE06_22.TXT, Separation cmyn6*, D65, not adapted $
%100 x LAB*          %#1000 x (r g b c m y o)          %nr.   pos $
%Z004431 006114 002466 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008914 -01081 007925 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005555 -06439 002361 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005687 -04327 -02071 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z004579 -01059 -04798 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z003235 004636 -02787 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001476 000048 000106 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009694 -00096 000191 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004431 006114 002466 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008914 -01081 007925 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005555 -06439 002361 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005687 -04327 -02071 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z004579 -01059 -04798 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z003235 004636 -02787 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001476 000048 000106 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009694 -00096 000191 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004431 006114 002466 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008914 -01081 007925 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005555 -06439 002361 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005687 -04327 -02071 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z004579 -01059 -04798 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z003235 004636 -02787 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001476 000048 000106 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009694 -00096 000191 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z004932 006174 005131 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008804 -02444 008817 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005647 -05788 000882 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005481 -03939 -03084 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003551 000668 -04764 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z003877 005889 -01803 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001494 000050 000095 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009702 -00101 000211 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z006509 003083 006645 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006910 -04553 005768 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005718 -05236 -00125 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z005360 -03238 -04091 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003165 002044 -04397 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004506 006918 -00810 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001551 000046 000090 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009707 -00097 000200 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z007648 001003 007799 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z005772 -06310 003980 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005787 -04698 -01161 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z005195 -02338 -04759 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z002926 003429 -03787 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004441 006453 001010 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001460 000045 000100 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009696 -00102 000210 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/HE16/HE16L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

%BEG HE06.22.TXT, Separation cmyn6*, D65, not adapted \$																			
%100 x LAB*																			
1000 x (r g b c m y θ)																			
000103 0000 0000 0000 1000 1000 1000 0000																			
000032 000034 0125 0125 0125 0875 0875 0875 0000																			
000005 000034 0125 0125 0125 0875 0875 0875 0000																			
000016 0250 0250 0250 0750 0750 0750 0000																			
000050 0375 0375 0375 0625 0625 0625 0000																			
000073 0500 0500 0500 0500 0500 0500 0000																			
000124 0625 0625 0625 0375 0375 0375 0000																			
000171 0750 0750 0750 0250 0250 0250 0000																			
000184 0875 0875 0875 0125 0125 0125 0000																			
000187 1000 1000 1000 0000 0000 0000 0000																			
000104 0000 0000 0000 1000 1000 1000 0000																			
000034 0125 0125 0125 0875 0875 0875 0000																			
000016 0250 0250 0250 0750 0750 0750 0000																			
000015 0375 0375 0375 0625 0625 0625 0000																			
000074 0500 0500 0500 0500 0500 0500 0000																			
000124 0625 0625 0625 0375 0375 0375 0000																			
000034 0125 0125 0125 0875 0875 0875 0000																			
000016 0250 0250 0250 0750 0750 0750 0000																			
000015 0375 0375 0375 0625 0625 0625 0000																			
000074 0500 0500 0500 0500 0500 0500 0000																			
000124 0625 0625 0625 0375 0375 0375 0000																			
000034 0125 0125 0125 0875 0875 0875 0000																			
000016 0250 0250 0250 0750 0750 0750 0000																			
000015 0375 0375 0375 0625 0625 0625 0000																			
000074 0500 0500 0500 0500 0500 0500 0000																			
000124 0625 0625 0625 0375 0375 0375 0000																			
000034 0125 0125 0125 0875 0875 0875 0000																			
000016 0250 0250 0250 0750 0750 0750 0000																			
000015 0375 0375 0375 0625 0625 0625 0000																			
000074 0500 0500 0500 0500 0500 0500 0000																			
000124 0625 0625 0625 0375 0375 0375 0000																			
000034 0125 0125 0125 0875 0875 0875 0000																			
000016 0250 0250 0250 0750 0750 0750 0000																			
000015 0375 0375 0375 0625 0625 0625 0000																			
000074 0500 0500 0500 0500 0500 0500 0000																			
000124 0625 0625 0625 0375 0375 0375 0000																			
000034 0125 0125 0125 0875 0875 0875 0000																			
000016 0250 0250 0250 0750 0750 0750 0000																			
000015 0375 0375 0375 0625 0625 0625 0000																			
000074 0500 0500 0500 0500 0500 0500 0000																			
000124 0625 0625 0625 0375 0375 0375 0000																			
000034 0125 0125 0125 0875 0875 0875 0000																			
000016 0250 0250 0250 0750 0750 0750 0000																			
000015 0375 0375 0375 0625 0625 0625 0000																			
000074 0500 0500 0500 0500 0500 0500 0000																			
000124 0625 0625 0625 0375 0375 0375 0000																			
000034 0125 0125 0125 0875 0875 0875 0000																			
000016 0250 0250 0250 0750 0750 0750 0000																			
000015 0375 0375 0375 0625 0625 0625 0000																			
000074 0500 0500 0500 0500 0500 0500 0000																			
000124 0625 0625 0625 0375 0375 0375 0000																			
000034 0125 0125 0125 0875 0875 0875 0000																			
000016 0250 0250 0250 0750 0750 0750 0000																			

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/HE16/HE16L0NA.TXT> / PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfl=1.00; nt=0.01; nx=1.33

TUB registration: 20091101-HE16/HE16L0NA.TXT/.PS TUB material: code=rha4ta

[illegible]

TUB-test chart HE16; Relative Elementary Colour System O
1080 spectral reflexions R $\rightarrow$ LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/HE16/HE16L0NA.TXT> / .PS
 Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0, cfl=1.00; nt=0.01; nx=1.33

[illegible]

See original or copy: <http://web.me.com/klaus.richter/HE16/HE16L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

```
%BEG HE06_22.TXT, Separation cmyn6*, D65, adapted S
%100 x LAB*a
%#1000 x (r g b c m y 0) %nr. pos $
%z004431 006117 002329 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008914 -00998 007741 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z005555 -06415 002212 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005687 -04301 -02221 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z004579 -01053 -04937 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z003235 004618 -02912 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z001476 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009694 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%z004431 006117 002329 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008914 -00998 007741 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z005555 -06415 002212 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005687 -04301 -02221 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z004579 -01053 -04937 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z003235 004618 -02912 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z001476 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009694 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%z004431 006117 002329 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008914 -00998 007741 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z005555 -06415 002212 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005687 -04301 -02221 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z004579 -01053 -04937 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z003235 004618 -02912 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z001476 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009694 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%z004932 006187 004987 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z008804 -02359 008618 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005647 -05761 000728 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z005481 -03916 -03235 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003551 000655 -04809 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z003877 005883 -02012 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z001494 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009702 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%z006509 003124 006487 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z006910 -04505 005605 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005718 -05209 -00272 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z005360 -03217 -04233 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z003165 002026 -04509 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004506 006923 -00941 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z001551 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009707 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%z007648 001069 007616 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z005772 -06278 003822 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005787 -04666 -01319 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z005195 -02317 -04909 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z002926 003409 -03907 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004441 006461 000869 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z001460 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009696 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

TUB registration: 20091101-HE16/HE16L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/HE16/HE16L0NA.TXT/.PS>
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

%BEG HE06.22.TXT, Separation cmyn6*, D65, adapted \$																									
%100 x LAB*a																									
1000 x (r g b c m y θ)																									
										%nr.	pos	\$													
001335	-00016	000026	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$	009195	000007	000005	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$
002435	-00024	-00059	0125	0125	0125	0875	0875	0875	0000	%0973	k02	\$	009648	-00009	-00003	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$
004348	-00011	-00105	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$	009707	-00008	000001	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$
005513	-00004	-00089	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$	001091	-00003	000040	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$
006779	000000	-00085	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	001643	000002	000007	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$
007766	000010	-00049	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$	002697	-00011	-00068	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$
008524	-00013	-00013	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$	003724	-00002	-00084	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$
009330	000004	-00002	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$	004435	000006	-00049	0266	0266	0266	0733	0733	0733	0000	%1060	n14	\$
009715	-00005	-00015	1000	1000	1000	1000	1000	1000	0000	%0980	k09	\$	005210	000004	-00075	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$
001254	-00015	000028	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$	005718	000012	-00064	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$
002360	-00015	000058	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$	006471	000006	-00062	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$
004274	-00009	-00106	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$	007014	000006	-00053	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$
005500	000001	-00092	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$	007503	-00004	-00039	0600	0600	0600	0399	0399	0399	0000	%1065	n19	\$
006723	000007	-00083	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	007965	000015	-00020	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$
007777	000011	-00050	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$	008376	000015	-00008	0733	0733	0733	0266	0266	0266	0000	%1067	n21	\$
008552	-00012	-00012	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$	008818	000013	000008	0800	0800	0800	0199	0199	0199	0000	%1068	n22	\$
009345	000000	000002	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$	009156	000007	000013	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$
009717	-00013	-00005	1000	1000	1000	1000	1000	1000	0000	%0989	l09	\$	009629	-00001	-00006	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$
001225	-00016	000014	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$	009705	000002	-00007	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$
002325	-00021	-00050	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$	001456	000000	000000	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$
004197	-00008	-00097	0250	0250	0250	0750	0750	0750	0000	%0992	m03	\$	009710	000000	000000	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$
005404	000000	-00074	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$	004312	006020	002600	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
006690	000003	-00077	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$	005760	-04559	-01668	0000	1000	1000	1000	0000	0000	0000	%1075	l27	\$
007731	000005	-00034	0625	0625	0625	0375	0375	0375	0000	%0995	m06	\$	008883	-00968	008116	1000	1000	0000	0000	0000	1000	0000	%1076	m26	\$
008548	000009	-00005	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$	004578	-01104	-04947	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$
009359	000010	000005	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$	005496	-06779	002551	0000	1000	0000	0000	0000	1000	0000	%1078	n26	\$
009718	-00010	000007	1000	1000	1000	1000	1000	1000	0000	%0998	m09	\$	003136	004822	-03141	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$
001184	-00015	000012	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$													
002315	-00016	-00046	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$	%z004312	006020	002600	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
004162	-00010	-00097	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$	%z008883	-00968	008116	1000	0000	0000	0000	0000	1000	0000	%1076	m26	\$
005406	-00001	-00074	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$	%z005496	-06779	002551	1000	0000	1000	0000	0000	1000	0000	%1078	n26	\$
006661	000003	-00075	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$	%z005760	-04559	-01668	1000	1000	1000	0000	0000	0000	0000	%1075	l27	\$
007719	000011	-00046	0625	0625	0625	0375	0375	0375	0000	%1004	n06	\$	%z004578	-01104	-04947	1000	1000	1000	1000	1000	0000	0000	%1077	m27	\$
008530	000014	-00006	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$	%z003136	004822	-03141	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$
009338	000005	000005	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$	%z001456	000000	000000	1000	0000	1000	1000	1000	1000	0000	%1072	k26	\$
009714	-00003	-00002	1000	1000	1000	1000	1000	1000	0000	%1007	n09	\$	%z009716	000000	000000	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$
001236	000002	000024	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$													
001777	000004	-00008	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$	%z001335	-00016	000026	1000	0000	0000	1000	1000	1000	0000	%0972	k01	\$
002848	-00004	-00099	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$	%z009715	-00005	-00015	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$
003862	000000	-00104	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$													
004619	000005	-00080	0266	0266	0266	0733	0733	0733	0000	%1012	k14	\$	%z001254	-00015	000028	1000	0000	1000	1000	1000	1000	0000	%0981	l01	\$
005383	000004	-00110	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$	%z009717	-00013	-00005	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$
005838	000006	-00083	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$													
006628	000004	-00086	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$	%z001225	-00016	000014	1000	0000	0000	1000	1000	1000	0000	%0990	m01	\$
007114	000001	-00064	0533	0533	0533	0466	0466	0466	0000	%1016	k18	\$	%z009718	-00010	000007	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$
007583	000003	-00047	0600	0600	0600	0399	0399	0399	0000	%1017	k19	\$													
008012	000014	-00023	0666	0666	0666	0333	0333	0333	0000	%1018	k20	\$	%z001184	-00015	000012	1000	0000	1000	1000	1000	1000	0000	%0999	n01	\$
008441	000013	-00005	0733	0733	0733	0266	0266	0266	0000	%1019	k21	\$	%z009714	-00003	-00002	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$
008835	000009	000005	0800	0800	0800	0199	0199	0199	0000	%1020	k22	\$													
009181	000007	000006	0866	0866	0866	0133	0133	0133	0000	%1021	k23	\$													

%BEG HE06.22.TXT, Separation cmykn6*, D50, not adapted \$																														
%100 x LAB*																														
1000 x (r g b c m y θ)																														
%rnr. pos \$																														
009701	-00071	000193	1000	1000	0000	0000	0000	0000	0000	%0000	A01	\$	009701	-00066	000179	1000	1000	0000	0000	0000	0000	0000	0000	0000	%0648	A19	\$			
009901	-00024	-00475	0875	1000	0000	0125	0000	0000	0000	%0001	A02	\$	009022	-00594	-00702	0875	0875	1000	0125	0125	0000	0000	0125	0000	0000	%0649	A20	\$		
008604	-01209	-00992	0750	1000	0000	0250	0000	0000	0000	%0002	A03	\$	008514	-01009	-01359	0750	0750	1000	0250	0250	0000	0000	0250	0000	0000	0000	%0650	A21	\$	
008010	-01786	-01358	0625	1000	0000	0375	0000	0000	0000	%0003	A04	\$	007541	-01220	-02344	0625	0625	1000	0375	0375	0000	0000	0375	0000	0000	0000	%0651	A22	\$	
007419	-02261	-01805	0500	1000	0000	0500	0000	0000	0000	%0004	A05	\$	006706	-01307	-03114	0500	0500	1000	0500	0500	0000	0000	0500	0000	0000	0000	%0652	A23	\$	
006924	-02753	-02075	0375	1000	0000	0625	0000	0000	0000	%0005	A06	\$	005874	-01415	-03790	0375	0375	1000	0625	0625	0000	0000	0625	0000	0000	0000	%0653	A24	\$	
006322	-03513	-02128	0250	1000	0000	0750	0000	0000	0000	%0006	A07	\$	005175	-01630	-04430	0250	0250	1000	0750	0750	0000	0000	0750	0000	0000	0000	%0654	A25	\$	
005857	-04188	-02271	0125	1000	0000	0875	0000	0000	0000	%0007	A08	\$	004727	-01857	-04843	0125	0125	1000	0875	0875	0000	0000	0875	0000	0000	0000	%0655	A26	\$	
005555	-04685	-02391	0000	1000	0000	1000	0000	0000	0000	%0008	A09	\$	004432	-01893	-05077	0000	0000	1000	1000	1000	0000	0000	1000	0000	0000	0000	%0656	A27	\$	
009182	000542	000740	1000	0875	0875	0000	0125	0125	0000	%0009	B01	\$	009650	-00490	001839	1000	1000	0875	0000	0000	0125	0000	0000	0125	0000	0000	%0657	B19	\$	
009230	-00052	000212	0875	0875	0875	0125	0125	0125	0000	%0010	B02	\$	009362	-00056	000205	0875	0875	0875	0125	0125	0125	0125	0125	0125	0125	0000	%0658	B20	\$	
008828	-01065	-00592	0750	0875	0875	0250	0125	0125	0000	%0011	B03	\$	008691	-00592	-01038	0750	0750	0875	0250	0250	0250	0125	0250	0125	0125	0000	%0659	B21	\$	
008277	-01066	-01017	0625	0875	0875	0375	0125	0125	0000	%0012	B04	\$	007874	-00847	-01902	0625	0625	0875	0375	0375	0125	0000	0000	0125	0125	0000	%0660	B22	\$	
007537	-02247	-01471	0500	0875	0875	0500	0125	0125	0000	%0013	B05	\$	006974	-01107	-02778	0500	0500	0875	0500	0500	0125	0000	0000	0125	0125	0000	%0661	B23	\$	
007015	-02701	-01905	0375	0875	0875	0625	0125	0125	0000	%0014	B06	\$	006171	-01369	-03524	0375	0375	0875	0625	0625	0625	0125	0000	0000	0125	0125	0000	%0662	B24	\$
006460	-03935	-01899	0250	0875	0875	0750	0125	0125	0000	%0015	B07	\$	005349	-01666	-04285	0250	0250	0875	0750	0750	0125	0000	0000	0125	0125	0000	%0663	B25	\$	
005924	-04116	-02111	0125	0875	0875	0875	0125	0125	0000	%0016	B08	\$	004772	-01835	-04759	0125	0125	0875	0875	0875	0125	0000	0000	0125	0125	0000	%0664	B26	\$	
005999	-04943	-02397	0000	0875	0875	1000	0125	0125	0000	%0017	B09	\$	004343	-01768	-05071	0000	0000	0875	1000	1000	0125	0000	0000	0125	0125	0000	%0665	B27	\$	
008586	001325	000996	1000	0750	0750	0000	0250	0250	0000	%0018	C01	\$	009490	-00542	002969	1000	1000	0750	0000	0000	0250	0000	0000	0250	0000	0000	%0666	C19	\$	
008422	000811	000742	0875	0750	0750	0125	0250	0250	0000	%0019	C02	\$	009249	-00285	001632	0875	0875	0750	0125	0125	0125	0250	0000	0000	0125	0250	0000	%0667	C20	\$
008400	-00030	000175	0750	0750	0750	0250	0250	0250	0000	%0020	C03	\$	008529	-00033	000184	0750	0750	0750	0250	0250	0250	0250	0000	0000	0250	0000	%0668	C21	\$	
008112	-01072	-00549	0625	0750	0750	0375	0250	0250	0000	%0021	C04	\$	007750	-00536	-01088	0625	0625	0750	0375	0375	0250	0000	0000	0375	0250	0000	%0669	C22	\$	
007539	-01820	-01057	0500	0750	0750	0500	0250	0250	0000	%0022	C05	\$	006838	-00682	-01901	0500	0500	0750	0500	0500	0250	0000	0000	0250	0000	0000	%0670	C23	\$	
007539	-01820	-01057	0500	0750	0750	0500	0250	0250	0000	%0023	C06	\$	006006	-01031	-02733	0375	0375	0750	0625	0625	0250	0000	0000	0250	0000	0000	%0671	C24	\$	
006321	-03021	-01822	0250	0750	0750	0750	0250	0250	0000	%0024	C07	\$	005239	-01318	-03399	0250	0250	0750	0750	0750	0250	0000	0000	0250	0000	0000	%0672	C25	\$	
005865	-03887	-02048	0125	0750	0750	0875	0250	0250	0000	%0025	C08	\$	004665	-01561	-04061	0125	0125	0750	0875	0875	0250	0000	0000	0250	0000	0000	%0673	C26	\$	
005273	-05091	-02520	0000	0750	0750	1000	0250	0250	0000	%0026	C09	\$	004174	-01503	-05099	0000	0000	0750	1000	1000	0250	0000	0000	0250	0000	0000	%0674	C27	\$	
007962	002131	004140	1000	0625	0625	0000	0375	0375	0000	%0027	D01	\$	009348	-00497	003777	1000	1000	0625	0000	0000	0375	0000	0000	0375	0000	0000	%0675	D19	\$	
007917	001510	001129	0875	0625	0625	0125	0375	0375	0000	%0028	D02	\$	009180	-00325	003088	0875	0875	0625	0125	0125	0125	0375	0000	0000	0125	0375	0000	%0676	D20	\$
007726	000877	000544	0750	0625	0625	0250	0375	0375	0000	%0029	D03	\$	008567	-00193	001510	0750	0750	0625	0250	0250	0375	0000	0000	0375	0000	0000	%0677	D21	\$	
007646	-00028	000133	0625	0625	0625	0375	0375	0375	0000	%0030	D04	\$	007732	-00026	000119	0625	0625	0625	0375	0375	0375	0375	0000	0000	0375	0375	0000	%0678	D22	\$
007179	-01039	-00724	0500	0625	0625	0500	0375	0375	0000	%0031	D05	\$	006834	-00421	-01255	0500	0500	0625	0500	0500	0375	0000	0000	0375	0000	0000	%0679	D23	\$	
006588	-01875	-01327	0375	0625	0625	0625	0375	0375	0000	%0032	D06	\$	005816	-00734	-02269	0375	0375	0625	0625	0625	0375	0000	0000	0625	0375	0000	%0680	D24	\$	
005881	-02399	-01958	0250	0625	0625	0250	0375	0375	0000	%0033	D07	\$	005063	-01097	-02059	0250	0250	0625	0750	0750	0375	0000	0000	0375	0000	0000	%0681	D25	\$	
005461	-03442	-02154	0125	0625	0625	0625	0875	0375	0000	%0034	D08	\$	004527	-01352	-03525	0125	0125	0625	0875	0875	0375	0000	0000	0375	0000	0000	%0682	D26	\$	
005144	-05226	-02619	0000	0625	0625	1000	0375	0375	0000	%0035	D09	\$	003755	-01259	-04675	0000	0000	0625	1000	1000	0375	0000	0000	0375	0000	0000	%0683	D27	\$	
007379	002895	002061	1000	0500	0500	0000	0500	0500	0000	%0036	E01	\$	009233	-00468	004603	1000	1000	0500	0000	0000	0500	0000	0000	0500	0000	0000	%0684	E19	\$	
007418	002289	001756	0875	0500	0500	0125	0500	0500	0000	%0037	E02	\$	009149	-00342	004108	0875	0875	0500	0125	0125	0500	0000	0000	0125	0500	0000	%0685	E20	\$	
007117	001528	001196	0750	0500	0500	0250	0500	050																						

See original or copy: <http://web.me.com/klaus.richter/HE16/HE16L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfl=1.00; nt=

TUB registration: 20091101-HE16/HE16L0NA.TXT /.PS TUB material application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

[illegible]

TUB-test chart HE16; Relative Elementary Colour System O
1080 spectral reflexions R $\rightarrow$ LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

009711	-00060	000182	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$
008999	-00822	-00788	0875	0937	1000	0125	0062	0000	0000	%0163	S02 \$
008551	-01175	-01288	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$
007927	-01644	-02127	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$
007383	-01986	-02745	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$
006916	-02343	-03202	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$
006271	-02705	-03857	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$
005625	-03471	-04285	0125	0562	1000	0875	0500	0000	0000	%0169	S08 \$
005194	-04036	-04441	0000	0500	1000	1000	0500	0000	0000	%0170	S09 \$
009322	-006155	001342	1000	0937	0875	0000	0062	0125	0000	%0171	T01 \$
009203	-006049	000282	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$
008766	-00940	-00972	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$
008130	-01432	-01848	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$
007526	-01934	-02499	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$
006943	-02313	-02983	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$
006291	-02737	-03619	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$
005557	-03331	-03988	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$
005128	-04098	-04427	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$
009011	-000322	002395	1000	0875	0750	0000	0125	0250	0000	%0180	U01 \$
008726	-000369	001328	0875	0812	0750	0125	0187	0250	0000	%0181	U02 \$
008399	-00032	000181	0750	0750	0750	0250	0250	0250	0000	%0182	U03 \$
008023	-00946	-01025	0625	0687	0750	0375	0312	0250	0000	%0183	U04 \$
007460	-01543	-01777	0500	0625	0750	0500	0375	0250	0000	%0184	U05 \$
006773	-01995	-02582	0375	0562	0750	0625	0437	0250	0000	%0185	U06 \$
006092	-02350	-03124	0250	0500	0750	0750	0500	0250	0000	%0186	U07 \$
005434	-02984	-03656	0125	0437	0750	0875	0562	0250	0000	%0187	U08 \$
005133	-04156	-04186	0000	0375	0750	1000	0625	0250	0000	%0188	U09 \$
005074	-000816	003059	1000	0812	0625	0000	0187	0375	0000	%0189	V01 \$
008358	-00628	002466	0875	0750	0625	0125	0250	0375	0000	%0190	V02 \$
008121	-00266	001236	0750	0687	0625	0250	0312	0375	0000	%0191	V03 \$
007655	-00032	000132	0625	0625	0625	0375	0375	0375	0000	%0192	V04 \$
007105	-00809	-01159	0500	0562	0625	0500	0437	0375	0000	%0193	V05 \$
006446	-01632	-02045	0375	0500	0625	0625	0500	0375	0000	%0194	V06 \$
005698	-01985	-02847	0250	0437	0625	0750	0562	0375	0000	%0195	V07 \$
005174	-02515	-03250	0125	0375	0625	0875	0625	0375	0000	%0196	V08 \$
004903	-03958	-04088	0000	0312	0625	1000	0687	0375	0000	%0197	V09 \$
008170	-001262	003860	1000	0750	0500	0000	0250	0500	0000	%0198	W01 \$
008010	-009994	003145	0875	0687	0500	0125	0312	0500	0000	%0199	W02 \$
007720	-000678	002467	0750	0625	0500	0250	0375	0500	0000	%0200	W03 \$
007271	-00368	001076	0625	0562	0500	0375	0437	0500	0000	%0201	W04 \$
006701	-00031	000079	0500	0500	0500	0500	0500	0500	0000	%0202	W05 \$
006069	-00916	-01455	0375	0437	0500	0625	0562	0500	0000	%0203	W06 \$
005314	-01665	-02232	0250	0375	0500	0750	0625	0500	0000	%0204	W07 \$
004774	-02139	-03046	0125	0312	0500	0875	0687	0500	0000	%0205	W08 \$
004432	-03321	-03955	0000	0250	0500	1000	0750	0500	0000	%0206	W09 \$
007731	-001875	004417	1000	0687	0375	0000	0312	0625	0000	%0207	X01 \$
007600	-001557	003786	0875	0625	0375	0125	0375	0625	0000	%0208	X02 \$
007201	-001116	002998	0750	0562	0375	0250	0437	0625	0000	%0209	X03 \$
006790	-000737	002325	0625	0500	0375	0375	0500	0625	0000	%0210	X04 \$
006277	-000386	001293	0500	0437	0375	0500	0562	0625	0000	%0211	X05 \$
005609	-00020	000044	0375	0375	0375	0625	0625	0625	0000	%0212	X06 \$
004988	-01155	-01633	0250	0312	0375	0750	0687	0625	0000	%0213	X07 \$
004421	-01609	-02510	0125	0250	0375	0875	0750	0625	0000	%0214	X08 \$
003889	-02861	-03516	0000	0187	0375	1000	0812	0625	0000	%0215	X09 \$
007347	-002443	005279	1000	0625	0250	0000	0375	0750	0000	%0216	Y01 \$
007193	-002161	004484	0875	0562	0250	0125	0437	0750	0000	%0217	Y02 \$
006774	-001647	003705	0500	0500	0250	0250	0500	0750	0000	%0218	Y03 \$
006265	-001343	003009	0625	0437	0250	0375	0500	0750	0000	%0219	Y04 \$
005697	-000886	002371	0500	0375	0250	0500	0625	0750	0000	%0220	Y05 \$
005207	-000389	001377	0375	0312	0250	0625	0687	0750	0000	%0221	Y06 \$
004503	-00807	000023	0250	0500	0250	0750	0750	0750	0000	%0222	Y07 \$
003925	-01267	-01944	0125	0187	0250	0875	0812	0750	0000	%0223	Y08 \$
003420	-02326	-03280	0000	0125	0250	1000	0875	0750	0000	%0224	Y09 \$
006913	-003139	006200	1000	0562	0125	0000	0437	0875	0000	%0225	Z01 \$
006749	-003034	005922	0875	0500	0125	0125	0500	0875	0000	%0226	Z02 \$
006236	-002368	004922	0750	0437	0125	0250	0562	0875	0000	%0227	Z03 \$
005727	-001494	004232	0625	0375	0125	0375	0625	0875	0000	%0228	Z04 \$
005118	-001550	003465	0500	0312	0125	0500	0687	0875	0000	%0229	Z05 \$
004513	-001158	002725	0375	0250	0125	0625	0750	0875	0000	%0230	Z06 \$
003952	-000681	001725	0250	0187	0125	0750	0812	0875	0000	%0231	Z07 \$
002730	-000017	000033	0125	0125	0125	0875	0875	0875	0000	%0232	Z08 \$
002852	-01981	-02545	0000	0062	0125	1000	0937	0875	0000	%0233	Z09 \$
006634	-003673	006677	1000	0500	0000	0000	0500	1000	0000	%0234	A01 \$
006464	-003524	006499	0875	0437	0000	0125	0562	1000	0000	%0235	A02 \$
005934	-003276	005893	0750	0375	0000	0250	0625	1000	0000	%0236	A03 \$
005066	-002960	004896	0625	0312	0000	0375	0687	1000	0000	%0237	A04 \$
004100	-002649	003799	0500	0250	0000	0500	0750	1000	0000	%0238	A05 \$
003527	-002267	003020	0375	0187	0000	0625	0812	1000	0000	%0239	A06 \$
002841	-001921	002064	0250	0125	0000	0750	0875	1000	0000	%0240	A07 \$
002268	-001228	001188	0125	0062	0000	0875	0937	1000	0000	%0241	A08 \$
001317	-000060	000104	0000	0000	0000	1000	1000	1000	0000	%0242	A09 \$
009704	-00072	000215	1000	1000	1000	0000	0000	0000	0000	%0486	S10 \$
008796	-00124	-00785	0937	0875	1000	0062	0125	0000	0000	%0487	S11 \$
007977	-00030	-01511	0875	0750	1000	0125	0250	0000	0000	%0488	S12 \$
006858	-00066	-02404	0812	0625	1000	0187	0375	0000	0000	%0489	S13 \$
005698	-000480	-03159	0750	0500	1000	0250	0500	0000	0000	%0490	S14 \$
004630	-009999	-03766	0687	0375	1000	0312	0625	0000	0000	%0491	S15 \$
003875	-001287	-04166	0625	0250	1000	0375	0750	0000	0000	%0492	S16 \$
003366	-001470	-04362	0562	0250	1000	0437	0875	0000	0000	%0493	S17 \$
003098	-001470	-04482	0500	1000	0500	1000	0000	0000	0000	%0494	S18 \$
009346	-000818	001168	0937	1000	0875	0062	0000	0125	0000	%0495	T10 \$
009360	-000504	000200	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$
008422	-00168	-01075	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$
007324	-000117	-02007	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$
006135	-000399	-02854	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$
004867	-000859	-03625	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$
003946	-001273	-04127	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$
003366	-001589	-04316	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$
002984	-001528	-04526	0437	0000	0875	0562	1000	0125	0000	%0503	T18 \$
009126	-01232	002139	0875	1000	0750	0125	0000	0250	0000	%0504	T19 \$
008978	-000829	001665	0812	0875	0750	0187	0125	0250	0000	%0505	U11 \$
008527	-000305	000191	0750	0750	0750	0250	0250	0250	0000	%0506	U12 \$
007449	-000041	-01174	0687	0625	0750	0312	0375	0250	0000	%0507	U13 \$
006308	-000293	-02149	0625	0500	0750	0375	0500	0250	0000	%0508	U14 \$
005344	-000476	-03036	0562	0375	0750	0437	0625	0250	0000	%0509	U15 \$
004379	-000801	-038									

[illegible]

See original or copy: <http://web.me.com/klaus.richter/HE16/HE16L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

```
%BEG HE06_22.TXT, Separation cmyn6*, D50, not adapted $
%100 x LAB*      %#1000 x (r g b c m y o)      %nr. pos $
%z004611 006398 002782 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008966 -00428 007761 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z005461 -06110 001982 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005555 -04685 -02391 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z004432 -01893 -05077 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z003296 004440 -02614 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z001479 000064 000110 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009695 -00068 000184 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%z004611 006398 002782 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008966 -00428 007761 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z005461 -06110 001982 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005555 -04685 -02391 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z004432 -01893 -05077 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z003296 004440 -02614 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z001479 000064 000110 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009695 -00068 000184 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%z004611 006398 002782 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008966 -00428 007761 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z005461 -06110 001982 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005555 -04685 -02391 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z004432 -01893 -05077 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z003296 004440 -02614 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z001479 000064 000110 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009695 -00068 000184 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%z005129 006586 005381 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z008834 -01778 008542 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005544 -05644 000540 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z005331 -04523 -03422 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003436 -00068 -04957 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z003995 005822 -01601 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z001497 000064 000089 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009703 -00071 000203 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%z006634 003673 006677 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z006877 -03982 005429 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005608 -05244 -00448 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z005194 -04036 -04441 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z003098 001479 -04482 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004673 006952 -00436 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z001553 000060 000094 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009708 -00068 000193 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%z007737 001654 007708 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z005695 -05832 003578 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005667 -04882 -01475 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z005025 -03250 -05099 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z002920 003041 -03744 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004618 006643 001363 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z001462 000060 000104 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009697 -00071 000202 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/HE16/HE16L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

%BEG HE06.22.TXT, Separation cmyn6*, D50, not adapted \$																									
%100 x LAB*																									
1000 x (r g b c m y θ)																									
001337 000046 000106 0000 0000 0000 1000 1000 1000 0000										%nr. pos \$															
002435	000011	000035	0125	0125	0125	0875	0875	0875	0000	009772	k01	\$	009196	-00047	000194	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$
004348	-00010	000016	0250	0250	0250	0750	0750	0750	0000	009783	k02	\$	009649	-00071	000190	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$
005513	-00018	000049	0375	0375	0375	0625	0625	0625	0000	009708	-00070	000197	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	%1055	m25	\$
006780	-00031	000071	0500	0500	0500	0500	0500	0500	0000	001094	000065	000118	0000	0000	0000	0000	1000	1000	1000	1000	1000	0000	%1056	n10	\$
007767	-00031	000121	0625	0625	0625	0375	0375	0375	0000	001645	000058	000093	0066	0066	0066	0933	0933	0933	0000	0000	0000	0000	%1057	n11	\$
008525	-00034	000167	0750	0750	0750	0250	0250	0250	0000	002698	000018	000031	0133	0133	0133	0866	0866	0866	0000	0000	0000	0000	%1058	n12	\$
009331	-00053	000189	0875	0875	0875	0125	0125	0125	0000	003724	000010	000030	0200	0200	0200	0800	0800	0800	0000	0000	0000	0000	%1059	n13	\$
009715	-00063	000180	1000	1000	1000	0000	0000	0000	0000	004436	000014	000075	0266	0266	0266	0733	0733	0733	0000	0000	0000	0000	%1060	n14	\$
010256	000049	000107	0000	0000	0000	1000	1000	1000	0000	005211	-00003	000060	0333	0333	0333	0666	0666	0666	0000	0000	0000	0000	%1061	n15	\$
002361	000021	000036	0125	0125	0125	0875	0875	0875	0000	005719	000000	000078	0400	0400	0400	0600	0600	0600	0000	0000	0000	0000	%1062	n16	\$
042744	-00007	000015	0250	0250	0250	0750	0750	0750	0000	006472	-00017	000090	0466	0466	0466	0533	0533	0533	0000	0000	0000	0000	%1063	n17	\$
005508	-00012	000047	0375	0375	0375	0625	0625	0625	0000	007814	-00024	000106	0533	0533	0533	0466	0466	0466	0000	0000	0000	0000	%1064	n18	\$
006723	-00022	000072	0500	0500	0500	0500	0500	0500	0000	007584	-00040	000126	0600	0600	0600	0399	0399	0399	0000	0000	0000	0000	%1065	n19	\$
007777	-00029	000120	0625	0625	0625	0375	0375	0375	0000	007966	-00024	000153	0666	0666	0666	0333	0333	0333	0000	0000	0000	0000	%1066	n20	\$
008554	-00034	000169	0750	0750	0750	0250	0250	0250	0000	008377	-00029	000171	0733	0733	0733	0266	0266	0266	0000	0000	0000	0000	%1067	n21	\$
009347	-00056	000193	0875	0875	0875	0125	0125	0125	0000	008819	-00034	000193	0800	0800	0800	0199	0199	0199	0000	0000	0000	0000	%1068	n22	\$
009717	-00076	000189	1000	1000	1000	0000	0000	0000	0000	009158	-00045	000202	0866	0866	0866	0133	0133	0133	0000	0000	0000	0000	%1069	n23	\$
010227	000047	000093	0000	0000	0000	1000	1000	1000	0000	009630	-00063	000188	0933	0933	0933	0066	0066	0066	0000	0000	0000	0000	%1070	n24	\$
002326	000016	000043	0125	0125	0125	0875	0875	0875	0000	009706	-00060	000188	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	%1071	n25	\$
004197	-00004	000023	0250	0250	0250	0750	0750	0750	0000	001458	000058	000082	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	%1072	k26	\$
005405	-00009	000063	0375	0375	0375	0625	0625	0625	0000	009717	-00062	000196	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	%1073	k27	\$
006690	-00025	000078	0500	0500	0500	0500	0500	0500	0000	004492	006310	003031	1000	0000	0000	0000	1000	1000	0000	0000	0000	0000	%1074	l26	\$
007732	-00033	000135	0625	0625	0625	0375	0375	0375	0000	005635	-04840	-01841	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	%1075	l27	\$
008550	-00036	000175	0750	0750	0750	0250	0250	0250	0000	008938	-00382	008131	1000	1000	0000	0000	0000	0000	1000	1000	0000	0000	%1076	m26	\$
009360	-00054	000197	0875	0875	0875	0125	0125	0125	0000	004428	-01960	-05101	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	%1077	m27	\$
009719	-00072	000202	1000	1000	1000	0000	0000	0000	0000	005401	-06440	002290	0000	1000	1000	0000	0000	0000	1000	1000	0000	0000	%1078	n26	\$
010186	000047	000090	0000	0000	0000	1000	1000	1000	0000	003196	-06414	-02862	1000	0000	1000	0000	1000	0000	0000	0000	0000	0000	%1079	n27	\$
002316	000022	000047	0125	0125	0125	0875	0875	0875	0000				%\$												
004162	-00006	000022	0250	0250	0250	0750	0750	0750	0000	%z004492	006310	003031	##1000	0000	0000	0000	1000	1000	0000	0000	0000	0000	%1074	l26	%03 0 0 \$
005407	-00011	000063	0375	0375	0375	0625	0625	0625	0000	%z008938	-00382	008131	##1000	1000	0000	0000	0000	1000	0000	0000	0000	0000	%1076	m26	%Y3 1 0 \$
006662	-00025	000080	0500	0500	0500	0500	0500	0500	0000	%z005401	-06440	002290	##0000	1000	0000	1000	0000	0000	0000	0000	0000	0000	%1078	n26	%L3 2 0 \$
007729	-00028	000124	0625	0625	0625	0375	0375	0375	0000	%z005635	-04840	-01841	##0000	1000	1000	0000	0000	0000	0000	0000	0000	0000	%1075	l27	%C3 3 0 \$
008532	-00032	000174	0750	0750	0750	0250	0250	0250	0000	%z004428	-01960	-05101	##0000	0000	1000	1000	0000	0000	0000	0000	0000	0000	%1077	m27	%V3 4 0 \$
009339	-00053	000197	0875	0875	0875	0125	0125	0125	0000	%z003196	004614	-02862	##1000	0000	1000	0000	1000	0000	0000	0000	0000	0000	%1079	n27	%M3 5 0 \$
009715	-00066	000193	1000	1000	1000	0000	0000	0000	0000	%z001458	000058	000082	##0000	0000	0000	1000	1000	0000	0000	0000	0000	%1072	k26	%M3 6 0 \$	
010238	000067	000105	0000	0000	0000	1000	1000	1000	0000	%z009717	-00062	000196	##1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	%1073	k27	%W3 7 0 \$
001779	000056	000079	0066	0066	0066	0933	0933	0933	0000	%\$															
002849	000019	000002	0133	0133	0133	0866	0866	0866	0000	%z001288	000057	000105	##0000	0000	0000	0000	1000	1000	0000	0000	0000	0000	%0972	k01	%N4 6 0 \$
003863	000007	000012	0200	0200	0200	0800	0800	0800	0000	%z009713	-00065	000177	##1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	%0980	k09	%W4 7 0 \$
004620	000005	000046	0266	0266	0266	0733	0733	0733	0000	%\$															
005383	-00009	000027	0333	0333	0333	0666	0666	0666	0000	%z001209	000057	000117	##0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	%0981	l01	%N5 6 0 \$
005839	-00010	000060	0400	0400	0400	0600	0600	0600	0000	%z009713	-00069	000182	##1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	%0989	l09	%W5 7 0 \$
006628	-00024	000068	0466	0466	0466	0533	0533	0533	0000	%\$															
007114	-00032	000096	0533	0533	0533	0466	0466	0466	0000	%z001205	000057	000105	##0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	%0990	m01	%N6 6 0 \$
007584	-00035	000120	0600	0600	0600	0399	0399	0399	0000	%z009713	-00071	000200	##1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	%0998	m09	%W6 7 0 \$
008013	-00027	000150	0666	0666	0666	0333	0333	0333	0000	%\$															
008442	-00031	000174	0733	0733	0733	0266	0266	0266	0000	%z001140	000056	000104	##0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	%0999	n01	%N7 6 0 \$
008836	-00039	000190	0800	0800	0800	0199	0199	0199	0000	%z009711	-00063	000191	##1000	1000	1000										

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/HE16/HE16L0NA.TXT/.PSS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfi=1.00; nt=1

TUB registration: 20091101-HE16/HE16LONA.TXT/.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

XREG H06E_2D.TXT, Separation cmyrn\$, D50, adapted \$					
\$x100 x Lab\$a	1900 x (r g b	c m y 0)	\$nrr.	pos \$	
009701 -00002 000008 1000 1000 1000 0000 0000 0000 0000	00000 A01 \$	009701 000002 -00005 -00001 1000 1000 1000 0000 0000 0000	000324 A10 \$	009681 000000 -00003 1000 1000 1000 0000 0000 0000	%0648 A19 \$
009069 -00765 -00654 0875 1000 1000 0125 0000 0000 0000	00001 A02 \$	009022 -00536 -00881 0875 0875 1000 0125 0125 0000	000325 A11 \$	008962 000366 -00672 1000 0875 1000 0000 0125 0000	%0649 A20 \$
008604 -01158 -01167 0750 1000 1000 0250 0000 0000 0000	00002 A03 \$	008514 -00959 -01533 0750 0750 1000 0250 0250 0000	000326 A12 \$	008173 001007 -01159 1000 0750 1000 0000 0250 0000	%0650 A21 \$
008010 -01745 -01527 0625 1000 1000 0375 0000 0000 0000	00003 A04 \$	007541 -01186 -02509 0625 0625 1000 0375 0375 0000	000327 A13 \$	007376 001786 -01478 1000 0625 1000 0000 0375 0000	%0651 A22 \$
007419 -02229 -01969 0500 1000 1000 0500 0000 0000 0000	00004 A05 \$	006706 -01287 -03272 0500 0500 1000 0500 0500 0000	000328 A14 \$	006341 002518 -01981 1000 0500 1000 0000 0500 0000	%0652 A23 \$
006924 -02279 -02234 0375 1000 1000 0625 0000 0000 0000	00005 A06 \$	005874 -01408 -03940 0375 0375 1000 0625 0625 0000	000329 A15 \$	005250 003063 -02580 1000 0375 1000 0000 0625 0000	%0653 A24 \$
006322 -03499 -02282 0250 1000 1000 0750 0000 0000 0000	00006 A07 \$	005175 -01635 -04573 0250 0250 1000 0750 0750 0000	000330 A16 \$	004229 003828 -02921 1000 0250 1000 0000 0750 0000	%0654 A25 \$
005857 -04181 -02421 0125 1000 1000 0875 0000 0000 0000	00007 A08 \$	004727 -01868 -04983 0125 0125 1000 0875 0875 0000	000331 A17 \$	003672 004216 -02986 1000 0125 1000 0000 0875 0000	%0655 A26 \$
005555 -04664 -02538 0000 1000 1000 1000 0000 0000 0000	00008 A09 \$	004032 -01909 -05214 0000 0000 1000 1000 1000 0000	000332 A18 \$	003296 004405 -02741 1000 0000 1000 0000 1000 0000	%0656 A27 \$
009182 000603 000560 1000 0875 0875 0000 0125 0125 0000	00009 B01 \$	009650 -00422 001655 1000 1000 0875 0000 0125 0000	000333 B10 \$	009102 -00889 000237 0875 1000 0875 0125 0000 0125 0000	%0657 B19 \$
009230 000008 000032 0875 0875 0875 0125 0125 0125 0000	00010 B02 \$	009362 000007 000023 0875 0875 0875 0125 0125 0125 0000	000334 B11 \$	009312 000009 000014 0875 0875 0875 0125 0125 0125 0000	%0658 B20 \$
008828 -01010 -00768 0750 0875 0875 0250 0125 0125 0000	00011 B03 \$	008601 -00541 -01213 0750 0750 0875 0250 0250 0125 0000	000335 B12 \$	008452 000462 -01028 0875 0750 0875 0125 0250 0125 0000	%0659 B21 \$
008277 -01560 -01189 0625 0875 0875 0375 0125 0125 0000	00012 B04 \$	007874 -00807 -02070 0625 0625 0875 0375 0375 0125 0000	000336 B13 \$	007687 001110 -01518 0875 0625 0875 0125 0375 0125 0000	%0660 B22 \$
007537 -02214 -01636 0500 0875 0875 0500 0125 0125 0000	00013 B05 \$	006974 -01082 -02938 0500 0500 0875 0500 0500 0125 0000	000337 B14 \$	006691 001985 -01943 0875 0500 0875 0125 0500 0125 0000	%0661 B23 \$
007015 -02675 -02065 0375 0875 0875 0625 0125 0125 0000	00014 B06 \$	006171 -01357 -03676 0375 0375 0875 0625 0625 0125 0000	000338 B15 \$	005489 002758 -02570 0875 0375 0875 0125 0625 0125 0000	%0662 B24 \$
006408 -03979 -02054 0250 0875 0875 0750 0125 0125 0000	00015 B07 \$	005349 -01667 -04430 0250 0250 0875 0750 0750 0125 0000	000339 B16 \$	004415 003440 -03034 0875 0250 0875 0125 0750 0125 0000	%0663 B25 \$
005924 -04108 -02621 0125 0875 0875 0875 0125 0125 0000	00016 B08 \$	004772 -01846 -04899 0125 0125 0875 0875 0875 0125 0000	000340 B17 \$	003630 004222 -03069 0875 0125 0875 0125 0875 0125 0000	%0664 B26 \$
005399 -04944 -02542 0000 0875 0875 1000 0125 0125 0000	00017 B09 \$	004343 -01786 -05207 0000 0000 0875 1000 1000 0125 0000	000341 B18 \$	003144 004243 -02797 0875 0000 0875 0125 1000 0125 0000	%0665 B27 \$
005866 -00075 -00022 1000 0750 0750 0000 0250 0250 0000	00018 C01 \$	004477 002787 1000 1000 07			

TUB-test chart HE16; Relative Elementary Colour System O
1080 spectral reflexions R $\rightarrow$ LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/HE16/HE16L0NA.TXT> / PS
 Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0, cfl=1.00; nt=0.01; nx=1.33

009711	000007	-00010	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
008999	-00766	-00973	0875	0937	1000	0125	0662	0000	0000	%0163	S02	\$
008551	-01125	-01468	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
007927	-01604	-02299	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
007383	-01955	-02911	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
006916	-02319	-03362	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
006271	-02692	-04009	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
005625	-03468	-04400	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$
005194	-04039	-04580	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
003932	-00217	-001153	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
002903	000010	000015	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
008766	-00887	-01154	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
008130	-01389	-02022	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
007526	-01900	-02666	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
006943	-02288	-03143	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
006291	-02722	-03771	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
005557	-03329	-04131	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
005128	-04102	-04565	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
009011	000379	002210	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
008726	000421	001146	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
008399	000014	000003	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
008023	-00904	-01198	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
007460	-01510	-01943	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
006773	-01973	-02740	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
006092	-02339	-03273	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
005434	-02983	-03798	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
005133	-04160	-04324	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
008574	000866	002289	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
008358	000675	002878	0875	0750	0625	0125	0250	0375	0000	%0190	V02	\$
008121	000303	001062	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
007655	000003	-00035	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
007105	-00872	-01321	0500	0562	0625	0500	0437	0375	0000	%0193	V05	\$
006446	-01616	-02199	0375	0500	0625	0625	0500	0375	0000	%0194	V06	\$
005698	-01980	-02982	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
005174	-02519	-03389	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
004903	-03966	-04223	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
008170	001306	003685	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
008010	001835	002972	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
007720	000707	002297	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
007428	000398	000912	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
006701	-00010	-00077	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
006069	-00905	-01604	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$
005314	-01666	-02373	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
004774	-02149	-03180	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
004432	-03336	-04084	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
007731	001912	004247	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
007600	001592	003618	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
007201	001145	002835	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
006790	000759	002167	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
006277	000400	001141	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
005609	-00017	-00099	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
004988	-01161	-01770	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
004421	-01714	-02640	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
003889	-02885	-03639	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
007347	002473	005114	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
007193	002190	004321	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
006774	001609	003547	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
006265	001327	002947	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
005697	000891	002226	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
005207	000386	001238	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
004503	-00021	-00107	0250	0250	0250	0500	0750	0750	0000	%0222	Y07	\$
003925	-01290	-02067	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
003420	-02351	-03398	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
006913	003163	006040	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
006749	003056	005764	0875	0500	0125	0125	0500	0875	0000	%0226	Z02	\$
006236	002381	004771	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
005727	001949	004087	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
005118	001546	003327	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
004513	001144	002595	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
003952	000658	001601	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
002730	-00232	-00075	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
002852	-02021	-02655	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$
002634	003692	006521	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
004644	003541	006345	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
005934	003285	005745	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
005066	002955	004759	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
004100	002629	003673	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
003527	002238	002901	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
002841	001881	001954	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
002268	001179	001085	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$
001317	-00003	000012	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009704	-00004	-000022	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
008796	-00071	-00967	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
007977	000010	-01684	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
006858	000090	-02563	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
006598	000485	-03304	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
004630	000987	-03898	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
003875	001263	-04289	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
003366	001460	-04563	0562	0250	1000	0437	0875	0000	0000	%0493	S17	\$
003099	001442	-04589	0500	0250	1000	0500	1000	0000	0000	%0494	S18	\$
003436	-00756	-000979	0937	1000	0875	0062	0100	0125	0000	%0495	T10	\$
003360	000007	000011	0875	0875	0875	0125	0125	0125	0000	%0496	T11	\$
008422	-00120	-01253	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
007324	-000148	-02172	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
006135	000411	-03004	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
004867	000850	-03760	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
003946	001250	-04251	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
003366	001558	-04432	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
002984	001490	-04638	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
009126	-01173	-001953	0875	1000	0750	0125	0000	0250	0000	%0504	U10	\$
008978	-00773	000880	0812	0875	0750	0187	0125	0250	0000	%0505	U11	\$
008527	000014	000012	0750	0750	0750	0250	0250	0250	0000			

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/HE16/HE16L0NA.TXT> / <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=

TUB registration: 20091101-HE16/HE16L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

[illegible]

TUB-test chart HE16; Relative Elementary Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/HE16/HE16L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

```
%BEG HE06_22.TXT, Separation cmyn6*, D50, adapted S
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr. pos $
%z004611 006385 002643 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008966 -00371 007583 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z005461 -06109 001836 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005555 -04684 -02538 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z004432 -01909 -05214 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z003296 004405 -02741 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z001479 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009695 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%z004611 006385 002643 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008966 -00371 007583 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z005461 -06109 001836 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005555 -04684 -02538 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z004432 -01909 -05214 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z003296 004405 -02741 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z001479 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009695 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%z004611 006385 002643 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008966 -00371 007583 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z005461 -06109 001836 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005555 -04684 -02538 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z004432 -01909 -05214 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z003296 004405 -02741 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z001479 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009695 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%z005129 006582 005236 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z008834 -01721 008350 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005544 -05642 000389 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z005331 -04524 -03570 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003436 -00100 -05081 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z003995 005799 -01732 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z001497 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009703 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%z006634 003692 006521 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z006877 -03959 005270 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005608 -05241 -00592 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z005194 -04039 -04580 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z003098 001442 -04595 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004673 006941 -00569 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z001553 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009708 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%z007737 001694 007529 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z005695 -05824 003423 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005667 -04875 -01630 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z005025 -03253 -05246 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z002920 003004 -03866 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004618 006633 001221 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z001462 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009697 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/HE16/HE16L0NA.TXT> / PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.01; nx=1.3

TUB registration: 20091101-HE16/HE16L0NA.TXT/.PS TUB material: code=rh4ta
application for evaluation and measurement of printer or monitor systems

BBEG H06.22.TXT, Separation (rmyb* D50, adapted \$									
#100 x LAB*a		1000 x (r g b		c m y o)		%nr.	pos \$		
001337	-00013	000025	0000	0000	1000	1000	0000	%0972	k01 \$
002435	-00032	000600	0125	0125	0125	0875	0875	%0973	k02 \$
000448	-00026	000105	0250	0250	0250	0750	0750	%0974	k03 \$
005513	-00018	000888	0375	0375	0375	0625	0625	%0975	k04 \$
006780	-00012	000840	0500	0500	0500	0500	0500	%0976	k05 \$
007767	0000002	000448	0625	0625	0625	0375	0375	%0977	k06 \$
008525	0000010	000012	0750	0750	0750	0250	0250	%0978	k07 \$
009331	0000003	000001	0875	0875	0875	0125	0125	%0979	k08 \$
009715	-00007	000015	1000	1000	1000	0000	0000	%0980	k09 \$
001256	-00011	000027	0000	0000	0000	1000	1000	%0981	l01 \$
002361	-00023	000058	0125	0125	0125	0875	0875	%0982	l02 \$
002474	-00024	000105	0250	0250	0250	0750	0750	%0983	l03 \$
005500	-00011	000091	0375	0375	0375	0625	0625	%0984	l04 \$
006723	-00004	000082	0500	0500	0500	0500	0500	%0985	l05 \$
007777	0000004	000448	0625	0625	0625	0375	0375	%0986	l06 \$
008554	0000010	000011	0750	0750	0750	0250	0250	%0987	l07 \$
009347	0000000	000002	0875	0875	0875	0125	0125	%0988	l08 \$
009717	-00014	000006	1000	1000	1000	0000	0000	%0989	l09 \$
001122	-00014	000004	0000	0000	0000	1000	1000	%0990	m01 \$
000656	00029	000005	0125	0125	0125	0875	0875	%0991	m02 \$
000497	-00023	000097	0250	0250	0250	0750	0750	%0992	o03 \$
005405	00010	000073	0375	0375	0375	0625	0625	%0993	m04 \$
006690	-00007	000075	0500	0500	0500	0500	0500	%0994	m05 \$
007732	0000000	000033	0625	0625	0625	0375	0375	%0995	m06 \$
008550	0000008	000004	0750	0750	0750	0250	0250	%0996	m07 \$
009360	0000002	000006	0875	0875	0875	0125	0125	%0997	m08 \$
009719	-00010	000006	1000	1000	1000	0000	0000	%0998	m09 \$
001186	-00014	000011	0000	0000	0000	1000	1000	%0999	n01 \$
002316	-00023	000047	0125	0125	0125	0875	0875	%1000	n02 \$
004162	-00025	000097	0250	0250	0250	0750	0750	%1001	n03 \$
005407	-00012	000073	0375	0375	0375	0625	0625	%1002	n04 \$
006662	-00007	000074	0500	0500	0500	0500	0500	%1003	n05 \$
007720	0000004	000044	0625	0625	0625	0375	0375	%1004	n06 \$
008532	0000012	000005	0750	0750	0750	0250	0250	%1005	n07 \$
009339	0000003	000006	0875	0875	0875	0125	0125	%1006	n08 \$
009715	-00004	000002	1000	1000	1000	0000	0000	%1007	n09 \$
001238	0000005	000025	0000	0000	0000	1000	1000	%1008	k10 \$
001779	0000002	000008	0066	0066	0066	0933	0933	%1009	k11 \$
002849	-00018	000099	0133	0133	0133	0866	0866	%1010	k12 \$
003863	-00015	000103	0200	0200	0200	0800	0800	%1011	k13 \$
004620	-00006	000079							

TUB-test chart HE16; Relative Elementary Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```