

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart HE18; Relative Elementary Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

input: *w setgray*
output: no change compared to input

TUB registration: 20091101-HE18/HE18L0NA.TXT/.PS TUB material application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

009270	000036	-00642	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009223	-00021	-00694	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008855	-00822	-01148	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
008287	-01572	-01746	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
007743	-02103	-02243	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
007249	-02449	-02638	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006713	-02721	-03012	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
00645	-02918	-03400	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005286	-02850	-03722	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
009249	000026	-00552	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
009181	-00003	-00618	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
008800	-00829	-01042	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
008249	-01600	-01593	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
007700	-02165	-02078	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
007199	-02527	-02474	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
006664	-02831	-02832	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
006011	-03031	-03216	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
005248	-03067	-03521	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
008617	-000798	-00439	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
008544	000758	-00463	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
008100	000088	-01045	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
007619	-00813	-01521	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
007143	-01526	-01944	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
006715	-02028	-02310	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
006234	-02487	-02604	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
005650	-02831	-02961	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
004976	-02965	-03221	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
007888	001559	-00957	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
007775	001595	-00109	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
007438	000784	-00556	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
006888	-00065	-01198	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
006452	-00896	-01509	0500	0593	0625	0500	0406	0375	0000	00112	M05	\$
006090	-01519	-01919	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
005679	-02109	-02193	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
005143	-02604	-02522	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
004549	-02891	-02764	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007174	002292	-00047	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
007105	002261	-00046	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
006270	001494	-00016	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
006206	000512	-00615	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
005711	-00239	-01161	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
005378	-00921	-01526	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
004996	-01612	-01801	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
004532	-02228	-02121	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
004004	-02603	-02361	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
006435	003064	000972	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
006341	003099	000883	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
005959	002322	000467	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
005417	001347	-00196	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
004968	000495	-00729	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
004545	-00088	-01250	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
004172	-00854	-01539	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
003760	-01551	-01857	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003302	-02035	-02069	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
005605	003937	001375	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
005589	000398	001339	0875	0406	0500	0125	0593	0750	0000	00136	P02	\$
005203	003224	000871	0750	0375	0250	0250	0625	0625	0000	00137	P03	\$
004650	002233	000206	0625	0343	0250	0375	0656	0750	0000	00138	P04	\$
004136	001424	-00413	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
003761	000724	-00921	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
003342	000934	-01391	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
002952	-00744	-01676	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
002536	-01283	-01897	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
004867	004776	-00216	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
004756	000440	002119	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
004377	004154	-00166	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
003782	002307	000881	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
003309	002350	000212	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
002861	001636	-00398	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
002447	000910	-00938	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
002023	000243	-01439	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
001666	-00388	-01640	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
003976	005571	003941	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
003885	005587	003894	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
003490	005038	003300	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
002926	004062	002439	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
002401	003196	-00162	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
001963	002387	000933	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
001524	001606	000294	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
001141	000791	-00311	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
000846	000140	-00736	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009226	000078	-00660	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
009183	000028	-00714	0906	0875	1000	0093	0125	0000	0000	00406	J11	\$
008564	-00255	-01452	0812	0750	1000	0187	0250	0000	0000	00407	J12	\$
007611	-00216	-02440	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
006688	-00023	-03265	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
005891	-00207	-03912	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
005013	000582	-04548	0347	0250	1000	0562	0750	0000	0000	00411	J16	\$
004613	001568	-05181	0433	0250	1000	0875	0875	0000	0000	00412	J17	\$
003077	001886	-05183	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
002915	000039	-00558	0906	0875	0031	0000	0125	0000	0000	00414	K10	\$
009139	000039	-00648	0875	0875	0875	0125	0125	0125	0000	00415	K11	\$
008372	000023	-01557	081	0750	0875	0218	0250	0125	0000	00416	K12	\$
007425	000058	-02525	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
006520	000199	-03338	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
005686	000497	-04017	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
004810	000892	-04650	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
003818	001475	-05279	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
002848	002288	-05732	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
009163	-00199	-00028	0937	1000	0750	0062	0000	0250	0000	00423	L10	\$
009020	-00367	-00010	08									

Application of the proposed model to the data of the 1990s and 2000s

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG HE08(7)_22.TXT, Separation olv*, D65, not adapted $
%100 x LAB*      %1000 x (r g b c m y o)      %nr.    pos $
%z003612 006686 -00739 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008423 -00457 009798 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z004633 -05962 001817 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005221 -03180 -03354 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z004115 -00408 -04778 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z002523 006378 -05542 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z000860 000156 -00749 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009259 000022 -00630 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%z003612 006686 -00739 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008423 -00457 009798 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z004633 -05962 001817 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005221 -03180 -03354 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z004115 -00408 -04778 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z002523 006378 -05542 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z000860 000156 -00749 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009259 000022 -00630 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%z003612 006686 -00739 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008423 -00457 009798 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z004633 -05962 001817 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005221 -03180 -03354 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z004115 -00408 -04778 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z002523 006378 -05542 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z000860 000156 -00749 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009259 000022 -00630 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%z003976 005571 003941 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z008017 -01349 009321 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z004814 -05472 000385 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z005286 -02850 -03722 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003074 001860 -05618 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z003449 007550 -04360 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z000822 000146 -00711 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009245 000058 -00654 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%z005861 003124 006308 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z006524 -03902 007051 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z004984 -04798 -00980 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z005302 -02865 -03712 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z001773 004544 -06344 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z003696 007903 -04023 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z000842 000140 -00701 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009245 000045 -00644 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%z007532 000855 008579 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z004998 -05754 004761 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005153 -03920 -02354 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z004927 -02048 -04072 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z001814 005593 -06285 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z003665 007478 -03023 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z000864 000143 -00723 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009258 000029 -00621 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG HE08(7)_22.TXT, Separation olv*, D65, not adapted S		1000 x (r g b c m y o)										%nr. pos \$	
%100 x LAB*													
000934	000105	-00706	0000	0000	0000	1000	1000	1000	0000	0000	0000	%0972	k01 \$
000212	000199	-01410	0125	0125	0125	0875	0875	0875	0000	0000	0000	%0977	k02 \$
000342	000059	-01366	0250	0250	0250	0750	0750	0750	0000	0000	0000	%0974	k03 \$
000463	-000096	-01198	0375	0375	0375	0625	0625	0625	0000	0000	0000	%0975	k04 \$
000548	-00213	-01167	0500	0500	0500	0500	0500	0500	0000	0000	0000	%0976	k05 \$
000702	-00118	-01140	0625	0625	0625	0375	0375	0375	0000	0000	0000	%0977	k06 \$
000820	-00015	-00949	0750	0750	0750	0250	0250	0250	0000	0000	0000	%0978	k07 \$
000919	-00025	-00590	0875	0875	0875	0125	0125	0125	0000	0000	0000	%0979	k08 \$
000925	000024	-00022	1000	1000	1000	0000	0000	0000	0000	0000	0000	%0980	k09 \$
000929	000111	-00705	0000	0000	0000	1000	1000	1000	0000	0000	0000	%0981	l01 \$
000211	000206	-01411	0125	0125	0125	0875	0875	0875	0000	0000	0000	%0982	l02 \$
000343	000080	-01395	0250	0250	0250	0750	0750	0750	0000	0000	0000	%0983	l03 \$
000463	-000086	-01213	0375	0375	0375	0625	0625	0625	0000	0000	0000	%0984	l04 \$
000543	-00213	-01167	0500	0500	0500	0500	0500	0500	0000	0000	0000	%0985	l05 \$
000702	-00108	-01158	0625	0625	0625	0375	0375	0375	0000	0000	0000	%0986	l06 \$
000820	-00016	-00953	0750	0750	0750	0250	0250	0250	0000	0000	0000	%0987	l07 \$
000920	-00029	-00587	0875	0875	0875	0125	0125	0125	0000	0000	0000	%0988	l08 \$
000924	000029	-00621	1000	1000	1000	0000	0000	0000	0000	0000	0000	%0989	l09 \$
000920	000121	-00726	0000	0000	0000	1000	1000	1000	0000	0000	0000	%0990	m01 \$
000926	000028	-01426	0125	0125	0125	0875	0875	0875	0000	0000	0000	%0991	m02 \$
000342	000076	-01391	0250	0250	0250	0750	0750	0750	0000	0000	0000	%0992	m03 \$
000462	-00065	-01247	0375	0375	0375	0625	0625	0625	0000	0000	0000	%0993	m04 \$
000542	-00202	-01183	0500	0500	0500	0500	0500	0500	0000	0000	0000	%0994	m05 \$
000701	-00118	-01141	0625	0625	0625	0375	0375	0375	0000	0000	0000	%0995	m06 \$
000820	-00015	-00949	0750	0750	0750	0250	0250	0250	0000	0000	0000	%0996	m07 \$
000915	-00031	-00586	0875	0875	0875	0125	0125	0125	0000	0000	0000	%0997	m08 \$
000925	000023	-00619	1000	1000	1000	0000	0000	0000	0000	0000	0000	%0998	m09 \$
000917	000117	-00707	0000	0000	0000	1000	1000	1000	0000	0000	0000	%0999	n01 \$
000210	000216	-01416	0125	0125	0125	0875	0875	0875	0000	0000	0000	%1000	n02 \$
000342	000076	-01395	0250	0250	0250	0750	0750	0750	0000	0000	0000	%1001	n03 \$
000461	-00066	-01245	0375	0375	0375	0625	0625	0625	0000	0000	0000	%1002	n04 \$
000543	-00214	-01167	0500	0500	0500	0500	0500	0500	0000	0000	0000	%1003	n05 \$
000704	-00112	-01143	0625	0625	0625	0375	0375	0375	0000	0000	0000	%1004	n06 \$
000819	-00011	-00960	0750	0750	0750	0250	0250	0250	0000	0000	0000	%1005	n07 \$
000912	-00033	-00583	0875	0875	0875	0125	0125	0125	0000	0000	0000	%1006	n08 \$
000925	000020	-00617	1000	1000	1000	0000	0000	0000	0000	0000	0000	%1007	n09 \$
000887	000135	-00749	0000	0000	0000	1000	1000	1000	0000	0000	0000	%1008	k10 \$
000144	000278	-01240	0066	0066	0066	0933	0933	0933	0000	0000	0000	%1009	k11 \$
000216	000186	-01434	0133	0133	0133	0866	0866	0866	0000	0000	0000	%1010	k12 \$
000287	000025	-01392	0200	0200	0200	0800	0800	0800	0000	0000	0000	%1011	k13 \$
000359	000029	-01345	0266	0266	0266	0733	0733	0733	0000	0000	0000	%1012	k14 \$
000425	-00033	-01197	0333	0333	0333	0666	0666	0666	0000	0000	0000	%1013	k15 \$
000482	-00146	-01195	0400	0400	0400	0600	0600	0600	0000	0000	0000	%1014	k16 \$
000526	-00216	-01171	0466	0466	0466	0533	0533	0533	0000	0000	0000	%1015	k17 \$
000616	-00249	-01102	0533	0533	0533	0466	0466	0466	0000	0000	0000	%1016	k18 \$
000675	-00148	-01118	0600	0600	0600	0399	0399	0399	0000	0000	0000	%1017	k19 \$
000738	-00022	-01122	0666	0666	0666	0333	0333	0333	0000	0000	0000	%1018	k20 \$
000801	000020	-00998	0733	0733	0733	0266	0266	0266	0000	0000	0000	%1019	k21 \$
000854	000039	-00835	0800	0800	0800	0199	0199	0199	0000	0000	0000	%1020	k22 \$
000915	-00052	-00568	0866	0866	0866	0133	0133	0133	0000	0000	0000	%1021	k23 \$
000920	000014	-00611	0933	0933	0933	0066	0066	0066	0000	0000	0000	%1022	k24 \$
000921	000035	-00624	1000	1000	1000	0000	0000	0000	0000	0000	0000	%1023	k25 \$
000898	000138	-00760	0000	0000	0000	1000	1000	1000	0000	0000	0000	%1024	l10 \$
000144	000285	-01252	0066	0066	0066	0933	0933	0933	0000	0000	0000	%1025	l11 \$
000214	000208	-01465	0133	0133	0133	0866	0866	0866	0000	0000	0000	%1026	l12 \$
000282	000034	-01408	0200	0200	0200	0800	0800	0800	0000	0000	0000	%1027	l13 \$
000355	000033	-01348	0266	0266	0266	0733	0733	0733	0000	0000	0000	%1028	l14 \$
000422	-00015	-01129	0333	0333	0333	0666	0666	0666	0000	0000	0000	%1029	l15 \$
000484	-00137	-01203	0400	0400	0400	0600	0600	0600	0000	0000	0000	%1030	l16 \$
000518	-00225	-01166	0466	0466	0466	0533	0533	0533	0000	0000	0000	%1031	l17 \$
000615	-00245	-01109	0533	0533	0533	0466	0466	0466	0000	0000	0000	%1032	l18 \$
000671	-00150	-01109	0600	0600	0600	0399	0399	0399	0000	0000	0000	%1033	l19 \$
000737	-00022	-01124	0666	0666	0666	0333	0333	0333	0000	0000	0000	%1034	l20 \$
000825	000019	-01000	0733	0733	0733	0266	0266	0266	0000	0000	0000	%1035	l21 \$
000858	000036	-00842	0800	0800	0800	0199	0199	0199	0000	0000	0000	%1036	l22 \$
000915	-00057	-00572	0866	0866	0866	0133	0133	0133	0000	0000	0000	%1037	l23 \$
000924	000016	-00620	0933	0933	0933	0066	0066	0066	0000	0000	0000	%1038	l24 \$
000925	000033	-00622	1000	1000	1000	0000	0000	0000	0000	0000	0000	%1039	l25 \$
000874	000150	-00775	0000	0000	0000	1000	1000	1000	0000	0000	0000	%1040	m10 \$
000143	000302	-01264	0066	0066	0066	0933	0933	0933	0000	0000	0000	%1041	m11 \$
000214	000220	-01479	0133	0133	0133	0866	0866	0866	0000	0000	0000	%1042	m12 \$
000285	000049	-01421	0200	0200	0200	0800	0800	0800	0000	0000	0000	%1043	m13 \$
000357	000032	-01355	0266	0266	0266	0733	0733	0733	0000	0000	0000	%1044	m14 \$
000425	-00016	-01232	0333	0333	0333	0666	0666	0666	0000	0000	0000	%1045	m15 \$
000487	-00134	-01215	0400	0400	0400	0600	0600	0600	0000	0000	0000	%1046	m16 \$
000512	-00209	-01184	0466	0466	0466	0533	0533	0533	0000	0000	0000	%1047	m17 \$
000614	-00247	-01107	0533	0533	0533	0466	0466	0466	0000	0000	0000	%1048	m18 \$
000675	-00157	-01100	0600	0600	0600	0399	0399	0399	0000	0000	0000	%1049	m19 \$
000738	-00024	-01116	0666	0666	0666	0333	0333	0333	0000	0000	0000	%1050	m20 \$
000820	000018	-00996	0733	0733	0733	0266	0266	0266	0000	0000	0000	%1051	m21 \$
000856	000032	-00839	0800	0800	0800	0199	0199	0199	0000	0000	0000	%1052	m22 \$

TUB registration: 20091101-HE18/HE18LONA.TXT/.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

XREG H087 (7). 22.TXT, Separation olv*, d65, adapted \$		Xnrr. pos \$	
\$100 x Lab* A	1000 x (r g b c m y 0)		
009276	-00008 000016 1000 1000 1000 0000 0000 0000	000900 A01 \$	009253 000006 -00009 1000 1000 1000 0000 0000 0000
009235	-00086 -00034 0875 1000 1000 0125 0000 0000 0000	000001 A02 \$	009223 -00068 -00050 0875 1000 1000 0125 0125 0000 0000
008834	-00893 -00533 0750 1000 1000 0250 0000 0000 0000	000002 A03 \$	008784 -00790 -00579 0750 1000 1000 0250 0250 0000 0000
008274	-01662 -01121 0625 1000 1000 0375 0000 0000 0000	000003 A04 \$	007975 -01022 -01437 0625 0625 1000 0375 0375 0000 0000
007726	-02209 -01585 0500 1000 1000 0500 0000 0000 0000	000004 A05 \$	007162 -01076 -02171 0500 0500 1000 0500 0500 0000 0000
007215	-02631 -01872 0375 1000 1000 0625 0000 0000 0000	000005 A06 \$	006432 -01015 -02755 0375 0375 1000 0625 0625 0000 0000
006664	-02984 -02150 0250 1000 1000 0750 0000 0000 0000	000006 A07 \$	005718 -00953 -03261 0250 0250 1000 0750 0750 0000 0000
005984	-03235 -02444 0125 1000 1000 0875 0000 0000 0000	000007 A08 \$	004938 -00891 -03710 0125 0125 1000 0875 0875 0000 0000
005221	-03267 -02666 0000 1000 1000 1000 0000 0000 0000	000008 A09 \$	004115 -00512 -04074 0000 1000 1000 1000 1000 0000 0000
009231	000076 -00041 1000 0875 0875 0000 0125 0125 0000	000009 B01 \$	009222 000006 000091 1000 1000 0875 0000 0125 0000 0000
009178	-00041 000023 0875 0875 0875 0125 0125 0125 0000	000010 B02 \$	009181 -00054 000040 0875 0875 0875 0125 0125 0125 0000
008777	-00927 -00300 0750 0875 0875 0250 0125 0125 0000	000011 B03 \$	008507 -00308 -00771 0750 0750 0875 0250 0250 0125 0000
008215	-01769 -00763 0625 0875 0875 0375 0125 0125 0000	000012 B04 \$	007669 -00519 -01633 0625 0625 0875 0375 0375 0125 0000
007657	-02383 -01144 0500 0875 0875 0500 0125 0125 0000	000013 B05 \$	006865 -00593 -02354 0500 0500 0875 0500 0500 0125 0000
007129	-02842 -01445 0375 0875 0875 0625 0125 0125 0000	000014 B06 \$	006155 -00561 -02923 0375 0375 0875 0625 0625 0125 0000
006576	-03239 -01681 0250 0875 0875 0750 0125 0125 0000	000015 B07 \$	005451 -00513 -03427 0250 0250 0875 0750 0750 0125 0000
005903	-03525 -01966 0125 0875 0875 0875 0125 0125 0000	000016 B08 \$	004637 -00340 -03908 0125 0125 0875 0875 0875 0125 0000
005147	-03647 -02127 0000 0875 0875 1000 0125 0125 0000	000017 B09 \$	003923 -00038 -04253 0000 0000 0875 1000 1000 0125 0000
004619	-03109 -01004 1000 0750 0750 0000 0250 0250 0000	000018 C01 \$	009164 -00223 009336 1000 1000 0750 0000 0250 0000
004849	000035 -00190 0500 0750 0750 0125 0250 0000 0000	000019 C02 \$	009063 -00186 000812 0875 0875 0750 0125 0125 0000
008102	000030 -00381 0750 0570 0750 0250 0250 0250 0000	000020 C03 \$	008123 000008 00341 0750 0750 0250 0250 0250 0000
007580	-00951 -00717 0625 0750 0750 0375 0250 0250 0000	000021 C04 \$	007295 -00237 -01258 0625 0625 0750 0375 0375 0250 0000
007087	-01751 -00979 0500 0750 0750 0500 0250 0250 0000	000022 C05 \$	006501 -00346 -02035 0500 0500 0750 0500 0500 0250 0000
006635	-02370 -01180 0375 0750 0750 0625 0250 0250 0000	000023 C06 \$	005817 -00359 -02649 0375 0375 0750 0625 0625 0250 0000
006155	-02921 -01359 0250 0750 0750 0750 0250 0250 0000	000024 C07 \$	005104 -00265 -03231 0250 0250 0750 0750 0750 0250 0000
005550	-03419 -01551 0125 0750 0750 0875 0250 0250 0000	000025 C08 \$	004299 -00079 -03765 0125 0125 0750 0875 0875 0250 0000
004854	-03685 -01699 0000 0750 0750 1000 0250 0250 0000	000026 C09 \$	003435 000448 -04191 0000 0000 0750 1000 1000 0250 0000
007793	002098 -00548 1000 0625 0625 0000 0375 0375 0000	000027 D01 \$	009079 -00501 002184 1000 1000 0625 0000 0000 0375 0000
007723	001921 -00253 0875 0625 0625 0125 0375 0375 0000	000028 D02 \$	008957 -00426 002009 0875 0875 0625 0125 0125 0375 0000
007362	000953 -00333 0750 0625 0625 0250 0375 0375 0000	000029 D03 \$	008016 -00308 000827 0750 0750 0625 0250 0250 0375 0000
006872	-00140 -00540 0625 0625 0625 0375 0375 0375 0000	000030 D04 \$	006908 -00155 -00474 0625 0625 0625 0375 0375 0375 0000
006399	-01085 -00711 0500 0625 0625 0500 0375 0375 0000	000031 D05 \$	006129 -00361 -01307 0500 0500 0625 0500 0500 0375 0000
006028	-01824 -00854 0375 0625 0625 0625 0375 0375 0000	000032 D06 \$	005411 -00311 -02062 0375 0375 0625 0625 0625 0375 0000
005588	-02531 -00964 0250 0625 0625 0750 0375 0375 0000	000033 D07 \$	004692 -00226 -02714 0250 0250 0625 0750 0750 0375 0000
005054	-03172 -01135 0125 0625 0625 0875 0375 0375 0000	000034 D08 \$	003854 000069 -03384 0125 0125 0625 0875 0875 0375 0000
004449	-03564 -01275 0000 0625 0625 1000 0375 0375 0000	000035 D09 \$	003086 000477 -03826 0000 0000 0625 1000 1000 0375 0000
006989	003046 -00551 1000 0500 0500 0000 0500 0500 0000	000036 E01 \$	008986 -00703 003541 1000 1000 0500 0000 0000 0500 0000
006950	002838 -00714 0875 0500 0500 0125 0500 0500 0000	000037 E02 \$	008828 -00586 003347 0875 0875 0500 0125 0125 0500 0000
006604	001779 -00214 0750 0500 0500 0250 0500 0500 0000	000038 E03 \$	007896 -00556 002120 0750 0750 0500 0250 0250 0500 0000
006131	000714 -00390 0625 0500 0500 0375 0500 0500 0000	000039 E04 \$	006771 -00551 000748 0625 0625 0500 0375 0375 0500 0000
005691	-00312 -00805 0500 0500 0500 0500 0500 0500 0000	000040 E05 \$	005716 -00295 -00804 0500 0500 0500 0500 0500 0500 0000
005345	-01113 -00670 0375 0500 0500 0625 0500 0500 0000	000041 E06 \$	004992 -00348 -01266 0375 0375 0500 0625 0625 0500 0000
004942	-01907 -00793 0250 0500 0500 0750 0500 0500 0000	000042 E07 \$	004198 -00182 -02075 0250 0250 0500 0750 0750 0500 0000
004618	-02007 -00604 0250 0500 0500 0500 0500 0500 0000	000043 E08 \$	003915 -00157 -02075 0250 0250 0500 0500 0500 0500 0000
003925	-03180 -01004 0000 0500 0500 1000 0500 0500 0000	000044 E09 \$	002622 000463 -03277 0000 0000 0500 1000 1000 0500 0000
003614	003993 -00427 1000 0375 0375 0000 0625 0625 0000	000045 F01 \$	008890 -00811 004875 1000 1000 0375 0000 0000 0625 0000
003135	003804 -00116 0875 0375 0375 0125 0625 0625 0000	000046 F02 \$	008698 -00649 004618 0875 0875 0375 0125 0125 0625 0000
005794	-02901 -00178 0750 0375 0375 0250 0625 0625 0000	000047 F03 \$	007786 -00727 003424 0750 0750 0375 0250 0250 0625 0000
005308	-001753 -00403 0625 0375 0375 0375 0625 0625 0000	000048 F04 \$	006654 -00852 001999 0625 0625 0375 0375 0375 0625 0000
004878	000721 -00511 0500 0375 0375 0500 0625 0625 0000	000049 F05 \$	005588 -00721 000693 0500 0500 0375 0500 0500 0625 0000
004513	-00180 -00598 0375 0375 0375 0625 0625 0625 0000	000050 F06 \$	004503 -00180 -00571 0375 0375 0375 0625 0625 0625 0000
004132	-01053 -00691 0250 0375 0375 0750 0625 0625 0000	000051 F07 \$	003765 -00189 -01371 0250 0250 0375 0750 0750 0625 0000
003669	-01881 -00778 0125 0375 0375 0875 0625 0625 0000	000052 F08 \$	002945 000004 -02155 0125 0125 0375 0875 0875 0625 0000
003231	-02460 -00902 0000 0375 0375 1000 0625 0625 0000	000053 F09 \$	002173 000447 -02716 0000 0000 0375 1000 1000 0625 0000
005347	004896 -00362 1000 0250 0250 0000 0750 0750 0000	000054 G01 \$	008787 -00833 006129 1000 1000 0250 0000 0000 0750 0000
005384	-004727 -00037 0875 0250 0250 0125 0750 0750 0000	000055 G02 \$	008561 -00623 005809 0875 0875 0250 0125 0125 0750 0000
005091	003887 -00089 0750 0250 0250 0250 0750 0750 0000	000056 G03 \$	007652 -00770 004638 0750 0750 0250 0250 0250 0750 0000
004482	-002779 -00330 0625 0250 0250 0375 0750 0750 0000	000057 G04 \$	006565 -01026 003230 0625 0625 0250 0375 0375 0750 0000
004054	-001744 -00433 0500 0250 0250 0500 0750 0750 0000	000058 G05 \$	005466 -00973 001827 0500 0500 0250 0500 0500 0750 0000
003700	000841 -00608 0375 0250 0250 0625 0750 0750 0000	000059 G06 \$	004386 -00531 000509 0375 0375 0250 0625 0625 0750 0000
003320	-00073 -00732 0250 0250 0250 0750 0750 0750 0000	000060 G07 \$	003300 -00043 -00719 0250 0250 0250 0750 0750 0750 0000
002998	-00984 -00775 0125 0250 0250 0875 0750 0750 0000	000061 G08 \$	002490 000082 -01555 0125 0125 0250 0875 0875 0750 0000
002490	-01627 -00834 0000 0250 0250 1000 0750 0750 0000	000062 G09 \$	001700 000603 -02257 0000 0000 0250 1000 1000 0750 0000
004517	005850 -00278 1000 0125 0125 1000 0875 0875 0000	000063 H01 \$	008755 -00777 007755 1000 1000 0125 0000 0000 0875 0000
004479	005678 000003 0875 0125 0125 0125 0875 0875 0000	000064 H02 \$	008425 -00548 007413 0875 0875 0125 0125 0125 0875 0000
004137	-004953 000009 0750 0125 0125 0250 0875 0875 0000	000065 H03 \$	007528 -00758 006257 0750 0750 0125 0250 0250 0875 0000
003617	003920 -00304 0625 0125 0125 0375 0875 0875 0000	000066 H04 \$	006436 -01154 004810 0625 0625 0125 0375 0375 0875 0000
003172	-002937 -00603 0500 0125 0125 0500 0875 0875 0000	000067 H05 \$	005337 -01107 003300 0500 0500 0125 0500 0500 0875 0000
002869	-00054 -00007 0000 0375 0375 1000 0875 0875 0000	000068 H06 \$	004222 -00876 000000 0375 0375 0125 0875 0875 0875 0000
002407	-001060 -00706 0250 0125 0125 0750 0875 0875 0000	000069 H07 \$	003585 -00505 000575 0250 0250 0125 0750 0750 0875 0000
002029	000129 00066 0125 0125 0125 0875 0875 0875 0000	000070 H08 \$	002001 000146 -00766 0125 0125 0125 0875 0875 0875 0000
001660	-00661 -00717 0000 0125 0125 1000 0875 0875 0000	000071 H09 \$	001223 000571 -01529 0000 0000 0125 1000 1000 0875 0000
003612	006574 -00029 1000 0000 0000 0000 1000 1000 0000	000072 T01 \$	008423 -00493 010441 1000 1000 0000 0000 0000 1000 0000
003576	006423 000289 0875 0000 0000 0125 1000 1000 0000	000073 T02 \$	008185 -00281 010071 0875 0875 0000 0125 0125 1000 0000
003261	-005758 000348 0750 0000 0000 0250 1000 1000 0000	000074 T03 \$	007351 -00574 008916 0750 0750 0000 0250 0250 1000 0000
002766	000486 000039 0625 0000 0000 0375 1000 1000 0000	000075 T04 \$	006253 -01080 007335 0625 0625 0000 0375 0375 1000 0000
002310	-003850 -00211 0500 0000 0000 0500 1000 1000 0000	000076 T05 \$	005156 -01280 005791 0500 0500 0000 0500 0500 1000 0000
001914	002948 -00352 0375 0000 0000 0625 1000 1000 0000	000077 T06 \$	004047 -01145 004245 0375 0375 0000 0625 0625 1000 0000
001528	-001975 -00306 0250 0000 0000 0750 1000 1000 0000	000078 T07 \$	002952 -00956 002756 0250 0250 0000 0750 0750 1000 0000
001163	000920 -00167 0125 0000 0000 0875 1000 1000 0000	000079 T08 \$	001786 -00528 001172 0125 0125 0000 0875 0875 1000 0000
000884	-00008 -00031 0000 0000 0000 1000 1000 1000 0000	000080 T09 \$	000849 000024 -00054 0000 0000 0000 1000 1000 1000 0000

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-HE18/HE18L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IOB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NA.TXT> / .PS
Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=

099276	-00021	000011	1000	1000	1000	0000	0000	0000	0000	00801	J01 \$	009226	00049	00019	-00006	1000	1000	0000	0000	0000	0000	%0405	J10 \$
099273	-00080	-00039	0875	0968	1000	0125	0031	0000	0000	00802	J02 \$	009183	-00029	-00059	0906	0875	1000	0093	0125	0000	0000	%0406	J11 \$
008855	-00884	-00491	0750	0937	1000	0250	0062	0000	0000	00803	J03 \$	008564	-00320	-00793	0812	0750	1000	0187	0250	0000	0000	%0407	J12 \$
008287	-01640	-01085	0625	0996	1000	0375	0093	0000	0000	00804	J04 \$	007611	-00292	-01775	0718	0625	1000	0281	0375	0000	0000	%0408	J13 \$
007743	-02177	-01579	0500	0875	1000	0500	0125	0000	0000	00805	J05 \$	006688	-00108	-02593	0625	0500	1000	0375	0500	0000	0000	%0409	J14 \$
007249	-02528	-01971	0375	0843	1000	0625	0156	0000	0000	00806	J06 \$	005691	000113	-013235	0531	0375	1000	0468	0625	0000	0000	%0410	J15 \$
006713	-02805	-02341	0250	0812	1000	0750	0187	0000	0000	00807	J07 \$	005013	000479	-03865	0437	0250	1000	0562	0750	0000	0000	%0411	J16 \$
006045	-03002	-02724	0125	0781	1000	0875	0218	0000	0000	00808	J08 \$	004003	001043	-04491	0343	0125	1000	0656	0875	0000	0000	%0412	J17 \$
005286	-02949	-03041	0000	0750	1000	1000	0250	0000	0000	00809	J09 \$	003074	001743	-04922	0250	0000	1000	0750	1000	0000	0000	%0413	J18 \$
009249	-00031	000101	1000	0996	0875	0000	0093	0125	0000	00900	K01 \$	009215	-00018	000095	0968	1000	0875	0031	0000	0125	0000	%0414	K10 \$
009181	-00062	000035	0875	0875	0875	0875	0125	0125	0125	00901	K02 \$	009139	-00019	000006	0875	0875	0875	0125	0125	0125	0000	%0415	K11 \$
008800	-00891	-00385	0750	0843	0875	0250	0156	0125	0000	00902	K03 \$	008372	-00043	-00897	0871	0750	0875	0218	0250	0125	0000	%0416	K12 \$
008249	-01668	-00932	0625	0812	0875	0375	0187	0125	0000	00903	K04 \$	007425	-00018	-01859	0687	0625	0875	0312	0375	0125	0000	%0417	K13 \$
007700	-02239	-01413	0500	0781	0875	0500	0218	0125	0000	00904	K05 \$	006520	000112	-02665	0593	0500	0875	0406	0500	0125	0000	%0418	K14 \$
007199	-02607	-01806	0375	0750	0875	0625	0250	0125	0000	00905	K06 \$	005686	000401	-03338	0500	0375	0875	0500	0625	0125	0000	%0419	K15 \$
006164	-02916	-02160	0250	0718	0875	0750	0250	0125	0000	00906	K07 \$	005480	000787	-03966	0406	0250	0875	0593	0750	0125	0000	%0420	K16 \$
006091	-03123	-02840	0125	0687	0875	0875	0312	0125	0000	00907	K08 \$	003248	001359	-04588	0312	0125	0875	0687	0875	0125	0000	%0421	K17 \$
005248	-03107	-02540	0000	0656	0875	1000	0343	0125	0000	00908	K09 \$	002848	002162	-05034	0218	0000	0875	0781	1000	0125	0000	%0422	K

TUB-test chart HE18; Relative Elementary Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

009264	-00012	000010	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
009223	-00079	-00033	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
008853	-00875	-00492	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
008302	-01624	-01077	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
007766	-02167	-01565	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
007262	-02519	-01964	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
006741	-02806	-02322	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
00668	-03000	-02714	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$
005302	-02955	-03040	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
009261	-00045	000119	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
009188	-00905	000044	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
008770	-00794	-00471	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
008162	-01435	-01124	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
007572	-01888	-01670	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
007056	-02176	-02099	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
006513	-02428	-02482	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
005858	-02630	-02852	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
005113	-02626	-03148	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
009039	000016	000750	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
008754	000374	000411	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
008141	000093	-00357	0750	0750	0750	0250	0500	0250	0000	%0182	U03	\$
007583	-00763	-00967	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
007057	-01310	-01500	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
006590	-01682	-01943	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
006091	-02012	-02328	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
005482	-02285	-02721	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
004808	-02381	-03013	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
008538	000443	001411	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
008267	000759	001109	0875	0750	0625	0125	0250	0375	0000	%0190	V02	\$
007658	000361	000328	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
006939	-00172	-00480	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
006446	-00841	-01026	0500	0562	0625	0500	0437	0375	0000	%0193	V05	\$
006022	-01327	-01455	0375	0500	0625	0625	0500	0375	0000	%0194	V06	\$
005573	-01734	-01872	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
005003	-02067	-02325	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
004395	-02249	-02627	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
008029	000871	002196	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
007734	001215	001853	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
007187	000679	001177	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
006457	000083	000312	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
005776	-00339	-00447	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
005372	-00879	-00922	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$
004943	-01356	-01888	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
004395	-01798	-01824	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
003833	-02022	-02175	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
007528	001342	002935	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
007237	001643	002603	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
006673	001136	001293	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
005941	000432	001080	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
005247	000000	000244	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
004594	-00213	-00501	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
004165	-00762	-00995	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
003671	-01285	-01460	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
003146	-01542	-01847	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
007029	001839	003693	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
006722	002169	003347	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
006141	001677	002615	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
005377	000900	001693	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
004689	000500	000831	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
004064	000160	000093	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
003411	-00096	-00662	0250	0250	0250	0750	0750	0750	0000	%0222	Y07	\$
002921	-00666	-01134	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
002440	-00951	-01562	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
006471	002399	004793	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
006168	002724	004461	0875	0500	0125	0125	0500	0875	0000	%0226	Z02	\$
005549	002291	003678	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
004791	001521	002712	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
004060	001018	001761	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
003419	000596	000936	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
002747	000281	001013	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
002074	000076	-00714	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
001627	-00271	-01154	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$
005861	003040	006976	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
005557	003357	006596	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
004947	002928	005736	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
004122	002183	004582	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
003397	001555	003524	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
002702	001089	002527	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
002057	000635	001584	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
001364	000300	000637	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$
000866	000002	-00040	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009234	000014	-00004	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
009183	-00019	-00069	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
008830	000147	-01074	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
007190	000467	-02178	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
006185	000829	-03036	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
005175	001450	-03816	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
004087	002218	-04566	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
002933	000151	-05252	0562	0250	1000	0875	0500	0000	0000	%0493	S17	\$
001773	000415	-05548	0500	0000	1000	0500	1000	0000	0000	%0494	S18	\$
009232	-00022	000106	0937	1000	0875	0062	0100	0125	0000	%0495	T10	\$
009160	-00025	000021	0875	0875	0875	0125	0125	0125	0000	%0496	T11	\$
008273	000148	-01009	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
007157	000484	-02123	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
006125	000853	-03024	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
005073	001539	-03836	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
004035	002250	-04556	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
002866	003231	-05238	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
001706	004491	-05639	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
009113	-00425	000874	0875	1000	0750	0125	0000	0250	0000	%0504	U10	\$
008920	-00698	000619	0812	0875	0750	0187	0125	0250	0000</			

009290	-00016	000019	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
009245	-00076	-00033	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008868	-00867	-00490	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
008305	-01588	-01085	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
007659	-01919	-01684	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
007048	-02001	-02202	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$
006418	-02147	-02650	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
005697	-02237	-03072	0125	0343	1000	0875	0656	0000	0000	%0250	b08	\$
004827	-02136	-03398	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
003282	-00047	000118	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
002911	-00062	000046	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
008660	-00536	-00616	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
007948	-00961	-01372	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
007298	-01276	-01967	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
006713	-01446	-02450	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
006102	-01556	-02891	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
005408	-01698	-03284	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
004684	-01667	-03564	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
002327	-00276	-000935	1000	0937	0750	0000	0062	0250	0000	%0261	d01	\$
008949	000044	006028	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
008175	-00006	-00353	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$
007492	-00485	-01125	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
006852	-00030	-01756	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
006303	-01046	-02263	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
005734	-01261	-02712	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
005052	-01372	-03169	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
004323	-01311	-03491	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
009110	-00472	002112	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
008660	000120	001579	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
007872	000013	000562	0750	0718	0625	0250	0281	0375	0000	%0272	e03	\$
006985	-00152	-00504	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
006389	-00096	-01160	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
005823	-00955	-01718	0375	0437	0625	0625	0562	0375	0000	%0275	e06	\$
005243	-01044	-02265	0250	0343	0625	0750	0656	0375	0000	%0276	e07	\$
004575	-01164	-03798	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
003858	-01066	-02177	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
008802	-00328	-003173	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
008379	000219	002648	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
007580	000059	001611	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
006682	-00250	-000539	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
005814	-03088	-00477	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
005244	-00584	-01103	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
004662	-00835	-01689	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
004001	-00960	-02293	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
003333	-00914	-02719	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
008501	-00124	004225	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
008047	000435	003637	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
007284	000163	002675	0750	0656	0375	0250	0343	0625	0000	%0290	g03	\$
006376	-00255	-001581	0625	0562	0375	0375	0437	0625	0000	%0291	g04	\$
005470	-00350	-000490	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
004631	-00214	-00502	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
004033	-00479	-01175	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
003404	-00727	-01777	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
002748	-00674	-02254	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
002077	000115	005297	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
007714	000703	004641	0875	0718	0250	0125	0281	0750	0000	%0298	h02	\$
006965	000375	003692	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
006020	-00119	-002556	0625	0531	0250	0375	0437	0750	0000	%0300	h04	\$
005125	-00292	-001405	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
004259	-00211	-000346	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
003400	-00801	-00665	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
002749	-00301	-01366	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
002121	-00251	-01895	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
007871	000433	006697	1000	0781	0125	0000	0218	0875	0000	%0306	i01	\$
007427	000933	006094	0875	0687	0125	0125	0312	0875	0000	%0307	i02	\$
006657	000593	005112	0750	0593	0125	0250	0406	0875	0000	%0308	i03	\$
005667	000108	003828	0625	0500	0125	0375	0500	0875	0000	%0309	i04	\$
004738	-00131	-002610	0500	0406	0125	0500	0593	0875	0000	%0310	i05	\$
003909	-00218	-001483	0375	0312	0125	0625	0687	0875	0000	%0311	i06	\$
003000	-00134	-000362	0250	0218	0125	0750	0781	0875	0000	%0312	i07	\$
002077	000078	-00704	0125	0125	0125	0875	0875	0875	0000	%0313	i08	\$
001446	000145	-01354	0000	0031	0125	1000	0968	0875	0000	%0314	i09	\$
007532	000802	009221	1000	0750	0000	0000	0250	1000	0000	%0315	j01	\$
007092	001272	008608	0875	0656	0000	0125	0343	1000	0000	%0316	j02	\$
006322	000953	007517	0750	0562	0000	0250	0437	1000	0000	%0317	j03	\$
005288	000404	006063	0625	0468	0000	0375	0531	1000	0000	%0318	j04	\$
004321	000103	004695	0500	0375	0000	0500	0625	1000	0000	%0319	j05	\$
003461	-00120	-003473	0375	0281	0000	0625	0718	1000	0000	%0320	j06	\$
002559	-00216	-002209	0250	0187	0000	0750	0812	1000	0000	%0321	j07	\$
001628	-00159	-000955	0125	0093	0000	0875	0906	1000	0000	%0322	j08	\$
000887	-00003	-000229	0000	0000	0000	1000	1000	1000	0000	%0323	j09	\$
009237	000014	000000	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
009199	000085	-00048	0875	1000	0031	0125	0000	0000	0000	%0568	b11	\$
008407	000635	-00954	0937	0750	0062	0250	0000	0000	0000	%0569	b12	\$
007358	001176	-02007	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$
006292	001751	-02936	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
005205	002539	-03769	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
004161	003440	-04479	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
003006	004508	-05148	0781	0250	1000	0218	0875	0000	0000	%0574	b17	\$
001814	005462	-05573	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
009231	-00040	000099	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$
009164	-00027	000020	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$
008334	000426	-00942	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
007292	000953	-01194	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
006229	001556	-02921	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
005137	002355	-03769	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
004090	003258	-04494	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$
002937	004362	-05170	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
001770	005389	-05587	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
000890	-00921	000545	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$
008801	-00961	000431	0781	0875	0750	0218	0125	0250	0000	%0586	d11	\$
008												

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG HE08(7)_22.TXT, Separation olv*, D65, adapted $
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr.    pos $
%Z003612 006574 -00029 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008423 -00493 010441 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z004633 -06058 002514 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005221 -03267 -02666 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z004115 -00512 -04074 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z002523 006248 -04816 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z000860 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009259 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z003612 006574 -00029 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008423 -00493 010441 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z004633 -06058 002514 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005221 -03267 -02666 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z004115 -00512 -04074 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z002523 006248 -04816 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z000860 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009259 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z003612 006574 -00029 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008423 -00493 010441 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z004633 -06058 002514 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005221 -03267 -02666 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z004115 -00512 -04074 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z002523 006248 -04816 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z000860 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009259 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z003976 005457 004631 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008017 -01420 009984 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z004814 -05577 001069 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005286 -02949 -03041 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003074 001743 -04922 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z003449 007431 -03666 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z000822 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009245 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z005861 003040 006976 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006524 -03978 007714 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z004984 -04891 -00306 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z005302 -02955 -03040 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z001773 004415 -05648 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z003696 007794 -03340 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z000842 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009245 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z007532 000802 009221 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z004998 -05841 005434 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005153 -04005 -01682 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z004927 -02136 -03398 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z001814 005462 -05573 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z003665 007373 -02334 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z000864 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009258 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG HE08(7)_22.TXT, Separation olv*, D65, adapted \$		1000 x (r g b c m y o)										%nr. pos \$	
%100 x LAB*a													
000934	-00043	-00004	0000	0000	0000	1000	1000	1000	0000			%0972	k01 \$
002112	000068	-00720	0125	0125	0125	0875	0875	0875	0000			%0973	k02 \$
003422	-00053	-00690	0250	0250	0250	0750	0750	0750	0000			%0974	k03 \$
004638	-00192	-00537	0375	0375	0375	0625	0625	0625	0000			%0975	k04 \$
005846	-00292	-00518	0500	0500	0500	0500	0500	0500	0000			%0976	k05 \$
007029	-00179	-00505	0625	0625	0625	0375	0375	0375	0000			%0977	k06 \$
008207	-00059	-00327	0750	0750	0750	0250	0250	0250	0000			%0978	k07 \$
009199	-00055	-00021	0875	0875	0875	0125	0125	0125	0000			%0979	k08 \$
009258	000005	-00011	1000	1000	1000	0000	0000	0000	0000			%0980	k09 \$
009929	-00037	-00002	0000	0000	0000	1000	1000	1000	0000			%0981	l01 \$
002111	000074	-00721	0125	0125	0125	0875	0875	0875	0000			%0982	l02 \$
003431	-00032	-00720	0250	0250	0250	0750	0750	0750	0000			%0983	l03 \$
004633	-00182	-00552	0375	0375	0375	0625	0625	0625	0000			%0984	l04 \$
005843	-00291	-00518	0500	0500	0500	0500	0500	0500	0000			%0985	l05 \$
007027	-00169	-00523	0625	0625	0625	0375	0375	0375	0000			%0986	l06 \$
008210	-00061	-00331	0750	0750	0750	0250	0250	0250	0000			%0987	l07 \$
009201	-00059	-00023	0875	0875	0875	0125	0125	0125	0000			%0988	l08 \$
009264	000000	-00010	1000	1000	1000	0000	0000	0000	0000			%0989	l09 \$
009920	-00027	-00023	0000	0000	0000	1000	1000	1000	0000			%0990	m01 \$
002096	000086	-00736	0125	0125	0125	0875	0875	0875	0000			%0991	m02 \$
003421	-00036	-00716	0250	0250	0250	0750	0750	0750	0000			%0992	m03 \$
004626	-00160	-00585	0375	0375	0375	0625	0625	0625	0000			%0993	m04 \$
005825	-00281	-00535	0500	0500	0500	0500	0500	0500	0000			%0994	m05 \$
007011	-00179	-00506	0625	0625	0625	0375	0375	0375	0000			%0995	m06 \$
008203	-00059	-00327	0750	0750	0750	0250	0250	0250	0000			%0996	m07 \$
009195	-00061	-00025	0875	0875	0875	0125	0125	0125	0000			%0997	m08 \$
009257	-00005	-00008	1000	1000	1000	0000	0000	0000	0000			%0998	m09 \$
009917	-00031	-00005	0000	0000	0000	1000	1000	1000	0000			%0999	n01 \$
002102	000084	-00726	0125	0125	0125	0875	0875	0875	0000			%1000	n02 \$
003412	-00036	-00720	0250	0250	0250	0750	0750	0750	0000			%1001	n03 \$
004614	-00162	-00583	0375	0375	0375	0625	0625	0625	0000			%1002	n04 \$
005833	-00292	-00518	0500	0500	0500	0500	0500	0500	0000			%1003	n05 \$
007004	-00174	-00508	0625	0625	0625	0375	0375	0375	0000			%1004	n06 \$
008191	-00056	-00337	0750	0750	0750	0250	0250	0250	0000			%1005	n07 \$
009192	-00063	-00027	0875	0875	0875	0125	0125	0125	0000			%1006	n08 \$
009250	-00009	-00006	1000	1000	1000	0000	0000	0000	0000			%1007	n09 \$
009887	-00013	-00046	0000	0000	0000	1000	1000	1000	0000			%1008	k10 \$
001448	000137	-00543	0066	0066	0066	0933	0933	0933	0000			%1009	k11 \$
002186	000055	-00745	0133	0133	0133	0866	0866	0866	0000			%1010	k12 \$
002876	-00095	-00710	0200	0200	0200	0800	0800	0800	0000			%1011	k13 \$
003594	-00081	-00672	0266	0266	0266	0733	0733	0733	0000			%1012	k14 \$
004256	-00134	-00531	0333	0333	0333	0666	0666	0666	0000			%1013	k15 \$
004892	-00238	-00536	0400	0400	0400	0600	0600	0600	0000			%1014	k16 \$
005526	-00299	-00519	0466	0466	0466	0533	0533	0533	0000			%1015	k17 \$
006161	-00322	-00457	0533	0533	0533	0466	0466	0466	0000			%1016	k18 \$
006758	-00213	-00480	0600	0600	0600	0399	0399	0399	0000			%1017	k19 \$
007380	-00078	-00490	0666	0666	0666	0333	0333	0333	0000			%1018	k20 \$
008017	-00026	-00374	0733	0733	0733	0266	0266	0266	0000			%1019	k21 \$
008594	-00001	-00217	0800	0800	0800	0199	0199	0199	0000			%1020	k22 \$
009155	-00082	-00043	0866	0866	0866	0133	0133	0133	0000			%1021	k23 \$
009280	-00014	-00001	0933	0933	0933	0066	0066	0066	0000			%1022	k24 \$
009261	000006	-00014	1000	1000	1000	0000	0000	0000	0000			%1023	k25 \$
009898	-00010	-00057	0000	0000	0000	1000	1000	1000	0000			%1024	l10 \$
001447	000144	-00555	0066	0066	0066	0933	0933	0933	0000			%1025	l11 \$
002174	000077	-00776	0133	0133	0133	0866	0866	0866	0000			%1026	l12 \$
002882	-00085	-00727	0200	0200	0200	0800	0800	0800	0000			%1027	l13 \$
003595	-00077	-00673	0266	0266	0266	0733	0733	0733	0000			%1028	l14 \$
004252	-00116	-00533	0333	0333	0333	0666	0666	0666	0000			%1029	l15 \$
004894	-00228	-00544	0400	0400	0400	0600	0600	0600	0000			%1030	l16 \$
005518	-00307	-00514	0466	0466	0466	0533	0533	0533	0000			%1031	l17 \$
006158	-00319	-00464	0533	0533	0533	0466	0466	0466	0000			%1032	l18 \$
006771	-00215	-00471	0600	0600	0600	0399	0399	0399	0000			%1033	l19 \$
007397	-00078	-00493	0666	0666	0666	0333	0333	0333	0000			%1034	l20 \$
008025	-00027	-00376	0733	0733	0733	0266	0266	0266	0000			%1035	l21 \$
008598	-00002	-00223	0800	0800	0800	0199	0199	0199	0000			%1036	l22 \$
009155	-00087	-00039	0866	0866	0866	0133	0133	0133	0000			%1037	l23 \$
009264	-00012	-00009	0933	0933	0933	0066	0066	0066	0000			%1038	l24 \$
009259	000003	-00011	1000	1000	1000	0000	0000	0000	0000			%1039	l25 \$
008874	000001	-00071	0000	0000	0000	1000	1000	1000	0000			%1040	m10 \$
001432	000160	-00567	0066	0066	0066	0933	0933	0933	0000			%1041	m11 \$
002154	000089	-00789	0133	0133	0133	0866	0866	0866	0000			%1042	m12 \$
002865	-00071	-00739	0200	0200	0200	0800	0800	0800	0000			%1043	m13 \$
003579	-00078	-00682	0266	0266	0266	0733	0733	0733	0000			%1044	m14 \$
004250	-00117	-00566	0333	0333	0333	0666	0666	0666	0000			%1045	m15 \$
004871	-00226	-00556	0400	0400	0400	0600	0600	0600	0000			%1046	m16 \$
005512	-00292	-00531	0466	0466	0466	0533	0533	0533	0000			%1047	m17 \$
006143	-00321	-00462	0533	0533	0533	0466	0466	0466	0000			%1048	m18 \$
006750	-00222	-00461	0600	0600	0600	0399	0399	0399	0000			%1049	m19 \$
007382	-00080	-00485	0666	0666	0666	0333	0333	0333	0000			%1050	m20 \$
008020	-00028	-00372	0733	0733	0733	0266	0266	0266	0000			%1051	m21 \$
008586	-00006	-00221	0800	0800	0800	0199	0199	0199	0000			%1052	m22 \$

TUB registration: 20091101-HE18/HE18L0NA.TXT /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

009260	00026	-00663	1000	1000	0000	0000	0000	0000	#0081	J01 \$
009121	-00095	-00718	0875	0968	1000	0125	0031	0000	#0082	J02 \$
008818	-01006	-01216	0750	0937	1000	0250	0062	0000	#0083	J03 \$
008224	-01896	-01858	0625	0906	1000	0375	0093	0000	#0084	J04 \$
007659	-02553	-02390	0500	0875	1000	0500	0125	0000	#0085	J05 \$
007149	-03008	-02811	0375	0843	1000	0625	0156	0000	#0086	J06 \$
006598	-03394	-03209	0250	0812	1000	0750	0187	0000	#0087	J07 \$
005915	-03712	-03621	0125	0781	1000	0875	0218	0000	#0088	J08 \$
005146	-03754	-03959	0000	0750	1000	1000	0250	0000	#0089	J09 \$
009241	-00025	-00571	1000	0906	0875	0000	0093	0125	#0090	K01 \$
009171	-00066	-00640	0875	0875	0875	0125	0125	0125	#0091	K02 \$
008765	-00999	-01107	0750	0843	0875	0250	0156	0125	#0092	K03 \$
008188	-01902	-01702	0625	0812	0875	0375	0187	0125	#0093	K04 \$
007618	-02590	-02222	0500	0781	0875	0500	0218	0125	#0094	K05 \$
007101	-03062	-02644	0375	0750	0875	0625	0250	0125	#0095	K06 \$
006551	-03477	-03026	0250	0718	0875	0750	0281	0125	#0096	K07 \$
005884	-03802	-03435	0125	0687	0875	0875	0312	0125	#0097	K08 \$
005110	-03879	-03735	0000	0656	0875	1000	0343	0125	#0098	K09 \$
004900	-04000	-03800	0000	0625	0750	0875	0375	0125	#0099	L01 \$
008552	-00057	-00444	0875	0781	0812	0125	0218	0250	#0100	L02 \$
008092	00032	-01065	0750	0750	0750	0250	0250	0250	#0101	L03 \$
007575	-01060	-01589	0625	0718	0750	0375	0281	0250	#0102	L04 \$
007076	-01894	-02052	0500	0687	0750	0500	0312	0250	#0103	L05 \$
006629	-02507	-02450	0375	0656	0750	0625	0343	0250	#0104	L06 \$
006132	-03072	-02772	0250	0607	0750	0750	0375	0250	#0105	L07 \$
005532	-03542	-03158	0125	0593	0750	0875	0406	0250	#0106	L08 \$
004847	-03775	-03439	0000	0562	0750	1000	0437	0250	#0107	L09 \$
007920	001649	000009	0000	0718	0625	0000	0281	0375	#0108	M01 \$
007807	001679	-00041	0875	0687	0625	0125	0312	0375	#0109	M02 \$
007436	000768	-00531	0750	0656	0625	0250	0343	0375	#0110	M03 \$
006865	-00221	-01222	0625	0625	0625	0375	0375	0375	#0111	M04 \$
006404	-01168	-01657	0500	0593	0625	0500	0406	0375	#0112	M05 \$
006203	-01897	-02021	0375	0562	0625	0625	0437	0375	#0113	M06 \$
005594	-02594	-02328	0250	0531	0625	0750	0468	0375	#0114	M07 \$
005040	-03215	-02690	0125	0500	0625	0875	0500	0375	#0115	M08 \$
004443	-03603	-02956	0000	0468	0625	1000	0531	0375	#0116	M09 \$
007230	002471	000590	1000	0625	0500	0000	0375	0500	#0117	N01 \$
007160	002436	000573	0875	0593	0500	0125	0406	0500	#0118	N02 \$
006750	001577	000054	0750	0562	050					

TUB-test chart HE18; Relative Elementary Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

009255	-00029	-00655	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$	
009211	-00105	-00703	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$	
008816	-01009	-01207	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$	
008239	-01888	-01840	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$	
007682	-02551	-02366	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$	
007162	-03098	-02794	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$	
006627	-03400	-03100	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$	
005935	-03716	-03600	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$	
005162	-03769	-03949	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$	
009253	-00050	-00545	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$	
009178	-00072	-00622	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$	
008736	-00920	-01181	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$	
008102	-01696	-01880	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$	
007492	-02273	-02462	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$	
006960	-02670	-02919	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$	
006402	-03032	-03329	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$	
005732	-03353	-03728	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$	
004976	-03445	-04048	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$	
009042	-00097	-00010	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$	
008758	-000435	-00228	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$	
008124	-00054	-01030	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$	
007540	-00956	-01688	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$	
006991	-01628	-02261	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$	
006506	-02114	-02736	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$	
005992	-02559	-03151	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$	
005366	-02960	-03577	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$	
004679	-03158	-03897	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$	
008559	-000627	-000792	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$	
008290	-009228	-000498	0875	0750	0875	0625	0125	0250	0375	0000	%0190	V02	\$
007660	-000419	-00314	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$	
006916	-00249	-01164	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$	
006399	-01044	-01754	0500	0562	0625	0500	0437	0375	0000	%0193	V05	\$	
005956	-01642	-02218	0375	0500	0625	0625	0625	0375	0000	%0194	V06	\$	
005488	-02168	-02668	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$	
004900	-02644	-03157	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$	
004277	-02934	-03488	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$	
008069	-001159	-001605	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$	
007777	-001487	-001272	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$	
007209	-000858	-000562	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$	
006453	-000136	-00344	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$	
005750	-00412	-01141	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$	
005325	-01064	-01651	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$	
004876	-01659	-02153	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$	
004308	-02048	-02627	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$	
003730	-02592	-03009	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$	
007587	-001716	-002371	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$	
007299	-002002	-002048	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$	
006715	-001408	-001336	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$	
005956	-000600	-000450	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$	
005240	-000050	-00421	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$	
004568	-00279	-01194	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$	
004117	-00951	-01727	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$	
003602	-01618	-02232	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$	
003060	-02006	-02652	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$	
007098	-002282	-003154	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$	
006804	-002598	-002819	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$	
006203	-002034	-002058	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$	
005412	-001920	-001892	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$	
004701	-000655	-000196	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$	
004057	-000210	-00571	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$	
003384	-00177	-01357	0250	0250	0250	0750	0750	0750	0000	%0222	Y07	\$	
002871	-00883	-01872	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$	
002372	-01308	-02333	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$	
006571	-002909	-004278	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$	
006272	-003221	-003959	0875	0500	0125	0125	0125	0800	0875	0000	%0226	Z02	\$
005635	-002727	-003152	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$	
004850	-001877	-002142	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$	
004097	-001288	-001159	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$	
003435	-000777	-000303	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$	
002742	-000349	-00558	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$	
002048	-00004	-01408	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$	
001581	-00406	-01885	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$	
005988	-003601	-006463	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$	
005689	-003904	-006101	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$	
005062	-003427	-005222	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$	
004211	-002620	-004032	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$	
003462	-001934	-002943	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$	
002747	-001409	-001922	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$	
002082	-000884	-000951	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$	
001370	-000450	-00021	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$	
000853	-000038	-00727	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$	
009224	-00002	-00670	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$	
009171	-00047	-00737	0875	1000	0062	0125	0000	0000	0000	%0487	S11	\$	
008727	-00010	-01758	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$	
008244	-00045	-02878	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$	
006130	-000359	-03750	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$	
005109	-000840	-04537	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$	
004008	-001454	-05299	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$	
002843	-00232	-05998	0562	0250	1000	0875	0500	0000	0000	%0493	S17	\$	
001564	-003432	-06420	0500	0000	1000	0500	1000	0000	0000	%0494	S18	\$	
009223	-00026	-00557	0937	1000	0875	0062	0000	0125	0000	%0495	T01	\$	
009150	-00040	-00644	0875	0875	0125	0125	0125	0000	0000	%0496	T11	\$	
008248	-000000	-01692	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$	
007116	-000173	-02820	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$	
006070	-000387	-03736	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$	
005008	-000930	-04555	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$	
003957	-001490	-05288	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$	
002772	-002317	-05992	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$	
001598	-003515	-06408	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$	
009108	-003555	-000209	0875	1000	0750	0125	0000	0250	0000	%0504	U10	\$	
008995	-00673	-00062	0812	0875	0750	0187	0125	0250	0000	%0505	U11	\$	
008160	-00												

009281	-00046	-00622	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
009233	-00117	-00680	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008832	-01014	-01183	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
008243	-01865	-01828	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
007578	-02320	-02464	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
006945	-02512	-03097	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$
006308	-02776	-03484	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
005572	-02982	-03937	0125	0343	1000	0875	0656	0000	0000	%0250	b08	\$
004791	-02988	-04290	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
003274	-00667	-00523	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
002901	-00901	-00597	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
008628	-00681	-01300	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
007893	-01245	-02098	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
007223	-01687	-02729	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
006623	-01970	-03240	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
005998	-02197	-03710	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
005288	-02465	-04137	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
004551	-02529	-04445	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
002327	-02027	-00301	1000	0937	0750	0000	0062	0250	0000	%0261	d01	\$
008950	000008	000000	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
008158	-00078	-01009	0750	0750	0750	0250	0500	0250	0000	%0263	d03	\$
007451	-00697	-01825	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
006791	-01172	-02493	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
006225	-01506	-03032	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
005639	-01845	-03513	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
004940	-02094	-04005	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
004198	-02137	-04357	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
009122	-00284	-00149	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
008677	-00290	-00969	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
007871	-00068	-00075	0750	0718	0875	0625	0250	0281	0375	%0272	e03	\$
006962	-00242	-01177	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
006344	-00816	-01874	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
005680	-01194	-02464	0375	0437	0625	0625	0562	0375	0000	%0275	e06	\$
005162	-01518	-03044	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$
004476	-01791	-03615	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
003745	-01806	-04022	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
008831	-00932	-02568	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
008412	000499	002047	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
007596	000241	000991	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
006674	-00199	-00128	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
005787	-00392	-01165	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
005199	-00788	-01824	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
004598	-01174	-02445	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
003918	-01458	-03086	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
003234	-01540	-03543	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
008545	000260	003634	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
008095	000087	003060	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
007315	000453	002069	0750	0656	0375	0250	0343	0625	0000	%0290	g03	\$
006489	-00076	-000937	0625	0656	0375	0375	0437	0625	0000	%0291	g04	\$
005354	-00293	-00182	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
004605	-00286	-01196	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
003988	-00687	-01905	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
003338	-01092	-02546	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
002666	-01177	-03054	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
008265	000573	004716	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
007778	001150	004075	0875	0718	0250	0125	0281	0750	0000	%0298	h02	\$
007012	000754	003099	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
006051	000161	001924	0500	0531	0250	0500	0468	0375	0000	%0300	h04	\$
005129	-00118	-000746	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
004248	-00153	-00333	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
003373	-00176	-01368	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
002709	-00545	-02108	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
002055	-00640	-02668	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
007945	001458	006120	1000	0781	0125	0000	0218	0875	0000	%0306	i01	\$
007507	001955	005533	0875	0687	0125	0125	0312	0875	0000	%0307	i02	\$
006720	001056	004525	0750	0593	0125	0250	0406	0875	0000	%0308	i03	\$
005707	000489	003206	0625	0500	0125	0375	0500	0875	0000	%0309	i04	\$
004760	000615	001963	0500	0406	0125	0500	0593	0875	0000	%0310	i05	\$
003915	-00107	-000816	0375	0312	0125	0625	0687	0875	0000	%0311	i06	\$
002991	-00053	-00323	0250	0218	0125	0750	0781	0875	0000	%0312	i07	\$
002051	-00002	-01414	0125	0125	0125	0875	0875	0875	0000	%0313	i08	\$
001402	-00091	-02094	0000	0031	0125	1000	0968	0875	0000	%0314	i09	\$
007626	001372	008613	1000	0750	0000	0000	0250	1000	0000	%0315	j01	\$
007191	001840	008019	0750	0656	0000	0125	0343	1000	0000	%0316	j02	\$
006406	001481	006910	0750	0562	0000	0250	0437	1000	0000	%0317	j03	\$
005349	000873	005427	0625	0468	0000	0375	0531	1000	0000	%0318	j04	\$
004365	000515	004042	0500	0375	0000	0500	0625	1000	0000	%0319	j05	\$
003489	000232	002806	0375	0281	0000	0625	0718	1000	0000	%0320	j06	\$
002573	000061	001529	0250	0187	0000	0750	0812	1000	0000	%0321	j07	\$
001628	000012	000261	0125	0093	0000	0875	0906	1000	0000	%0322	j08	\$
000873	000034	-00738	0000	0000	0000	1000	1000	1000	0000	%0323	j09	\$
009228	-00016	-00643	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
009191	000052	-00689	0800	0875	1000	0031	0125	0000	0000	%0568	b11	\$
008394	000512	-01595	0937	0750	1000	0062	0250	0000	0000	%0569	b12	\$
007335	000920	-02655	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$
006261	001360	-03593	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
005168	002021	-04428	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
004120	002807	-05138	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
002919	003749	-05867	0781	0250	1000	0218	0875	0000	0000	%0574	b17	\$
001755	004589	-06252	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
009223	-00061	-00542	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$
009155	-00057	-00623	0875	0875	0125	0125	0125	0000	0000	%0577	c11	\$
008316	000293	-01592	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
007265	000686	-02653	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
006193	001155	-03588	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
005095	001823	-04439	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
004042	002603	-05166	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$
002883	003581	-05848	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
001706	004504	-06278	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
000870	-00931	-00125	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$
008778	-00986	-00244	0781	0875	0750	0218	0125	0250	0000	%0586	d11	\$
008181	-00113											

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG HE08(7)_22.TXT, Separation olv*, D50, not adapted $
%100 x LAB*          %1000 x (r g b c m y o)          %nr.   pos $
%z003782 006739 -00347 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008501 000054 009774 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z004554 -06029 001620 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005085 -04028 -03588 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z003985 -01425 -04960 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z002550 005648 -05350 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z000847 000051 -00735 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009249 -00039 -00652 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W1 7 $
%S
%z003782 006739 -00347 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008501 000054 009774 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z004554 -06029 001620 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005085 -04028 -03588 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z003985 -01425 -04960 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z002550 005648 -05350 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z000847 000051 -00735 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009249 -00039 -00652 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W2 7 $
%S
%z003782 006739 -00347 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008501 000054 009774 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z004554 -06029 001620 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005085 -04028 -03588 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z003985 -01425 -04960 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z002550 005648 -05350 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z000847 000051 -00735 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009249 -00039 -00652 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W001 7 $
%S
%z004154 005900 004266 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z008074 -00880 009259 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z004720 -05726 000186 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z005146 -03754 -03959 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z002953 000778 -05752 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z003567 007132 -04007 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z000810 006048 -00696 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009235 -00005 -00674 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %W251 7 $
%S
%z005988 003601 006463 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z006519 -03572 006898 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z004876 -05256 -01187 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z005162 -03769 -03949 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z001664 003433 -06420 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z003836 007560 -03630 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z000830 000043 -00686 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009236 -00017 -00665 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %W501 7 $
%S
%z007626 001372 008613 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z004948 -05580 004555 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005029 -04601 -02574 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z004791 -02988 -04290 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z001755 004589 -06252 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z003817 007277 -02628 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z000851 000043 -00708 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009248 -00031 -00642 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %W751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG HE08(7)_22.TXT, Separation olv, D50, not adapted S																									
%100 x LAB*																									
1000 x (r g b c m y o)																									
000921	000007	-00693	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$	000143	-00122	-00584	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$
002086	-00007	-01412	0125	0125	0125	0875	0875	0875	0000	%0973	k02	\$	009269	-00048	-00636	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$
003396	-00132	-01375	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$	009255	-00030	-00642	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$
004612	-00262	-01215	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$	000845	000041	-00771	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$
005819	-00377	-01191	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	001398	000118	-01256	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$
006997	-00268	-01165	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$	002124	000012	-01492	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$
008190	-00127	-00972	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$	002815	-00146	-01448	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$
009189	-00085	-00612	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$	003531	-00152	-01362	0266	0266	0266	0733	0733	0733	0000	%1060	n14	\$
009248	-00026	-00643	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$	004210	-00197	-01234	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$
009916	000013	-00691	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$	004832	-00319	-01218	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$
002085	-00001	-01412	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$	005472	-00390	-01190	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$
003404	-00116	-01405	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$	006103	-00412	-01122	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$
004607	-00254	-01229	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$	006724	-00296	-01134	0600	0600	0600	0399	0399	0399	0000	%1065	n19	\$
005816	-00376	-01191	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	007354	-00162	-01139	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$
007004	-00260	-01183	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$	008006	-00009	-01015	0733	0733	0733	0266	0266	0266	0000	%1067	n21	\$
008193	-00130	-00977	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$	008585	-00062	-00846	0800	0800	0800	0199	0199	0199	0000	%1068	n22	\$
009191	-00089	-00610	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$	009139	-00122	-00587	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$
009255	-00031	-00643	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$	009266	-00050	-00636	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$
009906	000020	-00712	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$	009256	-00029	-00641	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$
002071	000008	-01427	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$	000857	-000853	-00688	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$
003394	-00119	-01401	0250	0250	0250	0750	0750	0750	0000	%0992	k03	\$	009242	-00031	-00631	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$
004600	-00237	-01263	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$	003760	-006750	-00262	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
005799	-00368	-01208	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$	005139	-00400	-03558	0000	1000	1000	1000	0000	0000	0000	%1075	l27	\$
006988	-00268	-01166	0625	0625	0625	0375	0375	0375	0000	%0995	m06	\$	008544	000097	010017	1000	1000	0000	0000	0000	1000	0000	%1076	m26	\$
008186	-00127	-00972	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$	003998	-01346	-04991	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$
009185	-00091	-00609	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$	004580	-006508	-001787	0000	1000	0000	0000	0000	1000	0000	%1078	n26	\$
009247	-00036	-00641	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$	002602	005693	-05313	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$
009904	000019	-00693	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$													
002076	000007	-01416	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$	%z003760	006750	-00262	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
003385	-00120	-01405	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$	%z008544	000097	010017	1000	0000	0000	0000	0000	1000	0000	%1076	m26	\$
004588	-00238	-01261	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$	%z004580	-006058	-001787	0000	1000	0000	0000	0000	1000	0000	%1078	n28	\$
005806	-00378	-01192	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$	%z005139	-00400	-03558	0000	1000	1000	1000	0000	0000	0000	%1075	l27	\$
006981	-00262	-01168	0625	0625	0625	0375	0375	0375	0000	%1004	n06	\$	%z003998	-01346	-04991	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$
008174	-00125	-00983	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$	%z002602	005693	-05313	1000	0000	0000	1000	0000	0000	%1079	n29	\$	
009182	-00093	-00606	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$	%z000857	-000853	-00688	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$
009240	-00040	-00639	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$	%z009242	-00031	-00631	1000	1000	0000	0000	0000	0000	0000	%1073	k27	\$
009874	000031	-00736	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$													
001427	000097	-01232	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$	%z000897	000019	-00715	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$
002159	-00026	-01437	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$	%z009250	-00026	-00644	1000	1000	0000	0000	0000	0000	0000	%0980	k00	\$
002848	-00179	-01402	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$	%z000990	000022	-00719	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$
003568	-00160	-01356	0266	0266	0266	0733	0733	0733	0000	%1012	k14	\$	%z009252	-00030	-00643	1000	1000	0000	0000	0000	0000	0000	%0989	l09	\$
004232	-00197	-01209	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$													
004865	-00314	-01213	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$	%z000884	000031	-00736	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$
005499	-00382	-01195	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$	%z009251	-00033	-00641	1000	1000	0000	0000	0000	0000	0000	%0998	m08	\$
006136	-00404	-01128	0533	0533	0533	0466	0466	0466	0000	%1016	k18	\$													
006734	-00297	-01142	0600	0600	0600	0399	0399	0399	0000	%1017	k19	\$													
007359	-00163	-01144	0666	0666	0666	0333	0333	0333	0000	%1018	k20	\$													
008000	-00097	-01020	0733	0733	0733	0266	0266	0266	0000	%1019	k21	\$	%z000875	000030	-00732	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$
008581	-00052	-00856	0800	0800	0800	0199	0199	0199	0000	%1020	k22	\$	%z009248	-00034	-00640	1000	1000	0000	0000	0000	0000	0000	%1007	n00	\$
009145	-00111	-00590	0866	0866	0866	0133	0133	0133	0000	%1021	k23	\$													
009271	-00045	-00633	0933	0933	0933	0066	0066	0066	0000	%1022	k24	\$													
009251	-00026	-00645	1000	1000	1000	0000	0000	0000	0000	%1023	k25	\$													
009885	000032	-00747	0000	0000	0000	1000	1000	1000	0000	%1024	l10	\$													
001426	000102	-01244	0066	0066	0066	0933	0933	0933	0000	%1025	l11	\$													
002147	-00008	-01468	0133	0133	0133	0866	0866	0866	0000	%1026	l12	\$													
002854	-00172	-01418	0200	0200	0200	0800	0800	0800	0000	%1027	l														

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NA.TXT> / .PS
 Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=

TUB registration: 20091101-HE18/HE18L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

#BEG H087#(T) .22.TXT, Separation olv*, d50, adapted \$			#nr. pos \$		
#100 x Lab*s	sep x (r g b c m y o)				
009267	-00006	000016	1000 1000 1000 0000 0000 0000	%0000 A01 \$	009243 000005 -00009 1000 1000 1000 0000 0000 0000
009222	-00096	-00039	0875 1000 1000 0125 0000 0000 0000	%0001 A02 \$	009211 -00079 -00054 0875 0875 1000 0125 0125 0000 0000
008796	-01019	-00582	0750 1000 1000 0250 0000 0000 0000	%0002 A03 \$	008747 -00917 -00625 0750 0750 1000 0250 0250 0000 0000
008210	-01926	-01218	0625 1000 1000 0375 0000 0000 0000	%0003 A04 \$	007917 -01301 -01513 0625 0625 1000 0375 0375 0000 0000
007641	-02593	-01718	0500 1000 1000 0500 0000 0000 0000	%0004 A05 \$	007087 -01500 -02271 0500 0500 1000 0500 0500 0000 0000
007115	-03108	-02032	0375 1000 1000 0625 0000 0000 0000	%0005 A06 \$	006343 -01570 -02873 0375 0375 1000 0625 0625 0000 0000
006550	-03560	-02336	0250 1000 1000 0750 0000 0000 0000	%0006 A07 \$	005615 -01640 -03400 0250 0250 1000 0750 0750 0000 0000
005857	-03919	-02654	0125 1000 1000 0875 0000 0000 0000	%0007 A08 \$	004819 -01719 -03870 0125 0125 1000 0875 0875 0000 0000
005085	-04034	-02894	0000 1000 1000 1000 0000 0000 0000	%0008 A09 \$	003985 -01443 -04255 0000 0000 1000 1000 1000 0000 0000
009222	000075	-00039	1000 0875 0875 0000 0125 0125 0000	%0009 B01 \$	009214 000019 000094 1000 1000 0875 0000 0125 0000
009168	-00040	000022	0875 0875 0875 0125 0125 0125 0000	%0010 B02 \$	009170 -00052 000038 0875 0875 0875 0125 0125 0125 0000
008743	-01022	-00344	0750 0875 0875 0250 0125 0125 0000	%0011 B03 \$	008476 -00435 -00800 0750 0750 0875 0250 0250 0125 0000
008155	-01892	-00854	0625 0875 0875 0375 0125 0125 0000	%0012 B04 \$	007617 -00802 -01692 0625 0625 0875 0375 0375 0125 0000
007578	-02701	-01269	0500 0875 0875 0500 0125 0125 0000	%0013 B05 \$	006915 -01023 -02438 0500 0500 0875 0500 0500 0125 0000
007033	-03254	-01600	0375 0875 0875 0625 0125 0125 0000	%0014 B06 \$	006071 -01123 -03063 0375 0375 0875 0625 0625 0125 0000
006468	-03741	-01861	0250 0875 0875 0750 0125 0125 0000	%0015 B07 \$	005352 -01211 -03553 0250 0250 0875 0750 0750 0125 0000
005782	-04130	-02169	0125 0875 0875 0875 0125 0125 0000	%0016 B08 \$	004522 -01182 -04059 0125 0125 0875 0875 0875 0125 0000
005018	-04322	-02347	0000 0875 0875 1000 0125 0125 0000	%0017 B09 \$	003697 -00903 -04422 0000 0000 0875 1000 1000 0125 0000
004508	-04614	-02510	0000 0750 0750 1000 0250 0250 0000	%0018 C01 \$	003164 -01117 000046 1000 1000 0750 0000 0250 0250 0000
003850	-00066	-01350	0500 0750 0750 0125 0250 0250 0000	%0019 C02 \$	002964 -00903 000082 0875 0875 0750 0125 0125 0250 0000
003085	-00020	-00348	0750 0750 0750 0250 0250 0250 0000	%0020 C03 \$	008107 -00937 -00345 0750 0750 0750 0250 0250 0250 0000
007537	-01109	-00771	0625 0750 0750 0375 0250 0250 0000	%0021 C04 \$	007257 -00401 -01293 0625 0625 0750 0375 0375 0250 0000
007023	-02005	-01073	0500 0750 0750 0500 0250 0250 0000	%0022 C05 \$	006443 -00701 -02097 0500 0500 0750 0500 0500 0250 0000
006554	-02707	-01305	0375 0750 0750 0625 0250 0250 0000	%0023 C06 \$	005743 -00852 -02734 0375 0375 0750 0625 0625 0250 0000
006059	-03343	-01513	0250 0750 0750 0750 0250 0250 0000	%0024 C07 \$	005014 -00995 -03338 0250 0250 0750 0750 0750 0250 0000
005441	-03935	-01734	0125 0750 0750 0875 0250 0250 0000	%0025 C08 \$	004192 -00874 -03898 0125 0125 0750 0875 0875 0250 0000
004735	-04275	-01903	0000 0750 0750 1000 0250 0250 0000	%0026 C09 \$	003316 -00459 -04342 0000 0000 0750 1000 1000 0250 0000
007819	-002143	-00460	1000 0625 0625 0000 0375 0375 0000	%0027 D01 \$	009992 -00275 002206 1000 1000 0625 0000 0000 0375 0000
007750	-001996	-00168	0875 0625 0625 0125 0375 0375 0000	%0028 D02 \$	008968 -00213 002031 0875 0875 0625 0125 0125 0375 0000
007366	-000961	-00293	0750 0625 0625 0250 0375 0375 0000	%0029 D03 \$	008012 -00216 000833 0750 0750 0625 0250 0250 0375 0000
006849	-00224	-00553	0625 0625 0375 0375 0375 0000	%0030 D04 \$	006885 -00229 -00486 0625 0625 0625 0375 0375 0375 0000
006352	-01254	-00769	0500 0625 0625 0500 0375 0375 0000	%0031 D05 \$	006885 -00586 -01348 0500 0500 0625 0500 0500 0375 0000
005964	-02078	-00946	0375 0625 0625 0625 0375 0375 0000	%0032 D06 \$	005351 -00684 -02125 0375 0375 0625 0625 0625 0375 0000
005507	-02854	-01089	0250 0625 0625 0750 0375 0375 0000	%0033 D07 \$	004615 -00751 -02800 0250 0250 0625 0750 0750 0375 0000
004958	-03591	-01293	0125 0625 0625 0875 0375 0375 0000	%0034 D08 \$	003759 -00629 -03496 0125 0125 0625 0875 0875 0375 0000
004342	-04059	-01458	0000 0625 0625 1000 0375 0375 0000	%0035 D09 \$	002978 -00347 -03958 0000 0000 0625 1000 1000 0375 0000
007037	-003135	-00416	1000 0500 0500 0000 0500 0500 0000	%0036 E01 \$	009011 -00366 003572 1000 1000 0500 0000 0000 0500 0000
007000	-002965	-00041	0875 0500 0500 0125 0500 0500 0000	%0037 E02 \$	008853 -00258 003379 0875 0875 0500 0125 0125 0500 0000
006631	-001951	-00128	0750 0500 0500 0250 0500 0500 0000	%0038 E03 \$	007905 -00333 002137 0750 0750 0500 0250 0250 0500 0000
006129	-000702	-00360	0625 0500 0500 0375 0500 0500 0000	%0039 E04 \$	006761 -00478 000744 0625 0625 0500 0375 0375 0500 0000
005663	-00400	-00524	0500 0500 0500 0500 0500 0500 0000	%0040 E05 \$	005689 -00382 -00522 0500 0500 0500 0500 0500 0500 0000
005298	-01281	-00728	0375 0500 0500 0625 0500 0500 0000	%0041 E06 \$	004948 -00572 -01307 0375 0375 0500 0625 0625 0500 0000
004876	-02157	-00888	0250 0500 0500 0750 0500 0500 0000	%0042 E07 \$	004138 -00570 -02136 0250 0250 0500 0750 0750 0500 0000
004308	-02593	-01001	0000 0500 0500 1000 0250 0250 0000	%0043 E08 \$	003601 -00504 -02136 0000 0000 0500 1000 1000 0250 0000
003830	-03595	-01162	0000 0500 0500 1000 0500 0500 0000	%0044 E09 \$	002529 -00233 -03385 0000 0000 0500 1000 1000 0500 0000
006239	-004131	-00238	1000 0375 0375 0000 0625 0625 0000	%0045 F01 \$	008927 -00307 000411 1000 1000 0375 0000 0000 0625 0000
006211	-003971	-00068	0875 0375 0375 0125 0625 0625 0000	%0046 F02 \$	008735 -00233 004658 0875 0875 0375 0125 0125 0625 0000
005845	-003019	-00039	0750 0375 0375 0250 0625 0625 0000	%0047 F03 \$	007808 -00396 003447 0750 0750 0375 0250 0250 0625 0000
005328	-001791	-00325	0625 0375 0375 0375 0625 0625 0000	%0048 F04 \$	006655 -00650 002000 0625 0625 0375 0375 0375 0625 0000
004872	-006091	-00483	0500 0375 0375 0500 0625 0625 0000	%0049 F05 \$	005572 -00659 000681 0500 0500 0375 0500 0500 0625 0000
004486	-00276	-00614	0375 0375 0375 0625 0625 0625 0000	%0050 F06 \$	004476 -00271 -00586 0375 0375 0375 0625 0625 0625 0000
004085	-01225	-00747	0250 0375 0375 0750 0625 0625 0000	%0051 F07 \$	003721 -00434 -01410 0250 0250 0375 0750 0750 0625 0000
003603	-02140	-00873	0125 0375 0375 0875 0625 0625 0000	%0052 F08 \$	002882 -00423 -02219 0125 0125 0375 0875 0875 0625 0000
003151	-02805	-01027	0000 0375 0375 1000 0625 0625 0000	%0053 F09 \$	002095 -00128 -02798 0000 0000 0375 1000 1000 0625 0000
005489	-005058	-00118	1000 0250 0250 0000 0750 0750 0000	%0054 G01 \$	008835 -00345 006167 1000 1000 0250 0000 0000 0750 0000
005447	-004919	-00203	0875 0250 0250 0125 0750 0750 0000	%0055 G02 \$	008609 -00142 005853 0875 0875 0250 0125 0125 0750 0000
005081	-004040	-00105	0750 0250 0250 0250 0750 0750 0000	%0056 G03 \$	007685 -00360 004665 0750 0750 0250 0250 0250 0750 0000
004529	-002863	-00197	0625 0250 0250 0375 0750 0750 0000	%0057 G04 \$	006577 -00720 003235 0625 0625 0250 0375 0375 0750 0000
004073	-001773	-00354	0500 0250 0250 0500 0750 0750 0000	%0058 G05 \$	005462 -00789 001820 0500 0500 0250 0500 0500 0750 0000
003695	-000801	-00577	0375 0250 0250 0625 0750 0750 0000	%0059 G06 \$	004371 -00479 000501 0375 0375 0250 0625 0625 0750 0000
003291	-00190	-00748	0250 0250 0250 0750 0750 0750 0000	%0060 G07 \$	003272 -00156 -00733 0250 0250 0250 0750 0750 0750 0000
002859	-01181	-00833	0125 0250 0250 0875 0750 0750 0000	%0061 G08 \$	002443 -00208 -01593 0125 0125 0250 0875 0875 0750 0000
002427	-01900	-00924	0000 0250 0250 1000 0750 0750 0000	%0062 G09 \$	001639 000142 -02312 0000 0000 0250 1000 1000 0750 0000
004652	-006013	-000933	1000 0125 0125 1000 0875 0875 0000	%0063 H01 \$	008715 -00232 007788 1000 1000 0125 0000 0000 0875 0000
004615	-005874	-000412	0875 0125 0125 0125 0875 0875 0000	%0064 H02 \$	008487 -00006 007454 0875 0875 0125 0125 0125 0875 0000
004251	-005118	-00075	0750 0125 0125 0250 0875 0875 0000	%0065 H03 \$	007574 -00269 006281 0750 0750 0125 0250 0250 0875 0000
003697	-004023	-00102	0625 0125 0125 0375 0875 0875 0000	%0066 H04 \$	006461 -00750 004811 0625 0625 0125 0375 0375 0875 0000
003222	-002900	-00060	0500 0125 0125 0500 0875 0875 0000	%0067 H05 \$	00534 -00886 003350 0500 0500 0125 0500 0500 0875 0000
002803	-001008	-00668	0250 0125 0125 0750 0875 0875 0000	%0068 H06 \$	003152 -00748 000573 0250 0250 0750 0875 0875 0000
002402	-001008	-00668	0250 0125 0125 0750 0875 0875 0000	%0069 H07 \$	003132 -00748 000568 0250 0250 0750 0875 0875 0000
002092	-000805	-00777	0125 0125 0125 0875 0875 0875 0000	%0070 H08 \$	001974 000022 -00776 0125 0125 0125 0875 0875 0000
001616	-00844	-00764	0000 0125 0125 1000 0875 0875 0000	%0071 H09 \$	001183 000276 -01553 0000 0000 0125 1000 1000 0875 0000
003782	-006719	-00359	1000 0000 0000 0000 1000 1000 0000	%0072 T01 \$	008501 000068 010434 1000 1000 0000 0000 0000 1000 0000
003746	-006595	-00673	0875 0000 0000 0125 1000 1000 0000	%0073 T02 \$	008264 000298 010073 0875 0875 0000 0125 0125 1000 0000
007412	-005919	-00091	0750 0000 0000 0250 1000 1000 0000	%0074 T03 \$	007415 -00031 000904 0750 0750 0000 0250 0250 1000 0000
002883	-004922	-003018	0625 0000 0000 0375 1000 1000 0000	%0075 T04 \$	006295 -00605 007305 0625 0625 0000 0375 0375 1000 0000
002394	-003927	-00003	0500 0000 0000 0500 1000 1000 0000	%0076 T05 \$	005182 -00859 005757 0500 0500 0000 0500 0500 1000 0000
001970	-002994	-00195	0375 0000 0000 0625 1000 1000 0000	%0077 T06 \$	004062 -00792 004221 0375 0375 0000 0625 0625 1000 0000
001558	-002005	-00205	0250 0000 0000 0750 1000 1000 0000	%0078 T07 \$	002957 -00684 002741 0250 0250 0000 0750 0750 1000 0000
001168	-000937	-00123	0125 0000 0000 0875 1000 1000 0000	%0079 T08 \$	001781 -00378 001167 0125 0125 0000 0875 0875 1000 0000
000870	-00013	-00033	0000 0000 0000 1000 1000 1000 0000	%0080 T09 \$	000836 000014 -00054 0000 0000 0000 1000 1000 1000 0000

TUB-test chart HE18; Relative Elementary Colour System O
1080 spectral reflexions R $\rightarrow$ LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

TUB registration: 20091101-HE18/HE18L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IUB material: code=rna4ta

TUB-test chart HE18; Relative Elementary Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

099260	000221	000010	1000	1000	0000	0000	0000	0000	#0081	J01 \$
099121	-009090	-000403	0875	0968	1000	0125	0031	0000	#0082	J02 \$
008818	-010064	-005040	0750	0937	1000	0250	0062	0000	#0083	J03 \$
008224	-018998	-011806	0625	0906	1000	0375	0093	0000	#0084	J04 \$
007659	-025558	-017111	0500	0875	1000	0500	0125	0000	#0085	J05 \$
007149	-030161	-021311	0375	0843	1000	0625	0156	0000	#0086	J06 \$
006598	-034066	-025227	0250	0812	1000	0750	0187	0000	#0087	J07 \$
005915	-037228	-029308	0125	0781	1000	0875	0218	0000	#0088	J08 \$
005146	-037775	-032723	0000	0750	1000	1000	0250	0000	#0089	J09 \$
009241	-000191	000102	0000	0906	0875	0000	0093	0125	#0090	K01 \$
009171	-000611	000034	0875	0875	0875	0125	0125	0125	#0091	K02 \$
008765	-009097	-000431	0750	0843	0875	0250	0156	0125	#0092	K03 \$
008188	-019093	-01024	0625	0812	0875	0375	0187	0125	#0093	K04 \$
007618	-025955	-015430	0500	0781	0875	0500	0218	0125	#0094	K05 \$
007101	-030971	-019664	0375	0750	0875	0625	0250	0125	#0095	K06 \$
006551	-034899	-023444	0250	0718	0875	0750	0281	0125	#0096	K07 \$
005884	-038181	-027511	0125	0687	0875	0875	0312	0125	#0097	K08 \$
005110	-039891	-030701	0000	0656	0875	1000	0343	0125	#0098	K09 \$
004901	-040000	-030000	0000	0625	0750	0000	0000	0000	#0099	L01 \$
008552	-000758	000232	0875	0781	0875	0125	0128	0250	#0100	L02 \$
008092	000034	-003807	0500	0750	0750	0250	0250	0250	#0101	L03 \$
007575	-010606	-000100	0625	0718	0750	0375	0281	0250	#0102	L04 \$
007076	-019093	-013720	0500	0687	0750	0500	0312	0250	#0103	L05 \$
006632	-025118	-017608	0375	0656	0750	0625	0343	0250	#0104	L06 \$
006129	-030807	-020809	0250	0607	0750	0750	0375	0250	#0105	L07 \$
005532	-035611	-024773	0125	0593	0750	0875	0406	0250	#0106	L08 \$
004847	-037908	-027550	0000	0562	0750	1000	0437	0250	#0107	L09 \$
007920	001646	000687	1000	0718	0625	0000	0281	0375	#0108	M01 \$
007807	001675	000636	0875	0687	0625	0125	0131	0375	#0109	M02 \$
007436	000761	000147	0750	0656	0625	0250	0343	0375	#0110	M03 \$
006865	-002311	-005411	0625	0625	0625	0375	0375	0375	#0111	M04 \$
006404	-011811	-009750	0500	0593	0625	0500	0406	0375	#0112	M05 \$
006203	-019121	-013338	0375	0562	0625	0625	0437	0375	#0113	M06 \$
005594	-026112	-016443	0250	0531	0625	0750	0468	0375	#0114	M07 \$
005040	-032327	-020004	0125	0500	0625	0875	0500	0375	#0115	M08 \$
004443	-032629	-022609	0000	0468	0625	1000	0531	0375	#0116	M09 \$
007230	002464	001270	1000	0625	0500	0000	0375	0500	#0117	N01 \$
007160	002428	001253	0875	0593	0500	0125	0406	0500	#0118	

009255	-00012	000010	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$	009224	000014	-00004	1000	1000	1000	0000	0000	0000	%0486	S10 \$	009228	-00002	-00005	1000	1000	1000	0000	0000	0000	0000	0000	%0810	S19 \$
009211	-00088	-00037	0875	0937	1000	0125	0662	0000	0000	%0163	S02 \$	009171	-00030	-00071	0937	0875	1000	0062	0125	0000	0000	%0487	S11 \$	009185	000071	-00044	1000	0875	0937	0000	0125	0662	0000	%0811	S20 \$
008816	-00995	-00540	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$	008277	000000	-01090	0875	0750	1000	0125	0250	0000	0000	%0488	S12 \$	008549	001167	-00726	1000	0750	0875	0000	0250	0125	0000	%0812	S21 \$
008239	-01878	-01171	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$	007147	000147	-02207	0812	0625	1000	0187	0375	0000	0000	%0489	S13 \$	007814	002375	-01411	1000	0625	0812	0000	0375	0187	0000	%0813	S22 \$
007682	-02545	-01697	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$	006130	000354	-03077	0750	0500	1000	0250	0500	0000	0000	%0490	S14 \$	007058	003556	-01993	1000	0500	0750	0000	0500	0250	0000	%0814	S23 \$
007162	-03096	-02123	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$	005109	000827	-03861	0687	0375	1000	0312	0625	0000	0000	%0491	S15 \$	006267	004745	-02486	1000	0375	0687	0000	0625	0312	0000	%0815	S24 \$
006627	-03402	-02508	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$	004008	001434	-04620	0625	0250	1000	0375	0750	0000	0000	%0492	S16 \$	005523	005805	-02634	1000	0250	0625	0000	0750	0375	0000	%0816	S25 \$
005938	-03722	-02926	0125	0562	1000	0875	0500	0000	0000	%0169	S08 \$	002843	002904	-05300	0562	0125	1000	0570	0875	0000	0000	%0493	S17 \$	004671	006867	-03057	1000	0125	0562	0000	0875	0500	0000	%0817	S26 \$
005162	-03781	-03273	0000	0500	1000	1000	0500	0000	0000	%0170	S09 \$	001164	003356	-05735	0500	0000	1000	0500	1000	0000	0000	%0494	S18 \$	003836	007538	-02951	1000	0000	0500	0000	1000	0500	0000	%0818	S27 \$
009253	-00063	000120	1000	0937	0875	0000	0662	0125	0000	%0171	T01 \$	009223	-00009	000108	0937	1000	0875	0662	0000	0125	0000	%0495	T10 \$	009201	-00088	-00048	0875	1000	0937	0125	0000	0662	0000	%0819	T10 \$
009178	-00956	000043	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$	009150	-00024	000021	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$	009147	-00046	000032	0875	0875	0875	0125	0125	0125	0000	%0820	T10 \$
008736	-00966	00514	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$	008248	000010	-01024	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$	008514	001046	-00609	0875	0750	0812	0125	0250	0187	0000	%0821	T21 \$
008102	-01687	-01211	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$	007116	000175	-02149	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$	007777	002232	-01260	0875	0625	0750	0125	0375	0250	0000	%0822	T22 \$
007492	-02268	-01792	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$	006070	000382	-03063	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$	007025	003410	-01817	0875	0500	0687	0125	0500	0312	0000	%0823	T23 \$
006960	-02669	-02247	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$	005008	000916	-03879	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$	006230	004617	-02322	0875	0375	0625	0125	0625	0375	0000	%0824	T24 \$
006402	-03035	-02656	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$	003957	001469	-04609	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$	005470	005696	-02682	0875	0250	0562	0125	0750	0437	0000	%0825	T25 \$
005732	-03361	-03053	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$	002772	002288	-05310	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$	004634	006765	-02922	0875	0125	0500	0125	0875	0500	0000	%0826	T26 \$
004976	-03459	-03371	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$	001598	003477	-05723	0437	0000	0875	0562	1000	0125	0000	%0503	T18 \$	003804	007445	-02836	0875	0000	0437	0125	1000	0562	0000	%0827	T27 \$
009042	-00012	000767	1000	0875	0875	0000	0125	0250	0000	%0180	T09 \$	009108	-00339	000875	0875	1000	0750	0125	0000	0250	0000	%0504	T19 \$	008779	-01028	-00394	0750	1000	0875	0250	0000	0125	0000	%0828	T28 \$
008758	000449	000438	0875	0812	0750	0125	0187	0250	0000	%0181	U02 \$	008995	-00658	000604	0812	0875	0750	0187	0125	0250	0000	%0505	U11 \$	008713	-01030	-00111	0750	0875	0812	0250	0125	0187	0000	%0829	U20 \$
008124	-00045	-00036	0750	0750	0750	0250	0250	0250	0000	%0182	U03 \$	008160	-00077	-00317	0750	0750	0750	0250	0250	0250	0000	%0506	U12 \$	008107	-00059	-00317	0750	0750	0750	0250	0250	0250	0000	%0830	U21 \$
007540	-00951	-01018	0625	0687	0750	0375	0312	0250	0000	%0183	U04 \$	007054	-00005	-01516	0687	0625	0750	0312	0375	0250	0000	%0507	U13 \$	007404	001131	-00981	0750	0625	0687	0250	0375	0312	0000	%0831	U22 \$
006991	-01627	-01590	0500	0625	0750	0500	0375	0250	0000	%0184	U05 \$	006010	000190	-02525	0625	0500	0750	0375	0250	0500	0000	%0508	U14 \$	006660	002357	-01616	0750	0500	0625	0250	0500	0375	0000	%0832	U23 \$
006506	-02116	-02064	0375	0562	0750	0625	0437	0250	0000	%0185	U06 \$	004957	000738	-03447	0562	0375	0750	0437	0625	0250	0000	%0509	U15 \$	005883	003598	-02140	0750	0375	0562	0250	0625	0437	0000	%0833	U24 \$
005992	-02565	-02477	0250	0500	0750	0750	0500	0250	0000	%0186	U07 \$	003866	001361	-04293	0500	0250	0750	0500	0750	0250	0000	%0510	U16 \$	005109	004786	-02611	0750	0250	0500	0250	0750	0500	0000	%0834	U25 \$
005366	-02971	-02901	0125	0437	0750	0875	0562	0250	0000	%0187	U08 \$	002712	002145	-05050	0437	0125	0750	0562	0875	0250	0000	%0511	U17 \$	004270	005955	-02915	0750	0125	0437	0250	0875	0562	0000	%0835	U26 \$
004679	-03174	-03220	0000	0375	0750	1000	0625	0250	0000	%0188	U09 \$	001537	003349	-05505	0375	0000	0750	0625	1000	0250	0000	%0512	U18 \$	003458	006780	-02923	0750	0000	0375	0250	1000	0625	0000	%0836	U27 \$
008559	000639	001459	1000	0812	0625	0000	0187	0375	0000	%0189	V01 \$	008820	-01011	001809	0812	1000	0625	0187	0000	0375	0000	%0513	V10 \$	008196	-02027	-00649	0625	1000	0812	0375	0000	0187	0000	%0837	V19 \$
008290	000938	001166	0875	0750	0625	0125	0250	0375	0000	%0190	V02 \$	008564	-01402	001484	0750	0875	0625	0250	0125	0375	0000	%0514	V11 \$	008137	-02083	-00242	0625	0875	0750	0375	0125	0250	0000	%0838	V20 \$
007660	000425	000354	0750	0687	0625	0250	0312	0375	0000	%0191	V03 \$	007815	-00938	000557	0687	0750	0625	0312	0250	0375	0000	%0515	V12 \$	007563	-01239	-00313	0625	0750	0687	0375	0250	0312	0000	%0839	V19 \$
006916	-00249	-00493	0625	0625	0625	0375	0375	0375	0000	%0192	V04 \$	006959	-00261	-00470	0625	0625	0625	0375	0375	0375	0000	%0516	V13 \$	006858	-00218	-00500	0625	0625	0625	0375	0375	0375	0000	%0840	V22 \$
006399	-01047	-01081	0500	0562	0625	0500	0437	0375	0000	%0193	V05 \$	005926	-00131	-01590	0562	0500	0625	0437	0500	0375	0000	%0517	V14 \$	006155	000960	-01143	0625	0500	0562	0375	0500	0437	0000	%0841	V23 \$
005956	-01648	-01544	0375	0500	0625	0625	0625	0375	0000	%0194	V06 \$	004960	-00390	-02644	0500	0375	0625	0500	0625	0375	0000	%0518	V15 \$	005363	002273	-01819	0625	0375	0500	0375	0625	0500	0000	%0842	V24 \$
005488	-02178	-01993	0250	0437	0625	0750	0562	0375	0000	%0195	V07 \$	003777	001006	-03623	0437	0250	0625	0562	0750	0375	0000	%0519	V16 \$	004581	003626	-02340	0625	0500	0437	0375	0750	0562	0000	%0843	V25 \$
004900	-02658	-02480	0125	0375	0625	0875	0625	0375	0000	%0196	V08 \$	002576	001866	-04534	0375	0125	0625	0625	0875	0375	0000	%0520	V17 \$	003738	004821	-02796	0625	0125	0375	0375	0875	0625	0000	%0844	V26 \$
004277	-02952	-02810	0000	0312	0625	1000	0687	0375	0000	%0197	V09 \$	001435	003032	-05065	0312	0000	0625	0687	1000	0375	0000	%0521	V18 \$	002943	005777	-02908	0625	0000							

009281	-00014	-000019	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
009233	-00085	-00037	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008832	-00985	-00537	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
008243	-01842	-01178	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
007578	-02303	-01808	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
006945	-02501	-02346	0375	0531	1000	0625	0488	0000	0000	%0248	b06	\$
006308	-02770	-02818	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
005572	-02993	-03205	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$
004791	-02906	-03612	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
003274	-03000	-000118	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
002901	-00060	000045	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
008628	-00654	-00652	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
007893	-0125	-01445	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
007223	-01673	-02070	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
006623	-01961	-02577	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
005998	-02195	-03041	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
005288	-02469	-03463	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
004551	-02540	-03766	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
00237	-00175	-000944	1000	0937	0750	0000	062	0250	0000	%0261	d01	\$
008950	000127	000645	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
008158	-00055	-00358	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$
007451	-00681	-01168	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
006791	-01162	-01831	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
006225	-01501	-02365	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
005639	-01846	-02842	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
004940	-02101	-03328	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
004198	-02151	-03675	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
009122	-00253	002134	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
008677	000316	001616	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
007871	000088	000577	0750	0718	0625	0250	0281	0375	0000	%0272	e03	\$
006962	-00231	-00516	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
006344	-00810	-01208	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
005670	-01194	-01704	0375	0437	0625	0625	0562	0375	0000	%0275	e06	\$
005162	-01523	-02370	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$
004476	-01802	-02934	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
003745	-01824	-03336	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
008831	-00904	-003214	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
008412	000524	002696	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
007596	000258	001646	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
006674	-00190	-000534	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
005787	-00391	-00496	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
005199	-00793	-01149	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
004598	-01184	-01765	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
003918	-01474	-02401	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
003234	-01562	-02853	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
008545	000266	004283	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
008095	000829	003711	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
007315	000468	002727	0750	0656	0375	0250	0343	0625	0000	%0290	g03	\$
006384	-00070	-001602	0625	0562	0375	0375	0437	0625	0000	%0291	g04	\$
005459	-00295	-000948	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
004605	-00296	-00517	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
003988	-00703	-01221	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
003338	-01113	-01857	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
002666	-01204	-02359	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
008265	000596	005367	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
007778	001169	004729	0875	0718	0250	0125	0281	0750	0000	%0298	h02	\$
007012	000765	003760	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
006051	000164	002591	0625	0531	0250	0375	0406	0750	0000	%0300	h04	\$
005129	-00123	-001421	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
004248	-00166	-000348	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
003373	-00197	-00680	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
002709	-00572	-01414	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
002055	-00673	-01969	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
007945	000979	006773	1000	0781	0125	0000	0218	0875	0000	%0306	h10	\$
007507	001469	006189	0875	0687	0125	0125	0312	0875	0000	%0307	h12	\$
006720	001065	005188	0750	0593	0125	0250	0406	0875	0000	%0308	h13	\$
005707	000489	003877	0625	0500	0125	0375	0500	0875	0000	%0309	h14	\$
004760	000156	002641	0500	0406	0125	0500	0593	0875	0000	%0310	h15	\$
003915	-00033	-001501	0375	0312	0125	0625	0687	0875	0000	%0311	h06	\$
002991	-00078	-000368	0250	0218	0125	0750	0781	0875	0000	%0312	h07	\$
002051	-00035	-00715	0125	0125	0125	0875	0875	0875	0000	%0313	h08	\$
001402	-00129	-01390	0000	0031	0125	1000	0968	0875	0000	%0314	h09	\$
007626	001399	009269	1000	0750	0000	0000	0250	1000	0000	%0315	h10	\$
007191	001854	008678	0875	0656	0000	0125	0343	1000	0000	%0316	h12	\$
006406	001487	007575	0750	0562	0000	0250	0437	1000	0000	%0317	h03	\$
005349	000870	006101	0625	0468	0000	0375	0531	1000	0000	%0318	h04	\$
004365	-000503	-004723	0500	0375	0000	0500	0625	1000	0000	%0319	h05	\$
003489	000212	003494	0375	0281	0000	0625	0718	1000	0000	%0320	h06	\$
002573	000033	002224	0250	0187	0000	0750	0812	1000	0000	%0321	h07	\$
001628	-00023	-000964	0125	0093	0000	0875	0906	1000	0000	%0322	h08	\$
000873	-00008	-000030	0000	0000	0000	1000	1000	1000	0000	%0323	h09	\$
009228	000015	000000	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
009191	000083	-00046	0875	1000	0031	0125	0000	0000	0000	%0568	b11	\$
008394	000536	-00946	0937	0750	0062	0250	0000	0000	0000	%0569	b12	\$
007335	000935	-01998	0967	0625	1000	0963	0375	0000	0000	%0570	b13	\$
006261	001365	-02926	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
005168	002017	-03753	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
004120	002792	-04455	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
002499	003724	-051	0781	0250	1000	0219	0875	0000	0000	%0574	b17	\$
001755	004553	-05550	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
009223	-00030	000100	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$
009155	-00026	000020	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$
008316	000317	-00942	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
007265	000700	-01995	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
006193	001159	-02921	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
005095	001817	-03763	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
004042	002589	-04483	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$
002883	003555	-05155	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
001706	004468	-05576	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
000870	-00902	000520	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$
008778	-00959	000402	0781	0875	0750	0218	0125	0250	0000	%0586	d11	

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG HE08(7)_22.TXT, Separation olv*, D50, adapted $
%100 x LAB*a      %1000 x (r g b c m y o)      %nr.    pos $
%Z003782 006719 000359 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008501 000086 010434 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z004554 -06041 002319 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005085 -04034 -02894 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003985 -01443 -04255 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z002550 005615 -04632 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z000847 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009249 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z003782 006719 000359 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008501 000086 010434 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z004554 -06041 002319 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005085 -04034 -02894 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003985 -01443 -04255 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z002550 005615 -04632 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z000847 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009249 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z003782 006719 000359 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008501 000086 010434 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z004554 -06041 002319 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005085 -04034 -02894 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003985 -01443 -04255 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z002550 005615 -04632 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z000847 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009249 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z004154 005873 004954 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008074 -00882 009937 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z004720 -05749 000873 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005146 -03775 -03273 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z002953 000743 -05061 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z003567 007101 -03318 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z000810 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009235 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z005988 003594 007137 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006519 -03574 007570 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z004876 -05271 -00511 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z005162 -03781 -03273 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z001664 003396 -05735 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z003836 007538 -02951 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z000830 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009236 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z007626 001390 009269 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z004948 -05587 005231 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005029 -04607 -01899 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z004791 -02996 -03612 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z001755 004553 -05550 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z003817 007260 -01943 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z000851 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009248 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG HE08(7)_22.TXT, Separation olv*, D50, adapted $
%100 x LAB*a      1000 x (r g b      c m y 0)      %nr. pos $
000921 -00045 -00006 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002086 -00048 -00732 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003396 -00160 -00704 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004612 -00278 -00552 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005819 -00380 -00537 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006997 -00259 -00519 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
008190 -00106 -00334 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
009189 -00054 -00091 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009248 000005 -00012 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
009916 -00039 -00003 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002085 -00042 -00732 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003404 -00143 -00734 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004607 -00270 -00567 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005816 -00379 -00537 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
007004 -00251 -00537 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
008193 -00109 -00338 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
009191 -00058 0000221 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009255 000000 -00011 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
009906 -00032 -00024 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002071 -00032 -00747 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003394 -00147 -00730 0250 0250 0250 0750 0750 0750 0000 %0992 k03 $
004600 -00252 -00600 0375 0375 0375 0625 0625 0625 0000 %0993 k04 $
005799 -00371 -00553 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006988 -00259 -00520 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
008186 -00107 -00333 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
009185 -00060 -00022 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009247 -00005 -00009 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
009904 -00033 -00006 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002076 -00033 -00737 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003385 -00148 -00734 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004588 -00254 -00598 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005805 -00381 -00537 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006981 -00254 -00521 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
008174 -00104 -00344 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
009182 -00062 -00025 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009240 -00009 -00008 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
009874 -00022 -00048 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
001427 000049 -00548 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002159 -00066 -00758 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
002848 -00212 -00727 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
003568 -00186 -00686 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
004232 -00217 -00544 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
004865 -00327 -00553 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005499 -00388 -00538 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
006136 -00404 -00475 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006734 -00291 -00494 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
007359 -00150 -00500 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
008000 -00078 -00380 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
008581 -00027 -00220 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
009145 -00081 000041 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
009271 -00014 -00002 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009251 000005 -00013 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
009885 -00021 -00059 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
001426 000054 -00560 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
002147 -00049 -00789 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
002854 -00205 -00744 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
003569 -00182 -00689 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
004228 -00201 -00665 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
004868 -00318 -00560 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005491 -00397 -00533 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
006132 -00401 -00483 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006747 -00292 -00485 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
007377 -00151 -00502 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
008008 -00080 -00382 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
008584 -00032 -00226 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
009144 -00086 000037 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
009255 -00013 -00010 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009249 000002 -00011 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
008061 -00010 -00073 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
001411 000069 -00571 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002127 -00038 -00802 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
002837 -00192 -00756 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
003552 -00185 -00696 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
004225 -00204 -00579 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
004845 -00318 -00573 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005485 -00383 -00550 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
006117 -00403 -00480 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006727 -00298 -00476 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
007362 -00151 -00494 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
008003 -00080 -00378 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
008572 -00035 -00223 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```