

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart HE18; Relative Elementary Colour System O
1080 spectral reflexions R $\rightarrow$ LAB* for D65 and D50

input: w *setgray*
output: no change compared to input

TUB registration: 20091101-HE18/HE18L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NP.PDF>/.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

XBOG x LAB* (7)_22.TXT, Separation olv*, D65, not adapted \$										Xnr., pos \$									
1000 x H08* (7)_22.TXT, Separation olv*, D65, not adapted \$										1000 x (r g b c m y a)									
000276 000013 -006613 1000 1000 1000 0000 0000 0000 0000 0000 0000 0000										000000 A01 \$									
0009235 -000663 -006665 0875 1000 1000 0125 0000 0000 0000 0000 0000										000001 A02 \$									
0008834 -000864 -01169 0750 1000 1000 0250 0000 0000 0000 0000 0000										000002 A03 \$									
0008274 -01263 -01765 0625 1000 1000 0375 0000 0000 0000 0000 0000										000003 A04 \$									
0007726 -02162 -02237 0500 1000 1000 0500 0000 0000 0000 0000 0000										000004 A05 \$									
0007215 -02575 -02531 0375 1000 1000 0625 0000 0000 0000 0000 0000										000005 A06 \$									
0006664 -02920 -02817 0250 1000 1000 0750 0000 0000 0000 0000 0000										000006 A07 \$									
0005984 -03160 -03120 0125 1000 1000 0875 0000 0000 0000 0000 0000										000007 A08 \$									
0005221 -03180 -03354 0000 1000 1000 1000 0000 0000 0000 0000 0000										000008 A09 \$									
0009231 0000099 -00672 1000 0875 0875 0000 0125 0125 0000 0000										000009 B01 \$									
0009178 -00017 -00608 0875 0875 0875 0125 0125 0125 0000 0000										000010 B02 \$									
0008777 -00897 -00937 0750 0875 0875 0250 0125 0125 0000 0000										000011 B03 \$									
0008215 -01730 -01408 0625 0875 0875 0375 0125 0125 0000 0000										000012 B04 \$									
0007657 -02334 -01795 0500 0875 0875 0500 0125 0125 0000 0000										000013 B05 \$									
0007129 -02785 -02106 0375 0875 0875 0625 0125 0125 0000 0000										000014 B06 \$									
0006576 -03174 -02350 0250 0875 0875 0750 0125 0125 0000 0000										000015 B07 \$									
0005903 -03449 -02644 0125 0875 0875 0875 0125 0125 0000 0000										000016 B08 \$									
0005147 -03559 -02816 0000 0875 0875 1000 0125 0125 0000 0000										000017 B09 \$									
0008542 001143 -01049 1000 0750 0750 0000 0250 0250 0000 0000										000018 C01 \$									
0008499 000972 -00831 0875 0750 0750 0125 0250 0250 0000 0000										000019 C02 \$									
0007502 000871 -01020 0875 0750 0750 0125 0250 0250 0000 0000										000020 C03 \$									
0007087 000969 -01027 0625 0750 0750 0375 0500 0250 0000 0000										000021 C04 \$									
0007807 -01694 -01640 0500 0750 0750 0500 0250 0250 0000 0000										000022 C05 \$									
0006635 -02305 -01847 0375 0750 0750 0625 0250 0250 0000 0000										000023 C06 \$									
0006155 -02849 -02033 0250 0750 0750 0750 0250 0250 0000 0000										000024 C07 \$									
0005550 -03337 -02234 0125 0750 0750 0875 0250 0250 0000 0000										000025 C08 \$									
0004854 -03593 -02392 0000 0750 0750 1000 0250 0250 0000 0000										000026 C09 \$									
0007793 002144 -01199 1000 0625 0625 0000 0375 0375 0000 0000										000027 D01 \$									
0007723 001619 -00905 0875 0625 0625 0125 0375 0375 0000 0000										000028 D02 \$									
0007362 001006 -00990 0750 0625 0625 0250 0375 0375 0000 0000										000029 D03 \$									
0006872 -00808 -01204 0625 0625 0625 0375 0375 0375 0000 0000										000030 D04 \$									
0006399 -01017 -01382 0500 0625 0625 0500 0375 0375 0000 0000										000031 D05 \$									
0006028 -01750 -01530 0375 0625 0625 0625 0375 0375 0000 0000										000032 D06 \$									
0005588 -02450 -01646 0250 0625 0625 0750 0375 0375 0000 0000										000033 D07 \$									
0005054 -03082 -01825 0125 0625 0625 0875 0375 0375 0000 0000										000034 D08 \$									
0004449 -03464 -01974 0000 0625 0625 1000 0375 0375 0000 0000										000035 D09 \$									
0006899 003105 -01214 1000 0500 0500 0000 0500 0500 0000 0000										000036 E01 \$									
0006950 002898 -00837 0875 0500 0500 0125 0500 0500 0000 0000										000037 E02 \$									
0006604 001944 -00882 0750 0500 0500 0250 0500 0500 0000 0000										000038 E03 \$									
0006131 000787 -01064 0625 0500 0500 0375 0500 0500 0000 0000										000039 E04 \$									
0005691 -00233 -01186 0500 0500 0500 0500 0500 0500 0000 0000										000040 E05 \$									
0005345 -01028 -01356 0375 0500 0500 0625 0500 0500 0000 0000										000041 E06 \$									
0004942 -01816 -01484 0250 0500 0500 0750 0500 0500 0000 0000										000042 E07 \$									

009270	000036	-00642	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009223	-00021	-00694	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008855	-00822	-01148	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
008287	-01572	-01746	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
007743	-02103	-02243	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
007249	-02449	-02638	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006713	-02721	-03012	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
00645	-02918	-03400	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005286	-03250	-03722	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
009249	-00026	-00552	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
009181	-00033	-00618	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
008800	-00829	-01042	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
008249	-01600	-01593	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
007700	-02165	-02078	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
007199	-02527	-02474	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
006664	-02831	-02832	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
006011	-03031	-03216	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
005248	-03067	-03521	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
008617	-00079	-00439	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
008544	000758	-00463	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
008100	000088	-01045	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
007619	-00813	-01521	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
007143	-01526	-01944	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
006715	-02028	-02310	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
006234	-02487	-02604	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
005650	-02831	-02961	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
004976	-02965	-03221	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
007888	001559	-00957	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
007775	001595	-00109	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
007438	000784	-00556	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
006888	-00065	-01198	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
006452	-00896	-01509	0500	0593	0625	0500	0406	0375	0000	00112	M05	\$
006090	-01519	-01919	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
005679	-02109	-02193	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
005143	-02604	-02522	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
004549	-02891	-02764	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007174	002292	-00047	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
007105	002261	-00046	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
006720	001494	-00016	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
006206	000512	-00615	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
005711	-00239	-01161	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
005378	-00921	-01526	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
004996	-01612	-01801	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
004532	-02228	-02121	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
004004	-02603	-02361	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
006435	003064	000972	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
006341	003099	000883	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
005959	002322	000467	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
005417	001347	-00196	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
004968	000495	-00729	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
004545	-00088	-01250	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
004172	-00854	-01539	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
003760	-01551	-01857	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003302	-02035	-02069	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
005605	003937	001375	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
005589	000398	001339	0875	0406	0500	0125	0593	0750	0000	00136	P02	\$
005203	003224	000871	0750	0375	0250	0250	0625	0625	0000	00137	P03	\$
004650	002233	000206	0625	0343	0250	0375	0656	0750	0000	00138	P04	\$
004136	001424	-00413	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
003761	000724	-00921	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
003342	000934	-01391	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
002952	-00744	-01676	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
002536	-01283	-01897	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
004867	004776	-00216	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
004756	000440	002119	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
004377	004154	-00167	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
003782	002307	000881	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
003309	002350	000212	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
002861	001636	-00398	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
002447	000910	-00938	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
002023	000243	-01439	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
001666	-00388	-01640	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
003976	005571	003941	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
003885	-00587	-003894	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
003490	-005038	-003300	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
002926	004062	002439	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
002401	003196	-001627	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
001963	002387	000933	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
001524	001606	000294	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
001146	000791	-00311	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
000841	000140	-00736	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009226	000078	-00660	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
009183	000028	-00714	0906	0875	1000	0093	0125	0000	0000	00406	J11	\$
008564	-00255	-01452	0812	0750	1000	0187	0250	0000	0000	00407	J12	\$
007611	-00216	-02440	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
006688	-00023	-03265	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
005891	-00207	-03912	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
005013	000582	-04548	0347	0250	1000	0562	0750	0000	0000	00411	J16	\$
004613	001565	-05181	0433	0250	1000	0875	0875	0000	0000	00412	J17	\$
003077	001886	-05183	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
009215	000039	-00558	0906	0875	0031	0000	0125	0000	0000	00414	K10	\$
009139	000039	-00648	0875	0875	0875	0125	0125	0125	0000	00415	K11	\$
008372	000023	-01557	081	0750	0875	0218	0250	0125	0000	00416	K12	\$
007425	000058	-02525	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
006520	000199	-03338	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
005686	000497	-04017	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
004810	000892	-04650	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
003818	001475	-05279	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
002848	002288	-05732	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
009163	-00199	-00280	0937	1000	0750	0062	0000	0250	0000	00423	L10	\$
009020	-00367	-00010	0843	0875</								

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-HE18/HE18L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IOB material: code=rha4ta

TUB-test chart HE18; Relative Elementary Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NP.PDF/>.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfl=1.00; nt=0.18; nx=1.0

[illegible]

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG HE08(7)_22.TXT, Separation olv*, D65, not adapted $
%100 x LAB*      %1000 x (r g b c m y o)      %nr.    pos $
%z003612 006686 -00739 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008423 -00457 009798 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z004633 -05962 001817 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005221 -03180 -03354 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z004115 -00408 -04778 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z002523 006378 -05542 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z000860 000156 -00749 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009259 000022 -00630 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%$
%z003612 006686 -00739 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008423 -00457 009798 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z004633 -05962 001817 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005221 -03180 -03354 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z004115 -00408 -04778 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z002523 006378 -05542 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z000860 000156 -00749 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009259 000022 -00630 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%$
%z003612 006686 -00739 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008423 -00457 009798 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z004633 -05962 001817 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005221 -03180 -03354 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z004115 -00408 -04778 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z002523 006378 -05542 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z000860 000156 -00749 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009259 000022 -00630 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%$
%z003976 005571 003941 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z008017 -01349 009321 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z004814 -05472 000385 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z005286 -02850 -03722 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003074 001860 -05618 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z003449 007550 -04360 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z000822 000146 -00711 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009245 000058 -00654 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%$
%z005861 003124 006308 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z006524 -03902 007051 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z004984 -04798 -00980 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z005302 -02865 -03712 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z001773 004544 -06344 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z003696 007903 -04023 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z000842 000140 -00701 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009245 000045 -00644 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%$
%z007532 000855 008579 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z004998 -05754 004761 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005153 -03920 -02354 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z004927 -02048 -04072 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z001814 005593 -06285 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z003665 007478 -03023 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z000864 000143 -00723 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009258 000029 -00621 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%$
```

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG HE08(7)_22.TXT, Separation olv*, D65, not adapted S		1000 x (r g b c m y o)										%nr. pos \$	
%100 x LAB*													
000934	000105	-00706	0000	0000	0000	1000	1000	1000	0000			%0972	k01 \$
000211	000199	-01410	0125	0125	0125	0875	0875	0875	0000			%0973	k02 \$
000342	000059	-01366	0250	0250	0250	0750	0750	0750	0000			%0974	k03 \$
000463	-000096	-01198	0375	0375	0375	0625	0625	0625	0000			%0975	k04 \$
000584	-00213	-01167	0500	0500	0500	0500	0500	0500	0000			%0976	k05 \$
000702	-00118	-01140	0625	0625	0625	0375	0375	0375	0000			%0977	k06 \$
000820	-00015	-00949	0750	0750	0750	0250	0250	0250	0000			%0978	k07 \$
000919	-00025	-00590	0875	0875	0875	0125	0125	0125	0000			%0979	k08 \$
000258	000024	-00022	1000	1000	1000	0000	0000	0000	0000			%0980	k09 \$
000929	000111	-00705	0000	0000	0000	1000	1000	1000	0000			%0981	l01 \$
000211	000206	-01411	0125	0125	0125	0875	0875	0875	0000			%0982	l02 \$
000343	000080	-01395	0250	0250	0250	0750	0750	0750	0000			%0983	l03 \$
000463	-000086	-01213	0375	0375	0375	0625	0625	0625	0000			%0984	l04 \$
000584	-00213	-01167	0500	0500	0500	0500	0500	0500	0000			%0985	l05 \$
000702	-00108	-01158	0625	0625	0625	0375	0375	0375	0000			%0986	l06 \$
000820	-00016	-00953	0750	0750	0750	0250	0250	0250	0000			%0987	l07 \$
000920	-00029	-00587	0875	0875	0875	0125	0125	0125	0000			%0988	l08 \$
000264	000029	-00621	1000	1000	1000	0000	0000	0000	0000			%0989	l09 \$
000920	000121	-00726	0000	0000	0000	1000	1000	1000	0000			%0990	m01 \$
000206	000218	-01426	0125	0125	0125	0875	0875	0875	0000			%0991	m02 \$
000342	000076	-01391	0250	0250	0250	0750	0750	0750	0000			%0992	m03 \$
000462	-00065	-01247	0375	0375	0375	0625	0625	0625	0000			%0993	m04 \$
000582	-00202	-01183	0500	0500	0500	0500	0500	0500	0000			%0994	m05 \$
000701	-00118	-01141	0625	0625	0625	0375	0375	0375	0000			%0995	m06 \$
000820	-00015	-00949	0750	0750	0750	0250	0250	0250	0000			%0996	m07 \$
000915	-00031	-00586	0875	0875	0875	0125	0125	0125	0000			%0997	m08 \$
000257	000023	-00619	1000	1000	1000	0000	0000	0000	0000			%0998	m09 \$
000917	000117	-00707	0000	0000	0000	1000	1000	1000	0000			%0999	n01 \$
000210	000216	-01416	0125	0125	0125	0875	0875	0875	0000			%1000	n02 \$
000342	000076	-01395	0250	0250	0250	0750	0750	0750	0000			%1001	n03 \$
000461	-00066	-01245	0375	0375	0375	0625	0625	0625	0000			%1002	n04 \$
000583	-00214	-01167	0500	0500	0500	0500	0500	0500	0000			%1003	n05 \$
000704	-00112	-01143	0625	0625	0625	0375	0375	0375	0000			%1004	n06 \$
000819	-00011	-00960	0750	0750	0750	0250	0250	0250	0000			%1005	n07 \$
000912	-00033	-00583	0875	0875	0875	0125	0125	0125	0000			%1006	n08 \$
000250	000020	-00617	1000	1000	1000	0000	0000	0000	0000			%1007	n09 \$
000887	000135	-00749	0000	0000	0000	1000	1000	1000	0000			%1008	k10 \$
000144	000278	-01240	0066	0066	0066	0933	0933	0933	0000			%1009	k11 \$
000216	000186	-01434	0133	0133	0133	0866	0866	0866	0000			%1010	k12 \$
000287	000025	-01392	0200	0200	0200	0800	0800	0800	0000			%1011	k13 \$
000359	000029	-01345	0266	0266	0266	0733	0733	0733	0000			%1012	k14 \$
000425	000033	-01197	0333	0333	0333	0666	0666	0666	0000			%1013	k15 \$
000489	-00146	-01195	0400	0400	0400	0600	0600	0600	0000			%1014	k16 \$
000526	-00216	-01171	0466	0466	0466	0533	0533	0533	0000			%1015	k17 \$
000616	-00249	-01102	0533	0533	0533	0466	0466	0466	0000			%1016	k18 \$
000675	-00148	-01118	0600	0600	0600	0399	0399	0399	0000			%1017	k19 \$
000738	-00022	-01122	0666	0666	0666	0333	0333	0333	0000			%1018	k20 \$
000801	000020	-00998	0733	0733	0733	0266	0266	0266	0000			%1019	k21 \$
000854	000039	-00835	0800	0800	0800	0199	0199	0199	0000			%1020	k22 \$
000915	-00052	-00568	0866	0866	0866	0133	0133	0133	0000			%1021	k23 \$
000920	000014	-00611	0933	0933	0933	0066	0066	0066	0000			%1022	k24 \$
000921	000035	-00624	1000	1000	1000	0000	0000	0000	0000			%1023	k25 \$
000898	000138	-00760	0000	0000	0000	1000	1000	1000	0000			%1024	l10 \$
000144	000285	-01252	0066	0066	0066	0933	0933	0933	0000			%1025	l11 \$
000214	000208	-01465	0133	0133	0133	0866	0866	0866	0000			%1026	l12 \$
000282	000034	-01408	0200	0200	0200	0800	0800	0800	0000			%1027	l13 \$
000355	000033	-01348	0266	0266	0266	0733	0733	0733	0000			%1028	l14 \$
000425	-00015	-01129	0333	0333	0333	0666	0666	0666	0000			%1029	l15 \$
000484	-00137	-01203	0400	0400	0400	0600	0600	0600	0000			%1030	l16 \$
000518	-00225	-01166	0466	0466	0466	0533	0533	0533	0000			%1031	l17 \$
000615	-00245	-01109	0533	0533	0533	0466	0466	0466	0000			%1032	l18 \$
000671	-00150	-01109	0600	0600	0600	0399	0399	0399	0000			%1033	l19 \$
000737	-00022	-01124	0666	0666	0666	0333	0333	0333	0000			%1034	l20 \$
000805	000019	-01000	0733	0733	0733	0266	0266	0266	0000			%1035	l21 \$
000858	000036	-00842	0800	0800	0800	0199	0199	0199	0000			%1036	l22 \$
000915	-00057	-00572	0866	0866	0866	0133	0133	0133	0000			%1037	l23 \$
000924	000016	-00620	0933	0933	0933	0066	0066	0066	0000			%1038	l24 \$
000925	000033	-00622	1000	1000	1000	0000	0000	0000	0000			%1039	l25 \$
000874	000150	-00775	0000	0000	0000	1000	1000	1000	0000			%1040	m10 \$
000143	000302	-01264	0066	0066	0066	0933	0933	0933	0000			%1041	m11 \$
000214	000220	-01479	0133	0133	0133	0866	0866	0866	0000			%1042	m12 \$
000285	000049	-01421	0200	0200	0200	0800	0800	0800	0000			%1043	m13 \$
000357	000032	-01355	0266	0266	0266	0733	0733	0733	0000			%1044	m14 \$
000425	-00016	-01232	0333	0333	0333	0666	0666	0666	0000			%1045	m15 \$
000487	-00134	-01215	0400	0400	0400	0600	0600	0600	0000			%1046	m16 \$
000512	-00209	-01184	0466	0466	0466	0533	0533	0533	0000			%1047	m17 \$
000614	-00247	-01107	0533	0533	0533	0466	0466	0466	0000			%1048	m18 \$
000675	-00157	-01100	0600	0600	0600	0399	0399	0399	0000			%1049	m19 \$
000738	-00024	-01116	0666	0666	0666	0333	0333	0333	0000			%1050	m20 \$
000802	000018	-00996	0733	0733	0733	0266	0266	0266	0000			%1051	m21 \$
000856	000032	-00839	0800	0800	0800	0199	0199	0199	0000			%1052	m22 \$

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart HE18; Relative Elementary Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

TUB registration: 20091101-HE18/HE18L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IOB material: code=rha4ta

See original or copy: <http://web.me.com/kliaus.richter/HE18/HE18L0NP.PDF>/.PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

```
input: w setgray
output: -> olv* setrabcOLOR
```

009264	-00012	000010	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
009223	-00079	-00033	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
008853	-00875	-00492	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
008302	-01624	-01077	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
007766	-02167	-01565	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
007262	-02519	-01964	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
006741	-02806	-02322	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
00668	-03000	-02714	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$
005302	-02955	-03040	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
009261	-00045	000119	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
009188	-00058	000044	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
008770	-00794	-00471	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
008162	-01435	-01124	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
007572	-01888	-01678	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
007056	-02176	-02099	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
006513	-02428	-02482	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
005858	-02630	-02852	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
005113	-02626	-03148	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
009039	000016	000750	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
008754	000374	000411	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
008141	000093	-00357	0570	0750	0750	0250	0500	0250	0000	%0182	U03	\$
007583	-00763	-00967	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
007057	-01310	-01500	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
006590	-01682	-01943	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
006091	-02012	-02328	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
005482	-02285	-02721	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
004808	-02381	-03013	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
008538	000443	001411	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
008267	000759	001109	0875	0750	0625	0125	0250	0375	0000	%0190	V02	\$
007658	000361	000328	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
006939	-00172	-00480	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
006446	-00844	-01026	0500	0562	0625	0500	0437	0375	0000	%0193	V05	\$
006022	-01327	-01455	0375	0500	0625	0625	0500	0375	0000	%0194	V06	\$
005573	-01734	-01872	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
005003	-02067	-02325	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
004395	-02249	-02627	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
008029	000871	002196	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
007734	001215	001853	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
007187	000679	001177	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
006457	000083	000312	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
005776	-00339	-00447	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
005372	-00879	-00922	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$
004943	-01350	-01388	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
004395	-01798	-01824	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
003833	-02022	-02175	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
007528	001342	002935	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
007237	001643	002603	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
006673	001130	001232	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
005941	000432	001080	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
005247	000000	000244	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
004594	-00213	-00501	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
004165	-00762	-00995	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
003671	-01285	-01460	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
003146	-01542	-01847	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
007020	001839	003693	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
006722	002169	003347	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
006141	001677	002615	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
005377	000900	001693	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
004689	000500	000831	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
004064	000160	000093	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
003411	-00096	-00662	0250	0250	0250	0750	0750	0750	0000	%0222	Y07	\$
002921	-00666	-01134	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
002440	-00951	-01562	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
006471	002399	004793	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
006168	002724	004461	0875	0500	0125	0125	0500	0875	0000	%0226	Z02	\$
005549	002291	003678	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
004791	001591	002712	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
004060	001018	001761	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
003419	000596	000936	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
002747	000281	001013	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
002074	000076	-00714	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
001627	-00271	-01154	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$
005811	003040	006976	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
005557	003357	006596	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
004947	002928	005736	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
004122	002183	004582	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
003397	001555	003524	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
002702	001089	002527	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
002057	000635	001584	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
001364	000300	000637	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$
000866	000002	-00040	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009234	000014	-00004	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
009183	-00019	-00069	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
008830	000147	-01074	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
007190	000467	-02178	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
006185	000829	-03836	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
005175	001450	-03816	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
004087	002218	-04566	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
002933	000151	-05238	0562	0250	1000	0875	0500	0000	0000	%0493	S17	\$
001773	000415	-05548	0500	0000	1000	0500	1000	0000	0000	%0494	S18	\$
009232	-00022	000106	0937	1000	0875	0062	0000	0125	0000	%0495	T10	\$
009160	-00025	000021	0875	0875	0875	0125	0125	0125	0000	%0496	T11	\$
008273	000148	-01009	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
007157	000484	-02123	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
006125	000853	-03024	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
005073	001539	-03836	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
004035	002250	-04556	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
002866	003231	-05238	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
001706	004491	-05639	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
009113	-00425	000874	0875	1000	0750	0125	0000	0250	0000	%0504	U10	\$
008920	-00698	000619	0812	0875	0750	0187	0125	0250	0000			

009290	-00016	000019	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$	009237	000014	000000	1000	1000	1000	0000	0000	0000	%0567	b10	\$	009246	000002	-00019	1000	1000	1000	0000	0000	0000	0000	0000	%0891	b19	\$	
009245	-00076	-00033	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$	009199	000085	-00048	0875	1000	0031	0125	0000	0000	0000	%0568	b11	\$	009219	000071	-00059	1000	0875	0906	0000	0125	0093	0000	%0892	b20	\$	
008868	-00867	-00490	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$	008407	000635	-00954	0937	0750	0062	0250	0000	0000	0000	%0569	b12	\$	008569	001200	-00773	1000	0750	0812	0000	0250	0187	0000	%0893	b21	\$	
008305	-01588	-01085	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$	007358	001176	-02007	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$	007815	002353	-01277	1000	0625	0718	0000	0375	0281	0000	%0894	b22	\$	
007659	-01919	-01684	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$	006292	001751	-02936	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$	007042	003486	-01710	1000	0500	0625	0000	0500	0375	0000	%0895	b23	\$	
007048	-02001	-02202	0375	0531	1000	0625	0478	0000	0000	%0248	b06	\$	005205	002539	-03769	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$	006295	004651	-02093	1000	0375	0531	0000	0625	0468	0000	%0896	b24	\$	
006418	-02147	-02650	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$	004161	003440	-04479	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$	005425	005653	-02303	1000	0250	0437	0000	0750	0562	0000	%0897	b25	\$	
005697	-02237	-03072	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$	003006	004508	-05148	0781	0125	1000	0217	0875	0000	0000	%0574	b17	\$	004549	006690	-02454	1000	0125	0343	0000	0875	0556	0000	%0898	b26	\$	
004827	-02136	-03398	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$	001814	005462	-05573	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$	003655	007377	-02334	1000	0000	0250	0000	1000	0750	0000	%0899	b27	\$	
003282	-00047	000118	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$	009231	-00040	000099	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$	009227	-00076	-00050	0875	1000	0968	0125	0000	0031	0000	%0900	c19	\$	
009211	-00062	000046	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$	009164	-00027	000020	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$	009186	-00046	000029	0875	0875	0875	0125	0125	0125	0000	%0901	c20	\$	
008660	-00536	-00616	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$	008334	000426	-00942	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$	008526	000985	-00431	0875	0750	0781	0125	0250	0218	0000	%0902	c21	\$	
007948	-00961	-01372	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$	007292	000953	-01194	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$	007794	002095	-00877	0875	0625	0687	0125	0375	0312	0000	%0903	c22	\$	
007298	-01276	-01967	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$	006229	001556	-02921	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$	007097	003202	-01238	0875	0500	0593	0125	0500	0406	0000	%0904	c23	\$	
006713	-01446	-02450	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$	005137	002355	-03769	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$	006182	004324	-01548	0875	0375	0500	0125	0625	0500	0000	%0905	c24	\$	
006102	-01556	-02891	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$	004090	003258	-04494	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$	005380	005382	-01808	0875	0250	0406	0125	0750	0593	0000	%0906	c25	\$	
005408	-01698	-03284	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$	002937	004362	-05170	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$	004498	006426	-01944	0875	0125	0312	0125	0875	0687	0000	%0907	c26	\$	
004684	-01667	-03564	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$	001770	005389	-05587	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$	003628	007138	-01873	0875	0000	0218	0125	1000	0781	0000	%0908	c27	\$	
009237	-00276	-000935	1000	0937	0750	0000	0682	0250	0000	%0261	d01	\$	008890	-00921	000545	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$	008847	-00857	-00519	0750	1000	0937	0250	0000	0062	0000	%0909	d19	\$	
008949	000044	006028	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$	008801	-00961	000431	0781	0875	0750	0218	0125	0250	0000	%0586	d11	\$	008785	-00928	-00188	0750	0875	0843	0250	0125	0156	0000	%0910	d20	\$	
008175	-00006	-00353	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$	008198	-00047	-00296	0750	0750	0250	0250	0250	0250	0000	%0587	d12	\$	008155	-00004	-00335	0750	0750	0750	0250	0250	0250	0000	%0911	d21	\$	
007492	-00485	-01125	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$	007179	000492	-01434	0718	0625	0750	0281	0375	0250	0000	%0588	d13	\$	007439	001069	-00691	0750	0625	0656	0250	0375	0343	0000	%0912	d22	\$	
006852	-00830	-01756	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$	006131	001065	-02444	0687	0500	0750	0312	0500	0250	0000	%0589	d14	\$	006665	002167	-00978	0750	0500	0562	0250	0500	0437	0000	%0913	d23	\$	
006303	-01046	-02263	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$	005075	001930	-03363	0656	0375	0750	0343	0625	0250	0000	%0590	d15	\$	005843	003315	-01302	0750	0375	0468	0250	0625	0531	0000	%0914	d24	\$	
005734	-01261	-02712	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$	004026	002887	-04176	0625	0250	0750	0375	0750	0250	0000	%0591	d16	\$	005027	004422	-01535	0750	0250	0375	0250	0750	0625	0000	%0915	d25	\$	
005052	-01372	-03169	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$	002842	003994	-04955	0531	0125	0750	0406	0875	0250	0000	%0592	d17	\$	004138	005598	-01792	0750	0125	0281	0250	0875	0718	0000	%0916	d26	\$	
004323	-01311	-03491	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$	001692	005143	-05425	0562	0000	0750	0437	1000	0250	0000	%0593	d18	\$	003284	006404	-01751	0750	0000	0187	0250	1000	0812	0000	%0917	d27	\$	
009110	-00472	002112	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$	008350	-02035	001176	0718	1000	0625	0281	0000	0375	0000	%0594	e10	\$	008309	-01689	-00897	0625	1000	0906	0375	0000	0093	0000	%0918	e19	\$	
008660	000120	001579	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$	008273	-02042	001062	0687	0875	0625	0312	0125	0375	0000	%0595	e11	\$	008245	-01816	-00490	0625	0875	0812	0375	0125	0187	0000	%0919	e20	\$	
007872	000013	000562	0750	0718	0875	0625	0250	0281	0375	0000	%0272	e03	\$	007703	-01231	000371	0656	0750	0625	0343	0250	0375	0000	%0596	e12	\$	007645	-01052	-00469	0625	0750	0718	0375	0250	0281	0000	%0920	e21	\$
006985	-00152	-00504	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$	007005	-00179	-00458	0625	0625	0625	0375	0375	0375	0000	%0597	e13	\$	006924	-00139	-00482	0625	0625	0625	0375	0375	0375	0000	%0921	e22	\$	
006389	-00096	-01160	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$	005995	000406	-01555	0593	0500	0625	0406	0500	0375	0000	%0598	e14	\$	006183	000806	-00774	0625	0500	0531	0375	0600	0468	0000	%0922	e23	\$	
005823	-00955	-01718	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$	004956	001285	-02602	0562	0375	0625	0437	0625	0375	0000	%0599	e15	\$	005349	002086	-01135	0625	0375	0437	0375	0625	0562	0000	%0923	e24	\$	
005243	-01044	-02265	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$	003909	002256	-03536	0531	0250	0625	0468	0750	0375	0000	%0600	e16	\$	004524	003268	-01471	0625	0250	0343	0375	0750	0656	0000	%0924	e25	\$	
004575	-01164	-03798	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$	002693	003415	-04458	0500	0125	0625	0500	0875	0375	0000	%0601	e17	\$														

```
%BEG HE08(7)_22.TXT, Separation olv*, D65, adapted $
%100 x LAB*a          %1000 x (r g b c m y o)          %nr.    pos $
%Z003612 006574 -00029 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008423 -00493 010441 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z004633 -06058 002514 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005221 -03267 -02666 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z004115 -00512 -04074 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z002523 006248 -04816 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z000860 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009259 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W1 7 $
%S
%Z003612 006574 -00029 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008423 -00493 010441 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z004633 -06058 002514 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005221 -03267 -02666 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z004115 -00512 -04074 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z002523 006248 -04816 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z000860 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009259 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W2 7 $
%S
%Z003612 006574 -00029 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008423 -00493 010441 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z004633 -06058 002514 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005221 -03267 -02666 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z004115 -00512 -04074 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z002523 006248 -04816 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z000860 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009259 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W001 7 $
%S
%Z003976 005457 004631 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008017 -01420 009984 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z004814 -05577 001069 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005286 -02949 -03041 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003074 001743 -04922 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z003449 007431 -03666 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z000822 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009245 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %W251 7 $
%S
%Z005861 003040 006976 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006524 -03978 007714 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z004984 -04891 -00306 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z005302 -02955 -03040 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z001773 004415 -05648 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z003696 007794 -03340 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z000842 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009245 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %W501 7 $
%S
%Z007532 000802 009221 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z004998 -05841 005434 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005153 -04005 -01682 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z004927 -02136 -03398 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z001814 005462 -05573 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z003665 007373 -02334 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z000864 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009258 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %W751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG HE08(7)_22.TXT, Separation olv*, D65, adapted \$																			
%100 x LAB*a										1000 x (r g b c m y o)									

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart HE18; Relative Elementary Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

TUB registration: 20091101-HE18/HE18L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IOB material: code=rha4ta

See original or copy: <http://web.me.com/kliaus.richter/HE18/HE18L0NP.PDF>/.PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

009255	-00029	-00655	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$	
009211	-00105	-00703	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$	
008816	-01009	-01207	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$	
008239	-01888	-01840	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$	
007682	-02551	-02366	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$	
007162	-03098	-02794	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$	
006627	-03400	-03100	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$	
005935	-03716	-03600	0125	0600	1000	0875	0500	0000	0000	%0169	S08	\$	
005162	-03769	-03949	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$	
009253	-00050	-00545	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$	
009178	-00072	-00622	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$	
008736	-00920	-01181	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$	
008102	-01696	-01880	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$	
007492	-02273	-02462	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$	
006960	-02670	-02919	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$	
006402	-03032	-03329	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$	
005732	-03353	-03728	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$	
004976	-03445	-04048	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$	
009042	-00097	-00010	1000	0875	0750	0000	0125	0250	0000	%0180	T10	\$	
008758	-000435	-00228	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$	
008124	-00054	-01030	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$	
007540	-00056	-01688	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$	
006991	-01628	-02261	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$	
006506	-02114	-02736	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$	
005992	-02559	-03151	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$	
005366	-02960	-03577	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$	
004679	-03158	-03897	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$	
008559	-000627	-000792	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$	
008290	-009228	-000498	0875	0750	0875	0625	0125	0250	0375	0000	%0190	V02	\$
007660	-000419	-00314	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$	
006916	-00249	-01164	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$	
006399	-01044	-01754	0500	0562	0625	0500	0437	0375	0000	%0193	V05	\$	
005956	-01642	-02218	0375	0500	0625	0625	0500	0375	0000	%0194	V06	\$	
005488	-02168	-02668	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$	
004900	-02644	-03157	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$	
004277	-02934	-03488	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$	
008069	-001159	-001605	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$	
007777	-001487	-001272	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$	
007209	-000858	-000562	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$	
006453	-000136	-00344	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$	
005750	-00412	-01141	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$	
005325	-01064	-01651	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$	
004876	-01659	-02153	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$	
004308	-02048	-02627	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$	
003730	-02592	-03009	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$	
007587	-001716	-002371	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$	
007299	-002002	-002048	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$	
006715	-001408	-001336	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$	
005956	-000600	-000450	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$	
005240	-000050	-00421	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$	
004568	-00279	-01194	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$	
004117	-00951	-01727	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$	
003602	-01618	-02232	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$	
003060	-02006	-02652	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$	
007098	-002282	-003154	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$	
006804	-002598	-002819	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$	
006203	-002034	-002058	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$	
005412	-001920	-001892	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$	
004701	-000655	-000196	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$	
004057	-000210	-00571	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$	
003384	-00177	-01357	0250	0250	0250	0750	0750	0750	0000	%0222	Y07	\$	
002871	-00808	-01872	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$	
002372	-01383	-02333	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$	
006571	-002909	-004278	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$	
006272	-003221	-003959	0875	0500	0125	0125	0125	0000	0875	0000	%0226	Z02	\$
005635	-002727	-003152	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$	
004850	-001875	-002142	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$	
004097	-001288	-001159	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$	
003435	-000777	-000303	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$	
002742	-000349	-00558	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$	
002048	-00004	-01408	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$	
001581	-00406	-01885	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$	
005988	-003601	-006463	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$	
005689	-003904	-006101	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$	
005062	-003427	-005222	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$	
004211	-002620	-004032	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$	
003462	-001934	-002943	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$	
002747	-001409	-001922	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$	
002082	-000884	-000951	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$	
001370	-000450	-00021	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$	
000853	-000038	-00727	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$	
009224	-00002	-00670	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$	
009171	-00047	-00737	0875	1000	0062	0125	0000	0000	0000	%0487	S11	\$	
008277	-00010	-01758	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$	
007144	-00045	-02878	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$	
006130	-000359	-03750	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$	
005109	-000840	-04537	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$	
004008	-001454	-05299	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$	
002843	-00232	-05996	0562	0250	1000	0500	0875	0000	0000	%0493	S17	\$	
001564	-003432	-06420	0500	0000	1000	0500	1000	0000	0000	%0494	S18	\$	
009223	-00026	-00557	0937	1000	0875	0062	0000	0125	0000	%0495	T01	\$	
009150	-00040	-00644	0875	0875	0125	0125	0125	0000	0000	%0496	T11	\$	
008248	-000000	-01692	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$	
007116	-000173	-02820	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$	
006070	-000387	-03736	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$	
005008	-000930	-04555	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$	
003957	-001490	-05288	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$	
002772	-002317	-05992	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$	
001598	-003515	-06408	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$	
009108	-003555	-000209	0875	1000	0750	0125	0000	0250	0000	%0504	U10	\$	
008995	-00673	-00062	0812	0875	0750	0187	0125	0250	0000</				

009281	-00046	-00622	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
009233	-00117	-00680	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008832	-01014	-01183	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
008243	-01865	-01828	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
007578	-02320	-02464	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
006945	-02512	-03097	0375	0531	1000	0625	0488	0000	0000	%0248	b06	\$
006308	-02776	-03484	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
005572	-02982	-03937	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$
004791	-02988	-04290	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
003274	-00667	-00523	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
002901	-00901	-00597	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
008628	-00681	-01300	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
007893	-01245	-02098	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
007223	-01687	-02729	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
006623	-01970	-03240	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
005998	-02197	-03710	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
005288	-02465	-04137	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
004551	-02529	-04445	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
00237	-02027	-00301	1000	0937	0750	0000	062	0250	0000	%0261	d01	\$
008950	000008	000000	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
008158	-00078	-01009	0750	0750	0750	0250	0500	0250	0000	%0263	d03	\$
007451	-00697	-01825	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
006791	-01172	-02493	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
006225	-01506	-03032	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
005639	-01845	-03513	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
004940	-02094	-04005	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
004198	-02137	-04357	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
009122	-00284	-001490	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
008677	-00290	-00969	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
007871	-00068	-00075	0750	0718	0875	0625	0250	0281	0375	%0272	e03	\$
006962	-00242	-01177	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
006344	-00816	-01874	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
005650	-01194	-02464	0375	0437	0625	0625	0500	0375	0000	%0275	e06	\$
005162	-01518	-03044	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$
004476	-01791	-03615	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
003745	-01806	-04022	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
008831	-00932	-02568	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
008412	000499	002047	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
007596	000241	000991	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
006674	-00199	-00128	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
005787	-00392	-01165	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
005199	-00788	-01824	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
004598	-01174	-02445	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
003918	-01458	-03086	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
003234	-01540	-03543	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
008545	000260	003634	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
008095	000087	003060	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
007315	000453	002069	0750	0656	0375	0250	0343	0625	0000	%0290	g03	\$
006459	-00076	-000937	0625	0652	0375	0375	0437	0625	0000	%0291	g04	\$
005384	-00293	-00182	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
004605	-00286	-01196	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
003988	-00687	-01905	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
003338	-01092	-02546	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
002666	-01177	-03054	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
008265	000573	004716	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
007778	001150	004075	0875	0718	0250	0125	0281	0750	0000	%0298	h02	\$
007012	000754	003099	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
006051	000161	001924	0500	0531	0250	0375	0406	0750	0000	%0300	h04	\$
005129	-00118	-000746	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
004248	-00153	-00333	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
003373	-00176	-01368	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
002709	-00545	-02108	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
002055	-00640	-02668	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
007945	001958	006120	1000	0781	0125	0000	0218	0875	0000	%0306	i01	\$
007507	001452	005533	0875	0687	0125	0125	0312	0875	0000	%0307	i02	\$
006720	001056	004525	0750	0593	0125	0250	0406	0875	0000	%0308	i03	\$
005707	000489	003206	0625	0500	0125	0375	0500	0875	0000	%0309	i04	\$
004760	000615	001963	0500	0406	0125	0500	0593	0875	0000	%0310	i05	\$
003915	-00107	-000816	0375	0312	0125	0625	0687	0875	0000	%0311	i06	\$
002901	-00053	-00323	0250	0218	0125	0750	0781	0875	0000	%0312	i07	\$
002051	-00002	-01414	0125	0125	0125	0875	0875	0875	0000	%0313	i08	\$
001402	-00091	-02094	0000	0031	0125	1000	0968	0875	0000	%0314	i09	\$
007626	001372	008613	1000	0750	0000	0000	0250	1000	0000	%0315	j01	\$
007191	001840	008019	0750	0656	0000	0125	0343	1000	0000	%0316	j02	\$
006406	001481	006910	0750	0562	0000	0250	0437	1000	0000	%0317	j03	\$
005349	000873	005427	0625	0468	0000	0375	0531	1000	0000	%0318	j04	\$
004365	000515	004042	0500	0375	0000	0500	0625	1000	0000	%0319	j05	\$
003489	000232	002806	0375	0281	0000	0625	0718	1000	0000	%0320	j06	\$
002573	000061	001529	0250	0187	0000	0750	0812	1000	0000	%0321	j07	\$
001628	000012	000261	0125	0093	0000	0875	0906	1000	0000	%0322	j08	\$
000873	000034	-00738	0000	0000	0000	1000	1000	1000	0000	%0323	j09	\$
009228	-00016	-00643	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
009191	000052	-00689	0800	0875	1000	0031	0125	0000	0000	%0568	b11	\$
008394	000512	-01595	0937	0750	1000	0062	0250	0000	0000	%0569	b12	\$
007335	000920	-02655	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$
006261	001360	-03593	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
005168	002621	-04428	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
004120	002807	-05138	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
002919	003749	-05817	0781	0250	1000	0281	0875	0000	0000	%0574	b17	\$
001755	004589	-06252	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
009223	-00061	-00542	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$
009155	-00057	-00623	0875	0875	0125	0125	0125	0000	0000	%0577	c11	\$
008316	000293	-01592	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
007265	000686	-02653	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
006193	001155	-03588	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
005095	001823	-04439	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
004042	002603	-05166	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$
002883	003581	-05848	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
001706	004504	-06278	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
000870	-00931	-00125	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$
008778	-00986	-00244	0781	0875	0750	0218	0125	0250	0000	%0586	d11	\$
008181												

```
%BEG HE08(7)_22.TXT, Separation olv*, D50, not adapted $
%100 x LAB*      %1000 x (r g b c m y o)      %nr.    pos $
%z003782 006739 -00347 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008501 000054 009774 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z004554 -06029 001620 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005085 -04028 -03588 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z003985 -01425 -04960 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z002550 005648 -05350 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z000847 000051 -00735 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009249 -00039 -00652 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W1 7 $
%S
%z003782 006739 -00347 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008501 000054 009774 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z004554 -06029 001620 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005085 -04028 -03588 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z003985 -01425 -04960 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z002550 005648 -05350 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z000847 000051 -00735 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009249 -00039 -00652 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W2 7 $
%S
%z003782 006739 -00347 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008501 000054 009774 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z004554 -06029 001620 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005085 -04028 -03588 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z003985 -01425 -04960 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z002550 005648 -05350 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M00 5 $
%z000847 000051 -00735 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009249 -00039 -00652 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W001 7 $
%S
%z004154 005900 004266 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z008074 -00880 009259 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z004720 -05726 000186 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z005146 -03754 -03959 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z002953 000778 -05752 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z003567 007132 -04007 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z000810 006048 -00696 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009235 -00005 -00674 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %W251 7 $
%S
%z005988 003601 006463 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z006519 -03572 006898 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z004876 -05256 -01187 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z005162 -03769 -03949 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z001664 003433 -06420 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z003836 007560 -03630 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z000830 000043 -00686 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009236 -00017 -00665 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %W501 7 $
%S
%z007626 001372 008613 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z004948 -05580 004555 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005029 -04601 -02574 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z004791 -02988 -04290 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z001755 004589 -06252 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z003817 007277 -02628 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z000851 000043 -00708 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009248 -00031 -00642 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %W751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG HE08(7)_22.TXT, Separation olv*, D50, not adapted \$		1000 x (r g b c m y o)										%nr. pos \$	
%100 x LAB*													
000921	000007	-00693	0000	0000	0000	1000	1000	1000	0000			%0972	k01 \$
002086	-00007	-01412	0125	0125	0125	0875	0875	0875	0000			%0973	k02 \$
003396	-00132	-01375	0250	0250	0250	0750	0750	0750	0000			%0974	k03 \$
004612	-00262	-01215	0375	0375	0375	0625	0625	0625	0000			%0975	k04 \$
005819	-00377	-01191	0500	0500	0500	0500	0500	0500	0000			%0976	k05 \$
006997	-00268	-01105	0625	0625	0625	0375	0375	0375	0000			%0977	k06 \$
008190	-00127	-00972	0750	0750	0750	0250	0250	0250	0000			%0978	k07 \$
009189	-00005	-00612	0875	0875	0875	0125	0125	0125	0000			%0979	k08 \$
009248	-00026	-00643	1000	1000	1000	0000	0000	0000	0000			%0980	k09 \$
009918	000013	-00691	0000	0000	0000	1000	1000	1000	0000			%0981	l01 \$
002085	-00001	-01412	0125	0125	0125	0875	0875	0875	0000			%0982	l02 \$
003404	-00116	-01405	0250	0250	0250	0750	0750	0750	0000			%0983	l03 \$
004607	-00254	-01229	0375	0375	0375	0625	0625	0625	0000			%0984	l04 \$
005816	-00376	-01191	0500	0500	0500	0500	0500	0500	0000			%0985	l05 \$
007004	-00260	-01183	0625	0625	0625	0375	0375	0375	0000			%0986	l06 \$
008193	-00130	-00977	0750	0750	0750	0250	0250	0250	0000			%0987	l07 \$
009191	-00089	-00610	0875	0875	0875	0125	0125	0125	0000			%0988	l08 \$
009255	-00031	-00643	1000	1000	1000	0000	0000	0000	0000			%0989	l09 \$
009906	000020	-00712	0000	0000	0000	1000	1000	1000	0000			%0990	m01 \$
002071	000008	-01427	0125	0125	0125	0875	0875	0875	0000			%0991	m02 \$
003394	-00119	-01401	0250	0250	0250	0750	0750	0750	0000			%0992	m03 \$
004600	-00237	-01263	0375	0375	0375	0625	0625	0625	0000			%0993	m04 \$
005799	-00368	-01208	0500	0500	0500	0500	0500	0500	0000			%0994	m05 \$
006988	-00268	-01166	0625	0625	0625	0375	0375	0375	0000			%0995	m06 \$
008186	-00127	-00972	0750	0750	0750	0250	0250	0250	0000			%0996	m07 \$
009185	-00091	-00609	0875	0875	0875	0125	0125	0125	0000			%0997	m08 \$
009247	-00036	-00641	1000	1000	1000	0000	0000	0000	0000			%0998	m09 \$
009904	000019	-00693	0000	0000	0000	1000	1000	1000	0000			%0999	n01 \$
002076	000007	-01416	0125	0125	0125	0875	0875	0875	0000			%1000	n02 \$
003385	-00120	-01405	0250	0250	0250	0750	0750	0750	0000			%1001	n03 \$
004588	-00238	-01261	0375	0375	0375	0625	0625	0625	0000			%1002	n04 \$
005805	-00378	-01192	0500	0500	0500	0500	0500	0500	0000			%1003	n05 \$
006981	-00262	-01168	0625	0625	0625	0375	0375	0375	0000			%1004	n06 \$
008174	-00125	-00983	0750	0750	0750	0250	0250	0250	0000			%1005	n07 \$
009182	-00093	-00606	0875	0875	0875	0125	0125	0125	0000			%1006	n08 \$
009240	-00040	-00639	1000	1000	1000	0000	0000	0000	0000			%1007	n09 \$
008074	000031	-00736	0000	0000	0000	1000	1000	1000	0000			%1008	k10 \$
001427	000097	-01232	0066	0066	0066	0933	0933	0933	0000			%1009	k11 \$
002159	-00026	-01437	0133	0133	0133	0866	0866	0866	0000			%1010	k12 \$
002848	-00179	-01402	0200	0200	0200	0800	0800	0800	0000			%1011	k13 \$
003568	-00160	-01356	0266	0266	0266	0733	0733	0733	0000			%1012	k14 \$
004232	-00197	-01209	0333	0333	0333	0666	0666	0666	0000			%1013	k15 \$
004865	-00314	-01213	0400	0400	0400	0600	0600	0600	0000			%1014	k16 \$
005499	-00382	-01195	0466	0466	0466	0533	0533	0533	0000			%1015	k17 \$
006136	-00404	-01128	0533	0533	0533	0466	0466	0466	0000			%1016	k18 \$
006734	-00297	-01142	0600	0600	0600	0399	0399	0399	0000			%1017	k19 \$
007359	-00163	-01144	0666	0666	0666	0333	0333	0333	0000			%1018	k20 \$
008000	-00097	-01020	0733	0733	0733	0266	0266	0266	0000			%1019	k21 \$
008581	-00052	-00856	0800	0800	0800	0199	0199	0199	0000			%1020	k22 \$
009145	-00111	-00590	0866	0866	0866	0133	0133	0133	0000			%1021	k23 \$
009271	-00045	-00633	0933	0933	0933	0066	0066	0066	0000			%1022	k24 \$
009251	-00026	-00645	1000	1000	1000	0000	0000	0000	0000			%1023	k25 \$
008085	000032	-00747	0000	0000	0000	1000	1000	1000	0000			%1024	l10 \$
001426	000102	-01244	0066	0066	0066	0933	0933	0933	0000			%1025	l11 \$
002147	-00008	-01468	0133	0133	0133	0866	0866	0866	0000			%1026	l12 \$
002854	-00172	-01418	0200	0200	0200	0800	0800	0800	0000			%1027	l13 \$
003569	-00156	-01358	0266	0266	0266	0733	0733	0733	0000			%1028	l14 \$
004228	-00182	-01230	0333	0333	0333	0666	0666	0666	0000			%1029	l15 \$
004868	-00305	-01221	0400	0400	0400	0600	0600	0600	0000			%1030	l16 \$
005491	-00390	-01190	0466	0466	0466	0533	0533	0533	0000			%1031	l17 \$
006132	-00401	-01135	0533	0533	0533	0466	0466	0466	0000			%1032	l18 \$
006747	-00298	-01134	0600	0600	0600	0399	0399	0399	0000			%1033	l19 \$
007377	-00163	-01146	0666	0666	0666	0333	0333	0333	0000			%1034	l20 \$
008008	-00099	-01022	0733	0733	0733	0266	0266	0266	0000			%1035	l21 \$
008584	-00057	-00862	0800	0800	0800	0199	0199	0199	0000			%1036	l22 \$
009144	-00117	-00594	0866	0866	0866	0133	0133	0133	0000			%1037	l23 \$
009255	-00045	-00641	0933	0933	0933	0066	0066	0066	0000			%1038	l24 \$
009249	-00028	-00642	1000	1000	1000	0000	0000	0000	0000			%1039	l25 \$
008061	000042	-00761	0000	0000	0000	1000	1000	1000	0000			%1040	m10 \$
001411	000117	-01256	0066	0066	0066	0933	0933	0933	0000			%1041	m11 \$
002127	000001	-01481	0133	0133	0133	0866	0866	0866	0000			%1042	m12 \$
002837	-00159	-01431	0200	0200	0200	0800	0800	0800	0000			%1043	m13 \$
003552	-00159	-01366	0266	0266	0266	0733	0733	0733	0000			%1044	m14 \$
004225	-00185	-01244	0333	0333	0333	0666	0666	0666	0000			%1045	m15 \$
004845	-00305	-01234	0400	0400	0400	0600	0600	0600	0000			%1046	m16 \$
005485	-00376	-01207	0466	0466	0466	0533	0533	0533	0000			%1047	m17 \$
006117	-00403	-01133	0533	0533	0533	0466	0466	0466	0000			%1048	m18 \$
006727	-00304	-01124	0600	0600	0600	0399	0399	0399	0000			%1049	m19 \$
007362	-00164	-01138	0666	0666	0666	0333	0333	0333	0000			%1050	m20 \$
008003	-00099	-01018	0733	0733	0733	0266	0266	0266	0000			%1051	m21 \$
008572	-00060	-00859	0800	0800	0800	0199	0199	0199	0000			%1052	m22 \$

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart HE18; Relative Elementary Colour System C
1080 spectral reflexions R -> LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

TUB registration: 20091101-HE18/HE18LONP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfl=1.00; nt=0.18; nx=1.00

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfl=1.00; nt=0.18; nx=1.00

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009255	-00012	000010	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
009211	-00088	-00037	0875	0937	1000	0125	0662	0000	0000	%0163	S02	\$
008816	-00995	-00540	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
008239	-01878	-01171	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
007682	-02545	-01697	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
007162	-03096	-02123	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
006627	-03402	-02508	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
005938	-03722	-02926	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$
005162	-03781	-03273	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
004253	-00063	-000120	1000	0937	0875	0000	0662	0125	0000	%0171	T01	\$
004178	-00956	-00043	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
008736	-00966	-00514	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
008102	-01687	-01211	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
007492	-02268	-01792	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
006960	-02669	-02247	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
006402	-03035	-02656	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
005732	-03361	-03053	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
004976	-03459	-03371	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
004042	-00112	-00076	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
003758	-00049	-000438	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
008124	-00045	-000361	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
007540	-00951	-01018	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
006991	-01627	-01590	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
006506	-02116	-02064	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
005992	-02565	-02477	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
005366	-02971	-02901	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
004679	-03174	-03220	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
008559	-000639	-001459	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
008298	-009938	-001166	0875	0750	0875	0625	0125	0250	0375	%0190	V02	\$
007660	-000425	-000354	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
006916	-00249	-00493	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
006398	-01047	-01081	0500	0562	0625	0500	0437	0375	0000	%0193	V05	\$
005956	-01648	-01544	0375	0500	0625	0625	0500	0375	0000	%0194	V06	\$
005488	-02178	-01993	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
004900	-02658	-02480	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
004277	-02952	-02810	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
008069	-001167	-002274	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
007777	-001494	-001941	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
007209	-000861	-001233	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
006453	-000133	-000327	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
005750	-00420	-00466	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
005325	-01075	-00976	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$
004876	-01673	-01477	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
004308	-02266	-01949	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
003730	-02614	-02330	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
007587	-001721	-003041	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
007299	-002005	-002719	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
006715	-001407	-002008	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
005956	-000594	-001124	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
005240	-000039	-000254	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
004458	-00296	-00516	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
004177	-00970	-01048	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
003602	-01642	-01552	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
003060	-02034	-01970	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
007098	-002284	-003825	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
006804	-002598	-003491	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
006203	-002029	-002732	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
005412	-001627	-001768	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
004701	-000639	-000873	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
004057	-000190	-000107	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
003384	-00202	-00677	0250	0250	0250	0750	0750	0750	0000	%0222	Y07	\$
002871	-00912	-01199	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
002372	-01340	-01650	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
006571	-002907	-004951	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
006272	-003217	-004632	0875	0500	0125	0125	0125	0800	0875	%0226	Z02	\$
005635	-002718	-003827	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
004850	-001861	-002819	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
004097	-001268	-001837	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
003435	-000752	-000984	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
002742	-000319	-000123	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
002048	-00038	-00725	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
001581	-00524	-01200	0000	0662	0125	1000	0937	0875	0000	%0233	Z09	\$
005988	-003594	-007137	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
005689	-003895	-006775	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
005062	-003414	-005898	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
004211	-002601	-004711	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
003462	-001910	-003623	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
002747	-001379	-002603	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
002082	-000850	-001634	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
001370	-000411	-000664	0125	0662	0000	0875	0937	1000	0000	%0241	A08	\$
008583	-00004	-000041	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009224	-000014	-00004	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
009171	-00030	-00071	0937	0875	1000	0662	0125	0000	0000	%0487	S11	\$
008277	-000000	-01090	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
007147	-000147	-02207	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
006130	-000354	-03077	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
005109	-000827	-03861	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
004008	-001434	-04620	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
002843	-002004	-053	0562	0250	1000	0875	0500	0000	0000	%0493	S17	\$
001624	-001524	-07335	0500	0000	1000	0500	1000	0000	0000	%0494	S18	\$
009223	-000009	-000108	0937	1000	0875	0662	0000	0125	0000	%0495	T01	\$
009150	-00024	-000021	0875	0875	0875	0125	0125	0125	0000	%0496	T11	\$
008248	-000010	-01024	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
007116	-000175	-02149	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
006070	-000382	-03063	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
005008	-000916	-03879	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
003957	-001469	-04609	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
002772	-002288	-05310	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
001598	-003477	-05723	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
009108	-003339	-008075	0875	1000	0750	0125	0000	0250	0000	%0504	U10	\$
008995	-00658	-000604	0812	0875	0750	0187	0125	0250	0000	%		

009281	-00014	-000019	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
009233	-00085	-00037	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008832	-00985	-00537	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
008243	-01842	-01178	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
007578	-02303	-01808	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
006945	-02501	-02346	0375	0531	1000	0625	0488	0000	0000	%0248	b06	\$
006308	-02770	-02818	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
005572	-02993	-03205	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$
004791	-02906	-03612	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
003274	-00000	-000118	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
002901	-00060	-000045	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
008628	-00654	-00652	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
007893	-0125	-01445	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
007223	-01673	-02070	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
006623	-01961	-02577	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
005998	-02195	-03041	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
005288	-02469	-03463	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
004551	-02540	-03766	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
002327	-00175	-000944	1000	0937	0750	0000	062	0250	0000	%0261	d01	\$
008950	000127	000645	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
008158	-00055	-00358	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$
007451	-00061	-01168	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
006791	-01162	-01831	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
006225	-01501	-02365	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
005639	-01846	-02842	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
004940	-02101	-03328	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
004198	-02151	-03675	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
009122	-00253	002134	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
008677	000316	000617	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
007871	000088	000577	0750	0718	0625	0250	0281	0375	0000	%0272	e03	\$
006962	-00231	-00516	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
006344	-00810	-01208	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
005670	-01194	-01704	0375	0437	0625	0625	0562	0375	0000	%0275	e06	\$
005162	-01523	-02370	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$
004476	-01802	-02934	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
003745	-01824	-03336	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
008831	-00904	-03214	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
008412	000524	002696	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
007596	000258	001646	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
006674	-00190	-000534	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
005787	-00391	-00496	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
005199	-00793	-01149	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
004598	-01184	-01765	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
003918	-01474	-02401	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
003234	-01562	-02853	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
008545	000266	004283	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
008095	000829	003711	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
007315	000468	002727	0750	0656	0375	0250	0343	0625	0000	%0290	g03	\$
006384	-00070	-001602	0625	0562	0375	0375	0437	0625	0000	%0291	g04	\$
005459	-00295	-000948	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
004605	-00296	-00517	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
003988	-00703	-01212	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
003338	-01113	-01857	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
002666	-01204	-02359	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
002625	000596	005367	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
007778	001169	004729	0875	0718	0250	0125	0281	0750	0000	%0298	h02	\$
007012	000765	003760	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
006051	000164	002591	0625	0531	0250	0375	0406	0750	0000	%0300	h04	\$
005129	-00123	-001421	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
004248	-00166	-000348	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
003373	-00197	-00680	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
002709	-00572	-01414	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
002055	-00673	-01969	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
007945	000979	006773	1000	0781	0125	0000	0218	0875	0000	%0306	i01	\$
007507	001469	006189	0875	0687	0125	0125	0312	0875	0000	%0307	i02	\$
006720	001065	005188	0750	0593	0125	0250	0406	0875	0000	%0308	i03	\$
005707	000489	003877	0625	0500	0125	0375	0500	0875	0000	%0309	i04	\$
004760	001016	002641	0500	0406	0125	0500	0593	0875	0000	%0310	i05	\$
003915	-00033	-001501	0375	0312	0125	0625	0687	0875	0000	%0311	i06	\$
002991	-00078	-000368	0250	0218	0125	0750	0781	0875	0000	%0312	i07	\$
002051	-00035	-00715	0125	0125	0125	0875	0875	0875	0000	%0313	i08	\$
001402	-00129	-01390	0000	0031	0125	1000	0968	0875	0000	%0314	i09	\$
007626	001399	009269	1000	0750	0000	0000	0250	1000	0000	%0315	j01	\$
007191	001854	008678	0875	0656	0000	0125	0343	1000	0000	%0316	j02	\$
006406	001487	007575	0750	0562	0000	0250	0437	1000	0000	%0317	j03	\$
005349	000870	006101	0625	0468	0000	0375	0531	1000	0000	%0318	j04	\$
004365	000503	004723	0500	0375	0000	0500	0625	1000	0000	%0319	j05	\$
003489	000212	003494	0375	0281	0000	0625	0718	1000	0000	%0320	j06	\$
002573	000033	002224	0250	0187	0000	0750	0812	1000	0000	%0321	j07	\$
001628	-00023	-000964	0125	0093	0000	0875	0906	1000	0000	%0322	j08	\$
000873	-00008	-000030	0000	0000	0000	1000	1000	1000	0000	%0323	j09	\$
009228	000015	000000	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
009191	000083	-00046	0875	1000	0031	0125	0000	0000	0000	%0568	b11	\$
008394	000536	-00946	0937	0750	0062	0250	0000	0000	0000	%0569	b12	\$
007335	000935	-01998	0968	0625	1000	0963	0375	0000	0000	%0570	b13	\$
006261	001365	-02926	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
005168	002017	-03753	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
004120	002792	-04455	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
002499	003724	-051	0781	0250	1000	0281	0875	0000	0000	%0574	b17	\$
001755	004553	-05550	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
009223	-00030	000100	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$
009155	-00026	000020	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$
008316	000317	-00942	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
007265	000700	-01995	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
006193	001159	-02921	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
005095	001817	-03763	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
004042	002589	-04483	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$
002883	003555	-05155	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
001706	004468	-05576	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
000870	-00902	000520	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$
008778	-00959	000402	0781	0875	0750	0218	0125	0250	0000	%0586	d11	\$

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG HE08(7)_22.TXT, Separation olv*, D50, adapted $
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr.    pos $
%Z003782 006719 000359 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008501 000086 010434 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z004554 -06041 002319 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005085 -04034 -02894 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003985 -01443 -04255 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z002550 005615 -04632 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z000847 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009249 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z003782 006719 000359 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008501 000086 010434 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z004554 -06041 002319 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005085 -04034 -02894 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003985 -01443 -04255 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z002550 005615 -04632 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z000847 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009249 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z003782 006719 000359 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008501 000086 010434 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z004554 -06041 002319 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005085 -04034 -02894 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003985 -01443 -04255 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z002550 005615 -04632 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z000847 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009249 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z004154 005873 004954 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008074 -00882 009937 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z004720 -05749 000873 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005146 -03775 -03273 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z002953 000743 -05061 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z003567 007101 -03318 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z000810 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009235 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z005988 003594 007137 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006519 -03574 007570 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z004876 -05271 -00511 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z005162 -03781 -03273 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z001664 003396 -05735 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z003836 007538 -02951 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z000830 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009236 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z007626 001390 009269 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z004948 -05587 005231 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005029 -04607 -01899 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z004791 -02996 -03612 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z001755 004553 -05550 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z003817 007260 -01943 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z000851 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009248 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/HE18/HE18L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG HE08(7)_22.TXT, Separation olv*, D50, adapted $
%100 x LAB*a      1000 x (r g b c m y 0)      %nr. pos $
000921 -00045 -00006 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002086 -00048 -00732 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003396 -00160 -00704 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004612 -00278 -00552 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005819 -00380 -00537 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006997 -00259 -00519 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
008190 -00106 -00334 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
009189 -00054 -000919 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009248 000005 -00012 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
009916 -00039 -00003 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002085 -00042 -00732 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003404 -00143 -00734 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004607 -00270 -00567 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005816 -00379 -00537 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
007004 -00251 -00537 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
008193 -00109 -00338 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
009191 -00058 0000221 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009255 000000 -00011 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
009906 -00032 -00024 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002071 -00032 -00747 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003394 -00147 -00730 0250 0250 0250 0750 0750 0750 0000 %0992 k03 $
004600 -00252 -00600 0375 0375 0375 0625 0625 0625 0000 %0993 k04 $
005799 -00371 -00553 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006988 -00259 -00520 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
008186 -00107 -00333 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
009185 -00060 -00022 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009247 -00005 -00009 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
009904 -00033 -00006 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002076 -00033 -00737 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003385 -00148 -00734 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004588 -00254 -00598 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005805 -00381 -00537 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006984 -00254 -00521 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
008174 -00104 -00344 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
009182 -00062 -00025 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009240 -00009 -00008 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
009874 -00022 -00048 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
001427 000049 -00548 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002159 -00066 -00758 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
002848 -00212 -00727 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
003568 -00186 -00686 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
004232 -00217 -00544 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
004865 -00327 -00553 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005499 -00388 -00538 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
006136 -00404 -00475 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006734 -00291 -00494 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
007359 -00150 -00500 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
008000 -00078 -00380 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
008581 -00027 -00220 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
009145 -00081 000041 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
009271 -00014 -00002 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009251 000005 -00013 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
009885 -00021 -00059 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
001426 000054 -00560 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
002147 -00049 -00789 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
002854 -00205 -00744 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
003569 -00182 -00689 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
004228 -00201 -00665 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
004868 -00318 -00560 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005491 -00397 -00533 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
006132 -00401 -00483 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006747 -00292 -00485 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
007377 -00151 -00502 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
008008 -00080 -00382 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
008584 -00032 -00226 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
009144 -00086 000037 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
009255 -00013 -00010 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009249 000002 -00011 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
008061 -00010 -00073 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
001411 000069 -00571 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002127 -00038 -00802 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
002837 -00192 -00756 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
003552 -00185 -00696 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
004225 -00204 -00579 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
004845 -00318 -00573 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005485 -00383 -00550 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
006117 -00403 -00480 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006727 -00298 -00476 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
007362 -00151 -00494 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
008003 -00080 -00378 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
008572 -00035 -00223 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB registration: 20091101-HE18/HE18L0NP.PDF /.PS
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta