

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart HE19; Relative Elementary Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

input: w *setgray*
output: no change compared to input

TUB registration: 20091101-HE19/HE19L0NP.PDF/.PSS
application for evaluation and measurement of printer on

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/HE19/HE19L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.70; nt=0.18; nx=1.00

[illegible]

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009270	000036	-00642	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009223	-00021	-00694	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008855	-00822	-01148	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
008287	-01572	-01746	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
007743	-02103	-02243	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
007249	-02449	-02638	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006713	-02721	-03012	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
00645	-02918	-03400	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005286	-02850	-03722	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
009249	000026	-00552	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
009181	-00003	-00618	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
008800	-00829	-01042	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
008249	-01600	-01593	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
007700	-02165	-02078	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
007199	-02527	-02474	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
006664	-02831	-02832	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
006011	-03031	-03216	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
005248	-03067	-03521	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
008617	-000798	-00439	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
008544	000758	-00463	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
008100	000088	-01045	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
007619	-01083	-01521	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
007143	-01526	-01944	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
006715	-02028	-02310	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
006234	-02487	-02604	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
005650	-02831	-02961	0125	0593	0750</							

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009264	000032	-006334	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
009223	000033	-006078	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
008853	-008225	-011440	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
008302	-01567	-017728	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
007766	-02104	-022220	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
007262	-02451	-02622	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
006741	-02733	-02984	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
00668	-02919	-03300	0125	0562	1000	0875	0507	0000	0000	%0169	S08	\$
005302	-02865	-03712	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
009261	000000	-00525	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
009188	-00012	-00600	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
008770	-00743	-01119	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
008162	-01377	-01776	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
007572	-01823	-02326	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
007056	-02106	-02758	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
006513	-02352	-03145	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
005858	-02546	-03519	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
005113	-02534	-03821	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
009039	000064	000104	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
008754	000425	-00236	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
008141	000061	-01009	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
007583	-00609	-01623	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
007057	-02498	-02159	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
006590	-01606	-02606	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
006091	-01931	-02994	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
005482	-02197	-03391	0125	0437	0750	0875	0562	0250	0000	%0187		

See original or copy: <http://web.me.com/klaus.richter/HE19/HE19L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.70; nt=0.18; nx=1.0

```
%BEG HE09(7)_22.TXT, Separation olv*, D65, not adapted $
%100 x LAB*
%#1000 x (r g b c m y o)
%nr. pos $
%z003612 006686 -00739 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008423 -00457 009798 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z004633 -05962 001817 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005221 -03180 -03354 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z004115 -00408 -04778 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z002523 006378 -05542 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z000860 000156 -00749 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009259 000022 -00630 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%z003612 006686 -00739 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008423 -00457 009798 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z004633 -05962 001817 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005221 -03180 -03354 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z004115 -00408 -04778 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z002523 006378 -05542 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z000860 000156 -00749 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009259 000022 -00630 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%z003612 006686 -00739 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008423 -00457 009798 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z004633 -05962 001817 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005221 -03180 -03354 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z004115 -00408 -04778 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z002523 006378 -05542 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z000860 000156 -00749 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009259 000022 -00630 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%z003976 005571 003941 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z008017 -01349 009321 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z004814 -05472 000385 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z005286 -02850 -03722 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003074 001860 -05618 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z003449 007550 -04360 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z000822 000146 -00711 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009245 000058 -00654 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%z005861 003124 006308 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z006524 -03902 007051 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z004984 -04798 -00980 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z005302 -02865 -03712 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z001773 004544 -06344 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z003696 007903 -04023 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z000842 000140 -00701 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009245 000045 -00644 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%z007532 000855 008579 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z004998 -05754 004761 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005153 -03920 -02354 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z004927 -02048 -04072 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z001814 005593 -06285 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z003665 007478 -03023 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z000864 000143 -00723 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009258 000029 -00621 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```


TUB registration: 20091101-HE19/HE19L0NP.PDF /.PS TUB material: code=rh4ta
application for evaluation and measurement of printer or monitor systems

009264	-00012	000010	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
009223	-00079	-00033	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
008853	-00875	-00492	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
008302	-01624	-01077	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
007766	-02167	-01565	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
007262	-02519	-01964	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
006741	-02806	-02322	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
00668	-03000	-02714	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$
005302	-02955	-03040	0000	0562	1000	1000	0500	0000	0000	%0170	S09	\$
009261	-00045	000119	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
009188	-00905	000044	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
008770	-00794	-00471	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
008162	-01435	-01124	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
007572	-01888	-01678	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
007066	-02176	-02099	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
006513	-02428	-02482	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
005858	-02630	-02852	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
005113	-02626	-03148	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
009039	000016	000750	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
008754	000374	000411	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
008141	000093	-00357	0570	0750	0750	0250	0500	0250	0000	%0182	U03	\$
007583	-00763	-00967	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
007057	-01310	-01500	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
006590	-01682	-01943	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
006091	-02012	-02328	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
005482	-02285	-02721	0125	0437	0750	0875	0562	0250	0000			

009290	-00016	000019	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$	009237	000014	000000	1000	1000	1000	0000	0000	0000	%0567	b10	\$	009246	000002	-00019	1000	1000	1000	0000	0000	0000	0000	0000	%0891	b19	\$
009245	-00076	-00033	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$	009199	000085	-00048	0875	1000	0031	0125	0000	0000	0000	%0568	b11	\$	009219	000071	-00059	1000	0875	0906	0000	0125	0093	0000	%0892	b20	\$
008868	-00867	-00490	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$	008407	000635	-00954	0937	0750	0062	0250	0000	0000	0000	%0569	b12	\$	008569	001200	-00773	1000	0750	0812	0000	0250	0187	0000	%0893	b21	\$
008305	-01588	-01085	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$	007358	001176	-02007	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$	007815	002353	-01277	1000	0625	0718	0000	0375	0281	0000	%0894	b22	\$
007659	-01919	-01684	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$	006292	001751	-02936	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$	007042	003486	-01710	1000	0500	0625	0000	0500	0375	0000	%0895	b23	\$
007048	-02001	-02202	0375	0531	1000	0625	0478	0000	0000	%0248	b06	\$	005205	002539	-03769	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$	006295	004651	-02093	1000	0375	0531	0000	0625	0468	0000	%0896	b24	\$
006418	-02147	-02650	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$	004161	003440	-04479	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$	005425	005653	-02303	1000	0250	0437	0000	0750	0562	0000	%0897	b25	\$
005697	-02237	-03072	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$	003006	004508	-05148	0781	0125	1000	0217	0875	0000	0000	%0574	b17	\$	004549	006690	-02454	1000	0125	0343	0000	0875	0556	0000	%0898	b26	\$
004827	-02136	-03398	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$	001814	005462	-05573	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$	003655	007377											

See original or copy: <http://web.me.com/klaus.richter/HE19/HE19L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.70; nt=0.18; nx=1.0

```
%BEG HE09(7)_22.TXT, Separation olv*, D65, adapted $
%100 x LAB*a      %1000 x (r g b c m y o)      %nr.    pos $
%z003612 006574 -00029 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008423 -00493 010441 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z004633 -06058 002514 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005221 -03267 -02666 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z004115 -00512 -04074 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z002523 006248 -04816 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z000860 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009259 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W1 7 $
%S
%z003612 006574 -00029 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008423 -00493 010441 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z004633 -06058 002514 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005221 -03267 -02666 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z004115 -00512 -04074 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z002523 006248 -04816 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z000860 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009259 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W2 7 $
%S
%z003612 006574 -00029 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008423 -00493 010441 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z004633 -06058 002514 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005221 -03267 -02666 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z004115 -00512 -04074 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z002523 006248 -04816 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z000860 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009259 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W001 7 $
%S
%z003976 005457 004631 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z008017 -01420 009984 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z004814 -05577 001069 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z005286 -02949 -03041 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003074 001743 -04922 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z003449 007431 -03666 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z000822 006000 000000 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009245 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %W251 7 $
%S
%z005861 003040 006976 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z006524 -03978 007714 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z004984 -04891 -00306 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z005302 -02955 -03040 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z001773 004415 -05648 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z003696 007794 -03340 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z000842 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009245 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %W501 7 $
%S
%z007532 000802 009221 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z004998 -05841 005434 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005153 -04005 -01682 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z004927 -02136 -03398 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z001814 005462 -05573 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z003665 007373 -02334 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z000864 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009258 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %W751 7 $
%S
```


N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-HE19/HE19L0NP.PDF/.PS
- application for evaluation and measurement of printer or

TUB material: code=rha4ta

TUB-test chart HE19; Relative Elementary Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/HE19/HE19L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.70; nt=0.18; nx=1.00

[illegible]

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009255	-00029	-00655	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
009211	-00105	-00703	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
008816	-01009	-01207	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
008239	-01888	-01840	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
007682	-02551	-02366	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
007162	-03098	-02794	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
006627	-03400	-03100	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
005935	-03716	-03600	0125	0602	1000	0875	0500	0000	0000	%0169	S08	\$
005162	-03769	-03949	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
009253	-00050	-00545	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
009178	-00072	-00622	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
008736	-00920	-01181	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
008102	-01696	-01880	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
007492	-02273	-02462	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
006960	-02670	-02919	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
006402	-03032	-03329	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
005732	-03353	-03728	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
004976	-03445	-04048	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
009042	-00097	-00010	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
008758	-000435	-00228	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
008124	-00054	-01030	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
007540	-00056	-01688	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
006991	-01628	-02261	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
006506	-02114	-02736	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
005992	-02559	-03151	0250	0500	0750	0750	0500	025				

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009281	-00046	-00622	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$	009228	-00016	-00643	1000	1000	1000	0000	0000	0000	%0567	b10	\$	009236	-00032	-00662	1000	1000	1000	0000	0000	0000	0000	%0891	b19	\$	
009233	-00117	-00680	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$	009191	000052	-00689	0880	0875	1000	0031	0125	0000	0000	%0568	b11	\$	009210	000035	-00700	1000	0875	0906	0000	0125	0093	0000	%0892	b20	\$
008832	-01014	-01183	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$	008394	000512	-01595	0937	0750	1000	0062	0250	0000	0000	%0569	b12	\$	008572	001136	-01383	1000	0750	0812	0000	0250	0187	0000	%0893	b21	\$
008243	-01865	-01828	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$	007335	000920	-02655	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$	007835	002287	-01847	1000	0625	0718	0000	0375	0281	0000	%0894	b22	\$
007578	-02320	-02464	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$	006261	001360	-03593	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$	007080	003418	-02237	1000	0500	0625	0000	0500	0375	0000	%0895	b23	\$
006945	-02512	-03097	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$	005168	002021	-04428	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$	006266	004580	-02570	1000	0375	0531	0000	0625	0468	0000	%0896	b24	\$
006308	-02776	-03484	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$	004120	002807	-05138	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$	005512	005583	-02730	1000	0250	0437	0000	0750	0562	0000	%0897	b25	\$
005572	-02982	-03937	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$	002499	003749	-05817	0781	0250	1000	0287	0875	0000	0000	%0574	b17	\$	004667	006607	-02816	1000	0125	0343	0000	0875	0556	0000	%0898	b2	

See original or copy: <http://web.me.com/klaus.richter/HE19/HE19L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.70; nt=0.18; nx=1.0

TUB registration: 20091101-HE19/HE19L0NP.PDF /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

```
%BEG HE09(7)_22.TXT, Separation olv*, D50, not adapted $
%100 x LAB*          %1000 x (r g b c m y o)          %nr.   pos $
%z003782 006739 -00347 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008501 000054 009774 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z004554 -06029 001620 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005085 -04028 -03588 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z003985 -01425 -04960 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z002550 005648 -05350 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z000847 000051 -00735 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009249 -00039 -00652 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W1 7 $
%S
%z003782 006739 -00347 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008501 000054 009774 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z004554 -06029 001620 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005085 -04028 -03588 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z003985 -01425 -04960 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z002550 005648 -05350 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z000847 000051 -00735 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009249 -00039 -00652 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W2 7 $
%S
%z003782 006739 -00347 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008501 000054 009774 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z004554 -06029 001620 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005085 -04028 -03588 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z003985 -01425 -04960 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z002550 005648 -05350 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z000847 000051 -00735 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009249 -00039 -00652 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W001 7 $
%S
%z004154 005900 004266 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z008074 -00880 009259 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z004720 -05726 000186 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z005146 -03754 -03959 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z002953 000778 -05752 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z003567 007132 -04007 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z000810 006048 -00696 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009235 -00005 -00674 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %W251 7 $
%S
%z005988 003601 006463 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z006519 -03572 006898 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z004876 -05256 -01187 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z005162 -03769 -03949 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z001664 003433 -06420 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z003836 007560 -03630 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z000830 000043 -00686 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009236 -00017 -00665 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %W501 7 $
%S
%z007626 001372 008613 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z004948 -05580 004555 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005029 -04601 -02574 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z004791 -02988 -04290 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z001755 004589 -06252 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z003817 007277 -02628 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z000851 000043 -00708 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009248 -00031 -00642 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %W751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/HE19/HE19L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.70; nt=0.18; nx=1.0

%BEG HE09(7)_22.TXT, Separation olv*, D50, not adapted S		1000 x (r g b c m y o)										%nr. pos \$	
%100 x LAB*													
000921	000007	-00693	0000	0000	0000	1000	1000	1000	0000			%0972	k01 \$
002086	-00007	-01412	0125	0125	0125	0875	0875	0875	0000			%0973	k02 \$
003396	-00132	-01375	0250	0250	0250	0750	0750	0750	0000			%0974	k03 \$
004612	-00262	-01215	0375	0375	0375	0625	0625	0625	0000			%0975	k04 \$
005819	-00377	-01191	0500	0500	0500	0500	0500	0500	0000			%0976	k05 \$
006997	-00268	-01105	0625	0625	0625	0375	0375	0375	0000			%0977	k06 \$
008190	-00127	-00972	0750	0750	0750	0250	0250	0250	0000			%0978	k07 \$
009189	-00005	-00612	0875	0875	0875	0125	0125	0125	0000			%0979	k08 \$
009248	-00026	-00643	1000	1000	1000	0000	0000	0000	0000			%0980	k09 \$
009918	000013	-00691	0000	0000	0000	1000	1000	1000	0000			%0981	l01 \$
002085	-00001	-01412	0125	0125	0125	0875	0875	0875	0000			%0982	l02 \$
003404	-00116	-01405	0250	0250	0250	0750	0750	0750	0000			%0983	l03 \$
004607	-00254	-01229	0375	0375	0375	0625	0625	0625	0000			%0984	l04 \$
005816	-00376	-01191	0500	0500	0500	0500	0500	0500	0000			%0985	l05 \$
007004	-00260	-01183	0625	0625	0625	0375	0375	0375	0000			%0986	l06 \$
008193	-00130	-00977	0750	0750	0750	0250	0250	025					

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009255	-00012	000010	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
009211	-00088	-00037	0875	0937	1000	0125	0662	0000	0000	%0163	S02	\$
008816	-00995	-00540	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
008239	-01878	-01171	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
007682	-02545	-01697	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
007162	-03096	-02123	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
006627	-03402	-02508	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
005938	-03722	-02926	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$
005162	-03781	-03273	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
004253	-00063	-000120	1000	0937	0875	0000	0662	0125	0000	%0171	T01	\$
004178	-00956	-00043	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
008736	-00967	-00514	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
008102	-01688	-01211	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
007492	-02268	-01792	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
006960	-02669	-02247	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
006402	-03035	-02656	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
005732	-03361	-03053	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
004976	-03459	-03371	0000	0437	0875	1000	0562	0125				

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009281	-00014	-000019	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
009233	-00085	-00037	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008832	-00985	-00537	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
008243	-01842	-01178	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
007578	-02303	-01808	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
006945	-02501	-02346	0375	0531	1000	0625	0488	0000	0000	%0248	b06	\$
006308	-02770	-02818	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
005572	-02993	-03205	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$
004791	-02906	-03612	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
003274	-00000	-000118	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
002901	-00060	-000045	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
008628	-00654	-00652	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
007893	-0125	-01445	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
007223	-01673	-02070	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
006623	-01961	-02577	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
005998	-02195	-03041	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
005288	-02469	-03463	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
004551	-02540	-03766	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
002327	-00175	-000944	1000	0937	0750	0000	062	0250	0000	%0261	d01	\$
008950	000127	000645	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
008158	-00055	-00358	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$
007451	-00061	-01168	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
006791	-01162	-01831	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
006225	-01501	-02365	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
005639	-01846	-02842	0250	0375	0750	0750	0625	0250	0000			

%BEG HE09(7)_22.TXT, Separation olv*, D50, adapted \$
%100 x LAB*a %1000 x (r g b c m y o) %nr. pos \$
%z003782 006719 000359 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 \$
%z008501 000086 010434 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 \$
%z004554 -06041 002319 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 \$
%z005085 -04034 -02894 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 \$
%z003985 -01443 -04255 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 \$
%z002550 005615 -04632 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 \$
%z000847 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 \$
%z009249 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W1 7 \$
%\$
%z003782 006719 000359 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 \$
%z008501 000086 010434 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 \$
%z004554 -06041 002319 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 \$
%z005085 -04034 -02894 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 \$
%z003985 -01443 -04255 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 \$
%z002550 005615 -04632 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 \$
%z000847 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 \$
%z009249 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W2 7 \$
%\$
%z003782 006719 000359 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 \$
%z008501 000086 010434 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 \$
%z004554 -06041 002319 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 \$
%z005085 -04034 -02894 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 \$
%z003985 -01443 -04255 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 \$
%z002550 005615 -04632 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 \$
%z000847 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 \$
%z009249 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W001 7 \$
%\$
%z004154 005873 004954 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 \$
%z008074 -00882 009937 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 \$
%z004720 -05749 000873 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 \$
%z005146 -03775 -03273 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 \$
%z002953 000743 -05061 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 \$
%z003567 007101 -03318 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 \$
%z000810 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 \$
%z009235 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %W251 7 \$
%\$
%z005988 003594 007137 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 \$
%z006519 -03574 007570 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 \$
%z004876 -05271 -00511 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 \$
%z005162 -03781 -03273 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 \$
%z001664 003396 -05735 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 \$
%z003836 007538 -02951 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 \$
%z000830 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 \$
%z009236 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %W501 7 \$
%\$
%z007626 001390 009269 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 \$
%z004948 -05587 005231 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 \$
%z005029 -04607 -01899 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 \$
%z004791 -02996 -03612 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 \$
%z001755 004553 -05550 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 \$
%z003817 007260 -01943 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 \$
%z000851 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 \$
%z009248 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %W751 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/HE19/HE19L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.70; nt=0.18; nx=1.0

TUB registration: 20091101-HE19/HE19L0NP.PDF /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

%BEG HE09(7)_22.TXT, Separation olv*, D50, adapted \$																				
%100 x LAB*a																				
1000 x (r g b c m y θ)																				
%nr. pos \$																				
000921	-00045	-00006	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$						%1053	m23	\$
002086	-00048	-00732	0125	0125	0125	0875	0875	0875	0000	%0973	k02	\$						%1054	m24	\$
003396	-00160	-00704	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$						%1055	m25	\$
004612	-00278	-00552	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$						%1056	n10	\$
005819	-00380	-00537	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$						%1057	n11	\$
006997	-00259	-00519	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$						%1058	n12	\$
008190	-00106	-00334	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$						%1059	n13	\$
009189	-00054	-000919	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$						%1060	n14	\$
009248	000005	-00012	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$						%1061	n15	\$
009916	-00039	-00003	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$						%1062	n16	\$
002085	-00042	-00732	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$						%1063	n17	\$
003404	-00143	-00734	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$						%1064	n18	\$
004607	-00270	-00567	0375	0375	0375	0625	0625													