

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/HE30/HE30L0NA.TXT> /PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

002327	002643	000822	0375	0000	0000	0625	1000	1000	0000	%0243	A10 \$	002869	003527	001496	0500	0000	0000	0500	1000	1000	0000	%0324	J10 \$	003333	004390	001953	0625	0000	0000	0375	1000	1000	0000	%0405	S10 \$
002357	003180	-01310	0375	0000	0125	0625	1000	0875	0000	%0244	A11 \$	002839	004116	-00776	0500	0000	0125	0500	1000	0875	0000	%0325	J11 \$	003300	004897	-00161	0625	0000	0125	0375	1000	0875	0000	%0406	S11 \$
002511	003241	-03688	0375	0000	0250	0625	1000	0750	0000	%0245	A12 \$	002926	003984	-02826	0500	0000	0250	0500	1000	0750	0000	%0326	J12 \$	003285	004789	-02255	0625	0000	0250	0375	1000	0750	0000	%0407	S12 \$
002850	001225	-04303	0375	0000	0375	0625	1000	0625	0000	%0246	A13 \$	002933	003285	-04079	0500	0000	0375	0500	1000	0625	0000	%0327	J13 \$	003190	004418	-03244	0625	0000	0375	0375	1000	0625	0000	%0408	S13 \$
002939	000332	-03849	0375	0000	0500	0625	1000	0500	0000	%0247	A14 \$	003168	001279	-04741	0500	0000	0500	0500	1000	0500	0000	%0328	J14 \$	003098	002949	-04112	0625	0000	0500	0375	1000	0500	0000	%0409	S14 \$
003121	-00136	-03752	0375	0000	0625	0625	1000	0375	0000	%0248	A15 \$	003287	000331	-04312	0500	0000	0625	0500	1000	0375	0000	%0329	J15 \$	003385	001010	-04724	0625	0000	0625	0375	1000	0375	0000	%0410	S15 \$
003531	-00254	-04223	0375	0000	0750	0625	1000	0250	0000	%0249	A16 \$	003507	-00154	-04297	0500	0000	0750	0500	1000	0250	0000	%0330	J16 \$	003559	000343	-04646	0625	0000	0750	0375	1000	0250	0000	%0411	S16 \$
003915	-00358	-04508	0375	0000	0875	0625	1000	0125	0000	%0250	A17 \$	003755	-00347	-04392	0500	0000	0875	0500	1000	0125	0000	%0331	J17 \$	003843	-00188	-04596	0625	0000	0875	0375	1000	0125	0000	%0412	S17 \$
004248	-00474	-04808	0375	0000	1000	0625	1000	0000	0000	%0251	A18 \$	004033	-00364	-04694	0500	0000	1000	0500	1000	0000	0000	%0332	J18 \$	004006	-00331	-04668	0625	0000	1000	0375	1000	0000	0000	%0413	S18 \$
002455	002585	001569	0375	0125	0000	0625	0875	1000	0000	%0252	B10 \$	002913	003570	002452	0500	0125	0000	0500	0875	1000	0000	%0333	K10 \$	003393	004334	002847	0625	0125	0000	0375	0875	1000	0000	%0414	T10 \$
002598	002979	-00060	0375	0125	0125	0625	0875	0875	0000	%0253	B11 \$	002980	004140	000284	0500	0125	0125	0500	0875	0875	0000	%0334	K11 \$	003463	004784	000706	0625	0125	0125	0375	0875	0875	0000	%0415	T11 \$
002689	003351	-02788	0375	0125	0250	0625	0875	0750	0000	%0254	B12 \$	003055	004305	-02051	0500	0125	0250	0500	0875	0750	0000	%0335	K12 \$	003490	005238	-01531	0625	0125	0250	0375	0875	0750	0000	%0416	T12 \$
003032	001734	-03905	0375	0125	0375	0625	0875	0625	0000	%0255	B13 \$	003061	003788	-03594	0500	0125	0375	0500	0875	0625	0000	%0336	K13 \$	003466	004697	-02957	0625	0125	0375	0375	0875	0625	0000	%0417	T13 \$
003436	000344	-04422	0375	0125	0500	0625	0875	0500	0000	%0256	B14 \$	003184	002054	-04417	0500	0125	0500	0500	0875	0500	0000	%0337	K14 \$	003311	003493	-03709	0625	0125	0500	0375	0875	0500	0000	%0418	T14 \$
003750	-00216	-04439	0375	0125	0625	0625	0875	0375	0000	%0257	B15 \$	003623	000524	-04714	0500	0125	0625	0500	0875	0375	0000	%0338	K15 \$	003313	001911	-04393	0625	0125	0625	0375	0875	0375	0000	%0419	T15 \$
004073	-00393	-04691	0375	0125	0750	0625	0875	0250	0000	%0258	B16 \$	003865	-00205	-04551	0500	0125	0750	0500	0875	0250	0000	%0339	K16 \$	003735	000402	-04086	0625	0125	0750	0375	0875	0250	0000	%0420	T16 \$
004382	-00703	-04774	0375	0125	0875	0625	0875	0125	0000	%0259	B17 \$	004172	-00383	-04769	0500	0125	0875	0500	0875	0125	0000	%0340	K17 \$	004093	-00178	-04752	0625	0125	0875	0375	0875	0125	0000	%0421	T17 \$
004511	-00959	-04792	0375	0125	1000	0625	0875	0000	0000	%0260	B18 \$	004274	-00546	-04808	0500	0125	1000	0500	0875	0000	0000	%0341	K18 \$	004202	-00362	-04784	0625	0125	1000	0375	0875	0000	0000	%0422	T18 \$
002904	001744	002219	0375	0250	0000	0625	0750	1000	0000	%0261	C10 \$	003124	003379	002628	0500	0250	0000	0500	0750	1000	0000	%0342	L10 \$	003610	004526	003335	0625	0250	0000	0375	0750	1000	0000	%0423	U10 \$
003306	001300	002001	0375	0250	0125	0625	0750	0875	0000	%0262	C11 \$	003418	003335	002284	0500	0250	0125	0500	0750	0875	0000	%0343	L11 \$	003647	004406	002558	0625	0250	0125	0375	0750	0875	0000	%0424	U11 \$
003489	001285	-00313	0375	0250	0250	0625	0750	0750	0000	%0263	C12 \$	003726	002966	-00935	0500	0250	0250	0500	0750	0750	0000	%0344	L12 \$	003895	004612	-00002	0625	0250	0250	0375	0750	0750	0000	%0425	U12 \$
003327	000550	-02160	0375	0250	0375	0625	0750	0625	0000	%0264	C13 \$	003630	003479	-02948	0500	0250	0375	0500	0750	0625	0000	%0345	L13 \$	003810	004930	-02376	0625	0250	0375	0375	0750	0625	0000	%0426	U13 \$
003949	-00276	-03666	0375	0250	0500	0625	0750	0500	0000	%0265	C14 \$	003803	001552	-03709	0500	0250	0500	0500	0750	0500	0000	%0346	L14 \$	003755	003595	-03412	0625	0250	0500	0375	0750	0500	0000	%0427	U14 \$
004254	-00579	-04359	0375	0250	0625	0625	0750	0375	0000	%0266	C15 \$	003968	000227	-04633	0500	0250	0625	0500	0750	0375	0000	%0347	L15 \$	003715	002009	-04085	0625	0250	0625	0375	0750	0375	0000	%0428	U15 \$
004614	-00894	-04684	0375	0250	0750	0625	0750	0250	0000	%0267	C16 \$	004255	-00416	-04761	0500	0250	0750	0500	0750	0250	0000	%0348	L16 \$	003968	000310	-04648	0625	0250	0750	0375	0750	0250	0000	%0429	U16 \$
004821	-01141	-04644	0375	0250	0875	0625	0750	0125	0000	%0268	C17 \$	004489	-00753	-04715	0500	0250	0875	0500	0750	0125	0000	%0349	L17 \$	004257	-00413	-04729	0625	0250	0875	0375	0750	0125	0000	%0430	U17 \$
005154	-01597	-04578	0375	0250	1000	0625	0750	0000	0000	%0269	C18 \$	004764	-01199	-04710	0500	0250	1000	0500	0750	0000	0000	%0350	L18 \$	004455	-00760	-04740	0625	0250	1000	0375	0750	0000	0000	%0431	U18 \$
004145	-00887	003786	0375	0375	0000	0625	0625	1000	0000	%0270	D10 \$	004110	001109	003647	0500	0375	0000	0500	0625	1000	0000	%0351	M10 \$	004337	002955	003793	0625	0375	0000	0375	0625	1000	0000	%0432	V10 \$
004318	-00953	003793	0375	0375	0125	0625	0625	0875	0000	%0271	D11 \$	004257	001026	003831	0500	0375	0125	0500	0625	0875	0000	%0352	M11 \$	004433	003032	004026	0625	0375	0125	0375	0625	0875	0000	%0433	V11 \$
004171	-00649	001656	0375	0375	0250	0625	0625	0750	0000	%0272	D12 \$	004527	000936	001876	0500	0375	0250	0500	0625	0750	0000	%0353	M12 \$	004581	002795	0									

003783	005152	002157	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$	004211	005837	002411	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$
003717	005536	000525	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$	004193	006206	001043	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$
003706	005931	-01327	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$	004304	006811	-00449	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$
003597	005494	-02456	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$	004272	006715	-01448	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$
003338	004209	-03326	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$	003976	005819	-02137	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$
003256	002704	-04142	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$	003534	003965	-03415	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$
003420	000958	-04792	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$	003365	002412	-04250	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$
003706	000334	-04805	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$	003544	000852	-04768	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$
003952	-00009	-04864	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$	003938	-00079	-04842	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$
003787	005063	003085	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$	004252	005770	003636	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$
003835	005464	001185	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$	004266	006148	001492	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$
003866	006074	-00849	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$	004330	006741	-00151	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$
003751	005686	-02281	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$	004395	006835	-01288	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$
003590	004584	-03021	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$	004149	005976	-01968	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$
003360	003233	-03821	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$	003750	004417	-03045	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$
003325	001827	-04494	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$	003382	003147	-03894	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$
003716	000384	-04833	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$	003465	001648	-04485	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$
004073	-00255	-04838	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$	003860	000176	-04830	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$
004026	005290	003947	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$	004412	005905	-04376	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$
003910	005112	002839	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$	004311	005762	002933	0875	0250	0125	0125	0750	0875	0000	%0586	L20	\$
004154	005859	000554	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$	004375	005683	001034	0875	0250	0125	0125	0750	0750	0000	%0587	L21	\$
004148	006101	-01795	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$	004703	007124	-00875	0875	0250	0375	0125	0750	0875	0000	%0588	L22	\$
003976	004636	-02817	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$	004504	005963	-01777	0875	0250	0500	0125	0750	0500	0000	%0589	L23	\$
003706	003301	-03574	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$	004288	004188	-02567	0875	0250	0625	0125	0750	0375	0000	%0590	L24	\$
003601	001999	-04249	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$	003868	003698	-03565	0875	0250	0750	0125	0750	0250	0000	%0591	L25	\$
003946	003054	-04688	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$	003885	001666	-04169	0875	0250	0875	0125	0750	0125	0000	%0592	L26	\$
004275	-00498	-04777	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$	004146	000117	-04606	0875	0250	1000	0125	0750	0000	0000	%0593	L27	\$
004399	004742	-04333	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$	004667	005832	-00477	0875	0375	0000	0125	0625	1000	0000	%0594	M19	\$
004305	005102	-04324	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$	004569	006181	004410	0875	0375	0125	0125	0625	0875	0000	%0595	M20	\$
004414	005055	002575	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$	004717	006159	003009	0875	0375	0250	0125	0625	0750	0000	%0596	M21	\$
005193	004247	-00089	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$	005392	005677	000506	0875	0375	0375	0125	0625	0625	0000	%0597	M22	\$
004854	004574	-02182	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$	005254	005767	-01374	0875	0375	0500	0125	0625	0500	0000	%0598	M23	\$
004369	003264	-03173	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$	004910	004549	-02190	0875	0375	0605	0125	0625	0375	0000	%0599	M24	\$
004261	001701	-03938	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$	004523	002973	-03171	0875	0375	0750	0125	0625	0250	0000	%0600	M25	\$
004389	002027	-04403	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$	004379	001598	-03848	0875	0375	0875	0125	0625	0125	0000	%0601	M26	\$
004594	-00741	-04658	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$	004572	000155	-04287	0875	0375	1000	0125	0625	0000	0000	%0602	M27	\$
005425	002533	005407	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$	005506	004095	005604	0875	0500	0000	0125	0500	1000	0000	%0603	N19	\$
005447	002587	005432	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$	005505	004603	005678	0875	0500	0125	0125	0500	0875	0000	%0604	N20	\$
005690	002457	003722	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$	005576	004766	004366	0875	0500	0250	0125	0500	0750	0000	%0605	N21	\$
005806	002483	001870	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$	005724	004622	002387	0875	0500	0375	0125	0500	0625	0000	%0606	N22	\$
006059	002514	-00287	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$	006352	004054	000034	0875	0500	0500	0125	0500	0500	0000	%0607	N23	\$
005655	002877	-02361	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$	005956	004088	-01603	0875	0500	0625	0125	0500	0375	0000	%0608	N24	\$
005456	001225	-03170	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$	005336	002970	-02550	0875	0500	0							

See original or copy: <http://web.me.com/klaus-richter/HE30/HE30L0NA.TXT> /PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

009710	-00099	000199	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009042	-00969	-00066	0875	1000	1000	0125	0000	0000	0000	%0730	b02	\$
008482	-01602	00009	0750	1000	1000	0250	0000	0000	0000	%0731	b03	\$
007928	-02220	-00002	0625	1000	1000	0375	0000	0000	0000	%0732	b04	\$
007327	-02890	000040	0500	1000	1000	0500	0000	0000	0000	%0733	b05	\$
006785	-03566	-00011	0375	1000	1000	0625	0000	0000	0000	%0734	b06	\$
006259	-04431	000245	0250	1000	1000	0750	0000	0000	0000	%0735	b07	\$
005919	-05126	000701	0125	1000	1000	0875	0000	0000	0000	%0736	b08	\$
005776	-05578	001232	0000	1000	1000	1000	0000	0000	0000	%0737	b09	\$
009002	000946	-00013	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
008606	-00069	000202	0875	0875	0875	0125	0125	0125	0000	%0739	c02	\$
008667	-01440	000217	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
007932	-02273	000244	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
007325	-02920	000196	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
006901	-03441	000187	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
006317	-04307	000040	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005853	-05147	000640	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
005678	-05660	001299	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008273	001897	-00062	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
008010	001089	-00105	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
007631	-00048	000107	0750	0750	0750	0150	0250	0250	0000	%0749	d03	\$
007531	-01513	000039	0625	0750	0750	0150	0250	0250	0000	%0750	d04	\$
007204	-02606	000164	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
006945	-03355	000237	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
006291	-04371	000241	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005743	-05292	000663	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
005460	-06010	001411	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007348	003094	000122	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007370	002399	-00103	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
006956	001125	-00327	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006525	-00039	000042	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
006404	-01643	000068	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
006223	-02761	000007	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
006015	-04267	000321	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
005415	-05945	000813	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
005133	-06718	001828	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
006330	004517	-000539	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006437	003955	-00049	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006182	002451	-00330	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$
005748	001164	-00326	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005138	-00022	000030	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005205	-01726	-00236	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
005037	-03152	000009	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
005038	-05899	000881	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
005000	-07211	002324	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
005375	006066	000931	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
005364	005686	000481	0750	0375	0375	0000	0625	0625	0000	%0775	g02	\$
005165	004248	-00111	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
004835	002740	-00295	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004437	001263	-00325	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
003796	-00001	000014	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
003817	-01942	-00272	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
004046	-04236	000263	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
004297	-06490	001855	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
004858	006893	001314	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
004616	006673	001022	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
004419	005842	000488	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
003679	004641	-00010	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
003488	003074	-00343	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
003315	001395	-00321	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
002672	000016	000029	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
003131	-02272	-00255	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
003348	-04581	001223	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
004809	006780	002170	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004197	005991	001459	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
003744	005353	001140	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
003281	004753	000757	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
002814	004026	000290	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
002515	003049	-00088	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
002328	001684	-00285	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
001734	000049	000109	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
002227	-01994	000097	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
004745	006651	002811	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
004093	005683	002467	0875	0000	0000	0125	1000	1000	0000	%0802	j02	\$
003675	004995	002228	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
003228	004308	002017	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
002729	003475	001448	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
002220	002637	000820	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
001923	002089	000900	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
001718	000513	-00210	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
003173	000044	000106	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009706	-00096	000199	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
009079	-00969	-00061	0875	1000	1000	0000	0125	0125	0000	%0811	b11	\$
008461	-01088	-01426	0750	0750	0750	0000	0250	0250	0000	%0812	b12	\$

%BEG HE20_22.TXT, Separation olv*, D65, not adapted \$
%100 x LAB*
%#1000 x (r g b c m y 0) %nr. pos \$
%z004769 006654 002683 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z009160 -01556 009565 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005845 -06262 004354 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005809 -05589 001147 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z004783 -01414 -04826 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003596 000918 -04664 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001310 000040 000095 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009707 -00096 000212 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004745 006651 002811 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z009166 -01551 009531 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005830 -06197 004169 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005776 -05578 001232 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z004717 -01395 -04822 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003541 000951 -04670 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z001308 000048 000105 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009703 -00098 000204 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/HE30/HE30L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG HE20.22.TXT, Separation olv*, D65, not adapted \$																											
%100 x LAB*				1000 x (r g b c m y θ)				%nr.		pos \$																	
001278	000026	000108	0000	0000	0000	0000	1000	1000	1000	0000	00972	k01	\$	000510	-000055	0000190	0866	0866	0866	0133	0133	0000	%1053	m23	\$		
001479	000030	000116	0125	0125	0125	0875	0875	0875	0875	0000	00973	k02	\$	009165	-00075	000208	0933	0933	0933	0066	0066	0066	%1054	m24	\$		
002442	000009	000043	0250	0250	0250	0750	0750	0750	0750	0000	00974	k03	\$	009701	-000098	000210	1000	1000	1000	0000	0000	0000	%1055	m25	\$		
003637	-000005	000015	0375	0375	0375	0625	0625	0625	0625	0000	00975	k04	\$	001441	000044	000118	0000	0000	0000	1000	1000	1000	%1056	n10	\$		
004998	-000016	000038	0500	0500	0500	0500	0500	0500	0500	0000	00976	k05	\$	001309	000054	000109	0066	0066	0066	0933	0933	0933	%1057	n11	\$		
006466	-000033	000060	0625	0625	0625	0625	0625	0625	0625	0000	00977	k06	\$	001758	000046	000094	0133	0133	0133	0866	0866	0866	%1058	n12	\$		
007659	-000045	000108	0750	0750	0750	0250	0250	0250	0250	0000	00978	k07	\$	002299	000026	000035	0200	0200	0200	0800	0800	0800	%1059	n13	\$		
008770	-000062	000176	0875	0875	0875	0125	0125	0125	0125	0000	00979	k08	\$	002835	000014	000022	0266	0266	0266	0333	0333	0333	%1060	n14	\$		
009723	-000096	000199	1000	1000	1000	0000	0000	0000	0000	0000	00980	k09	\$	003457	000010	000015	0333	0333	0333	0666	0666	0666	%1061	n15	\$		
001263	000028	000093	0000	0000	0000	1000	1000	1000	1000	0000	00981	l01	\$	004123	000004	000031	0400	0400	0400	0600	0600	0600	%1062	n16	\$		
001515	000033	000120	0125	0125	0125	0875	0875	0875	0875	0000	00982	l02	\$	004741	-000005	000063	0466	0466	0466	0533	0533	0533	%1063	n17	\$		
002423	000015	000026	0250	0250	0250	0750	0750	0750	0750	0000	00983	l03	\$	005514	-000018	000060	0533	0533	0533	0466	0466	0466	%1064	n18	\$		
003615	000000	000009	0375	0375	0375	0625	0625	0625	0625	0000	00984	l04	\$	006288	-000029	000078	0600	0600	0600	0400	0400	0400	%1065	n19	\$		
004997	-000015	000026	0500	0500	0500	0500	0500	0500	0500	0000	00985	l05	\$	006882	-000035	000102	0666	0666	0666	0333	0333	0333	%1066	n20	\$		
006472	-000033	000060	0625	0625	0625	0625	0625	0625	0625	0000	00986	l06	\$	007483	-000045	000140	0734	0734	0734	0266	0266	0266	%1067	n21	\$		
007684	-000047	000116	0750	0750	0750	0250	0250	0250	0250	0000	00987	l07	\$	008025	-000046	000167	0800	0800	0800	0200	0200	0200	%1068	n22	\$		
008786	-000063	000179	0875	0875	0875	0125	0125	0125	0125	0000	00988	l08	\$	008506	-000059	000199	0866	0866	0866	0133	0133	0133	%1069	n23	\$		
009726	-000095	000195	1000	1000	1000	0000	0000	0000	0000	0000	00989	l09	\$	009107	-000073	000213	0933	0933	0933	0066	0066	0066	%1070	n24	\$		
001281	000031	000108	0000	0000	0000	1000	1000	1000	1000	0000	00990	m01	\$	009710	-000092	000197	1000	1000	1000	0000	0000	0000	%1071	n25	\$		
001534	000033	000114	0125	0125	0125	0875	0875	0875	0875	0000	00991	m02	\$	001239	000042	000082	0000	0000	0000	1000	1000	1000	%1072	k26	\$		
002442	000013	000038	0250	0250	0250	0750	0750	0750	0750	0000	00992	m03	\$	009724	-000092	000202	1000	1000	1000	0000	0000	0000	%1073	k27	\$		
003651	000000	000015	0375	0375	0375	0625	0625	0625	0625	0000	00993	m04	\$	004739	000588	003043	1000	0000	0000	0000	1000	1000	%1074	l26	\$		
004990	-000012	000035	0500	0500	0500	0500	0500	0500	0500	0000	00994	m05	\$	005774	-05834	001556	0000	1000	1000	1000	0000	0000	%1075	l27	\$		
006480	-000036	000069	0625	0625	0625	0625	0625	0625	0625	0000	00995	m06	\$	009160	-01533	009743	1000	1000	0000	0000	0000	1000	%1076	m26	\$		
007685	-000050	000121	0750	0750	0750	0250	0250	0250	0250	0000	00996	m07	\$	004730	-01422	-04860	0000	1000	1000	1000	1000	0000	%1077	m27	\$		
008801	-000067	000183	0875	0875	0875	0125	0125	0125	0125	0000	00997	m08	\$	005755	-06510	004335	1000	0000	0000	1000	1000	1000	%1078	n26	\$		
009733	-00103	000213	1000	1000	1000	0000	0000	0000	0000	0000	00998	m09	\$	003598	000928	-04737	1000	0000	1000	0000	1000	0000	%1079	n27	\$		
001292	000035	000098	0000	0000	0000	1000	1000	1000	1000	0000	00999	n01	\$	%\$													
001502	000032	000113	0125	0125	0125	0875	0875	0875	0875	0000	10000	n02	\$	%004738	006588	003043	%#1000	0000	0000	0000	1000	1000	0000	%1074	l26	%03 0	\$
002517	000018	000031	0250	0250	0250	0750	0750	0750	0750	0000	10001	n03	\$	%009160	-01533	009743	%#1000	1000	0000	0000	0000	1000	0000	%1076	m26	%03 1	\$
003683	-000006	000011	0375	0375	0375	0625	0625	0625	0625	0000	10002	n04	\$	%005755	-06510	004335	%#0000	1000	0000	1000	0000	1000	0000	%1078	n26	%L3 2	\$
005014	-000020	000034	0500	0500	0500	0500	0500	0500	0500	0000	10003	n05	\$	%005774	-05834	001556	%#0000	1000	1000	1000	0000	0000	0000	%1075	l27	%C3 3	\$
006495	-000037	000069	0625	0625	0625	0625	0625	0625	0625	0000	10004	n06	\$	%004730	-01422	-04860	%#0000	0000	1000	1000	1000	0000	0000	%1077	m27	%W3 4	\$
007729	-000048	000117	0750	0750	0750	0250	0250	0250	0250	0000	10005	n07	\$	%003598	000928	-04737	%#1000	0000	1000	0000	1000	0000	0000	%1079	n27	%M3 5	\$
008829	-000063	000184	0875	0875	0875	0125	0125	0125	0125	0000	10006	n08	\$	%001239	000042	000082	%#0000	0000	0000	1000	1000	1000	0000	%1072	k26	%M3 6	\$
009727	-000094	000192	1000	1000	1000	0000	0000	0000	0000	0000	10007	n09	\$	%009724	-00092	000202	%#1000	1000	1000	0000	0000	0000	0000	%1073	k27	%M3 7	\$
001450	000038	000102	0000	0000	0000	1000	1000	1000	1000	0000	10008	k10	\$	%\$													
001345	000044	000105	0066	0066	0066	0933	0933	0933	0933	0000	10009	k11	\$	%001364	000032	000105	%#0000	0000	0000	1000	1000	0000	0000	%0972	k01	%N4 6	\$
001709	000041	000075	0133	0133	0133	0866	0866	0866	0866	0000	10010	k12	\$	%009718	-00092	000195	%#1000	1000	1000	0000	0000	0000	0000	%0980	k09	%N4 7	\$
002324	000024	000026	0200	0200	0200	0800	0800	0800	0800	0000	10011	k13	\$	%\$													
002832	000013	000008	0266	0266	0266	0333	0333	0333	0333	0000	10012	k14	\$	%001413	000035	000095	%#0000	0000	0000	1000	1000	1000	0000	%0981	l01	%N5 6	\$
003463	000013	000012	0333	0333	0333	0666	0666	0666	0666	0000	10013	k15	\$	%009718	-00090	000191	%#1000	1000	1000	0000	0000	0000	0000	%0989	l09	%M5 7	\$
004083	000006	000022	0400	0400	0400	0600	0600	0600	0600	0000	10014	k16	\$	%\$													
004759	-000003	000053	0466	0466	0466	0533	0533	0533	0533	0000	10015	k17	\$	%001377	000037	000108	%#0000	0000	0000	1000	1000	1000	0000	%0990	m01	%N6 6	\$
005509	-000016	000056	0533	0533	0533	0466	0466	0466	0466	0000	10016	k18	\$	%009717	-00101	000212	%#1000	1000	1000	0000	0000	0000	0000	%0998	m09	%M6 7	\$
006273	-000032	000081	0600	0600	0600	0400	0400	0400	0400	0000	10017	k19	\$	%\$													
006933	-000038	000097	0666	0666	0666	0333	0333	0333	0333	0000	10018	k20	\$	%001367	000040	000108	%#0000	0000	0000	1000	1000	1000	0000	%0999	n01	%M7 6	\$
007448	-000041	000134																									

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klau.s.richter/HE30/HE30L0NA.TXT> /PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

002327	002618	000712	0375	0000	0000	0025	1000	1000	0000	%0243	A10	\$	002869	003511	001378	0500	0000	0000	0500	1000	1000	0000	%0324	J10	\$	003333	004382	001829	0625	0000	0000	0375	1000	1000	0000	%0405	S10	\$
002357	003156	-01421	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$	002839	004100	-00894	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$	003300	004389	-00285	0625	0000	0125	0375	1000	0875	0000	%0406	S11	\$
002511	003220	-03800	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$	002926	003970	-02944	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$	003285	004781	-02378	0625	0000	0250	0375	1000	0750	0000	%0407	S12	\$
002850	001209	-04420	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$	002833	003269	-04196	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$	003190	004408	-03366	0625	0000	0375	0375	1000	0625	0000	%0408	S13	\$
002939	000317	-03967	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$	003168	001269	-04863	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$	003098	002938	-04233	0625	0000	0500	0375	1000	0500	0000	%0409	S14	\$
003121	-00147	-03873	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$	003287	000322	-04436	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$	003385	001903	-00489	0625	0000	0625	0375	1000	0375	0000	%0410	S15	\$
003531	-00259	-04350	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$	003507	-00158	-04424	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$	003559	000339	-04774	0625	0000	0750	0375	1000	0250	0000	%0411	S16	\$
003916	-00356	-04641	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$	003755	-00348	-04522	0500	0000	0875	0500	1000	0125	0000	%0331	J17	\$	003843	-00187	-04727	0625	0000	0875	0375	1000	0125	0000	%0412	S17	\$
004248	-00467	-04945	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$	004093	-00360	-04828	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$	004006	-00327	-04882	0625	0000	1000	0375	1000	0000	0000	%0413	S18	\$
004558	-00572	-05249	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$	002913	003555	002334	0500	0125	0000	0875	1000	0000	0000	%0333	K10	\$	003393	004328	002722	0625	0125	0000	0375	0875	1000	0000	%0414	T10	\$
002598	002960	-00174	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$	002980	004127	001065	0500	0125	0125	0500	0875	0875	0000	%0334	K11	\$	003463	004779	000580	0625	0125	0125	0375	0875	0875	0000	%0415	T11	\$
002689	003333	-02903	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$	003055	004293	-02171	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$	003490	005233	-01657	0625	0125	0250	0375	0875	0750	0000	%0416	T12	\$
003032	001721	-04025	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$	003061	003776	-03715	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$	003466	004692	-03082	0625	0125	0375	0375	0875	0625	0000	%0417	T13	\$
003436	000338	-04548	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$	003184	002044	-04539	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$	003311	003485	-03833	0625	0125	0500	0375	0875	0500	0000	%0418	T14	\$
003750	-00217	-04559	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$	003623	000521	-04842	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$	003313	001903	-04516	0625	0125	0625	0375	0875	0375	0000	%0419	T15	\$
004073	-00389	-04826	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$	003865	-00204	-04682	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$	003735	000401	-04936	0625	0125	0750	0375	0875	0250	0000	%0420	T16	\$
004382	-00694	-04913	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$	004172	-00377	-04904	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$	004093	-00173	-04887	0625	0125	0875	0375	0875	0125	0000	%0421	T17	\$
004511	-00947	-04932	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$	004274	-00538	-04945	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$	004202	-00356	-04920	0625	0125	1000	0375	0875	0000	0000	%0422	T18	\$
002904	001730	002101	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$	003124	003368	002507	0500	0250	0000	0500	0750	1000	0000	%0342	L10	\$	003610	004523	003207	0625	0250	0000	0375	0750	1000	0000	%0423	T19	\$
003306	001291	001877	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$	003418	003329	002159	0500	0250	0125	0500	0750	0875	0000	%0343	L11	\$	003647	004403	002430	0625	0250	0125	0375	0750	0875	0000	%0424	T20	\$
003489	001280	-00439	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$	003728	002965	-00646	0500	0250	0250	0500	0750	0750	0000	%0344	L12	\$	003895	004614	-00134	0625	0250	0250	0375	0750	0750	0000	%0425	T21	\$
003327	000543	-02284	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$	003630	003476	-03076	0500	0250	0375	0500	0750	0625	0000	%0345	L13	\$	003910	004930	-02507	0625	0250	0375	0375	0750	0625	0000	%0426	T22	\$
003949	-00273	-03799	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$	003803	001552	-03040	0500	0250	0500	0500	0750	0500	0000	%0346	L14	\$	003755	003595	-03542	0625	0250	0500	0375	0750	0500	0000	%0427	T23	\$
004254	-00572	-04496	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$	004073	-00389	-04826	0375	0250	0750	0625	0875	0250	0000	%0347	L15	\$	003827	-00327	-04882	0625	0250	0375	0375	0750	0625	0000	%0428	T24	\$
004614	-00881	-04826	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$	004255	-00409	-04988	0500	0250	0750	0500	0750	0250	0000	%0348	L16	\$	003968	003913	-04781	0625	0250	0750	0375	0750	0250	0000	%0429	T25	\$
004821	-01124	-04789	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$	004489	-00741	-04855	0500	0250	0875	0500	0750	0125	0000	%0349	L17	\$	004257	-00406	-04666	0625	0250	0875	0375	0750	0125	0000	%0430	T26	\$
005154	-01575	-04728	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$	004764	-01183	-04854	0500	0250	1000	0500	0750	0000	0000	%0350	L18	\$	004455	-00749	-04880	0625	0250	1000	0375	0750	0000	0000	%0431	T27	\$
004145	-00881	003650	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$	004110	001114	003512	0500	0375	0000	0500	0625	1000	0000	%0351	M10	\$	004187	002962	003657	0625	0375	0000	0375	0625	1000	0000	%0432	T28	\$
004318	-00944	-003655	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$	004257	001034	003694	0500	0375	0125	0500	0625	0875	0000	%0352	M11	\$	004333	003041	003888	0625									

003783	005152	002027	0750	0000	0000	0250	0000	1000	1000	0000	0000	%0486	A19	\$
003717	005535	000396	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$		
003706	005930	-01456	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$		
003597	005490	-02583	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$		
003338	004201	-03450	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$		
003256	002695	-04265	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$		
003420	000951	-04917	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$		
003706	000332	-04935	0750	0000	0875	0250	1000	0000	0000	%0493	A26	\$		
003952	000906	-04987	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$		
003787	005063	002954	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$		
003835	005464	001054	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$		
003866	006075	-00981	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$		
003751	005685	-02411	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$		
003590	004580	-03149	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$		
003360	003226	-03946	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$		
003325	001819	-04618	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$		
003716	000383	-04962	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$		
004073	-00251	-04972	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$		
004026	005294	003813	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$		
003910	005114	002707	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$		
004154	005865	000419	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$		
004148	006107	-01931	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$		
003976	004639	-02950	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$		
003706	003299	-03704	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$		
003601	001995	-04376	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$		
003946	000356	-04820	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$		
004275	-00490	-04914	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$		
004399	004752	004194	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$		
004305	005110	004187	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$		
004414	005065	002436	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$		
005193	004270	-00239	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$		
004854	004591	-02327	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$		
004369	003274	-03312	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$		
004261	001709	-04075	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$		
004389	000216	-04542	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$		
004594	-00728	-04800	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$		
005425	002560	005254	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$		
005447	002614	005278	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$		
005690	002488	003565	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$		
005806	002516	001712	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$		
006059	002551	-00449	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$		
005655	002907	-02518	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$		
005456	001252	-03324	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$		
005266	-00157	-04059	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$		
005568	-01092	-04190	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$		
006560	000490	006479	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$		
006591	000475	006473	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$		
006643	000410	005493	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$		
006696	000478	003384	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$		
006692	000689	001937	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$		
006592	001273	-00517	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$		
006541	000622	-01981	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$		
006748	-00594	-03030	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$		
007013	-01255	-03975	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$		
007715	-01227	-007709	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$		
007689	-01234	-007661	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$		
007675	-01243	-007320	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$		
007715	-01237	-005134	0750	0750	0375	0250	0250	0500	0000	%0543	G22	\$		
007646	-01132	-003527	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$		
007516	-00806	001926	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$		
007371	000016	000444	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$		
008100	-00855	-01277	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$		
008357	-01124	-01742	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$		
008192	-02972	-007560	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$		
008159	-03028	-007499	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$		
008110	-03112	-006891	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$		
008140	-03009	-005319	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$		
008131	-02839	-003805	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$		
008186	-02598	-002602	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$		
008471	-02031	-001449	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$		
008513	-01626	-000177	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$		
008382	-01384	-00989	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$		
007191	-04150	-006011	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$		
007215	-04130	-005737	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$		
007347	-03933	-005068	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$		
007445	-03646	-003633	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$		
007662	-03258	-002903	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$		
007900	-02866	-002307	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$		
008352	-02244	-001809	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$		
008434	-01961	-001995	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$		
008354	-01725	-000774	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$		
004211	005843	002275	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$		
004193	006212	000907	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$		
004304	006819	-00586	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$		
004272	006723	-01586	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$		
003976	005822	-02270	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$		
003534	003961	-03542	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$		
003365	002405	-04374	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$		
003934	006847	-04895	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$		
003932	-00026	-04875	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$		
004252	005778	003499	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$		
004266	006156	001355	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$		
004330	006750	-00288	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$		
004395	006844	-01426	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$		
004149	005981	-02104	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$		
003750	004416	-03175	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$		
003382	003140	-04019	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$		
003465	001643	-04611	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$		
003860	000176	-04962	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$		
004412	005915	004237	0875	0250	0000	0125	0750	1000	000					

See original or copy: <http://web.me.com/klaus.richter/HE30/HE30L0NA.TXT> /PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.10

009710	-00001	-00004	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009042	-00883	-00263	0875	1000	1000	0125	0000	0000	0000	%0730	b02	\$
008482	-01525	-00199	0750	1000	1000	0250	0000	0000	0000	%0731	b03	\$
007928	-02153	-00186	0625	1000	1000	0375	0000	0000	0000	%0732	b04	\$
007327	-02833	-00135	0500	1000	1000	0500	0000	0000	0000	%0733	b05	\$
006785	-03518	-00181	0375	1000	1000	0625	0000	0000	0000	%0734	b06	\$
006259	-04393	-00081	0250	1000	1000	0750	0000	0000	0000	%0735	b07	\$
005919	-05094	-00054	0125	1000	1000	0875	0000	0000	0000	%0736	b08	\$
005776	-05549	-001074	0000	1000	1000	1000	0000	0000	0000	%0737	b09	\$
009002	-001032	-00209	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
008606	-000009	-00011	0875	0875	0875	0125	0125	0125	0000	%0739	c02	\$
008667	-01360	-000025	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
007932	-02206	-00060	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
007325	-02863	-00020	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
006901	-03391	-00016	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
006317	-04268	-000235	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005853	-05116	-000481	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
005678	-05632	-00142	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008273	-001970	-00249	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
008010	-001158	-00369	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
007631	-000013	-00072	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
007531	-01453	-00139	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
007204	-02551	-00010	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
006945	-03305	-00065	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
006291	-04332	-000257	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005743	-05263	-000506	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
005460	-05986	-001257	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007348	-003151	-00054	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007370	-002457	-00280	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
006956	-001175	-00499	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006525	-000002	-00123	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
006404	-01602	-00234	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
006223	-02723	-00156	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
006015	-04234	-000160	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
005415	-05921	-000659	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
005133	-06700	-001677	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
006330	-004556	-000375	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006437	-003996	-00215	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006182	-002488	-00492	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$
005748	-001193	-00484	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005138	-000003	-00119	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005205	-01707	-00388	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
005037	-03135	-00139	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
005038	-05882	-000732	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
005000	-07195	-002175	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
005375	-006089	-000778	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
005364	-005709	-000328	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005165	-004267	-00261	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
004835	-002753	-00442	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004437	-001269	-00468	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
003796	-000006	-00120	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
003817	-01947	-00407	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
004046	-04237	-000125	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
004297	-06486	-001715	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
004858	-006907	-00167	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
004616	-006682	-000878	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
004419	-005843	-000349	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
003679	-004634	-00143	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
003488	-003064	-00474	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
003315	-001382	-00449	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
002672	-000008	-00091	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
003131	-02289	-00381	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
003348	-04593	-001094	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
004809	-006793	-002024	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004197	-005994	-001320	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
003744	-005348	-001006	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
003281	-004739	-000628	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
002814	-004004	-000167	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
002515	-003021	-00208	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
002328	-001653	-00403	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
001734	-000008	-00001	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
002227	-02026	-00018	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
004745	-006662	-002666	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
004093	-005683	-002329	0875	0000	0000	0125	1000	1000	0000	%0802	j02	\$
003675	-004988	-002095	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
003228	-004293	-001889	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
002729	-003451	-001326	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
002220	-002605	-000704	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
001923	-002052	-000088	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
001718	-000472	-00320	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
001373	-000003	-000000	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009706	-000001	-00004	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
009079	-006010	-00848	0875	0875	0875	0125	0125	0000	0000	%0811	b11	\$
008461	-01012	-01615	0750	0750	0750	0250	0250	0000	0000	%0812	b1	

%BEG HE20_22.TXT, Separation olv*, D65, adapted \$
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos \$
%z004769 006669 002539 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z009160 -01468 009360 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005845 -06228 004195 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005809 -05556 000989 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z004783 -01398 -04971 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003596 000907 -04791 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001310 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009707 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004745 006662 002666 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z009166 -01462 009334 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005830 -06167 004011 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005776 -05549 001074 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z004717 -01384 -04968 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003541 000942 -04801 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z001308 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009703 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/HE30/HE30L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG HE20.22.TXT, Separation olv*, D65 adapted \$		%100 x LAB*a		1000 x (r g b c m y 0)		%nr. pos \$																																					
001278	-00015	000025	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$	008510	000017	000004	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$	009165	000007	000013	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$					
001479	-00008	000030	0125	0125	0125	0875	0875	0875	0875	0000	%0973	k02	\$	009701	-00006	000008	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$	001441	000005	000033	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$				
002442	-00013	-00055	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$	001309	000012	000026	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$	001758	000012	000004	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$					
003637	-00010	-00101	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$	002299	000000	-00062	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$	002835	-00002	-00082	0266	0266	0266	0333	0333	0333	0000	%1060	n14	\$					
004998	000001	-00097	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	003457	000003	-00098	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$	004123	000007	-00092	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$					
006466	000007	-00096	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$	004741	000007	-00069	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$	005514	000006	-00082	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$					
007659	000014	-00065	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$	006288	000008	-00075	0600	0600	0600	0400	0400	0400	0000	%1065	n19	\$	006882	000012	-00059	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$					
008770	000015	-00012	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$	007483	000011	-00031	0734	0734	0734	0266	0266	0266	0000	%1067	n21	\$	008025	000018	-00010	0800	0800	0800	0200	0200	0200	0000	%1068	n22	\$					
009723	000004	-00093	1000	1000	1000	1000	1000	1000	0000	%0980	k09	\$	008506	000013	000013	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$	009107	000009	000019	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$					
001263	-00013	000010	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$	009710	000000	-00005	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$	001239	000000	000000	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$					
001515	-00004	000034	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$	009724	000000	000000	0000	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$	001242	000000	000000	0000	0000	0000	1000	1000	1000	0000	%1074	l26	\$				
002423	-00008	-00072	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$	005774	-05804	001409	0000	1000	1000	1000	0000	0000	0000	0000	%1075	l27	\$	004738	006601	002910	1000	0000	0000	0000	1000	1000	0000	%1076	m26	\$				
003615	-00003	-00106	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$	009160	-01449	009548	1000	1000	0000	0000	0000	1000	0000	0000	%1077	m27	\$	004730	-01409	-04992	0000	0000	1000	1000	1000	0000	%1078	n26	\$					
004997	000002	-00109	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	005755	-06480	004188	0000	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$	003598	000923	-04853	1000	0000	1000	0000	1000	0000	%1080	n09	\$					
006472	000007	-00096	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$	008510	000017	000004	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$	009165	000007	000013	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$					
007684	000013	-00057	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$	009701	-00006	000008	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$	001441	000005	000033	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$					
008786	000014	-00009	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$	001309	000012	000026	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$	001758	000012	000004	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$					
009726	-00003	-00007	1000	1000	1000	1000	1000	1000	0000	%0989	l09	\$	002299	000000	-00062	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$	002835	-00002	-00082	0266	0266	0266	0333	0333	0333	0000	%1060	n14	\$					
001281	-00010	000025	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$	003457	000003	-00098	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$	004123	000007	-00092	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$					
001534	-00004	000028	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$	004741	000007	-00069	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$	005514	000006	-00082	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$					
002442	-00009	-00060	0250	0250	0250	0750	0750	0750	0000	%0992	m03	\$	006288	000008	-00075	0600	0600	0600	0400	0400	0400	0000	%1065	n19	\$	006882	000012	-00059	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$					
003651	-00004	-00101	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$	007483	000011	-00031	0734	0734	0734	0266	0266	0266	0000	%1067	n21	\$	008025	000018	-00010	0800	0800	0800	0200	0200	0200	0000	%1068	n22	\$					
004990	000004	-00100	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$	008510	000017	000004	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$	009107	000009	000019	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$					
006480	000004	-00087	0625	0625	0625	0375	0375	0375	0000	%0995	m06	\$	009710	000000	-00005	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$	001239	000000	000000	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$					
007685	000010	-00052	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$	009724	000000	000000	0000	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$	001242	000000	000000	0000	0000	0000	1000	1000	1000	0000	%1074	l26	\$				
008801	000010	-00006	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$	005774	-05804	001409	0000	1000	1000	1000	0000	0000	0000	0000	%1075	l27	\$	004738	006601	002910	1000	0000	0000	0000	1000	1000	0000	%1076	m26	\$				
009733	-00010	000010	1000	1000	1000	1000	1000	1000	0000	%0998	m09	\$	009160	-01449	009548	1000	1000	0000	0000	0000	1000	0000	0000	%1077	m27	\$	004730	-01409	-04992	0000	0000	1000	1000	1000	0000	%1078	n26	\$					
001292	-00006	000015	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$	005755	-06480	004188	0000	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$	003598	000923	-04853	1000	0000	1000	0000	1000	0000	%1080	n09	\$					
001502	-00005	000026	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$	%004738	006601	002910	%1000	0000	0000	0000	0000	1000	1000	0000	%1074	l26	%03	0	\$	%009160	-01449	009548	%1000	1000	0000	0000	0000	1000	0000	%1076	m26	%Y3	1	\$
002517	-00011	-00069	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$	%005755	-06480	004188	%1000	1000	0000	0000	1000	0000	1000	0000	%1078	n26	%L3	2	\$	%005774	-05804	001409	%1000	1000	1000	0000	0000	1000	0000	%1075	l27	%C3	3	\$
003683	-00009	-00105	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$	%005774	-05804	001409	%1000	1000	1000	0000	0000	10																						

TUB registration: 20091101-HE30/HE30L0NA.TXT / .PS TUB ma
application for evaluation and measurement of printer or monitor systems

A target diagram consisting of three concentric circles. A vertical line and a horizontal line intersect at the center, dividing the target into four equal quadrants.

[illegible]

See original or copy: <http://web.me.com/klaustrichter/HE30/HE30L0NA.TXT> /PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

002399	002797	000952	0375	0000	0000	0625	1000	1000	0000	%0243	A10	\$
002411	003124	-01170	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$
002501	002832	-03651	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$
002761	000593	-04440	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$
002845	-00255	-04009	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$
003201	-00725	-03931	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$
003414	-00944	-04433	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$
003790	-01101	-04737	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$
004111	-01281	-05058	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$
002533	002798	001685	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$
002667	003063	000087	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$
002711	003119	-02699	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$
002973	001249	-03981	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$
003325	-00348	-04611	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$
003629	-00937	-04648	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$
003940	-01174	-04932	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$
004242	-01514	-05033	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$
004366	-01792	-05064	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$
002966	002012	002281	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$
003357	001559	002049	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$
003511	001326	-00263	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$
003293	000331	-02210	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$
003854	-00811	-03825	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$
004131	-01284	-04584	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$
004475	-01685	-04943	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$
004680	-01935	-04911	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$
005007	-02401	-04862	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$
004165	-00556	-003709	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$
004337	-00617	-003710	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$
004178	-00464	-001621	0375	0375	0250	0625	0625	0750	0000	%0272	D12	\$
003854	000003	000001	0375	0375	0375	0625	0625	0625	0000	%0273	D13	\$
004582	-01067	-01581	0375	0375	0500	0625	0625	0500	0000	%0274	D14	\$
005124	-01444	-02587	0375	0375	0625	0625	0625	0375	0000	%0275	D15	\$
005433	-01792	-03400	0375	0375	0750	0625	0625	0250	0000	%0276	D16	\$
005616	-02244	-04116	0375	0375	0875	0625	0625	0125	0000	%0277	D17	\$
006189	-02374	-03947	0375	0375	1000	0625	0625	0000	0000	%0278	D18	\$
005120	-03277	-003817	0375	0500	0000	0625	0500	1000	0000	%0279	D19	\$
005192	-03417	-003907	0375	0500	0125	0625	0500	0875	0000	%0280	E10	\$
005211	-03215	-002901	0375	0500	0250	0625	0500	0750	0000	%0281	E12	\$
005148	-02130	000656	0375	0500	0375	0625	0500	0625	0000	%0282	E13	\$
005088	-01791	-00366	0375	0500	0500	0625	0500	0500	0000	%0283	E14	\$
005856	-02356	-01147	0375	0500	0625	0625	0500	0375	0000	%0284	E15	\$
006083	-02436	-02208	0375	0500	0750	0625	0500	0250	0000	%0285	E16	\$
006499	-02841	-03225	0375	0500	0875	0625	0500	0125	0000	%0286	E17	\$
006559	-02591	-03717	0375	0500	1000	0625	0500	0000	0000	%0287	E18	\$
005429	-04807	003641	0375	0625	0000	0625	0375	1000	0000	%0288	F10	\$
005592	-04963	003737	0375	0625	0125	0625	0375	0875	0000	%0289	F11	\$
005765	-05389	003613	0375	0625	0250	0625	0375	0750	0000	%0290	F12	\$
006068	-03782	001699	0375	0625	0375	0625	0375	0625	0000	%0291	F13	\$
006089	-03276	000816	0375	0625	0500	0625	0375	0500	0000	%0292	F14	\$
006137	-02849	-00069	0375	0625	0625	0625	0375	0375	0000	%0293	F15	\$
006631	-03266	-00755	0375	0625	0750	0625	0375	0250	0000	%0294	F16	\$
006673	-03176	-01816	0375	0625	0875	0625	0375	0125	0000	%0295	F17	\$
006553	-02943	-02912	0375	0625	1000	0625	0375	0000	0000	%0296	F18	\$
005682	-05421	003661	0375	0750	0000	0625	0250	1000	0000	%0297	G10	\$
005784	-05532	003698	0375	0750	0125	0625	0250	0875	0000	%0298	G11	\$
005805	-05437	003450	0375	0750	0250	0625	0250	0750	0000	%0299	G12	\$
006354	-04465	002142	0375	0750	0375	0625	0250	0625	0000	%0300	G13	\$
006528	-04126	001514	0375	0750	0500	0625	0250	0500	0000	%0301	G14	\$
006704	-03809	000964	0375	0750	0625	0250	0250	0375	0000	%0302	G15	\$
006758	-03530	-00019	0375	0750	0750	0625	0250	0250	0000	%0303	G16	\$
006730	-03418	-00803	0375	0750	0875	0625	0250	0125	0000	%0304	G17	\$
006480	-03406	-01970	0375	0750	1000	0625	0250	0000	0000	%0305	G18	\$
005856	-05499	003871	0375	0875	0000	0625	0125	1000	0000	%0306	H10	\$
005816	-05599	003848	0375	0875	0125	0625	0125	0875	0000	%0307	H11	\$
005899	-05465	003499	0375	0875	0250	0625	0125	0750	0000	%0308	H12	\$
006328	-04571	002401	0375	0875	0375	0625	0125	0625	0000	%0309	H13	\$
006469	-04307	001895	0375	0875	0500	0625	0125	0500	0000	%0310	H14	\$
006605	-04055	001445	0375	0875	0625	0625	0125	0375	0000	%0311	H15	\$
006728	-03792	000042	0375	0875	0750	0625	0125	0250	0000	%0312	H16	\$
006794	-03550	000040	0375	0875	0875	0625	0125	0125	0000	%0313	H17	\$
006475	-03760	-00888	0375	0875	1000	0625	0125	0000	0000	%0314	H18	\$
005861	-05505	003945	0375	1000	0000	0625	0000	1000	0000	%0315	I10	\$
005961	-05358	003925	0375	1000	0125	0625	0000	0875	0000	%0316	I11	\$
005965	-05328	003461	0375	1000	0250	0625	0000	0750	0000	%0317	I12	\$
006433	-04445	002502	0375	1000	0375	0625	0000	0625	0000	%0318	I13	\$
006440	-04407	002150	0375	1000	0500	0625	0000	0500	0000	%0319	I14	\$
006491	-04264	001699	0375	1000	0625	0000	0000	0375	0000	%0320	I15	\$
006595	-04862	001298	0375	1000	0750	0625	0000	0250	0000	%0321	I16	\$
006685	-03854	000779	0375	1000	0875	0625	0000	0125	0000	%0322	I17	\$
006647	-03708	-00091	0375	1000	1000	0625	0000	0000	0000	%0323	I18	\$
002971	003738	001668	0500	0000	0000	0500	1000	1000	0000	%0324	J10	\$
002930	004128	-00567	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$
002966	003767	-02698	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$
002812	002831	-04064	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$
003066	000566	-04909	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$
003179	-00345	-04498	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$
003390	-00853	-04507	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$
003302	-01072	-04670	0500	0000	0875	0500	1000	0125	0000	%0331	J17	\$
003090	-01149	-04833	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$
003023	003832	002609	0500	0125	0000	0500	0875	1000	0000	%0333	K10	\$
003086	004255	000503	0500	0125	0125	0500	0875	0875	0000	%0334	K11	\$
003124	004196	-01872	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$
003072	003456	-03518	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$
003116	001482	-04502	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$
003508	-00212	-04908	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$
003740	-00948	-04774	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$
004038	-01175	-05012	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$
004135	-01357	-05062	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$
003230	003663	002769	0500	0250	0000	0500	0750	1000	0000	%0342	L10	\$
003521	003618	002430	0500	0250	0125	0500	0750	0875	0000	%0343	L11	\$

See original or copy: <http://web.me.com/klauz.richter/HE30/HE30L0NA.TXT /.PS>
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

003935	005409	002419	0750	0000	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003865	005675	000825	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$	
003838	005904	-01023	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$	
003691	005360	-02218	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$	
003370	003951	-03211	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$	
003217	002249	-04169	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$	
003311	000229	-04970	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$	
003583	-00433	-05017	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$	
003818	-00900	-05102	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$	
003942	005364	-003321	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$	
003987	005658	001475	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$	
004009	006090	-00526	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$	
003854	005577	-02027	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$	
003642	-004385	-02870	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$	
003348	002869	-03795	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$	
003249	001241	-04598	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$	
003594	-00385	-05043	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$	
003938	-01060	-05080	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$	
004193	005628	-004176	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$	
004066	005410	-003084	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$	
004309	006015	000067	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$	
004273	006052	-01503	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$	
004033	004480	-02657	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$	
003704	003001	-03533	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$	
003541	001503	-04324	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$	
003831	-00364	-04884	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$	
004138	-01298	-05025	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$	
004551	005130	-004514	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$	
004468	005474	-004528	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$	
004565	005372	-002817	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$	
005290	004391	-006114	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$	
004923	-003614	-02006	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$	
004377	003050	-03116	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$	
004206	001282	-04008	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$	
004283	-00420	-04584	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$	
004459	-01514	-04906	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$	
005529	003931	-005439	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$	
005552	003987	-005466	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$	
005782	002902	-003801	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$	
005883	002803	-001977	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$	
006109	002608	-00178	0750	0500	0500	0500	0250	0500	0000	%0526	E23	\$	
005674	002769	-02293	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$	
005416	000938	-03226	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$	
005172	-00696	-04075	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$	
005451	-01733	-04256	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$	
006627	001005	-006556	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$	
006659	000990	-006551	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$	
006705	000897	-005601	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$	
006744	000848	-003549	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$	
006731	000942	-002127	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$	
006612	001267	-00304	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$	
006518	000438	-01845	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$	
006676	-00985	-02995	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$	
006925	-01699	-03071	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$	
007759	-00694	-007697	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$	
007733	-00704	-007651	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$	
007717	-00719	-007318	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$	
007744	-00802	-005206	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$	
007664	-00802	-003630	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$	
007524	-00620	-002059	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$	
007372	-00822	-000132	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$	
008061	-01056	-01170	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$	
008303	-01393	-01660	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$	
008203	-02408	-007463	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$	
008168	-02464	-007399	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$	
008114	-02562	-006802	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$	
008136	-02531	-005285	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$	
008117	-02461	-003808	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$	
008165	-02323	-002628	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$	
008448	-01882	-001515	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$	
008480	-01629	-000260	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$	
008336	-01541	-00909	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$	
007168	-03619	-005862	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$	
007190	-03607	-005596	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$	
007321	-03443	-004957	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$	
007413	-03255	-003573	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$	
007630	-02936	-002878	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$	
007870	-02607	-002312	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$	
008328	-02052	-001860	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$	
008407	-01850	-001163	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$	
008315	-01755	-00003	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$	
004384	006112	-002710	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$	
004365	006389	-001379	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$	
004474	006866	-00076	0875	0000	0250	0125	1000	0750	0000	%0569	J21		

009711	-00071	000192	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$	
009919	-00963	-00135	0875	1000	1000	0000	0125	0000	0000	0000	%0730	b02	\$
008445	-01576	-00121	0750	1000	1000	0000	0250	0000	0000	0000	%0731	b03	\$
007878	-02185	-00155	0625	1000	1000	0000	0375	0000	0000	0000	%0732	b04	\$
007264	-02848	-00154	0500	1000	1000	0000	0500	0000	0000	0000	%0733	b05	\$
006707	-03523	-00246	0375	1000	1000	0000	0625	0000	0000	0000	%0734	b06	\$
006169	-04356	-00305	0250	1000	1000	0000	0750	0000	0000	0000	%0735	b07	\$
005824	-04992	-00308	0125	1000	1000	0000	0875	0000	0000	0000	%0736	b08	\$
005681	-05375	-00309	0000	1000	1000	0000	1000	0000	0000	0000	%0737	b09	\$
009021	-001008	000021	1000	0875	0875	0000	0125	0125	0000	0000	%0738	c01	\$
008608	-00041	000197	0875	0875	0875	0125	0125	0125	0000	0000	%0739	c02	\$
008638	-01388	000119	0750	0875	0875	0250	0125	0125	0000	0000	%0740	c03	\$
007885	-02205	000091	0625	0875	0875	0375	0125	0125	0000	0000	%0741	c04	\$
007264	-02848	000002	0500	0875	0875	0500	0125	0125	0000	0000	%0742	c05	\$
006829	-03368	-00037	0375	0875	0875	0625	0125	0125	0000	0000	%0743	c06	\$
006232	-04207	000128	0250	0875	0875	0750	0125	0125	0000	0000	%0744	c07	\$
005757	-05021	000326	0125	0875	0875	0875	0125	0125	0000	0000	%0745	c08	\$
005583	-05449	000062	0000	0875	0875	1000	0125	0125	0000	0000	%0746	c09	\$
008312	-02002	000015	1000	0750	0750	0000	0250	0250	0000	0000	%0747	d01	\$
008030	001139	-00145	0875	0750	0750	0125	0250	0250	0000	0000	%0748	d02	\$
007632	-00032	000103	0750	0750	0750	0250	0250	0250	0000	0000	%0749	d03	\$
007497	-01483	-00065	0625	0750	0750	0375	0250	0250	0000	0000	%0750	d04	\$
007148	-02543	-00009	0500	0750	0750	0500	0250	0250	0000	0000	%0751	d05	\$
006875	-03278	000018	0375	0750	0750	0625	0250	0250	0000	0000	%0752	d06	\$
006205	-04269	000146	0250	0750	0750	0750	0250	0250	0000	0000	%0753	d07	\$
005644	-05166	000343	0125	0750	0750	0875	0250	0250	0000	0000	%0754	d08	\$
005361	-05787	001058	0000	0750	0750	1000	0250	0250	0000	0000	%0755	d09	\$
007417	003267	000261	1000	0625	0625	0000	0375	0375	0000	0000	%0756	e01	\$
007420	002517	000000	0875	0625	0625	0125	0375	0375	0000	0000	%0757	e02	\$
006974	001159	-00286	0750	0625	0625	0250	0375	0375	0000	0000	%0758	e03	\$
006525	-00033	000040	0625	0625	0625	0375	0375	0375	0000	0000	%0759	e04	\$
006366	-01624	-00182	0500	0625	0625	0500	0375	0375	0000	0000	%0760	e05	\$
006162	-02720	-00176	0375	0625	0625	0625	0375	0375	0000	0000	%0761	e06	\$
005930	-04184	000052	0250	0625	0625	0750	0375	0375	0000	0000	%0762	e07	\$
005308	-05810	000482	0125	0625	0625	0875	0375	0375	0000	0000	%0763	e08	\$
005029	-06452	001442	0000	0625	0625	1000	0375	0375	0000	0000	%0764	e09	\$
006441	004754	000756	1000	0500	0500	0000	0500	0500	0000	0000	%0765	f01	\$
006525	004120	000134	0875	0500	0500	0125	0500	0500	0000	0000	%0766	f02	\$
006230	002538	-00223	0750	0500	0500	0250	0500	0500	0000	0000	%0767	f03	\$
005767	001202	-00283	0625	0500	0500	0375	0500	0500	0000	0000	%0768	f04	\$
005138	-00017	000030	0500	0500	0500	0500	0500	0500	0000	0000	%0769	f05	\$
005162	-01731	-00357	0375	0500	0500	0625	0500	0500	0000	0000	%0770	f06	\$
004970	-03116	-00194	0250	0500	0500	0750	0500	0500	0000	0000	%0771	f07	\$
004934	-05762	000537	0125	0500	0500	0875	0500	0500	0000	0000	%0772	f08	\$
004585	-06891	001912	0000	0500	0500	1000	0500	0500	0000	0000	%0773	f09	\$
005536	006307	001243	1000	0375	0375	0000	0625	0625	0000	0000	%0774	g01	\$
005508	005892	000770	0875	0375	0375	0125	0625	0625	0000	0000	%0775	g02	\$
005263	004389	000093	0750	0375	0375	0250	0625	0625	0000	0000	%0776	g03	\$
004892	002831	-00172	0625	0375	0375	0375	0625	0625	0000	0000	%0777	g04	\$
004458	001306	-00278	0500	0375	0375	0500	0625	0625	0000	0000	%0778	g05	\$
003796	000000	000015	0375	0375	0375	0625	0625	0625	0000	0000	%0779	g06	\$
003170	-01952	-00406	0250	0375	0375	0750	0625	0625	0000	0000	%0780	g07	\$
003963	-04182	000006	0125	0375	0375	0875	0625	0625	0000	0000	%0781	g08	\$
004209	-06232	001484	0000	0375	0375	1000	0625	0625	0000	0000	%0782	g09	\$
005059	007117	001605	1000	0250	0250	0000	0750	0750	0000	0000	%0783	h01	\$
004789	006867	001383	0875	0250	0250	0125	0750	0750	0000	0000	%0784	h02	\$
004273	005991	000091	0750	0250	0250	0250	0750	0750	0000	0000	%0785	h03	\$
003992	004732	000228	0625	0250	0250	0375	0750	0750	0000	0000	%0786	h04	\$
003554	003149	-00198	0500	0250	0250	0500	0750	0750	0000	0000	%0787	h05	\$
003340	001440	-00265	0375	0250	0250	0625	0750	0750	0000	0000	%0788	h06	\$
002673	000021	000031	0250	0250	0250	0750	0750	0750	0000	0000	%0789	h07	\$
003078	-02281	-00407	0125	0250	0250	0875	0750	0750	0000	0000	%0790	h08	\$
003276	-04390	000957	0000	0250	0250	1000	0750	0750	0000	0000	%0791	h09	\$
003066	007056	002529	1000	0125	0125	0000	0875	0875	0000	0000	%0792	i01	\$
005406	006209	001777	0875	0125	0125	0125	0875	0875	0000	0000	%0793	i02	\$
003893	005543	001424	0750	0125	0125	0250	0875	0875	0000	0000	%0794	i03	\$
003409	004907	001010	0625	0125	0125	0375	0875	0875	0000	0000	%0795	i04	\$
002918	004137	000503	0500	0125	0125	0500	0875	0875	0000	0000	%0796	i05	\$
002587	003128	000063	0375	0125	0125	0625	0875	0875	0000	0000	%0797	i06	\$
002360	001733	-00213	0250	0125	0125	0750	0875	0875	0000	0000	%0798	i07	\$
001737	000065	000112	0125	0125	0125	0875	0875	0875	0000	0000	%0799	i08	\$
002185	-01949	-00030	0000	0125	0125	1000	0875	0875	0000	0000	%0800	i09	\$
004943	006958	003155	1000	0000	0000	0000	1000	1000	0000	0000	%0801	j01	\$
004261	005959	002756	0875	0000	0000	0125	1000	1000	0000	0000	%0802	j02	\$
003823	005253	002479	0750	0000	0000	0250	1000	1000	0000	0000	%0803	j03	\$
003355	004548	002229	0625	0000	0000	0375	1000	1000	0000	0000	%0804	j04	\$
002820	003677	001619	0500	0000	0000	0500	1000	1000	0000	0000	%0805	j05	\$
002292	002788	000951	0375	0000	0000	0625	1000	1000	0000	0000	%0806	j06	\$
001974	002176	000305	0250	0000	0000	0750	1000	1000	0000	0000	%0807	j07	\$
001726	000522	-00192	0125	0000	0000	0875	1000	1000	0000	0000	%0808	j08	\$
001375	000059	000110	0000	0000	0000	1000	1000	1000	0000	0000	%0809	j09	\$
009707	-00068	000192	1000	1000	1000	0000	0000	0000	0000	0000	%0810	b10	\$
009052	-00771	-00710	0875	0875	0875	0125	0125	0000	0000	0000	%0811	b11	\$
008412	-01263	-01529	0750	0750	0750	0250	0250	0000	0000	0000	%0812	b12	\$
007604	-01858	-02502	0625	0625	1000	0375	0375	0000	0000	0000	%0813	b13	\$
006943	-02241	-03261	0500	0500	0500	0500	0500	0000	0000	0000	%0814	b14	\$
006163	-02391	-03947	0375	0375	1000	0625	0625	0000	0000	0000	%0815	b15	\$
005391	-02587	-04663	0250	0250	1000	0750	0750	0000	0000	0000	%0816	b16	\$
004406	-02555	-05068	0125	0250	1000	0875	0875	0000	0000	0000	%0817	b17	\$
004562	-02262	-05119	0000	0000	1000	1000	1000	0000	0000	0000	%0818	b18	\$
009647	-00518	002010	1000	1000	0875	0000	0125	0000	0000	0000	%0819	c10	\$
008775	-00039	000182	0875	0875	0875	0125	0125	0250	0000	0000	%0820	c11	\$
008306	-00928	-01027	0750	0750	0875	0250	0250	0125	0000	0000	%0821	c12	\$
007613	-01581	-02288	0625	0625	0875	0375	0375	0125	0000	0000	%0822	c13	\$
006777	-01912												

%BEG HE20_22.TXT, Separation olv*, D50, not adapted \$
%100 x LAB*
%#1000 x (r g b c m y 0) %nr. pos \$
%z004967 006956 003029 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z009212 -00871 009324 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005773 -05763 003948 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005712 -05398 000812 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z004629 -02284 -05122 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003492 000222 -04831 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001313 000054 000099 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009708 -00066 000205 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004943 006958 003155 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z009218 -00866 009293 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005757 -05709 003771 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005681 -05376 000899 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z004562 -02262 -05119 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003438 000263 -04837 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z001311 000063 000109 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009704 -00068 000196 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/HE30/HE30L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG HE20.22.TXT, Separation olv*, D50, not adapted \$																										
%100 x LAB*				1000 x (r g b c m y θ)				%nr.	pos	\$																
001280	000041	000111	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$	0005512	-000029	000186	0866	0866	0133	0133	0133	0000	%1053	m23	\$		
001482	000046	000119	0125	0125	0125	0875	0875	0875	0000	%0973	k02	\$	0009167	-000046	000203	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$	
002443	000016	000045	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$	0009702	-000068	000203	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$	
003638	-00003	000015	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$	0014444	000062	000122	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$	
004998	-00010	000038	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	0013132	000070	000113	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$	
006466	-00024	000058	0625	0625	0625	0625	0625	0625	0000	%0977	k06	\$	001760	000060	000097	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$	
007659	-00029	000105	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$	002300	000032	000037	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$	
008772	-00036	000172	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$	002836	000018	000024	0266	0266	0266	0333	0333	0333	0000	%1060	n14	\$	
009724	-00068	000192	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$	003457	000013	000016	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$	
001265	000041	000096	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$	004123	000009	000032	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$	
001518	000050	000123	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$	004742	000003	000063	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$	
002423	000019	000028	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$	005514	-000009	000059	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$	
003616	000002	000010	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$	006288	-00017	000076	0600	0600	0600	0400	0400	0400	0000	%1065	n19	\$	
004997	-00010	000026	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	006883	-00020	000100	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$	
006472	-00024	000058	0625	0625	0625	0625	0625	0625	0000	%0986	l06	\$	007485	-00025	000137	0734	0734	0734	0266	0266	0266	0000	%1067	n21	\$	
007685	-00030	000112	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$	008026	-00023	000164	0800	0800	0800	0200	0200	0200	0000	%1068	n22	\$	
008788	-00038	000175	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$	008508	-00031	000159	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$	
009726	-00067	000188	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$	009109	-00043	000208	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$	
001284	000046	000111	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$	009711	-00063	000190	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$	
001536	000049	000118	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$	001241	000054	000085	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$	
002443	000019	000040	0250	0250	0250	0750	0750	0750	0000	%0992	m03	\$	0009725	-00003	000195	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$	
003651	000002	000016	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$	004936	000005	003380	1000	0000	0000	1000	1000	1000	0000	%1074	l26	\$	
004990	-00007	000035	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$	005679	-05596	001211	0000	1000	1000	1000	0000	0000	0000	%1075	l27	\$	
006480	-00026	000067	0625	0625	0625	0625	0625	0625	0000	%0995	m06	\$	009213	-00046	009406	1000	1000	0000	0000	0000	1000	0000	%1076	m26	\$	
007686	-00032	000117	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$	004573	-02306	-05159	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$	
008802	-00041	000178	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$	005679	-00019	003920	0000	1000	0000	0000	0000	1000	0000	%1078	n26	\$	
009734	-00073	000205	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$	003491	000225	-04908	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$	
001295	000049	000102	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$														
001504	000048	000116	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$	%004936	000905	003380	%#1000	0000	0000	0000	1000	1000	0000	0000	%1074	l26	%03 0 0
002517	000015	000032	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$	%009213	-00046	009406	%#1000	1000	0000	0000	0000	1000	0000	0000	%1076	m26	%Y3 1 2
003683	-00004	000012	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$	%005679	-00019	003920	%#0000	1000	0000	1000	0000	0000	1000	0000	%1078	n26	%C3 3 3
004914	-00015	000034	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$	%005679	-05596	001211	%#0000	1000	1000	1000	0000	0000	0000	0000	%1075	l27	%C3 3 3
006495	-00028	000057	0625	0625	0625	0625	0625	0625	0000	%1004	n06	\$	%004573	-02306	-05159	%#0000	0000	1000	1000	1000	0000	0000	0000	%1077	m27	%V3 4 0
007730	-00031	000114	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$	%003491	000225	-04908	%#1000	0000	1000	0000	1000	0000	0000	0000	%1079	n27	%M3 5 0
008830	-00036	000179	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$	%003491	000254	%00005	%#0000	0000	0000	1000	1000	1000	0000	0000	%1072	k26	%N3 6 0
009728	-00067	000185	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$	%009725	-00003	000195	%#1000	1000	1000	0000	0000	0000	0000	0000	%1073	k27	%N3 7 0
001452	000053	000105	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$														
001348	000060	000109	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$	%001366	000047	000108	%#0000	0000	0000	1000	1000	1000	0000	0000	%0972	k01	%N4 6 0
001711	000052	000078	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$	%009718	-00064	000187	%#1000	1000	1000	0000	0000	0000	0000	0000	%0980	k09	%N4 7 0
002325	000028	000029	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$														
002832	000015	000010	0266	0266	0266	0333	0333	0333	0000	%1012	k14	\$	%001415	000049	000098	%#0000	0000	0000	1000	1000	1000	0000	0000	%0981	l01	%N5 6 0
003463	000016	000013	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$	%009719	-00062	000184	%#1000	1000	1000	0000	0000	0000	0000	0000	%0989	l09	%N5 7 0
004084	000010	000023	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$														
004760	000005	000053	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$	%001380	000053	000111	%#0000	0000	0000	1000	1000	1000	0000	0000	%0990	m01	%N6 6 0
005509	-00008	000055	0533	0533	0533	0466	0466	0466	0000	%1016	k18	\$	%009718	-00071	000204	%#1000	1000	1000	0000	0000	0000	0000	0000	%0998	m09	%N6 7 0
006274	-00020	000079	0600	0600	0600	0400	0400	0400	0000	%1017	k19	\$														
006934	-00024	000094	0666	0666	0666	0333	0333	0333	0000	%1018	k20	\$	%001369	000055	000112	%#0000	0000	0000	1000	1000	1000	0000	0000	%0999	n01	%N7 6 0
007449	-00021	000131	0734	0734	0734	0266	0266	0266	0000	%1019	k21	\$	%009720	-00065	000187	%#1000	1000	1000	0000	0000	0000					

```
input: w setgray
output: -> olv* setrgbcolor
```

See original or copy: <http://web.me.com/klau.s.richter/HE30/HE30L0NA.TXT> /PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

002399	002757	000839	0375	0000	0000	0625	1000	1000	0000	%0243	A10 \$	002971	003707	001547	0500	0000	0000	0500	1000	1000	0000	%0324	J10 \$	003462	004607	002044	0625	0000	0000	0375	1000	1000	0000	%0405	S10 \$
002411	003085	-01284	0375	0000	0125	0625	1000	0875	0000	%0244	A11 \$	002930	004096	-00687	0500	0000	0125	0500	1000	0875	0000	%0325	J11 \$	003421	004948	-00026	0625	0000	0125	0375	1000	0875	0000	%0406	S11 \$
002501	002795	-03766	0375	0000	0250	0625	1000	0750	0000	%0245	A12 \$	002966	003736	-02818	0500	0000	0250	0500	1000	0750	0000	%0326	J12 \$	003363	004642	-02180	0625	0000	0250	0375	1000	0750	0000	%0407	S12 \$
002761	000559	-04558	0375	0000	0375	0625	1000	0625	0000	%0246	A13 \$	002812	002798	-04182	0500	0000	0375	0500	1000	0625	0000	%0327	J13 \$	003231	004132	-03233	0625	0000	0375	0375	1000	0625	0000	%0408	S13 \$
002845	-00288	-04128	0375	0000	0500	0625	1000	0500	0000	%0247	A14 \$	003066	000537	-05022	0500	0000	0500	0500	1000	0500	0000	%0328	J14 \$	003066	002472	-04244	0625	0000	0500	0375	1000	0500	0000	%0409	S14 \$
003201	-00755	-04052	0375	0000	0625	0625	1000	0375	0000	%0248	A15 \$	003179	-00373	-04621	0500	0000	0625	0500	1000	0375	0000	%0329	J15 \$	003279	000269	-05019	0625	0000	0625	0375	1000	0375	0000	%0410	S15 \$
003414	-00968	-04559	0375	0000	0750	0625	1000	0250	0000	%0249	A16 \$	003390	-00078	-04633	0500	0000	0750	0500	1000	0250	0000	%0330	J16 \$	003441	-00419	-04976	0625	0000	0750	0375	1000	0250	0000	%0411	S16 \$
003790	-01120	-04867	0375	0000	0875	0625	1000	0125	0000	%0250	A17 \$	003632	-01093	-04744	0500	0000	0875	0500	1000	0125	0000	%0331	J17 \$	003717	-00962	-04952	0625	0000	0875	0375	1000	0125	0000	%0412	S17 \$
004111	-01295	-05193	0375	0000	1000	0625	1000	0000	0000	%0251	A18 \$	003900	-01165	-05065	0500	0000	1000	0500	1000	0000	0000	%0332	J18 \$	003875	-01123	-05036	0625	0000	1000	0375	1000	0000	0000	%0413	S18 \$
002533	002761	001570	0375	0125	0000	0625	0875	1000	0000	%0252	B10 \$	003023	003002	-002488	0500	0125	0000	0500	0875	1000	0000	%0333	K10 \$	003527	004509	002914	0625	0125	0000	0375	0875	1000	0000	%0414	T10 \$
002667	003028	-00929	0375	0125	0125	0625	0875	0875	0000	%0253	B11 \$	003086	004226	-000381	0500	0125	0125	0500	0875	0875	0000	%0334	K11 \$	003591	004920	000031	0625	0125	0125	0375	0875	0875	0000	%0415	T11 \$
002711	003084	-02817	0375	0125	0250	0625	0875	0750	0000	%0254	B12 \$	003124	004167	-01994	0500	0125	0250	0500	0875	0750	0000	%0335	K12 \$	003598	005173	-01406	0625	0125	0250	0375	0875	0750	0000	%0416	T12 \$
002973	001218	-04101	0375	0125	0375	0625	0875	0625	0000	%0255	B13 \$	003072	003427	-03640	0500	0125	0375	0500	0875	0625	0000	%0336	K13 \$	003524	004474	-02920	0625	0125	0375	0375	0875	0625	0000	%0417	T13 \$
003325	-00373	-04736	0375	0125	0500	0625	0875	0500	0000	%0256	B14 \$	003116	001453	-04624	0500	0125	0500	0500	0875	0500	0000	%0337	K14 \$	003310	003126	-03785	0625	0125	0500	0375	0875	0500	0000	%0418	T14 \$
003629	-00959	-04777	0375	0125	0625	0625	0875	0375	0000	%0257	B15 \$	003508	-00235	-05036	0500	0125	0625	0500	0875	0375	0000	%0338	K15 \$	003243	001323	-04609	0625	0125	0625	0375	0875	0375	0000	%0419	T15 \$
003940	-01191	-05065	0375	0125	0750	0625	0875	0250	0000	%0258	B16 \$	003740	-00968	-04904	0500	0125	0750	0500	0875	0250	0000	%0339	K16 \$	003614	-00379	-05142	0625	0125	0750	0375	0875	0250	0000	%0420	T16 \$
004242	-01527	-05170	0375	0125	0875	0625	0875	0125	0000	%0259	B17 \$	004038	-01191	-05146	0500	0125	0875	0500	0875	0125	0000	%0340	K17 \$	003964	-00968	-05117	0625	0125	0875	0375	0875	0125	0000	%0421	T17 \$
004366	-01803	-05202	0375	0125	1000	0625	0875	0000	0000	%0260	B18 \$	004135	-01371	-05197	0500	0125	1000	0500	0875	0000	0000	%0341	K18 \$	004068	-01169	-05161	0625	0125	1000	0375	0875	0000	0000	%0422	T18 \$
002966	001981	-002160	0375	0250	0000	0625	0750	1000	0000	%0261	C10 \$	003230	003636	-02645	0500	0250	0000	0500	0750	1000	0000	%0342	L10 \$	003752	004819	003402	0625	0250	0000	0375	0750	1000	0000	%0423	U10 \$
003357	001534	001923	0375	0250	0125	0625	0750	0875	0000	%0262	C11 \$	003521	003595	-002302	0500	0250	0125	0500	0750	0875	0000	%0343	L11 \$	003780	004675	002633	0625	0250	0125	0375	0750	0875	0000	%0424	U11 \$
003511	001302	-003090	0375	0250	0250	0625	0750	0750	0000	%0263	C12 \$	003789	003025	-00327	0500	0250	0250	0500	0750	0750	0000	%0344	L12 \$	004007	004715	000098	0625	0250	0250	0375	0750	0750	0000	%0425	U12 \$
003293	000304	-02335	0375	0250	0375	0625	0750	0625	0000	%0264	C13 \$	003651	003254	-02994	0500	0250	0375	0500	0750	0625	0000	%0345	L13 \$	003887	004800	-02310	0625	0250	0375	0375	0750	0625	0000	%0426	U13 \$
003854	-00829	-03967	0375	0250	0500	0625	0750	0500	0000	%0265	C14 \$	003750	001127	-03910	0500	0250	0500	0500	0750	0500	0000	%0346	L14 \$	003767	003311	-03475	0625	0250	0500	0375	0750	0500	0000	%0427	U14 \$
004131	-01298	-04719	0375	0250	0625	0625	0750	0375	0000	%0266	C15 \$	003851	-00505	-04966	0500	0250	0625	0500	0750	0375	0000	%0347	L15 \$	003661	001530	-04278	0625	0250	0625	0375	0750	0375	0000	%0428	U15 \$
004475	-01694	-05083	0375	0250	0750	0625	0750	0250	0000	%0267	C16 \$	004121	-01218	-05144	0500	0250	0750	0500	0750	0250	0000	%0348	L16 \$	003853	-00419	-04976	0625	0250	0750	0375	0750	0250	0000	%0429	U16 \$
004680	-01941	-05053	0375	0250	0875	0625	0750	0125	0000	%0268	C17 \$	004351	-01556	-05109	0500	0250	0875	0500	0750	0125	0000	%0349	L17 \$	004124	-01206	-05106	0625	0250	0875	0375	0750	0125	0000	%0430	U17 \$
005007	-02403	-05008	0375	0250	1000	0625	0750	0000	0000	%0269	C18 \$	004618	-02025	-05127	0500	0250	1000	0500	0750	0000	0000	%0350	L18 \$	004316	-01574	-05136	0625	0250	1000	0375	0750	0000	0000	%0431	U18 \$
004165	-00570	003573	0375	0375	0000	0625	0625	1000	0000	%0270	D10 \$	004169	001462	-03523	0500	0375	0000	0500	0625	1000	0000	%0351	M10 \$	004290	003328	003752	0625	0375	0000	0375	0625	1000	0000	%0432	U19 \$
004337	-00628	003572	0375	0375	0125	0625	0625	0875	0000	%0271	D11 \$	004316	001396	-03695	0500	0375	0125	0500	0625	0875	0000	%0352	M11 \$	004439	003423	003980	0625	0375	0125	0375	0625	0875	0000	%0433	V10 \$
004178	-00477	001485	0375	0375	0250	0625	0625	0750	0000	%0272	D12 \$	004569	001192	-03771	0500	0375	0250	0500	0625	0750	0000	%0353	M12 \$	004687</											

See original or copy: <http://web.me.com/klaustrichter/HE30/HE30L0NA.TXT> /PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

003935	005392	002286	0750	0000	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003865	005657	000693	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$	
003838	005886	-01154	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$	
003691	005339	-02348	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$	
003370	003926	-03336	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$	
003217	002222	-04293	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$	
003311	000203	-05094	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$	
003583	-00455	-05146	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$	
003818	-00919	-05234	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$	
003942	005347	003188	0750	0125	0000	0250	0875	1000	0000	%0495	B19	\$	
003887	005642	001342	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$	
004009	006075	-00660	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$	
003854	005559	-02159	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$	
003642	004364	-02999	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$	
003348	002844	-03921	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$	
003249	001214	-04722	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$	
003594	-00407	-05172	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$	
003938	-01077	-05213	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$	
004193	005614	004040	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$	
004066	005395	002959	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$	
004309	006003	000729	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$	
004273	006040	-01640	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$	
004033	004465	-02792	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$	
003704	002981	-03662	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$	
003541	001480	-04452	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$	
003831	-00382	-05015	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$	
004138	-01312	-05161	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$	
004551	005122	004373	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$	
004468	005465	004388	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$	
004565	005364	002676	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$	
005290	004394	-00035	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$	
004923	004511	-02152	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$	
004377	003040	-03255	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$	
004206	001269	-04145	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$	
004283	-00431	-04721	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$	
004459	-01523	-05045	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$	
005529	003938	005286	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$	
005552	003993	005313	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$	
005782	002911	003645	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$	
005883	002814	001820	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$	
006109	002622	-00338	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$	
005674	002777	-02447	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$	
005416	000942	-03377	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$	
005172	-00695	-04224	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$	
005451	-01728	-04408	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$	
006627	001027	-00639	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$	
006659	001013	005433	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$	
006705	000920	006383	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$	
006744	000871	003380	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$	
006731	000965	001959	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$	
006612	001289	-00471	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$	
006518	000458	-02010	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$	
006676	-00963	-03162	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$	
006925	-01672	-03241	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$	
007759	-00656	007516	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$	
007733	-00666	007470	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$	
007717	-00681	007137	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$	
007744	-00764	005026	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$	
007664	-00765	003451	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$	
007524	-00585	001881	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$	
007372	000010	-00043	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$	
008061	-01013	-01355	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$	
008303	-01347	-01848	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$	
008203	-02363	-00727	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$	
008168	-02419	-007213	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$	
008114	-02518	-006616	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$	
008136	-02487	-005109	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$	
008117	-02417	-003622	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$	
008165	-02279	-002442	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$	
008448	-01834	-001325	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$	
008480	-01580	-000609	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$	
008336	-01494	-01097	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$	
007168	-03589	-005689	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$	
007190	-03577	-005422	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$	
007321	-03411	-004782	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$	
007413	-03222	-003396	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$	
007630	-02899	-002698	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$	
007870	-02567	-002130	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$	
008328	-02005	-001671	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$	
008407	-01802	-000974	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$	
008315	-01709	-00191	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$	
004384	006102	002572	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$	
004365	006379	001241	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$	
004474	006857	-00215	0875	0000	0250	0125	1000	0750	0000	%0569	J21</		

009711	-00002	-00004	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009019	-00905	-00325	0875	1000	1000	0000	0125	0000	0000	%0730	b02	\$
008445	-01527	-00305	0750	1000	1000	0000	0250	0000	0000	%0731	b03	\$
007878	-02145	-00333	0625	1000	1000	0000	0375	0000	0000	%0732	b04	\$
007264	-02810	-00325	0500	1000	1000	0000	0500	0000	0000	%0733	b05	\$
006707	-03501	-00412	0375	1000	1000	0000	0625	0000	0000	%0734	b06	\$
006169	-04343	-00194	0250	1000	1000	0000	0750	0000	0000	%0735	b07	\$
005824	-04905	-00232	0125	1000	1000	0000	0875	0000	0000	%0736	b08	\$
005681	-05371	-00074	0000	1000	1000	0000	1000	0000	0000	%0737	b09	\$
009021	-00166	-00160	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
008608	-00010	-00012	0875	0875	0875	0125	0125	0125	0000	%0739	c02	\$
008638	-01336	-00066	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
007885	-02165	-00086	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
007264	-02810	-00168	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
006829	-03345	-00204	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
006232	-04193	-00032	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005757	-05014	-00017	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
005583	-05445	-00080	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008312	-02049	-00166	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
008030	-00181	-00325	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
007632	-00003	-00071	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
007147	-01449	-00238	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
007148	-02515	-00180	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
006875	-03254	-00148	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
006205	-04256	-00013	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005644	-05162	-00019	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
005361	-05787	-00096	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007417	-00329	-00088	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007420	-00250	-00172	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
006974	-00185	-00454	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006525	-00014	-00123	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
006366	-01608	-00344	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
006162	-02707	-00336	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
005930	-04174	-00104	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
005308	-05810	-00311	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
005029	-06457	-00129	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
006441	-004771	-00593	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006525	-004139	-00029	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006230	-002552	-00383	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$
005767	-001208	-00439	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005138	-00020	-00119	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005162	-01734	-00506	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
004970	-03122	-00342	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004934	-05769	-00039	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
004895	-06898	-001765	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
005536	-006310	-001090	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
005508	-005895	-000617	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005263	-004388	-00056	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
004892	-002824	-00318	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004458	-001292	-00420	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
003796	-00023	-00120	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
003770	-01977	-00541	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
003963	-04204	-00130	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
004200	-00250	-001345	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
005059	-007112	-001337	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
004799	-006859	-001238	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
004273	-005974	-000601	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
003972	-004728	-000093	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
003554	-003121	-00330	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
003340	-001408	-00396	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
002673	-00020	-00091	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
003078	-02316	-00535	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
003276	-04423	-000827	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
005006	-007051	-002381	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004366	-006194	-001636	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
003893	-005520	-001288	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
003409	-004876	-000879	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
002918	-004098	-000377	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
002587	-003085	-00058	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
002360	-001686	-00334	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
001737	-000009	-000000	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
002185	-01999	-00148	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
004943	-006952	-003008	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
004261	-005942	-002616	0875	0000	0000	0125	1000	1000	0000	%0802	j02	\$
003823	-005229	-002344	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
003355	-004517	-002098	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
002829	-003638	-001494	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
002292	-002740	-000832	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
001974	-001223	-000189	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
001726	-000465	-00306	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
001375	-00003	-000000	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009707	000000	-00004	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
009052	-00713	-00909	0875	0875	0875	0125	0125	0000	0000	%0811	b11	\$
008412	-01214	-01712	0750	0750	0750	0250	0250	0000	0000	%0812	b12	\$
007604	-01822	-02677	0625	0625	0625	0375	0375	0000	0000	%0813	b13	\$
006943	-02216	-03429	0500	0500	0500	0500	0500	0000	0000	%0814	b14	\$
006163	-02378	-04107	0375	0375	0375	0625	0625	0000	0000	%0815	b15	\$
005391	-02587	-04815	0250	0250	0250	0750	0750	0000	0000	%0816	b16	\$
004606	-02560	-05234	0125	0125	0125	0875	0875	0000	0000	%0817	b17	\$
004566	-02274	-05263	0000	0000	0000	1000	1000	0000	0000	%0818	b18	\$
009647	-00450	-001814	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$
008775	000014	-00004	0875	0875	0875	0125	0125	0125	0000	%0820	c11	\$
008306	-00881	-01209	0750	0750	0750	0250	0250	0125	0000	%0821	c12	\$
007613	-01545	-02463	0625	0625	0625	0375	0375	0125	0000	%0822	c13	\$
006777	-01890	-03435	0500	0500	0500	0500	0500	0125	0000	%0823	c14	\$
005825	-02273	-04338	0375	0375	0375	0625	0625	0125	0000	%0824	c15	\$
004958	-02332	-05001	0250	0250	0250	0750	0750	0125	0000	%0825	c16	\$
004648	-02275	-05202	0125	0125	0125	0875	0875	0125	0000	%0826	c17	\$
004443	-01953	-05214	0000	0000	0750	1000	1000	0125	0000	%0827	c18	\$
005952	-00690	-003175	1000	1000	0750	0000	0250	0000	0000	%0828	d10	\$
008896	-00453	-001514	0875	0875	0750	0125	0125	0250	0000	%0829	d11	\$
007783	000003	-0006										

```
%BEG HE20_22.TXT, Separation olv*, D50, adapted $
%100 x LAB*a      %#1000 x (r g b c m y 0)      %nr. pos $
%z004967 006954 002884 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 $
%z009212 -00812 009125 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 $
%z005773 -05754 003792 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 $
%z005712 -05389 000657 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 $
%z004629 -02290 -05264 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 $
%z003492 000198 -04958 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 $
%z001313 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 $
%z009708 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 $
%$
%z004943 006952 003008 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 $
%z009218 -00805 009102 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 $
%z005757 -05703 003616 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 $
%z005681 -05371 000744 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 $
%z004562 -02274 -05263 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 $
%z003438 000233 -04968 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 $
%z001311 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 $
%z009704 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 $
%$
```

See original or copy: <http://web.me.com/klaus.richter/HE30/HE30L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

TUB registration: 20091101-HE30/HE30L0NA.TXT /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

[illegible]

TUB-test chart HE30; Relative Elementary Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```