

See original or copy: <http://web.me.com/klaus.richter/HE37/HE37L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

[illegible]

TUB-test chart HE37; Relative Elementary Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

input: w *setgray*
output: no change compared to input

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-HE37/HE37L0NA.TXT /PS
 application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

001752	002855	-01028	0375	0000	0000	0025	1000	1000	0000	%0243	A10	\$
001859	003637	-02631	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$
001819	003952	-03594	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$
001400	003416	-04054	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$
001304	003909	-04962	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$
001219	004452	-05668	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$
001505	004548	-06090	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$
001890	004155	-06228	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$
002285	005403	-06074	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$
001990	001854	-00107	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$
002596	002037	-01310	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$
002722	002721	-02746	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$
002372	002219	-03331	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$
002227	002613	-04436	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$
002448	002850	-05169	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$
002931	002611	-05499	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$
003308	002244	-05590	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$
003664	001578	-05377	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$
002933	000283	-002178	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$
003173	000647	-000110	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$
003533	000843	-01268	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$
003446	000928	-02295	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$
003431	001096	-03424	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$
003881	001119	-04068	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$
004362	000973	-04501	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$
004740	000671	-04656	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$
005093	000062	-04424	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$
003850	-01204	003368	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$
004062	-00887	001168	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$
004266	-00598	-00156	0375	0375	0250	0625	0625	0750	0000	%0272	D12	\$
004379	-00168	-01266	0375	0375	0375	0625	0625	0625	0000	%0273	D13	\$
004870	-00348	-01980	0375	0375	0500	0625	0625	0500	0000	%0274	D14	\$
005285	-00305	-02768	0375	0375	0625	0625	0625	0375	0000	%0275	D15	\$
005692	-00316	-03382	0375	0375	0750	0625	0625	0250	0000	%0276	D16	\$
006023	-00499	-03677	0375	0375	0875	0625	0625	0125	0000	%0277	D17	\$
006297	-00972	-03499	0375	0375	1000	0625	0625	0000	0000	%0278	D18	\$
004766	-02571	-004614	0375	0500	0000	0625	0500	1000	0000	%0279	D19	\$
004906	-02373	-002271	0375	0500	0125	0625	0500	0875	0000	%0280	E11	\$
005014	-02102	-000781	0375	0500	0250	0625	0500	0750	0000	%0281	E12	\$
005145	-01467	-00564	0375	0500	0375	0625	0500	0625	0000	%0282	E13	\$
005202	-01142	-01320	0375	0500	0500	0625	0500	0500	0000	%0283	E14	\$
005815	-01322	-02198	0375	0500	0625	0625	0500	0375	0000	%0284	E15	\$
006151	-01206	-02927	0375	0500	0750	0625	0500	0250	0000	%0285	E16	\$
006480	-01398	-03250	0375	0500	0875	0625	0500	0125	0000	%0286	E17	\$
006717	-01805	-03104	0375	0500	1000	0625	0500	0000	0000	%0287	E18	\$
005254	-03618	-005253	0375	0625	0000	0625	0375	1000	0000	%0288	F10	\$
005541	-03499	-002964	0375	0625	0125	0625	0375	0875	0000	%0289	F11	\$
005442	-03263	-001492	0375	0625	0250	0625	0375	0750	0000	%0290	F12	\$
005774	-02528	-000062	0375	0625	0375	0625	0375	0625	0000	%0291	F13	\$
005841	-02198	-00771	0375	0625	0500	0625	0375	0500	0000	%0292	F14	\$
005898	-01844	-01530	0375	0625	0625	0625	0375	0375	0000	%0293	F15	\$
006573	-02032	-02491	0375	0625	0750	0625	0375	0250	0000	%0294	F16	\$
006879	-02176	-02858	0375	0625	0875	0625	0375	0125	0000	%0295	F17	\$
007062	-02498	-02758	0375	0625	1000	0625	0375	0000	0000	%0296	F18	\$
005594	-04373	-005718	0375	0750	0000	0625	0250	1000	0000	%0297	G10	\$
005783	-04389	-003444	0375	0750	0125	0625	0250	0875	0000	%0298	G11	\$
005908	-04228	-001970	0375	0750	0250	0625	0250	0750	0000	%0299	G12	\$
006300	-03300	-000530	0375	0750	0375	0625	0250	0625	0000	%0300	G13	\$
006365	-03115	-00260	0375	0750	0500	0625	0250	0500	0000	%0301	G14	\$
006436	-02771	-01070	0375	0750	0625	0250	0250	0375	0000	%0302	G15	\$
006522	-02389	-01834	0375	0750	0750	0625	0250	0250	0000	%0303	G16	\$
007055	-02626	-02537	0375	0750	0875	0625	0250	0125	0000	%0304	G17	\$
007085	-02538	-02735	0375	0750	1000	0625	0250	0000	0000	%0305	G18	\$
005747	-04921	-005935	0375	0875	0000	0625	0125	1000	0000	%0306	H10	\$
006018	-05000	-003777	0375	0875	0125	0625	0125	0875	0000	%0307	H11	\$
006125	-04902	-002275	0375	0875	0250	0625	0125	0750	0000	%0308	H12	\$
006710	-04058	-000853	0375	0875	0375	0625	0125	0625	0000	%0309	H13	\$
006787	-03813	-000094	0375	0875	0500	0625	0125	0500	0000	%0310	H14	\$
006862	-03496	-00759	0375	0875	0625	0625	0125	0375	0000	%0311	H15	\$
006957	-03169	-01471	0375	0875	0750	0625	0125	0250	0000	%0312	H16	\$
007015	-02853	-02132	0375	0875	0875	0625	0125	0125	0000	%0313	H17	\$
007091	-02532	-02733	0375	0875	1000	0625	0125	0000	0000	%0314	H18	\$
005641	-05080	-005771	0375	1000	0000	0625	0000	1000	0000	%0315	I10	\$
005903	-05151	-003608	0375	1000	0125	0625	0000	0875	0000	%0316	I11	\$
006037	-05018	-002128	0375	1000	0250	0625	0000	0750	0000	%0317	I12	\$
006750	-04020	-000706	0375	1000	0375	0625	0000	0625	0000	%0318	I13	\$
006840	-03765	-00051	0375	1000	0500	0625	0000	0500	0000	%0319	I14	\$
006926	-03436	-00899	0375	1000	0625	0000	0000	0250	0000	%0320	I15	\$
007011	-03096	-01641	0375	1000	0750	0625	0000	0250	0000	%0321	I16	\$
007053	-02820	-02214	0375	1000	0875	0625	0000	0125	0000	%0322	I17	\$
007086	-02610	-02592	0375	1000	1000	0625	0000	0000	0000	%0323	I18	\$
002227	003843	-00931	0500	0000	0000	0500	1000	1000	0000	%0324	J10	\$
002319	004469	-02405	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$
002427	005114	-03628	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$
002131	004849	-04295	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$
001710	004311	-04741	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$
001570	004782	-05562	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$
001442	005088	-06181	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$
001577	005133	-06358	0500	0000	0875	0500	1000	0125	0000	%0331	J17	\$
001678	004617	-06332	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$
002280	003048	-001475	0500	0125	0000	0500	0875	1000	0000	%0333	K10	\$
003065	002944	-01155	0500	0125	0125	0500	0875	0875	0000	%0334	K11	\$
003189	003547	-02571	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$
003126	003827	-03638	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$
002714	003172	-04091	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$
002537	003515	-05185	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$
002374	003826	-05874	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$
002732	003420	-05969	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$
003110	002733	-05771	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$
003197	001551	-002654	0500	0250	0000	0500	0750	1000	0000	%0342	L10	\$
003404	001852	-0004										

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

003157	005893	-00178	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003202	006204	-01663	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
003253	006661	-02904	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
003313	007127	-03915	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
002976	006796	-04579	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
002498	006194	-05179	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
002092	005758	-05653	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
001885	005771	-06117	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$
001660	005598	-06310	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$
003090	005341	-02651	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$
003962	005073	-00549	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
004037	005516	-02038	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
004097	006949	-03341	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
004040	006259	-04198	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
003478	005499	-04818	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
003029	004880	-05303	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
002807	004898	-05857	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
002557	004667	-06082	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
003822	004455	-06375	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
003974	004572	-001439	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
004836	004020	-00700	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
004918	004480	-02134	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
004969	005066	-03477	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
004553	004492	-04153	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
004057	003747	-04653	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
003383	003700	-05302	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
003587	003460	-05541	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
004764	003071	-049413	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
004903	003159	-002449	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005024	003274	-006954	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005647	003908	-00799	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005708	003569	-02322	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
005568	003609	-03245	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
005017	002696	-03905	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
004756	002641	-04685	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
004516	002346	-04936	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
005665	001687	-06088	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
005828	001692	-063597	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
005925	001791	-002057	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006035	001963	-000828	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006466	001942	-00791	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
006533	002553	-02370	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
006025	001700	-03014	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
005765	001563	-03930	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
005855	001029	-03948	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
006526	000437	-007288	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
006631	000427	-004681	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
006761	000454	-003123	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
006856	000595	-001847	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
006967	000803	-000561	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
007217	001016	-00949	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
007614	000872	-02060	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
006864	000640	-02996	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
007198	000997	-02803	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
007215	-00570	-008237	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
007375	-00692	-005690	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
007513	-00758	-004141	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
007620	-00703	-002895	0750	0750	0375	0250	0250	0500	0000	%0543	G22	\$
007726	-00520	-001542	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007861	-00301	-000230	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
007973	000043	-000991	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$
008332	-00248	-01518	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$
008670	-00828	-01287	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$
008931	-01244	-009417	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$
008226	-01618	-006913	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$
008284	-01831	-005254	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$
008353	-01853	-003924	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$
008415	-01781	-002512	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$
008489	-01667	-001043	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$
008653	-01162	-00360	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$
008675	-00988	-00928	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$
008724	-00928	-01227	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$
007963	-01482	-009291	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$
008138	-01896	-006784	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$
008233	-02056	-005178	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$
008278	-02128	-003822	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$
008343	-02038	-002384	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$
008424	-01897	-009047	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$
008704	-01175	-00449	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$
008737	-00997	-01010	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$
008734	-00915	-01226	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$
003535	006519	-00257	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$
003583	006880	-01602	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$
003630	007301	-02767	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$
003672	007671	-03647	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$
003650	007809	-04035	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$
003238	007262	-04555	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$
002741	006631	-05179	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$
002272	006138	-05735	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$
002932	005333	-06415	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$
003463	006067	-02386	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$
004404	005814	-00460	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$
004467	006223	-01882	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$
004523	006694	-03118	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$
004537	007036	-03873	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$
004285	006735	-04305	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$
003744	005993	-04917	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$
003228	005390	-05463	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$
002968	005125	-05753	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$
004062	005361	-04160	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$
004314	005440	-001613	0875	0250	0125	0125	0750	0875	0000	%0586	L20	

009293	000001	-00595	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009241	-00068	-00662	0875	1000	1000	0125	0000	0000	0000	%0730	b02	\$
008827	-00900	-01166	0750	1000	1000	0250	0000	0000	0000	%0731	b03	\$
008239	-01663	-01784	0625	1000	1000	0375	0000	0000	0000	%0732	b04	\$
007668	-02204	-02264	0500	1000	1000	0500	0000	0000	0000	%0733	b05	\$
007153	-02597	-02565	0375	1000	1000	0625	0000	0000	0000	%0734	b06	\$
006598	-02922	-02853	0250	1000	1000	0750	0000	0000	0000	%0735	b07	\$
005921	-03143	-03140	0125	1000	1000	0875	0000	0000	0000	%0736	b08	\$
005192	-03174	-03345	0000	1000	1000	1000	0000	0000	0000	%0737	b09	\$
009252	000074	-00643	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
009199	-00946	-00575	0875	0875	0875	0125	0125	0125	0000	%0739	c02	\$
008765	-00945	-00925	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
008163	-01778	-01427	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
007609	-02392	-01802	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
007064	-02837	-02120	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
006516	-03209	-02368	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005853	-03477	-02648	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
005121	-03587	-02793	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008550	001141	-01004	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
008483	000963	-00801	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
008085	000021	-01001	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
007552	-00975	-01348	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
007051	-01767	-01624	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
006584	-02396	-01821	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
006096	-02928	-02014	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005502	-03396	-02202	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
004830	-03674	-02285	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007787	002158	-01153	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007730	001968	-00868	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
007367	000961	-00952	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006858	-00151	-01152	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
006389	-01077	-01362	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
005976	-01850	-01480	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
005554	-02530	-01617	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
005014	-03146	-01788	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004430	-03523	-01903	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007004	003111	-01139	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006965	002885	-00778	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006613	001880	-00804	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$
006115	000696	-00981	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005668	-00308	-01141	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005297	-01142	-01282	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
004901	-01918	-01419	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004419	-02650	-01540	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
003909	-03145	-01616	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006172	004077	-01042	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
006134	003875	-00707	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005792	002922	-00789	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005287	001734	-00976	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004834	000705	-01111	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
004484	-00206	-01201	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004101	-01049	-01350	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
003640	-01840	-01429	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003199	-02380	-01525	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
005377	005025	-00969	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005333	004842	-00640	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
004969	003951	-00675	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
004442	002700	-00893	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
003978	001742	-01035	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
003616	000818	-01213	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
003246	-00966	-01377	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
002853	-00939	-01404	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
002434	-01558	-01450	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
004500	005991	-00855	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004452	005827	-00477	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
004091	005043	-00570	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
003554	003956	-00888	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
003094	002966	-01115	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
002696	001995	-01245	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
002320	001082	-01384	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
001936	000201	-01439	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
001593	-00550	-01354	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
003614	-006703	-00595	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
003587	006551	-00275	0875	0000	0000	0125	1000	1000	0000	%0802	j02	\$
003237	005846	-00253	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
002722	004828	-00566	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
002256	003879	-00882	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
001840	002934	-01035	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
001451	001958	-00986	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
001097	000973	-00880	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
000827	000128	-00745	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009243	000036	-00622	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
009193	-00029	-00682	0875	0875	0875	0125	0125	0125	0000	%0811	b11	\$
008764	-00791	-01210	0750	0750	0750	0250	0250	0250	0000	%0812	b12	\$
007915	-00990	-02117	0625	0625	1000	0375	0375	0000	0000	%0813	b13	\$
007613	-01051	-02857	0500	0500	0500	0500	0500	0000	0000	%0814	b14	\$
006391	-00989	-03445	0375	0375	1000	0625	0625	0000	0000	%0815	b15	\$
005669	-00910	-03954	0250	0250	1000	0750	0750	0000	0000	%0816	b16	\$
004945	-00910	-04015	0125	0250	1000	0875	0875	0000	0000	%0817	b17	\$
004072	-00357	-02792	0000	0000	1000	1000	1000	0000	0000	%0818	b18	\$
009229	-00001	-00507	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$
009151	-00013	-00600	0875	0875	0875	0125	0125	0125	0000	%0820	c11	\$
008470	-00296	-01419	0750	0750	0750	0250	0250	0125	0000	%0821	c12	\$
007612	-00494	-02317	0625	0625	0875	0375	0375	0125	0000	%0822	c13	\$
006804	-00557	-03058	0500	0500	0875	0500	0500	0125	0000	%0823	c14	\$
006095	-00532	-03630	0375	0375	0875	0625	0625	0125	0000	%0824	c15	\$
005390	-00456	-04138	0250	0250	0875	0750	0750	0125	0000	%0825	c16	\$
004599	-00249	-04617	0125	0125	0875	0875	0875	0125	0000	%0826	c17	\$
003781	000194	-04970	0000	0000	0750	1000	1000	0125	0000	%0827	c18	\$
009170	-00255	-00382	1000	1000	0750	0000	0250	0000	0000	%0828	d10	\$
009072	-00231	-00256	0750									

%BEG HE27_22.TXT, Separation olv*, D65, not adapted \$
%100 x LAB*
%#1000 x (r g b c m y 0) %nr. pos \$
%z003577 006648 -00503 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008430 -00459 010058 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z004600 -06044 002002 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005168 -03146 -03358 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z004037 -00302 -04824 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z002459 006363 -05542 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z000813 000100 -00693 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009207 000028 -00625 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z003614 006703 -00595 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008434 -00450 009955 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z004576 -06027 001974 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005192 -03174 -03345 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z004072 -00367 -04792 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z002476 006345 -05525 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z000816 000123 -00699 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009259 000020 -00612 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/HE37/HE37L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG HE27 22.TXT, Separation olv*, D65, not adapted \$																			
%100 x LAB*																			
1000 x (r g b c m y θ)																			

TUB-test chart HE37; Relative Elementary Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

TUB registration: 20091101-HE37/HE37L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/HE37/HE37L0NA.TXT> / .PS
 Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/HE37/HE37L0NA.TXT> /PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

001752	002762	-00342	0375	0000	0000	00625	1000	1000	0000	%0243	A10	\$	002227	003754	-00249	0500	0000	0000	00500	1000	1000	0000	%0324	J10	\$	002693	004708	000083	0625	0000	0000	0375	1000	1000	0000	0000	%0405	S10	\$	
001859	003545	-01947	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$	002319	004381	-01724	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$	002765	005377	-01393	0625	0000	0125	0375	1000	0875	0000	0000	%0406	S11	\$	
001819	003860	-02908	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$	002427	005027	-02948	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$	002856	005774	-02629	0625	0000	0250	0375	1000	0750	0000	0000	%0407	S12	\$	
001400	003320	-03365	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$	002131	004760	-03613	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$	002828	006141	-03592	0625	0000	0375	0375	1000	0625	0000	0000	%0408	S13	\$	
001304	003813	-04272	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$	001710	004218	-04055	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$	002367	005556	-04163	0625	0000	0500	0375	1000	0500	0000	0000	%0409	S14	\$	
001219	004355	-04970	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$	001570	004687	-04965	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$	001965	005031	-04598	0625	0000	0625	0375	1000	0375	0000	0000	%0410	S15	\$	
001505	004453	-05402	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$	001442	004993	-05493	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$	001766	005293	-05347	0625	0000	0750	0375	1000	0250	0000	0000	%0411	S16	\$	
001890	004064	-05543	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$	001357	005036	-05669	0500	0000	0875	0500	1000	0125	0000	%0331	J17	\$	001588	005343	-05673	0625	0000	0875	0375	1000	0125	0000	0000	%0412	S17	\$	
002288	003315	-05392	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$	001682	004524	-05646	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$	001416	005184	-05704	0625	0000	1000	0375	1000	0000	0000	0000	%0413	S18	\$	
001990	001763	-001691	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$	002280	002960	-002157	0500	0125	0000	0500	0875	1000	0000	%0333	K10	\$	002641	004115	-002846	0625	0125	0000	0375	0875	1000	0000	0000	%0414	T10	\$	
002596	001951	-00631	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$	003065	002862	-004080	0500	0125	0125	0500	0875	0875	0000	%0334	K11	\$	003524	003868	-00232	0625	0125	0125	0375	0875	0875	0000	0000	%0415	T11	\$	
002722	002637	-02068	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$	003189	003467	-01897	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$	003639	004384	-01663	0625	0125	0250	0375	0875	0750	0000	0000	%0416	T12	\$	
002372	002132	-02659	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$	003126	003746	-02964	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$	003735	005012	-02963	0625	0125	0375	0375	0875	0625	0000	0000	%0417	T13	\$	
002227	002525	-03755	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$	002714	003888	-03413	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$	003369	004600	-03650	0625	0125	0500	0375	0875	0500	0000	0000	%0418	T14	\$	
002448	002763	-04489	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$	002537	003429	-04506	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$	002958	003988	-04107	0625	0125	0625	0375	0875	0375	0000	0000	%0419	T15	\$	
002931	002528	-04822	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$	002374	003739	-05193	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$	002803	004194	-04933	0625	0125	0750	0375	0875	0250	0000	0000	%0420	T16	\$	
003308	002165	-04917	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$	002732	003336	-05291	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$	002558	004183	-05397	0625	0125	1000	0375	0875	0125	0000	0000	%0421	T17	\$	
003664	001502	-04707	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$	003110	002651	-05097	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$	002427	003964	-05479	0625	0125	0800	0375	0875	0000	0000	0000	%0422	T18	\$	
002933	000200	-002854	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$	003197	001471	-003328	0500	0250	0000	0000	0750	1000	0000	%0342	L10	\$	003510	002855	-003884	0625	0250	0000	0375	0750	1000	0000	0000	0000	%0423	U10	\$
003173	000566	-000784	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$	003404	001773	-001334	0500	0250	0125	0500	0750	0875	0000	%0343	L11	\$	003679	003083	-001589	0625	0250	0125	0375	0750	0875	0000	0000	0000	%0424	U11	\$
003533	000765	-00597	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$	003487	001767	-000568	0500	0250	0250	0500	0750	0750	0000	%0344	L12	\$	004533	003661	-00225	0625	0250	0250	0375	0750	0750	0000	0000	0000	%0425	U12	\$
003446	000850	-01623	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$	003408	002368	-000960	0500	0250	0775	0500	0750	0000	0000	%0345	L13	\$	004533	003661	-00225	0625	0250	0375	0750	0750	0000	0000	0000	0000	%0426	U13	\$
003431	001018	-02762	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$	003678	001769	-02476	0500	0250	0500	0500	0750	0500	0000	%0346	L14	\$	004431	003473	-02838	0625	0250	0500	0375	0750	0500	0000	0000	0000	%0427	U14	\$
003881	001044	-03400	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$	003588	002079	-03687	0500	0250	0625	0500	0750	0375	0000	%0347	L15	\$	003976	002715	-03318	0625	0250	0625	0375	0750	0375	0000	0000	0000	%0428	U15	\$
004362	000903	-03837	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$	003759	002111	-04328	0500	0250	0750	0500	0750	0250	0000	%0348	L16	\$	003823	002914	-04276	0625	0250	0750	0375	0750	0250	0000	0000	0000	%0429	U16	\$
004740	000604	-03994	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$	004131	001764	-04455	0500	0250	0875	0500	0750	0125	0000	%0349	L17	\$	003603	002865	-04827	0625	0250	0875	0375	0750	0125	0000	0000	0000	%0430	U17	\$
005093	-00001	-03765	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$	004505	001138	-04236	0500	0250	1000	0500	0750	0000	0000	%0350	L18	\$	003892	002295	-04676	0625	0250	1000	0375	0750	0000	0000	0000	0000	%0431	U18	\$
003850	-01279	-004037	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$	004059	000004	-004466	0500	0375	0000	0000	0625	1000	0000	%0351	M10	\$	004448	001361	-												

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

003157	005722	000496	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003202	006124	-00989	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
003253	006581	-02231	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
003313	007048	-03242	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
002976	006714	-03904	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
002948	006108	-04500	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
002092	005668	-04970	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
001885	005679	-05432	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$
001660	005505	-05624	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$
003090	005260	-063326	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$
003962	004999	-060118	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
004037	005443	-01371	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
004097	005977	-02674	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
004048	006186	-03539	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
003478	005412	-04147	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
003029	004798	-04628	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
002807	004814	-05180	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
002557	004581	-05402	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
003822	004380	-064404	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
003974	004498	-062106	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
004836	003954	-06040	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
004918	004414	-01474	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
004969	005001	-02818	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
004553	004424	-03490	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
004057	003674	-03986	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
003583	003625	-04633	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
003837	003383	-04871	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
004764	003004	-005574	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
004903	003093	-003109	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005024	003209	-001613	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005647	002941	-00145	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005708	003518	-01680	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
005569	003549	-02690	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
005017	002632	-03246	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
004756	002575	-04023	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
004516	002277	-04273	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
005665	001627	-006742	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
005828	001634	-004250	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
005925	001734	-002709	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006035	001907	-001479	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006466	001890	-001444	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
006533	002501	-01723	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
006025	001644	-02363	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
005765	001505	-03277	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
005855	000972	-03296	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
006526	000385	-007934	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
006631	000377	-005327	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
006761	000405	-003768	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
006856	000546	-002491	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
006967	000755	-001205	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
007217	000970	-00308	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
007614	000825	-01417	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
006864	000591	-02352	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
007198	000951	-02161	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
007215	-00616	008878	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
007375	-00736	006330	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
007513	-00801	004780	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
007629	-00746	003533	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$
007726	-00561	002179	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007861	-00341	000866	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
007973	000804	-00355	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$
008332	-00284	-00885	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$
008670	-00861	-00658	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$
008931	-01283	-010052	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$
008226	-01655	-007546	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$
008284	-01867	-005887	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$
008353	-01889	-004557	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$
008415	-01816	-003143	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$
008489	-01702	-001674	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$
008653	-01196	-000269	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$
008675	-01021	-00299	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$
008724	-00960	-00598	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$
007963	-01521	-009926	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$
008138	-01933	-007418	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$
008233	-02093	-005811	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$
008278	-02165	-004454	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$
008343	-02074	-003017	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$
008424	-01932	-001578	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$
008704	-01208	-00179	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$
008737	-01030	-00381	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$
008734	-00948	-00597	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$
003535	006441	-000413	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$
003583	006803	-00931	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$
003630	007224	-02097	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$
003672	007594	-02977	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$
003650	007732	-03364	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$
003238	007182	-03881	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$
002741	006547	-04502	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$
002272	005877	-05053	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$
002932	005843	-05331	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$
003463	005989	-060308	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$
004404	005744	-060203	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$
004467	006154	-01218	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$
004523	006625	-02455	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$
004537	006967	-03210	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$
004285	006664	-03640	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$
003744	005917	-04248	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$
003228	005310	-04789	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$
002968	005043	-05077	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$
004065	005288	-04827	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$
004314	005369	-002278	0875	0250	0125	0125	0750	0875	0000	%0586		

See original or copy: <http://web.me.com/klauz.richter/HE37/HE37L0NA.TXT> /PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

009293	-00018	000016	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$	009243	000002	-00007	1000	1000	1000	0000	0000	0000	0000	0000	0000	%0891	b10	\$	
009241	-00089	-00048	0875	1000	1000	0125	0000	0000	0000	%0730	b02	\$	009197	000084	-00059	1000	0875	1000	0000	0125	0000	0000	0000	0000	0000	%0892	b10	\$
008827	-00926	-00549	0750	1000	1000	0250	0000	0000	0000	%0731	b03	\$	008477	001185	-00841	1000	0750	1000	0000	0250	0000	0000	0000	0000	0000	%0893	b21	\$
008239	-01696	-01160	0625	1000	1000	0375	0000	0000	0000	%0732	b04	\$	007564	002067	-01760	1000	0625	1000	0000	0375	0000	0000	0000	0000	0000	%0894	b21	\$
007668	-02244	-01635	0500	1000	1000	0500	0000	0000	0000	%0733	b05	\$	006167	002895	-02585	1000	0500	1000	0000	0500	0000	0000	0000	0000	0000	%0895	b23	\$
007153	-02643	-01930	0375	1000	1000	0625	0000	0000	0000	%0734	b06	\$	005544	003738	-03392	1000	0375	1000	0000	0625	0000	0000	0000	0000	0000	%0896	b24	\$
006598	-02975	-02213	0250	1000	1000	0750	0000	0000	0000	%0735	b07	\$	004522	004629	-04057	1000	0250	1000	0000	0750	0000	0000	0000	0000	0000	%0897	b25	\$
005921	-03204	-02493	0125	1000	1000	0875	0000	0000	0000	%0736	b08	\$	003441	005573	-04621	1000	0125	1000	0000	0875	0000	0000	0000	0000	0000	%0898	b26	\$
005192	-03244	-02691	0000	1000	1000	0900	0000	0000	0000	%0737	b09	\$	002476	006242	-04843	1000	0000	1000	0000	1000	0000	0000	0000	0000	0000	%0899	b27	\$
009252	000053	-00030	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$	009200	-00097	-00027	8875	1000	0875	0125	0000	0125	0000	0125	0000	0000	%0900	c19	\$
009199	-00067	000038	0875	0875	0875	0125	0125	0125	0000	%0739	c02	\$	009147	-00057	000032	8875	0875	0875	0125	0125	0125	0125	0125	0000	0000	%0901	c20	\$
008765	-00972	-00308	0750	0875	0875	00250	0125	0125	0000	%0740	c03	\$	008312	000741	-00919	8875	0750	0875	0125	0250	0125	0125	0125	0000	0000	%0902	c21	\$
008163	-01812	-00803	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$	007364	001597	-01865	8875	0625	0875	0125	0375	0125	0125	0125	0000	0000	%0903	c22	\$
007609	-02433	-01172	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$	006374	002378	-02736	8875	0500	0875	0125	0500	0125	0125	0125	0000	0000	%0904	c23	\$
007064	-02884	-01485	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$	005320	003304	-03533	8875	0375	0875	0125	0625	0125	0125	0125	0000	0000	%0905	c24	\$
006516	-03263	-01727	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$	004313	004253	-04212	8875	0250	0875	0125	0750	0125	0125	0125	0000	0000	%0906	c25	\$
005853	-03539	-02000	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$	003249	005292	-04772	8875	0125	0875	0125	0875	0125	0875	0125	0000	0000	%0907	c26	\$
005121	-03658	-02138	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$	002283	006023	-05036	8875	0000	0875	0125	1000	0125	0000	0125	0000	0000	%0908	c27	\$
008550	-00112	-00384	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$	008742	-01158	000241	0750	1000	0750	0250	0000	0250	0000	0000	0000	0000	%0909	d10	\$
008483	000933	-00180	0875	0750	0750	00125	0250	0250	0000	%0748	d02	\$	008689	-01141	000238	0750	0875	0750	0250	0125	0250	0000	0125	0000	0000	%0910	d19	\$
008085	-00013	-00376	0750	0750	0750	00250	0250	0250	0000	%0749	d03	\$	008061	-00030	-00313	0750	0625	0750	0250	0250	0250	0000	0000	0000	0000	%0911	d21	\$
007552	-01016	-00718	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$	007120	000760	-01341	0750	0750	0750	0250	0375	0250	0000	0000	0000	0000	%0912	d22	\$
007051	-01814	-00989	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$	006135	001590	-02268	0750	0500	0750	0250	0500	0250	0000	0000	0000	0000	%0913	d23	\$
006584	-02449	-01181	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$	005773	003308	-03533	0750	0500	0750	0250	0500	0250	0000	0000	0000	0000	%0914	d24	\$
006096	-02987	-01368	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$	004115	003048	-03952	0750	0250	0750	0250	0750	0250	0000	0000	0000	0000	%0915	d25	\$
005502	-03462	-01550	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$	003069	004779	-04609	0750	0125	0750	0250	0875	0250	0000	0000	0000	0000	%0916	d26	\$
004830	-03749	-01627	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$	002107	005634	-04943	0750	0000	0750	0250	1000	0250	0000	0000	0000	0000	%0917	d27	\$
007787	002120	-00525	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$	008098	-02308	000469	0625	1000	0625	0375	0000	0375	0000	0000	0000	0000	%0918	e10	\$
007730	-001929	-00239	0875	0625	0625	00125	0375	0375	0000	%0757	e02	\$	008044	-02312	000596	0625	0875	0625	0375	0125	0375	0000	0000	0000	0000	%0919	e20	\$
007367	-000918	-00320	0750	0625	0625	00250	0375	0375	0000	%0758	e03	\$	007467	-01319	000082	0625	0750	0625	0375	0250	0375	0000	0000	0000	0000	%0920	e21	\$
006858	-00201	-00515	0625	0625	0625	00375	0375	0375	0000	%0759	e04	\$	006792	-00204	-00473	0625	0625	0625	0375	0125	0375	0000	0000	0000	0000	%0921	e22	\$
006389	-01133	-00720	0500	0625	0625	00500	0375	0375	0000	%0760	e05	\$	005840	000621	-01483	0625	0500	0625	0375	0500	0375	0000	0000	0000	0000	%0922	e23	\$
005976	-01910	-00834	0375	0625	0625	00625	0375	0375	0000	%0761	e06	\$	004864	001709	-02481	0625	0375	0625	0375	0625	0375	0000	0000	0000	0000	%0923	e24	\$
005554	-02596	-00966	0250	0625	0625	00750	0375	0375	0000	%0762	e07	\$	003869	002818	-03367	0625	0250	0625	0375	0750	0375	0000	0000	0000	0000	%0924	e25	\$
005014	-03218	-01132	0125	0625	0625	00875	0375	0375	0000	%0763	e08	\$	002844	000406	-04124	0625	0125	0625	0375	0875	0375	0000	0000	0000	0000	%0925	e26	\$
004430	-03602	-01241	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$	001882	005005	-04591	0625	0000	0625	0375	1000	0375	0000	0000	0000	0000	%0926	e27	\$
007004	-00363	-00504	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$	007410	-03311	000943	0500	1000	0500	0500	0000	0500	0000	0000	0000	0000	%0927	f19	\$
006965	-002837	-00142	0875	0500	0500	00125	0500	0500	0000	%0766	f02	\$	007368	-03333	001145	0500	0875	0500	0500	0125	0500	0000	0000	0000	0000	%0928	f20	\$
006613	-001827	-00164	0750	0500	0500	00250	0500	0500	0000	%0767	f03	\$	006859	-02530	000710	0500	0											

```
%BEG HE27_22.TXT, Separation olv*, D65, adapted $
%100 x LAB*a          %#1000 x (r g b c m y 0)          %nr.   pos $
%z003577 006571 000167 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 $
%z008430 -00494 010689 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 $
%z004600 -06112 002664 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 $
%z005168 -03209 -02700 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 $
%z004037 -00376 -04157 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 $
%z002459 006276 -04862 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 $
%z000813 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 $
%z009207 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 $
%S
%z003614 006614 000074 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 $
%z008434 -00481 010576 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 $
%z004576 -06105 002634 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 $
%z005192 -03244 -02691 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 $
%z004072 -00450 -04126 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 $
%z002476 006242 -04843 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 $
%z000816 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 $
%z009259 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 $
%S
```


[illegible]

TUB-test chart HE37; Relative Elementary Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

TUB registration: 20091101-HE37/HE37L0NA.TXT /.PS
+ application for evaluation and measurement of printer or

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/HE37/HE37L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfi=1.00; nt=

See original or copy: <http://web.me.com/klaus.richter/HE37/HE37L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1, Cx=0, cfi=1.00, nt=0

TUB registration: 20091101-HEE37/HEE37.LONA.TXT /.PS TUB material: code=rh44a
T application for evaluation and measurement of printer or monitor systems

XDEE HEGT 22.TXT, Separation plv*						D50, not adapted \$
\$	X LAB*	100 X	Y (g)	%nr.	pos \$	
000890	000804	-066808	0000 0000 1000 1000 1000 0000	000000	A01 \$	
001110	000272	-821225	0000 0125 1000 1000 0875	000001	A02 \$	
001533	000192	-829116	0000 0250 1000 1000 0750	000002	A03 \$	
001993	-09055	-034443	0000 0375 1000 1000 0625	000003	A04 \$	
002436	-08112	-040511	0000 0500 1000 1000 0500	000004	A05 \$	
002864	-09229	-046467	0000 0625 1000 1000 0375	000005	A06 \$	
003243	-08349	-05075	0000 0750 1000 1000 0250	000006	A07 \$	
003640	-08011	-05164	0000 0875 1000 1000 0125	000007	A08 \$	
003907	-01326	-05006	0000 1000 1000 1000 0000	000008	A09 \$	
001424	-01193	-060158	0000 0125 0000 1000 0875	000009	B01 \$	
001480	-00763	-01364	0000 0125 0125 1000 0875	000010	B02 \$	
002160	-01174	-02285	0000 0125 0250 1000 0875	000011	B03 \$	
002569	-01306	-02865	0000 0125 0375 1000 0875	000012	B04 \$	
002984	-01358	-035358	0000 0125 0500 1000 0875	000013	B05 \$	
003398	-01371	-04174	0000 0125 0625 1000 0875	000014	B06 \$	
003765	-01466	-04628	0000 0125 0750 1000 0875	000015	B07 \$	
004096	-01778	-04782	0000 0125 0875 1000 0875	000016	B08 \$	
004316	-02184	-04658	0000 0125 1000 1000 0875	000017	B09 \$	
002180	-02553	000528	0000 0250 0000 1000 0750	000018	C01 \$	
002245	-02187	-00737	0000 0250 0125 1000 0750	000019	C02 \$	
002306	-01837	-01537	0000 0250 0250 1000 0750	000020	C03 \$	
003080	-02367	-02346	0000 0250 0375 1000 0750	000021	C04 \$	
003523	-02500	-0298	0000 0250 0500 1000 0750	000022	C05 \$	
003907	-02500	-0298	0000 0250 0500 1000 0750	000023	C06 \$	
004217	-02421	-04220	0000 0250 0750 1000 0750	000024	C07 \$	
004458	-02539	-04469	0000 0250 0875 1000 0750	000025	C08 \$	
004645	-02863	-04372	0000 0250 1000 1000 0750	000026	C09 \$	
002842	03667	001905	0000 0375 0000 1000 0625	000027	D01 \$	
002920	03370	-00118	0000 0375 0125 1000 0625	000028	D02 \$	
002980	-03089	-00879	0000 0375 0250 1000 0625	000029	D03 \$	
003036	-02753	-01641	0000 0375 0375 1000 0625	000030	D04 \$	
003778	-03195	-02472	0000 0375 0500 1000 0625	000031	D05 \$	
004298	-03257	-03313	0000 0375 0625 1000 0625	000032	D06 \$	
004539	-03093	-03916	0000 0375 0750 1000 0625	000033	D07 \$	
004755	-03155	-04203	0000 0375 0875 1000 0625	000034	D08 \$	
004885	-03374	-04152	0000 0375 1000 1000 0625	000035	D09 \$	
003479	-04660	-001567	0000 0500 0000 1000 0500	000036	E01 \$	
003553	-04426	000497	0000 0500 0125 1000 0500	000037	E02 \$	
003606	-04188	-00334	0000 0500 0250 1000 0500	000038	E03 \$	
003657	-03927	-01009	0000 0500 0375 1000 0500	000039	E04 \$	
003725	-03588	-01775	0000 0500 0500 1000 0500	000040	E05 \$	
004323	-03724	-02714	0000 0500 0625 1000 0500	000041	E06 \$	
004784	-03620	-03661	0000 0500 0750 1000 0500	000042	E07 \$	
004969	-03601	-04006	0000 0500 0875 1000 0500	000043	E08 \$	
005055	-03725	-03995	0000 0500 1000 1000 0500	000044	E09 \$	
003948	-05357	-001873	0000 0625 0000 1000 0375	000045	F01 \$	
004046	-05186	-005883	0000 0625 0125 1000 0375	000046	F02 \$	
004089	-05186	-005883	0000 0625 0250 1000 0375	000047	F03 \$	
00						

001448	001895	-00816	0250	0000	0000	0750	1000	1000	0000	001602	S01
001544	002557	-02632	0250	0000	0125	0750	1000	0875	0000	001603	S02
001211	002097	-03238	0250	0000	0250	0750	1000	0750	0000	001604	S03
001078	002271	-04217	0250	0000	0375	0750	1000	0625	0000	001605	S04
001265	002549	-04955	0250	0000	0500	0750	1000	0500	0000	001606	S05
001699	002392	-05550	0250	0000	0625	0750	1000	0375	0000	001607	S06
002119	002092	-05891	0250	0000	0750	0750	1000	0250	0000	001608	S07
002540	001546	-05963	0250	0000	0875	0750	1000	0125	0000	001609	S08
002875	000879	-05786	0250	0000	1000	0750	1000	0000	0000	001700	S09
001893	000804	000858	0250	0125	0000	0750	0875	1000	0000	001701	T01
002252	000938	-01239	0250	0125	0125	0750	0875	0875	0000	001702	T02
002133	000859	-02446	0250	0125	0250	0750	0875	0750	0000	001703	T03
002156	000872	-03469	0250	0125	0375	0750	0875	0625	0000	001704	T04
002612	000713	-04089	0250	0125	0500	0750	0875	0500	0000	001705	T05
003120	000543	-04695	0250	0125	0625	0750	0875	0375	0000	001706	T06
003515	000377	-05121	0250	0125	0750	0875	0875	0250	0000	001707	T07
003928	-000806	-05207	0250	0125	0875	0750	0875	0125	0000	001708	T08
004262	-006078	-05807	0250	0125	1000	0750	0875	0000	0000	001709	T09
002862	-007305	001095	0250	0250	0000	0750	0750	1000	0000	001800	U01
002973	-005051	-008056	0250	0250	0125	0750	0750	0875	0000	001801	U02
003156	-001218	-00912	0250	0250	0250	0750	0750	0750	0000	001802	U03
003350	-000203	-01030	0250	0375	0000	0750	0750	0000	0000	001803	U04
004040	-006229	-02778	0250	0250	0500	0750	0750	0500	0000	001804	U05
004525	-008082	-03409	0250	0250	0625	0750	0750	0375	0000	001805	U06
004932	-00935	-04051	0250	0250	0750	0750	0750	0250	0000	001806	U07
005286	-01241	-04274	0250	0250	0875	0750	0750	0125	0000	001807	U08
005545	-01672	-04130	0250	0250	1000	0750	0750	0000	0000	001808	U09
003600	-02181	003628	0250	0375	0000	0750	0625	1000	0000	001809	V01
003764	-02072	000835	0250	0375	0125	0750	0625	0875	0000	001810	V02
003901	-01518	-00627	0250	0375	0250	0750	0625	0750	0000	001810	V03
003952	-01293	-01349	0250	0375	0375	0750	0625	0625	0000	001902	V04
004633	-01756	-02134	0250	0375	0500	0750	0625	0500	0000	001903	V05
005075	-01824	-02953	0250	0375	0625	0750	0625	0375	0000	001904	V06
005433	-01885	-03593	0250	0375	0750	0750	0625	0250	0000	001905	V07
005698	-02017	-03928	0250	0375	0875	0750	0625	0125	0000	001906	V08</

TUB-test chart HE37; Relative Elementary Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrabcOLOR
```

001803	002800	-00872	0375	0000	0000	0025	1000	1000	0000	%0243	A10	\$
001895	003358	-00279	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$
001832	003495	-03468	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$
001372	002794	-04005	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$
001243	003075	-04960	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$
001138	003471	-05700	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$
001402	003485	-06155	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$
001778	003046	-06316	0375	0000	0875	0625	1000	0100	0000	%0250	A17	\$
002172	002289	-06179	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$
002043	001993	001125	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$
002617	001943	-01218	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$
002726	002416	-02663	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$
002343	001747	-03304	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$
002166	001882	-04455	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$
002365	001952	-05221	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$
002835	001627	-05578	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$
003204	001221	-05689	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$
003556	000568	-05492	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$
002961	000494	-06221	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$
003185	000697	-000157	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$
003526	000713	-01240	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$
003418	000619	-02292	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$
003376	000548	-03467	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$
003810	000433	-04128	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$
004277	000183	-04587	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$
004645	-00170	-04762	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$
004994	-00763	-04548	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$
003861	-00953	003337	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$
004058	-00779	001156	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$
004248	-00636	-01172	0375	0375	0250	0625	0625	0750	0000	%0272	D12	\$
004350	-00351	-01287	0375	0375	0375	0625	0625	0625	0000	%0273	D13	\$
004824	-00658	-02029	0375	0375	0500	0625	0625	0500	0000	%0274	D14	\$
005225	-00771	-02841	0375	0375	0625	0625	0625	0375	0000	%0275	D15	\$
005615	-00905	-03478	0375	0375	0750	0625	0625	0250	0000	%0276	D16	\$
005935	-01160	-03794	0375	0375	0875	0625	0625	0125	0000	%0277	D17	\$
006205	-01624	-03632	0375	0375	1000	0625	0625	0000	0000	%0278	D18	\$
004763	-02294	-004521	0375	0500	0000	0625	0500	1000	0000	%0279	D10	\$
004888	-02223	-002206	0375	0500	0125	0625	0500	0875	0000	%0280	E11	\$
004982	-02096	-000714	0375	0500	0250	0625	0500	0750	0000	%0281	E12	\$
005103	-01614	-00627	0375	0500	0375	0625	0500	0625	0000	%0282	E13	\$
005154	-01393	-01387	0375	0500	0500	0625	0500	0500	0000	%0283	E14	\$
005745	-01742	-02299	0375	0500	0625	0625	0500	0375	0000	%0284	E15	\$
006068	-01758	-03049	0375	0500	0750	0625	0500	0250	0000	%0285	E16	\$
006386	-02024	-03394	0375	0500	0875	0625	0500	0125	0000	%0286	E17	\$
006618	-02425	-03262	0375	0500	1000	0625	0500	0000	0000	%0287	E18	\$
005240	-03346	-005117	0375	0625	0000	0625	0375	1000	0000	%0288	F10	\$
005381	-03339	-002858	0375	0625	0125	0625	0375	0875	0000	%0289	F11	\$
005499	-03233	-001388	0375	0625	0250	0625	0375	0750	0000	%0290	F12	\$
005723	-02644	-00033	0375	0625	0375	0625	0375	0625	0000	%0291	F13	\$
005782	-02422	-00871	0375	0625	0500	0625	0375	0500	0000	%0292	F14	\$
005832	-02175	-01635	0375	0625	0625	0625	0375	0375	0000	%0293	F15	\$
006483	-02548	-02637	0375	0625	0750	0625	0375	0250	0000	%0294	F16	\$
006778	-02769	-03025	0375	0625	0875	0625	0375	0125	0000	%0295	F17	\$
006958	-03089	-02937	0375	0625	1000	0625	0375	0000	0000	%0296	F18	\$
005571	-04105	-005551	0375	0750	0000	0625	0250	1000	0000	%0297	G10	\$
005743	-04229	-003306	0375	0750	0125	0625	0250	0875	0000	%0298	G11	\$
005855	-04186	-001834	0375	0750	0250	0625	0250	0750	0000	%0299	G12	\$
006250	-04300	-000400	0375	0750	0375	0625	0250	0500	0000	%0300	G13	\$
006298	-03313	-03089	0375	0750	0500	0625	0250	0500	0000	%0301	G14	\$
006361	-03078	-01204	0375	0750	0625	0250	0250	0375	0000	%0302	G15	\$
006440	-02805	-01974	0375	0750	0750	0625	0250	0250	0000	%0303	G16	\$
006953	-03182	-02713	0375	0750	0875	0625	0250	0125	0000	%0304	G17	\$
006981	-03126	-02915	0375	0750	1000	0625	0250	0000	0000	%0305	G18	\$
005718	-04662	-005747	0375	0875	0000	0625	0125	1000	0000	%0306	H10	\$
005972	-04841	-003618	0375	0875	0125	0625	0125	0875	0000	%0307	H11	\$
006064	-04869	-002117	0375	0875	0250	0625	0125	0750	0000	%0308	H12	\$
006644	-04151	-000708	0375	0875	0375	0625	0125	0625	0000	%0309	H13	\$
006714	-03998	-00055	0375	0875	0500	0625	0125	0500	0000	%0310	H14	\$
006779	-03794	-00917	0375	0875	0625	0625	0125	0375	0000	%0311	H15	\$
006867	-03567	-01635	0375	0875	0750	0625	0125	0250	0000	%0312	H16	\$
006918	-03349	-02304	0375	0875	0875	0625	0125	0125	0000	%0313	H17	\$
006987	-03119	-02913	0375	0875	1000	0625	0125	0000	0000	%0314	H18	\$
005609	-04832	-005578	0375	1000	0000	0625	0000	1000	0000	%0315	I10	\$
005853	-05011	-003443	0375	1000	0125	0625	0000	0875	0000	%0316	I11	\$
005973	-05006	-001965	0375	1000	0250	0625	0000	0750	0000	%0317	I12	\$
006683	-04131	-000560	0375	1000	0375	0625	0000	0625	0000	%0318	I13	\$
006765	-03968	-00203	0375	1000	0500	0625	0000	0500	0000	%0319	I14	\$
006843	-03753	-01058	0375	1000	0625	0000	0000	0375	0000	%0320	I15	\$
006919	-03518	-01808	0375	1000	0750	0625	0000	0250	0000	%0321	I16	\$
006955	-03329	-02388	0375	1000	0875	0625	0000	0125	0000	%0322	I17	\$
006983	-03175	-02769	0375	1000	1000	0625	0000	0000	0000	%0323	I18	\$
002308	003818	-00715	0500	0000	0000	0500	1000	1000	0000	%0324	J10	\$
002387	004262	-02191	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$
002481	004720	-03421	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$
002151	004303	-04146	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$
001686	003603	-04671	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$
001589	003861	-05636	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$
001353	004042	-06218	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$
001253	004060	-06408	0500	0000	0875	0500	1000	0125	0000	%0331	J17	\$
001573	004070	-06407	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$
002370	003218	-001662	0500	0125	0000	0500	0875	1000	0000	%0333	K10	\$
003113	002904	-01012	0500	0125	0125	0500	0875	0875	0000	%0334	K11	\$
003223	003320	-02434	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$
003137	003418	-03527	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$
002689	002609	-04045	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$
002476	002688	-05191	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$
002287	002822	-05921	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$
002634	002373	-06039	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$
003008	001695	-05858	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$
003258	001806	-062751	0500	0250	0000	0500	0750	1000	0000	%0342	L10	\$
003449	001972	-000571	0500	0250	0125	0500	0750	0875	0000	%0343	L11	\$
003985	001665	-009967										

See original or copy: <http://web.me.com/klaus.richter/HE37/HE37L0NA.TXT> /PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

003309	005877	000171	0750	0000	0000	0250	0000	1000	1000	0000	0000	%0486	A19	\$
003341	006137	-01315	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$		
003380	006443	-02560	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$		
003429	006767	-03574	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$		
003504	006298	-04293	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$		
003534	005534	-04978	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$		
003603	004943	-05531	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$		
003650	004825	-06045	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$		
003695	004572	-06238	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$		
003756	005572	-02982	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$		
004079	005152	-02774	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$		
004140	005440	-01770	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$		
004187	005804	-03077	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$		
004113	005875	-03951	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$		
003505	004936	-04653	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$		
003015	004162	-05212	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$		
002767	004030	-05807	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$		
002492	003701	-06076	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$		
003965	004771	-03399	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$		
004103	004803	-001705	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$		
004918	004093	-00502	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$		
004986	004391	-01942	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$		
005023	004793	-03290	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$		
004573	004058	-04023	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$		
004038	003148	-04592	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$		
003789	002932	-05279	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$		
003524	002596	-05552	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$		
004879	003462	-05074	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$		
005003	003472	-02632	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$		
005118	003491	-001133	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$		
005709	003043	-06663	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$		
005747	003428	-02190	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$		
005686	003298	-03240	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$		
004995	002210	-03869	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$		
004710	001972	-04684	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$		
004452	001581	-04967	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$		
005757	002123	006170	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$		
005904	002061	003707	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$		
005989	002073	002168	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$		
006088	002148	000936	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$		
006494	001948	-02172	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$		
006546	002361	-02297	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$		
006004	001339	-03000	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$		
005717	001005	-03953	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$		
005795	000428	-04000	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$		
006600	000897	-007303	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$		
006601	000829	004734	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$		
006088	000777	003179	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$		
006892	000828	001901	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$		
006990	000920	000608	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$		
007222	000958	-00921	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$		
006995	000636	-02063	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$		
006820	000223	-03036	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$		
007147	-00314	-02864	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$		
007278	-00104	-008204	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$		
007421	-00272	-005697	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$		
007547	-00409	004151	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$		
007652	-00424	002320	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$		
007736	-00360	001543	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$		
007857	-00274	000220	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$		
007957	-00071	01011	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$		
008309	-00456	01566	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$		
008631	-01033	01358	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$		
008909	-00767	009353	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$		
008267	-01177	006887	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$		
008309	-01458	005228	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$		
008366	-01556	003895	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$		
008413	-01589	002474	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$		
008470	-01616	000989	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$		
008623	-01256	-00422	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$		
008639	-01150	-00997	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$		
008684	-01129	-01301	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$		
008017	-01014	-009219	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$		
008172	-01469	006746	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$		
008253	-01696	005142	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$		
008284	-01849	003781	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$		
008335	-01869	002335	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$		
008399	-01867	000882	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$		
008673	-01281	-00514	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$		
008700	-01171	-01082	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$		
008694	-01116	-01299	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$		
003708	006604	000133	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$		
003745	006841	-01211	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$		
003781	007126	-02377	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$		
003815	007379	-03259	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$		
003787	007458	-03650	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$		
003339	006791	-04232	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$		
002795	005997	-04940	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$		
002277	005335	-05593	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$		
002011	005036	-05912	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$		
003649	006307	002764	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$		
004545	005928	-00144	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$		
004595	006195	-01569	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$		
004638	006513	-02808	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$		
004645	006750	-03563	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$		
004371	006356	-04030	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$		
003785	006448	-04720	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$		
003226	004675	-05342	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$		
002943	004309	-05676	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$		
004235	005699	-04468	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$		
004469	005700	-00192	0875	0250	0125	0125</								

009283	-00056	-00618	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009228	-00140	-00688	0875	1000	1000	0000	0125	0000	0000	%0730	b02	\$
008789	-01091	-01238	0750	1000	1000	0000	0250	0000	0000	%0731	b03	\$
008173	-01999	-01901	0625	1000	1000	0000	0375	0000	0000	%0732	b04	\$
007582	-02666	-02416	0500	1000	1000	0000	0500	0000	0000	%0733	b05	\$
007652	-03154	-02741	0375	1000	1000	0000	0625	0000	0000	%0734	b06	\$
006483	-03581	-03052	0250	1000	1000	0000	0750	0000	0000	%0735	b07	\$
005793	-03918	-03360	0125	1000	1000	0000	0875	0000	0000	%0736	b08	\$
005056	-04020	-03579	0000	1000	1000	0000	1000	0000	0000	%0737	b09	\$
009243	000014	-00663	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
009188	-00105	-00598	0875	0875	0875	0000	0125	0125	0125	%0739	c02	\$
008729	-01105	-00992	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
008101	-02064	-01538	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
007528	-02785	-01947	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
006967	-03328	-02291	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
006407	-03792	-02561	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005731	-04163	-02861	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
004991	-04341	-03020	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008557	001091	-00980	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
008490	000029	-00780	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
008068	-00095	-01023	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
007508	-01205	-01419	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
006985	-02095	-01734	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
006502	-02810	-01961	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
005999	-03430	-02180	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005392	-03990	-02393	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
004712	-04329	-02492	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007814	002139	-01079	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007758	001975	-00797	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
007378	000900	-00927	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006833	-00305	-01179	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
006342	-01323	-01432	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
005410	-02171	-01595	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
005473	-02934	-01752	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
004917	-03645	-01952	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004323	-04092	-02088	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007054	003135	-01014	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
007015	002944	-00657	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006639	001882	-00730	0750	0500	0500	0500	0250	0500	0000	%0767	f03	\$
006112	000612	-00962	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005640	-00474	-01169	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005249	-01386	-01348	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
004835	-02247	-01520	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004337	-03069	-01674	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
003815	-03631	-01773	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006249	004144	-00859	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
006211	003972	-00528	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005844	002966	-00658	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005306	001699	-00905	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004828	000599	-01089	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
004456	-00380	-01222	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004052	-01308	-01411	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
003574	-02183	-01524	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003121	-02798	-01646	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
005482	005112	-00724	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005438	004959	-00399	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
005050	004028	-00482	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
004489	002800	-00762	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
003996	001691	-00958	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
003610	000696	-01184	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
003217	-00270	-01392	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
002804	-01217	-01458	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
002372	-01908	-01533	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
004639	006077	-00536	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004592	005944	-00161	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
004207	005126	-00309	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
003604	003977	-00684	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
003143	002933	-00969	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
002717	001912	-01153	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
002315	000935	-01342	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
001909	-00015	-01441	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
001552	-00814	-01389	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
003787	006767	-00198	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
003759	006641	000115	0875	0000	0000	0125	1000	1000	0000	%0802	j02	\$
003388	005920	000094	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
002838	004856	-00284	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
002339	003861	-00663	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
001893	002882	-00875	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
001474	001889	-00881	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
001100	000887	-00826	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
000813	000023	-00732	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009234	-00023	-00644	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
009181	-00101	-00707	0875	0875	0875	0125	0125	0000	0000	%0811	b11	\$
008727	-00982	-01278	0750	0750	0750	0250	0250	0000	0000	%0812	b12	\$
007856	-01343	-02212	0625	0625	1000	0375	0375	0000	0000	%0813	b13	\$
007036	-01554	-02974	0500	0500	0500	0500	0500	0000	0000	%0814	b14	\$
006300	-01627	-03577	0375	0375	1000	0625	0625	0000	0000	%0815	b15	\$
005564	-01685	-04113	0250	0250	1000	0750	0750	0000	0000	%0816	b16	\$
004785	-01725	-04591	0125	0250	1000	0875	0875	0000	0000	%0817	b17	\$
003942	-01385	-04874	0000	0000	1000	1000	1000	0000	0000	%0818	b18	\$
009221	-00047	-00527	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$
009141	-00073	-00623	0875	0875	0875	0125	0125	0250	0000	%0820	c11	\$
008439	-00491	-01468	0750	0750	0750	0250	0250	0125	0000	%0821	c12	\$
007559	-00853	-02394	0625	0625	0875	0375	0375	0125	0000	%0822	c13	\$
006733	-01071	-03157	0500	0500	0875	0500	0500	0125	0000	%0823	c14	\$
006008	-01183	-03747	0375	0375	0875	0625	0625	0125	0000	%0824	c15	\$
005289	-01245	-04274	0250	0250	0875	0750	0750	0125	0000	%0825	c16	\$
004483	-01181	-04773	0125	0125	0875	0875	0875	0125	0000	%0826	c17	\$
003655	-00835	-05137	0000	0000	0875	1000	1000	0125	0000	%0827	c18	\$
009171	-02020	-00370	1000	1000	0750	0000	0250	0000	0000	%0828	d10	\$
009070	-00196	-00243	0750	0875	0750	0125	0125	0250	0000	%0829	d11	\$
008089	-00120	-00985	0750	0750	0750	0250	0250	00				

%BEG HE27_22.TXT, Separation olv*, D50, not adapted \$
%100 x LAB*
%#1000 x (r' g' b' c' m' y' 0)
%nr. pos \$
%z003750 006716 -00107 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008509 000055 010023 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z004521 -06090 001801 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005032 -03993 -03592 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z003907 -01326 -05006 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z002485 005625 -05352 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z000800 000004 -00680 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009198 -00032 -00646 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z003787 006767 -00198 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008513 000062 009927 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z004497 -06076 001774 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005056 -04020 -03579 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003942 -01386 -04974 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z002502 005611 -05336 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z000804 000026 -00685 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009249 -00038 -00634 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/HE37/HE37L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG HE27 22.TXT, Separation olv*, D50, not adapted \$		%100 x LAB* 1000 x (r g b c m y θ) %nr. pos \$																								
000877	000010	-00672	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$	0009100	-00133	-00568	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$	
0001929	-00028	-01392	0125	0125	0125	0875	0875	0875	0875	0000	%0973	k02	\$	0009235	-00053	-00609	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$
003206	-00209	-01413	0250	0250	0250	0750	0750	0750	0750	0000	%0974	k03	\$	0009221	-00042	-00625	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$
004418	-00349	-01241	0375	0375	0375	0625	0625	0625	0625	0000	%0975	k04	\$	0008000	000016	-00740	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$
005647	-00472	-01177	0500	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	001306	000090	-01245	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$
006859	-00324	-01174	0625	0625	0625	0375	0375	0375	0375	0000	%0977	k06	\$	001988	-00042	-01473	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$
008100	-00135	-00991	0750	0750	0750	0250	0250	0250	0250	0000	%0978	k07	\$	002670	-00255	-01434	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$
009173	-00100	-00900	0875	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$	003377	-00275	-01388	0266	0266	0266	0333	0333	0333	0000	%1060	n14	\$
009242	-00033	-00834	1000	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$	004041	-00316	-01241	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$
009854	000000	-00679	0000	0000	0000	1000	1000	1000	1000	0000	%0981	l01	\$	004708	-00420	-01238	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$
0091937	-00025	-01419	0125	0125	0125	0875	0875	0875	0875	0000	%0982	l02	\$	005339	-00484	-01216	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$
0093221	-00212	-01421	0250	0250	0250	0750	0750	0750	0750	0000	%0983	l03	\$	005985	-00505	-01129	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$
004438	-00346	-01252	0375	0375	0375	0625	0625	0625	0625	0000	%0984	l04	\$	006599	-00369	-01146	0600	0600	0600	0400	0400	0400	0000	%1065	n19	\$
005663	-00462	-01205	0500	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	007248	-00215	-01141	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$
006885	-00324	-01183	0625	0625	0625	0375	0375	0375	0375	0000	%0986	l06	\$	007911	-00123	-01009	0734	0734	0734	0266	0266	0266	0000	%1067	n21	\$
008108	-00142	-01002	0750	0750	0750	0250	0250	0250	0250	0000	%0987	l07	\$	008511	-00073	-00849	0800	0800	0800	0200	0200	0200	0000	%1068	n22	\$
009172	-00102	-00604	0875	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$	009097	-00129	-00572	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$
009246	-00038	-00631	1000	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$	009237	-00055	-00610	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$
000849	-00005	-00688	0000	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$	009213	-00045	-00629	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$
0091943	-00026	-01416	0125	0125	0125	0875	0875	0875	0875	0000	%0991	m02	\$	0009174	000035	-00653	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$
003226	-00218	-01422	0250	0250	0250	0750	0750	0750	0750	0000	%0992	m03	\$	009176	-00042	-00616	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$
004442	-00361	-01245	0375	0375	0375	0625	0625	0625	0625	0000	%0993	m04	\$	003743	006752	-00041	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
005668	-00473	-01192	0500	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$	005068	-04058	-03525	0000	1000	1000	1000	0000	0000	0000	%1075	l27	\$
006891	-00327	-01179	0625	0625	0625	0375	0375	0375	0375	0000	%0995	m06	\$	008504	000066	010029	1000	1000	0000	0000	1000	1000	0000	%1076	m26	\$
008112	-00150	-00989	0750	0750	0750	0250	0250	0250	0250	0000	%0996	m07	\$	003905	-01263	-05024	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$
009174	-00105	-00600	0875	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$	004502	-06101	001855	0000	1000	0000	0000	1000	0000	0000	%1078	n26	\$
009229	-00036	-00640	1000	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$	002523	005608	-05339	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$
000852	000001	-00704	0000	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$													
0091933	-00026	-01415	0125	0125	0125	0875	0875	0875	0875	0000	%1000	n02	\$	%z003743 006752 -00041 %1000 0000 0000 0000 1000 1000 0000 0000 %1074 l26 %03 0 0												
0093213	-00206	-01443	0250	0250	0250	0750	0750	0750	0750	0000	%1001	n03	\$	%z000504 000066 010029 %1000 1000 0000 0000 0000 0000 1000 0000 %1076 m26 %Y3 1 0												
004422	-00352	-01247	0375	0375	0375	0625	0625	0625	0625	0000	%1002	n04	\$	%z004502 -06101 001855 %1000 1000 0000 1000 0000 1000 0000 1000 %1078 n26 %L3 2 0												
005672	-00472	-01187	0500	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$	%z005068 -04058 -03525 %1000 1000 1000 1000 0000 0000 0000 0000 %1075 l27 %C3 3 0												
006874	-00330	-01174	0625	0625	0625	0375	0375	0375	0375	0000	%1004	n06	\$	%z003905 -01263 -05024 %1000 0000 1000 1000 1000 0000 0000 0000 %1077 m27 %V3 4 0												
008089	-00143	-00999	0750	0750	0750	0250	0250	0250	0250	0000	%1005	n07	\$	%z002523 005608 -05339 %1000 0000 1000 0000 1000 0000 0000 0000 %1079 n27 %M3 5 0												
009169	-00108	-00599	0875	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$	%z000791 000035 -00653 %1000 0000 0000 1000 1000 1000 0000 0000 %1072 k26 %N3 6 0												
009239	-00039	-00624	1000	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$	%z009176 -00042 -00616 %1000 1000 1000 0000 0000 0000 0000 0000 %1073 k27 %N3 7 0												
009822	000018	-00728	0000	0000	0000	1000	1000	1000	1000	0000	%1008	k10	\$													
0091341	000091	-01196	0066	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$	%z000850 000014 -00700 %1000 0000 0000 1000 1000 1000 0000 0000 %0972 k01 %N4 6 0												
0091993	-00051	-01429	0133	0133	0133	0866	0866	0866	0866	0000	%1010	k12	\$	%z009228 -00036 -00631 %1000 1000 1000 0000 0000 0000 0000 0000 %0980 k09 %N4 7 0												
002670	-00242	-01419	0200	0200	0200	0800	0800	0800	0800	0000	%1011	k13	\$													
003376	-00270	-01364	0266	0266	0266	0333	0333	0333	0333	0000	%1012	k14	\$	%z0008837 000009 -00701 %1000 0000 0000 1000 1000 1000 0000 0000 %0981 l01 %N5 6 0												
004039	-00310	-01228	0333	0333	0333	0666	0666	0666	0666	0000	%1013	k15	\$	%z0009234 -00039 -00626 %1000 1000 1000 0000 0000 0000 0000 0000 %0989 l09 %N5 7 0												
004687	-00424	-01213	0400	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$													
005319	-00489	-01187	0466	0466	0466	0533	0533	0533	0533	0000	%1015	k17	\$	%z000829 000008 -00719 %1000 0000 0000 1000 1000 1000 0000 0000 %0990 m01 %N6 6 0												
005960	-00512	-01111	0533	0533	0533	0466	0466	0466	0466	0000	%1016	k18	\$	%z009225 -00039 -00633 %1000 1000 1000 0000 0000 0000 0000 0000 %0998 m09 %N6 7 0												
005986	-00380	-01119	0600	0600	0600	0400	0400	0400	0400	0000	%1017	k19	\$													
007898	-00001	-01018	0666	0666	0666	0333	0333	0333	0333	0000	%1018	k20	\$	%z000826 000009 -00722 %1000 0000 0000 1000 1000 1000 0000 0000 %0999 n01 %N7 6 0												
007898	-00113	-01003	0734	0734	0734	0266	0266	0266	0266	0000	%1019	k21	\$	%z009226 -00042 -00627 %1000 1000 1000 0000 0000 0000 0000 0000 %1007 n09 %N7 7 0												
008498	-00063	-00845	0800	0800	0800	0200	0200	0200	0200	0000	%1020	k22	\$													
009098	-00128	-00566	0866	0866	0866	0133	0133	0133	0133	0000	%1021	k23	\$													
009235	-00051	-00613	0933	0933	0933	0666	0666	0666	0666	0000	%1022	k24	\$													
009213	-00039	-00629	1000	1000	1000	1000	0000	0000	0000	0000	%1023	k25	\$													
000819	000020	-00722	0000	0000	0000	0000	1000	1000	1000	0000	%1024	l10	\$													
001324	000084	-01225	0066	0066	0066	0066	0933	0933	0933	0000	%1025	l11	\$													
002004	-00052	-01444	0133	0133	0133	0866	0866	0866	0866	0000	%1026	l12	\$													
002678	-00248	-01428	0200	0200	0200	0800	0800	0800	0800	0000	%1027	l13	\$													
003392	-00282	-01365	0266	0266	0266	0333	0333	0333	0333	0000	%1028	l14	\$													
004064	-00313	-01250	0333	0333	0333	0666	0666	0666	0666	0000	%1029	l15	\$													
004685	-00436	-01218	0400	0400	0400	0400	0600	0600	0600	0000	%1030	l16	\$													
005350	-00489	-01199	0466	0466	0466	0533	0533	0533	0533	0000	%1031	l17	\$													
005																										

See original or copy: <http://web.me.com/klaus.richter/HE37/HE37L0NA.TXT> /PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG HE27 22.TXT, Separation olv*, D50, adapted s																													
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)										xnr. pos \$									
x100 x LAB*a										1000 x (r g b c m y o)																			

001803	002800	-00195	0375	0000	0000	0025	1000	1000	0000	%0243	A10	\$
001895	003359	-01803	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$
001832	003496	-02792	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$
001372	002792	-03326	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$
001243	003073	-04281	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$
001138	003468	-05020	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$
001402	003463	-05477	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$
001778	003046	-06630	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$
002172	002221	-05503	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$
002043	001994	-001801	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$
002617	001947	-00544	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$
002726	002420	-01990	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$
002343	001749	-02638	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$
002166	001884	-03779	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$
002365	001954	-04547	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$
002835	001632	-04905	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$
003204	001227	-05017	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$
003556	000576	-04822	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$
002961	000500	-002887	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$
003185	000703	-000828	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$
003526	000720	-00570	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$
003418	000626	-01622	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$
003376	000555	-02797	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$
003810	000441	-03460	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$
004277	000194	-03920	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$
004645	-00158	-04097	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$
004994	-00749	-03884	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$
003861	-00944	-004006	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$
004058	-00769	-001824	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$
004248	-00625	-000494	0375	0375	0250	0625	0625	0750	0000	%0272	D12	\$
004350	-00340	-00620	0375	0375	0375	0625	0625	0625	0000	%0273	D13	\$
004824	-00645	-01364	0375	0375	0500	0625	0625	0500	0000	%0274	D14	\$
005225	-00756	-02178	0375	0375	0625	0625	0625	0375	0000	%0275	D15	\$
005615	-00808	-02817	0375	0375	0750	0625	0625	0250	0000	%0276	D16	\$
005935	-01142	-03134	0375	0375	0875	0625	0625	0125	0000	%0277	D17	\$
006205	-01604	-02973	0375	0375	1000	0625	0625	0000	0000	%0278	D18	\$
004763	-02282	-005185	0375	0500	0000	0625	0500	1000	0000	%0279	D19	\$
004888	-02210	-002870	0375	0500	0125	0625	0500	0875	0000	%0280	E11	\$
004982	-02082	-001378	0375	0500	0250	0625	0500	0750	0000	%0281	E12	\$
005103	-01599	-000035	0375	0500	0375	0625	0500	0625	0000	%0282	E13	\$
005154	-01379	-00724	0375	0500	0500	0625	0500	0500	0000	%0283	E14	\$
005745	-01725	-01639	0375	0500	0625	0625	0500	0375	0000	%0284	E15	\$
006068	-01739	-02389	0375	0500	0750	0625	0500	0250	0000	%0285	E16	\$
006386	-02004	-02736	0375	0500	0875	0625	0500	0125	0000	%0286	E17	\$
006618	-02403	-02605	0375	0500	1000	0625	0500	0000	0000	%0287	E18	\$
005240	-03331	-005780	0375	0625	0000	0625	0375	1000	0000	%0288	F10	\$
005381	-03323	-003520	0375	0625	0125	0625	0375	0875	0000	%0289	F11	\$
005499	-03217	-002050	0375	0625	0250	0625	0375	0750	0000	%0290	F12	\$
005723	-02627	-000627	0375	0625	0375	0625	0375	0625	0000	%0291	F13	\$
005782	-02404	-00211	0375	0625	0500	0625	0375	0500	0000	%0292	F14	\$
005832	-02157	-00975	0375	0625	0625	0625	0375	0375	0000	%0293	F15	\$
006483	-02527	-01979	0375	0625	0750	0625	0375	0250	0000	%0294	F16	\$
006778	-02747	-02369	0375	0625	0875	0625	0375	0125	0000	%0295	F17	\$
006958	-03066	-02281	0375	0625	1000	0625	0375	0000	0000	%0296	F18	\$
005571	-04088	-006213	0375	0750	0000	0625	0250	1000	0000	%0297	G10	\$
005743	-04212	-003697	0375	0750	0125	0625	0250	0875	0000	%0298	G11	\$
005855	-04109	-002405	0375	0750	0250	0625	0250	0750	0000	%0299	G12	\$
006250	-04740	-002470	0375	0750	0375	0625	0250	0625	0000	%0300	G13	\$
006298	-03293	-000269	0375	0750	0500	0625	0250	0500	0000	%0301	G14	\$
006361	-03058	-00546	0375	0750	0625	0250	0250	0375	0000	%0302	G15	\$
006440	-02785	-01316	0375	0750	0750	0625	0250	0250	0000	%0303	G16	\$
006953	-03160	-02057	0375	0750	0875	0625	0250	0125	0000	%0304	G17	\$
006981	-03103	-02259	0375	0750	1000	0625	0250	0000	0000	%0305	G18	\$
005718	-04645	-006498	0375	0875	0000	0625	0125	1000	0000	%0306	H10	\$
005972	-04822	-004278	0375	0875	0125	0625	0125	0875	0000	%0307	H11	\$
006064	-04851	-002776	0375	0875	0250	0625	0125	0750	0000	%0308	H12	\$
006644	-04130	-001365	0375	0875	0375	0625	0125	0625	0000	%0309	H13	\$
006714	-03977	-000601	0375	0875	0500	0625	0125	0500	0000	%0310	H14	\$
006779	-03772	-00260	0375	0875	0625	0625	0125	0375	0000	%0311	H15	\$
006867	-03545	-00979	0375	0875	0750	0625	0125	0250	0000	%0312	H16	\$
006918	-03326	-01648	0375	0875	0875	0625	0125	0125	0000	%0313	H17	\$
005987	-03096	-02257	0375	0875	1000	0625	0125	0000	0000	%0314	H18	\$
006609	-04816	-006239	0375	1000	0000	0625	0000	1000	0000	%0315	I10	\$
005853	-04993	-004104	0375	1000	0125	0625	0000	0875	0000	%0316	I11	\$
005973	-04988	-002625	0375	1000	0250	0625	0000	0750	0000	%0317	I12	\$
006675	-04109	-001217	0375	1000	0375	0625	0000	0625	0000	%0318	I13	\$
006763	-03946	-000453	0375	1000	0500	0625	0000	0500	0000	%0319	I14	\$
006843	-03731	-004002	0375	1000	0625	0000	0000	0375	0000	%0320	I15	\$
006919	-03496	-01152	0375	1000	0750	0625	0000	0250	0000	%0321	I16	\$
006955	-03306	-01732	0375	1000	0875	0625	0000	0125	0000	%0322	I17	\$
006983	-03153	-02114	0375	1000	1000	0625	0000	0000	0000	%0323	I18	\$
002308	003821	-00040	0500	0000	0000	0500	1000	1000	0000	%0324	J10	\$
002387	004264	-01516	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$
002481	004723	-02747	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$
002151	004304	-03470	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$
001686	003602	-03994	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$
001509	003800	-04958	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$
001353	004040	-05531	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$
001253	004038	-05737	0500	0000	0875	0500	1000	0125	0000	%0331	J17	\$
001573	003508	-05729	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$
002370	003221	-02637	0500	0125	0000	0500	0875	1000	0000	%0333	K10	\$
003113	002910	-00340	0500	0125	0125	0500	0875	0075	0000	%0334	K11	\$
003223	003327	-01763	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$
003137	003424	-02855	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$
002689	002613	-03372	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$
002476	002691	-04517	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$
002287	002824	-05246	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$
002634	002377	-05365	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$
003008	001701	-05186	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$
003258	001812	-03422	0500	0250	0000	0500	0750	1000	0000	%0342	L10	\$
003449	001980	-001241	0500	0250	0125	0500	0750	0875	0000	%0343	L11	\$
003985	001674	-00299										

003309	005883	000841	0750	0000	0000	0250	0000	1000	1000	0000	0000	%0486	A19	\$
003341	006144	-00645	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$		
003380	006450	-01890	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$		
003429	006774	-02904	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$		
003534	006304	-03621	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$		
003654	005537	-04304	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$		
003683	004945	-04855	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$		
003750	004826	-05368	0750	0000	0875	0250	1000	0000	0000	%0493	A26	\$		
003850	004571	-05810	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$		
003256	005579	003653	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$		
004079	005162	000392	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$		
004140	005450	-01102	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$		
004187	005814	-02418	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$		
004113	005886	-03283	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$		
003505	004944	-03983	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$		
003015	004168	-04540	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$		
002767	004034	-05134	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$		
002492	003704	-05402	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$		
003965	004780	004657	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$		
004103	004813	002372	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$		
004918	004107	000161	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$		
004986	004404	-01278	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$		
005023	004807	-02626	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$		
004573	004071	-03357	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$		
004038	003158	-03924	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$		
003789	002941	-04610	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$		
003524	002604	-04882	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$		
004879	003476	005738	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$		
005003	003486	003296	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$		
005118	003506	001797	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$		
005708	003906	-00002	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$		
005747	003446	-01530	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$		
005686	003415	-02578	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$		
004995	002224	-03205	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$		
004710	001984	-04019	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$		
004452	001593	-04301	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$		
005757	002140	006831	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$		
005904	002079	004367	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$		
005989	002091	002828	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$		
006088	002167	001595	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$		
006494	001969	-00054	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$		
006546	002382	-01640	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$		
006004	001357	-02340	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$		
005717	001023	-03292	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$		
005795	000446	-03339	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$		
006600	000918	007960	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$		
006601	000851	005391	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$		
006608	000799	003835	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$		
006892	000850	002557	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$		
006990	000943	001264	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$		
007222	000982	-00266	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$		
006995	000659	-01407	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$		
006820	000245	-02380	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$		
007147	-00291	-02209	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$		
007278	-00080	008859	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$		
007421	-00248	006351	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$		
007547	-00384	004804	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$		
007652	-00408	003550	0750	0750	0375	0250	0250	0500	0000	%0543	G22	\$		
007736	-00334	002196	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$		
007857	-00247	000873	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$		
007957	-00044	-00359	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$		
008309	-00427	-00916	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$		
008631	-01003	-00709	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$		
008990	-00740	-010005	0750	0750	0000	0250	0125	1000	0000	%0549	H19	\$		
008267	-01149	007537	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$		
008309	-01430	005879	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$		
008366	-01527	004545	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$		
008413	-01560	003124	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$		
008470	-01586	001638	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$		
008623	-01226	000226	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$		
008639	-01120	-00348	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$		
008684	-01099	-00652	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$		
008017	-00987	009870	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$		
008172	-01442	007397	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$		
008253	-01668	005793	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$		
008284	-01821	004431	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$		
008335	-01840	002985	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$		
008399	-01838	001532	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$		
008673	-01251	006134	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$		
008700	-01141	-00433	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$		
008694	-01085	-00650	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$		
003708	006612	-00803	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$		
003745	006850	-00542	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$		
003811	007135	-01709	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$		
003785	007388	-02590	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$		
003787	007467	-02981	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$		
003839	006798	-03561	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$		
002795	006001	-04267	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$		
002277	005337	-04908	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$		
002011	005037	-05230	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$		
003649	006315	-00343	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$		
004574	005940	000520	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$		
004595	006207	-00903	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$		
004638	006526	-02142	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$		
004645	006762	-02897	0875	0125	0500	0125	0							

009283	-00017	000016	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009228	-00101	-00053	0875	1000	1000	0000	0125	0000	0000	%0730	b02	\$
008789	-01056	-00600	0750	1000	1000	0000	0250	0000	0000	%0731	b03	\$
008173	-01969	-01259	0625	1000	1000	0000	0375	0000	0000	%0732	b04	\$
007582	-02640	-01771	0500	1000	1000	0000	0500	0000	0000	%0733	b05	\$
007652	-03133	-02093	0375	1000	1000	0000	0625	0000	0000	%0734	b06	\$
006483	-03564	-02401	0250	1000	1000	0000	0750	0000	0000	%0735	b07	\$
005793	-03908	-02704	0125	1000	1000	0000	0875	0000	0000	%0736	b08	\$
005056	-04013	-02519	0000	1000	1000	0000	1000	0000	0000	%0737	b09	\$
009243	000052	-00028	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
009188	-00066	000036	0875	0875	0875	0000	0125	0125	0125	%0739	c02	\$
008729	-01070	-00354	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
008101	-02034	-00896	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
007528	-02760	-01302	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
006967	-03307	-01642	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
006407	-03775	-01909	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005731	-04152	-02205	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
004991	-04335	-02359	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008557	001124	-00341	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
008490	000962	-00140	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
008068	-00066	-00381	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
007508	-01179	-00773	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
006985	-02074	-01085	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
006502	-02793	-01310	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
005999	-03416	-01526	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005392	-03981	-01735	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
004712	-04325	-01830	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007814	002167	-00436	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007758	002003	-00153	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
007370	000924	-00281	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006833	-00285	-00529	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
006342	-01306	-00779	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
005410	-02158	-01098	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
005473	-02924	-01084	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
004917	-03639	-01291	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004323	-04091	-01424	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007054	003156	-00366	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
007015	002965	-00008	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006639	001900	-00079	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$
006112	000627	-00308	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005640	-00463	-00512	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005249	-01378	-00689	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
004835	-02242	-00859	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004337	-03068	-01010	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
003815	-03634	-01105	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006249	004159	-00206	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
006211	003988	-000124	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005844	002978	-00003	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005306	001708	-00246	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004828	000604	-00428	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
004456	-00378	-00558	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004052	-01310	-00745	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
003574	-02188	-00855	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003121	-02807	-00974	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
005482	005122	-00067	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005438	004968	-00058	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
005050	004035	-000170	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
004648	002802	-00009	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
003996	001689	-00292	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
003610	000692	-00515	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
003217	-00278	-00721	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
002804	-01228	-00785	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
002372	-01922	-00856	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
004639	006080	-000126	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004592	005947	-00501	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
004207	005126	-00364	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
003634	003973	-00015	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
003143	002925	-00297	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
002717	001900	-00479	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
002315	000920	-00665	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
001909	-00032	-00762	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
001552	-00835	-00708	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
003787	006764	-000469	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
003759	006638	-000783	0875	0000	0000	0125	1000	1000	0000	%0802	j02	\$
003388	005914	-000765	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
002838	004846	-000388	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
002339	003846	-000013	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
001893	002865	-00196	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
001478	001868	-00199	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
001100	000863	-00143	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
000813	-00002	-00047	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009234	000015	-00009	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
009181	-00063	-00072	0875	0875	0875	0125	0125	0000	0000	%0811	b11	\$
008727	-00947	-00640	0750	0750	0750	0250	0250	0000	0000	%0812	b12	\$
007856	-01315	-01569	0625	0625	0625	0375	0375	0000	0000	%0813	b13	\$
007036	-01533	-02325	0500	0500	0500	0500	0500	0000	0000	%0814	b14	\$
006300	-01611	-02924	0375	0375	0375	0625	0625	0000	0000	%0815	b15	\$
005564	-01675	-03456	0250	0250	0250	0750	0750	0000	0000	%0816	b16	\$
004785	-01721	-03815	0125	0125	0125	0875	0875	0000	0000	%0817	b17	\$
003942	-01380	-04307	0000	1000	1000	1000	1000	0000	0000	%0818	b18	\$
009221	-00009	000107	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$
009141	-00035	000012	0875	0875	0875	0125	0125	0250	0000	%0820	c11	\$
008439	-00459	-00828	0750	0750	0750	0250	0250	0125	0000	%0821	c12	\$
007559	-00827	-01749	0625	0625	0625	0375	0375	0125	0000	%0822	c13	\$
006733	-01052	-02507	0500	0500	0500	0500	0500	0125	0000	%0823	c14	\$
006008	-01169	-03093	0375	0375	0875	0625	0625	0125	0000	%0824	c15	\$
005289	-01237	-03615	0250	0250	0250	0750	0750	0125	0000	%0825	c16	\$
004483	-01179	-04109	0125	0125	0125	0875	0875	0125	0000	%0826	c17	\$
003655	-00840	-04469	0000	0000	0750	1000	1000	0125	0000	%0827	c18	\$
009171	-00167	-00106	1000	1000	0750	0000	0000	0250	0000	%0828	d10	\$
009070	-00158	-00880	0875	0875	0750	0125	0125	0250	0000	%0829	d11	\$
008089	-00090	-00343	0750</									

%BEG HE27_22.TXT, Separation olv*, D50, adapted \$
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos \$
%z003750 006724 000561 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008509 000084 010673 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z004521 -06078 002467 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005032 -03978 -02928 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z003907 -01317 -04337 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z002485 005628 -04678 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z000800 000000 000000 %#0000 0000 1000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009198 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z003787 006764 000469 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008513 000095 010566 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z004497 -06074 002438 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005056 -04013 -02919 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003942 -01388 -04307 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z002502 005598 -04660 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z000804 000000 000000 %#0000 0000 1000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009249 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/HE37/HE37L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

TUB registration: 20091101-HE37/HE37L0NA.TXT /.PS TUB material: code=rh4ta
application for evaluation and measurement of printer or monitor systems

KBEG HE27 22.TXT, Separation olv*, D5 adapted \$					
%100 x LAB*	1000 x (r g b c m y)	%nr.	pos	\$	
000877 -00024	-00019 0000 0000	0000 1000 1000	0000 0000	000972 k01	\$
001929 -00053	-00744 0125 0125	0125 0875 0875	0800 0000	000973 k02	\$
003416 -00222	-00770 0250 0250	0250 0750 0750	0750 0000	000974 k03	\$
004218 -00351	-00603 0375 0375	0375 0625 0625	0650 0000	000975 k04	\$
005647 -00463	-00545 0500 0500	0500 0500 0500	0500 0000	000976 k05	\$
006859 -00303	-00547 0625 0625	0625 0375 0375	0375 0000	000977 k06	\$
008100 -00102	-00370 0750 0750	0750 0250 0250	0250 0000	000978 k07	\$
009173 -00058	-00016 0875 0875	0875 0125 0125	0125 0000	000979 k08	\$
009242 000009	-00018 1000 1000	1000 0000 0000	0000 0000	000980 k09	\$
000854 -00035	-00026 0000 1000	1000 1000 1000	1000 0000	000981 l01	\$
001937 -00050	-00771 0125 0125	0125 0875 0875	0875 0000	000982 l02	\$
003221 -00225	-00779 0250 0250	0250 0750 0750	0750 0000	000983 l03	\$
004438 -00348	-00614 0375 0375	0375 0625 0625	0625 0000	000984 l04	\$
005663 -00453	-00573 0500 0500	0500 0500 0500	0500 0000	000985 l05	\$
006885 -00303	-00556 0625 0625	0625 0375 0375	0375 0000	000986 l06	\$
008108 -00110	-00380 0750 0750	0750 0250 0250	0250 0000	000987 l07	\$
009172 -00060	-00012 0875 0875	0875 0125 0125	0125 0000	000988 l08	\$
009246 000003	-00014 1000 1000	1000 0000 0000	0000 0000	000989 l09	\$
000849 -00040	-00035 0000 0000	0000 1000 1000	1000 0000	000990 m01	\$
001943 -00051	-00767 0125 0125	0125 0875 0875	0875 0000	000991 m02	\$
003423 -00219	-00800 0250 0250	0250 0750 0750	0750 0000	000992 m03	\$
004442 -00363	-00608 0375 0375	0375 0625 0625	0625 0000	000993 m04	\$
005668 -00463	-00560 0500 0500	0500 0500 0500	0500 0000	000994 m05	\$
006891 -00306	-00552 0625 0625	0625 0375 0375	0375 0000	000995 m06	\$
008112 -00117	-00367 0750 0750	0750 0250 0250	0250 0000	000996 m07	\$
009174 -00062	-00016 0875 0875	0875 0125 0125	0125 0000	000997 m08	\$
009229 000005	-00023 1000 1000	1000 0000 0000	0000 0000	000998 m09	\$
000852 -00033	-00051 0000 0000	0000 1000 1000	1000 0000	000999 n01	\$
001933 -00051	-00767 0125 0125	0125 0875 0875	0875 0000	001000 n02	\$
003421 -00219	-00800 0250 0250	0250 0750 0750	0750 0000	001001 n03	\$
004223 -00354	-00609 0375 0375	0375 0625 0625	0650 0000	001002 n04	\$
005672 -00462	-00555 0500 0500	0500 0500 0500	0500 0000	001003 n05	\$
006874 -00310	-00547 0625 0625	0625 0375 0375	0375 0000	001004 n06	\$
008099 -00111	-00378 0750 0750	0750 0250 0250	0250 0000	001005 n07	\$
009169 -00066	-00017 0875 0875	0875 0125 0125	0125 0000	001006 n08	\$
009239 000003	-00008 1000 1000	1000 0000 0000	0000 0000	001007 n09	\$
000822 -00017	-00075 0000 0000	0000 1000 1000	1000 0000	001008 k10	\$
001341 000061	-00545 0006 0066	0066 0063 0093	0933 0000	001009 k11	\$
001993 -00076	-00781 0133 0133	0133 0866 0866	0866 0000	001010 k12	\$
002670 -00261	-00773 0200 0200	0200 0800 0800	0800 0000	001011 k13	\$
003376 -00281	-00722 0266 0266	0266 0333 0333	0333 0000	001012 k14	\$
004039 -00315	-00589 0333 0333	0333 0666 0666	0666 0000	001013 k15	\$
004687 -00423	-00577 0400 0400	0400 0600 0600	0600 0000	001014 k16	\$
005					

TUB-test chart HE37; Relative Elementary Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```