
TUB registration: 20091101-HE53/HE53L0NA.TXT /.p

TUB material: code=rha4ta

TUB-test chart HE53; Relative Elementary Colour System C
1080 spectral reflexions R -> LAB* for D65 and D50

input: *w setgray*
output: no change compared to input

See original or copy: <http://web.me.com/klaus.richter/HE53/HE53L0NA.TXT/.PS>
 Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0, cfl=0.90; nt=

[illegible]

009652	-00071	000184	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$	
008710	-00418	-00459	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$	
008244	-00553	-00780	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$	
007512	-00651	-01166	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$	
006387	-00726	-01665	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$	
006870	-01026	-02161	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$	
005825	-01285	-02662	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$	
005253	-01446	-03108	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$	
004710	-01469	-03586	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$	
008818	-00929	000911	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$	
008411	-00060	000192	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$	
007912	-00355	-00536	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$	
007080	-00434	-00919	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$	
006574	-00638	-01211	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$	
006052	-00801	-01703	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$	
005513	-01139	-02218	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$	
004933	-01357	-02702	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$	
004440	-01449	-03038	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$	
008582	-00803	-001316	1000	0875	0875	0000	0125	0250	0000	%0180	U01	\$	
008051	-00300	-000684	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$	
007477	-00015	000121	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$	
006774	-00341	-00338	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$	
006288	-00491	-00975	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$	
005701	-00655	-01442	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$	
005161	-00977	-01797	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$	
004581	-01073	-02315	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$	
004087	-01191	-02597	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$	
003342	-00943	-002313	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$	
007597	-00667	-001341	0875	0750	0625	0125	0250	0375	0000	%0190	V02	\$	
006962	-00254	-000762	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$	
006326	-00042	-000191	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$	
005908	-00395	-00459	0500	0562	0625	0500	0437	0375	0000	%0193	V05	\$	
005404	-00645	-00888	0375	0562	0625	0625	0625	0375	0000	%0194	V06	\$	
004823	-00801	-01437	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$	
004282	-00976	-01777	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$	
003714	-01120	-02255	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$	
007879	-001438	-002896	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$	
007280	-00889	-002177	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$	
006638	-00629	-001692	0750	0562	0500	0250	0375	0500	0000	%0200	W03	\$	
005937	-00334	-000837	0625	0625	0500	0375	0437	0500	0000	%0201	W04	\$	
005350	-00076	-000151	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$	
005016	-00329	-00473	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$	
004496	-00594	-01057	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$	
003925	-00837	-01444	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$	
003439	-01034	-01827	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$	
007462	-00177	-003568	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$	
006791	-00136	-002767	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$	
006148	-00105	-002253	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$	
005519	-00062	-001784	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$	
004945	-00315	-000917	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$	
004492	-00063	-000097	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$	
004338	-00341	-00545	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$	
003625	-00501	-01067	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$	
003038	-00718	-01493	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$	
006974	-00258	-004137	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$	
006329	-001803	-003356	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$	
005686	-001509	-002856	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$	
005081	-00139	-002129	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$	
004562	-000914	-001403	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$	
004260	-00322	-000807	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$	
003734	-00089	-000029	0250	0250	0250	0500	0750	0750	0000	%0222	Y07	\$	
003435	-00331	-00569	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$	
003232	-00704	-01040	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$	
006660	-002904	-004785	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$	
005897	-00256	-003815	0875	0500	0625	0125	0125	0500	0875	0000	%0226	Z02	\$
005344	-001717	-003267	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$	
004692	-001534	-002742	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$	
004191	-001098	-002200	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$	
003836	-000864	-001446	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$	
003463	-000342	-000751	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$	
002770	-000013	-000044	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$	
002772	-00235	-004603	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$	
006090	-003269	-005351	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$	
005412	-002602	-004568	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$	
004863	-002474	-004172	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$	
004295	-001963	-003392	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$	
003812	-001449	-002599	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$	
003437	-001127	-002095	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$	
002989	-000952	-001494	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$	
002517	-000368	-000959	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$	
002459	-00218	-000066	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$	
009672	-00091	-000213	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$	
008549	-000156	-00393	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$	
008070	-000445	-00760	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$	
007220	-000580	-01195	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$	
006336	-000998	-01602	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$	
005591	-001171	-02210	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$	
004861	-001527	-02779	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$	
004025	-001001	-0339	0562	0250	1000	0875	0500	0000	0000	%0493	S17	\$	
003222	-002591	-04655	0500	0000	1000	0500	1000	0000	0000	%0494	S18	\$	
000913	-000618	-000649	0937	1000	0875	0062	0000	0125	0000	%0495	T01	\$	
008596	-000600	-000192	0875	0875	0875	0125	0125	0125	0000	%0496	T11	\$	
007910	-000156	-00418	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$	
006953	-000444	-00853	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$	
006135	-000779	-01265	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$	
005379	-001039	-01764	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$	
004615	-001339	-02277	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$	
003779	-001837	-02918	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$	
003138	-002006	-03282	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$	
008802	-00985	-001118	0875	1000	0750	0125	0000	0250	0000	%0504	U10	\$	
008231	-00452	-000517	0812	0875	0750	0187	0125	0250	0000	%0505	U11	\$	
007609	-0												

009635	-00093	000219	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
009566	-00275	-00348	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008042	-00234	-00849	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
007364	-00308	-01206	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
006743	-00316	-01607	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
006203	-00392	-02093	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$
005562	-00578	-02602	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
004978	-00770	-03157	0125	0343	1000	0875	0656	0000	0000	%0250	b08	\$
004437	-00787	-03556	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
008930	-00246	-00885	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
008402	-00607	-00210	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
007869	-00225	-00453	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
006992	-00211	-00906	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
006442	-00266	-01283	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
005881	-00383	-01740	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
005269	-00622	-02144	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
004581	-00584	-02730	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
004070	-00596	-03089	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
008766	-000480	-001485	1000	0937	0750	0000	0602	0250	0000	%0261	d01	\$
008158	-000174	-000666	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
007477	-000004	-000105	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$
006724	-00184	-00257	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
006188	-00300	-00962	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
005577	-00369	-01382	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
004925	-00589	-01818	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
004386	-00531	-02308	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
003880	-00662	-02639	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
008636	-00471	-02532	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
007883	-00241	-001535	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
007693	-00107	-00802	0750	0718	0625	0250	0281	0375	0000	%0272	e03	\$
006363	-00046	-00181	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
005899	-00134	-00397	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
005361	-00373	-00947	0375	0437	0625	0625	0562	0375	0000	%0275	e06	\$
004624	-00275	-01447	0250	0343	0625	0750	0656	0375	0000	%0276	e07	\$
004107	-00551	-01817	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
003533	-00555	-02309	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
008378	-00639	-003150	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
007591	-00480	-002377	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
006806	-00334	-001765	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
006041	-00208	-000813	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
005352	-00060	-000116	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
004983	-00108	-00543	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
004402	-00294	-01061	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
003822	-00335	-01507	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
003289	-00607	-01814	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
007998	-000940	-004135	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
007278	-000597	-003161	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
006489	-00445	-002570	0750	0656	0375	0250	0343	0625	0000	%0290	g03	\$
005695	-00335	-001939	0625	0562	0375	0375	0437	0625	0000	%0291	g04	\$
005013	-00173	-000953	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
004466	-000077	-000863	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
004228	-00147	-00563	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
003533	-00272	-01063	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
002689	-00172	-01450	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
007702	-001244	-004933	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
006911	-000869	-003951	0875	0718	0250	0125	0281	0750	0000	%0298	h02	\$
006108	-000728	-003314	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
005371	-000630	-002573	0625	0531	0250	0375	0437	0750	0000	%0300	h04	\$
004780	-000331	-001730	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
004254	-000122	-000924	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
003638	-000023	-000028	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
003271	-00091	-00615	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
002711	-000801	-00952	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
007404	-001505	-005806	1000	0781	0125	0000	0218	0875	0000	%0306	i01	\$
006631	-001045	-004547	0875	0687	0125	0125	0312	0875	0000	%0307	i02	\$
005798	-000961	-003766	0750	0593	0125	0250	0406	0875	0000	%0308	i03	\$
005034	-000820	-003201	0625	0500	0125	0375	0500	0875	0000	%0309	i04	\$
004379	-000718	-002452	0500	0406	0125	0500	0593	0875	0000	%0310	i05	\$
004007	-000438	-001634	0375	0312	0125	0625	0687	0875	0000	%0311	i06	\$
003507	-000074	-000022	0250	0218	0125	0750	0781	0875	0000	%0312	i07	\$
002698	-000013	-000855	0125	0125	0125	0875	0875	0875	0000	%0313	i08	\$
002602	-00092	-00537	0000	0031	0125	1000	0968	0875	0000	%0314	i09	\$
007079	-001743	-006359	1000	0750	0000	0000	0250	1000	0000	%0315	j01	\$
006214	-001399	-005547	0875	0656	0000	0125	0343	1000	0000	%0316	j02	\$
005444	-001412	-015038	0750	0562	0000	0250	0437	1000	0000	%0317	j03	\$
004824	-001062	-004011	0625	0468	0000	0375	0531	1000	0000	%0318	j04	\$
004198	-000874	-003175	0500	0375	0000	0500	0625	1000	0000	%0319	j05	\$
003682	-000621	-002451	0375	0281	0000	0625	0718	1000	0000	%0320	j06	\$
003349	-000335	-001886	0250	0187	0000	0750	0812	1000	0000	%0321	j07	\$
002629	-000201	-001156	0125	0093	0000	0875	0906	1000	0000	%0322	j08	\$
002313	-000014	-000053	0000	0000	0000	1000	1000	1000	0000	%0323	j09	\$
009685	-00088	000189	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
008577	-000250	-00401	0968	0875	1000	0031	0125	0000	0000	%0568	b11	\$
008151	-000706	-00650	0937	0750	1000	0062	0250	0000	0000	%0569	b12	\$
007337	-000899	-01008	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$
006516	-001395	-01348	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
005772	-001814	-01755	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
005006	-002283	-02257	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
004316	-00221	-02793	0781	025	1000	0217	0875	0000	0000	%0574	b17	\$
003406	-003425	-03323	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
008959	-00783	-00559	0906	1000	0875	0093	0000	0125	0000	%0576	c01	\$
008545	-00061	-000193	0875	0875	0125	0125	0125	0000	0000	%0577	c11	\$
007890	-000301	-00422	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
007038	-000701	-00744	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
006098	-001141	-01106	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
005405	-001585	-01510	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
004639	-002049	-01965	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$
003849	-002487	-02449	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
003157	-003064	-02891	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
008541	-01325	-00820	0812	1000	0750	0187	0000	0250	0000	%0585	d01	\$
008115	-00685	-00560	0781	0875	0750	0218	0125	0250	0000	%0586	d11	\$

See original or copy: <http://web.me.com/klaus.richter/HE53/HE53L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG HE43.22.TXT, Separation cmyn4*, cfi=0.90, D65, not adapted $
%100 x LAB*      %#1000 x (r g b c m y o)      %nr.      pos $
%z004657 006116 003264 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008202 -00391 007216 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z005603 -05175 001758 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005633 -04093 -02526 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z004109 000286 -03685 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z003724 003970 -02533 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z002313 -00227 000077 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009680 -00085 000195 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%z004657 006116 003264 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008202 -00391 007216 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z005603 -05175 001758 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005633 -04093 -02526 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z004109 000286 -03685 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z003724 003970 -02533 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z002313 -00227 000077 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009680 -00085 000195 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%z004657 006116 003264 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008202 -00391 007216 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z005603 -05175 001758 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005633 -04093 -02526 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z004109 000286 -03685 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z003724 003970 -02533 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z002313 -00227 000077 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009680 -00085 000195 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%z005246 004646 004380 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z008009 -02533 007038 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005551 -04925 000437 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z005181 -02824 -03612 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003804 000909 -03604 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z004192 005524 -01631 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z002383 -00222 000079 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009671 -00089 000207 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%z006090 003269 005351 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z006961 -04237 005554 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005618 -04593 -00356 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z004710 -01469 -03586 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z003223 002599 -04055 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004645 006276 000045 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z002327 -00225 000076 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009663 -00081 000193 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%z007079 001743 006359 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z006134 -05621 003969 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005667 -03914 -02031 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z004437 -00787 -03556 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z003406 003426 -03323 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004681 006074 001748 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z002230 -00219 000072 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009667 -00089 000200 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

TUB registration: 20091101-HE53/HE53L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/HE53/HE53L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

%BEG HE43.22.TXT, Separation cmy4*, cfi=0.90, D65, not adapted S										%nr. pos \$										
%100 x LAB*																				
1000 x (r g b c m y 0)																				
002094	-00214	000110	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$						%1053	m23	\$
002420	000008	000079	0125	0125	0125	0875	0875	0875	0000	%0973	k02	\$						%1054	m24	\$
003420	000014	000058	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$						%1055	m25	\$
004222	000066	000122	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$						%1056	n10	\$
005287	000076	000138	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$						%1057	n11	\$
006462	000032	000176	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$						%1058	n12	\$
007595	-00004	000100	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$						%1059	n13	\$
008563	-00058	000187	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$						%1060	n14	\$
009708	-00084	000195	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$						%1061	n15	\$
002096	-00204	000104	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$						%1062	n16	\$
002412	000013	000074	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$						%1063	n17	\$
003470	000025	000028	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$						%1064	n18	\$
004271	000079	000090	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$						%1065	n19	\$
005301	000074	000133	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$						%1066	n20	\$
006456	000039	000146	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$						%1067	n21	\$
007568	000060	000102	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$						%1068	n22	\$
008610	-00060	000186	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$						%1069	n23	\$
009704	-00088	000204	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$						%1070	n24	\$
002047	-00193	000115	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$						%1071	n25	\$
002350	000015	000084	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$						%1072	k26	\$
003387	000026	000043	0250	0250	0250	0750	0750	0750	0000	%0992	m03	\$						%1073	k27	\$
004225	000087	000101	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$						%1074	l26	\$
005161	000099	000122	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$						%1075	l27	\$
006329	000067	000165	0625	0625	0625	0375	0375	0375	0000	%0995	m06	\$						%1076	m26	\$
007538	000011	000103	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$						%1077	m27	\$
008536	-00060	000194	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$						%1078	n26	\$
009702	-00081	000190	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$						%1079	n27	\$
002050	-00183	000112	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$								
002347	000008	000088	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$						%1074	l26	%03 0 0 \$
003367	000026	000053	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$						%1076	m26	%Y3 1 0 \$
004223	000078	000124	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$						%1078	n26	%L3 2 0 \$
005212	000084	000146	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$						%1075	l27	%C3 3 0 \$
006404	000058	000179	0625	0625	0625	0375	0375	0375	0000	%1004	n06	\$						%1077	m27	%V3 4 0 \$
007562	000006	000161	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$						%1079	n27	%M3 5 0 \$
008574	-00055	000184	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$						%1072	k26	%N3 6 0 \$
009701	-00086	000189	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$						%1073	k27	%W3 7 0 \$
002266	-00221	000042	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$								
002255	-00138	000068	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$						%0972	k01	%N4 6 0 \$
002740	-00007	000108	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$						%0980	k09	%W4 7 0 \$
003097	000022	000069	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$								
003850	000023	000049	0266	0266	0266	0733	0733	0733	0000	%1012	k14	\$						%0981	l01	%N5 6 0 \$
004318	000063	000141	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$						%0989	l09	%W5 7 0 \$
004600	000026	000116	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$								
005251	-00004	000162	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$						%0990	m01	%N6 6 0 \$
005839	000034	000173	0533	0533	0533	0466	0466	0466	0000	%1016	k18	\$						%0998	m09	%W6 7 0 \$
006332	-00035	000168	0600	0600	0600	0399	0399	0399	0000	%1017	k19	\$								
006739	-00024	000216	0666	0666	0666	0333	0333	0333	0000	%1018	k20	\$						%0999	n01	%N7 6 0 \$
007388	-00010	000125	0733	0733	0733	0266	0266	0266	0000	%1019	k21	\$						%1007	n09	%W7 7 0 \$
008003	-00046	000174	0800	0800	0800	0199	0199	0199	0000	%1020	k22	\$								
008383	-00023	000187	0866	0866	0866	0133	0133	0133	0000	%1021	k23	\$								
008667	-00059	000199	0933	0933	0933	0066	0066	0066	0000	%1022	k24	\$								
009602	-00082	000190	1000	1000	1000	0000	0000	0000	0000	%1023	k25	\$								
002311	-00204	000060	0000	0000	0000	1000	1000	1000	0000	%1024	l10	\$								
002249	-00131	000075	0066	0066	0066	0933	0933	0933	0000	%1025	l11	\$								
002767	-00001	000117	0133	0133	0133	0866	0866	0866	0000	%1026	l12	\$								
003146	000027	000061	0200	0200	0200	0800	0800	0800	0000	%1027	l13	\$								
003866	000021	000047	0266	0266	0266	0733	0733	0733	0000	%1028	l14	\$								
004325	000073	000116	0333	0333	0333	0666	0666	0666	0000	%1029	l15	\$								
004585	000040	000090	0400	0400	0400	0600	0600	0600	0000	%1030	l16	\$								
005228	000011	000124	0466	0466	0466	0533	0533	0533	0000	%1031	l17	\$								
005773	000039	000149	0533	0533	0533	0466	0466	0466	0000	%1032	l18	\$								
006308	000017	000132	0600	0600	0600	0399	0399	0399	0000	%1033	l19	\$								
006690	-00013	000170	0666	0666	0666	0333	0333	0333	0000	%1034	l20	\$								
007381	000003	000108	0733	0733	0733	0266	0266	0266	0000	%1035	l21	\$								
007986	-00039	000163	0800	0800	0800	0199	0199	0199	0000	%1036	l22	\$								
008402	-00026	000167	0866	0866	0866	0133	0133	0133	0000	%1037	l23	\$								
008664	-00057	000194	0933	0933	0933	0066	0066	0066	0000	%1038	l24	\$								
009637	-00077	000178	1000	1000	1000	0000	0000	0000	0000	%1039	l25	\$								
002236	-00205	000041	0000	0000	0000	1000	1000	1000	0000	%1040	m10	\$								
002222	-00121	000071	0066	0066	0066	0933	0933	0933	0000	%1041	m11	\$								
002688	000008	000123	0133	0133	0133	0866	0866	0866	0000	%1042	m12	\$								
003011	000038	000081	0200	0200	0200	0800	0800	0800	0000	%1043	m13	\$								

%BEG HE43.22.TXT, Separation cmydn4*, cfi=0.90, D65, adapted S																																																						
%100 x LAB*a																																																						
1000 x (r g b c m y o)																																																						
%nrr. pos \$																																																						
009654	-00002	000020	1000	0000	0000	0000	0000	0000	0000	%0000	A01	\$	009710	000000	-00009	1000	1000	0000	0000	0000	0000	%0324	A10	\$	009677	000002	-00011	1000	1000	0000	0000	0000	0000	0000	0000	%0648	A19	\$																
008933	-00566	-00613	0875	1000	1000	0125	0000	0000	0000	%0001	A02	\$	008719	-00007	-00535	0875	0875	1000	0125	0125	0000	0000	%0325	A11	\$	008555	000469	-00663	1000	0875	1000	0000	0125	0000	0000	0000	0000	%0649	A20	\$														
008373	-00841	-00784	0750	1000	1000	0250	0000	0000	0000	%0002	A03	\$	008200	-00037	-00978	0750	0750	1000	0250	0250	0000	0000	%0326	A12	\$	008088	001152	-00713	1000	0750	1000	0000	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0650	A21	\$									
007790	-01172	-00907	0625	1000	1000	0375	0000	0000	0000	%0003	A04	\$	007454	-00065	-01369	0625	0625	1000	0375	0375	0000	0000	%0327	A13	\$	007383	001598	-00994	1000	0625	1000	0000	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0651	A22	\$								
007230	-01538	-01238	0500	1000	1000	0500	0000	0000	0000	%0004	A05	\$	006663	-00260	-01855	0500	0500	1000	0500	0500	0000	0000	%0328	A14	\$	006589	002138	-01274	1000	0500	1000	0000	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0652	A23	\$							
006748	-01970	-01701	0375	1000	1000	0625	0000	0000	0000	%0005	A06	\$	006042	-00154	-02324	0375	0375	1000	0625	0625	0000	0000	%0329	A15	\$	005724	002624	-01571	1000	0375	1000	0000	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0653	A24	\$						
006295	-02505	-02106	0250	1000	1000	0750	0000	0000	0000	%0006	A07	\$	005373	-00160	-02828	0250	0250	1000	0750	0750	0000	0000	%0330	A16	\$	004928	003263	-01903	1000	0250	1000	0000	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0654	A25	\$					
005795	-02868	-02385	0125	1000	1000	0875	0000	0000	0000	%0007	A08	\$	004700	-00260	-03393	0125	0125	1000	0875	0875	0000	0000	%0331	A17	\$	004401	003577	-02154	1000	0125	1000	0000	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0655	A26	\$					
005633	-03929	-02657	0000	1000	1000	1000	0000	0000	0000	%0008	A09	\$	004189	-000479	-03792	0000	0000	1000	1000	1000	0000	0000	%0332	A18	\$	003724	004171	-02633	1000	0000	1000	0000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0656	A27	\$				
008652	-000793	-000365	1000	0875	0875	0000	0125	0125	0000	%0009	B01	\$	009250	-00048	-00637	1000	1000	0875	0000	0000	0125	0000	%0333	B10	\$	008916	-00078	-00611	1000	0875	1000	0750	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0000	0000	%0657	B19	\$			
008393	-00047	-000036	0875	0875	0875	0000	0125	0125	0000	%0010	B02	\$	008570	-00049	-000014	0875	0875	0875	0125	0125	0125	0000	%0334	B11	\$	008526	-000050	-000021	0875	0875	0875	0125	0125	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0000	0000	%0658	B20	\$		
008011	-00520	-00555	0750	0875	0875	0875	0250	0125	0125	0000	%0011	B03	\$	007967	-00038	-00515	0750	0750	0875	0250	0250	0125	0000	%0335	B12	\$	007878	-000535	-00686	0875	0750	0875	0125	0250	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0000	0000	%0659	B21	\$	
007243	-00814	-00761	0625	0875	0875	0375	0125	0125	0000	%0012	B04	\$	007081	-00015	-00998	0625	0625	0875	0375	0375	0125	0000	%0336	B13	\$	007149	-001155	-00629	0875	0625	0875	0125	0375	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0000	0000	%0660	B22	\$		
006822	-01252	-00838	0500	0875	0875	0500	0125	0125	0000	%0013	B05	\$	006424	-00154	-01465	0500	0500	0875	0500	0500	0125	0000	%0337	B14	\$	006295	-001741	-01027	0875	0500	0875	0125	0500	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0000	0000	%0661	B23	\$		
006282	-01553	-01371	0375	0875	0875	0625	0125	0125	0000	%0014	B06	\$	005733	-00085	-01925	0375	0375	0875	0625	0625	0125	0000	%0338	B15	\$	005301	-002397	-01308	0875	0375	0875	0125	0625	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0000	0000	%0662	B24	\$
005761	-02019	-01844	0250	0875	0875	0750	0125	0125	0000	%0015	B07	\$	005073	-00017	-02440	0250	0250	0875	0750	0750	0125	0000	%0339	B16	\$	004511	-002933	-01656	0875	0250	0875	0125	0750	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0000	0000	%0663	B25	\$
005306	-02400	-02221	0125	0875	0875	0875	0125	0125	0000	%0016	B08	\$	004390	-00243	-02950	0125	0125	0875	0875	0875	0125	0000	%0340	B17	\$	003933	-003361	-01993	0875	0125	0875	0125	0875	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0000	0000	%0664	B26	\$
004857	-02476	-02437	0000	0875	0875	1000	0125	0125	0000	%0017	B09	\$	003808	-00333	-03294	0000	0000	0875	1000	1000	0125	0000	%0341	B18	\$	003210	-003751	-02266	0875	0000	0875	0125	1000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0125	0000	0000	0000	%0665	B27	\$
002876	-001412	-000805	1000	0750	0750	0000	0250	0250	0000	%0018	C01	\$	009122	-00018	-001675	1000	1000	0750	0000	0000	0250	0000	%0342	C10	\$	008369	-01312	-00255	0750	1000	0750	0250	0000	0250	0000	0250	0000	0250	0000	0250	0000	0250	0000	0250	0000	0250	0000	0250	0000	0000	0000	%0666	C19	\$
007815	-000764	-000190	0875	0750	0750	0125	0250	0250	0000	%0019	C02	\$	008442	-00102	-006628	0875	0875	0750	0125	0125	0250	0000	%0343	C11	\$	007953	-000606	-000105	0750	0875	0750	0250	0250	0125	0250	0000	0250	0000	0250	0000	0250	0000	0250	0000	0250	0000	0250	0000	0000	0000	%0667	C20	\$	
007480	-000156	-00063	0750	0750	0750	0250	0250	0250	0000	%0020	C03	\$	007619	-00102	-00620	0750	0750	0250	0250	0250	0250	0000	%0344	C12	\$	007563	-000133	-00047	0750	0750	0750	0250	0250	0250	0000	0250	0000	0250	0000	0250	0000	0250	0000	0250	0000	0250	0000	0250	0000	0000	0000	%0668	C21	\$
006784	-00370	-00382	0625	0750	0750	0375	0250	0250	0000	%0021	C04	\$	006817	-00017	-00311	0625	0625	0750	0375	0375	0250	0000	%0345	C13	\$	006624	-000536	-00469	0750	0625	0750	0250	0375	0250	0000	0250	0000	0250	0000	0250	0000	0250	0000	0250	0000	0250	0000	0250	0000	0000	0000	%0669	C22	\$
006384	-00785	-00691	0500	0750	0750	0500	0250	0250	0000	%0022	C05	\$	006182	-00065	-01095	0500	0500	0750	0500	0500	0250	0000	%0346	C14	\$	005867	-001209	-																										

See original or copy: <http://web.me.com/klaus.richter/HE53/HE53L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.00

[illegible]

TUB-test chart HE53; Relative Elementary Colour System C
1080 spectral reflexions R -> LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrabcOLOR
```


009652	000009	-00009	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
009870	-003018	-00638	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
008244	-004044	-00951	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
007512	-005028	-01326	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
006387	-005090	-01815	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
006370	-008081	-02303	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
005825	-011228	-02795	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
005253	-012176	-03311	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$
004740	-012291	-03701	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
008818	-000426	000731	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
008411	000045	000018	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
007912	-00239	-00702	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
007080	-00362	-01071	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
006574	-004096	-01355	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
006052	-006049	-01839	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
005513	-00976	-02345	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
004933	-01183	-02820	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
004440	-01266	-03148	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
008582	000096	001139	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
008051	000413	000516	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
007477	000139	-00037	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
006774	-00204	-00485	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
006288	-00343	-01115	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
005701	-004096	-01572	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
005161	-00807	-01919	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
004581	-00892	-02428	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
004087	-01000	-02702	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
003342	001050	002141	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
007597	000789	001180	0875	0750	0625	0125	0250	0375	0000	%0190	V02	\$
006962	000308	000611	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
006326	000188	000051	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
005906	-00240	-00593	0500	0537	0625	0500	0437	0375	0000	%0193	V05	\$
005404	-00481	-01014	0375	0500	0625	0625	0500	0375	0000	%0194	V06	\$
004823	-00625	-01554	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
004282	-00789	-01885	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
003714	-00922	-02354	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
007879	001555	002731	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
007280	001816	002021	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
006638	000770	001546	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
005937	000488	000703	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
005350	000241	000026	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
005016	-00157	-00593	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$
004496	-00412	-01168	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
003925	-00643	-01547	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
003439	-00830	-01922	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
007462	002001	003409	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
006791	001473	002619	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
006148	001215	002115	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
005519	000845	001656	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
004945	000488	000798	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
004492	000246	-00013	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
004338	-00155	-00654	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
003625	-00361	-01164	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
003038	-00498	-01581	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
006974	002702	003996	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
006329	001950	003215	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
005686	001608	002726	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
005081	001310	002108	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
004562	001095	001291	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
004260	000510	000700	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
003734	000246	-00069	0250	0250	0250	0750	0750	0750	0000	%0222	Y07	\$
003435	-00128	-00664	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
003232	-00496	-01131	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
006660	003044	004639	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
005897	002211	003681	0875	0500	0125	0125	0625	0875	0000	%0226	Z02	\$
005344	001883	003142	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
004692	001713	002628	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
004191	001266	002093	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
003836	001060	001345	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
003463	000545	000656	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
002770	000230	-00039	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
002772	-00018	-00547	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$
000990	003420	005214	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
005412	002767	004442	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
004863	002649	004055	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
004295	002149	003284	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
003812	001645	002499	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
003437	001330	002000	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
002989	001164	001406	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
002557	000509	000878	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$
002419	000004	-00011	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009672	-000010	-000019	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
008549	000259	-00569	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
008070	000557	-00928	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
007220	000709	-01350	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
006336	001145	-01743	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
005591	001332	-02338	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
004861	001703	-02896	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
004025	000803	-03481	0562	0250	1000	0437	0875	0000	0000	%0493	S17	\$
003222	002807	-04145	0500	0000	1000	0500	1000	0000	0000	%0494	S18	\$
000913	-00524	-00646	0937	1000	0875	0062	0000	0125	0000	%0495	T10	\$
008596	000041	000015	0875	0875	0875	0125	0125	0125	0000	%0496	T11	\$
007910	000272	-00584	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
006953	000578	-01003	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
006135	000929	-01403	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
005379	001204	-01890	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
004615	001519	-02391	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
003779	002033	-03018	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
003138	-002215	-03371	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
008802	-00887	000938	0875	1000	0750	0125	0000	0250	0000	%0504	U10	\$
008231	-00343	000346	0812	0875	0750	0187	0125	0250	0000	%0505	U11	\$
007609	000114	-00036	0750	0750	0750	0250	0250					

TUB registration: 20091101-HE53/HE53L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/HE53/HE53L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.00

[illegible]

TUB-test chart HE53; Relative Elementary Colour System CIE
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/HE53/HE53L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG HE43.22.TXT, Separation cmyn4*, cfi=0.90, D65, adapted S
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr.   pos $
%Z004657 006298 003149 000000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008202 -00276 007045 000000 0000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005603 -05011 001628 000000 0000 0000 0000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005633 -03929 -02657 000000 0000 0000 0000 0000 0000 0000 %0008 A09 %C1 3 $
%Z004109 000479 -03792 000000 0000 0000 0000 0000 0000 0000 %0332 A18 %V1 4 $
%Z003724 004171 -02633 000000 0000 0000 0000 0000 0000 0000 %0656 A27 %M1 5 $
%Z002313 000000 000000 000000 0000 0000 0000 0000 0000 0000 %0080 I09 %N1 6 $
%Z009680 000000 000000 000000 0000 0000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004657 006298 003149 000000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008202 -00276 007045 000000 0000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005603 -05011 001628 000000 0000 0000 0000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005633 -03929 -02657 000000 0000 0000 0000 0000 0000 0000 %0008 A09 %C2 3 $
%Z004109 000479 -03792 000000 0000 0000 0000 0000 0000 0000 %0332 A18 %V2 4 $
%Z003724 004171 -02633 000000 0000 0000 0000 0000 0000 0000 %0656 A27 %M2 5 $
%Z002313 000000 000000 000000 0000 0000 0000 0000 0000 0000 %0080 I09 %N2 6 $
%Z009680 000000 000000 000000 0000 0000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004657 006298 003149 000000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008202 -00276 007045 000000 0000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005603 -05011 001628 000000 0000 0000 0000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005633 -03929 -02657 000000 0000 0000 0000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z004109 000479 -03792 000000 0000 0000 0000 0000 0000 0000 %0332 A18 %V00M 4 $
%Z003724 004171 -02633 000000 0000 0000 0000 0000 0000 0000 %0656 A27 %M000 5 $
%Z002313 000000 000000 000000 0000 0000 0000 0000 0000 0000 %0080 I09 %N001 6 $
%Z009680 000000 000000 000000 0000 0000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005246 004816 004250 000000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008009 -02414 006859 000000 0750 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005551 -04760 000301 000000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005181 -02653 -03741 000000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003804 001196 -03708 000000 0000 0750 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004192 005713 -01742 000000 0750 0000 1000 0250 0000 0000 %0737 J27 %M250 5 $
%Z002383 000000 000000 000000 0000 0000 1000 1000 0000 0000 %0161 R09 %N251 6 $
%Z009671 000000 000000 000000 0000 0000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z006090 003420 005214 000000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006961 -04103 005404 000000 0500 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005618 -04432 -00485 000000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004710 -01291 -03701 000000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003223 002807 -04146 000000 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004645 006456 -00068 000000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z002327 000000 000000 000000 0000 0000 1000 1000 0000 0000 %0242 a09 %N501 6 $
%Z009663 000000 000000 000000 0000 0000 1000 1000 0000 0000 %0162 S01 %M501 7 $
%S
%Z007079 001878 006203 000000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006134 -05470 003829 000000 0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005667 -03754 -02163 000000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z004437 -00606 -03666 000000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003406 003625 -03416 000000 0750 0000 1000 0250 0000 0000 %0575 b18 %V75M 4 $
%Z004681 006250 001634 000000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z002230 000000 000000 000000 0000 0000 1000 1000 0000 0000 %0323 j09 %N751 6 $
%Z009667 000000 000000 000000 0000 0000 1000 1000 0000 0000 %0243 b01 %M751 7 $
%S
```



```
%BEG HE43.22.TXT, Separation cmy4*, cfi=0.90, D65, adapted S
%100 x LAB*a      1000 x (r g b   c m y 0)      %nrr. pos $
002094 000020 000015 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002420 000237 -00019 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003420 000223 -00054 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004222 000260 -00002 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005287 000250 -00001 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006462 000183 000020 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
007595 000124 -00071 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008563 000051 000091 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009705 000004 000015 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
002096 000030 -00009 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002412 000242 -00024 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003470 000234 -00085 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004271 000272 -00035 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005301 000247 -00005 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006456 000199 -00009 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
007568 000128 -00069 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
008618 000049 000000 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009704 000000 000003 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
002047 000041 000020 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002350 000245 -00013 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003387 000236 -00069 0250 0250 0250 0750 0750 0750 0000 %0992 k03 $
004225 000281 -00023 0375 0375 0375 0625 0625 0625 0000 %0993 k04 $
005161 000275 -00015 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006329 000220 00011 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
007538 000142 -00067 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
008536 000050 000009 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009702 000006 -00010 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
002050 000051 000018 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002347 000238 -00009 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003367 000237 -00058 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004223 000272 000000 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005212 000259 000008 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006404 000202 000024 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
007562 000136 000070 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008574 000055 000000 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009701 000002 00011 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
002266 000009 -00054 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
002255 000092 -00028 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002740 000215 000004 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
003097 000238 -00039 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
003850 000224 -00070 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
004318 000255 000015 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
004600 000213 -00013 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005251 000169 000023 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
005839 000197 000026 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006332 000118 000014 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
006739 000120 000056 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007388 000122 -00043 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
008003 000074 -00003 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
008383 000090 000004 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
008667 000049 000012 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009602 000008 -00010 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
002311 000025 -00037 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
002249 000100 000021 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
002767 000220 000013 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
003146 000242 -00047 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
003866 000222 -00072 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
004325 000209 000009 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
004585 000227 -00039 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005228 000185 -00014 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
005773 000203 000002 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006308 000135 -00021 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
006690 000133 000011 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007381 000137 -00060 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
007986 000081 -00013 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
008402 000086 -00016 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
008664 000051 000007 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009637 000012 -00021 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
002236 000026 -00055 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
002222 000110 -00025 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002688 000231 000020 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
003011 000256 -00025 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
003788 000237 -00057 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
004231 000269 000022 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
004495 000238 -00022 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005175 000187 000035 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
005673 000217 000033 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006173 000135 000034 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
006574 000143 000047 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007275 000145 -00042 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
007902 000086 -00004 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

%BEG HE43.22.TXT, Separation cmydn4*, cfi=0.90, D50, not adapted S																			
%100 x LAB*																			
1000 x (r g b c m y 0)																			
adaptd S																			
%nr. pos \$																			
0009656	-00057	000208	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0008910	-00096	-00488	0875	1000	1000	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0008341	-01017	-00685	0750	1000	1000	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0007748	-01372	-00844	0625	1000	1000	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0007174	-01794	-01216	0500	1000	1000	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0006673	-02306	-01728	0375	1000	1000	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0006199	-02929	-02186	0250	1000	1000	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0005685	-03271	-02594	0125	1000	1000	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0005494	-04541	-02851	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0008673	000015	000566	1000	0875	0875	0000	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0008395	000033	000296	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0007990	000668	-00440	0750	0875	0875	0250	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0007211	-01010	-00680	0625	0875	0875	0375	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0006779	-01463	-00796	0500	0875	0875	0500	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0006222	-01851	-01370	0375	0875	0875	0625	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0005681	-02411	-01895	0250	0875	0875	0750	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0005209	-02885	-02315	0125	0875	0875	0875	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0004752	-03030	-02551	0000	0875	0875	1000	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0008316	001512	001027	1000	0750	0750	0000	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0007833	000739	000377	0875	0750	0750	0125	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0007482	000047	000096	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0006769	-00533	-00272	0625	0750	0750	0375	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0006354	-00986	-00623	0500	0750	0750	0500	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0005843	-01500	-00924	0375	0750	0750	0625	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0005307	-01982	-01484	0250	0750	0750	0750	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0004792	-02378	-01859	0125	0750	0750	0875	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0004285	-02828	-01984	0000	0750	0750	1000	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0007729	002532	001215	1000	0625	0625	0000	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0007293	001556	000885	0875	0625	0625	0125	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0006773	000803	000470	0750	0625	0625	0250	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0006366	000100	000201	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0005958	-00563	-00310	0500	0625	0625	0500	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0005462	-01000	-00696	0375	0625	0625	0625	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0004925	-01613	-01226	0250	0625	0625	0750	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0004503	-01884	-01494	0125	0625	0625	0875	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0003941	-02379	-01995	0000	0625	0625	1000	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0007188	000326	001810	1000	0500	0500	0000	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0006677	002283	001320	0875	0500	0500	0125	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0006243	001577	001090	0750	0500	0500	0250	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0005683	000948	000612	0625	0500	0500	0375	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0005287	000128	000142	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0005009	-00536	-00323	0375	0500	0500	0625	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0004492	-01032	-00798	0250	0500	0500	0750	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0004055	-01477	-01325	0125	0500	0500	0875	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0003525	-01958	-01522	0000	0500	0500	1000	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0006637	004166	002226	1000	0375	0375	0000	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0006073	003075	001672	0875	0375	0375	0125	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0005643	002348	001459	0750	0375	0375	0250	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0005143	001649	001151	0625	0375	0375	0375	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0004786	000856	000567	0500	0375	0375	0500	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0004492	000999	000113	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0004316	-00554	-00470	0250	0375	0375	0750	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0003682	-00969	-00777	0125	0375	0375	0875	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0003137	-01624	-01137	0000	0375	0375	1000	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0006088	004865	002607	1000	0250	0250	0000	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0005430	003809	001985	0875	0250	02														

TUB registration: 20091101-HE53/HE53L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

TUB-test chart HE53; Relative Elementary Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/HE53/HE53L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.00

See original or copy: <http://web.me.com/klaus.richter/HE53/HE53L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.00

TUB registration: 20091101-HEE53/HEE53LONA.TXT /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

[illegible]

TUB-test chart HE53; Relative Elementary Colour System C
1080 spectral reflexions R -> LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/HE53/HE53L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.00

TUB registration: 20091101-HE53/HE53L0NA.TXT/.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

[illegible]

TUB-test chart HE53; Relative Elementary Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

Job Material: Code-M44a

See original or copy: <http://web.me.com/klaus.richter/HE53/HE53L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG HE43.22.TXT, Separation cmyn4*, cfi=0.90, D50, not adapted $
%100 x LAB*      %1000 x (r g b c m y o)      %nr.      pos $
%Z004843 006451 003564 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008262 000234 007095 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005522 -04910 001447 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005494 -04541 -02851 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z004027 -00186 -03825 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z003770 003834 -02403 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z002309 -00212 000063 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009681 -00056 000188 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004843 006451 003564 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008262 000234 007095 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005522 -04910 001447 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005494 -04541 -02851 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z004027 -00186 -03825 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z003770 003834 -02403 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z002309 -00212 000063 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009681 -00056 000188 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004843 006451 003564 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008262 000234 007095 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005522 -04910 001447 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005494 -04541 -02851 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z004027 -00186 -03825 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z003770 003834 -02403 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z002309 -00212 000063 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009681 -00056 000188 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005397 005094 004557 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008025 -01937 006805 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005457 -04837 000136 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005038 -03489 -03912 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003741 000584 -03701 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004302 005497 -01372 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z002379 -00207 000065 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009672 -00058 000200 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z006213 003804 005428 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006932 -03680 005241 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005516 -04627 -00649 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004595 -02053 -03809 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003184 002156 -04084 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004804 006405 000378 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z002323 -00210 000062 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009664 -00052 000186 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z007174 002346 006342 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006069 -05142 003605 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005543 -04251 -02326 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z004336 -01315 -03743 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003415 003158 -03260 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004853 006334 002065 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z002226 -00204 000058 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009668 -00059 000193 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```


See original or copy: <http://web.me.com/klaus.richter/HE53/HE53L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cf1=0.90; nt=0.18; nx=1.0.

TUB registration: 20091101-HE53/HE53L0NA.TXT/.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

KBEG HE43 22.TXT, Separation cmyu4*, cf1=0.90, D50, not adapted \$																						
%100 x LAB*	1000 x (r g b			c m y 0)			%kn	pos \$														
002091	-00195	000097	0000	0000	1000	1000	0000	%0972	k01 \$	008356	000014	000168	0866	0866	0866	0133	0133	0133	0000	%1053	m23 \$	
002422	000020	000080	0125	0125	0125	0875	0875	0000	%0973	k02 \$	008629	-00031	000213	0933	0933	0933	0666	0666	0666	0000	%1054	m24 \$
003421	000025	000059	0250	0250	0250	0750	0750	0000	%0974	k03 \$	009628	-00055	000198	1000	1000	1000	0000	0000	0000	0000	%1055	m25 \$
004225	000089	000125	0375	0375	0375	0625	0625	0000	%0975	k04 \$	002232	-00195	000025	0000	0000	0000	1000	1000	1000	0000	%1056	n10 \$
005291	000164	000141	0500	0500	0500	0500	0500	0000	%0976	k05 \$	002249	-00113	000073	0066	0066	0066	0933	0933	0933	0000	%1057	n11 \$
006465	000084	000176	0625	0625	0625	0375	0375	0000	%0977	k06 \$	002684	000017	000127	0133	0133	0133	0866	0866	0866	0000	%1058	n12 \$
007596	000012	000099	0750	0750	0750	0250	0250	0000	%0978	k07 \$	003087	000048	000086	0200	0200	0200	0800	0800	0800	0000	%1059	n13 \$
008564	-00032	000183	0875	0875	0875	0125	0125	0000	%0979	k08 \$	003798	000038	000066	0266	0266	0266	0733	0733	0733	0000	%1060	n14 \$
009709	-00057	000179	1000	1000	1000	0000	0000	0000	%0980	00 \$	004252	000098	000154	0333	0333	0333	0666	0666	0666	0000	%1061	n15 \$
002093	-00186	000091	0000	0000	0000	1000	1000	0000	%0981	l01 \$	004487	000061	000124	0400	0400	0400	0600	0600	0600	0000	%1062	n16 \$
002414	000025	000076	0125	0125	0125	0875	0875	0000	%0982	l02 \$	005205	000032	000190	0466	0466	0466	0533	0533	0533	0000	%1063	n17 \$
003471	000032	000030	0250	0250	0250	0750	0750	0000	%0983	l03 \$	005727	000078	000220	0533	0533	0533	0466	0466	0466	0000	%1064	n18 \$
004274	000099	000093	0375	0375	0375	0625	0625	0000	%0984	l04 \$	006240	-00003	000219	0600	0600	0600	0399	0399	0399	0000	%1065	n19 \$
005305	000101	000136	0500	0500	0500	0500	0500	0000	%0985	l05 \$	006680	000023	000209	0666	0666	0666	0333	0333	0333	0000	%1066	n20 \$
006459	000067	000146	0625	0625	0625	0375	0375	0000	%0986	l06 \$	007322	000034	000116	0733	0733	0733	0266	0266	0266	0000	%1067	n21 \$
007570	000016	000101	0750	0750	0750	0250	0250	0000	%0987	l07 \$	007949	-00014	000175	0800	0800	0800	0199	0199	0199	0000	%1068	n22 \$
008611	-00033	000181	0875	0875	0875	0125	0125	0000	%0988	l08 \$	008378	000026	000217	0866	0866	0866	0133	0133	0133	0000	%1069	n23 \$
009705	-00058	000197	1000	1000	1000	0000	0000	0000	%0989	l09 \$	008667	-00029	000211	0933	0933	0933	0666	0666	0666	0000	%1070	n24 \$
002044	-00175																					

TUB-test chart HE53; Relative Elementary Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

%BEG HE43.22.TXT, Separation cmydn4*, cfi=0.90, D50, adapted S																										
%100 x LAB*a																										
000020 1000 1000 1000 0000 0000 0000 0000 0000 0000																										
1000 x (r g b c m y o)																										
%nrr. pos \$																										
0009656	0000000	0000020	1000	1000	1000	0000	0000	0000	0000	%0000	A01	\$	0009710	-00001	-00009	1000	1000	1000	0000	0000	0000	%0024	A10	\$		
0008910	-00622	-00663	0875	1000	0000	0125	0000	0000	0000	%0001	A02	\$	0008711	-00057	-00547	0875	0875	1000	0125	0125	0000	0000	%0025	A11	\$	
0008341	-00932	-00850	0750	1000	1000	0250	0000	0000	0000	%0002	A03	\$	0008183	-00132	-01004	0750	0750	1000	0250	0250	0000	0000	%0026	A12	\$	
0007748	-01274	-00999	0625	1000	1000	0375	0000	0000	0000	%0003	A04	\$	0007430	-00965	-01402	0625	0625	1000	0375	0375	0000	0000	%0027	A13	\$	
0007174	-01685	-01362	0500	1000	1000	0500	0000	0000	0000	%0004	A05	\$	0006633	-00084	-01890	0500	0500	1000	0500	0500	0000	0000	%0028	A14	\$	
0006673	-02185	-01865	0375	1000	1000	0625	0000	0000	0000	%0005	A06	\$	0005998	-00084	-02389	0375	0375	1000	0625	0625	0000	0000	%0029	A15	\$	
0006199	-02799	-02315	0250	1000	1000	0750	0000	0000	0000	%0006	A07	\$	0005316	-00152	-02916	0250	0250	1000	0750	0750	0000	0000	%0030	A16	\$	
0005685	-03233	-02624	0125	1000	1000	0875	0000	0000	0000	%0007	A08	\$	0004628	-00149	-03505	0125	0125	1000	0875	0875	0000	0000	%0031	A17	\$	
0005494	-04396	-02968	0000	1000	1000	1000	0000	0000	0000	%0008	A09	\$	0004027	-00010	-03917	0000	0000	1000	1000	1000	0000	0000	%0032	A18	\$	
0008673	0000953	000395	1000	0875	0875	0000	0125	0125	0000	%0009	B01	\$	0002960	000145	000636	1000	1000	0875	0000	0000	0125	0000	%0033	B10	\$	
0008395	0000600	000040	0875	0875	0875	0125	0125	0125	0000	%0010	B02	\$	0008572	000049	000018	0875	0875	0125	0125	0125	0000	%0034	B11	\$		
0007990	-00576	-00509	0750	0875	0875	0250	0125	0125	0000	%0011	B03	\$	0007958	-00089	-00528	0750	0750	0250	0250	0125	0000	%0035	B12	\$		
0007211	-00901	-00826	0625	0875	0875	0375	0125	0125	0000	%0012	B04	\$	0007063	-00115	-01023	0625	0625	0875	0375	0125	0000	%0036	B13	\$		
0006779	-01345	-00935	0500	0875	0875	0500	0125	0125	0000	%0013	B05	\$	0006400	-00013	-01496	0500	0500	0875	0500	0500	0125	0000	%0037	B14	\$	
0006222	-01721	-01499	0375	0875	0875	0625	0125	0125	0000	%0014	B06	\$	0005697	-00113	-01978	0375	0375	0875	0625	0625	0125	0000	%0038	B15	\$	
0005681	-02270	-02015	0250	0875	0875	0750	0125	0125	0000	%0015	B07	\$	0005021	-00292	-02520	0250	0250	0875	0750	0750	0125	0000	%0039	B16	\$	
0005209	-02734	-02427	0125	0875	0875	0875	0125	0125	0000	%0016	B08	\$	0004329	-00104	-03042	0125	0125	0875	0875	0875	0125	0000	%0040	B17	\$	
0004752	-02870	-02656	0000	0875	0875	1000	0125	0125	0000	%0017	B09	\$	0003736	-00085	-03402	0000	0000	0875	1000	1000	0125	0000	%0041	B18	\$	
0003816	001508	000862	1000	0750	0750	0000	0250	0250	0000	%0018	C01	\$	0009144	000247	001668	1000	1000	0750	0000	0000	0250	0000	%0042	C10	\$	
0007433	0000835	000220	0875	0750	0750	0125	0250	0250	0000	%0019	C02	\$	0008453	000198	000630	0875	0875	0750	0125	0125	0250	0000	%0043	C11	\$	
0007882	000150	-00054	0750	0750	0750	0250	0250	0250	0000	%0020	C03	\$	0007621	000099	-00013	0750	0750	0250	0250	0250	0000	%0044	C12	\$		
0006769	-00414	-00410	0625	0750	0750	0375	0250	0250	0000	%0021	C04	\$	0006812	-00018	-00313	0625	0625	0750	0375	0375	0250	0000	%0045	C13	\$	
0006354	-00859	-00755	0500	0750	0750	0500	0250	0250	0000	%0022	C05	\$	0006163	-00044	-01118	0500	0500	0750	0500	0250	0250	0000	%0046	C14	\$	
0005843	-01362	-01047	0375	0750	0750	0625	0250	0250	0000	%0023	C06	\$	0005430	-00095	-01506	0375	0375	0750	0625	0625	0250	0000	%0047	C15	\$	
0005307	-01833	-01598	0250	0750	0750	0750	0250	0250	0000	%0024	C07	\$	0004719	-00074	-02060	0250	0250	0750	0750	0250	0250	0000	%0048	C16	\$	
0004792	-02218	-01965	0125	0750	0750	0875	0250	0250	0000	%0025	C08	\$	0004205	-00116	-02500	0125	0125	0750	0875	0875	0250	0000	%0049	C17	\$	
0004285	-02658	-02081	0000	0750	0750	1000	0250	0250	0000	%0026	C09	\$	0003582	-00182	-02893	0000	0000	0750	1000	1000	0250	0000	%0050	C18	\$	
0007729	002638	001060	1000	0625	0625	0000	0375	0375	0000	%0027	D01	\$	0009032	002625	002488	1000	1000	0625	0000	0000	0375	0000	%0051	D10	\$	
0007293	001664	000738	0875	0625	0625	0125	0375	0375	0000	%0028	D02	\$	0008254	000193	000154	0875	0875	0625	0125	0125	0375	0000	%0052	D11	\$	
0006773	001001	000331	0750	0625	0625	0250	0375	0375	0000	%0029	D03	\$	0007405	000125	000659	0750	0750	0625	0250	0375	0375	0000	%0053	D12	\$	
0006368	000227	-00069	0625	0625	0625	0375	0375	0375	0000	%0030	D04	\$	0006523	000174	000015	0625	0625	0625	0375	0375	0375	0000	%0054	D13	\$	
0005958	-00427	-00435	0500	0625	0625	0500	0375	0375	0000	%0031	D05	\$	0005920	000074	-00475	0500	0500	0625	0500	0375	0375	0000	%0055	D14	\$	
0005462	-00854	-00813	0375	0625	0625	0625	0375	0375	0000	%0032	D06	\$	0005106	000036	-01200	0375	0375	0625	0625	0375	0625	0375	0000	%0056	D15	\$
0004925	-01456	-01333	0250	0625	0625	0750	0375	0375	0000	%0033	D07	\$	0004196	-00033	-01699	0250	0250	0750	0375	0375	0375	0000	%0057	D16	\$	
0004503	-01718	-01504	0125	0625	0625	0875	0375	0375	0000	%0034	D08	\$	0003911	-00033	-02055	0125	0125	0625	0875	0875	0375	0000	%0058	D17	\$	
0003941	-02201	-02086	0000	0625	0625	1000	0375	0375	0000	%0035	D09	\$	0003243	-00129	-02478	0000	0000	0625	1000	1000	0375	0000	%0059	D18	\$	
0007188	000343	001664	1000	0500	0500	0000	0500	0500	0000	%0036	E01	\$	0008867	000369	003211	1000	1000	0500	0000	0000	0500	0000	%0060	E10	\$	
0006677	002404	001183	0875	0500	0500	0125	0500	0500	0000	%0037	E02	\$	0008166	000199	002615	0875	0875	0500	0125	0125	0500	0000	%0061	E11	\$	
0006243	001707	000961	0750	0500	0500	0250	0500	0500	0000	%0038	E03	\$	0007224	000245	001893	0750	0750	0500	0250	0250	0500	0000	%0062	E12	\$	
0005683	001099	000491	0625	0500	0500	0375	0500	0500	0000	%0039	E04	\$	0006731	000180	000860	0625	0625	0500	0375	0375	0500	0000	%0063	E13	\$	
0005287	000278	000028	0500	0500	0500	0500	0500	0500	0000	%0040	E05	\$	0005399	000256	000026	0500	0500	0500	0500	0500	0500	0000	%0064	E14	\$	
0005009	-00380	-00432	0375	0500	0500	0625	0500	0500	0000	%0041	E06	\$	0004933	000098	-00613	0375	0375	0500	0625	0625	0500	0000	%0065	E15	\$	
0004492	-00866	-00898	0250	0500	0500	0750	0500	0500	0000	%0042	E07	\$	0004389	000044	-01197	0250	0250	0500	0750	0750	0500	0000	%0066	E16	\$	
0004055	-01301	-01418	0125	0500	0500	0875	0500	0500	0000	%0043	E08	\$	0003662	-00014	-01764	0125	0125	0500	0875	0875	0500	0000	%0067	E17	\$	
0003525	-01771	-01606	0000	05																						

See original or copy: <http://web.me.com/klaus.richter/HE53/HE53L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.00

TUB registration: 20091101-HE53/HE53L0NA.TXT /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

008649	009007	009001	1000	1000	1000	0000	0000	0000	0000	#0081	J01 \$	009692	-000081	-000009	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0279	J19				
008649	-00476	-08085	0875	0968	1000	0125	0031	0000	0000	#0082	J02 \$	009692	-000081	-000524	0906	0875	1000	0093	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0279	J20			
008322	002728	-013101	0750	0937	1000	0250	0062	0000	0000	#0083	J03 \$	008114	0100113	-009883	0812	0750	1000	0817	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0731	J21			
007740	-011333	-010833	0625	0906	1000	0375	0093	0000	0000	#0084	J04 \$	007279	000387	-013393	0718	0625	1000	0281	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0732	J22		
007169	-014719	-017193	0500	0875	1000	0500	0125	0000	0000	#0085	J05 \$	006474	000478	-018806	0625	0500	1000	0375	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0733	J23		
006663	-01908	-02460	0375	0843	1000	0625	0156	0000	0000	#0086	J06 \$	005806	006560	-023237	0531	0375	1000	0468	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0734	J24		
006083	-02501	-02983	0250	0812	1000	0750	0187	0000	0000	#0087	J07 \$	005108	008582	-02895	0437	0250	1000	0562	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0735	J25	
005693	-02887	-03306	0125	0871	1000	0875	0218	0000	0000	#0088	J08 \$	004269	008773	-03548	0343	0125	1000	0656	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0736	J26	
005038	-03335	-04026	0000	0750	1000	1000	0250	0000	0000	#0089	J09 \$	007374	007673	-03792	0250	0000	1000	0750	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0737	J27	
008762	000818	000546	1000	0906	0875	0000	0093	0125	0000	#0090	K01 \$	009398	-00177	000675	0608	1000	0875	0031	0000	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0738	J19	
008428	000053	000006	0875	0875	0875	0125	0125	0125	0000	#0091	K02 \$	008592	000045	-000026	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0739	K20
007952	-00519	-00751	0750	0843	0875	0250	0156	0125	0000	#0092	K03 \$	007898	000055	-00618	0871	0750	0875	0218	0250	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	%0740	K21
007174	-00813	-01036																																			

TUB-test chart HE53; Relative Elementary Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> oly* setrgbcolor
```


009637	-00001	000019	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$	009686	-00001	-00011	1000	1000	1000	0000	0000	0000	%0567	b10	\$	009681	000002	-00008	1000	1000	1000	0000	0000	0000	0000	%0891	b19	\$		
009854	-00223	-00550	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$	009857	000318	-00579	0888	0875	1000	0031	0125	0000	0000	%0568	b11	\$	009879	000951	-00009	1000	0875	0906	0000	0125	0093	0000	%0892	b20	\$	
008021	-00216	-01054	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$	008154	000777	-00804	0937	0750	1000	0062	0250	0000	0000	%0569	b12	\$	008323	010621	-00506	1000	0750	0812	0000	0250	0187	0000	%0893	b21	\$	
007335	-00320	-01412	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$	007338	000961	-01147	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$	007902	002474	-00620	1000	0625	0718	0000	0375	0281	0000	%0894	b22	\$	
006706	-00362	-01817	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$	006522	001460	-01458	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$	007337	003360	-00819	1000	0500	0625	0000	0500	0375	0000	%0895	b23	\$	
006154	-00492	-02305	0375	0531	1000	0625	0478	0000	0000	%0248	b06	\$	005779	001869	-01844	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$	006634	004252	-00119	1000	0375	0531	0000	0625	0468	0000	%0896	b24	\$	
005495	-00754	-02844	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$	005013	002309	-02352	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$	006017	004980	-00145	1000	0250	0437	0000	0750	0562	0000	%0897	b25	\$	
004892	-01051	-03426	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$	004318	002596	-02852	0781	025	1000	0218	0875	0000	0000	%0574	b17	\$	005456	005535	-00164	1000	0125	0343	0000	0875	0556	0000	%0898	b26	\$	
004336	-01151	-03340	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$	003415	003340	-03341	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$	004853	006458	-00195	1000	0000	0250	1000	0750	0556	0000	%0899	b27	\$	
008947	-00040	-00078	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$	008949	-00629	-00032	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$	008909	-00639	-00471	0875	1000	0968	0125	0000	0031	0000	%0900	c10	\$	
008404	-00046	-000035	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$	008546	-00047	-000015	0875	0875	0125	0125	0125	0125	0000	%0577	c11	\$	008493	000053	-000026	0875	0875	0875	0125	0125	0125	0000	%0901	c20	\$	
007856	-00168	-00642	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$	007889	000381	-00584	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$	007880	000969	-000020	0875	0750	0781	0125	0250	0218	0000	%0902	c21	\$	
006971	-00170	-01091	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$	007940	000782	-00878	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$	007289	011682	-000463	0875	0625	0687	0125	0375	0312	0000	%0903	c22	\$	
006412	-00270	-01472	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$	006103	001226	-01213	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$	006656	002482	-000541	0875	0500	0593	0125	0500	0406	0000	%0904	c23	\$	
005839	-00438	-01941	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$	005412	001663	-01595	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$	005960	003262	-000716	0875	0375	0500	0125	0625	0500	0000	%0905	c24	\$	
005212	-00737	-02363	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$	004647	002107	-02029	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$	005331	004012	-001074	0875	0250	0406	0125	0750	0593	0000	%0906	c25	\$	
004509	-00780	-02963	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$	003856	002509	-02494	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$	004812	004682	-001341	0875	0125	0312	0125	0750	0687	0000	%0907	c26	\$	
003987	-00860	-03333	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$	003167	003036	-02908	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$	004192	005702	-001802	0875	0000	0218	0125	1000	0781	0000	%0908	c27	\$	
008795	-000796	-001318	1000	0937	0750	0000	0602	0250	0000	%0261	d01	\$	008523	-01123	-00564	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$	008360	-01042	-00562	0750	1000	0937	0250	0000	0062	0000	%0909	d19	\$	
008171	000376	000501	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$	008108	-00516	-000352	0781	0875	0750	0218	0125	0250	0000	%0586	d11	\$	007963	-00591	-00515	0750	0875	0843	0250	0125	0156	0000	%0910	d20	\$	
007479	000125	-00049	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$	007593	000122	-00029	0750	0750	0250	0250	0250	0250	0000	%0587	d12	\$	007526	000142	-00046	0750	0750	0750	0250	0250	0250	0000	%0911	d21	\$	
006715	-00091	-00415	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$	006698	000325	-00396	0718	0625	0750	0281	0375	0250	0000	%0588	d13	\$	006816	000998	-000181	0750	0625	0656	0250	0375	0343	0000	%0912	d22	\$	
006164	-00264	-01139	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$	005968	000802	-00882	0687	0500	0750	0312	0500	0250	0000	%0589	d14	\$	006204	001755	-000532	0750	0500	0562	0250	0500	0437	0000	%0913	d23	\$	
005543	-00373	-01565	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$	005188	001225	-01176	0656	0375	0750	0343	0625	0250	0000	%0590	d15	\$	005532	002531	-000823	0750	0375	0468	0250	0625	0531	0000	%0914	d24	\$	
004877	-00650	-02017	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$	004474	001665	-01547	0625	0250	0750	0375	0750	0250	0000	%0591	d16	\$	004824	003280	-001953	0750	0250	0375	0250	0750	0625	0000	%0915	d25	\$	
004326	-00658	-02515	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$	003743	002142	-02170	0593	0125	0750	0406	0875	0250	0000	%0592	d17	\$	004183	004166	-001241	0750	0125	0281	0250	0875	0718	0000	%0916	d26	\$	
003807	-00853	-02861	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$	002962	002464	-02529	0562	0000	0750	0437	1000	0250	0000	%0593	d18	\$	003607	004939	-001635	0750	0000	0187	0250	1000	0812	0000	%0917	d27	\$	
008677	000905	002363	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$	008177	-01754	-001404	0718	1000	0625	0281	0000	0375	0000	%0594	e10	\$	007708	-01376	-00480	0625	1000	0906	0375	0000	0093	0000	%0918	e19	\$	
007908	000565	001375	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$	007551	-01147	-001833	0687	0875	0625	0312	0125	0375	0000	%0595	e11	\$	007267	-00957	-00435	0625	0875	0812	0375	0125	0187	0000	%0919	e20	\$	
007106	000344	-000656	0750	0718	0875	0625	0250	0281	0375	0000	%0272	e03	\$	006967	-00474	-000438	0656	0750	0625	0343	0250	0375	0000	%0596	e12	\$	006768	-00349	-00203	0625	0750	0718	0375	0250	0281	0000	%0920	e21	\$
006367	-00023	-00048	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$	006597	000184	-000822	0625	0625	0625	0375	0375	0375	0000	%0597	e13	\$	006327	-000214	-000089	0625	0625	0625	0375	0375	0375	0000	%0921	e22	\$	
005889	-00037	-00540	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$	005778	-00041	-00523	0593	0500	0625	0406	0500	0375	0000	%0598	e14	\$	005630	001016	-000363	0625	0500	0531	0375	0000	0468	0000	%0922	e23	\$	
005325	-00314	-01115	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$	005018	-00057	-00096	0562	0375	0625	0437	0625	0375	0000	%0599	e15	\$	004959	001828	-000659	0625	0375	0437	0375	0625	0562	0000	%0923	e24	\$	
004588	-00369	-01618	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$	004261	001248	-01149	0531	0250	0625	0468	0750	0375	0000	%0600	e16	\$	004254	002611	-000859	0625	0250	0343	0375	0750	0656	0000	%0924	e25	\$	
004058	-00597	-02002	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$	003696	001617	-01583	0500	0125	062																					

See original or copy: <http://web.me.com/klaus.richter/HE53/HE53L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG HE43.22.TXT, Separation cmyn4*, cfi=0.90, D50, adapted S
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr.   pos $
%Z004843 006609 003457 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008262 000321 006931 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005522 -04766 001330 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005494 -04396 -02968 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z004027 -00010 -03917 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z003770 004016 -02491 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z002309 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009681 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004843 006609 003457 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008262 000321 006931 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005522 -04766 001330 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005494 -04396 -02968 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z004027 -00010 -03917 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z003770 004016 -02491 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z002309 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009681 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004843 006609 003457 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008262 000321 006931 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005522 -04766 001330 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005494 -04396 -02968 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z004027 -00010 -03917 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z003770 004016 -02491 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z002309 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009681 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005397 005239 004435 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008025 -01845 006635 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005457 -04693 000014 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005038 -03335 -04026 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003741 000763 -03792 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004302 005665 -01473 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z002379 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009672 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z006213 003931 005300 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006932 -03569 005101 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005516 -04486 -00766 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004595 -01892 -03910 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003184 002347 -04161 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004804 006561 000274 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z002323 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009664 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z007174 002454 006193 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006069 -05012 003476 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005543 -04111 -02445 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z004336 -01151 -03840 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003415 003340 -03341 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004853 006488 001958 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z002226 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009668 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```


See original or copy: <http://web.me.com/klaus.richter/HE53/HE53L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG HE43.22.TXT, Separation cmyn4*, cfi=0.90, D50, adapted S
%100 x LAB*a      1000 x (r g b   c m y 0)      %nrr. pos $
002091 000020 000017 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002422 000230 -00003 0125 0125 0125 0875 0875 0875 0000 %0862 m23 $
003421 000214 -00040 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004225 000262 000013 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005291 000255 000012 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006465 000191 000031 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
007596 000116 -00063 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008564 000051 000095 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009705 000002 000115 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
002093 000030 000012 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002414 000235 -00008 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003471 000220 -00070 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004274 000271 -00019 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005305 000251 000008 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006459 000194 000000 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
007570 000120 -00061 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
008611 000049 000003 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009705 000001 000002 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
002044 000042 000024 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002352 000239 000003 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003388 000225 -00053 0250 0250 0250 0750 0750 0750 0000 %0992 k03 $
004228 000281 -00006 0375 0375 0375 0625 0625 0625 0000 %0993 k04 $
005165 000278 000000 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006333 000228 000022 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
007540 000134 -00059 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
008538 000051 000013 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009703 000006 -00010 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
002048 000052 000022 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002349 000233 000006 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003369 000227 -00043 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004226 000275 000015 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005216 000205 000023 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006413 000120 000035 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
007563 000128 000062 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008575 000054 000002 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009702 000001 -00011 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
002262 000081 -00053 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
002253 000086 -00022 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002741 000211 000019 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
003099 000230 -00023 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
003851 000212 -00055 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
004321 000260 000030 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
004602 000210 000000 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005253 000172 000034 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
005842 000204 000038 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006333 000119 000022 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
006742 000129 000064 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007390 000116 -00035 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
008005 000073 000002 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
008385 000091 000009 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
008669 000050 000016 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009604 000007 -00009 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
002307 000019 -00035 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
002248 000095 -00014 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
002769 000217 000028 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
003148 000233 -00031 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
003867 000210 -00057 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
004328 000267 000006 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
004588 000222 00024 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005230 000183 -00002 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
005776 000206 000014 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006310 000132 -00012 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
006693 000135 000019 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007382 000129 -00051 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
007988 000078 -00008 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
008404 000085 -00010 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
008665 000051 000011 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009638 000009 -00021 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
002231 000018 -00053 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
002220 000105 -00017 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002690 000230 000036 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
003013 000250 -00009 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
003789 000227 -00041 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
004235 000275 000039 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
004498 000236 -00007 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005178 000192 000047 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
005677 000225 000045 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006175 000139 000044 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
006577 000151 000056 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007277 000140 -00034 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
007904 000084 000001 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart HE53; Relative Elementary Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: ->olv* setrgbcolor

TUB registration: 20091101-HE53/HE53L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta