

See original or copy: <http://web.me.com/klaus.richter/HE70/HE70L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.00

TUB registration: 20091101-HE70/HE70L0NÄ.TXT /.PS TUB material: code=rh4ta
application for evaluation and measurement of printer or monitor systems

KBOE HESB 22.TXT, Separation (lv* cf1=0.90, D65, not adapted \$												
id	id	id	id	id	id	id	id	id	id	id	id	id
id	id	id	id	id	id	id	id	id	id	id	id	id
002491	000076	000098	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000
002569	000051	000550	0000	0000	0125	1000	1000	0875	0000	0001	A02	\$
003000	000109	011411	0000	0000	0250	1000	1000	0750	0000	0002	A03	\$
003101	000038	016333	0000	0000	0375	1000	1000	0625	0000	0003	A04	\$
003431	000016	020606	0000	0000	0500	1000	1000	0500	0000	0004	A05	\$
003662	000083	025567	0000	0000	0625	1000	1000	0375	0000	0005	A06	\$
003831	000069	029098	0000	0000	0750	1000	1000	0250	0000	0006	A07	\$
003909	000208	034292	0000	0000	0875	1000	1000	0125	0000	0007	A08	\$
004231	000114	037336	0000	0000	1000	1000	1000	0000	0000	0008	A09	\$
004271	000473	000130	0000	0125	0000	0000	0875	1000	0000	0009	B01	\$
002956	000410	000454	0000	0125	0125	1000	0875	0875	0000	0010	B02	\$
003075	000452	011713	0000	0125	0250	1000	0875	0750	0000	0011	B03	\$
003260	000412	015266	0000	0125	0375	1000	0875	0625	0000	0012	B04	\$
003256	000405	019894	0000	0125	0500	1000	0875	0500	0000	0013	B05	\$
003792	000353	025252	0000	0125	0625	1000	0875	0375	0000	0014	B06	\$
003860	002222	029490	0000	0125	0750	1000	0875	0250	0000	0015	B07	\$
004029	000211	034548	0000	0125	0875	1000	0875	0125	0000	0016	B08	\$
004300	000289	037877	0000	0125	1000	1000	0875	0000	0000	0017	B09	\$
004386	001180	000070	0000	0250	0000	1000	0750	1000	0000	0018	C01	\$
003356	000979	000302	0000	0250	0125	1000	0750	0875	0000	0019	C02	\$
003368	000924	000814	0000	0250	0250	1000	0750	0750	0000	0020	C03	\$
003514	000976	015991	0000	0250	0375	1000	0750	0625	0000	0021	C04	\$
003700	000820	020113	0000	0250	0500	1000	0750	0500	0000	0022	C05	\$
004056	000649	028882	0000	0250	0750	1000	0750	0250	0000	0023	C06	\$
004056	000649	028882	0000	0250	0750	1000	0750	0250	0000	0024	C07	\$
004242	000660	003336	0000	0250	0875	1000	0750	0125	0000	0025	C08	\$
004551	000817	036552	0000	0250	1000	1000	0750	0000	0000	0026	C09	\$
003664	002022	000456	0000	0375	0000	1000	0625	1000	0000	0027	D01	\$
003626	019553	000075	0000	0375	0125	1000	0625	0875	0000	0028	D02	\$
003609	016443	000627	0000	0375	0250	1000	0625	0750	0000	0029	D03	\$
003613	013333	012120	0000	0375	0375	1000	0625	0625	0000	0030	D04	\$
003847	013189	018191	0000	03								

003089	001496	000826	0250	0000	0009	0750	1000	1000	0000	001612	S01
003125	001713	001556	0250	0000	0125	0750	1000	0875	0000	001613	S02
002979	001132	000843	0250	0000	0250	0750	1000	0750	0000	001614	S03
002967	001144	001474	0250	0000	0375	0750	1000	0625	0000	001615	S04
002930	001097	002211	0250	0000	0500	0750	1000	0500	0000	001616	S05
003013	001085	002213	0250	0000	0625	0750	1000	0375	0000	001617	S06
003545	001190	003367	0250	0000	0750	0750	1000	0250	0000	001618	S07
003570	001199	003354	0250	0000	0875	0750	1000	0125	0000	001619	S08
003714	001278	003879	0250	0000	1000	0750	1000	0000	0000	001710	S09
003341	001035	001184	0250	0125	0000	0750	0875	1000	0000	001711	T01
003700	000833	000626	0250	0125	0125	0750	0875	0875	0000	001712	T02
003683	000579	000527	0250	0125	0250	0750	0875	0750	0000	001713	T03
003638	000657	001223	0250	0125	0375	0750	0875	0625	0000	001714	T04
003822	000620	001686	0250	0125	0500	0750	0875	0500	0000	001715	T05
004038	000602	002160	0250	0125	0625	0750	0875	0375	0000	001716	T06
004197	000687	002536	0250	0125	0750	0750	0875	0250	0000	001717	T07
004396	000684	002995	0250	0125	0875	0750	0875	0125	0000	001718	T08
004682	000562	003288	0250	0125	1000	0750	0875	0000	0000	001719	T09
003992	001311	001923	0250	0250	0000	0750	0750	1000	0000	001800	U01
004147	001514	000940	0250	0250	0125	0750	0750	0875	0000	001810	U02
004206	000176	000070	0250	0250	0250	0750	0750	0750	0000	001812	U03
004009	000091	000051	0250	0375	0375	0750	0750	0750	0000	001813	U04
004620	000084	001125	0250	0250	0500	0750	0750	0500	0000	001814	U05
004824	000060	001606	0250	0250	0625	0750	0750	0375	0000	001815	U06
005122	000020	001992	0250	0250	0750	0750	0750	0250	0000	001816	U07
005363	000958	002312	0250	0250	0875	0750	0750	0125	0000	001817	U08
005529	000937	002721	0250	0250	1000	0750	0750	0000	0000	001818	U09
004488	001158	002375	0250	0375	0000	0750	0625	1000	0000	001819	V01
004585	001090	001307	0250	0375	0125	0750	0625	0875	0000	001900	V02
004767	000659	000219	0250	0375	0250	0750	0625	0750	0000	001910	V03
004703	000393	000448	0250	0375	0375	0750	0625	0625	0000	001912	V04
004896	000507	001091	0250	0375	0500	0750	0625	0500	0000	001913	V05
004961	000369	001594	0250	0375	0625	0750	0625	0375	0000	001914	V06
005229	000415	002037	0250	0375	0750	0750	0625	0250	0000	001915	V07
005441	000438	002343	0250	0375	0875	0750					

TUB-test chart HE70; Relative Elementary Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

input: *w setgray*
output: no change compared to input

003467	002364	000968	0375	0000	0000	0625	1000	1000	0000	%0243	A10	\$
003505	002509	000181	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$
003418	002508	-00655	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$
003299	001623	-01184	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$
003206	001712	-01873	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$
003257	001823	-02337	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$
003330	002441	-03235	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$
003393	001961	-04122	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$
003387	001960	-04122	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$
003909	001369	-001700	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$
004022	001598	000714	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$
004018	001832	-00180	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$
003971	001056	-00792	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$
003913	001163	-01042	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$
003757	001231	-02246	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$
003879	001307	-02718	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$
004147	001315	-03108	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$
004368	001085	-03447	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$
004305	000847	-002191	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$
004485	000845	-001406	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$
004868	000806	-000355	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$
004732	000537	-00475	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$
004573	000599	-01125	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$
004747	000633	-01556	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$
004869	000693	-02063	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$
005105	000515	-02427	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$
005282	000585	-02965	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$
004833	-000088	-002812	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$
005101	-000083	-002001	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$
005202	-000034	-000993	0375	0375	0250	0625	0625	0750	0000	%0272	D12	\$
005207	-000158	-00017	0375	0375	0375	0625	0625	0625	0000	%0273	D13	\$
005342	-000081	-00301	0375	0375	0500	0625	0625	0500	0000	%0274	D14	\$
005601	-000073	-00073	0375	0375	0625	0625	0625	0375	0000	%0275	D15	\$
005769	-000038	-01589	0375	0375	0750	0625	0625	0250	0000	%0276	D16	\$
005908	-000016	-01879	0375	0375	0875	0625	0625	0125	0000	%0277	D17	\$
006098	-000078	-02387	0375	0375	1000	0625	0625	0000	0000	%0278	D18	\$
005450	-01240	-003661	0375	0500	0000	0625	0500	1000	0000	%0279	D19	\$
005424	-01153	-002446	0375	0500	0125	0625	0500	0875	0000	%0280	E11	\$
005438	-01001	-001387	0375	0500	0250	0625	0500	0750	0000	%0281	E12	\$
005552	-00601	-000264	0375	0500	0375	0625	0500	0625	0000	%0282	E13	\$
005436	-00357	-00323	0375	0500	0500	0625	0500	0500	0000	%0283	E14	\$
005780	-00535	-00897	0375	0500	0625	0625	0500	0375	0000	%0284	E15	\$
005903	-00417	-01503	0375	0500	0750	0625	0500	0250	0000	%0285	E16	\$
006041	-00336	-01872	0375	0500	0875	0625	0500	0125	0000	%0286	E17	\$
006212	-00355	-02343	0375	0500	1000	0625	0500	0000	0000	%0287	E18	\$
005642	-02293	-00377	0375	0625	0000	0625	0375	1000	0000	%0288	F10	\$
005736	-02167	-002623	0375	0625	0125	0625	0375	0875	0000	%0289	F11	\$
005768	-01983	-001668	0375	0625	0250	0625	0375	0750	0000	%0290	F12	\$
005912	-01372	-000381	0375	0625	0375	0625	0375	0625	0000	%0291	F13	\$
005866	-01105	-00235	0375	0625	0500	0625	0375	0500	0000	%0292	F14	\$
005897	-00931	-00675	0375	0625	0625	0625	0375	0375	0000	%0293	F15	\$
006018	-00811	-01469	0375	0625	0750	0625	0375	0250	0000	%0294	F16	\$
006244	-00839	-01888	0375	0625	0875	0625	0375	0125	0000	%0295	F17	\$
006389	-00895	-02226	0375	0625	1000	0625	0375	0000	0000	%0296	F18	\$
005953	-03204	-003989	0375	0750	0000	0625	0250	1000	0000	%0297	G10	\$
005978	-03071	-002858	0375	0750	0125	0625	0250	0875	0000	%0298	G11	\$
006022	-03004	-001966	0375	0750	0250	0625	0250	0750	0000	%0299	G12	\$
006208	-02134	-000649	0375	0750	0375	0625	0250	0500	0000	%0300	G13	\$
006208	-01808	-00002	0375	0750	0500	0625	0250	0500	0000	%0301	G14	\$
006212	-01624	-00564	0375	0750	0625	0625	0250	0375	0000	%0302	G15	\$
006197	-01507	-00972	0375	0750	0750	0625	0250	0250	0000	%0303	G16	\$
006445	-01612	-01653	0375	0750	0875	0625	0250	0125	0000	%0304	G17	\$
006501	-01398	-02167	0375	0750	1000	0625	0250	0000	0000	%0305	G18	\$
006290	-04274	-004638	0375	0875	0000	0625	0125	1000	0000	%0306	H10	\$
006279	-03758	-003078	0375	0875	0125	0625	0125	0875	0000	%0307	H11	\$
006147	-03699	-002072	0375	0875	0250	0625	0125	0750	0000	%0308	H12	\$
006515	-02652	-000741	0375	0875	0375	0625	0125	0625	0000	%0309	H13	\$
006486	-02461	-000137	0375	0875	0500	0625	0125	0500	0000	%0310	H14	\$
006463	-02271	-003339	0375	0875	0625	0625	0125	0375	0000	%0311	H15	\$
006450	-02067	-00907	0375	0875	0750	0625	0125	0250	0000	%0312	H16	\$
006485	-01881	-01279	0375	0875	0875	0625	0125	0125	0000	%0313	H17	\$
006798	-02135	-02040	0375	0875	1000	0625	0125	0000	0000	%0314	H18	\$
006501	-05186	-004890	0375	1000	0000	0625	0000	1000	0000	%0315	I10	\$
006560	-04989	-003659	0375	1000	0125	0625	0000	0875	0000	%0316	I11	\$
006597	-04672	-002438	0375	1000	0250	0625	0000	0750	0000	%0317	I12	\$
007106	-03608	-001227	0375	1000	0375	0625	0000	0625	0000	%0318	I13	\$
007013	-03255	-000365	0375	1000	0500	0625	0000	0500	0000	%0319	I14	\$
006933	-03039	-00015	0375	1000	0625	0000	0000	0375	0000	%0320	I15	\$
006934	-02768	-00449	0375	1000	0750	0625	0000	0250	0000	%0321	I16	\$
006883	-02542	-01077	0375	1000	0875	0625	0000	0125	0000	%0322	I17	\$
006844	-02441	-01518	0375	1000	1000	0625	0000	0000	0000	%0323	I18	\$
003570	002970	001395	0500	0000	0000	0500	1000	1000	0000	%0324	J10	\$
003622	003081	000578	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$
003638	003286	-00243	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$
003519	002812	-00955	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$
003379	002194	-01478	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$
003255	002018	-02153	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$
003345	002355	-03233	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$
003371	002366	-03190	0500	0000	0875	0500	1000	0125	0000	%0331	J17	\$
003261	002551	-04131	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$
003895	002592	-001880	0500	0125	0000	0500	0875	1000	0000	%0333	K10	\$
004221	002172	-001068	0500	0125	0125	0500	0875	0875	0000	%0334	K11	\$
004295	002367	-003038	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$
004154	002433	-00668	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$
004021	001573	-01056	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$
003965	001563	-01831	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$
003795	001889	-02572	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$
003885	001863	-03134	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$
004175	001719	-03601	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$
004448	001753	-02525	0500	0250	0000	0500	0750	1000	0000	%0342	L10	\$
004669	001616	-001820	0500	0250	0125	0500	0750	0875	0000	%0343	L11	\$
005046												

004000	004937	002257	0750	0000	0000	0250	0000	0000	0000	%0486	A19	\$	004231	005820	002626	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$	004742	006503	002943	1000	0000	0000	0000	1000	1000	0000	%0648	S19	\$
004055	005021	001391	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$	004317	005849	001728	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$	004702	006609	002174	1000	0000	0125	0000	1000	0875	0000	%0649	S20	\$
004087	004997	000517	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$	004316	005891	000898	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$	004667	006847	001158	1000	0000	0250	0000	1000	0750	0000	%0650	S21	\$
004089	005105	002899	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$	004419	005787	000907	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$	004749	006799	000136	1000	0000	0375	0000	1000	0625	0000	%0651	S22	\$
003677	004748	-01005	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$	004412	005709	000625	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$	004757	006784	-00359	1000	0000	0500	0000	1000	0500	0000	%0652	S23	\$
003407	003905	-01680	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$	003922	005345	-01446	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$	004513	006522	-01275	1000	0000	0625	0000	1000	0375	0000	%0653	S24	\$
003140	003174	-02203	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$	003452	004701	-02030	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$	004158	006508	-01822	1000	0000	0750	0000	1000	0250	0000	%0654	S25	\$
003162	003271	-02954	0750	0000	0875	0250	1000	0000	0000	%0493	A26	\$	003530	003815	-02523	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$	003720	004787	-02326	1000	0000	0875	0000	1000	0125	0000	%0655	S26	\$
003252	003489	-03560	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$	003532	003909	-03253	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$	003666	004188	-02730	1000	0000	1000	0000	1000	0000	0000	%0656	S27	\$
004252	004216	002909	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$	004365	005351	003563	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$	004700	006392	003967	1000	0125	0000	0000	0875	1000	0000	%0657	T10	\$
004809	003807	001823	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$	005076	004392	002066	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$	005355	005689	002606	1000	0125	0125	0000	0875	0875	0000	%0658	T20	\$
004827	003873	000945	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$	005059	004614	001215	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$	005376	005796	001656	1000	0125	0250	0000	0875	0750	0000	%0659	T21	\$
004827	004023	000180	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$	005065	004689	000477	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$	005368	005880	000931	1000	0125	0375	0000	0875	0625	0000	%0660	T22	\$
004741	004254	-00608	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$	005055	004754	-00148	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$	005391	005952	000086	1000	0125	0500	0000	0875	0500	0000	%0661	T23	\$
004104	003443	-01346	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$	004819	004627	-01028	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$	005263	006214	-00983	1000	0125	0625	0000	0875	0375	0000	%0662	T24	\$
003788	002840	-01872	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$	004231	003906	-01657	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$	004874	004959	-01305	1000	0125	0750	0000	0875	0250	0000	%0663	T25	\$
003911	002685	-02482	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$	004052	003223	-02057	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$	004660	004344	-01929	1000	0125	0875	0000	0875	0125	0000	%0664	T26	\$
004076	002563	-03075	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$	004163	003123	-02667	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$	004340	003592	-02258	1000	0125	1000	0000	0875	0000	0000	%0665	T27	\$
004949	003133	003566	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$	005084	003703	003757	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$	005299	005325	004730	1000	0250	0000	0000	0750	1000	0000	%0666	U19	\$
005034	003230	002762	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$	005237	003897	002897	0875	0250	0125	0125	0750	0875	0000	%0586	L20	\$	005396	005427	003751	1000	0250	0125	0000	0750	0875	0000	%0667	U20	\$
005460	002940	001389	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$	005726	003750	001678	0875	0250	0250	0125	0750	0750	0000	%0587	L21	\$	006007	004623	002150	1000	0250	0250	0000	0750	0750	0000	%0668	U21	\$
005449	003176	000596	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$	005749	003941	000984	0875	0250	0375	0125	0750	0625	0000	%0588	L22	\$	006013	004799	001469	1000	0250	0375	0000	0750	0625	0000	%0669	U22	\$
005455	003333	-00148	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$	005661	004038	000158	0875	0250	0500	0125	0750	0500	0000	%0589	L23	\$	006055	004937	000749	1000	0250	0500	0000	0750	0500	0000	%0670	U23	\$
004835	002905	-00981	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$	005612	004110	-00466	0875	0250	0625	0125	0750	0375	0000	%0590	L24	\$	006092	005104	-00204	1000	0250	0625	0000	0750	0375	0000	%0671	U24	\$
004489	002255	-01492	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$	005098	003886	-01262	0875	0250	0750	0125	0750	0250	0000	%0591	L25	\$	005726	004579	-00961	1000	0250	0750	0000	0750	0250	0000	%0672	U25	\$
004656	002014	-01979	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$	004698	002736	-01701	0875	0250	0875	0125	0750	0125	0000	%0592	L26	\$	005401	003787	-01582	1000	0250	0875	0000	0750	0125	0000	%0673	U26	\$
004668	002092	-02751	0750	0250	1000	0250	0750	0000	0000	%0513	C27	\$	004811	002553	-02360	0875	0250	1000	0125	0750	0000	0000	%0593	L27	\$	004987	003203	-02026	1000	0250	1000	0000	0750	0000	0000	%0674	U27	\$
005369	002351	-004104	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$	005582	003036	004367	0875	0375	0000	0125	0625	1000	0000	%0594	M19	\$	005778	004489	005297	1000	0375	0000	0000	0625	1000	0000	%0675	V19	\$
005463	002481	003267	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$	005719	003261	003446	0875	0375	0125	0125	0625	0875	0000	%0595	M20	\$	005908	004415	004105	1000	0375	0125	0000	0625	0875	0000	%0676	V20	\$
005618	002523	002200	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$	005868	003375	002625	0875	0375	0250	0125	0625	0750	0000	%0596	M21	\$	006187	004091	003152	1000	0375	0250	0000	0625	0750	0000	%0677	V21	\$
006083	002199	001151	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$	006383	003000	000156	0875	0375	0375	0125	0625	0625	0000	%0597	M22	\$	006599	003901	001761	1000	0375	0375	0000	0625	0625	0000	%0678	V22	\$
006080	002324	003037	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$	006339	003098	000698	0875	0375	0500	0125	0625	0500	0000	%0598	M23	\$	006521	004090	001060	1000	0375	0500	0000	0625	0500	0000	%0679	V23	\$
005821	002334	-00497	0750	0375	0625	0250	0625	0375	0000	%0517	D24	\$	006432	003151	-00928	0875	0375	0625	0125	0625	0375	0000	%0599	M24	\$	006559	004344	000163	1000	0375	0625	0000	0625	0375	0000	%0680	V24	\$
005193	001671	-01194	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$	005972	002753	-00946	0875	0375	0750	0125	0625	0250	0000	%0600	M25	\$	006549	004510	-00736	1000	0375	0750	0000	0625	0250	0000	%0681	V25	\$
005211	001598	-01798	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$	005329																									

See original or copy: <http://web.me.com/klaustrichter/HE70/HE70L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

009752	-00101	000204	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$	
009062	-00630	-00359	0875	1000	1000	0000	0125	0000	0000	0000	%0730	b02	\$
008582	-00947	-00834	0750	1000	1000	0000	0250	0000	0000	0000	%0731	b03	\$
008099	-01505	-00745	0625	1000	1000	0000	0375	0000	0000	0000	%0732	b04	\$
007388	-01860	-01057	0500	1000	1000	0000	0500	0000	0000	0000	%0733	b05	\$
006853	-02278	-01605	0375	1000	1000	0000	0625	0000	0000	0000	%0734	b06	\$
006277	-02799	-02106	0250	1000	1000	0000	0750	0000	0000	0000	%0735	b07	\$
005852	-03320	-02365	0125	1000	1000	0000	0875	0000	0000	0000	%0736	b08	\$
005498	-03745	-02519	0000	1000	1000	0000	1000	0000	0000	0000	%0737	b09	\$
005093	-04080	-02812	0000	0875	0875	0000	0125	0125	0000	0000	%0738	c01	\$
004701	-000078	000130	0875	0875	0875	0000	0125	0125	0125	0000	%0739	c02	\$
004225	-00400	-00271	0750	0875	0875	0000	0250	0125	0125	0000	%0740	c03	\$
003752	-00934	-00665	0625	0875	0875	0000	0375	0125	0125	0000	%0741	c04	\$
003698	-01334	-00927	0500	0875	0875	0000	0500	0125	0125	0000	%0742	c05	\$
003650	-01760	-01307	0375	0875	0875	0000	0625	0125	0125	0000	%0743	c06	\$
003609	-02262	-01824	0250	0875	0875	0000	0750	0125	0125	0000	%0744	c07	\$
003532	-02646	-02170	0125	0875	0875	0000	0875	0125	0125	0000	%0745	c08	\$
003501	-02954	-02415	0000	0875	0875	0000	1000	0125	0125	0000	%0746	c09	\$
003443	001313	000923	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$	
003118	000613	000530	0875	0750	0750	0000	0125	0250	0250	0000	%0748	d02	\$
002794	000120	000073	0750	0750	0750	0000	0250	0250	0250	0000	%0749	d03	\$
002722	-00493	-00326	0625	0750	0750	0000	0375	0250	0250	0000	%0750	d04	\$
002671	-00923	-00681	0500	0750	0750	0000	0500	0250	0250	0000	%0751	d05	\$
002625	-01423	-00980	0375	0750	0750	0000	0625	0250	0250	0000	%0752	d06	\$
002562	-01844	-01430	0250	0750	0750	0000	0750	0250	0250	0000	%0753	d07	\$
002513	-02239	-01809	0125	0750	0750	0000	0875	0250	0250	0000	%0754	d08	\$
002476	-02539	-02138	0000	0750	0750	0000	1000	0250	0250	0000	%0755	d09	\$
002674	002323	001051	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$	
002760	001364	000827	0875	0625	0625	0000	0125	0375	0375	0000	%0757	e02	\$
002765	000703	000437	0750	0625	0625	0000	0250	0375	0375	0000	%0758	e03	\$
002691	000119	000011	0625	0625	0625	0000	0375	0375	0375	0000	%0759	e04	\$
002639	-00356	-00276	0500	0625	0625	0000	0500	0375	0375	0000	%0760	e05	\$
002527	-00975	-00626	0375	0625	0625	0000	0625	0375	0375	0000	%0761	e06	\$
002539	-01417	-01163	0250	0625	0625	0000	0750	0375	0375	0000	%0762	e07	\$
004829	-01774	-01525	0125	0625	0625	0000	0875	0375	0375	0000	%0763	e08	\$
004350	-02139	-01847	0000	0625	0625	0000	1000	0375	0375	0000	%0764	e09	\$
007076	003073	001508	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$	
006958	002187	001066	0875	0500	0500	0000	0125	0500	0500	0000	%0766	f02	\$
006761	001413	000688	0750	0500	0500	0000	0250	0500	0500	0000	%0767	f03	\$
006235	000778	000381	0625	0500	0500	0000	0375	0500	0500	0000	%0768	f04	\$
005909	000079	000120	0500	0500	0500	0000	0500	0500	0000	%0769	f05	\$	
005470	-00336	-00360	0375	0500	0500	0000	0625	0500	0500	0000	%0770	f06	\$
005159	-00986	-00782	0250	0500	0500	0000	0750	0500	0500	0000	%0771	f07	\$
004543	-01448	-01230	0125	0500	0500	0000	0875	0500	0500	0000	%0772	f08	\$
004091	-01694	-01425	0000	0500	0500	0000	1000	0500	0500	0000	%0773	f09	\$
003502	003925	001781	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$	
003613	003055	001405	0875	0375	0375	0000	0125	0625	0625	0000	%0775	g02	\$
003604	002236	001076	0750	0375	0375	0000	0250	0625	0625	0000	%0776	g03	\$
005590	001591	000699	0625	0375	0375	0000	0375	0625	0625	0000	%0777	g04	\$
005424	000891	000354	0500	0375	0375	0000	0500	0625	0625	0000	%0778	g05	\$
005098	000165	-00013	0375	0375	0375	0000	0625	0625	0625	0000	%0779	g06	\$
004774	-00395	-00446	0250	0375	0375	0000	0750	0625	0625	0000	%0780	g07	\$
004419	-00979	-00782	0125	0375	0375	0000	0875	0625	0625	0000	%0781	g08	\$
003749	-01279	-01195	0000	0375	0375	0000	1000	0625	0625	0000	%0782	g09	\$
005994	004672	002267	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$	
005619	003794	001724	0875	0250	0250	0000	0125	0750	0750	0000	%0784	h02	\$
005326	002932	001307	0750	0250	0250	0000	0250	0750	0750	0000	%0785	h03	\$
004963	002281	001190	0625	0250	0250	0000	0375	0750	0750	0000	%0786	h04	\$
004802	001600	000748	0500	0250	0250	0000	0500	0750	0750	0000	%0787	h05	\$
004666	000816	000351	0375	0250	0250	0000	0625	0750	0750	0000	%0788	h06	\$
004231	000189	-00058	0250	0250	0250	0000	0750	0750	0750	0000	%0789	h07	\$
004005	-00406	-00491	0125	0250	0250	0000	0875	0750	0750	0000	%0790	h08	\$
003513	-00880	-00829	0000	0250	0250	0000	1000	0750	0750	0000	%0791	h09	\$
003467	005722	002924	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$	
005963	004380	002167	0875	0125	0125	0000	0125	0875	0875	0000	%0793	i02	\$
004644	003835	001909	0750	0125	0125	0000	0250	0875	0875	0000	%0794	i03	\$
004232	003068	001446	0625	0125	0125	0000	0375	0875	0875	0000	%0795	i04	\$
003997	002203	001105	0500	0125	0125	0000	0500	0875	0875	0000	%0796	i05	\$
003828	001577	000709	0375	0125	0125	0000	0625	0875	0875	0000	%0797	i06	\$
003855	000816	000232	0250	0125	0125	0000	0750	0875	0875	0000	%0798	i07	\$
003524	000064	-00012	0125	0125	0125	0000	0875	0875	0875	0000	%0799	i08	\$
003242	-00410	-00478	0000	0125	0125	0000	1000	0875	0875	0000	%0800	i09	\$
004644	006595	003194	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$	
004063	005796	002862	0875	0000	0000	0000	0125	1000	1000	0000	%0802	j02	\$
003828	004899	002375	0750	0000	0000	0000	0250	1000	1000	0000	%0803	j03	\$
003585	003880	001811	0625	0000	0000	0000	0375	1000	1000	0000	%0804	j04	\$
003388	003042	001451	0500	0000	0000	0000	0500	1000	1000	0000	%0805	j05	\$
003301	002415	000947	0375	0000	0000	0000	0625	1000	1000	0000	%0806	j06	\$
003299	001567	000692	0250	0000	0000	0000	0750	1000	1000	0000	%0807	j07	\$
003029	000908	000157	0125	0000	0000	0000	0875	1000	1000	0000	%0808	j08	\$
002723	000087	-00173	0000	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009737	-00094	-000196	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$	
008928	000026	-00642	0875	0875	1000	0125	0125	0000	0000	%0811	b11	\$	
008400	-00047	-01874	0750	0750	0000	0250	0250	0000	0000	%0812	b12	\$	
007753	-00026	-01444	0625	1000	0375	0375	0000	0000	0000	%0813	b13	\$	
006764	000120	-01836	0500	0500	0000	0500	0500	0000	0000	%0814	b14	\$	
006102	-00002	-02401	0375	0375	1000	0625	0625	0000	0000	%0815	b15	\$	
005418	000032	-02847	0250	0250	1000	0750	0750	0000	0000	%0816	b16	\$	
004712	000000	-03472	0125	0250	1000	0875	0875	0000	0000	%0817	b17	\$	
004160	-00043	-01375	0000	1000	1000	1000	1000	0000	0000	%0818	b18	\$	
003511	-00063	-000841	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$	
002877	000049	000130	0875	0875	0125	0125	0125	0200	0000	%0820	c11	\$	
002810	000080	-00428	0750	0750	0250	0250	0125	0125	0000	%0821	c12	\$	
002746	-00102	-00864	0625	0625	0875	0375	0375	0125	0000	%0822	c13	\$	
002660	000128	-01393	0500	0500	0875	0500	0500	0125	0000	%0823	c14	\$	
002594	-00024	-0											

%BEG HE60_22.TXT, Separation olv*, cf1=0.90, D65, not adapted \$
%100 x LAB* %1000 x (r g b c m y 0) %nr. pos \$
%z004742 006503 002943 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008407 -00292 008564 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005553 -05510 001981 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005505 -03852 -02513 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z004231 -00014 -03736 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003666 004188 -02730 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z002491 000076 -00098 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009724 -00099 000210 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004644 006595 003194 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008406 -00299 008670 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005611 -05390 001722 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005498 -03745 -02519 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z004160 -00043 -03795 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003642 004244 -02712 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z002636 000084 -00150 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009736 -00096 000203 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/HE70/HE70L0NA.TXT> / PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.00

TUB registration: 20091101-HE70/HE70L0NA.TXT/.PS TUB material: code=rh4ta
application for evaluation and measurement of printer or monitor systems

BXB H6B 2.2.TXT, Separation olv		cf1=0.90, D65, not adapted								
100 x LAB	1000 x (r g	c-m y θ)		%n.	pos \$					
0023881	0009090	-00122	0000	0000	1000	1000	0000	0000	00972	k01 \$
0023201	0000701	-00010	0125	0125	0125	0875	0875	0875	00973	k02 \$
0040221	0002807	-00053	0250	0250	0750	0750	0750	0750	00974	k03 \$
0048871	0002124	0000001	0375	0375	0375	0625	0625	0625	00975	k04 \$
005789	0000392	0001117	0500	0500	0500	0500	0500	0500	00976	k05 \$
006828	0001355	0000221	0625	0625	0625	0375	0375	0375	00977	k06 \$
007917	0001111	0000806	0750	0750	0750	0250	0250	0250	00978	k07 \$
008827	0001802	0001083	0875	0875	0875	0125	0125	0125	00979	k08 \$
009753	-0000982	0001855	1000	1000	1000	0000	0000	0000	00980	k09 \$
002519	0000886	-00121	0000	0000	0000	1000	1000	1000	00981	l01 \$
003292	0000661	-00019	0125	0125	0125	0875	0875	0875	00982	l02 \$
004121	000189	-00061	0250	0250	0250	0750	0750	0750	00983	l03 \$
005004	000186	-00005	0375	0375	0375	0625	0625	0625	00984	l04 \$
005875	0000881	-0000805	0500	0500	0500	0500	0500	0500	00985	l05 \$
006950	0000807	-0000225	0625	0625	0625	0375	0375	0375	00986	l06 \$
007975	0000989	-0000985	0750	0750	0750	0250	0250	0250	00987	l07 \$
008860	0000704	-000116	0875	0875	0875	0125	0125	0125	00988	l08 \$
009753	000098	-000205	1000	1000	1000	0000	0000	0000	00989	l09 \$
000000	000000	-000000	0000	0000	0000	0000	0000	0000	00990	l10 \$
002390	0001059	-00000	0125	0125	0125	0875	0875	0875	00991	m01 \$
004112	000188	-00065	0250	0250	0250	0750	0750	0750	00992	m02 \$
004077	000168	-00002	0375	0375	0375	0625	0625	0625	00993	m04 \$
005863	000075	0000905	0500	0500	0500	0500	0500	0500	00994	m05 \$
006917	000095	0000333	0625	0625	0625	0375	0375	0375	00995	m06 \$
007980	000079	0000996	0750	0750	0750	0250	0250	0250	00996	m07 \$
008856	000037	0001446	0875	0875	0875	0125	0125	0125	00997	m08 \$
009759	000097	000198	1000	1000	1000	0000	0000	0000	00998	m09 \$
002471	0000581	-00113	0000	0000	0000	1000	1000	1000	00999	m10 \$
003261	0000980	0000000	0125	0125	0125	0875	0875	0875	00990	n02 \$
004072	000191	-00065	0250	0250	0250	0750	0750	0750	00991	n03 \$
004918	000195	000010	0375	0375	0375	0625	0625	0625	00992	n04 \$
005843	000086	000116	0500	0500	0500	0500	0500	0500	00993	n05 \$
006943	000103	000030	0625	0625	0625	0375	0375	0375	00994	n06 \$
007938	000094	000091	0750	0750	0750	0250	0250	0250	00995	n07 \$
008812	000087	000114	0875	0875	0875	0125	0125	0125	00996	n08 \$
009759	-00093	000186	1000	1000	1000	0000	0			

008591	-00029	000179	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$
009124	000050	-00064	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$
009744	-00098	000203	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$
002736	000084	-00161	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$
003258	000117	-00090	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$
003595	000043	000027	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$
003991	000131	-00082	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$
004285	000180	-00034	0266	0266	0266	0333	0333	0333	0000	%1060	n14	\$
004769	000111	000051	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$
005216	000158	000095	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$
005689	000178	000062	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$
006165	000096	000105	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$
006622	000148	000087	0600	0600	0600	0400	0400	0400	0000	%1065	n19	\$
007325	000091	000079	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$
007761	000103	000097	0734	0734	0734	0266	0266	0266	0000	%1067	n21	\$
008120	000054	000147	0800	0800	0800	0200	0200	0200	0000	%1068	n22	\$
008585	-00005	000182	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$
009119	000069	-00054	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$
009737	-00092	000186	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$
002502	000095	-00166	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$
009760	-00095	000196	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$
004607	000543	003383	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
005398	-04210	-02126	0000	1000	1000	1000	0000	0000	0000	%1075	l27	\$
008352	-00185	008796	1000	1000	0000	0000	0000	1000	0000	%1076	m26	\$
003934	000064	-03731	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$
005436	-05611	002030	0000	1000	0000	1000	1000	1000	0000	%1078	n26	\$
003586	004288	-02844	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$
%\$												
%z004607	006543	003383	%#1000	0000	0000	0000	1000	1000	0000	%1074	l26	%03 0
%z008352	-00185	008796	%#1000	1000	0000	0000	0000	1000	0000	%1076	m26	%Y3 1
%z005436	-05611	002030	%#0000	1000	0000	1000	0000	1000	0000	%1078	n26	%L3 2
%z005398	-04210	-02126	%#0000	1000	1000	1000	0000	0000	0000	%1075	l27	%C3 3
%z003934	000064	-03731	%#0000	0000	1000	1000	1000	0000	0000	%1077	m27	%V3 4
%z003586	004288	-02844	%#1000	0000	1000	0000	1000	0000	0000	%1079	n27	%M3 5
%z002502	000085	-										

TUB-test chart HE70; Relative Elementary Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```

[illegible]

See original or copy: <http://web.me.com/klaus.richter/HE70/HE70L0NA.TXT> /PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

003467	002311	001025	0375	0000	0000	0625	1000	1000	0000	%0243	A10 \$	003570	002919	001448	0500	0000	0000	0500	1000	1000	0000	%0324	J10 \$	003847	003720	001790	0625	0000	0000	0375	1000	1000	0000	%0405	S10 \$
003505	002457	000237	0375	0000	0125	0625	1000	0875	0000	%0244	A11 \$	003622	003032	000628	0500	0000	0125	0500	1000	0875	0000	%0325	J11 \$	003892	003907	000989	0625	0000	0125	0375	1000	0875	0000	%0406	S11 \$
003418	002454	-005096	0375	0000	0250	0625	1000	0750	0000	%0245	A12 \$	003638	002327	-00193	0500	0000	0250	0500	1000	0750	0000	%0326	J12 \$	003881	004148	000238	0625	0000	0250	0375	1000	0750	0000	%0407	S12 \$
003299	001566	-01119	0375	0000	0375	0625	1000	0625	0000	%0246	A13 \$	003651	002761	-00990	0500	0000	0375	0500	1000	0625	0000	%0327	J13 \$	003849	004168	-00541	0625	0000	0375	0375	1000	0625	0000	%0408	S13 \$
003206	001653	-01804	0375	0000	0500	0625	1000	0500	0000	%0247	A14 \$	003679	002140	-01417	0500	0000	0500	0500	1000	0500	0000	%0328	J14 \$	003578	003390	-01230	0625	0000	0500	0375	1000	0500	0000	%0409	S14 \$
003257	001766	-02271	0375	0000	0625	0625	1000	0375	0000	%0248	A15 \$	003255	001960	-02087	0500	0000	0625	0500	1000	0375	0000	%0329	J15 \$	003384	002735	-01915	0625	0000	0625	0375	1000	0375	0000	%0410	S15 \$
003330	002385	-03172	0375	0000	0750	0625	1000	0250	0000	%0249	A16 \$	003345	002300	-03171	0500	0000	0750	0500	1000	0250	0000	%0330	J16 \$	003315	002613	-02521	0625	0000	0750	0375	1000	0250	0000	%0411	S16 \$
003393	001906	-04061	0375	0000	0875	0625	1000	0075	0000	%0250	A17 \$	003371	002311	-03135	0500	0000	0875	0500	1000	0125	0000	%0331	J17 \$	003372	002683	-03206	0625	0000	0875	0375	1000	0125	0000	%0412	S17 \$
003387	001905	-04061	0375	0000	1000	0625	1000	0000	0000	%0251	A18 \$	003361	002285	-04125	0500	0000	1000	0500	1000	0000	0000	%0332	J18 \$	003278	003009	-03024	0625	0000	1000	0375	1000	0000	0000	%0413	S18 \$
003909	001327	-001738	0375	0125	0000	0625	0875	1000	0000	%0252	B10 \$	003895	002549	-001919	0500	0125	0000	0500	0875	1000	0000	%0333	K10 \$	004003	003334	002274	0625	0125	0000	0375	0875	1000	0000	%0414	T10 \$
004022	001559	000747	0375	0125	0125	0625	0875	0875	0000	%0253	B11 \$	004221	002138	-001093	0500	0125	0125	0500	0875	0075	0000	%0334	K11 \$	004530	003010	001318	0625	0125	0125	0375	0875	0875	0000	%0415	T11 \$
004018	001793	-00146	0375	0125	0250	0625	0875	0750	0000	%0254	B12 \$	004295	002334	-000329	0500	0125	0250	0500	0875	0750	0000	%0335	K12 \$	004541	003101	000646	0625	0125	0250	0375	0875	0750	0000	%0416	T12 \$
003971	001016	-00757	0375	0125	0375	0625	0875	0625	0000	%0255	B13 \$	004154	002397	-00640	0500	0125	0375	0500	0875	0625	0000	%0336	K13 \$	004587	003281	-00074	0625	0125	0375	0375	0875	0625	0000	%0417	T13 \$
003913	001121	-01464	0375	0125	0500	0625	0875	0500	0000	%0256	B14 \$	004021	001534	-01023	0500	0125	0500	0500	0875	0500	0000	%0337	K14 \$	004395	002914	-00946	0625	0125	0500	0375	0875	0500	0000	%0418	T14 \$
003757	001185	-02202	0375	0125	0625	0625	0875	0375	0000	%0257	B15 \$	003965	001522	-01795	0500	0125	0625	0500	0875	0375	0000	%0338	K15 \$	004207	002100	-01316	0625	0125	0625	0375	0875	0375	0000	%0419	T15 \$
003879	001264	-02678	0375	0125	0750	0625	0875	0250	0000	%0258	B16 \$	003795	001844	-02529	0500	0125	0750	0500	0875	0250	0000	%0339	K16 \$	004042	002239	-02176	0625	0125	0750	0375	0875	0250	0000	%0420	T16 \$
004147	001279	-03080	0375	0125	0875	0625	0875	0125	0000	%0259	B17 \$	003885	001821	-03094	0500	0125	0875	0500	0875	0125	0000	%0340	K17 \$	004041	002260	-02792	0625	0125	0875	0375	0875	0125	0000	%0421	T17 \$
004368	001055	-03428	0375	0125	1000	0625	0875	0000	0000	%0260	B18 \$	004175	001683	-03574	0500	0125	1000	0500	0875	0000	0000	%0341	K18 \$	004118	002240	-03415	0625	0125	1000	0375	0875	0000	0000	%0422	T18 \$
004305	000815	-002212	0375	0250	0000	0625	0750	1000	0000	%0261	C10 \$	004448	001724	-02540	0500	0250	0000	0500	0750	1000	0000	%0342	L10 \$	004591	002443	002095	0625	0250	0000	0375	0750	1000	0000	%0423	U10 \$
004485	000817	001420	0375	0250	0125	0625	0750	0875	0000	%0262	C11 \$	004669	001592	-001826	0500	0250	0125	0500	0750	0875	0000	%0343	L11 \$	004778	002511	002259	0625	0250	0125	0375	0750	0875	0000	%0424	U11 \$
004068	000787	000352	0375	0250	0250	0625	0750	0750	0000	%0263	C12 \$	005046	001530	-000723	0500	0250	0250	0500	0750	0750	0000	%0344	L12 \$	005256	002172	001018	0625	0250	0250	0375	0750	0750	0000	%0425	U12 \$
004732	000515	-00472	0375	0250	0375	0625	0750	0625	0000	%0264	C13 \$	005022	001677	-00074	0500	0250	0375	0500	0750	0625	0000	%0345	L13 \$	005226	002354	000267	0625	0250	0375	0375	0750	0625	0000	%0426	U13 \$
004573	000574	-01115	0375	0250	0500	0625	0750	0500	0000	%0265	C14 \$	004702	001141	-00734	0500	0250	0500	0500	0750	0500	0000	%0346	L14 \$	005125	002292	-00554	0625	0250	0500	0375	0750	0500	0000	%0427	U14 \$
004747	000611	-01554	0375	0250	0625	0625	0750	0375	0000	%0266	C15 \$	004748	001134	-01365	0500	0250	0625	0500	0750	0375	0000	%0347	L15 \$	004887	001649	-01112	0625	0250	0625	0375	0750	0375	0000	%0428	U15 \$
004869	000674	-02066	0375	0250	0750	0625	0750	0250	0000	%0267	C16 \$	004675	001195	-02076	0500	0250	0750	0500	0750	0250	0000	%0348	L16 \$	004886	001660	-01650	0625	0250	0750	0375	0750	0250	0000	%0429	U16 \$
005105	000502	-02440	0375	0250	0875	0625	0750	0125	0000	%0268	C17 \$	004852	001114	-02478	0500	0250	0875	0500	0750	0125	0000	%0349	L17 \$	004873	001570	-02204	0625	0250	0875	0375	0750	0125	0000	%0430	U17 \$
005282	000576	-02986	0375	0250	1000	0625	0750	0000	0000	%0269	C18 \$	005040	001037	-02896	0500	0250	1000	0500	0750	0000	0000	%0350	L18 \$	004820	001613	-02854	0625	0250	1000	0375	0750	0000	0000	%0431	U18 \$
005433	-00107	002811	0375	0375	0000	0625	0625	1000	0000	%0270	D10 \$	004964	000812	-003324	0500	0375	0000	0500	0625	1000	0000	%0351	M10 \$	005129	001641	003570	0625	0375	0000	0375	0625	1000	0000	%0432	V10 \$
005181	-00096	001988	0375	0375	0125	0625	0625	0875	0000	%0271	D11 \$	005152	-000870	-002365	0500	0375	0125	0500	0625	0875	0000	%0352	M11 \$	005333	001582	002762	0625	0375	0125	0375	0625	0875	0000	%0433	V11 \$
005202	-00044	000976	0375	0375	0250	0625	0625	0750	0000	%0272	D12 \$	005397	-000803	-001418	0500	0375	0250	0500	0625	0750	0000	%0353	M12 \$	005595	001592	001768	0625	0375	0250	0375	0625	0750	0000	%0434	V12 \$
005207	000148	-00034	0375	0375	0375	0625	0625	0625	0000	%0273	D13 \$	005580	000873	-00293	0500	0375	0375	0500	0625	0625	0000	%0354	M13 \$	005824	001492	000633	0625	0375	0375	0625	0625	0625	0000	%0435	V13 \$
005342	000074	-00404	0375	0375	0500	0625	0625	0500	0000	%0274	D14 \$	005424	000508	-00357	0500	0375	0500	0500	0625	0500	0000	%0355	M14 \$	005748	001655	-00117	0625	0375	0500	0375	0625	0500	0000	%0436	V14 \$
005601	000074	-01007	0375	0375	0625	0625	0625	0375	0000	%0275	D15 \$	005410	000503	-00357	0500	0375	0625	0500	0625	0375	0000	%0356	M15 \$	005906	001097	-00766	0625	0375	0625	0375	0625	0375	0000	%0437	V15 \$
005769	000041	-01630	0375	0375	0750	0625	0625	0250	0000	%0276	D16 \$	005678	000542	-01515	0500	0375	0750	0500	0625	0250	0000	%0357	M16 \$	005624	001069	-01372	0625	0375	0750	0375	0625	0250	0000	%0438	V16 \$
005908	000023	-01927	0375	0375	0875	0625	0625	0125	0000	%0277	D17 \$	005737	000475	-01921	0500	0375	0875	0500	0625	0125	0000	%0358	M17 \$	005543	001058	-01894	0625	0375	0875	0375	0625	0125	0000	%0439	V17 \$
006098	000089	-02443	0375	0375	1000	0625	0625	0000	0000	%0278	D18 \$	005965	000655	-02512	05																				

004000	004897	002291	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$	004231	005786	002650	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$	004742	006481	002945	1000	0000	0000	0000	1000	1000	0000	%0648	S19	\$
004055	004983	001423	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$	004317	005817	001749	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$	004702	006586	002178	1000	0000	0125	0000	1000	0875	0000	%0649	S20	\$
004087	004960	000547	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$	004316	005859	000919	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$	004667	006823	001164	1000	0000	0250	0000	1000	0750	0000	%0650	S21	\$
004009	005065	-002555	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$	004419	005757	000009	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$	004749	006777	000138	1000	0000	0375	0000	1000	0625	0000	%0651	S22	\$
003677	004700	-009557	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$	004412	005679	-006088	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$	004757	006763	-003557	1000	0000	0500	0000	1000	0500	0000	%0652	S23	\$
003407	003851	-016268	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$	003922	005304	-014099	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$	004513	006495	-012622	1000	0000	0625	0000	1000	0375	0000	%0653	S24	\$
003140	003113	-021332	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$	003452	004648	-019172	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$	004158	005572	-017195	1000	0000	0750	0000	1000	0250	0000	%0654	S25	\$
003162	003211	-029083	0750	0000	0875	0250	1000	0000	0000	%0493	A26	\$	003350	003760	-024782	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$	003720	004741	-022280	1000	0000	0875	0000	1000	0125	0000	%0655	S26	\$
003252	003441	-035339	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$	003345	003658	-032604	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$	003656	004140	-025631	1000	0000	1000	0000	1000	0000	%0656	S27	\$	
004252	004182	002932	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$	004365	005321	003581	0875	0125	0000	0125	0875	1000	0000	%0576	K10	\$	004700	006369	003971	1000	0125	0000	0000	0875	1000	0000	%0657	T10	\$
004809	003787	001823	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$	005076	004378	002054	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$	005355	005683	002582	1000	0125	0125	0000	0875	0875	0000	%0658	T20	\$
004827	003854	000944	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$	005059	004600	001204	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$	005376	005790	001632	1000	0125	0250	0000	0875	0750	0000	%0659	T21	\$
004827	004803	000179	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$	005065	004675	000466	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$	005368	005874	000907	1000	0125	0375	0000	0875	0625	0000	%0660	T22	\$
004741	004232	-006065	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$	005055	004740	-001519	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$	005391	005946	000061	1000	0125	0500	0000	0875	0500	0000	%0661	T23	\$
004104	003406	-013136	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$	004819	004607	-010929	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$	005263	006205	-010903	1000	0125	0625	0000	0875	0375	0000	%0662	T24	\$
003788	002795	-018228	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$	004231	003872	-016333	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$	004874	004940	-013088	1000	0125	0750	0000	0875	0250	0000	%0663	T25	\$
003911	002643	-024444	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$	004052	003184	-020825	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$	004660	004321	-019233	1000	0125	0875	0000	0875	0125	0000	%0664	T26	\$
004076	002525	-030444	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$	004163	003087	-026339	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$	004340	003561	-022338	1000	0125	1000	0000	0875	0000	0000	%0665	T27	\$
004949	003116	003560	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$	005084	003690	003745	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$	005299	005317	004708	1000	0250	0000	0000	0750	1000	0000	%0666	U19	\$
005034	003215	002752	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$	005237	003887	002878	0875	0250	0125	0125	0750	0875	0000	%0586	L20	\$	005396	005422	003725	1000	0250	0125	0000	0750	0875	0000	%0667	U20	\$
005460	002936	001361	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$	005726	003752	001639	0875	0250	0250	0125	0750	0750	0000	%0587	L21	\$	006007	004632	002098	1000	0250	0250	0000	0750	0750	0000	%0668	U21	\$
005449	003171	000569	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$	005749	003944	000943	0875	0250	0375	0125	0750	0625	0000	%0588	L22	\$	006013	004808	001417	1000	0250	0375	0000	0750	0625	0000	%0669	U22	\$
005455	003328	-00175	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$	005661	004039	000121	0875	0250	0500	0125	0750	0500	0000	%0589	L23	\$	006055	004947	000696	1000	0250	0500	0000	0750	0500	0000	%0670	U23	\$
004835	002886	-009882	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$	005612	004109	-005000	0875	0250	0625	0125	0750	0375	0000	%0590	L24	\$	006092	005115	-002559	1000	0250	0625	0000	0750	0375	0000	%0671	U24	\$
004489	002227	-01478	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$	005098	003373	-011274	0875	0250	0750	0125	0750	0250	0000	%0591	L25	\$	005726	004581	-010000	1000	0250	0750	0000	0750	0250	0000	%0672	U25	\$
004656	001990	-01973	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$	004698	002714	-01697	0875	0250	0875	0125	0750	0125	0000	%0592	L26	\$	005401	003782	-016088	1000	0250	0875	0000	0750	0125	0000	%0673	U26	\$
004668	002069	-02745	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$	004811	002533	-02360	0875	0250	1000	0125	0750	0000	0000	%0593	L27	\$	004987	003187	-020334	1000	0250	1000	0000	0750	0000	0000	%0674	U27	\$
005369	002344	004080	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$	005582	003635	004333	0875	0375	0000	0125	0625	1000	0000	%0594	M19	\$	005778	004492	002525	1000	0375	0000	0000	0625	1000	0000	%0675	V19	\$
005463	002476	003239	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$	005719	003263	003407	0875	0375	0125	0125	0625	0875	0000	%0595	M20	\$	005908	004422	004058	1000	0375	0125	0000	0625	0875	0000	%0676	V20	\$
005618	002522	002166	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$	005868	003381	002579	0875	0375	0250	0125	0625	0750	0000	%0596	M21	\$	006187	004105	003093	1000	0375	0250	0000	0625	0750	0000	%0677	V21	\$
006083	002209	001096	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$	006383	003018	001449	0875	0375	0375	0125	0625	0625	0000	%0597	M22	\$	006599	003922	001688	1000	0375	0375	0000	0625	0625	0000	%0678	V22	\$
006080	002334	000253	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$	006332	003115	000632	0875	0375	0500	0125	0625	0500	0000	%0598	M23	\$	006521	004111	000987	1000	0375	0500	0000	0625	0500	0000	%0679	V23	\$
005821	002341	-005644	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$	006324	003167	-000808	0875	0375	0625	0125	0625	0375	0000	%0599	M24	\$	006559	004366	000987	1000	0375	0625	0000	0625	0375	0000	%0680	V24	\$
005193	001661	-01210	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$	006972	002761	-009096	0875	0375	0750	0125	0625	0250	0000	%0600	M25	\$	006549	004532	-00811	1000	0375	0750	0000	0625	0250	0000	%0681	V25	\$
005211	001587	-01725	0750	0375	0875	02																																

009752	-00004	000000	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$	
009062	-00550	-00529	0875	1000	1000	0000	0125	0000	0000	0000	%0730	b02	\$
008582	-00880	-00980	0750	1000	1000	0000	0250	0000	0000	0000	%0731	b03	\$
008099	-01450	-00867	0625	1000	1000	0000	0375	0000	0000	0000	%0732	b04	\$
007388	-01823	-01143	0500	1000	1000	0000	0500	0000	0000	0000	%0733	b05	\$
006853	-02254	-01665	0375	1000	1000	0000	0625	0000	0000	0000	%0734	b06	\$
006277	-02781	-02137	0250	1000	1000	0000	0750	0000	0000	0000	%0735	b07	\$
005852	-03322	-02905	0125	1000	1000	0000	0875	0000	0000	0000	%0736	b08	\$
005498	-03756	-02511	0000	1000	1000	0000	1000	0000	0000	0000	%0737	b09	\$
009003	-00089	000045	1000	0875	0875	0000	0125	0125	0000	0000	%0738	c01	\$
008701	000149	-00021	0875	0875	0875	0000	0125	0125	0125	0000	%0739	c02	\$
008225	-00342	-00399	0750	0875	0875	0250	0125	0125	0000	0000	%0740	c03	\$
007532	-00894	-00758	0625	0875	0875	0375	0125	0125	0000	0000	%0741	c04	\$
006986	-01307	-00994	0500	0875	0875	0500	0125	0125	0000	0000	%0742	c05	\$
006560	-01744	-01352	0375	0875	0875	0625	0125	0125	0000	0000	%0743	c06	\$
006009	-02261	-01841	0250	0875	0875	0750	0125	0125	0000	0000	%0744	c07	\$
005532	-02656	-02164	0125	0875	0875	0875	0125	0125	0000	0000	%0745	c08	\$
005041	-02976	-02384	0000	0875	0875	1000	0125	0125	0000	0000	%0746	c09	\$
004843	001377	-000784	1000	0750	0750	0000	0250	0250	0000	0000	%0747	d01	\$
004818	000668	000407	0875	0750	0750	0125	0250	0250	0000	0000	%0748	d02	\$
007904	000170	-00038	0750	0750	0750	0250	0250	0250	0000	0000	%0749	d03	\$
007272	-00459	-00406	0625	0750	0750	0375	0250	0250	0000	0000	%0750	d04	\$
006716	-00904	-00734	0500	0750	0750	0500	0250	0250	0000	0000	%0751	d05	\$
006256	-01414	-01009	0375	0750	0750	0625	0250	0250	0000	0000	%0752	d06	\$
005626	-01852	-01428	0250	0750	0750	0750	0250	0250	0000	0000	%0753	d07	\$
005143	-02259	-01784	0125	0750	0750	0875	0250	0250	0000	0000	%0754	d08	\$
004716	-02570	-02091	0000	0750	0750	1000	0250	0250	0000	0000	%0755	d09	\$
007674	002367	000950	1000	0625	0625	0000	0375	0375	0000	0000	%0756	e01	\$
007604	001407	000730	0875	0625	0625	0125	0375	0375	0000	0000	%0757	e02	\$
007365	000739	000352	0750	0625	0625	0250	0375	0375	0000	0000	%0758	e03	\$
006891	000143	-00050	0625	0625	0625	0375	0375	0375	0000	0000	%0759	e04	\$
006329	-00348	-00309	0500	0625	0625	0500	0375	0375	0000	0000	%0760	e05	\$
005927	-00976	-00940	0375	0625	0625	0625	0375	0375	0000	0000	%0761	e06	\$
005339	-01432	-01148	0250	0625	0625	0750	0375	0375	0000	0000	%0762	e07	\$
004829	-01802	-01484	0125	0625	0625	0875	0375	0375	0000	0000	%0763	e08	\$
004350	-02179	-01782	0000	0625	0625	1000	0375	0375	0000	0000	%0764	e09	\$
007076	003102	001437	1000	0500	0500	0000	0500	0500	0000	0000	%0765	f01	\$
006958	002213	001001	0875	0500	0500	0125	0500	0500	0000	0000	%0766	f02	\$
006761	001434	000633	0750	0500	0500	0250	0500	0500	0000	0000	%0767	f03	\$
006235	000785	000352	0625	0500	0500	0375	0500	0500	0000	0000	%0768	f04	\$
005900	000078	000108	0500	0500	0500	0500	0500	0500	0000	0000	%0769	f05	\$
005470	-00347	-00351	0375	0500	0500	0625	0500	0500	0000	0000	%0770	f06	\$
005159	-01006	-00757	0250	0500	0500	0750	0500	0500	0000	0000	%0771	f07	\$
004543	-01483	-01175	0125	0500	0500	0875	0500	0500	0000	0000	%0772	f08	\$
004091	-01741	-01347	0000	0500	0500	1000	0500	0500	0000	0000	%0773	f09	\$
006502	000390	001739	1000	0375	0375	0000	0625	0625	0000	0000	%0774	g01	\$
006313	000365	001372	0875	0375	0375	0125	0625	0625	0000	0000	%0775	g02	\$
006043	002239	001057	0750	0375	0375	0250	0625	0625	0000	0000	%0776	g03	\$
005590	001583	000702	0625	0375	0375	0375	0625	0625	0000	0000	%0777	g04	\$
005424	000878	000365	0500	0375	0375	0500	0625	0625	0000	0000	%0778	g05	\$
005098	000144	000013	0375	0375	0375	0625	0625	0625	0000	0000	%0779	g06	\$
004774	-00425	-00402	0250	0375	0375	0750	0625	0625	0000	0000	%0780	g07	\$
004419	-01017	-00720	0125	0375	0375	0875	0625	0625	0000	0000	%0781	g08	\$
003749	-01335	-01100	0000	0375	0375	1000	0625	0625	0000	0000	%0782	g09	\$
005994	004673	002251	1000	0250	0250	0000	0750	0750	0000	0000	%0783	h01	\$
005619	003786	001726	0875	0250	0250	0125	0750	0750	0000	0000	%0784	h02	\$
005326	002916	001413	0750	0250	0250	0250	0750	0750	0000	0000	%0785	h03	\$
004963	002256	001143	0625	0250	0250	0375	0750	0750	0000	0000	%0786	h04	\$
004802	001571	-000790	0500	0250	0250	0500	0750	0750	0000	0000	%0787	h05	\$
004666	000783	000400	0375	0250	0250	0625	0750	0750	0000	0000	%0788	h06	\$
004231	000146	000012	0250	0250	0250	0750	0750	0750	0000	0000	%0789	h07	\$
004005	-00456	-00409	0125	0250	0250	0875	0750	0750	0000	0000	%0790	h08	\$
003513	-00942	-00722	0000	0250	0250	1000	0750	0750	0000	0000	%0791	h09	\$
003467	005707	002940	1000	0125	0125	0000	0875	0875	0000	0000	%0792	i01	\$
005933	004355	002202	0875	0125	0125	0125	0875	0875	0000	0000	%0793	i02	\$
004644	003802	001959	0750	0125	0125	0250	0875	0875	0000	0000	%0794	i03	\$
004232	003925	001517	0625	0125	0125	0375	0875	0875	0000	0000	%0795	i04	\$
003997	002153	001188	0500	0125	0125	0500	0875	0875	0000	0000	%0796	i05	\$
003828	001523	000800	0375	0125	0125	0625	0875	0875	0000	0000	%0797	i06	\$
003855	000763	000321	0250	0125	0125	0750	0875	0875	0000	0000	%0798	i07	\$
003524	000002	000093	0125	0125	0125	0875	0875	0875	0000	0000	%0799	i08	\$
003242	-00479	-00358	0000	0125	0125	1000	0875	0875	0000	0000	%0800	i09	\$
004644	006562	003244	1000	0000	0000	0000	1000	1000	0000	0000	%0801	j01	\$
004063	005749	002941	0875	0000	0000	0125	1000	1000	0000	0000	%0802	j02	\$
003828	004846	002466	0750	0000	0000	0250	1000	1000	0000	0000	%0803	j03	\$
003585	003820	001914	0625	0000	0000	0375	1000	1000	0000	0000	%0804	j04	\$
003388	002977	001563	0500	0000	0000	0500	1000	1000	0000	0000	%0805	j05	\$
003301	002348	001064	0375	0000	0000	0625	1000	1000	0000	0000	%0806	j06	\$
003299	001500	000809	0250	0000	0000	0750	1000	1000	0000	0000	%0807	j07	\$
003029	000834	000287	0125	0000	0000	0875	1000	1000	0000	0000	%0808	j08	\$
002723	000005	-00027	0000	0000	0000	1000	1000	1000	0000	0000	%0809	j09	\$
009737	000001	-00006	1000	1000	1000	0000	0000	0000	0000	0000	%0810	b10	\$
008928	000102	-00805	0875	0875	0875	0100	0125	0125	0000	0000	%0811	b11	\$
008400	000015	-01211	0750	0750	0750	0250	0250	0250	0000	0000	%0812	b12	\$
007753	000019	-01548	0625	0625	0625	0375	0375	0375	0000	0000	%0813	b13	\$
006764	000141	-01891	0500	0500	0500	0500	0500	0500	0000	0000	%0814	b14	\$
006102	000067	-02423	0375	0375	0375	0625	0625	0625	0000	0000	%0815	b15	\$
005418	000019	-02836	0250	0250	0250	0750	0750	0750	0000	0000	%0816	b16	\$
004712	000068	-03365	0125	0250	0250	0875	0875	0875	0000	0000	%0817	b17	\$
004160	-00088	-03721	0000	0250	0250	1000	1000	1000	0000	0000	%0818	b18	\$
009511	000027	000649	1000	1000	0875	0000	0125	0000	0000	0000	%0819	c10	\$
008877	000124	-00029	0875	0875	0875	0125	0125	0125	0000	0000	%0820	c11	\$
008180	000137	-00053	0750	0750	0750	0250	0250	0250	0000	0000	%0821	c12	\$
007467	-00063	-00954	0625	0625	0625	0375	0375	0125	0000	0000	%0822	c1	

%BEG HE60_22.TXT, Separation olv*, cf1=0.90, D65, adapted \$
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos \$
%z004742 006481 002945 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008407 -00224 008410 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005553 -05512 001949 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005505 -03855 -02543 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z004231 -00048 -03711 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003666 004140 -02681 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z002491 000000 000000 %#0000 0000 1000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009724 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004644 006562 003244 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008406 -00236 008533 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005611 -05398 001724 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005498 -03756 -02511 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z004160 -00088 -03721 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003642 004186 -02611 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z002636 000000 000000 %#0000 0000 1000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009736 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

\$BXE	1000 x LAB**a	1000 x (r g b	c m y r)	D65, adapted	\$nr.	pos			
002388	000001	000049	0000	0000	0000	0000	00972	K01	
002301	000002	000120	0125	0125	0875	0875	0000	00973	K02
004021	000159	000037	0250	0250	0750	0750	0000	00974	K03
004887	000188	000048	0375	0375	0625	0625	0625	00975	K04
005789	000088	000119	0500	0500	0500	0500	0500	00976	K05
006828	000157	-00028	0625	0625	0525	0375	0375	00977	K06
007917	000161	-00018	0750	0750	0250	0250	0250	00978	K07
008827	000175	-00046	0875	0875	0875	0125	0125	00979	K08
009553	000003	-00011	1000	1000	0000	0000	0000	00980	K09
002519	000000	000043	0000	0000	0000	1000	1000	00981	L01
003292	-00004	0000107	0125	0125	0125	0875	0875	00982	L02
004121	000144	000024	0250	0250	0250	0750	0750	00983	L03
005004	000163	000035	0375	0375	0375	0625	0625	00984	L04
005875	000079	000083	0500	0500	0500	0500	0500	00985	L05
006950	000112	-00030	0625	0625	0375	0375	0375	00986	L06
007975	000140	-00022	0750	0750	0250	0250	0250	00987	L07
008860	000147	-00035	0875	0875	0875	0125	0125	00988	L08
009753	-00002	000008	1000	1000	0000	0000	0000	00989	L09
002485	000007	000047	0000	0000	0000	1000	1000	00990	m01
003290	000006	000040	0125	0125	0875	0875	0875	00991	m02
004077	000000	000040	0250	0250	0750	0750	0750	00992	m03
004977	000145	000040	0375	0375	0375	0625	0625	00993	m04
005863	000073	000033	0500	0500	0500	0500	0500	00994	m05
006917	000119	-00021	0625	0625	0375	0375	0375	00995	m06
007980	000130	-00011	0750	0750	0250	0250	0250	00996	m07
008856	000111	-00005	0875	0875	0875	0125	0125	00997	m08
009759	000002	000001	1000	1000	0000	0000	0000	00998	m09
002471	000005	000054	0000	0000	0000	1000	1000	00999	m10
003261	-00008	0000127	0125	0125	0875	0875	0875	00000	m02
004072	000145	000022	0250	0250	0750	0750	0750	00001	m03
004918	000169	000056	0375	0375	0375	0625	0625	00002	m04
005843	000084	000116	0500	0500	0500	0500	0500	00003	m05
006943	000128	-00025	0625	0625	0625	0375	0375	00004	m06
007938	000144	-00013	0750	0750	0250	0250	0250	00005	m07
008812	000159	-00034	0875	0875	0875	0125	0125	00006	m08
009750	000001	-00010	1000	1000	0000	0000	0000	00007	m09
002713	-00002	-00022	0000	0000	0000	1000	1000	00008	k10
003225	000040	000039	0000	0000	0000	0933	0933	00009	k11
003582	-00017	000121	0133	0133	0866	0866	0866	00010	k12
004000	000077	000006	0200	0200	0800	0800	0800	00011	k13
004286	000130	000029	0						

008591	000036	000041	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$
009124	000139	-00229	0933	0933	0933	0966	0966	0966	0000	%1054	m24	\$
009744	-00002	000007	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$
002736	000004	-00006	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$
003258	000050	000038	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$
003595	-00015	000139	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$
003991	000083	000009	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$
004285	000139	000042	0266	0266	0266	0333	0333	0333	0000	%1060	n14	\$
004769	000081	000104	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$
005216	000140	000125	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$
005689	000172	000069	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$
006165	-000102	000088	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$
006622	000165	000047	0600	0600	0600	0400	0400	0400	0000	%1065	n19	\$
007325	000126	000004	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$
007761	000149	000000	0734	0734	0734	0266	0266	0266	0000	%1067	n21	\$
008120	000109	000032	0800	0800	0800	0200	0200	0200	0000	%1068	n22	\$
008585	000061	000044	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$
009119	000149	-00219	0933	0933	0933	0966	0966	0966	0000	%1070	n24	\$
009737	000003	-00008	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$
002502	000000	000000	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$
009760	000000	000000	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$
004607	006510	003445	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
005398	-04224	-02105	0000	1000	1000	1000	0000	0000	0000	%1075	l27	\$
008352	-00124	008669	1000	1000	0000	0000	0000	1000	0000	%1076	m26	\$
003934	000014	-03637	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$
005436	-05623	002049	0000	1000	0000	1000	0000	1000	0000	%1078	n26	\$
003586	004230	-02732	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$
%\$												
%z004607	006510	003445	%#1000	0000	0000	0000	1000	1000	0000	%1074	l26	%03 0
%z008352	-00124	008669	%#1000	1000	0000	0000	0000	1000	0000	%1076	m26	%Y3 1
%z005436	-05623	002049	%#0000	1000	0000	1000	0000	1000	0000	%1078	n26	%L3 2
%z005398	-04224	-02105	%#0000	1000	1000	1000	0000	0000	0000	%1075	l27	%C3 3
%z003934	000014	-03637	%#0000	0000	1000	1000	1000	0000	0000	%1077	m27	%V3 4
%z003586	004230	-02732	%#1000	0000	1000	0000	1000	0000	0000	%1079	n27	%M3 5
%z002502	00000											

TUB registration: 20091101-HE70/HE70L0NA.TXT /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

TUB-test chart HE70; Relative Elementary Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrabcOLOR
```


See original or copy: <http://web.me.com/klaustrichter/HE70/HE70L0NA.TXT> /PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

TUB registration: 20091101-HE70/HE70L0NA.TXT /PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

003532	002560	001079	0375	0000	0000	0000	0625	1000	1000	0000	%0243	A10 \$	003655	003205	0001534	0500	0000	0000	0500	1000	1000	0000	%0324	J10 \$	003956	004027	001929	0625	0000	0000	0375	1000	1000	0000	%0405	S10 \$
003564	002632	000300	0375	0000	0125	0625	1000	0875	0000	%0244	A11 \$	003701	003250	000727	0500	0000	0125	0500	1000	0875	0000	%0325	J11 \$	003998	004157	001147	0625	0000	0125	0375	1000	0875	0000	%0406	S11 \$	
003464	002539	-00545	0375	0000	0250	0625	1000	0750	0000	%0245	A12 \$	003711	003375	-00085	0500	0000	0250	0500	1000	0750	0000	%0326	J12 \$	003984	004331	000410	0625	0000	0250	0375	1000	0750	0000	%0407	S12 \$	
003313	001581	-01138	0375	0000	0375	0625	1000	0625	0000	%0246	A13 \$	003568	002818	-00834	0500	0000	0375	0500	1000	0625	0000	%0327	J13 \$	003941	004278	-00376	0625	0000	0375	0375	1000	0625	0000	%0408	S13 \$	
003207	001591	-01848	0375	0000	0500	0625	1000	0500	0000	%0247	A14 \$	003402	002132	-01410	0500	0000	0500	0500	1000	0500	0000	%0328	J14 \$	003637	003424	-01135	0625	0000	0500	0375	1000	0500	0000	%0409	S14 \$	
003249	001651	-02328	0375	0000	0625	0625	1000	0375	0000	%0248	A15 \$	003257	001869	-02122	0500	0000	0625	0500	1000	0375	0000	%0329	J15 \$	003410	002693	-01894	0625	0000	0625	0375	1000	0375	0000	%0410	S15 \$	
003314	002156	-03231	0375	0000	0750	0625	1000	0250	0000	%0249	A16 \$	003327	002063	-03234	0500	0000	0750	0500	1000	0250	0000	%0330	J16 \$	003322	002493	-02536	0625	0000	0750	0375	1000	0250	0000	%0411	S16 \$	
003335	001476	-04194	0375	0000	0875	0625	1000	0125	0000	%0250	A17 \$	003354	002080	-03193	0500	0000	0875	0500	1000	0125	0000	%0331	J17 \$	003363	002456	-03246	0625	0000	0875	0375	1000	0125	0000	%0412	S17 \$	
003329	001474	-04194	0375	0000	1000	0625	1000	0000	0000	%0251	A18 \$	003317	002098	-04231	0500	0000	1000	0500	1000	0000	0000	%0332	J18 \$	003247	002660	-03985	0625	0000	1000	0375	1000	0000	0000	%0413	S18 \$	
003958	001619	001757	0375	0125	0000	0625	0875	1000	0000	%0252	B10 \$	003975	002871	001995	0500	0125	0000	0500	0875	1000	0000	%0333	K10 \$	004106	003677	002392	0625	0125	0000	0375	0875	1000	0000	%0414	T10 \$	
004066	001764	000787	0375	0125	0125	0625	0875	0875	0000	%0253	B11 \$	004283	002388	001167	0500	0125	0125	0500	0875	0875	0000	%0334	K11 \$	004615	003291	001448	0625	0125	0125	0375	0875	0875	0000	%0415	T11 \$	
004055	001904	-00099	0375	0125	0250	0625	0875	0750	0000	%0254	B12 \$	004352	002511	000417	0500	0125	0250	0500	0875	0750	0000	%0335	K12 \$	004620	003323	000874	0625	0125	0250	0375	0875	0750	0000	%0416	T12 \$	
003980	001835	-00764	0375	0125	0375	0625	0875	0625	0000	%0255	B13 \$	004198	002466	-00563	0500	0125	0375	0500	0875	0625	0000	%0336	K13 \$	004661	003429	0008072	0625	0125	0375	0375	0875	0625	0000	%0417	T13 \$	
003910	001872	-01492	0375	0125	0500	0625	0875	0500	0000	%0256	B14 \$	004036	001546	-01009	0500	0125	0500	0500	0875	0500	0000	%0337	K14 \$	004446	002961	-00838	0625	0125	0500	0375	0875	0500	0000	%0418	T14 \$	
003737	001856	-02266	0375	0125	0625	0625	0875	0375	0000	%0257	B15 \$	003964	001453	-01814	0500	0125	0625	0500	0875	0375	0000	%0338	K15 \$	004231	002096	-01273	0625	0125	0625	0375	0875	0375	0000	%0419	T15 \$	
003849	001872	-02755	0375	0125	0750	0625	0875	0250	0000	%0258	B16 \$	003783	001698	-02569	0500	0125	0750	0500	0875	0250	0000	%0339	K16 \$	004049	002151	-02167	0625	0125	0750	0375	0875	0250	0000	%0420	T16 \$	
004107	001819	-03161	0375	0125	0875	0625	0875	0125	0000	%0259	B17 \$	003858	001585	-03157	0500	0125	0875	0500	0875	0125	0000	%0340	K17 \$	004034	002092	-02809	0625	0125	0875	0375	0875	0125	0000	%0421	T17 \$	
004314	000724	-03528	0375	0125	1000	0625	0875	0000	0000	%0260	B18 \$	004131	001359	-03654	0500	0125	1000	0500	0875	0000	0000	%0341	K18 \$	004093	001970	-03457	0625	0125	1000	0375	0875	0000	0000	%0422	T18 \$	
004348	001131	-002218	0375	0250	0000	0625	0750	1000	0000	%0261	C10 \$	004514	002082	-02590	0500	0250	0000	0500	0750	1000	0000	%0342	L10 \$	004677	002836	003079	0625	0250	0000	0375	0750	1000	0000	%0423	U10 \$	
004520	001063	001441	0375	0250	0125	0625	0750	0875	0000	%0262	C11 \$	004725	001894	000888	0500	0250	0125	0500	0750	0875	0000	%0343	L11 \$	004860	002860	002366	0625	0250	0125	0375	0750	0875	0000	%0424	U11 \$	
004889	000904	000389	0375	0250	0250	0625	0750	0750	0000	%0263	C12 \$	005088	001719	000802	0500	0250	0250	0500	0750	0750	0000	%0344	L12 \$	005317	002410	001136	0625	0250	0250	0375	0750	0750	0000	%0425	U12 \$	
004735	000524	-00463	0375	0250	0375	0625	0750	0625	0000	%0264	C13 \$	005058	001779	000041	0500	0250	0375	0500	0750	0625	0000	%0345	L13 \$	005281	002515	000393	0625	0250	0375	0375	0750	0625	0000	%0426	U13 \$	
004565	000525	-01131	0375	0250	0500	0625	0750	0500	0000	%0265	C14 \$	004714	001154	-00703	0500	0250	0500	0500	0750	0500	0000	%0346	L14 \$	005167	002352	-00441	0625	0250	0500	0375	0750	0500	0000	%0427	U14 \$	
004731	000517	-01576	0375	0250	0625	0625	0750	0375	0000	%0266	C15 \$	004748	001083	-01354	0500	0250	0625	0500	0750	0375	0000	%0347	L15 \$	004904	001639	-01057	0625	0250	0625	0375	0750	0375	0000	%0428	U15 \$	
004843	000523	-02100	0375	0250	0750	0625	0750	0250	0000	%0267	C16 \$	004660	001071	-02092	0500	0250	0750	0500	0750	0250	0000	%0348	L16 \$	004892	001598	-01615	0625	0250	0750	0375	0750	0250	0000	%0429	U16 \$	
005066	000290	-02488	0375	0250	0875	0625	0750	0125	0000	%0268	C17 \$	004826	000935	-02508	0500	0250	0875	0500	0750	0125	0000	%0349	L17 \$	004864	001445	-02197	0625	0250	0875	0375	0750	0125	0000	%0430	U17 \$	
005231	000289	-03047	0375	0250	1000	0625	0750	0000	0000	%0269	C18 \$	005002	000793	-02939	0500	0250	1000	0500	0750	0000	0000	%0350	L18 \$	004796	001403	-02874	0625	0250	1000	0375	0750	0000	0000	%0431	U18 \$	
004863	000222	002791	0375	0375	0000	0625	0625	1000	0000	%0270	D10 \$	005017	001204	003342	0500	0375	0000	0500	0625	1000	0000	%0351	M10 \$	005202	002062	003627	0625	0375	0000	0375	0625	1000	0000	%0432	V10 \$	
005124	000161	001990	0375	0375	0125	0625	0625	0875	0000	%0271	D11 \$	005198	001196	002407	0500	0375	0125	0500	0625	0875	0000	%0352	M11 \$	005398	001954	002840	0625	0375	0125	0375	0625	0875	0000	%0433	V11 \$	
005214	000106	000989	0375	0375	0250	0625	0625	0750	0000	%0272	D12 \$	005433	001037	001476	0500	0375	0250	0500	0625	0750	0000	%0353	M12 \$	005651	001883	001868	0625	0375	0250	0						

See original or copy: <http://web.me.com/klau.richter/HE70/HE70L0NA.TXT> /PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

004145	005216	002500	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
004195	005251	001647	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
004217	005165	000774	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
004131	005198	000772	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
003778	004770	000774	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
003471	003858	001520	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
003172	003056	002107	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
003176	003053	002885	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$
003254	003179	003552	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$
004382	004556	003095	0750	0125	0000	0250	0875	1000	0000	%0495	B19	\$
004919	004110	002001	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
004929	004108	001132	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
004923	004187	000375	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
004831	004339	004047	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
004161	003435	001205	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
003818	002767	001785	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
003922	002534	002429	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
004069	002330	003054	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
005056	003545	003679	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
005138	003602	002897	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
005542	003220	001522	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
005528	003383	000743	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
005528	003464	000004	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
004884	002930	000862	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
004512	002212	001424	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
004662	001910	001943	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
004658	001894	002741	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
005461	002802	004166	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
005553	002893	003356	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005691	002867	002306	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
006145	002449	001248	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
006114	002403	000410	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
005964	002393	000397	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
005208	001638	001147	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
005213	001512	001683	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
005367	001543	002389	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
005919	002016	004538	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
006015	002139	003769	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
006228	002019	002865	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006423	001921	001874	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006698	001648	000864	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
006654	001760	000061	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
006050	001114	000728	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
005941	000953	001299	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
006141	001067	002094	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
006453	001242	005203	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
006565	001226	004065	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
006712	001217	003264	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
006893	001141	002360	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
007087	000998	001572	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
007236	000867	000543	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
006959	000526	000380	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
006843	000359	001060	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
007498	000406	001773	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
007007	000251	005754	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
007155	000281	004703	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
007245	000282	003789	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
007387	000202	002849	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$
007588	000074	002108	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007700	000141	001136	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
007706	000126	000117	0750	0750	0875	0250	0250	0250	0000	%0546	G25	\$
007750	000016	000550	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$
008113	001916	001273	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$
007969	000847	0007138	0750	0875	0000	0250	0125	0875	0000	%0549	H19	\$
007884	000902	005429	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$
007905	000884	004742	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$
007986	000978	003677	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$
008006	000924	002599	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$
008050	001046	001513	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$
007974	000622	000323	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$
007895	000535	003040	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$
008065	000556	001218	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$
008286	002085	000727	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$
008253	001961	005832	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$
008250	002012	004997	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$
008390	002176	004078	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$
008383	002154	002964	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$
008344	002128	002038	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$
008575	001665	000501	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$
008617	001491	002025	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$
008368	001189	001020	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$
004404	006107	002920	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$
004484	006094	002603	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$
004475	006080	001210	0875									

See original or copy: <http://web.me.com/klaus.richter/HE70/HE70L0NA.TXT> /PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

009753	-00072	000197	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009042	-00656	-00412	0875	1000	1000	0000	0125	0000	0000	%0730	b02	\$
008547	-01044	-00913	0750	1000	1000	0000	0250	0000	0000	%0731	b03	\$
008053	-01580	-00862	0625	1000	1000	0000	0375	0000	0000	%0732	b04	\$
007328	-01976	-01204	0500	1000	1000	0000	0500	0000	0000	%0733	b05	\$
006773	-02479	-01793	0375	1000	1000	0000	0625	0000	0000	%0734	b06	\$
006175	-03088	-02341	0250	1000	1000	0000	0750	0000	0000	%0735	b07	\$
005733	-03690	-02629	0125	1000	1000	0000	0875	0000	0000	%0736	b08	\$
005365	-04179	-02824	0000	1000	1000	0000	1000	0000	0000	%0737	b09	\$
009022	000908	000240	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
008705	000107	000130	0875	0875	0875	0000	0125	0125	0125	%0739	c02	\$
008211	-00422	-00306	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
007500	-01006	-00740	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
006941	-01438	-01035	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
006498	-01918	-01452	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
005925	-02510	-02016	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005431	-02971	-02397	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
004928	-03351	-02669	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
004843	001520	000975	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
008137	000732	000551	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
007907	000141	000076	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
007255	-00520	-00367	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
006683	-00997	-00757	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
006207	-01534	-01094	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
005559	-02027	-01584	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005059	-02496	-01999	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
004618	-02876	-02357	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007738	002582	001151	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007643	001559	000883	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
007385	000813	000463	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006894	000131	000014	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
006316	-00382	-00305	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
005897	-00935	-00609	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
005287	-01557	-01283	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
004761	-01978	-01677	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004267	-02412	-02033	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007163	003394	001645	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
007019	002437	001161	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006800	001589	000748	0750	0500	0500	0000	0250	0500	0000	%0767	f03	\$
006256	000882	000412	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005903	000105	000123	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005457	-00369	-00309	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
005123	-01066	-00866	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004488	-01602	-01354	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
004026	-01888	-01570	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006613	004275	001960	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
006398	003354	001541	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
006105	002480	001174	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005633	001770	000768	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
005448	000996	000391	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
005101	000175	-00007	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004757	-00432	-00485	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
004383	-01057	-00866	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003698	-01423	-01310	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
006129	005948	002483	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005726	004116	001897	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
005408	003210	001528	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
005027	002516	001210	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
004846	001778	000818	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
004688	000914	000385	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
004234	000196	-00051	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
003987	-00445	-00533	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
003478	-00963	-00909	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
005517	006097	003196	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
005090	004711	002370	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
004755	004139	002086	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
004320	003328	001587	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
004059	002420	001204	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
003872	001741	000779	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
003875	000896	000267	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
003526	000668	-00009	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
003224	-00446	-00520	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
004843	006912	003527	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
004238	006082	003153	0875	0000	0000	0125	1000	1000	0000	%0802	j02	\$
003974	005176	002615	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
003698	004136	001996	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
003476	003276	001593	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
003367	002607	001060	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
003342	001722	000764	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
003050	000979	000197	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
002722	000077	-00173	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009737	-00066	000189	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
008917	-00016	-00664	0875	0875	0875	0125	0125	0000	0000	%0811	b11	\$
008380	-00136	-01112	0750	0750	0750	0250	0250	0000	0000	%0812	b12	\$
007726	-00153	-01494	0625	0625	0625	0375	0375	0000	0000	%0813	b13	\$
006731	-00044	-01892	0500	0500	0500	0500	0500	0000	0000	%0814	b14	\$
006055	-00176	-02483	0375	0375	0375	0625	0625	0000	0000	%0815	b15	\$
005359	-00277	-02953	0250	0250	0250	0750	0750	0000	0000	%0816	b16	\$
004636	-00314	-03561	0125	0125	0125	0875	0875	0000	0000	%0817	b17	\$
004067	-00562	-03859	0000	0000	0000	1000	1000	0000	0000	%0818	b18	\$
009521	000061	000833	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$
008880	000076	000130	0875	0875	0875	0125	0125	0125	0000	%0820	c11	\$
008174	000057	-00440	0750	0750	0750	0250	0250	0125	0000	%0821	c12	\$
007449	-00176	-00897	0625	0625	0875	0375	0375	0125	0000	%0822	c13	\$
006577	000010	-01433	0500	0500	0500	0500	0500	0125	0000	%0823	c14	\$
005911	-00204	-01920	0375	0375	0875	0625	0625	0125	0000	%0824	c15	\$
005235	-00298	-02462	0250	0250	0875	0750	0750	0125	0000	%0825	c16	\$
004486	-00168	-03094	0125	0125	0875	0875	0875	0125	0000	%0826	c17	\$
003789	-00220	-03632	0000	0000	0750	1000	1000	0125	0000	%0827	c18	\$
002921	000196	0001481	1000	1000	0750	0000	0000	0250	0000	%0828	d10	\$
008687	000071	001103	0875	0875	0750	0125	0125					

%BEG HE60_22.TXT, Separation olv*, cf1=0.90, D50, not adapted \$
%100 x LAB* %1000 x (r g b c m y 0) %nr. pos \$
%z004937 006819 003274 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008475 000383 008395 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005470 -05220 001650 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005371 -04295 -02823 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z004142 -00522 -03893 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003714 004027 -02593 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z002491 000075 -00098 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009725 -00069 000203 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004843 006912 003527 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008475 000377 008495 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005526 -05128 001398 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005365 -04179 -02824 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z004067 -00562 -03959 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003692 004085 -02570 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z002635 000077 -00150 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009737 -00067 000195 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

BEEG HE60 22.TXT, Separation olv*, cf1=0.90, D50, not adapted \$		1000 x (r g b c m y o)		%n r.		pos \$	
%100 x LAB*							
002387 000807	-00122	0090 0000	0000 1000	1000 0000	0000	%0972	k01 \$
002382 000876	-00008	0125 0125	0125 0125	0875 0875	0875	%0973	k02 \$
004024 000215	-00040	0250 0250	0250 0250	0750 0750	0750	%0974	k03 \$
004891 000229	-00005	0375 0375	0375 0625	0625 0625	0000	%0975	k04 \$
005792 000118	-00020	0500 0500	0500 0500	0500 0500	0000	%0976	k05 \$
006831 000149	-00025	0625 0625	0625 0375	0375 0375	0000	%0977	k06 \$
007921 000133	-00008	0750 0750	0750 0250	0250 0250	0000	%0978	k07 \$
008831 000128	-00015	0875 0875	0875 0125	0125 0125	0000	%0979	k08 \$
009753 -00065	-00017	1000 1000	1000 0000	0000 0000	0000	%0980	k09 \$
002518 000082	-00120	0000 0000	0000 1000	1000 0000	0000	%0981	l01 \$
003293 000064	-00017	0125 0125	0125 0875	0875 0875	0000	%0982	l02 \$
004123 000195	-00054	0250 0250	0250 0750	0750 0750	0000	%0983	l03 \$
005008 000199	-00000	0375 0375	0375 0625	0625 0000	0000	%0984	l04 \$
005877 000101	-00008	0500 0500	0500 0500	0500 0500	0000	%0985	l05 \$
006952 000099	-00028	0625 0625	0625 0375	0375 0375	0000	%0986	l06 \$
007978 000110	-00087	0750 0750	0750 0250	0250 0250	0000	%0987	l07 \$
008863 000100	-00016	0875 0875	0875 0125	0125 0125	0000	%0988	l08 \$
009764 -00068	-00019	1000 1000	1000 0000	0000 0000	0000	%0989	l09 \$
002485 -00009	-00110	0000 0000	0000 1000	1000 0000	0000	%0990	m01 \$
003282 000066	-00053	0125 0125	0125 0875	0875 0875	0000	%0991	m02 \$
004115 000144	-00003	0250 0250	0250 0750	0750 0750	0000	%0992	m03 \$
004900 000180	-00004	0375 0375	0375 0625	0625 0000	0000	%0993	m04 \$
005865 -00006	-00007	0500 0500	0500 0500	0500 0500	0000	%0994	m05 \$
006919 000188	-00035	0625 0625	0625 0375	0375 0375	0000	%0995	m06 \$
007983 000101	-00097	0750 0750	0750 0250	0250 0250	0000	%0996	m07 \$
008859 000065	-00014	0875 0875	0875 0125	0125 0125	0000	%0997	m08 \$
009760 -00069	-00019	1000 1000	1000 0000	0000 0000	0000	%0998	m09 \$
002470 000079	-00113	0000 0000	0000 1000	1000 0000	0000	%0999	n01 \$
003262 000064	-00001	0125 0125	0125 0875	0875 0875	0000	%1000	n02 \$
004075 000197	-00058	0250 0250	0250 0750	0750 0750	0000	%1001	n03 \$
004922 000210	-00018	0375 0375	0375 0625	0625 0000	0000	%1002	n04 \$
005846 000111	-00019	0500 0500	0500 0500	0500 0500	0000	%1003	n05 \$
006946 000116	-00003	0625 0625	0625 0375	0375 0375	0000	%1004	n06 \$
007941 000116	-00009	0750 0750	0750 0250	0250 0250	0000	%1005	n07 \$
008815 000114	-00015	0875 0875	0875 0125	0125 0125	0000	%1006	n08 \$
009750 -00066	-00017	1000 1000	1000 0000	0000 0000	0000	%1007	n09 \$
002712 000067	-00178	0000 0000	0000 1000	1000 0000	0000	%1008	k10 \$
003226 000106	-00087	0066 0066	0066 0933	0933 0933	0000	%1009	k11 \$
004383 000045	-00011	0133 0133	0133 0866	0866 0866	0000	%1010	k12 \$
004001 000126	-00081	0200 0200	0200 0800	0800			

TUB-test chart HE70; Relative Elementary Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

TUB registration: 20091101-HE70/HE70LONA.TXT /.PS
- application for evaluation and measurement of printer or

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/HE70/HE70L0NA.TXT> /PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

%BEG HE60.22.TXT, Separation olv*, cfi=0.90, D50, adapted \$																													
%100 x LAB*a										1000 x (r g b c m y o)										kmr. pos \$									

See original or copy: <http://web.me.com/klaus.richter/HE70/HE70L0NA.TXT> /PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

003532	002595	001334	0375	0000	0000	0625	1000	1000	0000	%0243	A10	\$
003564	002578	000354	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$
003464	002483	-004087	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$
003313	001521	-01074	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$
003207	001530	-01780	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$
003249	001591	-02261	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$
003314	002096	-03166	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$
003335	001418	-04130	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$
003328	001415	-04130	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$
003958	001573	-001784	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$
004066	001719	000820	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$
004055	001859	-00066	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$
003988	000989	-00727	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$
003910	001025	-01453	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$
003737	001006	-02219	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$
003849	001023	-02713	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$
004107	000976	-03129	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$
004314	000685	-03505	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$
004348	001092	-00240	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$
004520	001028	-001455	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$
004889	000877	-000388	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$
004735	000493	-00458	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$
004565	000491	-01119	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$
004731	000487	-01571	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$
004843	000495	-02100	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$
005066	000266	-02497	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$
005231	000268	-03062	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$
005463	000193	-002791	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$
005124	000138	-001979	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$
005214	000085	-000974	0375	0375	0250	0625	0625	0750	0000	%0272	D12	\$
005210	000146	-00025	0375	0375	0375	0625	0625	0625	0000	%0273	D13	\$
005337	000035	-00408	0375	0375	0500	0625	0625	0500	0000	%0274	D14	\$
005583	000089	-01033	0375	0375	0625	0625	0625	0375	0000	%0275	D15	\$
005740	-00120	-01676	0375	0375	0750	0625	0625	0250	0000	%0276	D16	\$
005872	-00172	-01985	0375	0375	0875	0625	0625	0125	0000	%0277	D17	\$
006052	-00165	-02517	0375	0375	1000	0625	0625	0000	0000	%0278	D18	\$
005465	-00905	-003548	0375	0500	0000	0625	0500	1000	0000	%0279	D19	\$
005429	-00902	-002353	0375	0500	0125	0625	0500	0875	0000	%0280	E11	\$
005543	-00846	-001305	0375	0500	0250	0625	0500	0750	0000	%0281	E12	\$
005435	-00574	-000197	0375	0500	0375	0625	0500	0625	0000	%0282	E13	\$
005422	-00403	-00377	0375	0500	0500	0625	0500	0500	0000	%0283	E14	\$
005751	-00629	-00995	0375	0500	0625	0625	0500	0375	0000	%0284	E15	\$
005866	-00587	-01615	0375	0500	0750	0625	0500	0250	0000	%0285	E16	\$
005997	-00541	-01999	0375	0500	0875	0625	0500	0125	0000	%0286	E17	\$
006157	-00617	-02497	0375	0500	1000	0625	0500	0000	0000	%0287	E18	\$
005636	-01915	-003532	0375	0625	0000	0625	0375	1000	0000	%0288	F10	\$
005723	-01867	-002449	0375	0625	0125	0625	0375	0875	0000	%0289	F11	\$
005747	-01772	-001509	0375	0625	0250	0625	0375	0750	0000	%0290	F12	\$
005887	-01309	-000249	0375	0625	0375	0625	0375	0625	0000	%0291	F13	\$
005837	-01126	-00355	0375	0625	0500	0625	0375	0500	0000	%0292	F14	\$
005864	-01007	-00795	0375	0625	0625	0625	0375	0375	0000	%0293	F15	\$
005973	-00990	-01606	0375	0625	0750	0625	0375	0250	0000	%0294	F16	\$
006189	-01071	-02049	0375	0625	0875	0625	0375	0125	0000	%0295	F17	\$
006326	-01169	-02418	0375	0625	1000	0625	0375	0000	0000	%0296	F18	\$
005931	-02776	-003720	0375	0750	0000	0625	0250	1000	0000	%0297	G10	\$
005948	-02726	-002615	0375	0750	0125	0625	0250	0875	0000	%0298	G11	\$
005983	-02748	-001631	0375	0750	0250	0625	0250	0750	0000	%0299	G12	\$
006255	-02920	-004653	0375	0750	0375	0625	0250	0625	0000	%0300	G13	\$
006168	-01782	-00180	0375	0750	0500	0625	0250	0500	0000	%0301	G14	\$
006167	-01677	-00739	0375	0750	0625	0250	0250	0375	0000	%0302	G15	\$
006147	-01621	-01146	0375	0750	0750	0625	0250	0250	0000	%0303	G16	\$
006379	-01820	-01862	0375	0750	0875	0625	0250	0125	0000	%0304	G17	\$
006519	-01681	-02383	0375	0750	1000	0625	0250	0000	0000	%0305	G18	\$
006254	-03772	-004276	0375	0875	0000	0625	0125	1000	0000	%0306	H10	\$
006238	-03372	-002778	0375	0875	0125	0625	0125	0875	0000	%0307	H11	\$
006097	-03410	-001790	0375	0875	0250	0625	0125	0750	0000	%0308	H12	\$
006488	-02515	-000504	0375	0875	0375	0625	0125	0625	0000	%0309	H13	\$
006434	-02404	-00091	0375	0875	0500	0625	0125	0500	0000	%0310	H14	\$
006407	-02281	-00562	0375	0875	0625	0625	0125	0375	0000	%0311	H15	\$
006389	-02164	-01127	0375	0875	0750	0625	0125	0250	0000	%0312	H16	\$
006420	-02035	-01495	0375	0875	0875	0625	0125	0125	0000	%0313	H17	\$
006712	-02399	-02309	0375	0875	1000	0625	0125	0000	0000	%0314	H18	\$
006450	-04646	-004464	0375	1000	0000	0625	0000	1000	0000	%0315	I10	\$
006502	-04529	-003269	0375	1000	0125	0625	0000	0875	0000	%0316	I11	\$
006533	-04322	-002079	0375	1000	0250	0625	0000	0750	0000	%0317	I12	\$
007046	-03388	-000909	0375	1000	0375	0625	0000	0625	0000	%0318	I13	\$
006948	-03149	-000605	0375	1000	0500	0625	0000	0500	0000	%0319	I14	\$
006866	-02989	-00302	0375	1000	0625	0000	0000	0375	0000	%0320	I15	\$
006805	-02780	-00727	0375	1000	0750	0625	0000	0250	0000	%0321	I16	\$
006808	-02651	-01350	0375	1000	0875	0625	0000	0125	0000	%0322	I17	\$
006762	-02622	-01792	0375	1000	1000	0625	0000	0000	0000	%0323	I18	\$
003655	003153	000585	0500	0000	0000	0500	1000	1000	0000	%0324	J10	\$
003701	003199	000775	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$
003711	003234	-00087	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$
003568	002764	-00780	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$
003402	002074	-01349	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$
003257	001809	-02056	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$
003327	002004	-03170	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$
003354	000222	-03131	0500	0000	0875	0500	1000	0125	0000	%0331	J17	\$
003317	002027	-04167	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$
003975	002825	-02032	0500	0125	0000	0500	0875	1000	0000	%0333	K10	\$
004023	002348	-001191	0500	0125	0125	0500	0875	0875	0000	%0334	K11	\$
004352	002472	-000438	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$
004198	002425	-00535	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$
004036	001501	-00975	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$
003964	001407	-01777	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$
003783	001648	-02525	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$
003858	001537	-03116	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$
004131	001316	-03624	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$
004514	002047	-002604	0500	0250	0000	0500	0750	1000	0000	%0342	L10	\$
004725	001864	-000189	0500	0250	0125	0500	0750	0875	0000	%03		

See original or copy: <http://web.me.com/klaustrichter/HE70/HE70L0NA.TXT> /PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

004145	005174	002530	0750	0000	0000	0000	0250	1000	1000	0000	%0486	A19	\$	004404	006069	002939	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$	004937	006792	003271	1000	0000	0000	0000	0000	1000	0000	0000	%0648	S19	\$
004195	005210	001675	0750	0000	0000	0125	0250	1000	0875	0000	%0487	A20	\$	004484	006058	002049	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$	004894	006753	002521	1000	0000	0125	0000	0125	1000	0875	0000	%0649	S20	\$
004217	005124	000801	0750	0000	0000	0250	0250	1000	0750	0000	%0488	A21	\$	004475	006044	001226	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$	004857	007020	001530	1000	0000	0250	0000	0750	1000	0750	0000	%0650	S21	\$
004131	005155	000003	0750	0000	0000	0375	0250	1000	0625	0000	%0489	A22	\$	004563	005876	000308	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$	004925	006903	000500	1000	0000	0375	0775	1000	0625	0000	%0651	S22	\$	
003378	004720	-00729	0750	0000	0000	0500	0250	1000	0500	0000	%0490	A23	\$	004544	005745	-00321	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$	004926	006845	000001	1000	0000	0500	0500	1000	0500	0000	%0652	S23	\$	
003471	003802	-01462	0750	0000	0000	0625	0250	1000	0375	0000	%0491	A24	\$	004031	005282	-01155	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$	004959	006944	-00934	1000	0000	0625	1000	0375	1000	0375	%0653	S24	\$	
003172	002994	-02037	0750	0000	0000	0750	0250	1000	0250	0000	%0492	A25	\$	003532	004564	-01777	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$	004268	005524	-01539	1000	0000	0750	0000	1000	0250	0000	%0654	S25	\$	
003176	002991	-02815	0750	0000	0875	0250	1000	0125	0000	0000	%0493	A26	\$	003402	003615	-02341	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$	003795	004629	-02091	1000	0000	0875	1000	0125	0000	0125	%0655	S26	\$	
003254	003119	-03486	0750	0000	1000	0250	1000	0000	0000	0000	%0494	A27	\$	003561	003616	-03109	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$	003714	003976	-02545	1000	0000	1000	0000	1000	0000	0000	%0656	S27	\$	
004382	004518	003115	0750	0125	0000	0250	0875	1000	0000	0000	%0495	B19	\$	004534	005664	003817	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$	004899	006720	004268	1000	0125	0000	0000	0875	1000	0000	%0657	T19	\$	
004919	004083	001999	0750	0125	0125	0250	0875	0875	0000	0000	%0496	B20	\$	005203	004697	002259	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$	005522	006032	002856	1000	0125	0125	0000	0875	0875	0000	%0658	T20	\$	
004929	004081	001129	0750	0125	0250	0250	0875	0750	0000	0000	%0497	B21	\$	005183	004855	001428	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$	005537	006079	001921	1000	0125	0250	0500	0875	0750	0000	%0659	T21	\$	
004923	004160	000372	0750	0125	0375	0250	0875	0625	0000	0000	%0498	B22	\$	005183	004867	000695	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$	005523	006107	001205	1000	0125	0375	0000	0875	0625	0000	%0660	T22	\$	
004831	004311	-00406	0750	0125	0500	0250	0875	0500	0000	0000	%0499	B23	\$	005166	004871	000072	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$	005538	006107	000362	1000	0125	0500	0000	0875	0500	0000	%0661	T23	\$	
004161	003393	-01176	0750	0125	0625	0250	0875	0375	0000	0000	%0500	B24	\$	004912	004647	-00816	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$	005401	006255	-00693	1000	0125	0625	0000	0875	0375	0000	%0662	T24	\$	
003818	002718	-01742	0750	0125	0750	0250	0875	0250	0000	0000	%0501	B25	\$	004294	003838	-01477	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$	004972	004955	-01081	1000	0125	0750	0750	0875	0250	0000	%0663	T25	\$	
003922	002487	-02390	0750	0125	0875	0250	0875	0125	0000	0000	%0502	B26	\$	004088	003094	-01923	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$	004728	004722	-01753	1000	0125	0875	0000	0875	0125	0000	%0664	T26	\$	
004069	002286	-03022	0750	0125	1000	0250	0875	0000	0000	0000	%0503	B27	\$	004182	002923	-02567	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$	004381	003458	-02122	1000	0125	1000	0000	0875	0000	0000	%0665	T27	\$	
005056	003521	003670	0750	0250	0000	0000	0250	0750	1000	0000	%0504	C19	\$	005206	004105	003883	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$	005470	005759	004915	1000	0250	0000	0000	0750	1000	0000	%0666	U19	\$	
005138	003579	002885	0750	0250	0125	0250	0750	0875	0000	0000	%0505	C20	\$	005358	004265	003045	0875	0250	0125	0125	0750	0875	0000	%0586	L20	\$	005564	005833	003965	1000	0250	0125	0000	0750	0875	0000	%0667	U20	\$	
005542	003206	001493	0750	0250	0250	0250	0750	0750	0000	0000	%0506	C21	\$	005832	004059	001811	0875	0250	0250	0125	0750	0750	0000	%0587	L21	\$	006140	004987	002314	1000	0250	0375	0000	0750	0750	0000	%0668	U21	\$	
005528	003368	000715	0750	0250	0375	0250	0750	0625	0000	0000	%0507	C22	\$	005852	004192	001129	0875	0250	0375	0125	0750	0625	0000	%0588	L22	\$	006144	005110	001647	1000	0250	0375	0000	0750	0625	0000	%0669	U22	\$	
005528	003449	-00623	0750	0250	0500	0250	0750	0500	0000	0000	%0508	C23	\$	005852	004192	001129	0875	0250	0375	0125	0750	0625	0000	%0588	L23	\$	006144	005110	001647	1000	0250	0375	0000	0750	0625	0000	%0670	U23	\$	
004884	002902	-00863	0750	0250	0625	0250	0750	0375	0000	0000	%0509	C24	\$	005700	004209	-00310	0875	0250	0625	0125	0750	0375	0000	%0589	L24	\$	006209	005053	00013	1000	0250	0625	0250	0750	0375	0000	%0671	U24	\$	
004512	002176	-01410	0750	0250	0750	0250	0750	0250	0000	0000	%0510	C25	\$	005154	003371	-01136	0875	0250	0750	0125	0750	0250	0000	%0591	L25	\$	006518	004640	-00792	1000	0250	0625	0750	0750	0250	0000	%0672	U25	\$	
004662	001878	-01934	0750	0250	0875	0250	0750	0125	0000	0000	%0511	C26	\$	004728	002654	-01609	0875	0250	0875	0125	0750	0125	0000	%0592	L26	\$	006540	003763	-01459	1000	0250	0875	0750	0125	0000	0125	%0673	U26	\$	
004658	001862	-02733	0750	0250	1000	0250	0750	0000	0000	0000	%0512	C27	\$	004823	002394	-02306	0875	0250	1000	0125	0750	0000	0000	%0593	L27	\$	006522	003109	-01932	1000	0250	1000	0000	0750	0000	0000	%0674	U27	\$	
005461	002786	004141	0750	0375	0000	0250	0625	1000	0000	0000	%0513	D19	\$	005693	003499	004424	0875	0375	0000	0125	0625	1000	0000	%0594	M19	\$	005930	0												

009753	-00004	000000	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009042	-00603	-00574	0875	1000	1000	0000	0125	0000	0000	%0730	b02	\$
008547	-01000	-01051	0750	1000	1000	0000	0250	0000	0000	%0731	b03	\$
008053	-01547	-00975	0625	1000	1000	0000	0375	0000	0000	%0732	b04	\$
007328	-01958	-01282	0500	1000	1000	0000	0500	0000	0000	%0733	b05	\$
006773	-02472	-01844	0375	1000	1000	0000	0625	0000	0000	%0734	b06	\$
006175	-03093	-02363	0250	1000	1000	0000	0750	0000	0000	%0735	b07	\$
005733	-03704	-02630	0125	1000	1000	0000	0875	0000	0000	%0736	b08	\$
005365	-04201	-02806	0000	1000	1000	0000	1000	0000	0000	%0737	b09	\$
009022	000661	000079	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
008705	000153	-00014	0875	0875	0875	0000	0125	0125	0125	%0739	c02	\$
008211	-00386	-00427	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
007500	-00984	-00827	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
006941	-01427	-01095	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
006498	-01917	-01490	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
005925	-02520	-02026	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005431	-02991	-02383	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
004928	-03382	-02631	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
004843	001562	000841	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
008137	000767	000433	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
007907	000172	-00029	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
007255	-00503	-00442	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
006683	-00992	-00804	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
006207	-01539	-01118	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
005559	-02045	-01576	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005059	-02524	-01967	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
004618	-02913	-02303	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007738	002608	001053	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007643	001583	000789	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
007385	000832	000382	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006894	000140	-00042	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
006316	-00384	-00334	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
005897	-00947	-00708	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
005287	-01580	-01262	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
004761	-02012	-01631	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004267	-02457	-01962	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007163	003409	001574	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
007019	002449	001098	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006800	001596	000695	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$
006256	000878	000386	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005903	000094	000114	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005457	-00389	-00377	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
005123	-01093	-00836	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004488	-01641	-01294	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
004026	-01937	-01487	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006613	004279	001917	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
006398	003353	001508	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
006105	002474	001155	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005633	001753	000772	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
005448	000975	000404	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
005101	000148	000022	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004757	-00466	-00438	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
004383	-01099	-00801	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003698	-01479	-01211	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
006129	005041	002463	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005726	004102	001897	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
005408	003190	001543	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
005027	002408	001242	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
004846	001745	000861	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
004688	000879	000435	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
004234	000151	000021	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
003987	-00495	-00449	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
003478	-01824	-00800	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
005517	006078	003206	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
005090	004683	002401	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
004755	004105	002133	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
004320	003285	001656	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
004059	002372	001285	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
003872	001688	000870	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
003875	000844	000357	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
003526	000008	000097	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
003224	-00511	-00398	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
004843	006879	003570	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
004238	006038	003225	0875	0000	0000	0125	1000	1000	0000	%0802	j02	\$
003974	005126	002700	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
003698	004080	002095	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
003476	003216	001702	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
003367	002545	001175	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
003342	001659	000880	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
003050	000918	000328	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
002722	000002	-00027	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009737	000001	-00006	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
008917	000034	-00820	0875	0875	0875	0100	0125	0125	0000	%0811	b11	\$
008380	-00907	-01242	0750	0750	0750	0250	0250	0250	0000	%0812	b12	\$
007726	-00126	-01592	0625	0625	0625	0375	0375	0375	0000	%0813	b13	\$
006731	-00938	-01941	0500	0500	0500	0500	0500	0500	0000	%0814	b14	\$
006055	-00184	-02509	0375	0375	0375	0625	0625	0625	0000	%0815	b15	\$
005359	-00299	-02935	0250	0250	0250	0750	0750	0750	0000	%0816	b16	\$
004636	-00350	-03491	0125	0125	0125	0875	0875	0875	0000	%0817	b17	\$
004067	-00511	-03879	0000	0000	0000	1000	1000	1000	0000	%0818	b18	\$
009521	000124	000648	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$
008880	000126	-00023	0875	0875	0875	0125	0125	0125	0000	%0820	c11	\$
008174	000093	-00560	0750	0750	0750	0250	0250	0125	0000	%0821	c12	\$
007449	-00155	-00982	0625	0625	0625	0375	0375	0125	0000	%0822	c13	\$
006577	000013	-01474	0500	0500	0500	0500	0500	0125	0000	%0823	c14	\$
005911	-00215	-01929	0375	0375	0375	0625	0625	0125	0000	%0824	c15	\$
005235	-00323	-02439	0250	0250	0250	0750	0750	0125	0000	%0825	c16	\$
004486	-00208	-03063	0125	0125	0125	0875	0875	0125	0000	%0826	c17	\$
003789	-00274	-03538	0000	0000	0750	1000	1000	0125	0000	%0827	c18	\$
002921	000255	001307	1000	1000	1000	0500	0500	0250	0000	%0828	d10	\$
008687	000117	000959	0875	0875	0750	0125	0125	0250	0000	%0829	d11	

%BEG HE60_22.TXT, Separation olv*, cf1=0.90, D50, adapted \$
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos \$
%z004937 006792 003271 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008475 000427 008244 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005470 -05236 001624 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005371 -04313 -02844 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z004142 -00565 -03863 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003714 003976 -02545 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z002491 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009725 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004843 006879 003570 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008475 000419 008361 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005526 -05146 001408 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005365 -04201 -02806 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z004067 -00611 -03879 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003692 004029 -02471 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z002635 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009737 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/HE70/HE70L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

%BEG HE60 22.TXT, Separation olv*, cfi=0.90, D50, adapted \$		%100 x LAB*a		1000 x (r g b		c m y θ		%nrr. pos \$																	
002387	000006	000050	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$	008593	000041	000044	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$
003202	000012	000124	0125	0125	0125	0875	0875	0875	0000	%0973	k02	\$	009124	000115	-00228	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$
004024	000168	000046	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$	009745	-00002	000007	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$
004891	000199	000060	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$	002735	000002	-00005	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$
005792	000105	000126	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	003259	000052	000042	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$
006831	000157	-00019	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$	003596	-00006	000143	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$
007921	000164	-00010	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$	003992	000083	000015	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$
008831	000177	-00018	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$	004289	000147	000052	0266	0266	0266	0333	0333	0333	0000	%1060	n14	\$
009753	000001	000011	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$	004772	000093	000111	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$
002518	000004	000045	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$	005221	000159	000135	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$
003293	000001	000110	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$	005694	000186	000079	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$
004123	000150	000033	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$	006169	000115	000095	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$
005008	000171	000045	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$	006626	000176	000056	0600	0600	0600	0400	0400	0400	0000	%1065	n19	\$
005877	000091	000090	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	007328	000129	000011	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$
006952	000110	-00023	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$	007764	000154	000008	0734	0734	0734	0266	0266	0266	0000	%1067	n21	\$
007978	000142	-00014	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$	008123	000116	000038	0800	0800	0800	0200	0200	0200	0000	%1068	n22	\$
008863	000149	-00028	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$	008588	000067	000048	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$
009754	-00001	000008	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$	009119	000135	-00216	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$
002485	000011	000049	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$	009738	000001	-00008	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$
003291	000001	000125	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$	002501	000000	000000	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$
004115	000148	000029	0250	0250	0250	0750	0750	0750	0000	%0992	m03	\$	009761	000000	000000	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$
004980	000152	000049	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$	004807	006833	003767	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
005865	000086	000099	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$	005267	-04615	-02409	0000	1000	1000	0000	0000	0000	0000	%1075	l27	\$
006919	000119	-00014	0625	0625	0625	0375	0375	0375	0000	%0995	m06	\$	008424	000534	008495	1000	1000	0000	0000	0000	1000	0000	%1076	m26	\$
007983	000132	-00004	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$	003844	-00501	-03785	0000	0000	1000	1000	0000	0000	0000	%1077	m27	\$
008859	000115	000000	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$	005352	-05337	001720	0000	1000	0000	0000	1000	0000	0000	%1078	n26	\$
009760	-00002	000001	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$	003633	0004057	-02594	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$
002470	000000	000055	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$													
003262	000001	000131	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$	%z004807 006833 003767 ##1000 0000 0000 0000 1000 1000 0000 %1074 126 %03 0 \$												
004075	000150	000031	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$	%z008424 000534 008495 ##1000 1000 0000 0000 0000 1000 0000 %1076 m26 %Y3 1 \$												
004922	000108	000066	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$	%z005352 -05337 001720 ##0000 1000 0000 0000 0000 0000 0000 %1078 n26 %L3 2 \$												
005846	000100	000122	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$	%z005267 -04615 -02409 ##0000 1000 1000 0000 0000 0000 0000 %1075 127 %C3 3 \$												
006946	000127	-00017	0625	0625	0625	0375	0375	0375	0000	%1004	n06	\$	%z003844 -00501 -03785 ##0000 0000 1000 1000 0000 0000 0000 %1077 m27 %V3 4 \$												
007941	000147	-00006	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$	%z003633 004057 -02594 ##1000 0000 0000 0000 0000 0000 0000 %1079 n27 %W3 5 \$												
008815	000162	-00027	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$	%z002501 000000 000000 ##0000 0000 0000 1000 1000 0000 %1072 k26 %W3 6 \$												
009750	000000	-00010	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$	%z009761 000000 000000 ##1000 1000 1000 0000 0000 0000 0000 %1073 k27 %W3 7 \$												
002712	-00006	-00021	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$													
003226	000042	000044	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$	%z002387 000006 000050 ##0000 0000 0000 1000 1000 0000 %0972 k01 %N4 6 \$												
003583	-00011	000125	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$	%z009753 000001 -00011 ##1000 1000 1000 0000 0000 0000 0000 %0980 k09 %W4 7 \$												
004001	000077	000012	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$													
004289	000135	000037	0266	0266	0266	0333	0333	0333	0000	%1012	k14	\$	%z002518 000004 000045 ##0000 0000 0000 1000 1000 0000 %0981 l01 %N5 6 \$												
004740	000098	000117	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$	%z009754 -00001 000008 ##1000 1000 1000 0000 0000 0000 0000 %0989 l09 %W5 7 \$												
005190	000151	000118	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$													
005626	000191	000078	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$	%z002485 000011 000049 ##0000 0000 0000 1000 1000 0000 0000 %0990 m01 %N6 6 \$												
006095	000120	000087	0533	0533	0533	0466	0466	0466	0000	%1016	k18	\$	%z009760 -00002 000001 ##1000 1000 1000 0000 0000 0000 0000 %0998 m09 %W6 7 \$												
006642	000185	000056	0600	0600	0600	0400	0400	0400	0000	%1017	k19	\$													
007709	000110	000021	0666	0666	0666	0333	0333	0333	0000	%1018	k20	\$	%z002470 000000 000055 ##0000 0000 0000 1000 1000 0000 0000 %0999 n01 %N7 6 \$												
007709	000110	000021	0666	0666	0666	0333	0333	0333	0000	%1018	k21	\$	%z009750 000000 -00010 1000 1000 1000 0000 0000 0000 0000 %1007 n09 %W7 7 \$												
008144	000123	000022	0800	0800	0800	0200	0200	0200	0000	%1020	k22	\$													
008588	000046	000051	0866	0866	0866	0133	0133	0133	0000	%1021	k23	\$													
009111	000105	-00242	0933	0933	0933	0066	0066	0066	0000	%1022	k24	\$													
009746	000001	-00008	1000	1000	1000	0000	0000	0000	0000	%1023	k25	\$													
002859	-00007	-00019	0000	0000	0000	1000	1000	1000	0000	%1024	l10	\$													
003333	000043	000039	0066	0066	0066	0933	0933	0933	0000	%1025	l11	\$													
003642	-00020	000124	0133	0133	0133	0866	0866	0866	0000	%1026	l12	\$													
004087	000073	000066	0200	0200	0200	0800	0800	0800	0000	%1027	l13	\$													
004402	000125	000033	0266	0266	0266	0333	0333	0333	0000	%1028	l14	\$													
004839	000081	000102	0333	0333	0333	0666	0666	0666	0000	%1029	l15	\$													
005310	000150	000089	0400	0400	0400	0600	0600	0600	0000	%1030	l16	\$													
005707	000177	000052	0466	0466	0466	0533	0533	0533	0000	%1031	l17	\$													
006191	000108	000046	0533	0533	0533	0466	0466	0466	0000	%1032	l18	\$													
006696	000158	000009	0600	0600	0600	0400	0400	0400	0000	%1033	l19	\$													
007357	000101	000001	0666	0666	0666	0333	0333	0333	0000	%1034	l20	\$													
007870	000132	-00003	0734	0734	0734	0266	0266	0266	0000	%1035															