

TUB-test chart HE74; Relative Elementary Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

input: *w setgray*
output: no change compared to input

TUB registration: 20091101-HE74/HE74L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/HE74/HE74L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.00

See original or copy: <http://web.me.com/klaus.richter/HE74/HE74L0NA.TXT> /PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.0

003018	002346	001200	0375	0000	0000	0000	0025	1000	1000	0000	0000	%0243	A10	\$
002991	002462	000474	0375	0000	0125	0625	1000	1000	0875	0000	0000	%0244	A11	\$
002945	002522	-00472	0375	0000	0250	0625	1000	1000	0750	0000	0000	%0245	A12	\$
002938	001866	-01087	0375	0000	0375	0625	1000	1000	0625	0000	0000	%0246	A13	\$
002933	001852	-01805	0375	0000	0500	0625	1000	1000	0500	0000	0000	%0247	A14	\$
002988	001852	-02347	0375	0000	0625	0625	1000	1000	0375	0000	0000	%0248	A15	\$
002978	002007	-03069	0375	0000	0750	0625	1000	1000	0250	0000	0000	%0249	A16	\$
003210	001702	-03516	0375	0000	0875	0625	1000	1000	0125	0000	0000	%0250	A17	\$
003524	001765	-03926	0375	0000	1000	0625	1000	1000	0000	0000	0000	%0251	A18	\$
003347	001412	-001930	0375	0125	0000	0625	0875	1000	0000	0000	0000	%0252	B10	\$
003578	001324	-000851	0375	0125	0125	0625	0875	0875	0000	0000	0000	%0253	B11	\$
003516	001554	-000816	0375	0125	0250	0625	0875	0750	0000	0000	0000	%0254	B12	\$
003606	000780	-00655	0375	0125	0375	0625	0875	0625	0000	0000	0000	%0255	B13	\$
003638	000943	-01262	0375	0125	0500	0625	0875	0500	0000	0000	0000	%0256	B14	\$
003632	000946	-01912	0375	0125	0625	0625	0875	0375	0000	0000	0000	%0257	B15	\$
003794	000962	-02423	0375	0125	0750	0625	0875	0250	0000	0000	0000	%0258	B16	\$
004029	001098	-02917	0375	0125	0875	0625	0875	0125	0000	0000	0000	%0259	B17	\$
004266	001111	-03379	0375	0125	1000	0625	0875	0000	0000	0000	0000	%0260	B18	\$
003745	000719	-020417	0375	0250	0000	0625	0750	1000	0000	0000	0000	%0261	C10	\$
003901	000760	-001370	0375	0250	0125	0625	0750	0875	0000	0000	0000	%0262	C11	\$
004005	000753	-000468	0375	0250	0250	0625	0750	0750	0000	0000	0000	%0263	C12	\$
004092	000494	-00353	0375	0250	0375	0625	0750	0625	0000	0000	0000	%0264	C13	\$
004155	000535	-00932	0375	0250	0500	0625	0750	0500	0000	0000	0000	%0265	C14	\$
004223	000493	-01534	0375	0250	0625	0625	0750	0375	0000	0000	0000	%0266	C15	\$
004498	000571	-01907	0375	0250	0750	0625	0750	0250	0000	0000	0000	%0267	C16	\$
004833	000509	-02384	0375	0250	0875	0625	0750	0125	0000	0000	0000	%0268	C17	\$
005189	000450	-02716	0375	0250	1000	0625	0750	0000	0000	0000	0000	%0269	C18	\$
004306	-00219	003146	0375	0375	0000	0625	0625	1000	0000	0000	0000	%0270	D10	\$
004421	-00116	001993	0375	0375	0125	0625	0625	0875	0000	0000	0000	%0271	D11	\$
004436	-00107	000956	0375	0375	0250	0625	0625	0750	0000	0000	0000	%0272	D12	\$
004508	000023	-000122	0375	0375	0375	0625	0625	0625	0000	0000	0000	%0273	D13	\$
004895	-00058	-00538	0375	0375	0500	0625	0625	0500	0000	0000	0000	%0274	D14	\$
005247	-00028	-01088	0375	0375	0625	0625	0625	0375	0000	0000	0000	%0275	D15	\$
005392	-00077	-01468	0375	0375	0750	0625	0625	0250	0000	0000	0000	%0276	D16	\$
005685	000031	-01874	0375	0375	0875	0625	0625	0125	0000	0000	0000	%0277	D17	\$
005955	000047	-02183	0375	0375	1000	0625	0625	0000	0000	0000	0000	%0278	D18	\$
005008	-01235	003912	0375	0500	0000	0625	0500	1000	0000	0000	0000	%0279	E10	\$
004943	-01860	002440	0375	0500	0125	0625	0500	0875	0000	0000	0000	%0280	E11	\$
004989	-00928	001322	0375	0500	0250	0625	0500	0750	0000	0000	0000	%0281	E12	\$
005085	-00614	000189	0375	0500	0375	0625	0500	0625	0000	0000	0000	%0282	E13	\$
005076	-00479	-00376	0375	0500	0500	0625	0500	0500	0000	0000	0000	%0283	E14	\$
005491	-00567	-00995	0375	0500	0625	0625	0500	0375	0000	0000	0000	%0284	E15	\$
005652	-00441	-01495	0375	0500	0750	0625	0500	0250	0000	0000	0000	%0285	E16	\$
005930	-00370	-01785	0375	0500	0875	0625	0500	0125	0000	0000	0000	%0286	E17	\$
006167	-00299	-02089	0375	0500	1000	0625	0500	0000	0000	0000	0000	%0287	E18	\$
005328	-02263	003810	0375	0625	0000	0625	0375	1000	0000	0000	0000	%0288	F10	\$
005432	-02060	002521	0375	0625	0125	0625	0375	0875	0000	0000	0000	%0289	F11	\$
005421	-01785	001580	0375	0625	0250	0625	0375	0750	0000	0000	0000	%0290	F12	\$
005573	-01280	000505	0375	0625	0375	0625	0375	0625	0000	0000	0000	%0291	F13	\$
005569	-01015	-02092	0375	0625	0500	0625	0375	0500	0000	0000	0000	%0292	F14	\$
005635	-00941	-00475	0375	0625	0625	0625	0375	0375	0000	0000	0000	%0293	F15	\$
005833	-00912	-01013	0375	0625	0750	0625	0375	0250	0000	0000	0000	%0294	F16	\$
006096	-00787	-01733	0375	0625	0875	0625	0375	0125	0000	0000	0000	%0295	F17	\$
006314	-00860	-02149	0375	0625	1000	0625	0375	0000	0000	0000	0000	%0296	F18	\$
005854	-03907	003912	0375	0750	0000	0625	0250	1000	0000	0000	0000	%0297	G10	\$
005505	-02671	002675	0375	0750	0125	0625	0250	0875	0000	0000	0000	%0298	G11	\$
005721	-02754	001810	0375	0750	0250	0625	0250	0750	0000	0000	0000	%0299	G12	\$
006066	-02908	000895	0375	0750	0375	0625	0250	0625	0000	0000	0000	%0300	G13	\$
006017	-01782	000268	0375	0750	0500	0625	0250	0500	0000	0000	0000	%0301	G14	\$
005948	-01474	-00391	0375	0750	0625	0250	0250	0375	0000	0000	0000	%0302	G15	\$
005938	-01380	-00825	0375	0750	0750	0625	0250	0250	0000	0000	0000	%0303	G16	\$
006384	-01582	-01558	0375	0750	0875	0625	0250	0125	0000	0000	0000	%0304	G17	\$
006497	-01385	-02053	0375	0750	1000	0625	0250	0000	0000	0000	0000	%0305	G18	\$
006103	-04203	004771	0375	0875	0000	0625	0125	1000	0000	0000	0000	%0306	H10	\$
006125	-03450	002711	0375	0875	0125	0625	0125	0875	0000	0000	0000	%0307	H11	\$
006104	-03519	002063	0375	0875	0250	0625	0125	0750	0000	0000	0000	%0308	H12	\$
006431	-02618	000810	0375	0875	0375	0625	0125	0625	0000	0000	0000	%0309	H13	\$
006437	-02293	000247	0375	0875	0500	0625	0125	0500	0000	0000	0000	%0310	H14	\$
006465	-02163	-00089	0375	0875	0625	0625	0125	0375	0000	0000	0000	%0311	H15	\$
006419	-01996	-00605	0375	0875	0750	0625	0125	0250	0000	0000	0000	%0312	H16	\$
006398	-01767	-01087	0375	0875	0875	0625	0125	0125	0000	0000	0000	%0313	H17	\$
006820	-01953	-01982	0375	0875	1000	0625	0125	0000	0000	0000	0000	%0314	H18	\$
006546	-04936	004921	0375	1000	0000	0625	0000	1000	0000	0000	0000	%0315	I10	\$
006513	-04413	003185	0375	1000	0125	0625	0000	0875	0000	0000	0000	%0316	I11	\$
006538	-04395	002400	0375	1000	0250	0625	0000	0750	0000	0000	0000	%0317	I12	\$
006931	-03246	001132	0375	1000	0375	0625	0000	0625	0000	0000	0000	%0318	I13	\$
006849	-02909	000440	0375	1000	0500	0625	0000	0500	0000	0000	0000	%0319	I14	\$
006812	-02696	-00057	0375	1000	0625	0000	0000	0375	0000	0000	0000	%0320	I15	\$
006814	-02506	-00536	0375	1000	0750	0625	0000	0250	0000	0000	0000	%0321	I16	\$
006775	-02309	-01057	0375	1000	0875	0625	0000	0125	0000	0000	0000	%0322	I17	\$
006769	-02153	-01449	0375	1000	1000	0625	0000	0000	0000	0000	0000	%0323	I18	\$
003208	002969	000514	0500	0000	0000	0500	1000	1000	0000	0000	0000	%0324	J10	\$
003157	003278	000743	0500	0000	0125	0500	1000	0875	0000	0000	0000	%0325	J11	\$
003102	003482	-00066	0500	0000	0250	0500	1000	0750	0000	0000	0000	%0326	J12	\$
003088	003169	-00919	0500	0000	0375	0500	1000	0625	0000	0000	0000	%0327	J13	\$
003056	002406	-01423	0500	0000	0500	0500	1000	0500	0000	0000	0000	%0328	J14	\$
003060	002193	-01978	0500	0000	0625	0500	1000	0375	0000	0000	0000	%0329	J15	\$
003058	002351	-02749	0500	0000	0750	0500	1000	0250	0000					

003819	004766	002398	0750	0000	0000	0250	0000	0000	0000	%0486	A19	\$	004218	005347	002729	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$	004695	005924	003052	1000	0000	0000	0000	1000	1000	0000	%0648	S19	\$
003814	004876	001691	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$	004271	005317	001913	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$	004728	005914	002348	1000	0000	0125	0000	1000	0875	0000	%0649	S20	\$
003784	004902	000803	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$	004287	005457	001032	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$	004768	005958	001456	1000	0000	0250	0000	1000	0750	0000	%0650	S21	\$
003729	005018	-000091	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$	004252	005482	000353	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$	004676	006127	000646	1000	0000	0375	0000	1000	0625	0000	%0651	S22	\$
003573	004631	-000904	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$	004235	005517	-004010	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$	004629	006344	-001093	1000	0000	0500	0000	1000	0500	0000	%0652	S23	\$
003257	003738	-014440	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$	003813	005032	-013566	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$	004499	006490	-011446	1000	0000	0625	0000	1000	0375	0000	%0653	S24	\$
002993	003088	-019194	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$	003454	004281	-018008	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$	004186	005322	-015450	1000	0000	0750	0000	1000	0250	0000	%0654	S25	\$
003126	002907	-026212	0750	0000	0875	0250	1000	0005	0000	%0493	A26	\$	003275	003522	-021420	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$	003955	004547	-021093	1000	0000	0875	0000	1000	0125	0000	%0655	S26	\$
003415	003089	-031172	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$	003056	003370	-028411	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$	003737	003927	-024112	1000	0000	1000	0000	1000	0000	%0656	S27	\$	
004296	003432	002616	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$	004810	004281	003341	0875	0125	0000	0125	0875	1000	0000	%0576	K10	\$	004799	005276	003764	1000	0125	0000	0000	0875	1000	0000	%0657	T10	\$
004532	003491	002000	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$	005016	003943	002116	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$	005345	005244	002685	1000	0125	0125	0000	0875	0875	0000	%0658	T20	\$
004476	003626	001170	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$	004981	004218	001330	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$	005349	005306	001722	1000	0125	0250	0000	0875	0750	0000	%0659	T21	\$
004485	003745	000546	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$	004955	004289	000783	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$	005326	005328	001063	1000	0125	0375	0000	0875	0625	0000	%0660	T22	\$
004324	003840	-003091	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$	004900	004473	000025	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$	005248	005445	000331	1000	0125	0500	0000	0875	0500	0000	%0661	T23	\$
003892	003253	-01207	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$	004745	004341	-008222	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$	005181	005622	-00495	1000	0125	0625	0000	0875	0375	0000	%0662	T24	\$
003509	002690	-01597	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$	004240	003569	-01459	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$	004743	004825	-01254	1000	0125	0750	0000	0875	0250	0000	%0663	T25	\$
003745	002625	-02265	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$	004006	003016	-01807	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$	004626	003963	-01621	1000	0125	0875	0000	0875	0125	0000	%0664	T26	\$
004062	002587	-02914	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$	004313	002770	-02353	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$	004411	003277	-01989	1000	0125	1000	0000	0875	0000	0000	%0665	T27	\$
004706	002813	003040	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$	005109	003412	003498	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$	005362	004591	004338	1000	0250	0000	0000	0750	1000	0000	%0666	U19	\$
004771	002939	002550	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$	005192	003503	002850	0875	0250	0125	0125	0750	0875	0000	%0586	L20	\$	005593	004789	003564	1000	0250	0125	0000	0750	0875	0000	%0667	U20	\$
005090	002833	001501	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$	005516	003541	001692	0875	0250	0250	0125	0750	0750	0000	%0587	L21	\$	006024	004484	002270	1000	0250	0250	0000	0750	0750	0000	%0668	U21	\$
005014	003005	000833	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$	005471	003680	000985	0875	0250	0375	0125	0750	0625	0000	%0588	L22	\$	005937	004617	001490	1000	0250	0375	0000	0750	0625	0000	%0669	U22	\$
004921	003181	000008	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$	005478	003756	000286	0875	0250	0500	0125	0750	0500	0000	%0589	L23	\$	005927	004683	000758	1000	0250	0500	0000	0750	0500	0000	%0670	U23	\$
004573	002696	-00620	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$	005402	003916	-00394	0875	0250	0625	0125	0750	0375	0000	%0590	L24	\$	005904	004737	000029	1000	0250	0625	0000	0750	0375	0000	%0671	U24	\$
004153	002234	-01267	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$	004910	003428	-01159	0875	0250	0750	0125	0750	0250	0000	%0591	L25	\$	005602	004507	-00837	1000	0250	0750	0000	0750	0250	0000	%0672	U25	\$
004371	002142	-01950	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$	004591	002648	-01475	0875	0250	0875	0125	0750	0125	0000	%0592	L26	\$	005335	003477	-01304	1000	0250	0875	0000	0750	0125	0000	%0673	U26	\$
004649	002118	-02486	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$	004857	002423	-02089	0875	0250	1000	0125	0750	0000	0000	%0593	L27	\$	005014	002793	-01633	1000	0250	1000	0000	0750	0000	0000	%0674	U27	\$
005089	002278	003602	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$	005464	002845	003734	0875	0375	0000	0125	0625	1000	0000	%0594	M19	\$	005753	004032	004846	1000	0375	0000	0000	0625	1000	0000	%0675	V19	\$
005231	002243	002890	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$	005580	002878	003208	0875	0375	0125	0125	0625	0875	0000	%0595	M20	\$	006034	004042	004009	1000	0375	0125	0000	0625	0875	0000	%0676	V20	\$
005395	002226	002254	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$	005747	002937	002421	0875	0375	0250	0125	0625	0750	0000	%0596	M21	\$	006241	003945	003116	1000	0375	0250	0000	0625	0750	0000	%0677	V21	\$
005689	002092	001215	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$	006067	002747	001449	0875	0375	0375	0125	0625	0625	0000	%0597	M22	\$	006554	003779	001887	1000	0375	0375	0000	0625	0625	0000	%0678	V22	\$
005616	002268	004061	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$	006239	002903	000649	0875	0375	0500	0125	0625	0500	0000	%0598	M23	\$	006554	003933	001202	1000	0375	0500	0000	0625	0500	0000	%0679	V23	\$
005356	002324	-00234	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$	006050	002963	000994	0875	0375	0625	0125	0625	0375	0000	%0599	M24	\$	006501	004084	001241	1000	0375	0625	0000	0625	0375	0000	%0680	V24	\$
004925	001677	-00962	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$	005865	002658	000994	0875	0375	0750	0125	0625	0250	0000	%0600	M25	\$	006435	004104	-00505	1000	0375	0750	0000	0625	0250	0000	%0681	V25	\$
005039	001665	-01527	0750	0375	0875	0250	0625	0																														

009562	-00091	000200	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009894	-00679	-00450	0875	1000	1000	0000	0125	0000	0000	%0730	b02	\$
008320	-00957	-00550	0750	1000	1000	0000	0250	0000	0000	%0731	b03	\$
007760	-01294	-00688	0625	1000	1000	0000	0375	0000	0000	%0732	b04	\$
007275	-01702	-01097	0500	1000	1000	0000	0500	0000	0000	%0733	b05	\$
006769	-02019	-01515	0375	1000	1000	0000	0625	0000	0000	%0734	b06	\$
006236	-02769	-01850	0250	1000	1000	0000	0750	0000	0000	%0735	b07	\$
005668	-02981	-02267	0125	1000	1000	0000	0875	0000	0000	%0736	b08	\$
005086	-04063	-02481	0000	1000	1000	0000	1000	0000	0000	%0737	b09	\$
008683	000718	000514	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
008431	-00024	000188	0875	0875	0875	0000	0125	0125	0000	%0739	c02	\$
008049	-00610	-00422	0750	0875	0875	0000	0250	0125	0125	%0740	c03	\$
007302	-00945	-00545	0625	0875	0875	0000	0375	0125	0125	%0741	c04	\$
006886	-01371	-00715	0500	0875	0875	0000	0500	0125	0125	%0742	c05	\$
006397	-01701	-01090	0375	0875	0875	0000	0625	0125	0125	%0743	c06	\$
005777	-02120	-01678	0250	0875	0875	0000	0750	0125	0125	%0744	c07	\$
005312	-02455	-01968	0125	0875	0875	0000	0875	0125	0125	%0745	c08	\$
004850	-03290	-02251	0000	0875	0875	0000	1000	0125	0125	%0746	c09	\$
008300	001296	000876	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
007862	000606	000420	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
007525	-00005	000102	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
006875	-00577	-00282	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
006396	-00885	-00555	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
005867	-01344	-00888	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
005333	-01823	-01347	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
004817	-02062	-01687	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
004247	-02601	-01886	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007795	002088	001037	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007336	001336	000761	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
006895	000632	000441	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006425	-00020	000164	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
005987	-00543	-00273	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
005573	-00899	-00589	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
004991	-01524	-01094	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
004380	-01663	-01417	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004014	-01963	-01845	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007223	002779	001685	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006742	001904	001237	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006367	001337	000914	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$
005807	000671	000516	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005461	000038	000125	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005087	-00459	-00362	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
004599	-01002	-00637	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004073	-01264	-01275	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
003606	-01708	-01216	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006627	003671	001936	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
006093	002653	001478	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005660	002059	001182	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005135	001433	001006	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004724	000709	000439	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
004534	000008	000115	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004329	-00422	-00423	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
003654	-00894	-00677	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003359	-01461	-01148	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
006598	004396	002280	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005431	003465	001685	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
005013	002746	001481	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
004533	002978	001224	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
004192	001409	000910	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
004032	000692	000441	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
003814	000937	-00001	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
003461	-00456	-00375	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
003311	-00980	-00756	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
005436	005138	002999	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004864	003901	002211	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
004340	003489	002094	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
003943	002814	001662	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
003642	002051	001271	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
003447	001314	000874	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
003128	000707	000288	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
002700	000006	000038	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
002876	-00299	-00621	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
004619	005910	003243	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
004088	005255	002842	0750	0000	0000	0125	1000	1000	0000	%0802	j02	\$
003659	004675	002510	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
003389	003721	001954	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
003027	002971	001546	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
002801	002463	001206	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
002607	001810	000772	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
002585	001006	000745	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
002174	000561	000394	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009638	-00093	000201	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
008664	-00161	-00356	0875	0875	0875	0125	0125	0000	0000	%0811	b11	\$
008087	-00117	-00871	0750	0750	0750	0250	0250	0000	0000	%0812	b12	\$
007405	-00953	-01213	0625	0625	0625	0375	0375	0000	0000	%0813	b13	\$
006611	-00115	-01675	0500	0500	0500	0500	0500	0000	0000	%0814	b14	\$
006031	000020	-01215	0375	0375	0375	0625	0625	0000	0000	%0815	b15	\$
005366	000016	-02681	0250	0250	0250	0750	0750	0000	0000	%0816	b16	\$
004677	000010	-03293	0125	0250	0250	0875	0875	0000	0000	%0817	b17	\$
003969	000246	-04004	0000	0000	0000	1000	1000	0000	0000	%0818	b18	\$
002921	-00048	000927	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$
008605	-00029	000174	0875	0875	0875	0125	0125	0250	0000	%0820	c11	\$
007959	-00132	-00386	0750	0750	0750	0250	0250	0125	0000	%0821	c12	\$
007153	-00104	-00854	0625	0625	0625	0375	0375	0125	0000	%0822	c13	\$
006388	000111	-01410	0500	0500	0500	0500	0500	0125	0000	%0823	c14	\$
005705	000011	-01861	0375	0375	0375	0625	0625	0125	0000	%0824	c15	\$
005034	-00094	-02340	0250	0250	0250	0750	0750	0125	0000	%0825	c16	\$
004327	000131	-02845	0125	0125	0125	0875	0875	0125	0000	%0826	c17	\$
003685	000266	-03434	0000	0000	0000	0750	1000	0125	0000	%0827	c18	\$
002908	-00101	-00174	1000	1000	1000	0500	0500	0250	0000	%0828	d10	\$
008416	-00030	000816	0875	0875	0875	0125	0125	0250	0000	%0829	d11	

%BEG HE64_22.TXT, Separation cmyn5*, cfi=0.90, D65, not adapted \$
%100 x LAB* %1000 x (r g b c m y 0) %nr. pos \$
%z004695 005924 003052 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008220 -00382 007003 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005574 -05443 002051 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005635 -04104 -02482 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z004078 000168 -03949 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003737 003827 -02412 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z002016 000547 000430 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009540 -00095 000219 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004619 005910 003243 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008254 -00427 007018 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005592 -05450 001920 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005606 -04063 -02481 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003969 000246 -04004 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003767 003812 -02372 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z002079 000584 000422 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009609 -00094 000206 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/HE74/HE74L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

%BEG HE64_22.TXT, Separation cmy5*, cfi=0.90, D65, not adapted S																
%100 x LAB*	1000 x (r g b			c m y θ)			%nr.	pos \$								
0001910	0000579	0000365	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000
0002470	-000008	000091	0125	0125	0125	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000
0003567	0000037	0000003	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000
0004339	0000026	0000131	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000
0005332	0000076	0000999	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000
0006447	-000001	0000136	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000
0007631	-000020	0000113	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000
0008594	-000020	0000157	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000
0009552	-000001	0000196	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0010183	0000576	0000393	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000
0002396	0000009	0000068	0125	0125	0125	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000
0003538	0000036	-000001	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000
0004309	0000029	0000116	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000
0005287	0000057	0000108	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000
0006459	-000010	0000122	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000
0007614	-000023	0000114	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000
0008549	-000025	0000167	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000
0009635	-000090	0000194	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0010169	0000589	0000393	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000
0002417	-000002	0000089	0125	0125	0125	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000
0003527	0000039	000012	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000
0004295	0000024	0000125	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000
0005261	0000067	0000121	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000
0006407	-000016	0000173	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000
0007618	-000019	0000122	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000
0008573	-000022	0000176	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000
0009637	-000095	0000202	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0010131	0000581	0000375	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000
0002381	-000001	0000088	0125	0125	0125	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000
0003494	0000042	0000014	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000
0004265	0000222	0000158	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000
0005255	0000078	0000123	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000
0006426	-000020	0000173	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000
0007579	-000001	0000119	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000
0008541	-000012	0000168	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000
0009648	-000089	0000187	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0002137	0000553	0000367	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000
0002481	0000020	0000041	0066	0066	0066	0933	0933	0933	0000	0000	0000	0000	0000	0000	0000	0000
0002689	0000010	0000028	0133	0133	0133	0866	0866	0866	0000	0000	0000	0000	0000	0000	0000	0000
0003095	0000013	0000017	0200	0200	0200	0800	0800	0800	0000	0000	0000	0000	0000	0000	0000	0000
0003927	0000021	0000041	0266	0266	0266	0333	0333	0333	0000	0000	0000	0000	0000	0000	0000	0000
0004305	0000046	0000111	0333	0333	0333	0666	0666	0666	0000	0000	0000	0000	0000	0000	0000	0000
0004570	0000051	0000077	0400	0400	0400	0600	0600	0600	0000	0000	0000	0000	0000	0000	0000	0000
0005247	0000011	0000138	0466	0466	0466	0533	0533	0533	0000	0000	0000	0000	0000	0000	0000	0000
0005799	0000044	0000164	0533	0533	0533	0466	0466	0466	0000	0000	0000	0000	0000	0000	0000	0000
0006298	-000046	0000219	0600	0600	0600	0400	0400	0400	0000	0000	0000	0000	0000	0000	0000	0000
0006763	-000069	0000205	0666	0666	0666	0333	0333	0333	0000	0000	0000	0000	0000	0000	0000	0000
0007428	0000007	0000113	0734	0734	0734	0266	0266	0266	0000	0000	0000	0000	0000	0000	0000	0000
0007958	-000043	0000169	0800	0800	0800	0200	0200	0200	0000	0000	0000	0000	0000	0000	0000	0000
0008401	-000051	0000186	0866	0866	0866	0133	0133	0133	0000	0000	0000	0000	0000	0000	0000	0000
0008695	-000057	0000191	0933	0933	0933	0066	0066	0066	0000	0000	0000	0000	0000	0000	0000	0000
0009529	-000083	0000187	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
0002103	0000593	0000371	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000
0002422	0000015	0000071	0066	0066	0066	0933	0933	0933	0000	0000	0000	0000	0000	0000	0000	0000
0002668	0000008	0000042	0133	0133	0133	0866	0866	0866	0000	0000	0000	0000	0000	0000	0000	0000
0003056	0000010	0000032	0200	0200	0200	0800	0800	0800	0000	0000	0000	0000	0000	0000	0000	0000
0003908	0000024	0000060	0266	0266	0266	0333	0333	0333	0000	0000	0000	0000	0000	0000	0000	0000
0004309	0000052	0000116	0333	0333	0333	0666	0666	0666	0000	0000	0000	0000	0000	0000	0000	0000
0004572	0000051	0000066	0400	0400	0400	0600	0600	0600	0000	0000	0000	0000	0000	0000	0000	0000
0005261	0000020	0000119	0466	0466	0466	0533	0533	0533	0000	0000	0000	0000	0000	0000	0000	0000
0005776	0000071	0000112	0533	0533	0533	0466	0466	0466	0000	0000	0000	0000	0000	0000	0000	0000
0006282	-000027	0000180	0600	0600	0600	0400	0400	0400	0000	0000	0000	0000	0000	0000	0000	0000
0006730	-000048	0000155	0666	0666	0666	0333	0333	0333	0000	0000	0000	0000	0000	0000	0000	0000
0007416	0000024	0000096	0734	0734	0734	0266	0266	0266	0000	0000	0000	0000	0000	0000	0000	0000
0007996	-000039	0000164	0800	0800	0800	0200	0200	0200	0000	0000	0000	0000	0000	0000	0000	0000
0008373	-															

```
input: w setgray
output: ->olv* setrgbcolor
```


003018 001884 000797 0375 0000 0000 0025 1000 1000 0000 %0243 A10 \$
002991 001998 000070 0375 0000 0125 0625 1000 0875 0000 %0244 A11 \$
002945 002054 -000876 0375 0000 0250 0625 1000 0750 0000 %0245 A12 \$
002938 001397 -01492 0375 0000 0375 0625 1000 0625 0000 %0246 A13 \$
002933 001383 -02210 0375 0000 0500 0625 1000 0500 0000 %0247 A14 \$
002938 001387 -02750 0375 0000 0625 0625 1000 0375 0000 %0248 A15 \$
002978 001542 -03473 0375 0000 0750 0625 1000 0250 0000 %0249 A16 \$
003210 001456 -03913 0375 0000 0875 0625 1000 0000 0000 %0250 A17 \$
003524 001246 -04315 0375 0000 1000 0625 1000 0000 0000 %0251 A18 \$
003347 000979 001536 0375 0125 0000 0625 0875 1000 0000 %0252 B10 \$
003578 000909 000464 0375 0125 0125 0625 0875 0875 0000 %0253 B11 \$
003516 001134 -00371 0375 0125 0250 0625 0875 0750 0000 %0254 B12 \$
003606 000368 -01041 0375 0125 0375 0625 0875 0625 0000 %0255 B13 \$
003638 000534 -01647 0375 0125 0500 0625 0875 0500 0000 %0256 B14 \$
003632 000536 -02297 0375 0125 0625 0625 0875 0375 0000 %0257 B15 \$
003794 000566 -02804 0375 0125 0750 0625 0875 0250 0000 %0258 B16 \$
004029 000723 -03292 0375 0125 0875 0625 0875 0125 0000 %0259 B17 \$
004266 000756 -03747 0375 0125 1000 0625 0875 0000 0000 %0260 B18 \$
003745 000319 002035 0375 0250 0000 0625 0750 1000 0000 %0261 C10 \$
003901 000373 000094 0375 0250 0125 0625 0750 0875 0000 %0262 C11 \$
004005 000376 000094 0375 0250 0250 0625 0750 0750 0000 %0263 C12 \$
004092 000124 -00726 0375 0250 0375 0625 0750 0625 0000 %0264 C13 \$
004155 000170 -01303 0375 0250 0500 0625 0750 0500 0000 %0265 C14 \$
004223 000134 -01903 0375 0250 0625 0625 0750 0375 0000 %0266 C15 \$
004498 000235 -02269 0375 0250 0750 0625 0750 0250 0000 %0267 C16 \$
004833 000202 -02736 0375 0250 0875 0625 0750 0125 0000 %0268 C17 \$
005189 000174 -03058 0375 0250 1000 0625 0750 0000 0000 %0269 C18 \$
004306 -00571 002779 0375 0375 0000 0625 0625 1000 0000 %0270 D10 \$
004421 -00458 001639 0375 0375 0125 0625 0625 0875 0000 %0271 D11 \$
004436 -00448 000593 0375 0375 0250 0625 0625 0750 0000 %0272 D12 \$
004509 -00311 -00238 0375 0375 0375 0625 0625 0625 0000 %0273 D13 \$
004895 -00306 -00888 0375 0375 0500 0625 0625 0500 0000 %0274 D14 \$
005247 -00242 -01428 0375 0375 0625 0625 0625 0375 0000 %0275 D15 \$
005392 -00336 -01804 0375 0375 0750 0625 0625 0250 0000 %0276 D16 \$
005685 -00203 -02202 0375 0375 0875 0625 0625 0125 0000 %0277 D17 \$
005955 -00163 -02503 0375 0375 1000 0625 0625 0000 0000 %0278 D18 \$
005908 -01527 003565 0375 0500 0000 0625 0500 1000 0000 %0279 D19 \$
004943 -01358 002091 0375 0500 0125 0625 0500 0875 0000 %0280 E11 \$
004899 -01230 000972 0375 0500 0250 0625 0500 0750 0000 %0281 E12 \$
005085 -00899 -00154 0375 0500 0375 0625 0500 0625 0000 %0282 E13 \$
005076 -00765 -00721 0375 0500 0500 0625 0500 0500 0000 %0283 E14 \$
005491 -00818 -01329 0375 0500 0625 0625 0500 0375 0000 %0284 E15 \$
005652 -00678 -01824 0375 0500 0750 0625 0500 0250 0000 %0285 E16 \$
005930 -00584 -02106 0375 0500 0875 0625 0500 0125 0000 %0286 E17 \$
006167 -00492 -02403 0375 0500 1000 0625 0500 0000 0000 %0287 E18 \$
005328 -02528 003473 0375 0625 0000 0625 0375 1000 0000 %0288 F10 \$
005432 -02316 002186 0375 0625 0125 0625 0375 0875 0000 %0289 F11 \$
005421 -02042 001245 0375 0625 0250 0625 0375 0750 0000 %0290 F12 \$
005573 -01524 000175 0375 0625 0375 0625 0375 0625 0000 %0291 F13 \$
005569 -01259 -00533 0375 0625 0500 0625 0375 0500 0000 %0292 F14 \$
005635 -01179 -00904 0375 0625 0625 0625 0375 0375 0000 %0293 F15 \$
005833 -01134 -01734 0375 0625 0750 0625 0375 0250 0000 %0294 F16 \$
006096 -00986 -02049 0375 0625 0875 0625 0375 0125 0000 %0295 F17 \$
006314 -01040 -02459 0375 0625 1000 0625 0375 0000 0000 %0296 F18 \$
005854 -03244 003583 0375 0750 0000 0625 0250 1000 0000 %0297 G10 \$
005805 -02895 002350 0375 0750 0125 0625 0250 0875 0000 %0298 G11 \$
005721 -02905 001484 0375 0750 0250 0625 0250 0750 0000 %0299 G12 \$
006066 -02310 000489 0375 0750 0375 0625 0250 0625 0000 %0300 G13 \$
006017 -01988 -00049 0375 0750 0500 0625 0250 0500 0000 %0301 G14 \$
005948 -01686 -00712 0375 0750 0625 0250 0250 0375 0000 %0302 G15 \$
005938 -01593 -01145 0375 0750 0750 0625 0250 0250 0000 %0303 G16 \$
006384 -01756 -01866 0375 0750 0875 0625 0250 0125 0000 %0304 G17 \$
006497 -01550 -02358 0375 0750 1000 0625 0250 0000 0000 %0305 G18 \$
006103 -04401 004385 0375 0875 0000 0625 0125 1000 0000 %0306 H10 \$
006125 -03646 002402 0375 0875 0125 0625 0125 0875 0000 %0307 H11 \$
006104 -03717 001747 0375 0875 0250 0625 0125 0750 0000 %0308 H12 \$
006431 -02789 000503 0375 0875 0375 0625 0125 0625 0000 %0309 H13 \$
006437 -02463 -00059 0375 0875 0500 0625 0125 0500 0000 %0310 H14 \$
006465 -02330 -00395 0375 0875 0625 0625 0125 0375 0000 %0311 H15 \$
006419 -02168 -00913 0375 0875 0750 0625 0125 0250 0000 %0312 H16 \$
006398 -01941 -01395 0375 0875 0875 0625 0125 0125 0000 %0313 H17 \$
006820 -02090 -02278 0375 0875 1000 0625 0125 0000 0000 %0314 H18 \$
006546 -05097 004617 0375 1000 0000 0625 0000 1000 0000 %0315 I10 \$
006513 -04577 002880 0375 1000 0125 0625 0000 0875 0000 %0316 I11 \$
006538 -04557 002096 0375 1000 0250 0625 0000 0750 0000 %0317 I12 \$
006931 -03374 000839 0375 1000 0375 0625 0000 0625 0000 %0318 I13 \$
006849 -03044 000145 0375 1000 0500 0625 0000 0500 0000 %0319 I14 \$
006812 -02834 -00353 0375 1000 0625 0000 0000 0375 0000 %0320 I15 \$
006814 -02643 -00832 0375 1000 0750 0625 0000 0250 0000 %0321 I16 \$
006775 -02450 -01354 0375 1000 0875 0625 0000 0125 0000 %0322 I17 \$
006769 -02294 -01746 0375 1000 1000 0625 0000 0000 0000 %0323 I18 \$

003208 002523 001117 0500 0000 0000 0500 1000 1000 0000 %0324 J10 \$
003157 002828 003044 0500 0000 0125 0500 1000 0875 0000 %0325 J11 \$
003102 003028 -00466 0500 0000 0250 0500 1000 0750 0000 %0326 J12 \$
003088 002713 -01319 0500 0000 0375 0500 1000 0625 0000 %0327 J13 \$
003056 001948 -01825 0500 0000 0500 0500 1000 0500 0000 %0328 J14 \$
003060 001734 -02379 0500 0000 0625 0500 1000 0375 0000 %0329 J15 \$
003058 001893 -03150 0500 0000 0750 0500 1000 0250 0000 %0330 J16 \$
003163 001860 -03705 0500 0000 0875 0500 1000 0125 0000 %0331 J17 \$
003207 002187 -04446 0500 0000 1000 0500 1000 0000 0000 %0332 J18 \$
003460 001760 001754 0500 0125 0000 0500 0875 1000 0000 %0333 K10 \$
003819 001678 000904 0500 0125 0125 0500 0875 0000 %0334 K11 \$
003790 001851 000899 0500 0125 0250 0500 0875 0625 0000 %0335 K12 \$
003711 001719 -00764 0500 0125 0375 0500 0875 0250 0000 %0336 K13 \$
003785 001173 -01405 0500 0125 0500 0500 0875 0500 0000 %0337 K14 \$
003736 001148 -01935 0500 0125 0625 0500 0875 0375 0000 %0338 K15 \$
003717 001243 -02731 0500 0125 0750 0500 0875 0250 0000 %0339 K16 \$
003855 001263 -03369 0500 0125 0875 0500 0875 0125 0000 %0340 K17 \$
004056 001325 -03847 0500 0125 1000 0500 0875 0000 0000 %0341 K18 \$
003982 000990 002254 0500 0250 0000 0500 0750 1000 0000 %0342 L10 \$
004194 001023 001416 0500 0250 0125 0500 0750 0875 0000 %0343 L11 \$
004318 001067 000518 0500 0250 0250 0500 0750 0750 0000 %0344 L12 \$
004282 001345 -00365 0500 0250 0375 0500 0750 0625 0000 %0345 L13 \$
004298 000794 -01046 0500 0250 0500 0500 0750 0500 0000 %0346 L14 \$
004243 000718 -01624 0500 0250 0625 0500 0750 0375 0000 %0347 L15 \$
004349 000873 -02267 0500 0250 0750 0500 0750 0250 0000 %0348 L16 \$
004631 000750 -02767 0500 0250 0875 0500 0750 0125 0000 %0349 L17 \$
005004 000767 -03126 0500 0250 1000 0500 0750 0000 0000 %0350 L18 \$
004316 000529 002818 0500 0375 0000 0500 0625 1000 0000 %0351 M10 \$
004508 000497 001825 0500 0375 0125 0500 0625 0875 0000 %0352 M11 \$
004624 000575 000943 0500 0375 0250 0500 0625 0750 0000 %0353 M12 \$
004820 000408 000843 0500 0375 0375 0500 0625 0250 0000 %0354 M13 \$
004855 000172 -00689 0500 0375 0500 0500 0625 0500 0000 %0355 M14 \$
005051 001327 -01328 0500 0375 0625 0500 0625 0375 0000 %0356 M15 \$
005238 000231 -01709 0500 0375 0750 0500 0625 0250 0000 %0357 M16 \$
005510 000271 -02158 0500 0375 0875 0500 0625 0125 0000 %0358 M17 \$
005815 000295 -02515 0500 0375 1000 0500 0625 0000 0000 %0359 M18 \$
004886 -00498 003499 0500 0500 0000 0500 0500 1000 0000 %0360 N10 \$
005105 -00422 002517 0500 0500 0125 0500 0875 0000 %0361 N11 \$
005200 -00345 001636 0500 0500 0250 0500 0750 0500 0000 %0362 N12 \$
005353 -00359 000645 0500 0500 0375 0500 0500 0625 0000 %0363 N13 \$
005481 -00190 -00222 0500 0500 0500 0500 0500 0000 %0364 N14 \$
005939 -00217 -00734 0500 0500 0625 0500 0500 0375 0000 %0365 N15 \$
006177 -00275 -01299 0500 0500 0750 0500 0500 0250 0000 %0366 N16 \$
006428 -00065 -01687 0500 0500 0875 0500 0500 0125 0000 %0367 N17 \$
006624 -00069 -01936 0500 0500 1000 0500 0500 0000 0000 %0368 N18 \$
005906 -01401 004124 0500 0625 0000 0500 0375 1000 0000 %0369 O10 \$
005868 -01449 003124 0500 0625 0125 0500 0375 0875 0000 %0370 O11 \$
005869 -01293 002124 0500 0625 0250 0500 0375 0750 0000 %0371 O12 \$
005938 -01130 001026 0500 0625 0375 0500 0375 0625 0000 %0372 O13 \$
006078 -00778 000044 0500 0625 0500 0500 0375 0500 0000 %0373 O14 \$
006122 -00763 -00580 0500 0625 0625 0500 0375 0375 0000 %0374 O15 \$
006410 -00711 -01262 0500 0625 0750 0500 0375 0250 0000 %0375 O16 \$
006616 -00577 -01549 0500 0625 0875 0500 0375 0125 0000 %0376 O17 \$
006830 -00535 -01896 0500 0625 1000 0500 0375 0000 0000 %0377 O18 \$
006983 -02332 004203 0500 0750 0000 0500 0250 1000 0000 %0378 P10 \$
006248 -02094 003083 0500 0750 0125 0500 0250 0875 0000 %0379 P11 \$
006251 -02106 002281 0500 0750 0250 0500 0250 0750 0000 %0380 P12 \$
006371 -01935 001318 0500 0750 0375 0500 0250 0625 0000 %0381 P13 \$
006576 -01507 000343 0500 0750 0500 0500 0250 0500 0000 %0382 P14 \$
006546 -01311 -00313 0500 0750 0625 0500 0250 0375 0000 %0383 P15 \$
006517 -01084 -00835 0500 0750 0750 0500 0250 0250 0000 %0384 P16 \$
006855 -01115 -01613 0500 0750 0875 0500 0250 0125 0000 %0385 P17 \$
006972 -00938 -02008 0500 0750 1000 0500 0250 0000 0000 %0386 P18 \$
006500 -03247 004436 0500 0875 0000 0500 0125 1000 0000 %0387 Q10 \$
006650 -02987 003660 0500 0875 0125 0500 0125 0875 0000 %0388 Q11 \$
006625 -03040 002646 0500 0875 0250 0500 0125 0750 0000 %0389 Q12 \$
006688 -02826 001672 0500 0875 0375 0500 0125 0625 0000 %0390 Q13 \$
006901 -02152 000415 0500 0875 0500 0500 0125 0500 0000 %0391 Q14 \$
006922 -01921 -00068 0500 0875 0625 0500 0125 0375 0000 %0392 Q15 \$
006903 -01700 -00597 0500 0875 0750 0500 0125 0250 0000 %0393 Q16 \$
006922 -01545 -01012 0500 0875 0875 0500 0125 0125 0000 %0394 Q17 \$
007226 -01637 -01838 0500 0875 1000 0500 0125 0000 0000 %0395 Q18 \$
007804 -04264 004989 0500 1000 0000 0500 0000 1000 0000 %0396 R10 \$
006942 -03855 003570 0500 1000 0125 0500 0000 0875 0000 %0397 R11 \$
007007 -03806 002938 0500 1000 0250 0500 0000 0750 0000 %0398 R12 \$
007090 -03673 001934 0500 1000 0375 0500 0000 0625 0000 %0399 R13 \$
007492 -02693 000796 0500 1000 0500 0500 0000 0500 0000 %0400 R14 \$
007416 -02491 000167 0500 1000 0625 0500 0000 0375 0000 %0401 R15 \$
007287 -02277 -00383 0500 1000 0750 0500 0000 0250 0000 %0402 R16 \$
007273 -02035 -00896 0500 1000 0875 0500 0000 0125 0000 %0403 R17 \$
007281 -01881 -01313 0500 1000 1000 0500 0000 0000 0000 %0404 R18 \$

003594 003186 001403 0625 0000 0000 0375 1000 1000 0000 %0405 S10 \$
003462 003536 000740 0625 0000 0125 0375 1000 0875 0000 %0406 S11 \$
003468 003657 -00007 0625 0000 0250 0375 1000 0750 0000 %0407 S12 \$
003502 003619 -00780 0625 0000 0375 0375 1000 0625 0000 %0408 S13 \$
003227 002995 -01478 0625 0000 0500 0375 1000 0500 0000 %0409 S14 \$
003114 002354 -01921 0625 0000 0625 0375 1000 0375 0000 %0410 S15 \$
003230 002245 -02577 0625 0000 0750 0375 1000 0250 0000 %0411 S16 \$
003259 002324 -03361 0625 0000 0875 0375 1000 0125 0000 %0412 S17 \$
003399 002370 -03074 0625 0000 1000 0375 1000 0000 0000 %0413 S18 \$
003899 002387 001961 0625 0125 0000 0375 0875 1000 0000 %0414 T10 \$
004108 002443 001206 0625 0125 0125 0375 0875 0875 0000 %0415 T11 \$
004064 002677 000372 0625 0125 0250 0375 0875 0750 0000 %0416 T12 \$
004145 002779 -00401 0625 0125 0375 0375 0875 0625 0000 %0417 T13 \$
003992 002448 -01203 0625 0125 0500 0375 0875 0500 0000 %0418 T14 \$
003787 001751 -01617 0625 0125 0625 0375 0875 0375 0000 %0419 T15 \$
003800 001824 -02345 0625 0125 0750 0375 0875 0250 0000 %0420 T16 \$
003941 001713 -02923 0625 0125 0875 0375 0875 0125 0000 %0421 T17 \$
004077 001922 -03601 0625 0125 1000 0375 0875 0000 0000 %0422 T18 \$
004332 001747 002395 0625 0250 0000 0375 0750 1000 0000 %0423 U10 \$
004496 001820 001776 0625 0250 0125 0375 0750 0875 0000 %0424 U11 \$
004697 001801 000802 0625 0250 0250 0375 0750 0750 0000 %0425 U12 \$
004770 001851 000105 0625 025

003819	004372	002017	0750	0000	0000	0250	0000	1000	1000	0000	0000	%0486	A19	\$
003814	004482	001310	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$		
003784	004506	000422	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$		
003379	004616	-00474	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$		
003573	004217	-01291	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$		
003257	003297	-01836	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$		
002993	002624	-02397	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$		
003126	002544	-03012	0750	0000	0875	0250	1000	0000	0000	%0493	A26	\$		
003415	002660	-03564	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$		
004296	003079	002250	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$		
004532	003158	001640	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$		
004476	003289	000808	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$		
004485	003409	000185	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$		
004324	003490	-00757	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$		
003892	002866	-01585	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$		
003509	002270	-01986	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$		
003745	002225	-02647	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$		
004062	002214	-03288	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$		
004706	002495	-002685	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$		
004771	002626	-002196	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$		
005090	002548	001157	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$		
005014	002713	000487	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$		
004921	002881	-00340	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$		
004573	002367	-00979	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$		
004153	001869	-01638	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$		
004371	001796	-02314	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$		
004649	001795	-02843	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$		
005089	001993	003258	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$		
005231	001976	002549	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$		
005395	001967	-001918	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$		
005689	001858	000884	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$		
005616	002028	000131	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$		
005356	002062	-00071	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$		
004925	001378	-01311	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$		
005039	001376	-01873	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$		
005319	001237	-02410	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$		
005588	001212	003905	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$		
005701	001261	003058	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$		
005861	001245	002427	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$		
006106	001166	-001599	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$		
006326	001189	-000706	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$		
006217	001310	-00046	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$		
005741	000774	-00886	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$		
005843	000838	-01485	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$		
006009	000851	-02064	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$		
006053	000478	004324	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$		
006157	000480	003453	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$		
006266	000525	002933	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$		
006481	000531	002033	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$		
006446	000505	001328	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$		
006733	000484	000282	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$		
006441	000203	-00764	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$		
006608	000290	-01208	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$		
006837	000360	-01654	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$		
006594	-00423	005046	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$		
006665	-00366	004119	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$		
006780	-00314	003553	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$		
007013	-00263	002690	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$		
007128	-00230	001880	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$		
007225	-00277	000762	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$		
007314	-00100	-00154	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$		
007563	-00253	-00728	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$		
007772	-00227	-01240	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$		
007711	-01398	006142	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$		
007729	-01375	005044	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$		
007668	-01348	004298	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$		
007705	-01409	003559	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$		
007701	-01363	002276	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$		
007612	-01151	001050	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$		
007778	-00832	000074	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$		
007786	-00806	-006045	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$		
007935	-00690	-01175	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$		
008032	-02395	006355	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$		
008019	-02396	005154	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$		
008032	-02314	004474	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$		
008036	-02238	003523	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$		
008075	-02173	002569	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$		
008081	-02057	001728	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$		
008232	-01561	000426	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$		
008147	-01350	-00235	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$		
008128	-01132	-00899	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$		
004218	004988	002360	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$		
004271	004962	001546	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$		
004287	005103	000665	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$		
004252	005125	-00014	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$		
004235	005159	-00778	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$		
003813	004637	-01747	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$		
003454	003856	-02198	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$		
003275	003882	-02500	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$		
003356	002963	-03228	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$		
004610	003955	002984	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$		
005016	003651	-001770	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$		
004981	003923	000983	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$		
004955	003993	000435	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$		
004900	004171	-00324	0875	0125	0500	0125	0875	0500						

See original or copy: <http://web.me.com/klaus.richter/HE74/HE74L0NA.TXT> /PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

009562	000000	-00007	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009804	-00648	-00677	0875	1000	1000	00125	0000	0000	0000	%0730	b02	\$
008320	-00978	-00793	0750	1000	1000	00250	0000	0000	0000	%0731	b03	\$
007760	-01366	-00948	0625	1000	1000	00375	0000	0000	0000	%0732	b04	\$
007275	-01818	-01371	0500	1000	1000	00500	0000	0000	0000	%0733	b05	\$
006769	-02180	-01803	0375	1000	1000	00625	0000	0000	0000	%0734	b06	\$
006236	-02978	-02154	0250	1000	1000	00750	0000	0000	0000	%0735	b07	\$
005668	-03242	-02507	0125	1000	1000	00875	0000	0000	0000	%0736	b08	\$
005046	-04329	-02892	0000	1000	1000	00900	0000	0000	0000	%0737	b09	\$
008683	000730	000280	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
008431	-00035	-00052	0875	0875	0875	0125	0125	0125	0000	%0739	c02	\$
008049	-00656	-00673	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
007302	-01059	-00818	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
006886	-01522	-01000	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
006397	-01896	-01389	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
005777	-02371	-01995	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005312	-02748	-02298	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
004850	-03624	-02594	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008300	001272	000631	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
007862	000543	000163	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
007525	-00098	-00163	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
006875	-00729	-00568	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
006396	-01080	-00854	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
005867	-01586	-01203	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
005333	-02113	-01677	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
004817	-02399	-02032	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
004247	-02990	-02247	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007795	002019	000778	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007336	001226	000489	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
006895	000482	000157	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006425	-00212	-00133	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
005987	-00775	-00584	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
005573	-01168	-00812	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
004991	-01846	-01433	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
004380	-02039	-01774	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004014	-02373	-02212	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007223	002659	001410	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006742	-001741	-000948	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006367	-001140	-000615	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$
005807	000423	000200	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005461	-00240	-00200	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005087	-00772	-00699	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
004599	-01359	-00988	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004073	-01668	-01640	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
003606	-02155	-01595	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006627	003497	001644	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
006093	002431	001171	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005660	001797	000862	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005135	001124	000670	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004724	000364	000092	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
004324	-00354	-00237	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004329	-00803	-00781	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
003654	-01336	-01055	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003309	-01935	-01535	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
006508	004171	001971	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005431	003184	001358	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
005013	002426	001143	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
004533	001715	000804	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
004192	001015	000548	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
004032	000284	000074	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
003814	-00390	-00374	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
003461	-00915	-00758	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
003311	-01453	-01144	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
005338	004848	002579	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004864	003568	001868	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
004340	003109	001736	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
003943	002398	001293	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
003642	001607	000893	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
003447	000854	000490	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
003128	000218	-00103	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
002700	-00521	-00366	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
002876	-00812	-01020	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
004619	005555	002893	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
004088	004852	002476	0875	0000	0000	0125	1000	1000	0000	%0802	j02	\$
003659	004233	002133	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
003389	003255	001568	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
003027	002473	001150	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
002801	001944	000804	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
002607	001279	000366	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
002585	000468	000336	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
002174	-00014	-00025	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009638	000003	-00004	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
008664	-00152	-00590	0875	0875	0875	0125	0125	0125	0000	%0811	b11	\$
008087	-00160	-01122	0750	0750	0750	0250	0250	0250	0000	%0812	b12	\$
007405	-00157	-01483	0625	0625	0625	0375	0375	0375	0000	%0813	b13	\$
006611	-00059	-01968	0500	0500	0500	0500	0500	0500	0000	%0814	b14	\$
006031	-00207	-02434	0375	0375	0375	0625	0625	0625	0000	%0815	b15	\$
005366	-00243	-03009	0250	0250	0250	0750	0750	0750	0000	%0816	b16	\$
004647	-00271	-03642	0125	0125	0125	0875	0875	0875	0000	%0817	b17	\$
003969	-00167	-04372	0000	0000	0000	1000	1000	1000	0000	%0818	b18	\$
002921	000014	000710	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$
008605	-00025	-00060	0875	0875	0875	0125	0125	0125	0000	%0820	c11	\$
007959	-00186	-00640	0750	0750	0750	0250	0250	0125	0000	%0821	c12	\$
007153	-00231	-01131	0625	0625	0875	0375	0375	0125	0000	%0822	c13	\$
006388	-00084	-01710	0500	0500	0875	0500	0500	0125	0000	%0823	c14	\$
005705	-00245	-02180	0375	0375	0875	0625	0625	0125	0000	%0824	c15	\$
005034	-00412	-02678	0250	0250	0875	0750	0750	0125	0000	%0825	c16	\$
004327	-00250	-03203	0125	0125	0875	0875	0875	0125	0000	%0826	c17	\$
003685	-00173	-03810	0000	0000	0875	1000	1000	0125	0000	%0827	c18	\$
009098	000033	001523	1000	1000	0750	0000	0250	0000	0000	%0828	d10	\$
008416	-00043	000575	0750	0875	0750	0125	0125	0250</				

%BEG HE64_22.TXT, Separation cmyn5*, cfi=0.90, D65, adapted \$
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos \$
%z004695 005605 002696 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008220 -00400 006746 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005574 -05687 001720 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005635 -04343 -02811 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z004078 -00202 -04322 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003737 003427 -02794 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z002016 000000 000000 %#0000 0000 1000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009540 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004619 005555 002893 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008254 -00454 006772 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005592 -05718 001508 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005606 -04329 -02802 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003969 -00167 -04372 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003767 003380 -02746 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z002079 000000 000000 %#0000 0000 1000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009609 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/HE74/HE74L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

%BEG HE64_22.TXT, Separation cmy5*, cfi=0.90, D65, adapted S										%100 x LAB*a										1000 x (r g b c m y 0)										%nrr. pos \$																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																					
001910	000014	-00081	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																							</

%BEG HE64 22.TXT, Separation cmy5n*, cfi=0.90, D50, not adapted S																			
%1000 x (r g b c m y o)																			
nmr. pos \$																			
%02033	%00630	%00456	%00000	%00000	%00000	%00000	%00000	%00000	%00000	%002428	%001113	%008856	%01250	%00000	%00000	%00875	%00000	%00081	%001J01 \$
%02290	%000574	%01022	%00000	%00000	%01250	%00000	%00000	%00875	%00000	%02598	%008842	%00632	%01250	%00000	%01250	%00875	%00000	%00882	%002J02 \$
%02754	%000019	%01195	%00000	%00000	%02500	%00000	%00000	%00750	%00000	%02464	%008824	%01392	%01250	%00000	%02500	%00875	%00000	%00883	%003J03 \$
%02809	%00153	%01702	%00000	%00000	%03750	%00000	%00000	%00625	%00000	%02547	%008554	%01730	%01250	%00000	%03750	%00875	%00000	%00884	%004J04 \$
%03001	%00265	%01939	%00000	%00000	%05000	%00000	%00000	%00500	%00000	%02697	%008287	%01955	%01250	%00000	%05000	%00875	%00000	%00885	%005J05 \$
%03251	%00206	%02440	%00000	%00000	%06250	%00000	%00000	%00375	%00000	%02985	%008343	%02457	%01250	%00000	%06250	%00875	%00000	%00886	%006J06 \$
%03553	%00309	%02946	%00000	%00000	%07500	%00000	%00000	%00250	%00000	%03383	%008084	%02901	%01250	%00000	%07500	%00875	%00000	%00887	%007J07 \$
%03792	%00378	%03453	%00000	%00000	%08750	%00000	%00000	%00125	%00000	%03539	%008107	%03432	%01250	%00000	%08750	%00875	%00000	%00888	%008J08 \$
%03985	%00378	%04109	%00000	%00000	%10000	%00000	%00000	%00000	%00000	%03851	%008289	%04039	%01250	%00000	%10000	%00875	%00000	%00889	%009J09 \$
%04269	%00454	%001025	%00000	%01250	%00000	%00000	%00875	%00000	%00000	%03114	%00111	%001587	%01250	%01250	%00000	%08750	%00000	%00900	%001K01 \$
%02556	%00348	%00636	%00000	%01250	%01250	%00000	%00875	%00750	%00000	%02499	%000007	%000084	%01250	%01250	%01250	%00875	%00750	%00000	%00910K02 \$
%02796	%00697	%01195	%00000	%01250	%02500	%00000	%00875	%00750	%00000	%03049	%000028	%00595	%01250	%01250	%02500	%00875	%00750	%00000	%00920K03 \$
%02822	%00838	%01635	%00000	%01250	%03750	%00000	%00875	%00625	%00000	%03260	%00125	%01145	%01250	%01250	%03750	%00875	%00625	%00000	%00930K04 \$
%03133	%00854	%01987	%00000	%01250	%05000	%00000	%00875	%00500	%00000	%03511	%00093	%01766	%01250	%01250	%05000	%00875	%00500	%00000	%00940K05 \$
%03398	%00785	%02524	%00000	%01250	%06250	%00000	%00875	%00375	%00000	%03850	%00219	%01949	%01250	%01250	%06250	%00875	%00375	%00000	%00950K06 \$
%03644	%00906	%02956	%00000	%01250	%07500	%00000	%00875	%00250	%00000	%04155	%00381	%02492	%01250	%01250	%07500	%00875	%00250	%00000	%00960K07 \$
%03821	%00787	%03482	%00000	%01250	%08750	%00000	%00875	%00125	%00000	%04317	%00282	%02936	%01250	%01250	%08750	%00875	%00125	%00000	%00970K08 \$
%04079	%00893	%04080	%00000	%01250	%10000	%00000	%00875	%00000	%00000	%04634	%00285	%03383	%01250	%01250	%10000	%00875	%00000	%00980K09 \$	
%03305	%01142	%00791	%00000	%02500	%00000	%00000	%07500	%00000	%00000	%03735	%00784	%02058	%01250	%02500	%00000	%08750	%00000	%00990L01 \$	
%03043	%01029	%00012	%00000	%02500	%01250	%00000	%07500	%00875	%00000	%03358	%00546	%00336	%01250	%02500	%01250	%08750	%00750	%00000	%01000L02 \$
%02934	%01152	%00870	%00000	%02500	%02500	%00000	%07500	%00750	%00000	%03182	%00506	%00415	%01250	%02500	%02500	%08750	%00750	%00000	%01010L03 \$
%03008	%01383	%01686	%00000	%02500	%03750	%00000	%07500	%00625	%00000	%03382	%00626	%01189	%01250	%02500	%03750	%00875	%00625	%00000	%01020L04 \$
%03268	%01363	%02027	%00000	%02500	%05000	%00000	%07500	%00500	%00000	%03644	%00672	%01728	%01250	%02500	%05000	%00875	%00500	%00000	%01030L05 \$
%03479	%01282	%02481	%00000	%02500	%06250	%00000	%07500	%00375	%00000	%04236	%00744	%01971	%01250	%02500	%06250	%00875	%00375	%00000	%01040L06 \$
%03740	%01291	%02918	%00000	%02500	%07500	%00000	%07500	%00250	%00000	%04937	%00752	%02446	%01250	%02500	%07500	%00875	%00250	%00000	%01050L07 \$
%03974	%01382	%03383	%00000	%02500	%08750	%00000	%07500	%00125	%00000	%04482	%00792	%02881	%01250	%02500	%08750	%00875	%00125	%00000	%01060L08 \$
%04231	%01433	%03907	%00000	%02500	%10000	%00000	%07500	%00000	%00000	%04788	%00801	%03312	%01250	%02500	%10000	%00875	%00000	%01070L09 \$	
%04346	%01611	%00748	%00000	%03750	%00000	%00000	%06250	%00000	%00000	%03566	%01550	%002025	%01250	%03750	%00000	%08750	%00625	%00000	%01080M01 \$
%03199	%01617	%00948	%00000	%03750	%01250	%00000	%06250	%00875	%00000	%03612	%01256	%000473	%01250	%03750	%01250	%08750	%00625	%00000	%01090M02 \$
%03084	%01763	%00515	%00000	%03750	%02500	%00000	%06250	%00750	%00000	%03446	%01141	%00122	%01250	%03750	%02500	%08750	%00625	%00000	%01100M03 \$
%03064	%01705	%01352	%00000	%03750	%03750	%00000	%06250	%00625	%00000	%03455	%01011	%00816	%01250	%03750	%03750	%00875	%00625	%00000	%01110M04 \$
%03504	%01785	%01924	%00000	%03750	%05000	%00000	%06250	%00500	%00000	%03063	%01255	%01822	%01250	%03750	%05000	%00875	%00625	%00000	%01120M05 \$
%03745	%01687	%02421	%00000	%03750	%06250	%00000	%06250	%00375	%00000	%04136	%01128	%02025	%01250	%03750	%06250	%00875	%00625	%00000	%01130M06 \$
%03837	%01740	%02857	%00000	%03750	%07500	%00000	%06250	%00250	%00000	%04341	%01072	%02522	%01250	%03750	%07500	%00875	%00625	%00000	%01140M07 \$
%04135	%01867	%03301	%00000	%03750	%08750	%00000	%06250	%00125	%00000	%04601	%01249	%02875	%01250	%03750	%08750	%00875	%00625	%00000	%01150M08 \$
%04352	%01868	%03911	%00000	%03750	%10000	%00000	%06250	%00000	%00000	%04935	%01233	%03270	%01250	%03750	%10000	%00875	%00625	%00000	%01160M09 \$
%03666	%02258	%00873	%00000	%05000	%00000	%00000	%05000	%00000	%00000	%03918	%02911	%02177	%01250	%05000	%00000	%08750	%00500	%00000	%01170N01 \$
%03308	%02084	%00667	%00000	%05000	%01250	%00000	%05000	%00875	%00000	%03872	%02233	%00549	%01250	%05000	%01250	%08750	%00500	%00000	%01180N02 \$
%03241	%02139	%00395	%00000	%05000	%02500	%00000	%05000	%00750	%00000	%03849	%01985	%00109	%01250	%05000	%02500	%08750	%00500	%00000	%01190N03 \$
%03199	%02080	%00889	%00000	%05000	%03750	%00000	%05000	%00625	%00000	%03817	%01777	%00587	%01250	%05000	%03750	%08750	%00500	%00000	%01200N04 \$
%03347	%02048	%01493	%00000	%05000	%05000	%00000	%05000	%00500	%00000	%03916	%01503	%01438	%01250	%05000	%05000	%08750	%00500	%00000	%01210N05 \$
%03936	%02225	%02542	%00000	%05000	%06250	%00000	%05000	%00375	%00000	%04311	%01679	%02090	%01250	%05000	%06250	%08750	%00375	%00000	%01220N06 \$
%04056	%02447	%02762	%00000	%05000	%07500	%00000	%05000	%00250	%00000	%04554	%01685	%02479	%01250	%05000	%07500	%08750	%00500	%00000	%01230N07 \$
%04313	%02297	%03338	%00000	%05000	%08750	%00000	%05000	%00125	%00000	%04747	%01711	%02861	%01250	%05000	%08750	%08750	%00500	%00000	%01240N08 \$
%04403	%02278	%03977	%00000	%05000	%10000	%00000	%05000	%00000	%00000	%05089	%01689	%03275	%01250	%05000	%10000	%08750	%00500	%00000	%01250N09 \$
%04032	%00807	%00916	%00000	%06250	%00000	%00000	%03750	%00000	%00000	%04247	%03792	%002452	%01250	%06250	%00000	%08750	%00375	%00000	%01260O01 \$
%03920	%02694	%00302	%00000	%06250	%01250	%00000	%03750	%00875	%00000	%04325	%02714	%00712	%01250	%06250	%01250	%08750	%00375	%00000	%01270O02 \$
%03889	%02707	%00236	%00000	%06250	%02500	%00000	%03750	%00750	%00000	%04385	%02463	%00132	%01250	%06250	%02500	%08750	%00375	%00000	%01280O03 \$
%03785	%02557	%00836	%00000	%06250	%03750	%00000	%03750	%00625	%00000	%04284	%02272	%00355	%01250	%06250	%03750	%08750	%00375	%00000	%01290O04 \$
%03791	%02411	%01473	%00000	%06250	%05000	%00000	%03750	%00500	%00000	%04351	%02208	%00863	%01250	%06250	%05000	%08750	%00375	%00000	%01300O05 \$
%03938	%02246	%02039	%00000	%06250	%06250	%00													

See original or copy: <http://web.me.com/klaus.richter/HE74/HE74L0NA.TXT> /.PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

003086	002550	001309	0375	0000	0000	0000	0025	1000	1000	0000	0000	%0243	A10 \$	003294	003201	001654	0500	0000	0000	0500	1000	1000	0000	003324	J10 \$	003699	003858	001960	0625	0000	0000	0375	1000	1000	0000	%0405	S10 \$
003084	002604	000593	0375	0000	0125	0625	1000	1000	0875	0000	0000	%0244	A11 \$	003244	003449	000906	0500	0000	0125	0500	1000	0875	0000	003325	J11 \$	003571	004164	001330	0625	0000	0125	0375	1000	0875	0000	%0406	S11 \$
002996	002568	-003056	0375	0000	0250	0625	1000	0750	0000	0000	0000	%0245	A12 \$	003184	003578	000107	0500	0000	0250	0500	1000	0750	0000	003326	J12 \$	003571	004224	000591	0625	0000	0250	0375	1000	0750	0000	%0407	S12 \$
002960	001835	-01025	0375	0000	0375	0625	1000	0625	0000	0000	0000	%0246	A13 \$	003148	003176	-00775	0500	0000	0375	0500	1000	0625	0000	003327	J13 \$	003593	004113	-00189	0625	0000	0375	0375	1000	0625	0000	%0408	S13 \$
002939	001737	-01769	0375	0000	0500	0625	1000	0500	0000	0000	0000	%0247	A14 \$	003085	002355	-01341	0500	0000	0500	0500	1000	0500	0000	003328	J14 \$	003291	003433	-00925	0625	0000	0500	0375	1000	0500	0000	%0409	S14 \$
002980	001669	-02335	0375	0000	0625	0625	1000	0375	0000	0000	0000	%0248	A15 \$	003071	002074	-01931	0500	0000	0625	0500	1000	0375	0000	003329	J15 \$	003152	002751	-01418	0625	0000	0625	0375	1000	0375	0000	%0410	S15 \$
002953	001714	-03084	0375	0000	0750	0625	1000	0250	0000	0000	0000	%0249	A16 \$	003053	002134	-02728	0500	0000	0750	0500	1000	0250	0000	003330	J16 \$	003249	002558	-02111	0625	0000	0750	0375	1000	0250	0000	%0411	S16 \$
003170	001533	-03560	0375	0000	0875	0625	1000	0750	0000	0000	0000	%0250	A17 \$	003143	002103	-03308	0500	0000	0875	0500	1000	0125	0000	003331	J17 \$	003259	002531	-02927	0625	0000	0875	0375	1000	0125	0000	%0412	S17 \$
003469	001318	-03998	0375	0000	1000	0625	1000	0000	0000	0000	0000	%0251	A18 \$	003168	002173	-04878	0500	0000	1000	0750	0500	1000	0000	003332	J18 \$	003382	002466	-03572	0625	0000	1000	0375	1000	0000	0000	%0413	S18 \$
003399	001670	001984	0375	0125	0000	0625	0875	1000	0000	0000	0000	%0252	B10 \$	003533	002466	-02233	0500	0125	0000	0500	0875	1000	0000	003333	K10 \$	003988	003082	002456	0625	0125	0000	0375	0875	1000	0000	%0414	T10 \$
003617	001491	000910	0375	0125	0125	0625	0875	0875	0000	0000	0000	%0253	B11 \$	003581	002299	001377	0500	0125	0125	0500	0875	0875	0000	003334	K11 \$	004190	003076	001707	0625	0125	0125	0375	0875	0875	0000	%0415	T11 \$
003550	001636	000086	0375	0125	0250	0625	0875	0750	0000	0000	0000	%0254	B12 \$	003847	002400	000585	0500	0125	0250	0500	0875	0750	0000	003335	K12 \$	004143	003244	000891	0625	0125	0250	0375	0875	0750	0000	%0416	T12 \$
003611	000760	-00636	0375	0125	0375	0625	0875	0625	0000	0000	0000	%0255	B13 \$	003752	002178	-00288	0500	0125	0375	0500	0875	0625	0000	003336	K13 \$	004216	003263	000120	0625	0125	0375	0375	0875	0625	0000	%0417	T13 \$
003635	000864	-01255	0375	0125	0500	0625	0875	0500	0000	0000	0000	%0256	B14 \$	003801	001547	-00978	0500	0125	0500	0500	0875	0500	0000	003337	K14 \$	004043	002851	-00704	0625	0125	0500	0375	0875	0500	0000	%0418	T14 \$
003614	000789	-01939	0375	0125	0600	0625	0875	0375	0000	0000	0000	%0257	B15 \$	003741	001467	-01525	0500	0125	0625	0500	0875	0375	0000	003338	K15 \$	003813	002117	-01163	0625	0125	0625	0375	0875	0375	0000	%0419	T15 \$
003763	000738	-02462	0375	0125	0750	0625	0875	0250	0000	0000	0000	%0258	B16 \$	003705	001473	-02349	0500	0125	0750	0500	0875	0250	0000	003339	K16 \$	003812	002114	-01916	0625	0125	0750	0375	0875	0250	0000	%0420	T16 \$
003989	000816	-02973	0375	0125	0875	0625	0875	0125	0000	0000	0000	%0259	B17 \$	003826	001390	-03019	0500	0125	0875	0500	0875	0125	0000	003400	K17 \$	003936	001919	-02530	0625	0125	0875	0375	0875	0125	0000	%0421	T17 \$
004214	000754	-03454	0375	0125	1000	0625	0875	0000	0000	0000	0000	%0260	B18 \$	004015	001358	-03523	0500	0125	1000	0500	0875	0000	0000	003411	K18 \$	004058	002026	-03230	0625	0125	1000	0375	0875	0000	0000	%0422	T18 \$
003786	001005	002434	0375	0250	0000	0625	0750	1000	0000	0000	0000	%0261	C10 \$	004039	001688	-02672	0500	0250	0000	0500	0750	1000	0000	003412	L10 \$	004407	002442	002837	0625	0250	0000	0375	0750	1000	0000	%0423	U10 \$
003933	000965	001401	0375	0250	0125	0625	0750	0875	0000	0000	0000	%0262	C11 \$	004245	001649	-001841	0500	0250	0125	0500	0750	0875	0000	003413	L11 \$	004568	002467	002225	0625	0250	0125	0375	0750	0875	0000	%0424	U11 \$
004027	000861	000501	0375	0250	0250	0625	0750	0750	0000	0000	0000	%0263	C12 \$	004360	001600	000947	0500	0250	0250	0500	0750	0750	0000	003414	L12 \$	004758	002351	001252	0625	0250	0250	0375	0750	0750	0000	%0425	U12 \$
004096	000491	-00340	0375	0250	0375	0625	0750	0625	0000	0000	0000	%0264	C13 \$	004318	001789	000077	0500	0250	0375	0500	0750	0625	0000	003415	L13 \$	004823	002325	000557	0625	0250	0375	0375	0750	0625	0000	%0426	U13 \$
004149	000474	-00934	0375	0250	0500	0625	0750	0500	0000	0000	0000	%0265	C14 \$	004311	001141	-00643	0500	0250	0500	0500	0750	0500	0000	003416	L14 \$	004789	002305	-00183	0625	0250	0500	0375	0750	0500	0000	%0427	U14 \$
004204	000367	-01560	0375	0250	0625	0625	0750	0375	0000	0000	0000	%0266	C15 \$	004243	001008	-01241	0500	0250	0625	0500	0750	0375	0000	003417	L15 \$	004430	001598	-00818	0625	0250	0625	0375	0750	0375	0000	%0428	U15 \$
004472	000407	-01944	0375	0250	0750	0625	0750	0250	0000	0000	0000	%0267	C16 \$	004338	001093	-01190	0500	0250	0750	0500	0750	0250	0000	003418	L16 \$	004573	001541	-01456	0625	0250	0750	0375	0750	0250	0000	%0429	U16 \$
004795	000283	-02444	0375	0250	0875	0625	0750	0125	0000	0000	0000	%0268	C17 \$	004605	000879	-02443	0500	0250	0875	0500	0750	0125	0000	003419	L17 \$	004673	001520	-02150	0625	0250	0875	0375	0750	0125	0000	%0430	U17 \$
005142	000179	-02793	0375	0250	1000	0625	0750	0000	0000	0000	0000	%0269	C18 \$	004969	000815	-02828	0500	0250	1000	0500	0750	0000	0000	00350	L18 \$	004805	001320	-02771	0625	0250	1000	0375	0750	0000	0000	%0431	U18 \$
004435	000099	003110	0375	0375	0000	0625	0625	1000	0000	0000	0000	%0270	D10 \$	004368	001231	003195	0500	0375	0000	0500	0625	1000	0000	00351	M10 \$	004791	001825	003358	0625	0375	0000	0375	0625	1000	0000	%0432	V10 \$
004443	000121	001979	0375	0375	0125	0625	0625	0875	0000	0000	0000	%0271	D11 \$	004551	001129	002212	0500	0375	0125	0500	0875	0625	0000	00352	M11 \$	004942	001729	002660	0625	0375	0125	0375	0625	0875	0000	%0433	V11 \$
004407	000024	000949	0375	0375	0250	0625	0625	0750	0000	0000	0000	%0272	D12 \$	004659	001111	001344	0500	0375	0250	0500	0625	0750	0000	00353	M12 \$	005103	001755	001740	0625	0375	0250	0375	0625	0750	0000	%0434	V12 \$
004502	000044	000124	0375	0375	0375	0625	0625	0625	0000	0000	0000	%0273	D13 \$	004840	000815	000426	0500	0375	0375	0500	0625	0625	0000	00354	M13 \$	005349	001569	000986	0625	0375	0375	0625	0625	0625	0000	%0435	V13 \$
004887	-00106	-00557	0375	0375	0500	0625	0625	0500	0000	0000	0000	%0274	D14 \$	004851	000476	-00304	0500	0375	0500	0500	0625	0500	0000	00355	M14 \$	005308	001582	000237	0625	0375	0500	0375	0625	0500	0000	%0436	V14 \$
005227	-00106	-01122	0375	0375	0625	0625	0625	0375	0000	0000	0000	%0275	D15 \$	005045	000485	-00983	0500	0375	0625	0500	0625	0375	0000	00356	M15 \$	005211	001046	-00607	0625	0375	0625	0375	0625	0375	0000	%0437	V15 \$
005362	-00213	-01551	0375	0375	0750	0625	0625	0250	0000	0000	0000	%0276	D16 \$	005223	000402	-01388	0500																				

See original or copy: <http://web.me.com/klaus.richter/HE74/HE74L0NA.TXT> /.PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

003961	005045	002630	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003954	005116	001938	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
003945	005080	001059	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
003913	005118	000170	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
003673	004661	-00678	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
003322	003708	-01281	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
003027	002908	-01894	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
003142	002817	-02544	0750	0000	0875	0250	1000	0125	0000	%0483	A26	\$
003418	002837	-03125	0750	0000	0975	0250	1000	0000	0000	%0484	A27	\$
004403	003768	002765	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$
004463	003798	002160	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
004575	003870	001344	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
004580	003935	000728	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
004408	003938	-00209	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
003946	003250	-01071	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
003541	002637	-01508	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
003760	002498	-02205	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
004059	002378	-02885	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
004801	003189	003148	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
004865	003289	002672	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
005172	003114	001628	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
005092	003226	000972	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
004993	003316	000156	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
004623	002753	-00505	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
004180	002210	-01193	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
004381	002047	-01905	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
004647	001957	-02464	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
005176	002695	003672	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
005311	002623	002973	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005470	002565	002344	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005750	002341	-001303	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005671	002440	-000562	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
005404	002411	-00131	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
004944	001663	-00906	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
005047	001599	-01493	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
005312	001372	-02067	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
005661	001909	-004255	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
005770	001905	-003427	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
005923	001835	-002799	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006158	001665	-001969	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006368	001578	-001073	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
006252	001622	-001230	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
005742	001008	-00529	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
005845	001003	-01145	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
005999	000945	-01750	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
006113	001155	-004619	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
006212	001101	-003767	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
006317	001105	-003255	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
006524	001020	-002359	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
006680	000908	-001651	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
006753	000753	-000604	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
006441	000355	-00454	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
006601	000390	-00912	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
006823	000398	-01378	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
006641	000236	-005270	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
006707	000236	-004369	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
006819	000245	-003813	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
007045	000222	-002957	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$
007153	000150	-002182	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007235	-00025	-001033	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
007316	000015	-000126	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$
007551	-00216	-00478	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$
007751	-00257	-01011	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$
007746	-00785	-006267	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$
007758	-00818	-005202	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$
007692	-00830	-004472	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$
007720	-00967	-003535	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$
007705	-01007	-002470	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$
007606	-00911	-001260	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$
007765	-00722	-000292	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$
007763	-00777	-00437	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$
007905	-00741	-00976	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$
008049	-01784	-006409	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$
008028	-01840	-005242	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$
008037	-01799	-004579	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$
008035	-01789	-003643	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$
008065	-01804	-002697	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$
008063	-01768	-001864	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$
008207	-01437	-000583	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$
008117	-01303	-000668	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$
008093	-01174	-00726	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$
004379	005651	002991	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$
004423	005583	002184	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$
004435	005664	001317	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$
004393	005634	000639	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$
004366	005603	-001126	0875	0000	0500	0125	1000	0375	0000	%0571	J23	\$
003915	005019	-011126	0875	0000	0625	0125	1000	0500	0000	%0572	J24	\$
003526	004221	-01629	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$
003317	003499	-02069	0875	0000	1000	0125	1000	0125	0000	%0574	J26	\$
003676	003182	-02761	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$
004745	004658	003523	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$
005132	004273	002299	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$
005096	004489	001534	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$
005066	004514	000993	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$
005006	004624	000245	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$
004835	004405	-00619	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$
004298	003550	-01314	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$
004042	002950	-01706	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$
004330	002638	-02287	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$
005223	003827	003629	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$
005303	003887	002998	0875	02								

See original or copy: <http://web.me.com/klaus.richter/HE74/HE74L0NA.TXT> /.PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

009563	-00062	000193	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
008881	-00712	-00510	0875	1000	1000	0000	0000	0000	0000	%0730	b02	\$
008290	-01012	-00625	0750	1000	1000	0000	0000	0000	0000	%0731	b03	\$
007719	-01363	-00790	0625	1000	1000	0000	0000	0000	0000	%0732	b04	\$
007218	-01826	-01234	0500	1000	1000	0000	0000	0000	0000	%0733	b05	\$
006697	-02206	-01693	0375	1000	1000	0000	0000	0000	0000	%0734	b06	\$
006140	-03022	-02076	0250	1000	1000	0000	0000	0000	0000	%0735	b07	\$
005556	-03331	-02518	0125	1000	1000	0000	0000	0000	0000	%0736	b08	\$
005468	-04406	-02893	0000	1000	1000	0000	0000	0000	0000	%0737	b09	\$
008704	000843	000538	1000	0875	0875	0000	0000	0000	0000	%0738	c01	\$
008433	000004	000185	0875	0875	0875	0000	0000	0000	0000	%0739	c02	\$
008028	-00644	-00474	0750	0875	0875	0000	0000	0000	0000	%0740	c03	\$
007272	-01001	-00619	0625	0875	0875	0000	0000	0000	0000	%0741	c04	\$
006843	-01445	-00821	0500	0875	0875	0000	0000	0000	0000	%0742	c05	\$
006339	-01828	-01226	0375	0875	0875	0000	0000	0000	0000	%0743	c06	\$
005699	-02345	-01857	0250	0875	0875	0000	0000	0000	0000	%0744	c07	\$
005219	-02742	-02177	0125	0875	0875	0000	0000	0000	0000	%0745	c08	\$
004734	-03670	-02520	0000	0875	0875	0000	0000	0000	0000	%0746	c09	\$
008338	001496	000926	1000	0750	0750	0000	0000	0000	0000	%0747	d01	\$
007880	000709	000441	0875	0750	0750	0000	0000	0000	0000	%0748	d02	\$
007526	000012	000101	0750	0750	0750	0000	0000	0000	0000	%0749	d03	\$
006857	-00604	-00326	0625	0750	0750	0000	0000	0000	0000	%0750	d04	\$
006367	-00937	-00627	0500	0750	0750	0000	0000	0000	0000	%0751	d05	\$
005821	-01440	-00997	0375	0750	0750	0000	0000	0000	0000	%0752	d06	\$
005268	-01994	-01498	0250	0750	0750	0000	0000	0000	0000	%0753	d07	\$
004739	-02301	-01862	0125	0750	0750	0000	0000	0000	0000	%0754	d08	\$
004152	-02897	-02102	0000	0750	0750	0000	0000	0000	0000	%0755	d09	\$
007853	002339	001126	1000	0625	0625	0000	0000	0000	0000	%0756	e01	\$
007374	001520	000816	0875	0625	0625	0000	0000	0000	0000	%0757	e02	\$
006914	000738	000466	0750	0625	0625	0000	0000	0000	0000	%0758	e03	\$
006427	000006	000162	0625	0625	0625	0000	0000	0000	0000	%0759	e04	\$
005971	-00565	-00315	0500	0625	0625	0000	0000	0000	0000	%0760	e05	\$
005543	-00957	-00612	0375	0625	0625	0000	0000	0000	0000	%0761	e06	\$
004937	-01650	-01216	0250	0625	0625	0000	0000	0000	0000	%0762	e07	\$
004317	-01852	-01560	0125	0625	0625	0000	0000	0000	0000	%0763	e08	\$
003934	-02240	-02021	0000	0625	0625	0000	0000	0000	0000	%0764	e09	\$
007305	003113	001807	1000	0500	0500	0000	0000	0000	0000	%0765	f01	\$
006799	002161	001319	0875	0500	0500	0000	0000	0000	0000	%0766	f02	\$
006407	001535	000971	0750	0500	0500	0000	0000	0000	0000	%0767	f03	\$
005828	000786	000543	0625	0500	0500	0000	0000	0000	0000	%0768	f04	\$
005464	000062	000126	0500	0500	0500	0000	0000	0000	0000	%0769	f05	\$
005070	-00488	-00402	0375	0500	0500	0000	0000	0000	0000	%0770	f06	\$
004565	-01063	-00719	0250	0500	0500	0000	0000	0000	0000	%0771	f07	\$
004021	-01422	-01390	0125	0500	0500	0000	0000	0000	0000	%0772	f08	\$
003545	-01871	-01356	0000	0500	0500	0000	0000	0000	0000	%0773	f09	\$
006733	004034	002101	1000	0375	0375	0000	0000	0000	0000	%0774	g01	\$
006169	002947	001595	0875	0375	0375	0000	0000	0000	0000	%0775	g02	\$
005719	002304	001273	0750	0375	0375	0000	0000	0000	0000	%0776	g03	\$
005179	001636	001068	0625	0375	0375	0000	0000	0000	0000	%0777	g04	\$
004744	000814	000469	0500	0375	0375	0000	0000	0000	0000	%0778	g05	\$
004536	000027	000115	0375	0375	0375	0000	0000	0000	0000	%0779	g06	\$
004312	-00456	-00463	0250	0375	0375	0000	0000	0000	0000	%0780	g07	\$
003622	-00959	-00754	0125	0375	0375	0000	0000	0000	0000	%0781	g08	\$
003254	-01604	-01273	0000	0375	0375	0000	0000	0000	0000	%0782	g09	\$
006186	004775	002408	1000	0250	0250	0000	0000	0000	0000	%0783	h01	\$
005530	003776	001842	0875	0250	0250	0000	0000	0000	0000	%0784	h02	\$
005092	002023	001604	0750	0250	0250	0000	0000	0000	0000	%0785	h03	\$
004624	002313	001312	0625	0250	0250	0000	0000	0000	0000	%0786	h04	\$
004234	001592	000973	0500	0250	0250	0000	0000	0000	0000	%0787	h05	\$
004052	000795	000471	0375	0250	0250	0000	0000	0000	0000	%0788	h06	\$
003814	000040	000000	0250	0250	0250	0000	0000	0000	0000	%0789	h07	\$
003444	-00484	-00416	0125	0250	0250	0000	0000	0000	0000	%0790	h08	\$
003276	-01057	-00841	0000	0250	0250	0000	0000	0000	0000	%0791	h09	\$
005492	005521	003147	1000	0125	0125	0000	0000	0000	0000	%0792	i01	\$
004980	004233	002389	0875	0125	0125	0000	0000	0000	0000	%0793	i02	\$
004445	003796	002253	0750	0125	0125	0000	0000	0000	0000	%0794	i03	\$
004026	003080	001790	0625	0125	0125	0000	0000	0000	0000	%0795	i04	\$
003702	002274	001362	0500	0125	0125	0000	0000	0000	0000	%0796	i05	\$
003487	001483	000933	0375	0125	0125	0000	0000	0000	0000	%0797	i06	\$
003147	000787	000320	0250	0125	0125	0000	0000	0000	0000	%0798	i07	\$
002701	000012	000039	0125	0125	0125	0000	0000	0000	0000	%0799	i08	\$
002858	-00349	-00661	0000	0125	0125	0000	0000	0000	0000	%0800	i09	\$
004799	006248	003528	1000	0000	0000	0000	0000	0000	0000	%0801	j01	\$
004247	005559	003094	0875	0000	0000	0000	0000	0000	0000	%0802	j02	\$
003799	004954	002734	0750	0000	0000	0000	0000	0000	0000	%0803	j03	\$
003499	003978	002130	0625	0000	0000	0000	0000	0000	0000	%0804	j04	\$
003114	003199	001685	0500	0000	0000	0000	0000	0000	0000	%0805	j05	\$
002872	002663	001322	0375	0000	0000	0000	0000	0000	0000	%0806	j06	\$
002718	001967	000856	0250	0000	0000	0000	0000	0000	0000	%0807	j07	\$
002616	001144	000791	0125	0000	0000	0000	0000	0000	0000	%0808	j08	\$
002191	000641	000420	0000	0000	0000	0000	0000	0000	0000	%0809	j09	\$
009639	-00065	000194	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
008654	-00186	-00379	0875	1000	1000	0000	0000	0000	0000	%0811	b11	\$
008069	-00191	-00906	0750	1000	1000	0000	0000	0000	0000	%0812	b12	\$
007382	-00159	-01255	0625	1000	1000	0000	0000	0000	0000	%0813	b13	\$
006581	-00933	-01725	0500	1000	1000	0000	0000	0000	0000	%0814	b14	\$
005989	-00187	-02198	0375	1000	1000	0000	0000	0000	0000	%0815	b15	\$
005310	-00272	-02779	0250	1000	1000	0000	0000	0000	0000	%0816	b16	\$
004675	-00203	-03125	0125	1000	1000	0000	0000	0000	0000	%0817	b17	\$
003975	-00209	-04154	0000	1000	1000	0000	0000	0000	0000	%0818	b18	\$
002973	000089	000919	1000	1000	1000	0000	0000	0000	0000	%0819	c10	\$
002607	-00002	000171	0875	0875	0875	0000	0000	0000	0000	%0820	c11	\$
002150	-00160	-00408	0750	0875	0875	0000	0000	0000	0000	%0821	c12	\$
001935	-00179	-00886	0625	0875	0875	0000	0000	0000	0000	%0822	c13	\$
006364	-00009	-01451	0500	0875	0875	0000	0000	0000	0000	%0823	c14	\$
005669	-00166	-01924	0375	0875	0875	0000	0000	0000	0000	%0824	c15	\$
004983	-00344	-02429	0250	0875	0875	0000	0000	0000	0000	%0825	c16	\$
004267	-00189	-02949	0125	0875	0875	0000	0000	0000	0000	%0826	c17	\$
003608	-00172	-03565	0000	0875	1000	1000	0000	0000	0000	%0827	c18	\$
009121	000230	001735	1000	1000	1000	0000	0000	0000	0000	%0828	d10	\$
008426	000092	000810	0875	0875	0875	0000	0000</					

%BEG HE64_22.TXT, Separation cmyn5*, cfi=0.90, D50, not adapted \$
%100 x LAB* %1000 x (r g b c m y 0) %nr. pos \$
%z004874 006258 003343 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008278 000236 006888 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005493 -05144 001724 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005496 -04543 -02805 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z003985 -00378 -04109 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003781 003707 -02286 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z002033 000630 000456 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009541 -00064 000212 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004799 006248 003528 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008312 000192 006902 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005509 -05166 001502 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005468 -04496 -02803 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003875 -00309 -04164 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003812 003695 -02245 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z002097 000667 000450 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009610 -00065 000199 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/HE74/HE74L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

%BEG HE64_22.TXT, Separation cmy5*, cfi=0.90, D50, not adapted S																			
%100 x LAB*				1000 x (r g b c m y 0)				%nr.				pos \$							
001927	000056	000393	0000	0000	0000	0000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002471	000003	000092	0125	0125	0125	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003567	000040	000005	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004341	000049	000133	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005335	000098	000102	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006449	000021	000135	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007632	-000002	000110	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008595	000004	000154	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009553	-000006	000190	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001910	000655	000420	0000	0000	0000	0000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002397	000019	000070	0125	0125	0125	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003539	000039	000000	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004311	000050	000118	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005290	000079	000111	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006460	000010	000121	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007615	-000005	000112	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008551	000000	000164	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009636	-000062	000187	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001886	000668	000420	0000	0000	0000	0000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002418	000009	000090	0125	0125	0125	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003528	000044	000014	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004297	000046	000127	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005264	000092	000123	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006409	000011	000172	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007619	000000	000120	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008575	000005	000173	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009638	-000066	000195	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001848	000658	000402	0000	0000	0000	0000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002382	000011	000089	0125	0125	0125	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003495	000047	000017	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004268	000048	000159	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005259	000004	000126	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006428	000006	000172	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007581	000018	000118	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008543	000014	000165	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009649	-000063	000181	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002154	000639	000393	0000	0000	0000	0000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002482	000027	000043	0066	0066	0066	0933	0933	0933	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002689	000014	000030	0133	0133	0133	0866	0866	0866	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003096	000017	000019	0200	0200	0200	0800	0800	0800	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003928	000029	000042	0266	0266	0266	0333	0333	0333	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004308	000066	000113	0333	0333	0333	0666	0666	0666	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004572	000066	000080	0400	0400	0400	0600	0600	0600	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005250	000033	000139	0466	0466	0466	0533	0533	0533	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005803	000073	000166	0533	0533	0533	0666	0666	0666	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006300	-000015	000217	0600	0600	0600	0400	0400	0400	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006764	-000040	000202	0666	0666	0666	0333	0333	0333	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007430	000027	000112	0734	0734	0734	0266	0266	0266	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007960	-000018	000165	0800	0800	0800	0200	0200	0200	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008402	-00024	000182	0866	0866	0866	0133	0133	0133	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008697	-00029	000187	0933	0933	0933	0066	0066	0066	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009530	-00056	000181	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002120	000672	000399	0000	0000	0000	0000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002424	000026	000073	0066	0066	0066	0933	0933	0933	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002609	000015	000044	0133	0133	0133	0866	0866	0866	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003057	000015	000034	0200	0200	0200	0800	0800	0800	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003909	000035	000062	0266	0266	0266	0333	0333	0333	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004311	000073	000119	0333	0333	0333	0666	0666	0666	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004574	000064	000069	0400	0400	0400	0600	0600	0600	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005263	000041	000120	0466	0466	0466	0													

TUB registration: 20091101-HE74/HE74L0NA.TXT /.PS
TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

002514	001308	000423	0250	0000	0000	0750	1000	1000	0000	001612	S01
002441	001481	-00467	0250	0000	0125	0750	1000	0875	0000	001613	S02
002595	000867	-01381	0250	0000	0250	0750	1000	0750	0000	001614	S03
002583	000717	-01952	0250	0000	0375	0750	1000	0625	0000	001615	S04
002583	000507	-02513	0250	0000	0500	0750	1000	0500	0000	001616	S05
002893	000438	-02945	0250	0000	0625	0750	1000	0375	0000	001617	S06
003159	000208	-03379	0250	0000	0750	0750	1000	0250	0000	001618	S07
003584	000172	-03709	0250	0000	0875	0750	1000	0125	0000	001619	S08
003632	000319	-04192	0250	0125	0000	0750	0875	0000	0000	001620	S09
003932	000319	-04126	0250	0125	0000	0750	0875	1000	0000	001621	S10
002942	000281	-00078	0250	0125	0125	0750	0875	0875	0000	001712	T02
003833	000059	-00792	0250	0125	0250	0750	0875	0750	0000	001713	T03
003213	-00023	-01469	0250	0125	0375	0750	0875	0625	0000	001714	T04
003327	-00095	-02049	0250	0125	0500	0750	0875	0500	0000	001715	T05
003559	-00086	-02383	0250	0125	0625	0750	0875	0375	0000	001716	T06
003937	-00137	-02826	0250	0125	0750	0750	0875	0250	0000	001717	T07
004180	-00176	-03268	0250	0125	0875	0750	0875	0125	0000	001718	T08
004473	-00271	-03800	0250	0125	1000	0750	0875	0000	0000	001719	T09
003484	-00579	-001886	0250	0250	0000	0750	0750	1000	0000	001800	U01
003383	-00574	000590	0250	0250	0125	0750	0750	0875	0000	00181	U02
003601	-00432	-00402	0250	0250	0250	0750	0750	0750	0000	001812	U03
004020	-00404	-01038	0250	0250	0375	0750	0750	0625	0000	001813	U04
004271	-00569	-01420	0250	0250	0500	0750	0750	0500	0000	001814	U05
004352	-00641	-02029	0250	0250	0625	0750	0750	0375	0000	001815	U06
004352	-00641	-02292	0250	0250	0625	0750	0750	0000	0000	001816	U07
005055	-00761	-02250	0250	0300	0875	0750	0750	0125	0000	001818	U08
005385	-00651	-03048	0250	0250	1000	0750	0750	0000	0000	001818	U09
003971	-01314	-00276	0250	0375	0000	0750	0625	1000	0000	001819	V01
003917	-01216	-000872	0250	0375	0125	0750	0625	0875	0000	001910	V02
004068	-01082	-008238	0250	0375	0250	0750	0625	0750	0000	00191	V03
004123	-00882	-00865	0250	0375	0375	0750	0625	0625	0000	001912	V04
004338	-01113	-01484	0250	0375	0500	0750	0625	0500	0000	001913	V05
004545	-00979	-01897	0250	0375	0625	0750	0625	0375	0000	001914	V06
004777	-01105	-02339	0250	0375	0750	0750	0625	0250	0000	001915	V07
005126	-01095	-02724	0250	0375	0875	0750	0625	0125	0000	001916	V08
005424											

```
input: w setgray
output: ->oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/HE74/HE74L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

003086	002017	000887	0375	0000	0000	0625	1000	1000	0000	%0243	A10	\$	003294	002688	001238	0500	0000	0000	0500	1000	1000	0000	%0324	J10	\$	003699	003381	001558	0625	0000	0000	0375	1000	1000	0000	%0405	S10	\$
003084	002068	000169	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$	003244	002931	000489	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$	003571	003676	000923	0625	0000	0125	0375	1000	0875	0000	%0406	S11	\$
002996	002027	-00782	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$	003184	003054	-00311	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$	003571	003736	000184	0625	0000	0250	0375	1000	0750	0000	%0407	S12	\$
002960	001291	-01451	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$	003148	002649	-01195	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$	003593	003627	-00595	0625	0000	0375	0375	1000	0625	0000	%0408	S13	\$
002939	001191	-02197	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$	003085	001822	-01764	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$	003291	002919	-01341	0625	0000	0500	0375	1000	0500	0000	%0409	S14	\$
002980	001126	-02761	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$	003071	001540	-02354	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$	003152	002224	-01839	0625	0000	0625	0375	1000	0375	0000	%0410	S15	\$
002953	001168	-03510	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$	003053	001598	-03151	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$	003249	002040	-02529	0625	0000	0750	0375	1000	0250	0000	%0411	S16	\$
003170	001007	-03980	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$	003143	001576	-03729	0500	0000	0875	0500	1000	0125	0000	%0331	J17	\$	003259	002014	-03244	0625	0000	0875	0375	1000	0125	0000	%0412	S17	\$
003468	000820	-04408	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$	003168	001648	-04497	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$	003382	001961	-03985	0625	0000	1000	0375	1000	0000	0000	%0413	S18	\$
003399	001166	-001572	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$	003553	001974	-001825	0500	0125	0000	0500	0875	1000	0000	%0333	K10	\$	003988	002633	002063	0625	0125	0000	0375	0875	1000	0000	%0414	T10	\$
003617	001007	000505	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$	003881	001839	000081	0500	0125	0125	0500	0875	0875	0000	%0334	K11	\$	004190	002645	001320	0625	0125	0125	0375	0875	0875	0000	%0415	T11	\$
003550	001146	-00321	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$	003847	001938	000187	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$	004143	002800	000503	0625	0125	0250	0375	0875	0750	0000	%0416	T12	\$
003611	000276	-01042	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$	003752	001707	-00689	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$	004216	002835	-00265	0625	0125	0375	0375	0875	0625	0000	%0417	T13	\$
003635	000382	-01659	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$	003801	001880	-01377	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$	004043	002406	-01096	0625	0125	0500	0375	0875	0500	0000	%0418	T14	\$
003614	000305	-02335	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$	003741	000994	-01926	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$	003813	001651	-01562	0625	0125	0625	0375	0875	0375	0000	%0419	T15	\$
003763	000267	-02863	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$	003705	000997	-02751	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$	003812	001648	-02315	0625	0125	0750	0375	0875	0250	0000	%0420	T16	\$
003989	000366	-03366	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$	003826	000925	-03417	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$	003936	001465	-02925	0625	0125	0875	0375	0875	0125	0000	%0421	T17	\$
004214	000326	-03840	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$	004015	000911	-03915	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$	004058	001583	-03621	0625	0125	1000	0375	0875	0000	0000	%0422	T18	\$
003786	000537	-02034	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$	004039	001244	-02280	0500	0250	0000	0500	0750	1000	0000	%0342	L10	\$	004407	002031	-00245	0625	0250	0000	0375	0750	0875	0000	%0423	U10	\$
003933	000511	001006	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$	004245	001223	-001456	0500	0250	0125	0500	0750	0875	0000	%0343	L11	\$	004568	002071	001850	0625	0250	0125	0375	0750	0875	0000	%0424	U11	\$
004027	000415	000109	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$	004360	001185	-00566	0500	0250	0250	0500	0750	0750	0000	%0344	L12	\$	004758	001973	000884	0625	0250	0250	0375	0750	0750	0000	%0425	U12	\$
004096	000051	-00730	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$	004318	001370	-00305	0500	0250	0375	0500	0750	0625	0000	%0345	L13	\$	004823	001952	000191	0625	0250	0375	0375	0750	0625	0000	%0426	U13	\$
004149	000039	-01322	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$	004311	000722	-01026	0500	0250	0500	0500	0750	0500	0000	%0346	L14	\$	004789	001929	-00550	0625	0250	0500	0375	0750	0500	0000	%0427	U14	\$
004204	-00061	-01946	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$	004243	000582	-01626	0500	0250	0625	0500	0750	0375	0000	%0347	L15	\$	004430	001189	-01197	0625	0250	0625	0375	0750	0375	0000	%0428	U15	\$
004472	000002	-02322	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$	004338	000676	-02287	0500	0250	0750	0500	0750	0250	0000	%0348	L16	\$	004573	001146	-01830	0625	0250	0750	0375	0750	0250	0000	%0429	U16	\$
004795	-00091	-02811	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$	004605	000487	-02816	0500	0250	0875	0500	0750	0125	0000	%0349	L17	\$	004673	001134	-02521	0625	0250	0875	0375	0750	0125	0000	%0430	U17	\$
005142	-00162	-03149	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$	004969	000457	-03189	0500	0250	1000	0500	0750	0000	0000	%0350	L18	\$	004805	000946	-03138	0625	0250	1000	0375	0750	0000	0000	%0431	U18	\$
004435	-00318	002728	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$	004368	000816	-002814	0500	0375	0000	0500	0625	1000	0000	%0351	M10	\$	004791	001449	002991	0625	0375	0000	0375	0625	1000	0000	%0432	V10	\$
004443	-00286	001601	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$	004551	000722	-001837	0500	0375	0125	0500	0625																		

See original or copy: <http://web.me.com/klaus.richter/HE74/HE74L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

003961	004593	002236	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003954	004663	001544	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
003915	004624	000663	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
003843	004656	-00227	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
003673	004182	-01081	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
003322	003197	-01695	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
003027	002450	-02319	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
003142	002289	-02965	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$
003419	002335	-03536	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$
004403	003357	002385	0750	0125	0000	0250	0875	1000	0000	%0495	B19	\$
004635	003408	001788	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
004575	003475	000970	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
004580	003540	000354	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
004408	003527	-00588	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
003946	002797	-01466	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
003541	002146	-01916	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
003760	002027	-02606	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
004059	001935	-03276	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
004801	002815	002781	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
004865	002921	002307	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
005172	002774	001273	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
005092	002878	000615	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
004993	002959	-00204	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
004623	002362	-00877	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
004180	001778	-01580	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
004381	001633	-02286	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
004647	001568	-02836	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
005176	002355	003317	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
005311	002296	002622	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005470	002253	001999	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005759	002055	000967	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005671	002146	000224	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
005404	002092	-00478	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
004944	001301	-01268	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
005047	001247	-01851	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
005312	001045	-02417	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
005661	001615	003916	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
005770	001620	003092	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
005923	001565	002469	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006158	001417	001646	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006368	001349	000757	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
006252	001381	000010	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
005742	000720	-00866	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
005845	000726	-01478	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
005999	000681	-02078	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
006113	000902	004295	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
006212	000857	003446	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
006317	000871	002937	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
006524	000805	002048	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
006680	000707	001346	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
006753	000559	000300	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
006441	000132	-00768	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
006601	000182	-01221	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
006823	000211	-01679	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
006641	000028	-004963	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
006707	000038	-004064	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
006819	000057	003511	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
007045	000055	002663	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$
007153	000002	-001861	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007235	-00174	000745	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
007316	-00126	00158	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$
007551	-00336	-00756	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$
007751	-00358	-01282	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$
007746	-00887	-005996	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$
007758	-00919	-004932	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$
007692	-00937	-004199	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$
007720	-01071	003263	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$
007705	-01113	002198	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$
007606	-01026	000985	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$
007765	-00823	000022	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$
007763	-00877	-00708	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$
007905	-00828	-01242	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$
008049	-01858	-006148	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$
008028	-01916	-004980	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$
008037	-01874	-004317	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$
008035	-01864	-003381	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$
008065	-01876	-002437	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$
008063	-01841	-001603	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$
008207	-01496	-000327	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$
008117	-01371	-00327	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$
008093	-01244	-00985	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$
004379	005238	002611	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$
004423	005174	001805	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$
004435	005255	000938	0875	0000	0250	0125	1000	0750	000			

See original or copy: <http://web.me.com/klaus.richter/HE74/HE74L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

009563	-00002	-00007	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
008881	-00718	-00734	0875	1000	1000	0000	0125	0000	0000	%0730	b02	\$
008290	-01076	-00868	0750	1000	1000	0000	0250	0000	0000	%0731	b03	\$
007719	-01483	-01052	0625	1000	1000	0000	0375	0000	0000	%0732	b04	\$
007618	-01994	-01514	0500	1000	1000	0000	0500	0000	0000	%0733	b05	\$
006297	-02425	-01980	0375	1000	1000	0000	0625	0000	0000	%0734	b06	\$
006140	-03295	-02391	0250	1000	1000	0000	0750	0000	0000	%0735	b07	\$
005556	-03651	-02853	0125	1000	1000	0000	0875	0000	0000	%0736	b08	\$
005468	-04351	-03141	0000	1000	1000	0000	1000	0000	0000	%0737	b09	\$
008704	-00820	-000309	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
008433	-00044	-00053	0875	0875	0875	0125	0125	0125	0000	%0739	c02	\$
008028	-00733	-00727	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
007272	-01164	-00897	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
006843	-01650	-01113	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
006339	-02082	-01535	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
005699	-02661	-02187	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005219	-03105	-02523	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
004734	-04081	-02882	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008338	001437	000684	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
007880	000606	000184	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
007526	-00125	-00167	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
006857	-00807	-00618	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
006367	-01189	-00935	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
005821	-01744	-01323	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
005268	-02352	-01842	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
004739	-02711	-02224	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
004152	-03364	-02484	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007853	002233	000868	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007374	001367	000542	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
006914	000540	000176	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006427	-00239	-00142	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
005971	-00855	-00636	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
005543	-01289	-00897	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
004937	-02049	-01517	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
004317	-02303	-01936	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
003934	-02729	-02410	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007305	002953	001539	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006799	001952	001025	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006407	001287	000665	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$
005828	000483	000218	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005464	-00277	-00211	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005070	-00866	-00753	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
004565	-01490	-01087	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004021	-01903	-01776	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
003545	-02398	-01758	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006733	003818	001805	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
006169	002677	001280	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005719	001989	000944	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005179	001269	000720	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004744	000405	000107	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
004536	-00402	-00252	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004312	-00908	-00839	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
003622	-01478	-01153	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003254	-02159	-01684	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
006186	003406	002166	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005530	004544	001506	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
005092	002647	001254	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
004594	001898	000944	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
004234	001133	000594	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
004052	000317	000086	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
003814	-00460	-00392	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
003444	-01020	-00821	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
003276	-01610	-01252	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
005492	005184	002810	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004980	003847	002035	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
004445	003357	001881	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
004026	002601	001404	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
003702	001763	000966	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
003487	000951	000529	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
003147	000221	-00094	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
002701	-00596	-00390	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
002858	-00943	-01086	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
004799	005844	003168	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
004247	005101	002716	0750	0000	0000	0125	1000	1000	0000	%0802	j02	\$
003799	004452	002341	0875	0000	0000	0250	1000	1000	0000	%0803	j03	\$
003499	003447	001726	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
003114	-002631	-001269	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
002872	-002071	-000897	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
002718	-001360	-000427	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
002616	-000526	-000358	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
002191	-000017	-000026	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009639	000002	-00004	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
008654	-00214	-00611	0875	0875	0875	0100	0125	0125	0000	%0811	b11	\$
008069	-00276	-01157	0750	0750	0750	0250	0250	0250	0000	%0812	b12	\$
007382	-00311	-01529	0625	1000	0375	0375	0000	0000	0000	%0813	b13	\$
006581	-00263	-02026	0500	0500	0500	0500	0000	0000	0000	%0814	b14	\$
005989	-00475	-02518	0375	0375	0375	0625	0625	0625	0000	%0815	b15	\$
005310	-00626	-03122	0250	0250	0250	0750	0750	0750	0000	%0816	b16	\$
004675	-00710	-03710	0125	0100	0875	0875	0000	0000	0000	%0817	b17	\$
003975	-00803	-04555	0000	1000	1000	1000	0000	0000	0000	%0818	b18	\$
003273	000121	000708	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$
002973	-00034	-00061	0875	0875	0875	0125	0125	0125	0000	%0820	c11	\$
002750	-00257	-00663	0750	0750	0750	0250	0250	0125	0000	%0821	c12	\$
002135	-00355	-01168	0625	0625	0875	0375	0375	0125	0000	%0822	c13	\$
006364	-00261	-01759	0500	0500	0500	0500	0125	0000	0000	%0823	c14	\$
005669	-00485	-02255	0375	0375	0875	0625	0625	0125	0000	%0824	c15	\$
004983	-00730	-02783	0250	0250	0875	0750	0750	0125	0000	%0825	c16	\$
004267	-00645	-03327	0125	0125	0875	0875	0125	0000	0000	%0826	c17	\$
003608	-00692	-03965	0000	0000	0875	1000	1000	0125	0000	%0827	c18	\$
009121	000247	-001519	1000	1000	0750	0000	0250	0000	0000	%0828	d10	\$
008426	000042	000570	0875	0875	0750	0125	0125	0250	0000			

%BEG HE64_22.TXT, Separation cmyn5*, cfi=0.90, D50, adapted \$
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos \$
%z004874 005890 002978 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008278 000183 006635 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005493 -05455 001379 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005496 -04853 -03150 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z003985 -00828 -04503 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003781 003238 -02686 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z002933 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009541 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004799 005844 003168 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008312 000131 006659 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005509 -05501 001256 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005468 -04835 -03141 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003875 -00803 -04555 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003812 003194 -02638 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z002097 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009610 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/HE74/HE74L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG HE64.22.TXT, Separation cmy5*, cfi=0.90, D50, adapted S
%100 x LAB*a      1000 x (r g b   c m y 0)   %nrr. pos $
001927 000005 -00080 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002471 -00595 -00362 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003567 -00455 -00410 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004341 -00375 -00254 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005335 -00233 -00250 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006449 -00205 -00178 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
007632 -00119 -00160 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008595 -00021 -00082 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009533 -00008 -00009 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
010190 -00003 -00053 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002397 -00586 -00387 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003539 -00460 -00416 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004311 -00376 -00270 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005290 -00256 -00243 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006460 -00215 -00191 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
007615 -00123 -00159 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
008551 -00030 -00074 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009636 -00008 -00012 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
010186 -00015 -00054 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002418 -00594 -00365 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003528 -00456 -00402 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004297 -00381 -00262 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
005264 -00245 -00231 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006409 -00219 -00142 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
007619 -00117 -00151 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
008575 -00022 -00064 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009638 -00004 -00004 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
010184 -00000 -00074 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002382 -00596 -00368 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003495 -00455 -00401 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004268 -00382 -00231 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005259 -00243 -00229 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006428 -00182 -00142 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
007581 -00102 -00154 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008543 -00017 -00073 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009649 -00009 -00018 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
010154 -00001 -00072 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
002482 -00570 -00410 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002689 -00564 -00416 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
003096 -00523 -00413 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
003928 -00433 -00360 0266 0266 0266 0333 0333 0333 0000 %1012 k14 $
004308 -00360 -00275 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
004572 -00335 -00299 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005250 -00305 -00216 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
005803 -00214 -00170 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006300 -00256 -00101 0600 0600 0600 0400 0400 0400 0000 %1017 k19 $
006764 -00238 -00099 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007430 -00108 -00165 0734 0734 0734 0266 0266 0266 0000 %1019 k21 $
007960 -00104 -00093 0800 0800 0800 0200 0200 0200 0000 %1020 k22 $
008402 -00069 -00061 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
008697 -00046 -00045 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009530 -00004 -00022 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
010120 -00000 -00067 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
002424 -00577 -00383 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
002609 -00565 -00403 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
003057 -00528 -00399 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
003909 -00429 -00341 0266 0266 0266 0333 0333 0333 0000 %1028 l14 $
004311 -00353 -00270 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
004574 -00337 -00310 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005263 -00296 -00235 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
005780 -00195 -00221 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006284 -00243 -00140 0600 0600 0600 0400 0400 0400 0000 %1033 l19 $
006731 -00227 -00151 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007417 -00094 -00182 0734 0734 0734 0266 0266 0266 0000 %1035 l21 $
007998 -00098 -00096 0800 0800 0800 0200 0200 0200 0000 %1036 l22 $
008375 -00068 -00073 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
008683 -00046 -00045 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009552 -00005 -00018 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
010203 -00056 -00074 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
002428 -00568 -00391 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002658 -00561 -00402 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
003021 -00529 -00390 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
003889 -00428 -00342 0266 0266 0266 0333 0333 0333 0000 %1044 m14 $
004287 -00352 -00246 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
004533 -00326 -00308 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005221 -00300 -00211 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
005769 -00201 -00192 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006264 -00243 -00123 0600 0600 0600 0400 0400 0400 0000 %1049 m19 $
006742 -00231 -00123 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007424 -00092 -00169 0734 0734 0734 0266 0266 0266 0000 %1051 m21 $
007990 -00100 -00097 0800 0800 0800 0200 0200 0200 0000 %1052 m22 $
```