

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE10/GE10L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=

TUB registration: 20091101-GE10/GE10L0NA.TXT / .PS TUB ma
application for evaluation and measurement of printer or monitor systems

IUB material: code=rha4ta

SBEQ GE00 22 REM.TXT, Separation olv*, D65, not adapted																				
%100 x LAB*	1000 x r g b	%100 x c m y	%100 x a	%100 x pos \$	%100 x pos \$	%100 x pos \$	%100 x pos \$	%100 x pos \$	%100 x pos \$	%100 x pos \$	%100 x pos \$	%100 x pos \$	%100 x pos \$	%100 x pos \$	%100 x pos \$	%100 x pos \$	%100 x pos \$	%100 x pos \$	%100 x pos \$	%100 x pos \$
000714	006221	000018	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
000913	006227	000033	008750	1000	0125	0000	0000	0000	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
000879	011137	003032	0750	1000	0000	0000	0000	0000	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
000294	01629	005676	0625	1000	0000	0000	0000	0000	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
007672	02079	011191	0500	1000	0000	0000	0000	0000	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
007065	02779	01152	0375	1000	1000	0625	0000	0000	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
006405	03415	01578	0250	1000	1000	0750	0000	0000	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
006109	03726	01770	0125	1000	1000	0875	0000	0000	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
005993	03908	01875	0000	1000	1000	0000	0000	0000	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
008930	000867	000387	1000	0875	0000	0125	0125	0000	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
008646	00071	000231	0875	0875	0875	0125	0125	0125	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
008889	01246	000327	0750	0875	0875	0250	0125	0125	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
008325	01800	00030	0625	0875	0875	0375	0125	0125	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
007677	02428	00265	0500	0875	0875	0500	0125	0125	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
007239	02847	00395	0375	0875	0875	0625	0125	0125	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
006612	03254	00747	0250	0875	0875	0750	0125	0125	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
006074	04155	01032	0125	0875	0875	0875	0125	0125	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
005861	04316	01330	0000	0875	0875	1000	0125	0125	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
008118	001827	000627	1000	0750	0750	0000	0250	0250	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
007961	000995	000394	0875	0750	0750	0125	0250	0250	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
007738	000950	000149	0750	0750	0750	0250	0250	0250	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
007649	01245	000117	0625	0750	0750	0375	0250	0250	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
007638	02138	000122	0500	0750	0750	0500	0250	0250	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
007250	02836	000144	0375	0750	0750	0625	0250	0250	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
006955	000933	000100	0750	0750	0750	0750	0250	0250	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
006055	04400	00716	0125	0750	0750	0875	0250	0250	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
005724	04746	01002	0000	0750	0750	1000	0250	0250	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
007243	002863	001271	1000	0625	0625	0000	0375	0375	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
007334	002069	000749	0875	0625	0625	0125	0375	0375	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
006922	001068	000283	0750	0625	0625	0250	0375	0375	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
006458	00035	000096	0625	0625	0625	0375	0375	0375	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
006746	01270	00020	0500	0625	0625	0500	0375	0375	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
006546	02339	00054	0375	0625	0625	0625	0375	0375	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
006371	03473	00345	0250	0625	0625	0625	0750	0375	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
005736	05066	00626	0125	0625	0625	0875	0375	0375	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
005317	05437	01049	0000	0625	0625	1000	0375	0375	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
006201	004407	001786	1000	0500	0500	0000	0500	0500	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
006430	003450	001469	0875	0500	0500	0125	0500	0500	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
006186	002090	000851	0750	0500	0500	0250	0500	0500	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
005728	001083	000307	0625	0500	0500	0375	0500	0500	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
005174	000019	000064	0500	0500	0500	0500	0500	0500	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
005505	01351	00217	0375	0500	0500	0625	0500	0500	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
005376	02562	00325	0250	0500	0500	0500	0750	0500	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
005147	05211	00577	0125	0500	0500	0875	0500	0500	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
005092	05652	00548	0000	0500	0500	0500	1000	0500	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
005276	005884	002548	1000	0375	0375	0000	0625	0625	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
005355	005517	002374	0875	0375	0375	0375	0125	0625	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
005407	002380	000859	0250	0375	0375	0375	0125	0625	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
004907	002100	000869	0250	0375	0375	0375	0125	0625	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
004600	001187	000262	0500	0375	0375	0375	0500	0625	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
003942	000004	000026	0375	0375	0375	0625	0625	0625	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
004249	01515	00230	0250	0375	0375	0750	0625	0625	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
004272	03618	00473	0125	0375	0375	0875	0625	0625	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
004264	04591	00482	0000	0375	0375	1000	0625	0625	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000
004829	006578	003196	1000	0250	0250	0000	0750	0750	0000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000	000000</

TUB-test chart GE10; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

input: w *setgray*
output: no change compared to input

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009702	-00109	000237	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009307	-00563	-00207	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008818	-00970	-00698	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
008329	-01304	-01263	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
007805	-01601	-01902	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
007116	-02025	-02586	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006285	-02418	-03527	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
005484	-02548	-04529	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005381	-02303	-04782	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
009190	-000329	-000854	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
008722	-00063	-000211	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
008790	-00931	-00281	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
008329	-01450	-00956	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
007642	-01949	-01577	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
007055	-02311	-02165	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
006241	-02801	-02887	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
005375	-03122	-04040	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
005304	-02296	-04707	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
008740	000790	001208	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
008188	000487	000905	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
007637	-00049	-000151	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
007527	-00979	-00379	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
007172	-01553	-00921	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
006514	-01900	-01582	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
005947	-02579	-02314	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
005379	-03506	-03505	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
005299	-02548	-04422	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
008125	001330	002036	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
007721	000970	001663	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
007137	000605	000651	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
006450	-00037	-000118	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
006484	-00933	-00443	0500	0593	0625	0500	0406	0375	0000	00112	M05	\$
005974	-01600	-01130	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
005543	-02135	-01941	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
005064	-03246	-03197	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
005008	-02624	-04041	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007370	002293	002512	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
007185	001854	002230	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
006602	001158	001564	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
005922	000664	000601	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
005195	-00016	-00006	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
005241	-00970	-00702	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
004920	-01566	-01486	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
004517	-02747	-02602	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
004401	-02199	-03719	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
006431	003601	003539	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
006525	003010	003089	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
006117	001985	002185	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
005508	001293	001536	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
004876	000656	000661	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
004033	-00005	-000032	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
004080	-01099	-00838	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
003948	-02102	-01818	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003724	-02049	-02756	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
005640	004846	004678	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
005633	004731	004452	0875	0406	0500	0125	0593	0750	0000	00136	P02	\$
005287	003396	003320	0750	0375	0250	0250	0625	0625	0000	00137	P03	\$
004785	002304	002305	0625	0343	0250	0500	0625	0750	0000	00138	P04	\$
004284	001409	001566	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
003672	000751	000709	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
002932	000010	000027	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
003204	-01661	-00984	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
002832	-01267	-01826	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
005115	005855	005001	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
004877	006099	005035	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
004347	005057	004083	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
003872	004206	003311	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
003620	002912	002406	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
003206	001859	001543	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
002683	000863	000806	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
002083	000040	000081	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
002423	-00976	-00299	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
004915	006218	005015	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
004590	005869	004753	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
004079	005425	004036	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
003621	004522	003279	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
003182	003646	002479	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
002745	002534	001582	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
002539	001949	001019	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
002074	000277	000178	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
001973	000635	000074	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009688	-00009	-000216	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
008977	-000215	-00049	0806	0875	1000	0093	0125	0000	0000	00406	J11	\$
007925	-000218	-01461	0812	0750	1000	0187	0250	0000	0000	00407	J12	\$
006622	-000275	-02563	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
005660	-000359	-03320	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
004805	-000354	-03981	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
004158	-000001	-04619	0347	0250	1000	0562	0750	0000	0000	00411	J16	\$
003912	-00120	-04783	0343	0250	1000	0875	0875	0000	0000	00412	J17	\$
003022	-00141	-04769	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
000574	-00788	-001832	0968	1000	0875	0031	0000	0125	0000	00414	J19	\$
000862	-00703	-000227	0875	0875	0875	0125	0125	0125	0000	00415	K10	\$
008229	-00353	-01145	0781	0750	0875	0218	0250	0125	0000	00416	K12	\$
008669	-000392	-02221	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
005644	-000595	-03231	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
004682	-000614	-03982	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
003994	-000398	-04610	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
003840	-000175	-04793	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
003773	-000167	-04784	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
009373	-01345	-003117	0937	1000	0750	0062	0000	0250	0000	00423	L10	\$
009029												

009719	-00094	000296	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$	009705	-00104	000237	1000	1000	1000	0000	0000	0000	%0486	S10 \$	009701	-00094	000206	1000	1000	1000	0000	0000	0000	0000	%0810	S19 \$	
009342	-00496	-000315	0875	0937	1000	0125	0062	0000	0000	%0163	S02 \$	008923	-000525	-00449	0937	0875	1000	0062	0125	0000	0000	%0487	S11 \$	008956	001138	-00244	1000	0875	0937	0000	0125	0062	0000	%0811	S20 \$
008782	-00898	-01012	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$	007823	000969	-01266	0875	0750	1000	0125	0250	0000	0000	%0488	S12 \$	008120	002295	-00449	1000	0750	0875	0000	0250	0125	0000	%0812	S21 \$
008139	-01314	-01815	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$	006625	-001292	-02137	0812	0625	1000	0187	0375	0000	0000	%0489	S13 \$	007212	003481	-00239	1000	0625	0812	0000	0375	0187	0000	%0813	S22 \$
007518	-01549	-02488	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$	005682	-001542	-02809	0750	0500	1000	0250	0500	0000	0000	%0490	S14 \$	005623	004772	-00059	1000	0500	0750	0000	0500	0250	0000	%0814	S23 \$
006754	-01512	-03190	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$	004916	-001837	-03297	0687	0375	1000	0312	0625	0000	0000	%0491	S15 \$	005409	006267	000117	1000	0375	0687	0000	0625	0312	0000	%0815	S24 \$
005849	-01646	-04033	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$	004255	-001908	-03762	0625	0250	1000	0375	0750	0000	0000	%0492	S16 \$	004848	007877	000617	1000	0250	0625	0000	0750	0375	0000	%0816	S25 \$
005008	-01566	-04672	0125	0562	1000	0875	0507	0000	0000	%0169	S08 \$	003606	-002030	-04514	0562	0125	1000	0507	0875	0000	0000	%0493	S17 \$	004782	006878	001298	1000	0125	0562	0000	0875	0507	0000	%0817	S26 \$
004761	-01253	-04740	0000	0500	1000	1000	0500	0000	0000	%0170	S09 \$	003652	-002100	-04514	0500	1000	0500	1000	0000	0000	0000	%0494	S18 \$	004790	006892	001540	1000	0000	0500	0000	1000	0500	0000	%0818	S27 \$
003403	-00168	001414	1000	0937	0875	0000	0062	0125	0000	%0171	T01 \$	000974	-000840	001486	0937	1000	0875	0062	1000	0125	0000	%0495	T10 \$	005283	-000878	000681	0875	1000	0937	0125	0000	0062	0000	%0819	T19 \$
008725	-00068	000214	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$	008896	-000701	000217	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$	008843	-000666	000210	0875	0875	0875	0125	0125	0125	0000	%0820	T20 \$
008523	-00670	006643	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$	008227	000681	-01056	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$	008137	001412	-00422	0875	0750	0812	0125	0250	0187	0000	%0821	T21 \$
008101	-01124	-01671	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$	006933	001082	-01961	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$	007372	002928	-00786	0875	0625	0750	0125	0375	0250	0000	%0822	T22 \$
007289	-01245	-02589	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$	005700	001526	-02809	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$	006361	004596	-00931	0875	0500	0687	0125	0500	0312	0000	%0823	T23 \$
006417	-01525	-03472	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$	004666	002029	-03412	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$	005390	006340	-00925	0875	0375	0625	0125	0625	0375	0000	%0824	T24 \$
005347	-01457	-04354	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$	004007	002079	-03883	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$	004693	007237	-00432	0875	0250	0562	0125	0750	0437	0000	%0825	T25 \$
004819	-01413	-04744	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$	003699	001920	-04119	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$	004272	006567	000013	0875	0125	0500	0125	0875	0500	0000	%0826	T26 \$
004623	-01001	-04734	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$	003502	000957	-04698	0437	0000	0875	0562	1000	0125	0000	%0503	T18 \$	004125	006080	000942	0875	0000	0437	0125	1000	0562	0000	%0827	T27 \$
004123	-00183	-002446	1000	0875	0750	0000	0125	0250	0000	%0180	T10 \$	009125	-01552	-02542	0875	1000	0750	0125	0000	0250	0000	%0504	T19 \$	008756	-01638	001186	0750	1000	0875	0250	0000	0125	0000	%0828	T28 \$
008441	000028	001252	0875	0812	0750	0125	0187	0250	0000	%0181	U02 \$	009165	-01416	002129	0812	0875	0750	0187	0125	0250	0000	%0505	U11 \$	008835	-01534	001090	0750	0875	0812	0250	0125	0187	0000	%0829	U20 \$
007639	-00054	000156	0750	0750	0750	0250	0250	0250	0000	%0182	U03 \$	007809	-00053	000157	0750	0750	0750	0250	0250	0250	0000	%0506	U12 \$	007705	-00046	000161	0750	0750	0750	0250	0250	0250	0000	%0830	U21 \$
007284	-00967	-00862	0625	0687	0750	0375	0312	0250	0000	%0183	U04 \$	007138	000720	-01404	0687	0625	0750	0312	0375	0250	0000	%0507	U13 \$	006953	001432	-000591	0750	0625	0687	0250	0375	0312	0000	%0831	U22 \$
006753	-00056	-01823	0500	0625	0750	0500	0375	0250	0000	%0184	U05 \$	005907	001414	-02676	0625	0500	0750	0375	0500	0250	0000	%0508	U14 \$	006103	002976	-00915	0750	0500	0625	0250	0500	0375	0000	%0832	U23 \$
005876	-01105	-02837	0375	0562	0750	0625	0437	0250	0000	%0185	U06 \$	004694	001987	-03438	0562	0375	0750	0437	0625	0250	0000	%0509	U15 \$	005083	004882	-01183	0750	0375	0562	0250	0625	0437	0000	%0833	U24 \$
005171	-01375	-03950	0250	0500	0750	0750	0500	0250	0000	%0186	U07 \$	003883	002181	-03955	0500	0250	0750	0500	0750	0250	0000	%0510	U16 \$	004171	006401	-01953	0750	0375	0500	0250	0750	0500	0000	%0834	U25 \$
004722	-01323	-04759	0125	0437	0750	0875	0562	0250	0000	%0187	U08 \$	003577	002028	-04232	0437	0125	0750	0562	0875	0250	0000	%0511	U17 \$	003743	005955	-00460	0750	0125	0437	0250	0875	0562	0000	%0835	U26 \$
004443	-00752	-04743	0000	0375	0750	1000	0625	0250	0000	%0188	U09 \$	003443	000947	-04755	0375	0000	0750	0625	1000	0250	0000	%0512	U18 \$	003576	005289	000625	0750	0000	0375	0250	1000	0625	0000	%0836	U27 \$
008658	000194	003325	1000	0812	0625	0000	0187	0375	0000	%0189	V01 \$	008712	-02028	002859	0812	1000	0625	0187	0000	0375	0000	%0513	V10 \$	008271	-02255	001487	0625	1000	0812	0375	0000	0187	0000	%0837	V19 \$
008161	000211	002514	0875	0750	0625	0125	0250	0375	0000	%0190	V02 \$	008653	-02129	002946	0750	0875	0625	0250	0125	0375	0000	%0514	V11 \$	008187	-02365	001511	0625	0875	0750	0375	0125	0250	0000	%0838	V20 \$
007412	000018	001955	0750	0687	0625	0250	0312	0375	0000	%0191	V03 \$	007957	-01439	001923	0687	0750	0625	0312	0250	0375	0000	%0515	V12 \$	007893	-01658	001109	0625	0750	0687	0375	0250	0312	0000	%0839	V21 \$
006459	-00033	000091	0625	0625	0625	0375	0375	0375	0000	%0192	V04 \$	006651	-00035	000099	0625	0625	0625	0375	0375	0375	0000	%0516	V13 \$	006556	-00024	000100	0625	0625	0625	0375	0375	0375	0000	%0840	V22 \$
006151	-00463	-01901	0500	0625	0625	0500	0437	0375	0000	%0193	V05 \$	006181	000823	-01531	0562	0500	0625	0437	0500	0375	0000	%0517	V14 \$	005789	001460	-00700	0625	0500	0562	0375	0500	0437	0000	%0841	V23 \$
005554	-00901	-02014	0375	0562	0625	0625	0625	0375	0000	%0194	V06 \$	004941	001749	-03110	0500	0375	0625	0500	0625	0375	0000	%0518	V15 \$	004835	003223	-01065	0625	0375	0500	0375	0625	0500	0000	%0842	V24 \$
004909	-01146	-03184	0250	0437	0625	0750	0562	0375	0000	%0195	V07 \$	003894	002301	-03904	0437	0250	0625	0562	0750	0375	0000	%0519	V16 \$	003725	005541	-01111	0625	0500	0437	0375	0750	0562	0000	%0843	V25 \$
004520	-01331	-04409	0125	0375	0625	0875	0625	0375	0000	%0196	V08 \$	003523	002132	-04206	0375	0125	0625	0625	0875	0375	0000	%0520	V17 \$	003303	005153	-00685	0625	0125	0375	0375	0875	0625	0000	%0844	V26 \$
004229	-00739	-04502	0000	0312	0625	1000	0687	0375	0000	%0197	V09 \$	003370	001085	-04764	0312	0000	0625	0687	1000	0375	0000	%0521	V18 \$	003094	004430	000388	0625	0000</							

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009725	-00097	000240	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
009225	-00345	-00403	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008489	-00744	-01262	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
007557	-01014	-02271	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
006758	-01281	-03090	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
005673	-01143	-03948	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$
004861	-01233	-04653	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
004483	-00857	-04761	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$
004367	-00532	-04692	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
009566	-00543	-001820	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
008740	-00070	000231	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
008430	-00273	-00909	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
007695	-01371	-02039	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
006622	-00874	-03026	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
005510	-00943	-03987	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
004692	-00932	-04637	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
004427	-00745	-04754	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
004246	-00358	-04616	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
009345	-00728	-003276	1000	0937	0750	0000	0602	0250	0000	%0261	d01	\$
008627	-00310	-001580	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
007686	-00045	-000143	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$
006177	-00295	-01171	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
007329	-00480	-02473	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
005414	-00660	-03667	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
004617	-00814	-04650	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
004292	-00589	-04766	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
003989	-00424	-04407	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
009159	-00748	-004324	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
008544	-00575	-003173	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
007660	-00314	-001482	0750	0718	0625	0250	0281	0375	0000	%0272	e03	\$
006542	-00033	-000093	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
006010	-00158	-01444	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
005248	-00498	-02738	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$
004479	-00617	-04133	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$
004052	-00513	-04538	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
003698	-00328	-04072	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
008926	-00686	-005545	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
008377	-00493	-004534	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
007559	-00514	-003086	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
006528	-00320	-001568	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
005290	-00016	-000057	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
004957	-00239	-001637	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
004341	-00410	-03113	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
003758	-00520	-04110	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
003354	-00164	-03658	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
008615	-00437	-006562	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
008180	-00479	-006360	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
007330	-00484	-004574	0750	0656	0375	0250	0343	0625	0000	%0290	g03	\$
006437	-00509	-003230	0625	0562	0375	0375	0437	0625	0000	%0291	g04	\$
005350	-00360	-001569	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
003992	-00006	-000023	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
003699	-00358	-01878	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
003388	-00475	-03328	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
002932	-00069	-03152	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
008405	-00236	-007633	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
007889	-00156	-007818	0875	0718	0500	0125	0250	0812	0000	%0298	h02	\$
007065	-00272	-006402	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
006137	-00309	-004778	0625	0531	0250	0375	0750	0500	0000	%0300	h04	\$
005176	-00411	-003253	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
004062	-00290	-001468	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
002841	-000010	-000025	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
002768	-00572	-02112	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
002470	-00341	-02058	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
008161	-000126	-008213	1000	0781	0125	0000	0218	0875	0000	%0306	h10	\$
007723	-000101	-007916	0875	0687	0125	0125	0312	0875	0000	%0307	h11	\$
006830	-00009	-006934	0750	0593	0125	0250	0406	0875	0000	%0308	h12	\$
005809	-00019	-005860	0625	0500	0125	0375	0500	0875	0000	%0309	h13	\$
004753	-00046	-004661	0500	0406	0125	0500	0593	0875	0000	%0310	h14	\$
003945	-00306	-003299	0375	0312	0125	0625	0687	0875	0000	%0311	h05	\$
003014	-00310	-001850	0250	0218	0125	0750	0781	0875	0000	%0312	h10	\$
001855	-00004	-000096	0125	0125	0125	0875	0875	0875	0000	%0313	h07	\$
002118	-00308	-000908	0000	0031	0125	1000	0968	0875	0000	%0314	h09	\$
008087	-00248	-008298	1000	0750	0000	0000	0250	1000	0000	%0315	h11	\$
007514	-00457	-007753	0875	0656	0000	0125	0343	1000	0000	%0316	h12	\$
006583	-00466	-006697	0750	0562	0000	0250	0437	1000	0000	%0317	h03	\$
005511	-00437	-005584	0625	0468	0000	0375	0531	1000	0000	%0318	h04	\$
004413	-00426	-004283	0500	0375	0000	0500	0625	1000	0000	%0319	h05	\$
003494	-00427	-003109	0375	0281	0000	0625	0718	1000	0000	%0320	h06	\$
002593	-00402	-001901	0250	0187	0000	0750	0812	1000	0000	%0321	h07	\$
001949	-00048	-000273	0125	0093	0000	0875	0906	1000	0000	%0322	h08	\$
001745	-00038	-000091	0000	0000	0000	1000	1000	1000	0000	%0323	h09	\$
009720	-00093	-000224	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
008814	-001038	-00382	0875	1000	0031	0125	0000	0000	0000	%0568	b11	\$
007736	-001896	-00982	0937	0750	1000	0602	0250	0000	0000	%0569	b12	\$
006556	-002747	-01618	0967	0625	1000	0993	0375	0000	0000	%0570	b13	\$
005643	-003385	-02119	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
005004	-003749	-02385	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
004464	-004006	-02711	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
004018	-003953	-02892	0781	0250	1000	0281	0875	0000	0000	%0574	b17	\$
003984	-003751	-03119	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
009409	-00886	-001333	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$
008888	-00065	-000217	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$
008278	-001005	-00873	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
007902	-001830	-01603	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
005784	-002644	-02320	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
004910	-003075	-02737	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
004257	-003693	-02992	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$
003902	-003840	-03117	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
003720	-003593	-03395	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
008883	-01713	-002134	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$
009026	-01538	-0001903	0781	0875	0750	0218	0125	0250	0000	%0586	d11	

See original or copy: <http://web.me.com/klaus.richter/GE10/GE10L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE00_22_REM.TXT, Separation olv*, D65, not adapted $
%100 x LAB*
%#1000 x (r g b c m y o)
%nr. pos $
%Z004779 006509 004267 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009354 -01833 009530 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z006144 -05646 004555 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005903 -03908 -01875 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003986 -00320 -04611 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004851 007294 -00738 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001680 000046 000099 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009699 -00103 000215 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W1 7 $
%S
%Z004779 006509 004267 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009354 -01833 009530 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z006144 -05646 004555 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005903 -03908 -01875 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003986 -00320 -04611 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004851 007294 -00738 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001680 000046 000099 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009699 -00103 000215 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W2 7 $
%S
%Z004779 006509 004267 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009354 -01833 009530 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z006144 -05646 004555 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005903 -03908 -01875 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003986 -00320 -04611 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004851 007294 -00738 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001680 000046 000099 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009699 -00103 000215 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W001 7 $
%S
%Z004915 006218 005015 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z007611 -03638 006647 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z006136 -05592 004468 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005381 -02303 -04782 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z004020 -00141 -04700 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004782 007322 000170 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001811 006040 000099 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009693 -00105 000229 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %W251 7 $
%S
%Z006257 003609 006357 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006463 -04947 004788 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z006031 -05699 003779 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004761 -01253 -04740 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003652 001100 -04514 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004798 006892 001540 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001831 000048 000102 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009708 -00097 000217 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %W501 7 $
%S
%Z008087 000248 008298 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006179 -05423 004465 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z006098 -05305 002043 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z004367 -00532 -04692 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003984 003751 -03119 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004746 006564 003109 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001508 000049 000111 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009718 -00096 000232 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %W751 7 $
%S
```

TUB registration: 20091101-GE10/GE10L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/GE10/GE10L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG GE00_22_REM.TXT, Separation olv*, D65, not adapted \$																								
%100 x LAB*					1000 x (r g b c m y θ)					xnr.					pos \$									
%001663	%00027	%000117	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000
%001266	%00030	%000104	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125
%02623	%00010	%000032	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250
%003857	%00006	%000030	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375
%005309	%00025	%000039	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500
%066664	%00035	%000073	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625
%007785	%00050	%000136	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750
%008883	%00068	%000285	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875
%009725	%00100	%000210	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000
%001239	%00041	%000104	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000
%001630	%00029	%000029	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125
%002648	%00010	%000026	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250
%003850	%00003	%000023	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375
%005327	%00022	%000033	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500
%006704	%00039	%000070	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625
%007840	%00050	%000138	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750
%008908	%00070	%000210	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875
%009725	%00106	%000225	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000
%001182	%00040	%000081	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000
%001616	%00037	%000108	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125
%002616	%00011	%000026	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250
%003834	%00002	%000032	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375
%005298	%00021	%000049	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500
%007740	%00048	%000152	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750
%008871	%00069	%000218	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875
%009725	%00102	%000224	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000
%001166	%00036	%000100	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000
%001536	%00034	%000101	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125	%0125
%002582	%00012	%000039	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250	%0250
%003746	%00000	%000041	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375	%0375
%005218	%00017	%000060	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500	%0500
%006579	%00031	%000086	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625	%0625
%007704	%00044	%000149	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750	%0750
%008896	%00068	%000211	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875	%0875
%009722	%00098	%000214	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000
%001737	%00036	%000086	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000
%001384	%00048	%000097	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000
%001892	%00041	%000065	%0133	%0133	%0133	%0133	%0133	%0133	%0133	%0133	%0133	%0133	%0133	%0133	%0133	%0133	%0133	%0133	%0133	%0133	%0133	%0133	%0133	%0133
%002433	%00025	%000018	%0200	%0200	%0200	%0200	%0200	%0200	%0200	%0200	%0200	%0200	%0200	%0200	%0200	%0200	%0200	%0200	%0200	%0200	%0200	%0200	%0200	%0200
%003031	%00013	%000024	%0266	%0266	%0266	%0266	%0266	%0266	%0266	%0266	%0266	%0266	%0266	%0266	%0266	%0266	%0266	%0266	%0266	%0266	%0266	%0266	%0266	%0266
%003698	%00010	%000027	%0333	%0333	%0333	%0333	%0333	%0333	%0333	%0333	%0333	%0333	%0333	%0333	%0333	%0333	%0333	%0333	%0333	%0333	%0333	%0333	%0333	%0333
%004341	%00002	%000038	%0400	%0400	%0400	%0400	%0400	%0400	%0400	%0400	%0400	%0400	%0400	%0400	%0400	%0400	%0400	%0400	%0400	%0400	%0400	%0400	%0400	%0400
%005022	%00007	%000061	%0466	%0466	%0466	%0466	%0466	%0466	%0466	%0466	%0466	%0466	%0466	%0466	%0466	%0466	%0466	%0466	%0466	%0466	%0466	%0466	%0466	%0466
%005678	%00018	%000071	%0533	%0533	%0533	%0533	%0533	%0533	%0533	%0533	%0533	%0533	%0533	%0533	%0533	%0533	%0533	%0533	%0533	%0533	%0533	%0533	%0533	%0533
%006478	%00034	%000104	%0600	%0600	%0600	%0600	%0600	%0600	%0600	%0600	%0600	%0600	%0600	%0600	%0600	%0600	%0600	%0600	%0600	%0600	%0600	%0600	%0600	%0600
%006544	%00037	%000119	%0666	%0666	%0666	%0666	%0666	%0666	%0666	%0666	%0666	%0666	%0666	%0666	%0666	%0666	%0666	%0666	%0666	%0666	%0666	%0666	%0666	%0666
%007672	%00044	%000144	%0733	%0733	%0733	%0733	%0733	%0733	%0733	%0733	%0733	%0733	%0733	%0733	%0733	%0733	%0733	%0733	%0733	%0733	%0733	%0733	%0733	%0733
%008180	%00049	%000180	%0800	%0800	%0800	%0800	%0800	%0800	%0800	%0800	%0800	%0800	%0800	%0800	%0800	%0800	%0800	%0800	%0800	%0800	%0800	%0800	%0800	%0800
%008675	%00058	%000200	%0866	%0866	%0866	%0866	%0866	%0866	%0866	%0866	%0866	%0866	%0866	%0866	%0866	%0866	%0866	%0866	%0866	%0866	%0866	%0866	%0866	%0866
%009194	%00073	%000210	%0933	%0933	%0933	%0933	%0933	%0933	%0933	%0933	%0933	%0933	%0933	%0933	%0933	%0933	%0933	%0933	%0933	%0933	%0933	%0933	%0933	%0933
%009715	%00095	%000199	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000	%1000
%001700	%00046	%000085	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000
%001330	%00046	%000117	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%0000													

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart GE10; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

TUB registration: 20091101-GE10/GE10L0NA.TXT / .PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/GEI10/GEI10L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=

[illegible]

009725	-00001	000007	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
009225	-00258	-00628	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008489	-00670	-01476	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
007587	-00956	-02471	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
006758	-01237	-03279	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
005673	-01119	-04121	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$
004861	-01224	-04814	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
004483	-00854	-04916	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$
004367	-00521	-04846	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
003566	-00449	-001599	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
008740	-00008	000013	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
008430	-00200	-01123	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
007695	-00671	-02242	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
006622	-00833	-03213	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
005510	-00921	-04158	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
004692	-00925	-04795	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
004427	-00742	-04908	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
004246	-00359	-04770	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
009345	-00638	003049	1000	0937	0750	0000	0662	0250	0000	%0261	d01	\$
008627	-00233	-001364	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
007686	000014	-00059	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$
007177	-00244	-01366	0250	0656	0750	0375	0343	0250	0000	%0264	d04	\$
006139	-00444	-02656	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
005414	-00640	-03836	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
004617	-00809	-04807	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
004292	-00589	-04919	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
003989	-00430	-04555	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
009159	-00662	004100	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
008544	-00508	002958	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
007660	-00254	-001280	0750	0718	0625	0250	0281	0375	0000	%0272	e03	\$
006542	000005	-00092	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
006010	-00127	-01522	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
005248	-00482	-02905	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$
004479	-00614	-04289	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$
004052	-00517	-04688	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
003698	-00339	-04216	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
008926	-00604	005325	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
008377	-00420	-04322	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
007559	-00456	002885	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
006528	-00208	-001382	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
005290	000001	-00109	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
004957	-00227	-01778	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
004341	-00409	-03266	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
003758	-00530	-04255	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
003354	-00181	-03797	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
008615	-00360	006346	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
008180	-00410	006150	0750	0750	0375	0125	0250	0625	0000	%0289	g02	\$
007330	-00430	004377	0750	0656	0375	0250	0343	0625	0000	%0290	g03	\$
006437	-00552	-003046	0625	0562	0375	0375	0437	0625	0000	%0291	g04	\$
005350	-00341	-001401	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
003992	-00011	-00125	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
003699	-00369	-02022	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
003388	-00492	-03467	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
002932	-00094	-03284	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
008405	-00163	-007420	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
007889	-00092	-007612	0875	0718	0500	0125	0250	0187	0750	%0298	h02	\$
007065	-00223	-006208	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
006137	-00256	-004508	0625	0531	0250	0375	0500	0750	0000	%0300	h04	\$
005176	-00396	-003087	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
004062	-00295	-001319	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
002841	-00015	-00106	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
002768	-00599	-02242	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
002470	-00373	-02184	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
008161	000194	008003	1000	0781	0125	0000	0218	0875	0000	%0306	i01	\$
007723	-000162	-00713	0875	0687	0125	0125	0312	0875	0000	%0307	i02	\$
006830	000134	006744	0750	0593	0125	0250	0406	0875	0000	%0308	i03	\$
005809	-00097	-005686	0625	0500	0125	0375	0500	0875	0000	%0309	i04	\$
004753	-00038	-004502	0500	0406	0125	0500	0593	0875	0000	%0310	i05	\$
003945	-00312	-003152	0375	0312	0125	0625	0687	0875	0000	%0311	i06	\$
003014	-00333	-001716	0250	0218	0125	0750	0781	0875	0000	%0312	i07	\$
001855	-00002	-000020	0125	0125	0125	0875	0875	0875	0000	%0313	i08	\$
002118	-00346	-00219	0000	0031	0125	1000	0968	0875	0000	%0314	i09	\$
008087	000315	008090	1000	0750	0000	0000	0250	1000	0000	%0315	j01	\$
007514	000514	007553	0875	0656	0000	0125	0343	1000	0000	%0316	j02	\$
006583	000506	006511	0750	0562	0000	0250	0437	1000	0000	%0317	j03	\$
005511	000459	005414	0625	0468	0000	0375	0531	1000	0000	%0318	j04	\$
004413	000428	004128	0500	0375	0000	0500	0625	1000	0000	%0319	j05	\$
003494	000413	002968	0375	0281	0000	0625	0718	1000	0000	%0320	j06	\$
002593	000372	001773	0250	0187	0000	0750	0812	1000	0000	%0321	j07	\$
001949	000006	000155	0125	0093	0000	0875	0906	1000	0000	%0322	j08	\$
006175	-00006	-00023	0000	0000	0000	1000	1000	1000	0000	%0323	j09	\$
009720	000002	-00008	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
008814	001118	-00061	0968	0875	1000	0031	0125	0000	0000	%0568	b11	\$
007736	001957	-01186	0937	0750	1000	0062	0250	0000	0000	%0569	b12	\$
006556	000187	-01804	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$
005643	003409	-02291	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
005004	003762	-02548	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
004464	004009	-02856	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
004018	003951	-03087	0781	0250	1000	0218	0875	0000	0000	%0574	b17	\$
003984	003745	-03267	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
003409	-00795	-001105	0906	1000	0875	0093	0000	0125	0000	%0576	c01	\$
008888	000015	-00002	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$
008278	001076	-01084	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
007902	001878	-01796	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
005784	002670	-02495	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
004910	003086	-02899	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
004257	003692	-03144	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$
003902	003832	-03264	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
003720	003583	-03539	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
008883	-01632	-001914	0812	1000	0750	0187	0000	0250	0000	%0585	d01	\$
009026	-01454	-001681	0781	0875	0750	0218	0125	0250	0000	%0586	d11	\$
007792	000013	-00032	0750	0750	0750	0250	0250	0250	0000	%0587	d12	\$
007259												

See original or copy: <http://web.me.com/klaus.richter/GE10/GE10L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE00_22_REM.TXT, Separation olv*, D65, adapted $
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr.    pos $
%Z004779 006520 004122 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009354 -01736 009319 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z006144 -05609 004390 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005903 -03876 -02035 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003986 -00323 -04744 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004851 007307 -00884 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001680 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009699 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%$
%Z004779 006520 004122 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009354 -01736 009319 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z006144 -05609 004390 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005903 -03876 -02035 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003986 -00323 -04744 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004851 007307 -00884 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001680 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009699 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%$
%Z004779 006520 004122 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009354 -01736 009319 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z006144 -05609 004390 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005903 -03876 -02035 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003986 -00323 -04744 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004851 007307 -00884 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001680 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009699 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%$
%Z004915 006235 004864 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z007611 -03571 006451 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z006136 -05553 004296 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005381 -02278 -04941 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z004020 -00140 -04896 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004782 007336 000021 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001811 006000 000000 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009693 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%$
%Z006257 003643 006190 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006463 -04910 004618 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z006031 -05669 003615 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004761 -01247 -04885 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003652 001085 -04642 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004798 006899 001395 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001831 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009708 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%$
%Z008087 000315 008090 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006179 -05390 004285 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z006098 -05273 001863 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z004367 -00531 -04846 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003984 003745 -03267 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004746 006572 002949 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001508 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009718 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%$
```


See original or copy: <http://web.me.com/klaus.richter/GE10/GE10L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG GE00_22_REM.TXT, Separation of r, D65, adapted S																			
%100 x LAB*a										1000 x (r g b c m y θ)									
										%nr.	pos \$								
001266	-00019	000028	0000	0000	0000	1000	1000	1000	0000	%0972	k01 \$	008618	000021	000020	0866	0866	0866	0133	0133
001633	-00010	000010	0125	0125	0125	0875	0875	0875	0000	%0973	k02 \$	009178	000013	000024	0933	0933	0933	0066	0066
002623	-00013	-00075	0250	0250	0250	0750	0750	0750	0000	%0974	k03 \$	009716	-00007	000023	1000	1000	1000	0000	0000
003287	-00009	-00093	0375	0375	0375	0625	0625	0625	0000	%0975	k04 \$	001490	-00000	000005	0000	0000	0000	1000	1000
005309	-00004	-00184	0500	0500	0500	0500	0500	0500	0000	%0976	k05 \$	001213	000005	000029	0066	0066	0066	0933	0933
006664	-00018	-00088	0625	0625	0625	0375	0375	0375	0000	%0977	k06 \$	001780	000009	-00007	0133	0133	0866	0866	0000
007785	-00012	-00041	0750	0750	0750	0250	0250	0250	0000	%0978	k07 \$	002371	000001	-00050	0200	0200	0200	0800	0800
008883	-00013	000013	0875	0875	0875	0125	0125	0125	0000	%0979	k08 \$	002963	000007	-00048	0266	0266	0266	0733	0733
009725	-00005	000006	1000	1000	1000	0000	0000	0000	0000	%0980	k09 \$	003627	000011	-00051	0333	0333	0333	0666	0666
001239	-00005	000015	0000	0000	0000	1000	1000	1000	0000	%0981	l01 \$	004239	000014	-00048	0400	0400	0400	0600	0600
001630	-00011	000012	0125	0125	0125	0875	0875	0875	0000	%0982	l02 \$	004898	000015	-00030	0466	0466	0466	0533	0533
002648	-00013	-00078	0250	0250	0250	0750	0750	0750	0000	%0983	l03 \$	005563	000014	-00035	0533	0533	0533	0466	0466
003850	-00006	-00100	0375	0375	0375	0625	0625	0625	0000	%0984	l04 \$	006281	000013	-00028	0600	0600	0600	0399	0399
005327	-00001	-00111	0500	0500	0500	0500	0500	0500	0000	%0985	l05 \$	006941	000021	-00032	0666	0666	0666	0333	0333
006704	-00004	-00092	0625	0625	0625	0375	0375	0375	0000	%0986	l06 \$	007511	000018	-00014	0733	0733	0733	0266	0266
007840	-00013	-00040	0750	0750	0750	0250	0250	0250	0000	%0987	l07 \$	008081	000021	000016	0800	0800	0800	0199	0199
008908	-00011	000017	0875	0875	0875	0125	0125	0125	0000	%0988	l08 \$	008634	000016	000032	0866	0866	0866	0133	0133
009725	-00011	000021	1000	1000	1000	0000	0000	0000	0000	%0989	l09 \$	009184	000015	000015	0933	0933	0933	0066	0066
001182	-00007	-00006	0000	0000	0000	1000	1000	1000	0000	%0990	m01 \$	009707	000000	000008	1000	1000	1000	0000	0000
001616	-00003	000014	0125	0125	0125	0875	0875	0875	0000	%0991	m02 \$	001312	000000	000000	0000	0000	0000	1000	1000
002648	-00013	-00078	0250	0250	0250	0750	0750	0750	0000	%0992	m03 \$	009714	000000	000000	1000	1000	1000	0000	0000
003834	-00006	-00091	0375	0375	0375	0625	0625	0625	0000	%0993	m04 \$	004715	000006	004457	1000	0000	0000	1000	1000
005298	-00000	-00094	0500	0500	0500	0500	0500	0500	0000	%0994	m05 \$	005948	-04346	-01490	0000	1000	1000	1000	0000
006650	-00008	-00078	0625	0625	0625	0375	0375	0375	0000	%0995	m06 \$	009341	-01739	009771	1000	1000	0000	0000	1000
007740	-00013	-00024	0750	0750	0750	0250	0250	0250	0000	%0996	m07 \$	003871	-00354	-04717	0000	0000	1000	1000	0000
008871	-00011	000025	0875	0875	0875	0125	0125	0125	0000	%0997	m08 \$	006133	-05857	004707	1000	0000	0000	1000	0000
009725	-00006	000020	1000	1000	1000	0000	0000	0000	0000	%0998	m09 \$	004841	007412	-00968	0000	0000	1000	0000	
001166	-00012	000013	0000	0000	0000	1000	1000	1000	0000	%0999	n01 \$								
001536	-00007	000009	0125	0125	0125	0875	0875	0875	0000	%1000	n02 \$	%004715	006606	004457	%#1000	0000	0000	0000	1000
002582	-00012	-00067	0250	0250	0250	0750	0750	0750	0000	%1001	n03 \$	%009341	-01739	009771	%#1000	1000	0000	0000	0000
003746	-00004	-00081	0375	0375	0375	0625	0625	0625	0000	%1002	n04 \$	%006133	-05857	004707	%#1000	1000	0000	0000	1000
005218	-00002	-00082	0500	0500	0500	0500	0500	0500	0000	%1003	n05 \$	%005948	-04346	-01490	%#1000	1000	1000	0000	0000
006579	-00010	-00074	0625	0625	0625	0375	0375	0375	0000	%1004	n06 \$	%003871	-00354	-04717	%#1000	0000	1000	1000	0000
007704	-00016	-00026	0750	0750	0750	0250	0250	0250	0000	%1005	n07 \$	%004841	007412	-00968	%#1000	0000	1000	0000	1000
008896	-00013	000018	0875	0875	0875	0125	0125	0125	0000	%1006	n08 \$	%001312	000000	000000	%#1000	0000	0000	1000	1000
009722	-00003	000010	1000	1000	1000	0000	0000	0000	0000	%1007	n09 \$	%009714	000000	000000	%#1000	1000	1000	0000	0000
001737	-00002	-00009	0000	0000	0000	1000	1000	1000	0000	%1008	k10 \$								
001384	-00003	000006	0066	0066	0066	0933	0933	0933	0000	%1009	k11 \$	%001266	-00019	000028	%#1000	0000	0000	1000	1000
001892	-00004	-00031	0133	0133	0133	0866	0866	0866	0000	%1010	k12 \$	%009725	-00005	000006	%#1000	1000	1000	0000	0000
002431	-00002	-00086	0200	0200	0200	0800	0800	0800	0000	%1011	k13 \$								
003031	-00003	-00088	0266	0266	0266	0733	0733	0733	0000	%1012	k14 \$	%001239	-00005	000015	%#1000	0000	0000	1000	1000
003698	-00004	-00094	0333	0333	0333	0666	0666	0666	0000	%1013	k15 \$	%009725	-00011	000021	%#1000	1000	1000	0000	0000
004341	-00006	-00092	0400	0400	0400	0600	0600	0600	0000	%1014	k16 \$								
005022	-00008	-00078	0466	0466	0466	0533	0533	0533	0000	%1015	k17 \$	%001182	-00007	-00006	%#1000	0000	0000	1000	1000
005977	-00017	000017	0533	0533	0533	0466	0466	0466	0000	%1016	k18 \$	%009725	-00006	000020	%#1000	1000	1000	0000	0000
006478	-00006	-00055	0600	0600	0600	0399	0399	0399	0000	%1017	k19 \$								
007054	-00012	-00048	0666	0666	0666	0666	0333	0333	0000	%1018	k20 \$	%001166	-00012	000013	%#1000	0000	0000	1000	1000
007629	-00015	-00031	0733	0733	0733	0266	0266	0266	0000	%1019	k21 \$	%009722	-00003	000010	%#1000	1000	1000	0000	0000
008180	-00019	-00062	0800	0800	0800	0800	0199	0199	0000	%1020	k22 \$								
008675	-00018	000010	0866	0866	0866	0133	0133	0133	0000	%1021	k23 \$								
009194	-00013	000013	0933	0933	0933	0066	0066	0066	0000	%1022	k24 \$								
009715	-00000	-00004	1000	1000	1000	0000	0000	0000	0000	%1023	k25 \$								
001700	-00006	-00009	0000	0000	0000	1000	1000	1000	0000	%1024	l10 \$								
001330	-00000	000027	0066	0066	0066	0933	0933	0933	0000	%1025	l11 \$								
001886	-00001	-00021	0133	0133	0133	0866	0866	0866	0000	%1026	l12 \$								
002509	-00002	-00068	0200	0200	0200	0800	0800	0800	0000	%1027	l13 \$								
003079	-00006	-00077	0266	0266	0266	0733	0733	0733	0000	%1028	l14 \$								
003771	-00008	-00082	0333	0333	0333	0666	0666	0666	0000	%1029	l15 \$								
004359	-00008	-00088	0400	0400	0400	0600	0600	0600	0000	%1030	l16 \$								
005030	-00015	-00076	0466	0466	0466	0533	0533	0533	0000	%1031	l17 \$								
005714	-00015	-00082	0533	0533	0533	0466	0466	0466	0000	%1032	l18 \$								
006467	-00015	-00081	0600	0600	0600	0399	0399	0399	0000	%1033	l19 \$								
007024	-00018	-00056	0666	0666	0666	0666	0333	0333	0000	%1034	l20 \$								
007582	-00020	-00036	0733	0733	0733	0266	0266	0266	0000	%1035	l21 \$								
008124	-00022	-00008	0800	0800	0800	0800	0199	0199	0000	%1036	l22 \$								
008622	-00022	000009	0866	0866	0866	0133	0133	0133	0000	%1037	l23 \$								
009173	-00015	000015	0933	0933	0933	0066	0066	0066	0000	%1038	l24 \$								
009718	-00002	-00005	1000	1000	1000	0000	0000	0000	0000	%1039	l25 \$								
%1406	-00004	-00004	0000	0000	0000	1000	1000	1000	0000	%1040	m10 \$								
001207	-00005	000017	0066	0066	0066	0933	0933												

009703	-00076	000230	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009291	-00582	-00249	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008278	-01046	-00777	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
008275	-01454	-01378	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
007735	-01844	-02054	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
007621	-02387	-02789	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006156	-02977	-03796	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
005318	-03382	-04066	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005213	-03192	-05124	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
009209	000477	000862	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
008724	-00034	000287	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
008765	-00953	-00351	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
008281	-01555	-01074	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
007570	-02142	-01743	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
006963	-02604	-02372	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
006121	-03250	-03151	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
005213	-03887	-04383	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
005138	-03172	-05043	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
008772	-00107	-001235	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
008210	000649	000921	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
007638	-00028	-000148	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
007499	-01012	-00453	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
007121	-01653	-01045	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
006442	-02100	-01745	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
005845	-02924	-02541	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
005225	-04169	-03840	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
005137	-03380	-04753	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
008179	001662	002086	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
007762	-001244	-001699	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
007158	-000737	-000674	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
006451	-00022	-000108	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
006458	-00905	-00517	0500	0593	0593	0625	0500	0406	0375	00112	M05	\$
005915	-01734	-01260	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
005458	-02410	-02128	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
004924	-03841	-03502	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
004855	-03382	-04357	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007450	002690	002604	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
007251	-002212	-002304	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
006646	-001421	-001611	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
005943	-000799	-000628	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
005196	-00008	-000060	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
005206	-01032	-00786	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
004857	-01760	-01624	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
004402	-03203	-02852	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
004255	-02885	-03997	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
006551	004068	003684	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
006626	003445	003210	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
006186	-00236	-002267	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
005555	001548	001509	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
004898	000786	000689	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
004033	000000	000033	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
004048	-01179	-00934	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
003866	-02381	-02091	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003617	-02520	-02981	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
005798	005326	004862	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
005787	-000203	-004634	0875	0406	0500	0125	0593	0750	0000	00136	P02	\$
005398	-003008	-003454	0750	0375	0250	0250	0625	0625	0000	00137	P03	\$
004864	-002730	-002493	0625	0343	0250	0625	0625	0750	0000	00138	P04	\$
004334	-001663	-001715	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
003697	-000884	-000743	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
002932	-000014	-000028	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
003149	-01769	-01119	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
002765	-01519	-01972	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
005302	-006208	-005233	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
005072	000586	005285	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
004507	-005428	-004292	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
004004	-004543	-003484	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
003713	-003215	-002527	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
003265	-002092	-001624	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
002712	-001002	-000846	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
002085	-000050	-000084	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
002395	-00990	-00373	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
005112	-006625	-005273	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
004777	-006252	-004997	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
004250	-005766	-004275	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
003763	-004834	-003748	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
003294	-003924	-002640	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
002822	-002761	-001692	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
002595	-002127	-001107	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
002082	-000315	-000192	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
001975	-000046	-000077	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009689	-000069	-000208	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
008973	-000194	-000499	0800	0875	1000	0093	0125	0000	0000	00406	J11	\$
007503	-000104	-01501	0812	0750	1000	0187	0250	0000	0000	00407	J12	\$
006576	-000032	-02642	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
005596	-000001	-03429	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
004719	-00144	-04129	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
004038	-00709	-04831	0347	0250	1000	0562	0750	0000	0000	00411	J16	\$
003022	-0089	-05343	0250	0100	0875	0875	0875	0000	0000	00412	J17	\$
003089	-00912	-04894	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
002582	-00569	-001791	0968	1000	0875	0031	0000	0125	0000	00414	J19	\$
008863	-00042	-000222	0875	0875	0875	0125	0125	0125	0000	00415	K11	\$
008215	-000277	-01167	0781	0750	0875	0218	0250	0125	0000	00416	K12	\$
006934	-000199	-02279	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
005587	-000265	-03323	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
004601	-000124	-04114	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
003883	-00289	-04799	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
003715	-00591	-05013	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
003647	-00602	-05004	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
009384	-00998	-003042	0937	1000	0750	0062	0000	0250	0000	00423	L10	\$
009033	-00904</											

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009720	-00065	000199	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
009326	-00530	-00354	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
008745	-01017	-01092	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
008077	-01546	-01943	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
007436	-01885	-02656	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
006655	-01964	-03388	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
005721	-02287	-04284	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
004845	-02399	-04966	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$
004813	-02074	-05026	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
009418	-00042	001400	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
008726	-00909	000209	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
008498	-00744	-00708	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
008946	-01328	-01785	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
007210	-01579	-02746	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
006309	-02032	-03685	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
005211	-02176	-04616	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
004667	-02251	-05037	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
004479	-01866	-05007	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
009150	-00132	002426	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
008458	-000211	001247	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
007640	-00032	000153	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
007254	-00799	-00925	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
006698	-01177	-01933	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
005793	-01489	-02998	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
005049	-02007	-04186	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
004571	-02166	-05048	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
004304	-01548	-05005	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
008702	000610	003314	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
008196	000546	002511	0875	0750	0625	0125	0250	0375	0000	%0190	V02	\$
007426	000613	001052	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
006459	-00028	000099	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
005122	-00576	-01119	0500	0375	0562	0625	0500	0437	0000	%0193	V05	\$
005494	-01140	-02134	0375	0562	0625	0625	0625	0375	0000	%0194	V06	\$
004895	-01612	-03367	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
004380	-02104	-04677	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
004097	-01492	-04748	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
008272	-001668	-004348	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
007867	-009048	-003463	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
007079	-005085	-002513	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
006242	-000259	-001050	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
005233	-000011	-000052	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
004939	-00782	-01203	0375	0437	0500	0625	0560	0500	0000	%0203	W06	\$
004532	-01255	-02441	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
003954	-01887	-03966	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
003680	-01184	-04223	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
007742	-001793	-005125	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
007492	-001576	-004418	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
006740	-001081	-003355	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
005954	-000763	-002292	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
005118	-000297	-001181	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
004010	-000001	-000023	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
003727	-00849	-01362	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
003643	-01533	-02827	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
003184	-00893	-03521	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
007195	-002664	-006350	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
006863	-002717	-005975	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
006255	-002093	-004631	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
005534	-001378	-003425	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
004724	-000873	-002335	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
003875	-000350	-001093	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
002907	-000012	-000022	0250	0250	0250	0750	0750	0750	0000	%0222	Y07	\$
002788	-00148	-01796	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
002733	-00209	-02534	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
006737	-003518	-006718	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
006299	-003432	-006249	0875	0500	0125	0125	0125	0500	0875	%0226	Z02	\$
005578	-003019	-005337	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
004823	-002483	-004452	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
004208	-001712	-003489	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
003592	-001135	-002324	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
002883	-000319	-001371	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
002034	-000048	-000093	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
002277	-00573	-00283	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$
006393	-004177	-006423	1000	0500	0000	0000	0500	1000	0000	%0234	Z10	\$
005921	-004067	-005903	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
005219	-003706	-005010	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
004335	-003245	-003986	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
003625	-002717	-002945	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
003011	-002303	-002026	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
002488	-001363	-001256	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
002093	-000337	-000197	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$
002038	-000054	-000079	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009706	-00072	-000230	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
008926	-000522	-00432	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
007821	-000910	-01261	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
006612	-001154	-02147	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
005658	-001326	-02832	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
004886	-001554	-03327	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
004212	-001534	-03813	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
003901	-00165	-04191	0562	0250	1000	0437	0500	0000	0000	%0493	S17	\$
003559	-000472	-04650	0500	0250	1000	0500	1000	0000	0000	%0494	S18	\$
009477	-000657	-001440	0937	1000	0875	0062	0000	0125	0000	%0495	T10	\$
008897	-00042	-000212	0875	0875	0125	0125	0125	0000	0000	%0496	T11	\$
008223	-000627	-01058	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
006919	-000955	-01974	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
005676	-001309	-02833	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
004637	-001731	-03437	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
003964	-001682	-03930	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
003642	-001450	-04192	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
003397	-000259	-04868	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
009125	-01252	-02453	0875	1000	0750	0125	0000	0250	0000	%0504	T19	\$
009163	-01157	-02048	0812	0875	0750	0187	0125	0250				

009727	-00064	000232	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$	009722	-00062	000217	1000	1000	1000	0000	0000	0000	%0567	b10	\$	009709	-00064	000225	1000	1000	1000	0000	0000	0000	0000	0000	%0891	b19	\$	
009211	-00380	-00437	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$	008829	001061	-00348	0886	0875	1000	0031	0125	0000	0000	%0568	b11	\$	008983	001091	000049	1000	0875	0906	0000	0125	0093	0000	%0892	b20	\$	
008450	-00882	-01343	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$	007760	001901	-00921	0937	0750	1000	0062	0250	0000	0000	%0569	b12	\$	008272	002079	000119	1000	0750	0812	0000	0250	0187	0000	%0893	b21	\$	
007492	-01290	-02402	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$	006588	002722	-01532	0936	0625	1000	0093	0375	0000	0000	%0570	b13	\$	007431	003249	000465	1000	0625	0718	0000	0375	0281	0000	%0894	b22	\$	
006666	-01701	-03271	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$	005681	003320	-02013	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$	006489	004636	001085	1000	0500	0625	0000	0500	0375	0000	%0895	b23	\$	
005558	-01730	-04168	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$	005046	003658	-02267	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$	005511	006313	001605	1000	0375	0531	0000	0625	0468	0000	%0896	b24	\$	
004717	-02027	-04929	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$	004506	003873	-02590	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$	005013	007060	002253	1000	0250	0437	0000	0750	0562	0000	%0897	b25	\$	
004348	-01261	-05030	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$	004043	003788	-02781	0781	0025	1000	0278	0875	0000	0000	%0574	b17	\$	004985	006973	003095	1000	0125	0343	0000	0875	0556	0000	%0898	b26	\$	
004233	-01204	-04941	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$	004000	003547	-03039	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$	004944	006839	003446	1000	0000	0250	0000	1000	0750	0000	%0899	b27	\$	
009579	-00317	001790	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$	009409	-00719	001283	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$	009271	-00725	000295	0875	1000	0968	0125	0000	0031	0000	%0900	c10	\$	
008742	-00039	000226	0875	0875	0875	0075	0125	0125	0000	%0253	c02	\$	008890	-00035	000212	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$	008867	-00033	000223	0875	0875	0875	0125	0125	0125	0000	%0901	c10	\$	
008407	-00355	-00955	0750	0881	0875	0250	0218	0125	0000	%0254	c03	\$	008284	000984	-00854	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$	008163	001363	-00057	0875	0750	0781	0125	0250	0218	0000	%0902	c21	\$	
007640	-00962	-02147	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$	007912	001775	-01565	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$	007444	002544	000103	0875	0625	0687	0125	0375	0312	0000	%0903	c22	\$	
006541	-01257	-03183	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$	005798	002535	-02264	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$	006518	004165	000388	0875	0500	0593	0125	0500	0406	0000	%0904	c23	\$	
005397	-01527	-04199	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$	004926	002920	-02672	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$	005529	005913	001137	0875	0375	0500	0125	0625	0500	0000	%0905	c24	\$	
004554	-01703	-04896	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$	004282	003511	-02901	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$	004783	006764	001992	0875	0250	0406	0125	0750	0593	0000	%0906	c25	\$	
004287	-01542	-05016	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$	003929	003633	-02901	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$	004368	006136	002290	0875	0125	0312	0125	0875	0687	0000	%0907	c26	\$	
004118	-01095	-04853	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$	003732	003334	-03327	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$	004276	005862	002990	0875	0000	0218	0125	1000	0781	0000	%0908	c27	\$	
009370	-00352	003228	1000	0937	0750	1000	0602	0250	0000	%0261	d01	\$	008874	-01448	002034	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$	008688	-01371	000238	0750	1000	0937	0250	0000	0062	0000	%0909	d19	\$	
008641	-00104	001560	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$	009018	-01299	000181	0781	0875	0750	0218	0125	0250	0000	%0586	d11	\$	008842	-01259	000493	0750	0875	0843	0250	0125	0156	0000	%0910	d20	\$	
007687	-00025	000140	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$	007793	-00024	000167	0750	0750	0750	0250	0250	0250	0000	%0587	d12	\$	007710	-00018	000154	0750	0750	0750	0250	0250	0250	0000	%0911	d21	\$	
007149	-00408	-01225	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$	007259	000995	-01225	0718	0625	0750	0281	0375	0250	0000	%0588	d13	\$	006993	001374	-00141	0750	0625	0656	0250	0375	0343	0000	%0912	d22	\$	
006269	-00758	-02587	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$	005990	002072	-02297	0687	0500	0750	0312	0500	0250	0000	%0589	d14	\$	006190	002710	-00096	0750	0500	0562	0250	0500	0437	0000	%0913	d23	\$	
005317	-01159	-03848	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$	004823	002770	-02870	0656	0375	0750	0343	0625	0250	0000	%0590	d15	\$	005271	004333	000368	0750	0375	0468	0250	0625	0531	0000	%0914	d24	\$	
004481	-01582	-04904	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$	004049	003445	-03148	0625	0250	0750	0375	0750	0250	0000	%0591	d16	\$	004184	005957	001340	0750	0250	0375	0250	0750	0625	0000	%0915	d25	\$	
004154	-01385	-05022	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$	003702	003520	-03321	0593	0125	0750	0406	0875	0250	0000	%0592	d17	\$	003862	005503	001867	0750	0125	0281	0250	0875	0718	0000	%0916	d26	\$	
003865	-01135	-04634	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$	003454	003263	-03556	0562	0000	0750	0437	1000	0250	0000	%0593	d18	\$	003728	005257	002716	0750	0000	0187	0250	1000	0812	0000	%0917	d27	\$	
009194	-00282	004264	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$	008394	-01944	002283	0718	1000	0625	0281	0000	0375	0000	%0594	e10	\$	008249	-01899	000486	0625	1000	0906	0375	0000	0093	0000	%0918	e19	\$	
008570	-00209	003132	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$	008330	-02060	002341	0687	0875	0625	0312	0125	0375	0000	%0595	e11	\$	008253	-01940	000722	0625	0875	0812	0375	0125	0187	0000	%0919	e20	\$	
007673	-00123	001464	0750	0718	0875	0625	0250	0281	0375	0000	%0272	e03	\$	007948	-01362	001716	0656	0750	0625	0343	0250	0375	0000	%0596	e12	\$	007776	-01310	000457	0625	0750	0718	0375	0250	0281	0000	%0920	e21	\$
006542	-00028	000091	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$	006708	-00019	000087	0625	0625	0625	0375	0375	0375	0000	%0597	e13	\$	006576	-00008	000104	0625	0625	0625	0375	0375	0375	0000	%0921	e22	\$	
005978	-00296	-01500	0500	0531	0875	0525	0500	0468	0375	0000	%0274	e05	\$	005982	001159	-01413	0593	0500	0625	0406	0500	0375	0000	%0598	e14	\$	005834	001369	-00139	0625	0500	0531	0375	0500	0468	0000	%0922	e23	\$
005180	-00288	-02867	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$	004846	002474	-02029	0562	0375	0625	0437	0625	0375	0000	%0599	e15	\$	004851	002923	-00103	0625	0375	0437	0375	0625	0562	0000	%0923	e24	\$	
004364	-01249	-04346	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$	003854	003302	-03333	0531	0250	0625	0468	0750	0375	0000	%0600	e16	\$	003777	004064	000699	0625	0250	0343	0375	0750	0656	0000	%0924	e25	\$	
003922	-01262	-04778	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$	003428	003526	-03434	0500	0125	0625	0500	0875	0375	0000	%0601	e17	\$	003376	004742	001											

See original or copy: <http://web.me.com/klaus.richter/GE10/GE10L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE00_22_REM.TXT, Separation olv*, D50, not adapted $
%100 x LAB*
%#1000 x (r g b c m y o)
%nr. pos $
%Z004982 006878 004568 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009401 -01154 009295 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z006083 -05136 004182 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005783 -04195 -02168 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003857 -01073 -04846 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z005029 007342 -00344 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001682 000060 000103 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009700 -00073 000207 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004982 006878 004568 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009401 -01154 009295 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z006083 -05136 004182 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005783 -04195 -02168 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003857 -01073 -04846 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z005029 007342 -00344 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001682 000060 000103 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009700 -00073 000207 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004982 006878 004568 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009401 -01154 009295 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z006083 -05136 004182 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005783 -04195 -02168 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003857 -01073 -04846 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z005029 007342 -00344 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001682 000060 000103 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009700 -00073 000207 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005112 006625 005273 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z007603 -03042 006358 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z006075 -05088 004102 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005213 -03192 -05124 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003890 -00912 -04994 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004974 007445 000576 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001813 006055 000103 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009694 -00073 000222 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z006393 004177 006423 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006416 -04429 004458 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005963 -05235 003418 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004613 -02074 -05026 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003559 000472 -04660 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004993 007127 001915 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001833 000063 000106 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009709 -00067 000209 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z008164 000914 008160 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006121 -04919 004110 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z006018 -05002 001722 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z004233 -01294 -04941 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004008 003547 -03030 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004944 006888 003446 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001511 000065 000115 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009719 -00063 000225 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```


See original or copy: <http://web.me.com/klaus.richter/GE10/GE10L0NA.TXT> / PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

TUB registration: 20091101-GE10/GE10L0NA.TXT /.PS TUB material: code=rha4ta
- application for evaluation and measurement of printer or monitor systems

RBEG G000 22 REM.TXT, Separation olv's D50, not adapted \$									
%100 x LAB*	1000 x (r g b			c m y g)			%nr.	pos \$	
001269 000044 000120	0090	0080	1000	1000	1000	0000	%0072 k01 \$	008620 -00026	000206 0866 0866 0866 0133 0133 0133 0000 %1053 m23 \$
001635 000045 000100	0125	0125	0125	0875	0875	0875 0000	%0073 k02 \$	009180 -00042	000216 0933 0933 0933 0666 0666 0666 0000 %1054 m24 \$
002624 000015 000934	0250	0250	0250	0750	0750	0750 0000	%0074 k03 \$	009717 -00071	000220 1000 1000 1000 0000 0000 0000 0000 %1055 m25 \$
003858 -00001 000031	0375	0375	0375	0625	0625	0625 0000	%0075 k04 \$	001493 000057	000101 0000 0000 0000 1000 1000 1000 0000 %1056 n10 \$
005309 -00019 000038	0500	0500	0500	0500	0500	0500 0000	%0076 k05 \$	001216 000070	000122 0666 0666 0666 0933 0933 0933 0000 %1057 n11 \$
006664 -00025 000071	0625	0625	0625	0375	0375	0375 0000	%0077 k06 \$	000783 000061	000092 0133 0133 0133 0866 0866 0866 0000 %1058 n12 \$
007786 -00031 000133	0750	0750	0750	0250	0250	0250 0000	%0078 k07 \$	002373 000038	000056 0200 0200 0200 0800 0800 0800 0000 %1059 n13 \$
008885 -00040 000201	0875	0875	0875	0125	0125	0125 0000	%0079 k08 \$	002965 000035	000065 0266 0266 0266 0733 0733 0733 0000 %1060 n14 \$
009126 -00051 000203	1000	1000	1000	0000	0000	0000 0000	%0080 k09 \$	003629 000029	000071 0333 0333 0333 0666 0666 0666 0000 %1061 n15 \$
001241 000056 000107	0000	0000	0000	1000	1000	1000 0000	%0081 l01 \$	004240 000023	000082 0400 0400 0400 0600 0600 0600 0000 %1062 n16 \$
001632 000044 000109	0125	0125	0125	0875	0875	0875 0000	%0082 l02 \$	004900 000016	000108 0466 0466 0466 0533 0533 0533 0000 %1063 n17 \$
002648 000015 000031	0250	0250	0250	0750	0750	0750 0000	%0083 l03 \$	005565 000004	000111 0533 0533 0533 0466 0466 0466 0000 %1064 n18 \$
003851 000000 000024	0375	0375	0375	0625	0625	0625 0000	%0084 l04 \$	006282 -00005	000128 0600 0600 0600 0399 0399 0399 0000 %1065 n19 \$
005327 -00018 000032	0500	0500	0500	0500	0500	0500 0000	%0085 l05 \$	006942 -00008	000132 0666 0666 0666 0333 0333 0333 0000 %1066 n20 \$
006704 -00030 000067	0625	0625	0625	0375	0375	0375 0000	%0086 l06 \$	007513 -00017	000156 0733 0733 0733 0266 0266 0266 0000 %1067 n21 \$
007841 -00031 000134	0750	0750	0750	0250	0250	0250 0000	%0087 l07 \$	008083 -00019	000195 0800 0800 0800 0199 0199 0199 0000 %1068 n22 \$
008910 -00041 000206	0875	0875	0875	0125	0125	0125 0000	%0088 l08 \$	008636 -00029	000218 0866 0866 0866 0133 0133 0133 0000 %1069 n23 \$
009726 -00075 000217	1000	1000	1000	0000	0000	0000 0000	%0089 l09 \$	009186 -00041	000207 0933 0933 0933 0666 0666 0666 0000 %1070 n24 \$
001184 000053 000085	0000	0000	0000	1000	1000	1000 0000	%0090 m01 \$	009708 -00066	000205 1000 1000 1000 0000 0000 0000 0000 %1071 n25 \$
001619 000053 000111	0125	0125	0125	0875	0875	0875 0000	%0091 m02 \$	001315 000059	000093 0000 0000 0000 1000 1000 1000 0000 %1072 k26 \$
002648 000015 000031	0250	0250	0250	0750	0750	0750 0000	%0092 m03 \$	009715 -00066	000196 1000 1000 1000 0000 0000 0000 0000 %1073 k27 \$
003835 000002 000033	0375	0375	0375	0625	0625	0625 0000	%0093 m04 \$	004922 000693	004897 1000 0000 0000 1000 1000 1000 0000 %1074 l26 \$
005398 -00014 000048	0500	0500	0500	0500	0500	0500 0000	%0094 m05 \$	005830 -04581	-01639 1000 1000 1000 1000 0000 0000 0000 %1075 l27 \$
006651 -00023 000082									

TUB-test chart GE10; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

application for evaluation and measurement of printer or monitor systems

TUB-test chart GE10; Relative Device Colour System O
 1080 spectral reflexions R → LAB* for D65 and D50
 input: w *setgray*
 output: → *oly* setrgbcolor*

009703	-00002	000007	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009291	-00515	-00466	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008785	-00987	-00986	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
008278	-01403	-01579	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
007735	-01802	-02247	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
007621	-02357	-02971	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006156	-02961	-03965	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
005318	-03308	-05022	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005213	-03102	-05279	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
009209	000543	000647	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
008724	000023	000006	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
008765	-00895	-00559	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
008281	-01505	-01275	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
007570	-02103	-01933	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
006963	-02575	-02553	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
006121	-03235	-03319	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
005213	-03887	-04538	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
005138	-03173	-05197	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
008772	001066	001026	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
008210	000698	000721	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
007638	000011	-00043	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
007499	-00974	-00642	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
007121	-01622	-01228	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
006442	-02080	-01918	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
005845	-02913	-02705	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
005225	-04169	-03995	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
005137	-03381	-04906	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
008179	001711	001886	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
007762	001286	001506	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
007158	000497	000490	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
006451	-00061	-00065	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
006458	-00944	-00691	0500	0593	0593	0500	0406	0375	0000	00112	M05	\$
005915	-01723	-01426	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
005458	-02406	-02287	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
004924	-03846	-03652	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
004855	-03387	-04506	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007450	002727	002416	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
007251	002266	002118	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
006646	001445	001435	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
005943	000803	000462	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
005196	-00008	-00094	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
005206	-01032	-00941	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
004857	-01766	-01773	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
004402	-03216	-02994	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
004655	-02901	-04138	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
005251	000409	000350	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
006626	003469	003034	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
006186	002342	002097	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
005555	001554	001430	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
004898	000781	000539	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
004033	-00019	-00103	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
004048	-01198	-01071	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
003866	-02403	-02135	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003617	-02546	-03112	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
005798	005336	004698	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
005787	005213	004470	0875	0406	0500	0125	0593	0750	0000	00136	P02	\$
005398	002742	003297	0750	0375	0250	0250	0625	0750	0000	00137	P03	\$
005464	002243	002343	0625	0343	0250	0375	0625	0750	0000	00138	P04	\$
004334	001649	001574	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
003697	000860	000611	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
002932	-00021	-00091	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
003149	-01803	-01243	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
002765	-01559	-02089	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
005302	006289	005077	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
005072	006504	005133	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
004507	005416	004148	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
004054	004524	003348	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
003713	003190	002395	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
003265	002060	001499	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
002712	000062	000729	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
002085	000001	-00023	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
002395	-01036	-00485	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
005112	006624	005120	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
004777	006245	004849	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
004250	005750	004135	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
003763	004810	003345	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
003294	003893	002515	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
002822	002722	001574	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
002595	002084	000992	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
002082	000264	000084	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
001975	-00055	-00028	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009689	000004	-00013	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
008973	000256	-00711	0800	0875	1000	0093	0125	0000	0000	00406	J11	\$
007903	000148	-01696	0812	0750	1000	0818	0250	0000	0000	00407	J12	\$
006576	000055	-02817	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
005596	000007	-03589	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
004719	-00152	-04276	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
004038	-00728	-04968	0437	0250	1000	0562	0750	0000	0000	00411	J16	\$
003902	-00122	-05142	0343	0250	1000	0875	0875	0000	0000	00412	J17	\$
003899	-00932	-05123	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
009852	-00497	-001570	0968	1000	0875	0031	0000	0125	0000	00414	K01	\$
008683	000017	000012	0875	0875	0875	0125	0125	0125	0000	00415	K11	\$
008215	000326	-01367	0781	0750	0875	0218	0250	0125	0000	00416	K12	\$
006934	000228	-02460	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
005587	000272	-03484	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
004691	000114	-04260	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
003883	-00311	-04934	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
003715	-00615	-05145	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
003647	-00627	-05135	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
009384	-00929	-002824	0937	1000	0750	0062	0000	0250	0000	00423	L10	\$
009033	-00841	-001932	0843	0875	0750	0156	0125	0250	0000	00424	L11	\$
007783	000014</											

009727	000000	000007	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$	009722	000001	-00008	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$	009709	000000	000000	1000	1000	1000	0000	0000	0000	0000	0000	%0891	b19	\$
009821	-00325	-00656	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$	008829	001111	-00562	0968	0875	1000	0031	0125	0000	0000	0000	%0568	b11	\$	008983	001144	-00166	1000	0875	0906	0000	0125	0093	0000	%0892	b20	\$
008450	-00839	-01551	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$	007660	001934	-01120	0937	0750	1000	0062	0250	0000	0000	0000	%0569	b12	\$	008272	002120	-00086	1000	0750	0812	0000	0250	0187	0000	%0893	b21	\$
007492	-01262	-02597	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$	006758	002736	-01716	0906	0625	1000	0093	0375	0000	0000	0000	%0570	b13	\$	007431	003277	-00086	1000	0625	0718	0000	0375	0281	0000	%0894	b22	\$
006666	-01685	-03455	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$	005681	003320	-02184	0875	0500	1000	0125	0500	0000	0000	0000	%0571	b14	\$	006489	004649	-00902	1000	0500	0625	0000	0500	0375	0000	%0895	b23	\$
005558	-01732	-04338	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$	005046	003648	-02430	0843	0375	1000	0156	0625	0000	0000	0000	%0572	b15	\$	005511	006311	001436	1000	0375	0531	0000	0625	0468	0000	%0896	b24	\$
004717	-02042	-05087	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$	004506	003854	-02748	0812	0250	1000	0187	0750	0000	0000	0000	%0573	b16	\$	005013	007049	002091	1000	0250	0437	0000	0750	0562	0000	%0897	b25	\$
004348	-01502	-05104	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$	004063	003766	-02933	0781	0250	1000	0293	0875	0000	0000	0000	%0574	b17	\$	004985	006962	002933	1000	0125	0343	0000	0875	0556	0000	%0898	b26	\$
004233	-01317	-05093	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$	004008	003521	-03179	0750	0000	1000	0250	1000	0000	0000	0000	%0575	b18	\$	004944	006876	002344	1000	0000	0250	1000	0750	0556	0000	%0899	b27	\$
009579	-00255	001575	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$	009409	-00659	001062	0966	1000	0875	0093	0000	0125	0000	%0576	c10	\$	009271	-00669	000076	0875	1000	0968	0125	0000	0031	0000	%0900	c19	\$	
008742	000009	000014	0875	0875	0875	0000	0125	0125	0000	%0253	c02	\$	008890	000015	-00001	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$	008867	000017	000009	0875	0875	0875	0125	0125	0125	0000	%0901	c20	\$	
008407	-00311	-01162	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$	008284	001025	-01060	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$	008163	001402	-00261	0875	0750	0781	0125	0250	0218	0000	%0902	c21	\$	
007460	-09331	-02344	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$	007912	001796	-01754	0812	0625	0875	0817	0375	0125	0000	%0579	c13	\$	007444	002572	-00091	0875	0625	0687	0125	0375	0312	0000	%0903	c22	\$	
006541	-01243	-03366	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$	005798	002537	-02437	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$	006518	004178	002095	0875	0500	0593	0125	0500	0406	0000	%0904	c23	\$	
005397	-01531	-04367	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$	004926	002908	-02823	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$	005529	005911	000967	0875	0375	0500	0125	0625	0500	0000	%0905	c24	\$	
004554	-01720	-05053	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$	004282	003489	-03054	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$	004783	006750	001833	0875	0250	0406	0125	0750	0593	0000	%0906	c25	\$	
004287	-01564	-05169	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$	003929	003605	-03169	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$	004368	006115	002137	0875	0125	0312	0125	0875	0687	0000	%0907	c26	\$	
004118	-01120	-05003	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$	003732	003304	-03473	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$	004276	005840	002838	0875	0000	0218	0125	1000	0781	0000	%0908	c27	\$	
009370	-00293	003008	1000	0937	0750	0000	0602	0250	0000	%0261	d01	\$	008874	-01397	001820	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$	008688	-01323	000026	0750	1000	0937	0250	0000	0062	0000	%0909	d19	\$	
006841	-00057	001349	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$	009018	-01246	001597	0781	0875	0750	0218	0125	0250	0000	%0586	d11	\$	008842	-01209	000279	0750	0875	0843	0250	0125	0156	0000	%0910	d20	\$	
007687	000006	-00057	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$	007793	000008	-00031	0750	0750	0750	0250	0250	0250	0000	%0587	d12	\$	007710	000013	-00043	0750	0750	0750	0250	0250	0250	0000	%0911	d21	\$	
007149	-00384	-01416	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$	007259	001020	-01417	0718	0625	0750	0281	0375	0250	0000	%0588	d13	\$	006993	001395	-00330	0750	0625	0656	0250	0375	0343	0000	%0912	d22	\$	
006269	-00749	-02766	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$	005990	002077	-02473	0687	0500	0750	0312	0500	0250	0000	%0589	d14	\$	006190	002718	-00275	0750	0500	0562	0250	0500	0437	0000	%0913	d23	\$	
005317	-01164	-04014	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$	004823	002757	-03030	0656	0375	0750	0343	0625	0250	0000	%0590	d15	\$	005271	004326	002020	0750	0375	0468	0250	0625	0531	0000	%0914	d24	\$	
004481	-01601	-05060	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$	004049	003420	-03297	0625	0250	0750	0375	0750	0250	0000	%0591	d16	\$	004184	005933	001189	0750	0250	0375	0250	0750	0625	0000	%0915	d25	\$	
004154	-01408	-05173	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$	003702	003489	-03466	0593	0125	0750	0406	0875	0250	0000	%0592	d17	\$	003862	005474	001720	0750	0125	0281	0250	0875	0718	0000	%0916	d26	\$	
003865	-01163	-04781	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$	003454	003228	-03697	0562	0000	0750	0437	1000	0250	0000	%0593	d18	\$	003728	005227	002571	0750	0000	0187	0250	1000	0812	0000	%0917	d27	\$	
009194	-00227	004046	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$	008394	-01901	002976	0718	1000	0625	0281	0000	0375	0000	%0594	e10	\$	008249	-01858	000280	0625	1000	0906	0375	0000	0093	0000	%0918	e19	\$	
008570	-00163	002922	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$	008330	-02018	002134	0687	0875	0625	0312	0125	0375	0000	%0595	e11	\$	008253	-01899	000517	0625	0875	0812	0375	0125	0187	0000	%0919	e20	\$	
007673	-00091	001266	0750	0718	0875	0625	0250	0281	0375	0000	%0272	e03	\$	007948	-01326	001515	0656	0750	0625	0343	0250	0375	0000	%0596	e12	\$	007776	-01277	000258	0625	0750	0718	0375	0250	0281	0000	%0920	e21	\$
006542	-00007	-00091	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$	006708	-00002	-00007	0625	0625	0625	0375	0375	0375	0000	%0597	e13	\$	006576	-00006	-00079	0625	0625	0625	0375	0375	0375	0000	%0921	e22	\$	
005978	-00291	-01676	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$	006082	001166	-01590	0593	0500	0625	0406	0500	0375	0000	%0598	e14	\$	005834	001372	-00313	0625	0500	0531	0375	0600	0468	0000	%0922	e23	\$	
005180	-00036	-03021	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$	004846	002461	-03089	0562	0375	0625	0437	0625	0375	0000	%0599	e15	\$	004951	002910	-00164	0625	0375	0437	0375	0625	0562	0000	%0923	e24	\$	
004364	-01270	-04500	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$	003854	003273	-03480	0531	0250	0625	0468	0750	0375	0000	%0600	e16	\$	003777	004664	000553	0625	0250	0343	0375	0750	0656	0000	%0924	e25	\$	
003922	-01290	-04926	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$	003428	003490	-03576	0500	0125	0625	0500	0875																			

See original or copy: <http://web.me.com/klaus.richter/GE10/GE10L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE00_22_REM.TXT, Separation olv*, D50, adapted $
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr. pos $
%Z004982 006872 004421 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009401 -01086 009091 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z006083 -05123 004021 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005783 -04187 -02326 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003857 -01097 -04978 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z005029 007337 -00491 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001682 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009700 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004982 006872 004421 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009401 -01086 009091 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z006083 -05123 004021 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005783 -04187 -02326 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003857 -01097 -04978 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z005029 007337 -00491 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001682 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009700 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004982 006872 004421 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009401 -01086 009091 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z006083 -05123 004021 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005783 -04187 -02326 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003857 -01097 -04978 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z005029 007337 -00491 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001682 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009700 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005112 006624 005120 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z007603 -03003 006167 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z006075 -05074 003934 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005213 -03192 -05279 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003890 -00933 -05128 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004974 007441 000425 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001813 006000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009694 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z006393 004190 006257 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006416 -04416 004292 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005963 -05230 003257 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004613 -02090 -05169 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003559 000438 -04789 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004993 007117 001767 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001833 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009709 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z008164 000954 007956 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006121 -04912 003933 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z006018 -04996 001546 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z004233 -01317 -05093 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004008 003521 -03179 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004944 006876 003284 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001511 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009719 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```


See original or copy: <http://web.me.com/klaus.richter/GE10/GE10L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG GE00_22_REM.TXT, Separation of r, D50, adapted S																							
%100 x LAB*a				1000 x (r g b c m y θ)				%nrr.		pos \$													
001269	-00015	000027	00000	0000	0000	1000	1000	1000	0000	%0972	k01 \$	0008620	000023	000022	0066	0066	0066	0133	0133	0133	0000	%1053	m23 \$
001635	-00008	000010	0125	0125	0125	0875	0875	0875	0000	%0973	k02 \$	0009180	000016	000026	0033	0933	0933	0066	0066	0066	0000	%1054	m24 \$
002624	-00024	-00075	0250	0250	0250	0750	0750	0750	0000	%0974	k03 \$	0009717	-00005	000023	1000	1000	1000	0000	0000	0000	0000	%1055	m25 \$
003858	-00023	-00093	0375	0375	0375	0625	0625	0625	0000	%0975	k04 \$	001493	000000	000006	0000	0000	0000	1000	1000	1000	0000	%1056	n10 \$
005309	-00019	-00184	0500	0500	0500	0500	0500	0500	0000	%0976	k05 \$	0012116	000009	000030	0066	0066	0066	0933	0933	0933	0000	%1057	n11 \$
006664	-00004	-00087	0625	0625	0625	0375	0375	0375	0000	%0977	k06 \$	001783	000008	-00006	0133	0133	0133	0866	0866	0866	0000	%1058	n12 \$
007786	000005	-00039	0750	0750	0750	0250	0250	0250	0000	%0978	k07 \$	002373	-00005	-00050	0200	0200	0200	0800	0800	0800	0000	%1059	n13 \$
008885	000014	000014	0875	0875	0875	0125	0125	0125	0000	%0979	k08 \$	002965	000000	-00047	0266	0266	0266	0733	0733	0733	0000	%1060	n14 \$
009726	-00004	000006	1000	1000	1000	0000	0000	0000	0000	%0980	000 \$	003629	000004	-00049	0333	0333	0333	0666	0666	0666	0000	%1061	n15 \$
001241	-00003	000015	0000	0000	0000	1000	1000	1000	0000	%0981	l01 \$	004240	000008	-00046	0400	0400	0400	0600	0600	0600	0000	%1062	n16 \$
001632	-00010	000012	0125	0125	0125	0875	0875	0875	0000	%0982	l02 \$	004900	000010	-00028	0466	0466	0466	0533	0533	0533	0000	%1063	n17 \$
002648	-00024	-00078	0250	0250	0250	0750	0750	0750	0000	%0983	l03 \$	005565	000008	-00034	0533	0533	0533	0466	0466	0466	0000	%1064	n18 \$
003851	-00021	-00100	0375	0375	0375	0625	0625	0625	0000	%0984	l04 \$	006282	000009	-00026	0600	0600	0600	0399	0399	0399	0000	%1065	n19 \$
005327	-00017	-00110	0500	0500	0500	0500	0500	0500	0000	%0985	l05 \$	006942	000016	-00030	0666	0666	0666	0333	0333	0333	0000	%1066	n20 \$
006704	-00008	-00091	0625	0625	0625	0375	0375	0375	0000	%0986	l06 \$	007513	000016	-00012	0733	0733	0733	0266	0266	0266	0000	%1067	n21 \$
007841	-00007	-00038	0750	0750	0750	0250	0250	0250	0000	%0987	l07 \$	008083	000022	000018	0800	0800	0800	0199	0199	0199	0000	%1068	n22 \$
008910	000012	000019	0875	0875	0875	0125	0125	0125	0000	%0988	l08 \$	008636	000020	000034	0866	0866	0866	0133	0133	0133	0000	%1069	n23 \$
009726	-00009	000020	1000	1000	1000	0000	0000	0000	0000	%0989	l09 \$	009186	000017	000016	0933	0933	0933	0066	0066	0066	0000	%1070	n24 \$
001164	-00008	-00006	0000	0000	0000	1000	1000	1000	0000	%0990	m01 \$	009708	000000	000008	1000	1000	1000	0000	0000	0000	0000	%1071	n25 \$
001619	-00001	000014	0125	0125	0125	0875	0875	0875	0000	%0991	m02 \$	001315	000000	000000	0000	0000	0000	1000	1000	1000	0000	%1072	k26 \$
002648	-00024	-00078	0250	0250	0250	0750	0750	0750	0000	%0992	m03 \$	009715	000000	000000	1000	1000	1000	0000	0000	0000	0000	%1073	k27 \$
003835	-00019	-00008	0375	0375	0375	0625	0625	0625	0000	%0993	m04 \$	004922	006957	004759	1000	0000	0000	0000	1000	1000	0000	%1074	l26 \$
005298	-00014	-00093	0500	0500	0500	0500	0500	0500	0000	%0994	m05 \$	005830	-04573	-01788	0000	1000	1000	1000	0000	0000	0000	%1075	l27 \$
006651	-00003	-00076	0625	0625	0625	0375	0375	0375	0000	%0995	m06 \$	009390	-01078	009513	1000	1000	0000	0000	0000	1000	0000	%1076	m26 \$
007741	000009	-00022	0750	0750	0750	0250	0250	0250	0000	%0996	m07 \$	003741	-01140	-04950	0000	0000	1000	1000	1000	0000	0000	%1077	m27 \$
008872	000013	000026	0875	0875	0875	0125	0125	0125	0000	%0997	m08 \$	006071	-05355	004314	1000	1000	0000	0000	0000	1000	0000	%1078	n26 \$
009727	-00004	000020	1000	1000	1000	0000	0000	0000	0000	%0998	m09 \$	005021	007431	-00570	1000	0000	1000	0000	1000	0000	0000	%1079	n27 \$
001168	-00010	000012	0000	0000	0000	1000	1000	1000	0000	%0999	n01 \$	%\$											
001538	-00006	000009	0125	0125	0125	0875	0875	0875	0000	%1000	n02 \$	%004922	006957	004759	##1000	0000	0000	0000	1000	1000	0000	%1074	l26 \$
002583	-00021	-00067	0250	0250	0250	0750	0750	0750	0000	%1001	n03 \$	%009390	-01078	009513	##1000	1000	0000	0000	0000	1000	0000	%1076	m26 \$
003747	-00016	-00081	0375	0375	0375	0625	0625	0625	0000	%1002	n04 \$	%006071	-05355	004314	##1000	1000	0000	0000	1000	1000	0000	%1078	n28 \$
005219	-00009	-00081	0500	0500	0500	0500	0500	0500	0000	%1003	n05 \$	%005830	-04573	-01788	##1000	1000	1000	1000	0000	0000	0000	%1075	l26 \$
006580	000000	-00072	0625	0625	0625	0375	0375	0375	0000	%1004	n06 \$	%003741	-01140	-04950	##1000	0000	1000	1000	1000	1000	0000	%1077	m27 \$
007705	000012	-00025	0750	0750	0750	0250	0250	0250	0000	%1005	n07 \$	%005021	007431	-00570	##1000	0000	1000	0000	1000	0000	0000	%1079	n29 \$
008898	000015	000019	0875	0875	0875	0125	0125	0125	0000	%1006	n08 \$	%001315	000000	000000	##1000	0000	0000	1000	1000	1000	0000	%1072	k28 \$
009723	-00002	000010	1000	1000	1000	0000	0000	0000	0000	%1007	n09 \$	%009715	000000	000000	##1000	1000	1000	0000	0000	0000	0000	%1073	k29 \$
001739	-00004	-00008	0000	0000	0000	1000	1000	1000	0000	%1008	k10 \$	%\$											
001386	000004	000007	0066	0066	0066	0933	0933	0933	0000	%1009	k11 \$	%001269	-00015	000027	##0000	0000	0000	1000	1000	1000	0000	%0972	k01 \$
001894	000000	-00031	0133	0133	0133	0866	0866	0866	0000	%1010	k12 \$	%009726	-00004	000006	##1000	1000	1000	0000	0000	0000	0000	%0989	l25 \$
002434	-00014	-00086	0200	0200	0200	0800	0800	0800	0000	%1011	k13 \$	%\$											
003031	-00015	-00087	0266	0266	0266	0733	0733	0733	0000	%1012	k14 \$	%001241	-00003	000015	##0000	0000	0000	1000	1000	1000	0000	%0981	l24 \$
003699	-00008	-00093	0333	0333	0333	0666	0666	0666	0000	%1013	k15 \$	%009726	-00009	000020	##1000	1000	1000	0000	0000	0000	0000	%0989	l25 \$
004342	-00006	-00090	0400	0400	0400	0600	0600	0600	0000	%1014	k16 \$	%\$											
005023	-00002	-00077	0466	0466	0466	0533	0533	0533	0000	%1015	k17 \$	%001184	-00008	-00006	##0000	0000	0000	1000	1000	1000	0000	%0990	m28 \$
005679	-00002	-00076	0533	0533	0533	0466	0466	0466	0000	%1016	k18 \$	%009727	-00004	000020	##1000	1000	1000	0000	0000	0000	0000	%0998	m29 \$
006479	000001	-00050	0600	0600	0600	0399	0399	0399	0000	%1017	k19 \$	%\$											
007073	-00004	000006	0666	0666	0666	0333	0333	0333	0000	%1018	k20 \$	%001168	-00010	000012	##0000	0000	0000	1000	1000	1000	0000	%0999	n30 \$
007531	000010	-00029	0733	0733	0733	0266	0266	0266	0000	%1019	k21 \$	%009723	-00002	000010	##1000	1000	1000	0000	0000	0000	0000	%1007	n31 \$
008181	000018	000000	0800	0800	0800	0199	0199	0199	0000	%1020	k22 \$	%\$											
008677	000019	000012	0866	0866	0866	0133	0133	0133	0000	%1021	k23 \$												
009195	000014	000014	0933	0933	0933	0066	0066	0066	0000	%1022	k24 \$												
009716	000000	-00004	1000	1000	1000	0000	0000	0000	0000	%1023	k25 \$												
001703	000004	-00008	0000	0000	0000	1000	1000	1000	0000	%1024	l10 \$												
001333	000028	00066	0066	0066	0066	0933	0933	0933	0000	%1025	l11 \$												
001888	000000	-00020	0133	0133	0133	0866	0866	0866	0000	%1026	l12 \$												
002510	-00012	-00068	0200	0200	0200	0800	0800	0800	0000	%1027	l13 \$												
003080	-00004	-00076	0266	0266	0266	0733	0733	0733	0000	%1028	l14 \$												
003772	-00003	-00081	0333	0333	0333	0666	0666	0666	0000	%1029	l15 \$												