

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-GE13/GE13LONA.TXT/.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

TUB-test chart GE13; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

input: w *setgray*
output: no change compared to input

See original or copy: <http://web.me.com/klaus.richter/GEI13/GEI13L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

#BEG	GEO3	2D	REM.TXT,	Separation	cmylnA*	D65,	not	adopted	\$																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																														
------	------	----	----------	------------	---------	------	-----	---------	----	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009724	-00094	000192	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$
009864	-00510	-00737	0875	0937	1000	0125	0062	0000	0000	%0163	S02 \$
008509	-00841	-01295	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$
007586	-00990	-02251	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$
006806	-00952	-02913	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$
006073	-00986	-03560	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$
005404	-01156	-04177	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$
004943	-01319	-04613	0125	0562	1000	0875	0312	0000	0000	%0169	S08 \$
004440	-01361	-04840	0000	0500	1000	1000	0500	0000	0000	%0170	S09 \$
003408	-00234	-001502	1000	0937	0875	0000	0062	0125	0000	%0171	T01 \$
008750	-00667	000210	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$
008137	-00325	-00901	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$
007607	-00454	-01466	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$
006882	-00620	-02206	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$
006335	-00842	-02723	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$
005709	-00988	-03249	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$
005198	-01085	-03737	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$
004757	-01202	-04323	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$
009138	-00274	-002619	1000	0875	0750	0000	0125	0250	0000	%0180	U01 \$
008453	000022	001159	0875	0812	0750	0125	0187	0250	0000	%0181	U02 \$
007767	-00051	-000055	0750	0750	0750	0250	0250	0250	0000	%0182	U03 \$
007244	-00272	-010902	0625	0687	0750	0375	0312	0250	0000	%0183	U04 \$
006852	-00390	-01304	0500	0625	0750	0500	0375	0250	0000	%0184	U05 \$
006294	-00523	-01891	0375	0562	0750	0625	0437	0250	0000	%0185	U06 \$
005681	-00718	-02544	0250	0500	0750	0750	0500	0250	0000	%0186	U07 \$
005249	-00805	-02855	0125	0437	0750	0875	0562	0250	0000	%0187	U08 \$
004897	-00896	-03170	0000	0375	0750	1000	0625	0250	0000	%0188	U09 \$
008663	000224	003140	1000	0812	0625	0000	0187	0375	0000	%0189	V01 \$
008227	000045	002229	0875	0750	0625	0125	0250	0375	0000	%0190	V02 \$
007679	-00028	-000891	0750	0687	0625	0250	0312	0375	0000	%0191	V03 \$
006849	-00040	-000102	0625	0625	0625	0375	0375	0375	0000	%0192	V04 \$
006514	-00275	-00910	0500	0375	0562	0500	0437	0375	0000	%0193	V05 \$
006107	-00391	-01428	0375	0562	0625	0625	0500	0375	0000	%0194	V06 \$
005473	-00516	-02022	0250	0437	0625	0750	0562	0375	0000	%0195	V07 \$
005154	-00613	-02309	0125	0375	0625	0875	0625	0375	0000	%0196	V08 \$
004798	-00714	-02664	0000	0312	0625	1000	0687	0375	0000	%0197	V09 \$
008393	000344	004060	1000	0750	0500	0000	0250	0500	0000	%0198	W01 \$
007952	000227	002860	0875	0687	0500	0125	0312	0500	0000	%0199	W02 \$
007456	000078	001785	0750	0625	0500	0250	0375	0500	0000	%0200	W03 \$
006747	-00068	-000538	0625	0562	0500	0375	0437	0500	0000	%0201	W04 \$
005953	-00203	-000064	0500	0500	0500	0500	0500	0500	0000	%0202	W05 \$
005759	-00629	-00900	0375	0437	0500	0625	0560	0500	0000	%0203	W06 \$
005199	-00371	-01462	0250	0375	0500	0750	0625	0500	0000	%0204	W07 \$
004805	-00557	-01897	0125	0312	0500	0875	0687	0500	0000	%0205	W08 \$
004580	-00517	-02201	0000	0250	0500	1000	0750	0500	0000	%0206	W09 \$
008070	000670	004694	1000	0687	0375	0000	0312	0625	0000	%0207	X01 \$
007695	000307	003477	0875	0625	0375	0125	0375	0625	0000	%0208	X02 \$
007204	000203	002431	0750	0562	0375	0250	0437	0625	0000	%0209	X03 \$
006535	000043	001440	0625	0500	0375	0375	0500	0625	0000	%0210	X04 \$
005792	000000	000417	0500	0437	0375	0500	0562	0625	0000	%0211	X05 \$
004862	-00012	-000022	0375	0375	0375	0625	0625	0625	0000	%0212	X06 \$
004770	-00264	-00847	0250	0312	0375	0750	0687	0625	0000	%0213	X07 \$
004257	-00300	-01389	0125	0250	0375	0875	0750	0625	0000	%0214	X08 \$
004060	-00535	-01690	0000	0187	0375	1000	0812	0625	0000	%0215	X09 \$
007704	001094	005547	1000	0625	0250	0000	0375	0750	0000	%0216	Y01 \$
007341	000597	004001	0875	0562	0250	0125	0437	0750	0000	%0217	Y02 \$
006923	000252	003115	0750	0500	0250	0250	0500	0750	0000	%0218	Y03 \$
006360	000115	002107	0625	0437	0250	0375	0500	0750	0000	%0219	Y04 \$
005601	-00078	-001184	0500	0375	0250	0500	0625	0750	0000	%0220	Y05 \$
004763	000026	000341	0375	0312	0250	0625	0687	0750	0000	%0221	Y06 \$
003833	-00006	-000012	0250	0250	0250	0750	0750	0750	0000	%0222	Y07 \$
003796	-00003	-00732	0125	0187	0250	0875	0812	0750	0000	%0223	Y08 \$
003570	-00143	-01166	0000	0125	0250	1000	0875	0750	0000	%0224	Y09 \$
007346	001572	006673	1000	0562	0125	0000	0437	0875	0000	%0225	Z01 \$
007076	000875	004554	0875	0500	0125	0125	0500	0875	0000	%0226	Z02 \$
006608	000484	003603	0750	0437	0125	0250	0562	0875	0000	%0227	Z03 \$
006073	000333	002668	0625	0375	0125	0375	0625	0875	0000	%0228	Z04 \$
005413	000071	001743	0500	0312	0125	0500	0687	0875	0000	%0229	Z05 \$
004593	000015	000823	0375	0250	0125	0625	0750	0875	0000	%0230	Z06 \$
003805	000061	000242	0250	0187	0125	0750	0812	0875	0000	%0231	Z07 \$
002224	000025	000053	0125	0125	0125	0875	0875	0875	0000	%0232	Z08 \$
002734	000033	-00452	0000	0062	0125	1000	0937	0875	0000	%0233	Z09 \$
007056	002063	007215	1000	0500	0000	0000	0500	1000	0000	%0234	A01 \$
006737	001471	006329	0875	0437	0000	0125	0562	1000	0000	%0235	A02 \$
006314	000781	004294	0750	0375	0000	0250	0625	1000	0000	%0236	A03 \$
005802	004058	003227	0625	0312	0000	0375	0687	1000	0000	%0237	A04 \$
005191	000168	002306	0500	0250	0000	0500	0750	1000	0000	%0238	A05 \$
004548	000121	001433	0375	0187	0000	0625	0812	1000	0000	%0239	A06 \$
003698	000073	000742	0250	0125	0000	0750	0875	1000	0000	%0240	A07 \$
002594	000059	000295	0125	0062	0000	0875	0937	1000	0000	%0241	A08 \$
001330	000044	000114	0000	0000	0000	1000	1000	1000	0000	%0242	A09 \$
009709	-00103	000221	1000	1000	1000	0000	0000	0000	0000	%0486	S10 \$
009019	000406	-00403	0937	0875	1000	0062	0125	0000	0000	%0487	S11 \$
008219	001012	-00956	0875	0750	1000	0125	0250	0000	0000	%0488	S12 \$
007402	001006	-01328	0812	0625	1000	0187	0375	0000	0000	%0489	S13 \$
006422	002631	-01827	0750	0500	1000	0250	0500	0000	0000	%0490	S14 \$
005347	003232	-01429	0687	0375	1000	0312	0625	0000	0000	%0491	S15 \$
004429	003900	-02873	0625	0250	1000	0375	0750	0000	0000	%0492	S16 \$
003706	004081	-03062	0562	0250	1000	0437	0875	0000	0000	%0493	S17 \$
003263	004594	-03024	0500	0250	1000	0500	1000	0000	0000	%0494	S18 \$
002936	-00899	001248	0937	1000	0875	0062	0000	0125	0000	%0495	T10 \$
008903	-00068	000207	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$
008144	000400	-00764	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$
007500	000933	-01179	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$
006814	001645	-01625	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$
005961	002444	-02112	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$
005158	003133	-02573	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$
004326	003899	-02932	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$
003642	004518	-03103	0437	0000	0875	0562	1000	0125	0000	%0503	T18 \$
002903	-01410	002323	0875	1000	0750	0125	0000	0250	0000	%0504	T19 \$
002726	-00748	000919	0812	0875	0750	0187	0125	0250	0000	%0505	U11 \$
007959	-00052	000153	0750	0750	0750	0250	0250	0250	0000	%0506	U12 \$
007329	000307	-00687	0687	0625	0750	0312	0375	0250	0000	%0507	U13 \$
006626	000834	-01164	0625	0500	0750	0375	0500	0250	0000	%0508	U14 \$
006012	00143										

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

```

009714 -00102 000218 1000 1000 1000 0000 0000 0000 0000 %0243 b01 $
008895 -00317 -00760 0875 0906 1000 0125 0093 0000 0000 %0244 b02 $
008277 -00419 -01382 0750 0812 1000 0250 0187 0000 0000 %0245 b03 $
007183 -00327 -02359 0625 0718 1000 0375 0281 0000 0000 %0246 b04 $
006209 000019 -03016 0500 0625 1000 0500 0375 0000 0000 %0247 b05 $
005258 000367 -03663 0375 0531 1000 0625 0468 0000 0000 %0248 b06 $
004468 000624 -04204 0250 0437 1000 0750 0562 0000 0000 %0249 b07 $
003929 000577 -04605 0125 0343 1000 0875 0556 0000 0000 %0250 b08 $
003565 000664 -04842 0000 0250 1000 1000 0750 0000 0000 %0251 b09 $
009546 -00456 001630 1000 0968 0875 0000 0031 0125 0000 %0252 c01 $
008728 -00072 000214 0875 0875 0875 0125 0125 0125 0000 %0253 c02 $
008011 -00198 -00915 0750 0781 0875 0250 0218 0125 0000 %0254 c03 $
007388 000047 -01560 0625 0687 0875 0375 0312 0125 0000 %0255 c04 $
006577 -00048 -02311 0500 0593 0875 0500 0406 0125 0000 %0256 c05 $
005908 000050 -02968 0375 0500 0875 0625 0500 0125 0000 %0257 c06 $
005160 000036 -03688 0250 0406 0875 0750 0593 0125 0000 %0258 c07 $
004618 000238 -04197 0125 0312 0875 0875 0687 0125 0000 %0259 c08 $
003960 000397 -04649 0000 0218 0875 1000 0781 0125 0000 %0260 c09 $
009284 -00482 002680 1000 0937 0750 0000 0662 0250 0000 %0261 d01 $
008650 -00205 001278 0875 0843 0750 0125 0156 0250 0000 %0262 d02 $
007811 -00049 000146 0750 0750 0750 0250 0500 0437 0250 0000 %0263 d03 $
007189 -00145 -00908 0625 0656 0750 0375 0343 0250 0000 %0264 d04 $
006582 000055 -01468 0500 0562 0750 0500 0500 0437 0250 0000 %0265 d05 $
005910 -00071 -02100 0375 0468 0750 0625 0531 0250 0000 %0266 d06 $
005335 -00128 -02549 0250 0375 0750 0750 0625 0250 0000 %0267 d07 $
004808 000020 -02988 0125 0281 0750 0875 0718 0250 0000 %0268 d08 $
004479 000070 -03367 0000 0187 0750 1000 0812 0250 0000 %0269 d09 $
009108 -00510 003622 1000 0906 0625 0000 0093 0375 0000 %0270 e01 $
008561 -00372 002394 0875 0812 0625 0125 0187 0375 0000 %0271 e02 $
007844 -00271 000897 0750 0718 0625 0250 0281 0375 0000 %0272 e03 $
006932 -00042 000091 0625 0625 0625 0375 0375 0375 0000 %0273 e04 $
006450 -00109 -00084 0500 0531 0625 0500 0468 0375 0000 %0274 e05 $
005841 -00081 -01601 0375 0437 0625 0625 0500 0375 0000 %0275 e06 $
005263 -00189 -02016 0250 0343 0625 0750 0566 0375 0000 %0276 e07 $
004927 -00077 -02369 0125 0250 0625 0875 0750 0375 0000 %0277 e08 $
004477 000242 -02749 0000 0156 0625 1000 0843 0375 0000 %0278 e09 $
008852 -00330 004274 1000 0875 0500 0000 0125 0500 0000 %0279 f01 $
008436 -00401 003238 0875 0781 0500 0125 0218 0500 0000 %0280 f02 $
007790 -00360 002099 0750 0687 0500 0250 0312 0500 0000 %0281 f03 $
006935 -00170 000561 0625 0593 0500 0375 0406 0500 0000 %0282 f04 $
005970 -00029 000049 0500 0500 0500 0500 0500 0500 0000 %0283 f05 $
005644 -00075 -00948 0375 0406 0500 0625 0593 0500 0000 %0284 f06 $
005019 -00107 -01598 0250 0312 0500 0750 0687 0500 0000 %0285 f07 $
004618 -00106 -01958 0125 0218 0500 0875 0781 0500 0000 %0286 f08 $
004387 -00207 -02284 0000 0125 0500 1000 0875 0500 0000 %0287 f09 $
006866 -00264 004922 1000 0843 0375 0000 0156 0625 0000 %0288 g01 $
008278 -00273 003944 0875 0750 0375 0125 0250 0625 0000 %0289 g02 $
007611 -00373 002824 0750 0656 0375 0250 0343 0625 0000 %0290 g03 $
006825 -00230 001526 0625 0562 0375 0375 0437 0625 0000 %0291 g04 $
005947 -00102 000426 0500 0468 0375 0500 0531 0625 0000 %0292 g05 $
004935 -00018 -00023 0375 0375 0375 0625 0625 0625 0000 %0293 g06 $
004730 -00031 -00926 0250 0281 0375 0750 0718 0625 0000 %0294 g07 $
004172 -00064 -01500 0125 0187 0375 0875 0812 0625 0000 %0295 g08 $
003891 000011 -01855 0000 0093 0375 1000 0906 0625 0000 %0296 g09 $
008550 -00202 005613 1000 0812 0250 0000 0187 0750 0000 %0297 h01 $
008130 -00281 -004692 0875 0718 0250 0125 0281 0750 0000 %0298 h02 $
007416 -00370 003545 0750 0625 0250 0250 0375 0750 0000 %0299 h03 $
006724 -00403 002403 0625 0531 0250 0375 0437 0750 0000 %0300 h04 $
005800 -00280 001170 0500 0437 0250 0500 0562 0750 0000 %0301 h05 $
004801 -00004 000278 0375 0343 0250 0625 0656 0750 0000 %0302 h06 $
003813 -00005 000016 0250 0250 0250 0750 0750 0750 0000 %0303 h07 $
003742 000133 -00737 0125 0156 0250 0875 0843 0750 0000 %0304 h08 $
003462 000050 -01235 0000 0062 0250 1000 0937 0750 0000 %0305 h09 $
008413 -00180 006868 1000 0781 0125 0000 0218 0875 0000 %0306 i01 $
007999 -00315 005645 0875 0687 0125 0125 0312 0875 0000 %0307 i02 $
007348 -00329 004294 0750 0593 0125 0250 0406 0875 0000 %0308 i03 $
006571 -00349 003197 0625 0500 0125 0375 0500 0875 0000 %0309 i04 $
005812 -00368 002109 0500 0406 0125 0500 0593 0875 0000 %0310 i05 $
004761 -00240 000936 0375 0312 0125 0625 0687 0875 0000 %0311 i06 $
003809 000056 001019 0250 0218 0125 0750 0781 0875 0000 %0312 i07 $
002171 000028 000056 0125 0125 0125 0875 0875 0875 0000 %0313 i08 $
002690 000108 -00414 0000 0031 0125 1000 0968 0875 0000 %0314 i09 $
008214 000038 008035 1000 0750 0000 0000 0250 1000 0000 %0315 j01 $
007767 -00030 007770 0875 0656 0000 0125 0343 1000 0000 %0316 j02 $
007176 -00270 005250 0750 0562 0000 0250 0437 1000 0000 %0317 j03 $
006434 -00308 003793 0625 0406 0000 0375 0531 1000 0000 %0318 j04 $
005654 -00402 002696 0500 0378 0000 0500 0625 1000 0000 %0319 j05 $
004844 -00388 001644 0375 0281 0000 0625 0718 1000 0000 %0320 j06 $
003789 -00166 000781 0250 0187 0000 0750 0812 1000 0000 %0321 j07 $
002603 -00006 000325 0125 0093 0000 0875 0906 1000 0000 %0322 j08 $
001307 000050 000111 0000 0000 0000 1000 1000 1000 0000 %0323 j09 $
009705 -00092 000198 1000 1000 1000 0000 0000 0000 %0567 b10 $
009114 000539 -00265 0968 0875 1000 0031 0125 0000 0000 %0568 b11 $
008443 001344 -00643 9937 0750 1000 0062 0250 0000 0000 %0569 b12 $
007844 002079 -00843 0906 0625 1000 0093 0375 0000 0000 %0570 b13 $
006957 002805 -01323 0875 0500 1000 0125 0500 0000 0000 %0571 b14 $
005985 003774 -01704 0843 0375 1000 0156 0625 0000 0000 %0572 b15 $
005176 004685 -01954 0812 0250 1000 0187 0750 0000 0000 %0573 b16 $
004383 004966 -02141 0781 0250 1000 0218 0875 0000 0000 %0574 b17 $
003822 005337 -02204 0750 0000 1000 0250 1000 0000 0000 %0575 b18 $
009250 -00990 000915 0906 1000 0875 0093 0000 0125 0000 %0576 c10 $
008889 -00067 000202 0875 0875 0875 0125 0125 0125 0000 %0577 c11 $
008259 000479 -00575 0843 0750 0875 0156 0250 0125 0000 %0578 c12 $
007653 001129 -00942 0812 0625 0875 0187 0375 0125 0000 %0579 c13 $
007030 001860 -01238 0781 0500 0875 0218 0500 0125 0000 %0580 c14 $
006307 002768 -01536 0590 0375 0875 0250 0625 0125 0000 %0581 c15 $
005584 003622 -01719 0718 0250 0875 0281 0750 0125 0000 %0582 c16 $
004964 004247 -01880 0687 0125 0875 0312 0875 0125 0000 %0583 c17 $
004038 005303 -02199 0656 0000 0875 0343 1000 0125 0000 %0584 c18 $
009018 -01473 001664 0812 1000 0750 0187 0000 0250 0000 %0585 d10 $
007874 -00930 000768 0781 0875 0750 0218 0125 0250 0000 %0586 d11 $
007905 -00051 000159 0750 0750 0750 0250 0250 0250 0000 %0587 d12 $
007409 000480 -00588 0718 0625 0750 0281 0375 0250 0000 %0588 d13 $
006831 001072 -00872 0687 0500 0750 0312 0500 0250 0000 %0589 d14 $
006241 001737 -01135 0656 0375 0750 0343 0625 0250 0000 %0590 d15 $
005620 002450 -01327 0625 0250 0750 0375 0750 0250 0000 %0591 d16 $
005118 003148 -01517 0593 0125 0750 0406 0875 0250 0000 %0592 d17 $
004455 003873 -01755 0562 0000 0750 0437 1000 0250 0000 %0593 d18 $
008565 -02032 002065 0718 1000 0625 0281 0000 0375 0000 %0594 e10 $
008412 -01483 001429 0687 0875 0625 0312 0125 0375 0000 %0595 e11 $
007828 -00734 000499 0656 0750 0625 0343 0250 0375 0000 %0596 e12 $
007065 -00040 000079 0625 0625 0625 0375 0375 0375 0000 %0597 e13 $
006065 000386 -00581 0593 0500 0625 0406 0500 0375 0000 %0598 e14 $
008045 000992 -00877 0562 0375 0625 0437 0625 0375 0000 %0599 e15 $
005464 001655 -01170 0531 0250 0625 0468 0750 0375 0000 %0600 e16 $
005020 002270 -01359 0500 0125 0625 0500 0875 0375 0000 %0601 e17 $
004456 003045 -01579 0468 0000 0625 0531 1000 0375 0000 %0602 e18 $
008035 -02641 002204 0625 1000 0500 0375 0000 0500 0000 %0603 f10 $
008042 -01997 001785 0937 0875 0500 0406 0125 0500 0000 %0604 f11 $
007543 -01306 001022 0562 0750 0500 0437 0250 0500 0000 %0605 f12 $
006886 -00545 000259 0312 0625 0500 0468 0375 0500 0000 %0606 f13 $
006061 -00029 000063 0500 0500 0500 0500 0500 0500 0000 %0607 f14 $
005671 000385 -00646 0468 0375 0500 0531 0625 0500 0000 %0608 f15 $
005283 000821 -00877 0437 0250 0500 0562 0750 0500 0000 %0609 f16 $
004856 001432 -01146 0406 0125 0500 0593 0875 0500 0000 %0610 f17 $
004357 002032 -01354 0375 0000 0500 0625 1000 0500 0000 %0611 f18 $
007470 -03353 002464 0351 1000 0375 0468 0000 0625 0000 %0612 g10 $
007596 -02692 002067 0500 0875 0375 0500 0125 0625 0000 %0613 g11 $
007265 -01790 001431 0468 0750 0375 0531 0250 0625 0000 %0614 g12 $
006671 -01145 000740 0437 0625 0375 0562 0375 0625 0000 %0615 g13 $
005919 -00467 000253 0406 0500 0375 0593 0500 0625 0000 %0616 g14 $
004918 -00006 000028 0375 0375 0375 0625 0625 0625 0000 %0617 g15 $
004879 000322 -00526 0343 0250 0375 0656 0750 0625 0000 %0618 g16 $
004429 000687 -00783 0312 0125 0375 0687 0875 0625 0000 %0619 g17 $
004122 001252 -01042 0281 0000 0375 0718 1000 0625 0000 %0620 g18 $
007067 -04066 003207 0437 1000 0250 0562 0000 0750 0000 %0621 h10 $
007190 -03309 002367 0406 0875 0250 0593 0125 0750 0000 %0622 h11 $
006844 -02428 001590 0375 0750 0250 0625 0250 0750 0000 %0623 h12 $
006337 -01647 001118 0343 0625 0250 0656 0375 0750 0000 %0624 h13 $
005666 -01074 000613 0312 0500 0250 0687 0500 0750 0000 %0625 h14 $
004731 -00348 000093 0281 0375 0250 0718 0625 0750 0000 %0626 h15 $
003813 -00005 000022 0250 0250 0250 0750 0750 0750 0000 %0627 h16 $
003831 000364 -00441 0218 0125 0250 0781 0875 0750 0000 %0628 h17 $
003633 000650 -00723 0187 0000 0250 0812 1000 0750 0000 %0629 h18 $
006606 -04993 004308 0343 1000 0125 0656 0000 0875 0000 %0630 i10 $
006904 -03960 003082 0312 0875 0125 0687 0125 0875 0000 %0631 i11 $
006382 -03008 002103 0281 0750 0125 0718 0250 0875 0000 %0632 i12 $
005933 -02173 001460 0250 0625 0125 0750 0375 0875 0000 %0633 i13 $
005318 -01447 000952 0187 0500 0125 0781 0500 0875 0000 %0634 i14 $
004644 -00861 000559 0218 0375 0125 0812 0625 0875 0000 %0635 i15 $
003778 -00221 000169 0156 0250 0125 0843 0750 0875 0000 %0636 i16 $
002180 000034 000066 0125 0125 0125 0875 0875 0750 0000 %0637 i17 $
002590 000331 -00292 0093 0000 0125 0900 1000 0875 0000 %0638 i18 $
006200 -00548 004682 0250 1000 0000 0750 0000 1000 0000 %0639 j10 $
006557 -05083 004299 0218 0875 0000 0781 0125 1000 0000 %0640 j11 $
006004 -03486 002522 0817 0750 0000 0812 0250 1000 0000 %0641 j12 $
005605 -02837 001864 0156 0625 0000 0843 0375 1000 0000 %0642 j13 $
005121 -02017 001279 0125 0500 0000 0875 0500 1000 0000 %0643 j14 $
004512 -01153 000851 0093 0375 0000 0906 0625 1000 0000 %0644 j15 $
003865 -00567 000379 0662 0250 0000 0937 0750 1000 0000 %0645 j16 $
002726 -00165 000274 0031 0125 0000 0968 0875 1000 0000 %0646 j17 $
001228 000059 000138 0000 0000 0000 1000 1000 1000 0000 %0647 j18 $
009690 -00097 000215 1000 1000 1000 0000 0000 0000 %09690 b10 $
009114 000523 000626 1000 0875 0906 0000 0125 0093 0000 %09691 b11 $
008618 001014 001013 1000 0750 0812 0000 0250 0187 0000 %09692 b12 $
007983 001718 001457 1000 0625 0718 0000 0375 0281 0000 %09693 b13 $
007297 002535 002017 1000 0500 0625 0000 0500 0375 0000 %09694 b14 $
006433 003835 002427 1000 0375 0531 0000 0625 0468 0000 %09695 b15 $
005609 005161 002952 1000 0250 0437 0000 0750 0562 0000 %09696 b16 $
004929 006382 003191 1000 0125 0343 0000 0875 0656 0000 %09697 b17 $
004407 006013 002869 1000 0000 0250 0000 1000 0750 0000 %09698 b18 $
009029 -00845 -00452 0875 1000 0968 0125 0000 0031 0000 %09699 c10 $
008822 -00066 000203 0875 0875 0875 0125 0125 0125 0000 %09700 c11 $
008170 000475 000540 0875 0750 0781 0125 0250 0218 0000 %09701 c12 $
007617 001034 001019 0875 0625 0687 0125 0375 0312 0000 %09702 c13 $
007133 001527 001509 0875 0500 0593 0125 0500 0406 0000 %09703 c14 $
006512 002220 001818 0875 0375 0500 0125 0625 0500 0000 %09704 c15 $
005823 003158 002155 0875 0250 0406 0125 0750 0593 0000 %09705 c16 $
005247 004026 002514 0875 0125 0312 0125 0875 0687 0000 %09706 c17 $
004484 005279 002696 0875 0000 0218 0125 1000 0781 0000 %09707 c18 $
008576 -01178 -00925 0750 1000 0937 0250 0000 0062 0000 %09708 d19 $
008582 -00956 -00905 0750 0875 0843 0250 0125 0156 0000 %09709 d20 $
007883 -00044 000148 0750 0750 0750 0250 0250 0250 0000 %09710 d21 $
007435 000531 000353 0750 0625 0562 0250 0375 0343 0000 %09711 d22 $
006903 000999 000793 0750 0500 0656 0250 0500 0437 0000 %09712 d23 $
006390 001351 001381 0750 0375 0468 0250 0625 0531 0000 %09713 d24 $
005769 001945 001653 0750 0250 0375 0250 0750 0625 0000 %09714 d25 $
005141 002737 001943 0750 0125 0281 0250 0875 0718 0000 %09715 d26 $
004476 003463 002201 0750 0000 0187 0250 1000 0812 0000 %09716 d27 $
008001 -01689 -01258 0625 1000 0906 0375 0000 0093 0000 %09717 e10 $
008102 -01342 -00689 0625 08
```

See original or copy: <http://web.me.com/klaus.richter/GE13/GE13L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE03_22_REM.TXT, Separation cmyn4*, D65, not adapted $
%100 x LAB*      %#1000 x (r g b c m y 0)      %nr.    pos $
%Z004442 006225 004026 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009129 -01489 008739 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005534 -06924 003563 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005423 -03481 -03828 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z002990 002526 -04473 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004437 006999 -01100 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001269 000047 000107 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009707 -00097 000200 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004442 006225 004026 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009129 -01489 008739 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005534 -06924 003563 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005423 -03481 -03828 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z002990 002526 -04473 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004437 006999 -01100 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001269 000047 000107 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009707 -00097 000200 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004442 006225 004026 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009129 -01489 008739 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005534 -06924 003563 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005423 -03481 -03828 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z002990 002526 -04473 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004437 006999 -01100 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001269 000047 000107 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009707 -00097 000200 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005872 004320 006155 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008733 -02533 008735 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005617 -06149 001356 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005351 -02837 -04537 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z002862 003944 -03797 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004393 006798 000066 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001326 000050 000108 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009699 -00098 000209 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z007056 002063 007215 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007148 -04264 006115 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005689 -05300 -00381 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004640 -01301 -04840 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003263 004894 -03024 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004339 006239 001608 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001372 000043 000117 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009714 -00097 000202 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z008214 000038 008035 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006200 -05648 004682 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005730 -04462 -01867 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003565 000664 -04842 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003822 005837 -02204 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004407 006013 002869 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001315 000051 000117 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009703 -00097 000210 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

TUB registration: 20091101-GE13/GE13L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/GE13/GE13L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG GE03_22_REM.TXT, Separation cmyn4*, D65, not adapted \$																			
%100 x LAB*										1000 x (r g b c m y θ) %nr. pos \$									
001213	000031	000121	0000	0000	0000	0000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001938	000018	000069	0125	0125	0125	0125	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003679	-000008	000027	0250	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004717	-000111	000056	0375	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005957	-000226	000069	0500	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006984	-000339	000093	0625	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007911	-000447	000149	0750	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008926	-000565	000192	0875	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009725	-000696	000195	1000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
010187	000033	000114	0000	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001889	000021	000083	0125	0125	0125	0125	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003598	000008	000027	0250	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004701	000008	000055	0375	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005896	000023	000070	0500	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006995	000039	000089	0625	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007903	000045	000142	0750	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008932	000069	000196	0875	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009718	000099	000210	1000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
010219	000024	000101	0000	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001861	000022	000078	0125	0125	0125	0125	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003547	000000	000023	0250	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004663	-000006	000054	0375	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005870	-000211	000065	0500	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006920	-000408	000104	0625	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007902	-000406	000148	0750	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008910	-000711	000201	0875	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009727	-000955	000198	1000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
010214	000028	000108	0000	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001903	000022	000077	0125	0125	0125	0125	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003546	-000003	000025	0250	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004671	-000008	000058	0375	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005856	-000223	000071	0500	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006927	-000335	000097	0625	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007921	-000406	000146	0750	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008901	-000666	000193	0875	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009720	-000991	000199	1000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
010242	000044	000121	0000	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001475	000048	000105	0066	0066	0066	0066	0933	0933	0933	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002283	000023	000028	0133	0133	0133	0133	0866	0866	0866	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003115	000016	000019	0200	0200	0200	0200	0800	0800	0800	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003980	000009	000040	0266	0266	0266	0266	0733	0733	0733	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004566	000002	000053	0333	0333	0333	0333	0666	0666	0666	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005192	000008	000053	0400	0400	0400	0400	0600	0600	0600	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005676	-000155	000076	0466	0466	0466	0466	0533	0533	0533	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006348	-000225	000080	0533	0533	0533	0533	0466	0466	0466	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006816	-000377	000108	0600	0600	0600	0600	0399	0399	0399	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007311	-000408	000128	0666	0666	0666	0666	0333	0333	0333	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007810	-000445	000156	0733	0733	0733	0733	0266	0266	0266	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008253	-000551	000180	0800	0800	0800	0800	0199	0199	0199	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008706	-000660	000194	0866	0866	0866	0866	0133	0133	0133	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009196	-000772	000199	0933	0933	0933	0933	0066	0066	0066	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009709	-000990	000186	1000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
010266	000045	000123	0000	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001476	000045	000110	0066	0066	0066	0066	0933	0933	0933	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002302	000022	000037	0133	0133	0133	0133	0866	0866	0866	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003139	000016	000022	0200	0200	0200	0200	0800	0800	0800	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004042	000006	000042	0266	0266	0266	0266	0733	0733	0733	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004993	000008	000057	0333	0333	0333	0333	0666	0666	0666	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005174	-000008	000057																	

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart GE13; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> oly* setrgbcolor
```

TUB registration: 20091101-GE13/GE13L0NA.TXT /.PS TUB material application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/GE13/GE13L0NA.TXT> /
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009724	000002	-00010	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$	009709	-000006	000019	1000	1000	1000	0000	0000	0000	%0486	S10 \$	009710	000003	-000008	1000	1000	1000	0000	0000	0000	0000	0000	%0810	S19 \$
009864	-00425	-00932	0875	0937	1000	0125	0062	0000	0000	%0163	S02 \$	009019	000492	-00599	0937	0875	1000	0062	0125	0000	0000	%0487	S11 \$	009143	000081	-000608	1000	0875	0937	0000	0125	0062	0000	%0811	S20 \$
008509	-00764	-01485	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$	008219	001084	-01143	0875	0750	1000	0125	0250	0000	0000	%0488	S12 \$	008520	001521	-001009	1000	0750	0875	0000	0250	0125	0000	%0812	S21 \$
007586	-00929	-02432	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$	007402	001865	-01507	0812	0625	1000	0187	0375	0000	0000	%0489	S13 \$	007910	002220	-000398	1000	0625	0812	0000	0375	0187	0000	%0813	S22 \$
006806	-00904	-03086	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$	006422	002673	-01996	0750	0500	1000	0250	0500	0000	0000	%0490	S14 \$	007251	003007	-000772	1000	0500	0750	0000	0500	0250	0000	%0814	S23 \$
006073	-00950	-03726	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$	005347	003256	-02587	0687	0375	1000	0312	0625	0000	0000	%0491	S15 \$	006453	004143	-001137	1000	0375	0687	0000	0625	0312	0000	%0815	S24 \$
005044	-01131	-04335	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$	004429	003908	-03022	0625	0250	1000	0375	0750	0000	0000	%0492	S16 \$	005617	005496	-001379	1000	0250	0625	0000	0750	0375	0000	%0816	S25 \$
004943	-01302	-04767	0125	0562	1000	0875	0507	0000	0000	%0169	S08 \$	003706	004478	-03252	0562	0125	1000	0507	0875	0000	0000	%0493	S17 \$	004925	006712	-001556	1000	0125	0562	0000	0875	0507	0000	%0817	S26 \$
004640	-01209	-04991	0000	0500	1000	1000	0500	0000	0000	%0170	S09 \$	003263	004383	-03161	0500	0000	1000	0500	1000	0000	0000	%0494	S18 \$	004339	006246	-001460	1000	0000	0500	0000	1000	0500	0000	%0818	S27 \$
003408	-00142	-001302	1000	0937	0875	0000	0062	0125	0000	%0171	T01 \$	0009396	-00807	001049	0937	1000	0875	0062	0000	0125	0000	%0495	T10 \$	009079	-00783	-00399	0875	1000	0937	0125	0000	0062	0000	%0819	T19 \$
008750	000013	000017	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$	008903	000015	000013	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$	008851	000021	000005	0875	0875	0875	0125	0125	0125	0000	%0820	T20 \$
008137	-00254	-01088	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$	008144	000471	-00951	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$	008192	000732	-000811	0875	0750	0812	0125	0250	0187	0000	%0821	T21 \$
007607	-00392	-01647	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$	007500	000993	-01359	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$	007568	001351	-000322	0875	0625	0750	0125	0375	0250	0000	%0822	T22 \$
006882	-00571	-02379	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$	006814	001694	-01798	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$	007059	001988	-000460	0875	0500	0687	0125	0500	0312	0000	%0823	T23 \$
006335	-00802	-02891	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$	005961	002478	-02277	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$	006490	002644	-000775	0875	0375	0625	0125	0625	0375	0000	%0824	T24 \$
005709	-00958	-03411	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$	005158	003154	-02729	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$	005791	003545	-000492	0875	0250	0562	0125	0750	0437	0000	%0825	T25 \$
005198	-01064	-03894	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$	004326	003906	-03080	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$	005200	004346	-001287	0875	0125	0500	0125	0875	0500	0000	%0826	T26 \$
004757	-01188	-04475	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$	003642	004513	-03244	0437	0000	0875	0562	1000	0125	0000	%0503	T18 \$	004405	005570	-001393	0875	0000	0437	0125	1000	0562	0000	%0827	T27 \$
009138	-00186	-002422	1000	0875	0750	0000	0125	0250	0000	%0180	T01 \$	009203	-01321	-002125	0875	1000	0750	0125	0000	0250	0000	%0504	T19 \$	008603	-01380	-00250	0750	1000	0875	0250	0000	0125	0000	%0828	T28 \$
008453	000098	000060	0875	0812	0750	0125	0187	0250	0000	%0181	T02 \$	008726	-00668	000727	0812	0875	0750	0187	0125	0250	0000	%0505	T11 \$	008509	-00968	-00252	0750	0875	0812	0250	0125	0187	0000	%0829	T29 \$
007767	000012	-00027	0750	0750	0750	0250	0250	0250	0000	%0182	T03 \$	007959	000015	-00031	0750	0750	0750	0250	0250	0250	0000	%0506	T12 \$	007858	000019	-00015	0750	0750	0750	0250	0250	0250	0000	%0830	T30 \$
007244	-00217	-01080	0625	0687	0750	0375	0312	0250	0000	%0183	T04 \$	007329	000364	-00866	0687	0625	0750	0312	0375	0250	0000	%0507	T13 \$	007411	000668	-00108	0750	0625	0687	0250	0375	0312	0000	%0831	T31 \$
006852	-00341	-01478	0500	0625	0750	0500	0375	0250	0000	%0184	T05 \$	006626	000879	-01336	0625	0500	0750	0375	0250	0500	0000	%0508	T14 \$	006888	001214	-000196	0750	0500	0625	0250	0500	0375	0000	%0832	T32 \$
006294	-00483	-02058	0375	0562	0750	0625	0437	0250	0000	%0185	T06 \$	006012	001465	-01641	0562	0375	0750	0437	0625	0250	0000	%0509	T15 \$	006352	001720	-000443	0750	0375	0562	0250	0625	0437	0000	%0833	T33 \$
006581	-00688	-02607	0250	0500	0750	0750	0500	0250	0000	%0186	T07 \$	005340	002003	-01965	0500	0250	0750	0500	0750	0250	0000	%0510	T16 \$	005747	002269	-000579	0750	0250	0500	0250	0750	0500	0000	%0834	T34 \$
005249	-00782	-03012	0125	0437	0750	0875	0562	0250	0000	%0187	T08 \$	004715	002449	-02311	0437	0125	0750	0562	0875	0250	0000	%0511	T17 \$	005171	002921	-000824	0750	0125	0437	0250	0875	0562	0000	%0835	T35 \$
004897	-00880	-03323	0000	0375	0750	1000	0625	0250	0000	%0188	T09 \$	004139	003112	-02601	0375	0000	0750	0625	1000	0250	0000	%0512	T18 \$	004473	003698	-001044	0750	0000	0375	0250	1000	0625	0000	%0836	T36 \$
008663	000303	002948	1000	0812	0625	0000	0187	0375	0000	%0189	V01 \$	008925	-01764	-002727	0812	1000	0625	0187	0000	0375	0000	%0513	T19 \$	008088	-01816	-00751	0625	1000	0812	0375	0000	0187	0000	%0837	V19 \$
008227	-000118	-002042	0875	0750	0625	0125	0250	0375	0000	%0190	V02 \$	008600	-01148	-001671	0750	0875	0625	0250	0125	0375	0000	%0514	T20 \$	008142	-01527	-00181	0625	0875	0750	0375	0125	0250	0000	%0838	V20 \$
007679	000034	000709	0750	0687	0625	0250	0312	0375	0000	%0191	V03 \$	007844	-00498	-000356	0687	0750	0625	0312	0250	0375	0000	%0515	T21 \$	007556	-00807	-000391	0625	0750	0687	0375	0250	0312	0000	%0839	V21 \$
006849	000008	-00071	0625	0625	0625	0375	0375	0375	0000	%0192	V04 \$	007014	000010	-00086	0625	0625	0625	0375	0375	0375	0000	%0516	T22 \$	006913	000020	-000608	0625	0625	0625	0375	0375	0375	0000	%0840	V22 \$
006514	-00232	-01800	0500	0375	0562	0625	0500	0437	0000	%0193	V05 \$	006440	000346	-00820	0562	0500	0625	0437	0500	0375	0000	%0517	T23 \$	006452	000519	-00223	0625	0500	0562	0375	0500	0437	0000	%0841	V23 \$
006107	-00354	-01594	0375	0562	0625	0625	0625	0375	0000	%0194	V06 \$	005847	000334	-01285	0500	0375	0625	0500	0625	0375	0000	%0518	T24 \$	005999	001046	-000608	0625	0375	0500	0375	0625	0500	0000	%0842	V24 \$
005473	-00490	-02181	0250	0437	0625	0750	0562	0375	0000	%0195	V07 \$	005276	001490	-01628	0437	0250	0625	0562	0750	0375	0000	%0519	T25 \$	005425	001589	-000329	0625	0250	0437	0375	0750	0562	0000	%0843	V25 \$
005154	-00592	-02466	0125	0375	0625	0875	0625	0375	0000	%0196	V08 \$	004747	-001862	-01960	0375	0125	0625	0625	0875	0375	0000	%0520	T26 \$	004964	002052	-000524	0625	0125	0375	0375	0875	0625	0000	%0844	V26 \$
004798	-00909	-02816	0000	0312	0625	1000	0687	0375	0000	%0197	V09 \$	004172	002409	-02274	0312	0000	0625	0687	1000	0375	0000	%0521	T27 \$	004247	002676	-000561	0625	0000	0						

See original or copy: <http://web.me.com/klaus.richter/GE13/GE13L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

TUB registration: 20091101-GE13/GE13L0NA.TXT /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

[illegible]

TUB-test chart GE13; Relative Device Colour System CIE
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrabcOLOR
```

```
%BEG GE03_22_REM.TXT, Separation cmyn4*, D65, adapted $
%100 x LAB*a      %#1000 x (r g b c m y 0)      %nr. pos $
%Z004442 006232 003884 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009129 -01401 008544 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005534 -06898 003408 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005423 -03457 -03981 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z002990 002508 -04599 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004437 007006 -01242 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001269 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009707 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004442 006232 003884 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009129 -01401 008544 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005534 -06898 003408 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005423 -03457 -03981 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z002990 002508 -04599 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004437 007006 -01242 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001269 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009707 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004442 006232 003884 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009129 -01401 008544 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005534 -06898 003408 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005423 -03457 -03981 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z002990 002508 -04599 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004437 007006 -01242 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001269 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009707 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005872 004351 005992 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008733 -02452 008537 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005617 -06123 001196 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005351 -02815 -04694 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z002862 003921 -03924 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004393 006800 -00078 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001326 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009699 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z007056 002115 007040 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007148 -04210 005939 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005689 -05270 -00543 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004640 -01289 -04991 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003263 004883 -03161 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004339 006246 001460 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001372 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009714 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z008214 000109 007841 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006200 -05613 004510 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005730 -04436 -02033 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003565 000652 -04984 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003822 005830 -02350 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004407 006016 002717 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001315 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009703 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```


See original or copy: <http://web.me.com/klaus.richter/GE13/GE13L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG GE03_22_REM.TXT, Separation cmyn4*, D65, adapted \$																			
%100 x LAB*a																			
1000 x (r g b c m y θ)																			
001213 -00018 000023 0000 0000 0000 1000 1000 1000 0000										%nr. pos \$									
001213	-00018	000023	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$							
001938	-00018	-00037	0125	0125	0125	0875	0875	0875	0000	%0983	k02	\$							
003679	-00015	-00100	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$							
004717	-00001	-00084	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$							
005957	-00004	-00087	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$							
006984	-00010	-00075	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$							
007911	-00017	-00031	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$							
008926	-00017	-00001	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$							
009725	-00000	-00007	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$							
001187	-00017	000016	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$							
001889	-00016	-00022	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$							
003598	-00009	-00100	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$							
004701	-00002	-00085	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$							
005896	-00006	-00085	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$							
006995	-00009	-00080	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$							
007903	-00019	-00037	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$							
008932	-00013	-00003	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$							
009718	-00003	-00007	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$							
001219	-00025	000003	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$							
001861	-00016	-00027	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$							
003547	-00009	-00103	0250	0250	0250	0750	0750	0750	0000	%0992	m03	\$							
004663	-00002	-00086	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$							
005870	-00009	-00090	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$							
006920	-00008	-00064	0625	0625	0625	0375	0375	0375	0000	%0995	m06	\$							
007902	-00019	-00032	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$							
008910	-00011	-00008	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$							
009727	-00001	-00004	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$							
001214	-00021	000010	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$							
001903	-00015	-00028	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$							
003546	-00013	-00100	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$							
004671	-00001	-00082	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$							
005856	-00006	-00093	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$							
006927	-00012	-00073	0625	0625	0625	0375	0375	0375	0000	%1004	n06	\$							
007921	-00019	-00034	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$							
008901	-00016	-00000	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$							
009720	-00004	-00003	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$							
001242	-00004	-00023	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$							
001475	-00002	-00004	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$							
002283	-00008	-00082	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$							
003115	-00001	-00102	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$							
003980	-00007	-00092	0266	0266	0266	0733	0733	0733	0000	%1012	k14	\$							
004566	-00010	-00086	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$							
005192	-00010	-00093	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$							
005676	-00011	-00076	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$							
006348	-00012	-00081	0533	0533	0533	0466	0466	0466	0000	%1016	k18	\$							
006816	-00008	-00058	0600	0600	0600	0399	0399	0399	0000	%1017	k19	\$							
007311	-00014	-00045	0666	0666	0666	0333	0333	0333	0000	%1018	k20	\$							
007810	-00018	-00023	0733	0733	0733	0266	0266	0266	0000	%1019	k21	\$							
008253	-00020	-00003	0800	0800	0800	0199	0199	0199	0000	%1020	k22	\$							
008706	-00018	-00004	0866	0866	0866	0133	0133	0133	0000	%1021	k23	\$							
009196	-00015	-00002	0933	0933	0933	0066	0066	0066	0000	%1022	k24	\$							
009709	-00005	-00016	1000	1000	1000	0000	0000	0000	0000	%1023	k25	\$							
001266	-00003	-00025	0000	0000	0000	1000	1000	1000	0000	%1024	l10	\$							
001476	-00000	-00009	0066	0066	0066	0933	0933	0933	0000	%1025	l11	\$							
002302	-00009	-00074	0133	0133	0133	0866	0866	0866	0000	%1026	l12	\$							
003139	-00000	-00099	0200	0200	0200	0800	0800	0800	0000	%1027	l13	\$							
004042	-00005	-00090	0266	0266	0266	0733	0733	0733	0000	%1028	l14	\$							
004993	-00008	-00082	0333	0333	0333	0666	0666	0666	0000	%1029	l15	\$							
005174	-00009	-00089	0400	0400	0400	0600	0600	0600	0000	%1030	l16	\$							
005681	-00016	-00088	0466	0466	0466	0533	0533	0533	0000	%1031	l17	\$							
006316	-00017	-00091	0533	0533	0533	0466	0466	0466	0000	%1032	l18	\$							
006795	-00019	-00071	0600	0600	0600	0399	0399	0399	0000	%1033	l19	\$							
007255	-00022	-00055	0666	0666	0666	0333	0333	0333	0000	%1034	l20	\$							
007776	-00024	-00031	0733	0733	0733	0266	0266	0266	0000	%1035	l21	\$							
008207	-00026	-00010	0800	0800	0800	0199	0199	0199	0000	%1036	l22	\$							
008679	-00026	-00007	0866	0866	0866	0133	0133	0133	0000	%1037	l23	\$							
009206	-00017	-00003	0933	0933	0933	0066	0066	0066	0000	%1038	l24	\$							
009714	-00005	-00007	1000	1000	1000	0000	0000	0000	0000	%1039	l25	\$							
001292	-00003	-00002	0000	0000	0000	1000	1000	1000	0000	%1040	m10	\$							
001468	-00002	-00012	0066	0066	0066	0933	0933	0933	0000	%1041	m11	\$							
002299	-00005	-00079	0133	0133	0133	0866	0866	0866	0000	%1042	m12	\$							
003115	-00002	-00095	0200	0200	0200	0800	0800	0800	0000	%1043	m13	\$							
003982	-00006	-00093	0266	0266	0266	0733	0733	0733	0000	%1044	m14	\$							
004519	-00006	-00071	0333	0333	0333	0666	0666	0666	0000	%1045	m15	\$							
005136	-00013	-00086	0400	0400	0400	0600	0600	0600	0000	%1046	m16	\$							
005591	-00013	-00077	0466	0466	0466	0533	0533	0533	0000	%1047	m17	\$							
006270	-00017	-00087	0533	0533	0533	0466													

TUB registration: 20091101-GE13/GE13L0NA.TXT/.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

TUB-test chart GE13; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GEI3/GEI3L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

[illegible]

See original or copy: <http://web.me.com/klaus.richter/GEI13/GEI13L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfi=1.00; nt=;

TUB registration: 20091101-GE13/GE13L0NA.TXT /PS TUB material: code=rh4ta
application for evaluation and measurement of printer or monitor systems

[illegible]

TUB-test chart GE13; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

```
%BEG GE03_22_REM.TXT, Separation cmyn4*, D50, not adapted $
%100 x LAB*      %#1000 x (r g b c m y o)      %nr.    pos $
%Z004636 006568 004316 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009178 -00814 008529 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005445 -06484 003140 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005260 -04229 -04176 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z002931 001968 -04534 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004602 007006 -00728 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001272 000063 000110 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009708 -00068 000193 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004636 006568 004316 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009178 -00814 008529 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005445 -06484 003140 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005260 -04229 -04176 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z002931 001968 -04534 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004602 007006 -00728 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001272 000063 000110 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009708 -00068 000193 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004636 006568 004316 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009178 -00814 008529 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005445 -06484 003140 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005260 -04229 -04176 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z002931 001968 -04534 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004602 007006 -00728 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001272 000063 000110 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009708 -00068 000193 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z006024 004858 006259 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008760 -01868 008455 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005515 -05943 000996 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005179 -03728 -04889 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z002871 003572 -03721 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004569 006900 000441 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001329 000065 000112 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009700 -00068 000201 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z007163 002688 007182 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007123 -03679 005786 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005574 -05356 -00712 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004486 -02171 -05134 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003325 004677 -02847 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004517 006467 001943 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001375 000060 000120 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009715 -00068 000195 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z008286 000703 007897 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006140 -05127 004301 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005600 -04785 -02187 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003447 -00088 -05039 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003932 005736 -01938 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004588 006318 003174 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001318 000068 000121 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009704 -00067 000203 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```


See original or copy: <http://web.me.com/klaus.richter/GE13/GE13L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG GE03_22_REM.TXT, Separation cmyn4*, D50, not adapted \$																			
%100 x LAB*										1000 x (r g b c m y θ) %nr. pos \$									
001216	000048	000123	0000	0000	0000	0000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001940	000028	000071	0125	0125	0125	0125	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003679	-00003	000028	0250	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004718	-00003	000056	0375	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005958	-00016	000067	0500	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006984	-00025	000091	0625	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007912	-00026	000145	0750	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008927	-00038	000187	0875	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009725	-00058	000198	1000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001190	000049	000117	0000	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001891	000033	000085	0125	0125	0125	0125	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003599	000004	000028	0250	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004702	000000	000055	0375	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005896	-00013	000069	0500	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006995	-00026	000086	0625	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007904	-00024	000139	0750	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008933	-00041	000191	0875	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009719	-00070	000202	1000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001221	000039	000104	0000	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001862	000033	000081	0125	0125	0125	0125	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003547	000003	000024	0250	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004664	000001	000054	0375	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005870	-00011	000064	0500	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006921	-00025	000101	0625	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007903	-00025	000145	0750	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008912	-00043	000196	0875	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009728	-00066	000191	1000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001216	000044	000111	0000	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001905	000034	000080	0125	0125	0125	0125	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003546	000000	000026	0250	0250	0250	0250	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004672	000000	000058	0375	0375	0375	0375	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005856	-00013	000070	0500	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006927	-00021	000095	0625	0625	0625	0625	0375	0375	0375	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007922	-00024	000143	0750	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008903	-00038	000188	0875	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009721	-00063	000192	1000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001244	000063	000124	0000	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001477	000063	000109	0066	0066	0066	0066	0933	0933	0933	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002284	000027	000030	0133	0133	0133	0133	0866	0866	0866	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003115	000019	000020	0200	0200	0200	0200	0800	0800	0800	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003981	000015	000041	0266	0266	0266	0266	0733	0733	0733	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004567	000010	000054	0333	0333	0333	0333	0666	0666	0666	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005193	000000	000053	0400	0400	0400	0400	0600	0600	0600	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005677	-00003	000075	0466	0466	0466	0466	0533	0533	0533	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006349	-00014	000078	0533	0533	0533	0533	0466	0466	0466	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006817	-00022	000106	0600	0600	0600	0600	0399	0399	0399	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007312	-00021	000125	0666	0666	0666	0666	0333	0333	0333	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
007812	-00022	000152	0733	0733	0733	0733	0266	0266	0266	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008254	-00025	000177	0800	0800	0800	0800	0199	0199	0199	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008708	-00032	000190	0866	0866	0866	0866	0133	0133	0133	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009197	-00043	000193	0933	0933	0933	0933	0066	0066	0066	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009710	-00063	000179	1000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001269	000063	000127	0000	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001478	000062	000114	0066	0066	0066	0066	0933	0933	0933	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
002303	000028	000039	0133	0133	0133	0133	0866	0866	0866	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003140	000020	000024	0200	0200	0200	0200	0800	0800	0800	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004043	000012	000043	0266	0266	0266	0266	0733	0733	0733	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004594	000009	000057	0333	0333	0333	0333	0666	0666	0666	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005175	000000	000056	0400	0400	0400	0400													

%BEG GE03_22.REM.TXT, Separation cmyn4*, D50, adapted S																																									
%1000 x LAB*a																																									
1000 x (r g b c m y θ)																																									
nrr. pos \$																																									
009725	-00003	000003	1000	1000	1000	0000	0000	0000	0000	%0000	A01	\$	009708	000001	-00007	1000	1000	1000	0000	0000	%00324	A10	\$	009690	000001	000003	1000	1000	1000	0000	0000	0000	0000	0000	0000	%00648	A19	\$			
008988	-00821	-00913	0875	1000	1000	0125	0000	0000	0000	%0001	A02	\$	008824	-00026	-00954	0875	0875	1000	0125	0125	0000	0000	%00325	A11	\$	009157	000003	-00337	1000	0875	1000	0000	0125	0000	0000	0000	0000	%00649	A20	\$	
008505	-01189	-01540	0750	1000	1000	0250	0000	0000	0000	%0002	A03	\$	007920	000154	-01713	0750	0750	1000	0250	0250	0000	0000	%00326	A12	\$	008594	001799	-00537	1000	0750	1000	0000	0250	0000	0000	0000	0000	0000	%00650	A21	\$
007927	-01673	-02209	0625	1000	1000	0375	0000	0000	0000	%0003	A04	\$	006734	000383	-02568	0625	0625	1000	0375	0375	0000	0000	%00327	A13	\$	007986	002690	-00661	1000	0625	1000	0000	0375	0000	0000	0000	0000	0000	%00651	A22	\$
007348	-02069	-02814	0500	1000	1000	0500	0000	0000	0000	%0004	A05	\$	005495	000844	-03356	0500	0500	1000	0500	0500	0000	0000	%00328	A14	\$	007317	003707	-00744	1000	0500	1000	0000	0500	0000	0000	0000	0000	0000	%00652	A23	\$
006790	-02574	-03271	0375	1000	1000	0625	0000	0000	0000	%0005	A06	\$	004514	001311	-03899	0375	0375	1000	0625	0625	0000	0000	%00329	A15	\$	006658	004804	-00807	1000	0375	1000	0000	0625	0000	0000	0000	0000	0000	%00653	A24	\$
006011	-03356	-03803	0250	1000	1000	0750	0000	0000	0000	%0006	A07	\$	003664	001828	-04283	0250	0250	1000	0750	0750	0000	0000	%00330	A16	\$	005839	005652	-00983	1000	0250	1000	0000	0750	0000	0000	0000	0000	0000	%00654	A25	\$
005493	-03997	-04088	0125	1000	1000	0875	0000	0000	0000	%0007	A08	\$	003301	001882	-04459	0125	0125	1000	0875	0875	0000	0000	%00331	A17	\$	005048	006889	-00826	1000	0125	1000	0000	0875	0000	0000	0000	0000	0000	%00655	A26	\$
005260	-04230	-04326	0000	1000	1000	1000	0000	0000	0000	%0008	A09	\$	002931	001930	-04661	0000	0000	1000	1000	1000	0000	0000	%00332	A18	\$	004602	006995	-00871	1000	0000	1000	0000	1000	0000	0000	0000	0000	0000	%00656	A27	\$
009140	000518	001020	1000	0875	0875	0000	0125	0125	0000	%0009	B01	\$	009648	-00406	001585	1000	1000	0875	0000	0000	0125	0000	%00333	B10	\$	009088	-00963	000516	0875	1000	0875	0125	0000	0125	0000	0000	0000	0000	%00657	B19	\$
008736	000011	000032	0875	0875	0875	0125	0125	0125	0000	%0010	B02	\$	008899	000015	000021	0875	0875	0875	0125	0125	0125	0000	%00334	B11	\$	008845	000019	000013	0875	0875	0875	0125	0125	0125	0000	0000	0000	0000	%00658	B20	\$
008522	-00885	-01053	0750	0875	0875	0250	0125	0125	0000	%0011	B03	\$	008008	-00056	-01168	0750	0750	0875	0250	0250	0125	0000	%00335	B12	\$	008200	000787	-00731	0875	0750	0875	0125	0250	0125	0000	0000	0000	0000	%00659	B21	\$
008141	-01472	-01687	0625	0875	0875	0375	0125	0125	0000	%0012	B04	\$	007188	-000270	-01906	0625	0625	0875	0375	0375	0125	0000	%00336	B13	\$	007586	001595	-00858	0875	0625	0875	0125	0375	0125	0000	0000	0000	0000	%00660	B22	\$
007594	-01946	-02455	0500	0875	0875	0500	0125	0125	0000	%0013	B05	\$	006194	000572	-02791	0500	0500	0875	0500	0500	0125	0000	%00337	B14	\$	007114	002436	-01038	0875	0500	0875	0125	0500	0125	0000	0000	0000	0000	%00661	B23	\$
007146	-02296	-02816	0375	0875	0875	0625	0125	0125	0000	%0014	B06	\$	005263	000797	-03511	0375	0375	0875	0625	0625	0125	0000	%00338	B15	\$	005832	003264	-01133	0875	0375	0875	0125	0625	0125	0000	0000	0000	0000	%00662	B24	\$
006659	-02709	-03281	0250	0875	0875	0750	0125	0125	0000	%0015	B07	\$	004316	001331	-03991	0250	0250	0875	0750	0750	0125	0000	%00339	B16	\$	005081	004346	-01256	0875	0250	0875	0125	0750	0125	0000	0000	0000	0000	%00663	B25	\$
006064	-03062	-03490	0125	0875	0875	0875	0125	0125	0000	%0016	B08	\$	003639	001749	-04234	0125	0125	0875	0875	0875	0125	0000	%00340	B17	\$	005203	005136	-01365	0875	0125	0875	0125	0875	0125	0000	0000	0000	0000	%00664	B26	\$
005548	-04020	-03899	0000	0875	0875	1000	0125	0125	0000	%0017	B09	\$	003266	001792	-04475	0000	0000	0875	1000	1000	0125	0000	%00341	B18	\$	004574	006188	-01341	0875	0000	0875	0125	1000	0125	0000	0000	0000	0000	%00665	B27	\$
008663	001069	001534	1000	0750	0750	0000	0250	0250	0000	%0018	C01	\$	009590	-00653	002885	1000	1000	0750	0000	0000	0250	0000	%00342	C10	\$	008694	-01522	001078	0750	1000	0750	0250	0000	0250	0000	0000	0000	0000	%00666	C19	\$
008138	000661	000658	0875	0750	0750	0125	0250	0250	0000	%0019	C02	\$	008922	-00255	001282	0875	0875	0750	0125	0125	0250	0000	%00343	C11	\$	008446	-01058	000184	0750	0875	0750	0250	0125	0250	0000	0000	0000	0000	%00667	C20	\$
007775	000013	-00027	0750	0750	0750	0250	0250	0250	0000	%0020	C03	\$	007899	000100	-00020	0750	0750	0750	0250	0250	0250	0000	%00344	C12	\$	007842	000020	-00021	0750	0750	0750	0250	0250	0250	0000	0000	0000	0000	%00668	C21	\$
007517	-00822	-00977	0625	0750	0750	0375	0250	0250	0000	%0021	C04	\$	007120	-00024	-01167	0625	0625	0750	0375	0375	0250	0000	%00345	C13	\$	007307	000013	-00025	0750	0625	0750	0250	0375	0250	0000	0000	0000	0000	%00669	C22	\$
007221	-01264	-01567	0500	0750	0750	0500	0250	0250	0000	%0022	C05	\$	006292	-00026	-01836	0500	0500	0750	0500	0500	0250	0000	%00346	C14	\$	006765	001423	-00843	0750	0500	0750	0250	0500	0250	0000	0000	0000	0000	%00670	C23	\$
006804	-01796	-02144	0375	0750	0750	0625	0250	0250	0000	%0023	C06	\$	005453	000303	-02426	0375	0375	0750	0625	0625	0125	0000	%00347	C15	\$	007145	002248	-01038	0750	0625	0750	0125	0625	0250	0000	0000	0000	0000	%00671	C24	\$
006405	-02144	-02577	0250	0750	0750	0750	0250	0250	0000	%0024	C07	\$	004800	-000672	-02932	0250	0250	0750	0750	0750	0250	0000	%00348	C16	\$	005690	002936	-01065	0750	0250	0750	0250	0750	0250	0000	0000	0000	0000	%00672	C25	\$
005994	-02446	-02908	0125	0750	0750	0875	0250	0250	0000	%0025	C08	\$	004293	000985	-03392	0125	0125	0750	0875	0875	0250	0000	%00349	C17	\$	005124	003722	-01099	0750	0125	0750	0250	0875	0250	0000	0000	0000	0000	%00673	C26	\$
005597	-02991	-03180	0000	0750	0750	1000	0250	0250	0000	%0026	C09	\$	003774	001123	-03912	0000	0000	0750	1000	1000	0250	0000	%00350	C18	\$	004583	004550	-01243	0750	0000	0750	0250	1000	0250	0000	0000	0000	0000	%00674	C27	\$
007993	001865	002278	1000	0625	0625	0000	0375	0375	0000	%0027	D01	\$	009424	-00563	00																										

application for evaluation and measurement of printer or monitor systems

009725	000001	-00010	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
008940	-00529	-00977	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
008468	-00941	-01565	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
007521	-01231	-02555	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
006726	-01300	-03237	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
005974	-01467	-03911	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
005281	-01805	-04567	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
004800	-02121	-05938	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$
004486	-02184	-05282	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
009423	000003	001291	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
008752	000015	000018	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
008114	-00366	-01129	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
007570	-00570	-01714	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
006825	-00849	-02482	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
006261	-01169	-03029	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
005617	-01430	-03583	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
005088	-01649	-04098	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
004625	-00136	-04724	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
009165	000917	002403	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
008468	000242	000661	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
007768	000008	-00026	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
007222	-00323	-01120	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
006819	-00500	-01536	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
006246	-00720	-02145	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
005615	-01016	-02728	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
005171	-01184	-03157	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
004807	-01350	-03491	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
008705	000677	002947	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
008255	000390	002038	0875	0750	0625	0125	0250	0375	0000	%0190	V02	\$
007690	000140	000708	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
006850	-00001	-00069	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
006491	-00343	-01120	0500	0625	0625	0500	0437	0375	0000	%0193	V05	\$
006072	-00530	-01657	0375	0562	0625	0625	0625	0375	0000	%0194	V06	\$
005421	-00750	-02274	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
005093	-00900	-02577	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
004726	-01071	-02950	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
008446	000871	003866	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
007991	000636	002676	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
007481	000358	001606	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
006756	000177	000370	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
005953	-00009	-00099	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
005737	-00339	-01104	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$
005163	-00525	-01685	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
004755	-00789	-02142	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
004532	-00796	-02455	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
008135	001241	004507	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
007742	000677	003293	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
007238	000551	002257	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
006554	000264	001271	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
005797	000074	000255	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
004862	-00015	-00129	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
004748	-00345	-01042	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
004223	-00452	-01600	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
004114	-00743	-01924	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
007783	001711	005358	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
007398	001095	003824	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
006964	000657	002939	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
006385	000408	001939	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
005615	000087	001010	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
004768	000072	000190	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
003833	-00026	-00129	0250	0250	0250	0750	0750	0750	0000	%0222	Y07	\$
003783	-00080	-00898	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
003543	-00270	-01357	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
007440	002227	006466	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
007142	001406	004379	0875	0500	0125	0125	0125	0800	0875	%0226	Z02	\$
006658	000925	003432	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
006111	000679	002506	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
005436	000303	001584	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
004604	000124	000672	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
003809	000081	000101	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
002225	-00013	-00072	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
002726	-00040	-00507	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$
007163	002717	007010	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
006825	002077	006122	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
006375	001264	004121	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
005847	000844	003063	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
005221	000452	002147	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
004568	000303	001286	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
003708	000066	000599	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
002599	000064	000167	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$
001333	000000	-00003	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009710	-00004	-000018	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
009021	000459	-00590	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
008223	001026	-01120	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
007417	001807	-01455	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
006447	002595	-01919	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
005374	003125	-02499	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
004463	003726	-02912	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
003813	002652	-03085	0500	0250	1000	0437	0500	0000	0000	%0493	S17	\$
003225	004547	-02085	0000	1000	0500	0500	1000	0000	0000	%0494	S18	\$
009394	-00675	-001004	0937	1000	0875	0062	0000	0125	0000	%0495	T10	\$
008905	000016	-000014	0875	0875	0875	0125	0125	0125	0000	%0496	T11	\$
008138	000404	-00952	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
007498	000912	-01347	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
006820	001600	-01766	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
005976	002362	-02221	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
005179	003000	-02652	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
004359	003714	-02973	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
003689	004287	-03102	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
009204	-01071	-002051	0875	1000	0750	0125	0000	0250	0000	%0504	U10	\$
008723	-00574	-000689	0812	0875	0750	0187	0125	0250	0000	%05		

```
input: w setgray  
output: -> olv* setrgbcolor
```

```
%BEG GE03_22_REM.TXT, Separation cmyn4*, D50, adapted $
%100 x LAB*a      %1000 x (r g b c m y o)      %nr. pos $
%Z004636 006557 004172 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009178 -00754 008341 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005445 -06482 002988 %1000 1000 0000 0000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005260 -04230 -04326 %1000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z002931 001930 -04661 %1000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004602 006995 -00871 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001272 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009708 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004636 006557 004172 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009178 -00754 008341 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005445 -06482 002988 %1000 1000 0000 0000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005260 -04230 -04326 %1000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z002931 001930 -04661 %1000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004602 006995 -00871 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001272 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009708 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004636 006557 004172 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009178 -00754 008341 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005445 -06482 002988 %1000 1000 0000 0000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005260 -04230 -04326 %1000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z002931 001930 -04661 %1000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004602 006995 -00871 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001272 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009708 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z006024 004867 006097 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008760 -01815 008263 %1000 0000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005515 -05942 000839 %1000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005179 -03732 -05043 %1000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z002871 003531 -93851 %1000 0000 0000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004569 006886 000294 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001329 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009708 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z007163 002717 007010 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007123 -03651 005613 %1000 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005574 -05351 -00870 %1000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004486 -02184 -05282 %1000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003325 004647 -02986 %1000 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004517 006455 001794 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001375 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009715 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z008286 000747 007708 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006140 -05117 004132 %1000 0000 0750 0000 1000 0000 0000 %0639 j10 %Y75L 1 $
%Z005600 -04784 -02350 %1000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003447 -00123 -05182 %1000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003932 005710 -02085 %1000 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004588 006302 003020 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001318 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009704 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```


See original or copy: <http://web.me.com/klaus.richter/GE13/GE13L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG GE03_22_REM.TXT, Separation cmyn4*, D50, adapted S																									
%100 x LAB*a																									
1000 x (r g b c m y θ)																									
%nr. pos \$																									
001216	-00015	000022	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$	008678	000021	000002	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$
001940	-00024	-00037	0125	0125	0125	0875	0875	0875	0000	%0973	k02	\$	009186	000015	000010	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$
003679	-00030	-00100	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$	009714	000000	000005	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$
004718	-00013	-00083	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$	001237	-00004	000018	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$
005958	-00007	-00086	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	001382	000008	000017	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$
006984	000000	-00074	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$	002245	-00015	-00067	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$
007912	000013	-00029	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$	003050	-00016	-00099	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$
008927	000016	000000	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$	003951	-00007	-00087	0266	0266	0266	0733	0733	0733	0000	%1060	n14	\$
009725	000000	000007	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$	004516	-00004	-00084	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$
001190	-00015	000015	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$	005118	-00002	-00083	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$
001891	-00020	-00023	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$	005589	000002	-00062	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$
003599	-00023	-00100	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$	006247	000001	-00071	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$
004702	-00010	-00084	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$	006743	000002	-00048	0600	0600	0600	0399	0399	0399	0000	%1065	n19	\$
005896	-00005	-00083	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	007174	000012	-00034	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$
006995	-00001	-00078	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$	007710	000017	-00026	0733	0733	0733	0266	0266	0266	0000	%1067	n21	\$
007904	000014	-00036	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$	008196	000022	000012	0800	0800	0800	0199	0199	0199	0000	%1068	n22	\$
008933	000013	000004	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$	008664	000019	000020	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$
009719	-00002	000007	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$	009159	000017	000002	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$
001221	-00025	000002	0000	0000	0000	0000	1000	1000	1000	%0990	m01	\$	009702	000004	-00009	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$
001862	-00020	-00027	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$	001336	000000	000000	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$
003547	-00024	-00103	0250	0250	0250	0750	0750	0750	0000	%0992	m03	\$	009723	000000	000000	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$
004664	-00009	-00085	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$	004648	006465	004249	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
005870	-00003	-00088	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$	005248	-04268	-04157	0000	1000	1000	0000	0000	0000	0000	%1075	l27	\$
006921	-00001	-00062	0625	0625	0625	0625	0375	0375	0000	%0995	m06	\$	009189	-00732	008593	1000	1000	0000	0000	0000	1000	0000	%1076	m26	\$
007903	000014	-00030	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$	002883	001998	-04626	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$
008912	000011	000009	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$	005352	-06577	003055	0000	1000	0000	0000	0000	1000	0000	%1078	n26	\$
009728	000000	-00004	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$	004587	007039	-01002	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$
001216	-00020	000009	0000	0000	0000	0000	1000	1000	1000	%0999	n01	\$													
001905	-00019	-00028	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$	%z004648 006465 004249 ##1000 0000 0000 0000 1000 1000 0000 %1074 l26 %03 0 0 \$												
003546	-00028	-00101	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$	%z009189 -00732 008593 ##1000 1000 0000 0000 0000 1000 0000 %1076 m26 %Y3 1 0 \$												
004672	-00010	-00081	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$	%z005352 -06577 003955 ##0000 1000 0000 0000 0000 1000 0000 %1078 n26 %L3 2 0 \$												
005856	-00006	-00082	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$	%z005248 -04268 -04157 ##0000 1000 1000 0000 0000 0000 0000 %1075 l27 %C3 3 0 \$												
006927	-00002	-00069	0625	0625	0625	0625	0375	0375	0000	%1004	n06	\$	%z002883 001998 -04626 ##0000 0000 1000 1000 1000 0000 0000 %1077 m27 %V3 4 0 \$												
007922	000014	-00032	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$	%z004587 007039 -01002 ##1000 0000 1000 0000 0000 1000 0000 %1079 n27 %M3 5 0 \$												
008903	000015	000001	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$	%z001336 000000 000000 ##0000 0000 0000 1000 1000 1000 0000 %1072 k26 %M3 6 0 \$												
009721	000004	-00003	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$	%z009723 000000 000000 ##1000 1000 1000 0000 0000 0000 0000 %1073 k27 %W3 7 0 \$												
001244	-00001	-00022	0000	0000	0000	0000	1000	1000	1000	%1008	k10	\$													
001477	000003	000004	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$	%z001216 -00015 000022 ##0000 0000 0000 0000 1000 1000 0000 %0972 k01 %N4 6 0 \$												
002284	-00020	-00082	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$	%z009725 000000 -00007 ##1000 1000 1000 0000 0000 0000 0000 %0980 k09 %W4 7 0 \$												
003115	-00015	-00101	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$													
003981	-00005	-00091	0266	0266	0266	0733	0733	0733	0000	%1012	k14	\$	%z001190 -00015 000005 ##0000 0000 0000 1000 1000 1000 0000 %0981 l01 %N5 6 0 \$												
004567	-00001	-00084	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$	%z009719 -00002 000007 ##1000 1000 1000 0000 0000 0000 0000 %0989 l09 %W5 7 0 \$												
005193	-00003	-00092	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$													
005677	000000	-00075	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$	%z001221 -00025 000002 ##0000 0000 0000 1000 1000 1000 0000 %0990 m01 %N6 8 0 \$												
006349	-00000	-00079	0533	0533	0533	0666	0666	0666	0000	%1016	k18	\$	%z009728 000000 -00004 ##1000 1000 1000 0000 0000 0000 0000 %0998 m02 %W6 8 0 \$												
006817	000000	-00057	0600	0600	0600	0600	0399	0399	0000	%1017	k19	\$													
007542	-00004	-00066	0666	0666	0666	0666	0333	0333	0000	%1018	k20	\$	%z001216 -00020 000009 ##0000 0000 0000 0000 1000 1000 0000 %0999 n01 %N7 9 0 \$												
007812	000014	-00021	0733	0733	0733	0733	0266	0266	0266	%1019	k21	\$	%z009721 000004 -00003 ##1000 1000 1000 0000 0000 0000 0000 %1007 n02 %W7 9 0 \$												
008254	000019	-00001	0800	0800	0800	0800	0199	0199	0199	%1020	k22	\$													
008708	000019	000005	0866	0866	0866	0866	0133	0133	0133	%1021	k23	\$													
009197	000015	000003	0933	0933	0933	0066	0066	0066	0000	%1022	k24	\$													
009710	000004	-00015	1000	1000	1000	0000	0000	0000	0000	%1023	k25	\$													
001269	000000	000025	0000	0000	0000	0000	1000	1000	1000	%1024	l10	\$													
001478	000001	000009	0066	0066	0066	0933	0933	0933	0000	%1025	l11	\$													
002303	-00019	-00074	0133	0133	0133	0866	0866	0866	0000	%1026	l12	\$													
003140	-00013	-00098	0200	0200	0200	0800	0800	0800	0000	%1027	l13	\$													
004043	-00007	-00089	0266	0266	0266	0733	0733	0733	0000	%1028	l14	\$													
004594	-00002	-00081	0333	0333	0333	0666	0666	0666	0000	%1029	l15	\$													
005175	-00003	-00088	0400	0400	0400	0600	0600	0600	0000	%1030	l16	\$													
005682	000004	-00087	0466	0466	0466	0533	0533	0533	0000	%1031	l17	\$													
006317	000004	-00090	0533	0533	0533	0666	0666	0666	0000	%1032	l18	\$													
006796	000009	-00069	0600	0600	0600	0399	0399	0399	0000	%1033	l19	\$													
007256	000014	-00053	0666	0666	0666	0666	0333	0333	0000	%1034	l20	\$													
007777	000019	-00029	0733	0733	0733	0266	0266	0266	0000	%1035	l21	\$													