

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE15/GE15L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.02; nx=1.00

TUB registration: 20091101-GE15/GE15L0NA.TXT /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

[illegible]

TUB-test chart GE15; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w *setgray*
output: no change compared to input

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-GE15/GE15L0NA.TXT /.PS
 application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

009737	-00093	000197	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009161	-00676	-00567	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008586	-01087	-01264	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
007966	-01269	-01924	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
007393	-01443	-02497	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
006916	-01691	-02978	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006226	-01774	-03535	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
005524	-02236	-03992	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005058	-02282	-04429	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
009239	000104	001269	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
008891	-00066	000188	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
008420	-00649	-00866	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
007754	-00869	-01497	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
007188	-01275	-02159	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
006565	-01419	-02698	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
005980	-01697	-03071	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
005343	-02024	-03552	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
004868	-02748	-04229	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
008889	000255	002142	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
008384	000231	001143	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
007923	-00049	000142	0750	0750	0750	0250	0500	0250	0000	00101	L03	\$
007360	-00493	-00989	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
006845	-00856	-01532	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
006180	-01241	-02271	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
005643	-01422	-02748	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
005082	-01765	-03240	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
004668	-02460	-04110	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
004143	000593	003030	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
007920	000465	002267	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
007533	000193	001028	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
007014	-00046	000118	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
006468	-00548	-01798	0500	0542	0625	0500	0406	0375	0000	00112	M05	\$
005874	-00975	-01729	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
005291	-01213	-02398	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
004861	-01489	-03031	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
004191	-02012	-03990	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007845	001324	003441	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
007419	000882	002730	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
006987	000536	002117	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
006493	000341	000908	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
006040	-00028	-00071	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
005553	-00634	-01077	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
004947	-01034	-01959	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
004499	-01362	-02636	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
003735	-01618	-03737	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
007312	002012	004090	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
006871	001426	003312	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
006443	001018	002731	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
005957	000699	002049	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
005574	000276	001062	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
005163	-00013	000047	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
004557	-00734	-01375	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
004239	-01011	-02210	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003443	-01527	-03357	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
006820	002689	005105	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
006459	002036	003933	0875	0406	0500	0125	0593	0750	0000	00136	P02	\$
005917	001613	003251	0750	0375	0250	0250	0625	0750	0000	00137	P03	\$
005426	000620	002738	0625	0343	0250	0375	0656	0750	0000	00138	P04	\$
004907	000879	002039	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
004540	000421	001180	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
004008	-00044	-00037	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
003710	-00809	-01589	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
003160	-01539	-02856	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
002663	003419	005948	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
005968	002873	005055	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
005346	002496	004372	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
004764	002127	003942	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
004431	001484	003092	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
003996	001054	002357	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
003579	000062	001533	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
002521	000626	000039	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
002786	-01344	-02292	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
005909	004267	006185	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
005526	003788	005737	0750	0218	0000	0125	0781	1000	0000	00154	R02	\$
004820	003613	005012	0875	0187	0000	0250	0812	1000	0000	00155	R03	\$
003900	003179	003965	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
003395	002750	003209	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
002977	002353	002545	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
002483	001919	001757	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
002203	001248	000965	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
001394	000051	000123	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009724	-00092	000185	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
008886	-000238	-00620	0800	0875	1000	0093	0125	0000	0000	00406	J11	\$
008099	000656	-01183	0812	0750	1000	0187	0250	0000	0000	00407	J12	\$
007064	-001292	-01773	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
006082	-001784	-02371	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
005040	-002451	-02894	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
004085	-003220	-03259	0437	0250	1000	0562	0750	0000	0000	00411	J16	\$
003520	-003729	-03408	0343	0250	1000	0875	0875	0000	0000	00412	J17	\$
002976	-004125	-03417	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
001955	-007448	-001598	0000	0875	0031	0000	0125	0000	0000	00414	K10	\$
000906	-00071	000193	0875	0875	0875	0125	0125	0125	0000	00415	K11	\$
008040	-000284	-00872	0781	0750	0875	0218	0250	0125	0000	00416	K12	\$
007241	-000747	-01517	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
006251	-001652	-02243	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
005131	-002318	-02900	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
004127	-003142	-03286	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
003441	-003717	-03483	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
002758	-003966	-03449	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
009426												

009720	-00087	000174	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$
009902	-00475	-00714	0875	0937	1000	0125	0062	0000	0000	%0163	S02 \$
008444	-00925	-01387	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$
007607	-00949	-02179	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$
006815	-00912	-02810	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$
006106	-00896	-03341	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$
005401	-01068	-03922	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$
004885	-01237	-04403	0125	0562	1000	0875	0500	0000	0000	%0169	S08 \$
004388	-01327	-04689	0000	0500	1000	1000	0500	0000	0000	%0170	S09 \$
003426	-02050	-001556	1000	0937	0875	0000	0062	0125	0000	%0171	T01 \$
008874	-00669	000196	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$
008119	-00326	-00956	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$
007498	-00408	-01618	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$
006809	-00611	-02249	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$
006093	-00810	-02785	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$
005483	-00977	-03328	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$
004920	-01146	-03959	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$
004208	-00989	-04693	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$
009169	-00284	-002566	1000	0875	0750	0000	0125	0250	0000	%0180	T01 \$
008546	-00043	-001284	0875	0812	0750	0125	0187	0250	0000	%0181	T02 \$
007916	-00008	-000148	0750	0750	0750	0250	0250	0250	0000	%0182	T03 \$
007157	-00251	-01008	0625	0687	0750	0375	0312	0250	0000	%0183	T04 \$
006567	-00377	-01261	0500	0625	0750	0500	0375	0250	0000	%0184	T05 \$
005806	-00622	-02292	0375	0562	0750	0625	0437	0250	0000	%0185	T06 \$
005246	-00769	-02782	0250	0500	0750	0750	0500	0250	0000	%0186	T07 \$
004750	-00925	-03324	0125	0437	0750	0875	0562	0250	0000	%0187	T08 \$
003916	-00792	-04456	0000	0375	0750	1000	0625	0250	0000	%0188	T09 \$
008676	-00029	-003181	1000	0812	0625	0000	0187	0375	0000	%0189	V01 \$
008205	-00143	-002440	0875	0750	0625	0125	0250	0375	0000	%0190	V02 \$
007669	-00038	-001053	0750	0687	0625	0250	0312	0375	0000	%0191	V03 \$
007009	-00038	-000095	0625	0625	0625	0375	0375	0375	0000	%0192	V04 \$
006289	-00267	-01188	0500	0562	0625	0500	0437	0375	0000	%0193	V05 \$
005545	-00459	-01921	0375	0500	0625	0625	0375	0375	0000	%0194	V06 \$
004909	-00690	-02489	0250	0437	0625	0750	0562	0375	0000	%0195	V07 \$
004502	-00750	-03027	0125	0375	0625	0875	0625	0375	0000	%0196	V08 \$
003565	-00727	-04150	0000	0312	0625	1000	0687	0375	0000	%0197	V09 \$
008413	-00301	-004215	1000	0750	0500	0000	0250	0500	0000	%0198	V01 \$
007914	-00202	-003247	0875	0687	0500	0125	0312	0500	0000	%0199	V02 \$
007354	-00150	-002451	0750	0625	0500	0250	0375	0500	0000	%0200	V03 \$
006739	-00097	-001037	0625	0562	0500	0375	0437	0500	0000	%0201	V04 \$
006039	-00031	-000081	0500	0500	0500	0500	0500	0500	0000	%0202	V05 \$
005364	-00305	-01296	0375	0437	0500	0625	0560	0500	0000	%0203	V06 \$
004722	-00522	-02128	0250	0375	0500	0750	0625	0500	0000	%0204	V07 \$
004245	-00661	-02709	0125	0312	0500	0875	0687	0500	0000	%0205	V08 \$
003243	-00576	-03862	0000	0250	0500	1000	0750	0500	0000	%0206	V09 \$
008050	-00695	-004862	1000	0687	0375	0000	0312	0625	0000	%0207	X01 \$
007538	-000520	-003999	0875	0625	0375	0125	0375	0625	0000	%0208	X02 \$
006990	-000238	-003341	0750	0562	0375	0250	0437	0625	0000	%0209	X03 \$
006371	-000124	-002439	0625	0500	0375	0375	0500	0625	0000	%0210	X04 \$
005821	-00051	-001241	0500	0437	0375	0500	0562	0625	0000	%0211	X05 \$
005086	-00013	-000044	0375	0375	0375	0625	0625	0625	0000	%0212	X06 \$
004306	-00430	-01382	0250	0312	0375	0750	0687	0625	0000	%0213	X07 \$
003886	-00644	-02231	0125	0250	0375	0875	0750	0625	0000	%0214	X08 \$
003034	-00756	-03458	0000	0187	0375	1000	0812	0625	0000	%0215	X09 \$
007693	-00136	-005550	1000	0625	0250	0000	0375	0750	0000	%0216	Y01 \$
007246	-000782	-004513	0875	0562	0500	0125	0437	0750	0000	%0217	Y02 \$
00624	-00095	-003815	0750	0500	0250	0250	0500	0750	0000	%0218	Y03 \$
005685	-00423	-003144	0625	0437	0250	0375	0500	0750	0000	%0219	Y04 \$
005378	-00220	-002274	0500	0375	0250	0500	0625	0750	0000	%0220	Y05 \$
004754	-000125	-001281	0375	0312	0250	0625	0687	0750	0000	%0221	Y06 \$
004032	-000000	-000019	0250	0250	0250	0250	0750	0750	0000	%0222	Y07 \$
003748	-00489	-01593	0125	0187	0250	0875	0812	0750	0000	%0223	Y08 \$
002474	-00734	-03021	0000	0125	0250	1000	0875	0750	0000	%0224	Y09 \$
007406	-001491	-006698	1000	0562	0125	0000	0437	0875	0000	%0225	Z01 \$
006885	-001299	-006092	0875	0500	0125	0125	0500	0875	0000	%0226	Z02 \$
006146	-00135	-005457	0750	0437	0125	0250	0562	0875	0000	%0227	Z03 \$
005408	-000962	-004510	0625	0375	0125	0375	0625	0875	0000	%0228	Z04 \$
004986	-000607	-003696	0500	0312	0125	0500	0687	0875	0000	%0229	Z05 \$
004399	-000408	-002699	0375	0250	0125	0625	0750	0875	0000	%0230	Z06 \$
003811	-000137	-001721	0250	0187	0125	0750	0812	0875	0000	%0231	Z07 \$
002449	-000028	-000059	0125	0125	0125	0875	0875	0875	0000	%0232	Z08 \$
002595	-00632	-021906	0000	0625	0125	1000	0937	0875	0000	%0233	Z09 \$
007099	-002011	-007218	1000	0500	0000	0000	0500	1000	0000	%0234	A01 \$
006628	-001803	-006748	0875	0437	0000	0125	0562	1000	0000	%0235	A02 \$
005653	-001535	-005723	0750	0375	0000	0250	0625	1000	0000	%0236	A03 \$
004625	-001400	-004628	0625	0312	0000	0375	0687	1000	0000	%0237	A04 \$
003950	-001255	-003721	0500	0250	0000	0500	0750	1000	0000	%0238	A05 \$
003382	-001169	-002927	0375	0187	0000	0625	0812	1000	0000	%0239	A06 \$
002748	-001118	-002112	0250	0125	0000	0750	0875	1000	0000	%0240	A07 \$
002353	-000657	-001185	0125	0062	0000	0875	0937	1000	0000	%0241	A08 \$
001390	-000052	-000105	0000	0000	0000	1000	1000	1000	0000	%0242	A09 \$
009724	-00098	000000	0000	0000	0000	0000	0000	0000	0000	%0206	S10 \$
008999	-000410	-000434	0937	0875	1000	0000	0062	0125	0000	%0487	S11 \$
008234	-001020	-00945	0875	0750	1000	0125	0250	0000	0000	%0488	S12 \$
007378	-001889	-01328	0812	0625	1000	0187	0375	0000	0000	%0489	S13 \$
006420	-002644	-01812	0750	0500	1000	0250	0500	0000	0000	%0490	S14 \$
005426	-003384	-02268	0687	0375	1000	0312	0625	0000	0000	%0491	S15 \$
004565	-003978	-02655	0625	0250	1000	0375	0750	0000	0000	%0492	S16 \$
003941	-00462	-02809	0562	0250	1000	0437	0875	0000	0000	%0493	S17 \$
003379	-005055	-02737	0500	0000	1000	0500	1000	0000	0000	%0494	S18 \$
009409	-00935	-001294	0937	1000	0875	0062	0000	0125	0000	%0495	T10 \$
009022	-00071	-000194	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$
008109	-000511	-00709	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$
007383	-001149	-01305	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$
006590	-001990	-01789	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$
005616	-002949	-02245	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$
004706	-003789	-02661	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$
003812	-004566	-02864	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$
003161	-004622	-02769	0437	0000	0875	0562	1000	0125	0000	%0503	T18 \$
009180	-01479	-002299	0875	1000	0750	0125	0000	0250	0000	%0504	T19 \$
008747	-00922	-001028	0812	0875	0750	0187	0125	0250	0000	%0505	U11 \$
008051	-000409	-000145	0750	0750	0750	0250	0250	0250	0000	%0506	U12 \$
007141	-000549	-00822	0687	0625	0750	0312	0375	0250	0000	%0507	U13 \$
006335	-001231	-01282	0625	0500	0750	0375	0500	0250	0000	%0508	U14 \$
005474	-001982	-01723	0562	037							

TUB registration: 20091101-GE15/GE15L0NA.TXT /.PS TUB material application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

```
input: w setgray
output: ->oly* setrgbcolor
```

TUB-test chart GE15; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

See original or copy: <http://web.me.com/klaus.richter/GE15/GE15L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=

[illegible][illegible][illegible]

See original or copy: <http://web.me.com/klaus.richter/GE15/GE15L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.02; nx=1.0

```
%BEG GE05_22_REM.TXT, Separation cmyn61*, D65, not adapted S
%100 x LAB*      %1000 x (r g b c m y o)      %nr.   pos $
%Z004491 006255 004070 0000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009150 -01493 008704 0000 0000 0000 0000 1000 1000 0000 %0396 I10 %Y1 1 $
%Z005699 -06337 003723 0000 0000 0000 0000 1000 1000 0000 %0720 I19 %L1 2 $
%Z005135 -03387 -03818 0000 0000 1000 1000 1000 0000 0000 %0008 A09 %C1 3 $
%Z003012 002596 -04185 0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004501 007086 -01103 0000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001303 000055 000104 0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009731 -00094 000179 0000 0000 1000 1000 0000 0000 0000 %0000 A01 %W1 7 $
%S
%Z004491 006255 004070 0000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009150 -01493 008704 0000 0000 0000 0000 1000 1000 0000 %0396 I10 %Y2 1 $
%Z005699 -06337 003723 0000 0000 0000 0000 1000 1000 0000 %0720 I19 %L2 2 $
%Z005135 -03387 -03818 0000 0000 1000 1000 1000 0000 0000 %0008 A09 %C2 3 $
%Z003012 002596 -04185 0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004501 007086 -01103 0000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001303 000055 000104 0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009731 -00094 000179 0000 0000 1000 1000 0000 0000 0000 %0000 A01 %W2 7 $
%S
%Z004491 006255 004070 0000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009150 -01493 008704 0000 0000 0000 0000 1000 1000 0000 %0396 I10 %Y00L 1 $
%Z005699 -06337 003723 0000 0000 0000 0000 1000 1000 0000 %0720 I19 %L00C 2 $
%Z005135 -03387 -03818 0000 0000 1000 1000 1000 0000 0000 %0008 A09 %C00V 3 $
%Z003012 002596 -04185 0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004501 007086 -01103 0000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001303 000055 000104 0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009731 -00094 000179 0000 0000 1000 1000 0000 0000 0000 %0000 A01 %W001 7 $
%S
%Z005909 004267 006185 0000 0000 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008826 -02431 008843 0000 0000 0000 0000 0250 1000 0000 %0477 R10 %Y25L 1 $
%Z005745 -05671 001517 0000 0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005058 -02802 -04429 0000 0000 0750 1000 1000 0000 0000 0000 %0089 J09 %C25V 3 $
%Z002976 004125 -03417 0000 0000 0000 0750 1000 0000 0000 0000 %0413 J18 %V25M 4 $
%Z004439 006908 000028 0000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001355 000048 000108 0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009729 -00095 000194 0000 0000 1000 1000 0000 0000 0000 %0081 J01 %W251 7 $
%S
%Z007099 002011 007218 0000 0000 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007379 -03946 006374 0000 0000 0000 0000 0500 1000 0000 %0558 a10 %Y50L 1 $
%Z005810 -04956 -00148 0000 0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004388 -01337 -04689 0000 0000 0500 1000 1000 0000 0000 0000 %0170 S09 %C50V 3 $
%Z003379 005055 -02757 0000 0000 1000 0500 1000 0000 0000 0000 %0494 S18 %V50M 4 $
%Z004380 006350 001612 0000 0000 0500 0000 1000 0500 0000 0000 %0818 S27 %M500 5 $
%Z001438 000049 000104 0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009721 -00091 000186 0000 0000 1000 1000 0000 0000 0000 %0162 S01 %W501 7 $
%S
%Z008240 000002 008020 0000 0000 0000 0000 0750 1000 0000 %0315 j01 %075Y 0 $
%Z006368 -05216 004826 0000 0000 0750 0000 1000 0000 0000 0000 %0639 j10 %Y75L 1 $
%Z005808 -04290 -01574 0000 0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003423 000467 -04629 0000 0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003908 005964 -01953 0000 0000 1000 0250 1000 0000 0000 0000 %0575 b18 %V75M 4 $
%Z004434 006102 002890 0000 0000 0250 0000 1000 0750 0000 0000 %0899 b27 %M750 5 $
%Z001359 000048 000114 0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009721 -00094 000194 0000 0000 1000 1000 0000 0000 0000 %0243 b01 %W751 7 $
%S
```

TUB registration: 20091101-GE15/GE15L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

TUB-test chart GE15; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE15/GE15L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfl=1.00; nt=0.02; nx=1.00

BEO	GEO	22	REM.	TXT.	Separation	cmyn61	D65,	adapted	\$	nrr	pos	\$
x100	Lab	A			1000	x (r	g	b	c	m	y	
009741	-00601	000005	1000	1000	1000	0000	0000	0000	0000	0000	0000	A01 \$
009074	-00721	-00758	0875	1000	1000	0125	0000	0000	0000	0000	0000	A02 \$
008507	-01108	-01480	0750	1000	1000	0250	0000	0000	0000	0000	0000	A03 \$
008034	-01447	-01965	0625	1000	1000	0375	0000	0000	0000	0000	0000	A04 \$
007515	-01762	-02464	0500	1000	1000	0500	0000	0000	0000	0000	0000	A004 \$
006956	-02093	-02855	0375	1000	1000	0625	0000	0000	0000	0000	0000	A05 \$
006158	-02704	-03292	0250	1000	1000	0750	0000	0000	0000	0000	0000	A06 \$
005559	-03194	-03599	0125	1000	1000	0875	0000	0000	0000	0000	0000	A07 \$
005135	-03375	-03957	0000	1000	1000	1000	0000	0000	0000	0000	0000	A08 \$
009152	000314	001048	1000	0875	0875	0000	0125	0125	0000	0000	0000	A09 \$
008905	000003	000035	0875	0875	0875	0125	0125	0125	0000	0000	0000	B02 \$
008547	-00848	-01060	0750	0875	0875	0250	0125	0125	0000	0000	0000	B03 \$
008159	-01347	-01616	0625	0875	0875	0375	0125	0125	0000	0000	0000	B04 \$
007608	-01777	-02107	0500	0875	0875	0500	0125	0125	0000	0000	0000	B05 \$
007026	-02098	-02671	0375	0875	0875	0625	0125	0125	0000	0000	0000	B06 \$
006418	-02408	-02935	0250	0875	0875	0750	0125	0125	0000	0000	0000	B07 \$
005756	-03139	-03328	0125	0875	0875	0875	0125	0125	0000	0000	0000	B08 \$
005177	-03447	-03636	0000	0875	0875	1000	0125	0125	0000	0000	0000	B09 \$
006651	000789	001565	1000	0500	0750	0000	0250	0250	0000	0000	0000	C01 \$
008126	000532	000854	0875	0750	0750	0125	0250	0250	0000	0000	0000	C02 \$
007865	000014	-00021	0750	0750	0750	0250	0250	0250	0000	0000	0000	C03 \$
007534	-00784	-01089	0625	0750	0750	0375	0250	0250	0000	0000	0000	C04 \$
007099	-01361	-01625	0500	0750	0750	0500	0250	0250	0000	0000	0000	C05 \$
006598	-01798	-02198	0375	0750	0750	0625	0250	0250	0000	0000	0000	C06 \$
005989	-02082	-02648	0250	0750	0750	0750	0250	0250	0000	0000	0000	C07 \$
005537	-02804	-03103	0125	0750	0750	0875	0250	0250	0000	0000	0000	C08 \$
005058	-03838	-04346	0000	0750	0750	1000	0250	0250	0000	0000	0000	C09 \$
007914	-001589	002149	1000	0625	0625	0000	0375	0375	0000	0000	0000	D01 \$
007556	000935	001724	0875	0625	0625	0125	0375	0375	0000	0000	0000	D02 \$
007292	000629	000670	0750	0625	0625	0250	0375	0375	0000	0000	0000	D03 \$
006950	000010	-00066	0625	0625	0625	0375	0375	0375	0000	0000	0000	D04 \$
006630	-00763	-01231	0500	0625	0625	0500</						

009738	000003	-000010	1000	1000	1000	0000	0000	0000	0000	%0324	A10	\$	009714	-00001	000005	1000	1000	1000	0000	0000	0000	0000	%0648	A19	\$
000847	000129	-000009	0875	0875	1000	0125	0125	0000	0000	%0325	A11	\$	009136	000964	-00387	1000	0875	1000	0000	0125	0000	0000	%0649	A20	\$
007884	000287	-01705	075	0750	1000	0250	0250	0000	0000	%0326	A12	\$	004843	001933	-00666	1000	0750	1000	0000	0250	0000	0000	%0650	A21	\$
006778	000700	-02401	0625	0625	1000	0375	0375	0000	0000	%0327	A13	\$	007846	002836	-00848	1000	0625	1000	0000	0375	0000	0000	%0651	A22	\$
005608	001234	-03097	050	0500	1000	0500	0500	0000	0000	%0328	A14	\$	007170	003825	-00966	1000	0500	1000	0000	0500	0000	0000	%0652	A23	\$
004649	001820	-03555	0375	0375	1000	0625	0625	0000	0000	%0329	A15	\$	006499	004922	-01096	1000	0375	1000	0000	0625	0000	0000	%0653	A24	\$
003779	002311	-03986	025	0250	1000	0875	0875	0000	0000	%0330	A16	\$	005692	005736	-01280	1000	0250	1000	0000	0875	0000	0000	%0654	A25	\$
003434	002380	-04127	0125	0125	1000	0875	0875	0000	0000	%0331	A17	\$	004685	006939	-01216	1000	0125	1000	0000	0875	0000	0000	%0655	A26	\$
003012	002571	-04306	0000	0000	1000	1000	1000	0000	0000	%0332	A18	\$	004501	007088	-01237	1000	0000	1000	0000	1000	0000	0000	%0656	A27	\$
009660	-00622	001670	1000	1000	0875	0000	0000	0125	0000	%0333	B10	\$	009121	-01073	000589	0875	1000	0875	0125	0000	0125	0000	%0657	B19	\$
009040	000011	000008	0875	0875	0875	0125	0125	0125	0000	%0334	B11	\$	009004	000010	000018	0875	0875	0875	0125	0125	0125	0000	%0658	B20	\$
007961	000048	-01217	075	0750	0875	0250	0250	0125	0000	%0335	B12	\$	008110	000931	-00827	0875	0750	0875	0125	0250	0125	0000	%0659	B21	\$
006976	000507	-01997	0625	0625	0875	0375	0375	0125	0000	%0336	B13	\$	007422	001995	-01050	0875	0625	0875	0125	0375	0125	0000	%0660	B22	\$
006012	000961	-02825	0500	0500	0875	0500	0500	0125	0000	%0337	B14	\$	006789	002939	-01246	0875	0500	0875	0125	0500	0125	0000	%0661	B23	\$
004859	001602	-03494	0375	0375	0875	0625	0625	0125	0000	%0338	B15	\$	006049	003963	-01454	0875	0375	0875	0125	0625	0125	0000	%0662	B24	\$
003938	002053	-03959	0250	0250	0875	0750	0750	0125	0000	%0339	B16	\$	005395	005076	-01547	0875	0250	0875	0125	0750	0125	0000	%0663	B25	\$
003463	002238	-04141	0125	0125	0875	0875	0875	0125	0000	%0340	B17	\$	004552	006293	-01673	0875	0125	0875	0125	0875	0125	0000	%0664	B26	\$
002575	002600	-04373	0000	0000	087	1000	1000	01																	

TUB-test chart GE15; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w *setgray*
output: -> *oly* setrgbcolor*

```
input: w setgray
output: ->olv* setrgbcolor
```

See original on copy: <http://web.me.com/klaus.richter/GE15/GE15L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfi=1.00; nt=0.02; nx=1

TUB registration: 20091101-GE15/GE15L0NA.TXT /.PS TUB material: code=rh4ta
application for evaluation and measurement of printer or monitor systems

See original or copy: <http://web.me.com/klaus.richter/GE15/GE15L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.02; nx=1.0

```
%BEG GE05_22_REM.TXT, Separation cmyn61*, D65, adapted $
%100 x LAB*a          %1000 x (r g b c m y o)          %nr. pos $
%Z004491 006257 003937 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009150 -01409 008530 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005699 -06314 003579 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005135 -03375 -03957 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003012 002571 -04306 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004501 007088 -01237 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001303 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009731 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004491 006257 003937 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009150 -01409 008530 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005699 -06314 003579 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005135 -03375 -03957 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003012 002571 -04306 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004501 007088 -01237 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001303 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009731 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004491 006257 003937 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009150 -01409 008530 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005699 -06314 003579 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005135 -03375 -03957 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003012 002571 -04306 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004501 007088 -01237 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001303 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009731 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005909 004297 006030 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008826 -02351 008658 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005745 -05644 001364 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005058 -02787 -04575 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z002976 004104 -03542 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004439 006912 -00111 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001355 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009729 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z007099 002058 007057 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007379 -03894 006211 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005810 -04931 -00296 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004388 -01336 -04822 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003379 005039 -02881 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004380 006350 001478 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001438 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009721 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z008240 000072 007840 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006368 -05178 004664 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005808 -04263 -01731 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003423 000454 -04763 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003908 005959 -02092 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004434 006106 002746 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001359 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009721 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE15/GE15L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.02; nx=1.0

```
%BEG GE05_22_REM.TXT, Separation cmyn61*, D65, adapted S
%100 x LAB*a      1000 x (r g b   c m y 0)      %nr. pos $
001310 -00015 000037 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002151 -00014 -00014 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003800 -00010 -00089 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
005047 000001 -00084 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
006064 000006 -00079 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
007096 000010 -00066 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
008013 000018 -00035 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
009151 000013 -00006 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009735 000002 -00012 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
001356 -00005 000045 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002142 -00006 00014 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003781 -00005 -00093 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004988 000003 -00089 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
006021 000006 -00088 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
007092 000013 -00070 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
007969 000018 -00032 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
009002 000009 000000 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009733 -00003 -00003 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
001269 -00011 000032 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002157 -00011 -00010 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003794 -00008 -00090 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004960 000001 -00088 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
006043 000004 -00081 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
007055 000008 -00062 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
007980 000014 -00021 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
009000 000008 000004 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009734 -00009 000008 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
001232 -00012 000054 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002091 -00016 -00010 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003711 -00008 -00076 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004924 -00001 -00070 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005972 000007 -00079 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006994 000011 -00051 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
007930 000010 -00022 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008988 000010 000011 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009720 000001 -00016 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
001320 000006 000020 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
001684 000002 000005 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002490 -00006 -00081 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
003348 000000 -00111 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
004215 -00005 -00101 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
004728 000010 -00089 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
005339 000011 -00088 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005837 000023 -00048 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
006381 000025 -00039 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006979 000009 -00053 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
007408 000012 -00041 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007899 000014 -00015 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
008359 000019 -00007 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
008813 000015 000000 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
009344 000009 -00006 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009724 000004 -00021 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
001329 000006 000027 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
001684 000006 000018 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
002493 -00002 -00071 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
003290 000000 -00090 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
004164 000003 -00092 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
004704 000014 -00093 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
005330 000012 -00086 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005835 000017 -00077 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
006405 000017 -00081 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006919 000017 -00068 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
007357 000021 -00048 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007860 000022 -00030 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
008258 000025 -00005 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
008759 000019 -00001 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
009316 000008 -00001 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009726 000001 -00010 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
001285 000002 000025 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
001598 000010 000012 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002480 -00003 -00070 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
003237 000000 -00095 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
004158 000008 -00093 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
004689 000010 -00075 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
005296 000013 -00095 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005850 000014 -00068 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
006399 000017 -00076 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006845 000015 -00048 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
007335 000021 -00049 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007852 000019 -00017 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
008276 000025 -00006 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE15; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w *setgray*
output: -> *olv* setrgbcolor*

TUB registration: 20091101-GE15/GE15L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

%BEG GE05_22_REM.TXT, Separation cmyn61*, D50, not adapted \$																									
%100 x LAB*																									
1000 x (r g b c m y o)																									
nrr. pos \$																									
009741	-00069	000177	1000	1000	1000	0000	0000	0000	0000	%0000	A01	\$	009738	-00067	000162	1000	1000	1000	0000	0000	0000	0000	%0024	A10	\$
009046	-00869	-00648	0875	1000	1000	0125	0000	0000	0000	%0001	A02	\$	008835	000000	-00750	0875	0875	1000	0125	0125	0000	0000	%0035	A11	\$
008458	-01342	-01415	0750	1000	1000	0250	0000	0000	0000	%0002	A03	\$	007860	000101	-01583	0750	0750	1000	0250	0250	0000	0000	%0036	A12	\$
007968	-01744	-01940	0625	1000	1000	0375	0000	0000	0000	%0003	A04	\$	006748	000476	-02293	0625	0625	1000	0375	0375	0000	0000	%0037	A13	\$
007431	-02129	-02481	0500	1000	1000	0500	0000	0000	0000	%0004	A05	\$	005573	000961	-03081	0500	0500	1000	0500	0500	0000	0000	%0038	A14	\$
006856	-02521	-02915	0375	1000	1000	0625	0000	0000	0000	%0005	A06	\$	004614	001509	-03459	0375	0375	1000	0625	0625	0000	0000	%0039	A15	\$
006032	-03229	-03418	0250	1000	1000	0750	0000	0000	0000	%0006	A07	\$	003742	001936	-03893	0250	0250	1000	0750	0750	0000	0000	%0040	A16	\$
005413	-03818	-03776	0125	1000	1000	0875	0000	0000	0000	%0007	A08	\$	003392	001972	-04043	0125	0125	1000	0875	0875	0000	0000	%0041	A17	\$
004872	-04112	-04173	0000	1000	1000	1000	0000	0000	0000	%0008	A09	\$	002966	002115	-04227	0000	0000	1000	1000	1000	0000	0000	%0042	A18	\$
009173	000423	001224	1000	0875	0875	0000	0125	0125	0000	%0009	B01	\$	009669	-00493	001810	1000	1000	0875	0000	0000	0125	0000	%0043	B10	\$
009096	-00047	000282	0875	0875	0875	0125	0125	0125	0000	%0010	B02	\$	009041	-00404	000177	0875	0875	0875	0125	0125	0125	0000	%0044	B11	\$
008512	-01827	-00967	0750	0875	0875	0250	0125	0125	0000	%0011	B03	\$	007941	-00099	-01089	0750	0750	0875	0250	0250	0125	0000	%0045	B12	\$
008101	-01590	-01575	0625	0875	0875	0375	0125	0125	0000	%0012	B04	\$	006951	000316	-01882	0625	0625	0875	0375	0375	0125	0000	%0046	B13	\$
007531	-02084	-02114	0500	0875	0875	0500	0125	0125	0000	%0013	B05	\$	005978	007077	-02727	0500	0500	0875	0500	0500	0125	0000	%0047	B14	\$
006930	-02493	-02724	0375	0875	0875	0625	0125	0125	0000	%0014	B06	\$	004821	001289	-03405	0375	0375	0875	0625	0625	0125	0000	%0048	B15	\$
006308	-02852	-03025	0250	0875	0875	0750	0125	0125	0000	%0015	B07	\$	003895	001675	-03878	0250	0250	0875	0750	0750	0125	0000	%0049	B16	\$
005619	-03693	-03487	0125	0875	0875	0875	0125	0125	0000	%0016	B08	\$	003417	001819	-04067	0125	0125	0875	0875	0875	0125	0000	%0050	B17	\$
004892	-04270	-03984	0000	0875	0875	1000	0125	0125	0000	%0017	B09	\$	002777	002124	-04298	0000	0000	0875	1000	0125	0000	%0051	B18	\$	
008688	000092	001757	1000	0750	0750	0000	0250	0250	0000	%0018	C01	\$	009606	-00742	003147	1000	1000	0750	0000	0000	0250	0000	%0052	C10	\$
008149	000643	001033	0875	0750	0750	0125	0250	0250	0000	%0019	C02	\$	009010	-00348	001570	0875	0875	0750	0125	0125	0250	0000	%0053	C11	\$
007866	-00025	001338	0750	0750	0750	0250	0250	0250	0000	%0020	C03	\$	008015	-00030	00145	0750	0750	0250	0250	0250	0000	%0054	C12	\$	
007500	-00950	-01002	0625	0750	0750	0375	0250	0250	0000	%0021	C04	\$	006950	000067	-01191	0625	0625	0750	0375	0375	0000	%0055	C13	\$	
007041	-01587	-01595	0500	0750	0750	0500	0250	0250	0000	%0022	C05	\$	005918	000395	-01856	0500	0500	0750	0500	0500	0250	0000	%0056	C14	\$
006519	-02108	-02218	0375	0750	0750	0625	0250	0250	0000	%0023	C06	\$	005015	000693	-02552	0375	0375	0750	0625	0625	0250	0000	%0057	C15	\$
005892	-02468	-02710	0250	0750	0750	0750	0250	0250	0000	%0024	C07	\$	004318	001216	-03152	0250	0250	0750	0750	0750	0250	0000	%0058	C16	\$
005412	-03301	-03233	0125	0750	0750	0875	0250	0250	0000	%0025	C08	\$	003569	001628	-03842	0125	0125	0750	0875	0875	0250	0000	%0059	C17	\$
004900	-04473	-03652	0000	0750	0750	1000	0250	0250	0000	%0026	C09	\$	002596	002048	-04425	0000	0000	0750	1000	0250	0000	%0060	C18	\$	
007975	001891	002371	1000	0625	0625	0000	0375	0375	0000	%0027	D01	\$	009426	-00625	003923	1000	1000	0625	0000	0000	0375	0000	%0061	D10	\$
007598	001173	001914	0875	0625	0625	0125	0375	0375	0000	%0028	D02	\$	008927	-00383	003014	0875	0875	0625	0125	0125	0375	0000	%0062	D11	\$
007314	000733	000849	0750	0625	0625	0250	0375	0375	0000	%0029	D03	\$	008102	-00268	001302	0750	0750	0625	0250	0250	0375	0000	%0063	D12	\$
006951	-00021	000086	0625	0625	0625	0375	0375	0375	0000	%0030	D04	\$	007065	-00022	000079	0625	0625	0625	0375	0375	0375	0000	%0064	D13	\$
006093	-00929	-01155	0500	0625	0625	0500	0375	0375	0000	%0031	D05	\$	005943	000135	-01339	0500	0500	0625	0500	0500	0375	0000	%0065	D14	\$
006091	-01580	-01643	0375	0625	0625	0625	0375	0375	0000	%0032	D06	\$	004974	000505	-02118	0375	0375	0625	0625	0625	0375	0000	%0066	D15	\$
005489	-02102	-02319	0250	0625	0625	0750	0375	0375	0000	%0033	D07	\$	004221	000969	-02752	0250	0250	0625	0750	0750	0375	0000	%0067	D16	\$
005112	-02770	-02924	0125	0625	0625	0875	0375	0375	0000	%0034	D08	\$	003393	001588	-03513	0125	0125	0625	0875	0875	0375	0000	%0068	D17	\$
004693	-04240	-03631	0000	0625	0625	1000	0375	0375	0000	%0035	D09	\$	002446	002079	-04517	0000	0000	0625	1000	0375	0000	%0069	D18	\$	
007368	002714	003174	1000	0500	0500	0000	0500	0500	0000	%0036	E01	\$	009386	-00736	004875	1000	1000	0500	0000	0000	0500	0000	%0070	E10	\$
007021	-001958	-002396	0875	0500	0500	0125	0500	0500	0000	%0037	E02	\$	008872	-00446	004131	0875	0875	0500	0125	0125	0500	0000	%0071	E11	\$
006701	-001245	-001790	0750	0500	0500	0250	0500	0500	0000	%0038	E03	\$	008126	-00499	002957	0750	0750	0500	0250	0250	0500	0000	%0072	E12	\$
006335	000745	000806	0625	0500	0500	0375	0500	0500	0000	%0039	E04	\$	007154	-00339	001208	0625	0625	0500	0375	0375	0500	0000	%0073	E13	\$
006019	-000018	-000076	0500	0500	0500	0500	0500	0500	0000	%0040	E05	\$	006072	-00012	000069	0500	0500	0500	0500	0500	0500	0000	%0074	E14	\$
005600	-00969	-01181	0375	0500	0500	0625	0500	0500	0000	%0041	E06	\$	004903	000122	-01541	0375	0375	0500	0625	0625	0500	0000	%0075	E15	\$
005152	-01678	-01945	0250	0500	0500	0750	0500	0500	0000	%0042	E07	\$	004073	000432	-02359	0250	0250	0500	0750	0750	0500	0000	%0076	E16	\$
004675	-02329	-02853	0125	0500	0500	0875	0500	0500	0000	%0043	E08	\$	003377	001067	-02967	0125	0125	0500	0875	0875	0500	0000	%0077	E17	\$
004200	-03709	-03584	0000	0500	0500</																				

TUB material: code=rh4ta

```
input: w setgray
output: -> olv* setrgbcolor
```

009721	00061	000167	1000	1000	0000	0000	0000	0000	%0162	\$01 S	009725	-00068	000199	1000	1000	0000	0000	0000	%0486	\$11 S	009720	-00063	000171	1000	1000	0000	0000	0000	0000	0000	0000	%0810	\$19 S		
009729	-00547	-00763	0875	0937	1000	0125	0062	0000	0000	%0163	\$02 S	009700	000402	-00432	0937	0875	1000	0062	0125	0000	0000	009712	000791	000173	1000	0875	0937	0000	0125	0062	0000	0000	%0811	\$20 S	
008399	-01087	-01479	0750	0875	1000	0250	0125	0000	0000	%0164	\$03 S	008239	000991	-00926	0875	0750	1000	0125	0250	0000	0000	008535	000165	000386	1000	0750	0875	0000	0250	0125	0000	0000	%0812	\$21 S	
007545	-01209	-02302	0625	0812	1000	0375	0187	0000	0000	%0165	\$04 S	007395	001860	-01277	0812	0625	1000	0187	0375	0000	0000	007907	002441	000717	1000	0625	0812	0000	0375	0187	0000	0000	%0813	\$22 S	
006738	-01259	-02960	0500	0750	1000	0500	0250	0000	0000	%0166	\$05 S	006445	002592	-01737	0750	0500	1000	0250	0500	0000	0000	007325	003233	001152	1000	0500	0750	0000	0500	0250	0000	0000	%0814	\$23 S	
006014	-01332	-03517	0375	0687	1000	0625	0312	0000	0000	%0167	\$06 S	005461	002390	-02168	0687	0375	1000	0312	0625	0000	0000	006558	004425	001560	1000	0375	0687	0000	0625	0312	0000	0000	%0815	\$24 S	
005287	-01639	-04142	0250	0652	1000	0750	0375	0000	0000	%0168	\$07 S	004607	003850	-02533	0652	0250	1000	0375	0750	0000	0000	005765	005768	001906	1000	0250	0652	0000	0750	0375	0000	0000	%0816	\$25 S	
004709	-02017	-04670	0125	0562	1000	0875	0437	0000	0000	%0169	\$08 S	003898	004453	-02650	0562	0125	1000	0437	0875	0000	0000	005088	006983	002146	1000	0125	0562	0000	0875	0437	0000	0000	%0817	\$26 S	
004236	-02161	-04988	0000	0500	1000	1000	0500	0000	0000	%0170	\$09 S	003453	004877	-02560	0500	0000	1000	0500	1000	0000	0000	004561	006576	001954	1000	0000	0500	0000	1000	0500	0000	0000	%0818	\$27 S	
000944	-00049	001537	1000	0937	0875	0000	0062	0125	0000	%0171	\$01 S	000407	-00769	000124	0937	1000	0875	0062	0000	0125	0000	009094	-00889	-00227	0875	1000	0937	0125	0000	0062	0000	0000	%0819	\$19 S	
008876	-00041	000191	0875	0875	0875	0125	0125	0125	0000	%0172	\$02 S	000924	-00043	000188	0875	0875	0875	0125	0125	0125	0000	00496	T11 S	008890	-00038	000178	0875	0875	0875	0125	0125	0125	0000	%0820	\$20 S
008095	-00417	-01004	0750	0812	0875	0250	0187	0125	0000	%0173	\$03 S	008105	-00473	-000801	0812	0750	0875	0187	0250	0125	0000	00497	T12 S	008183	-00088	000336	0875	0750	0812	0125	0250	0187	0000	%0821	\$21 S
007457	-00648	-01697	0625	0750	0875	0375	0250	0125	0000	%0174																									


See original or copy: <http://web.me.com/klaus.richter/GE15/GE15L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.02; nx=1.0

```
%BEG GE05_22_REM.TXT, Separation cmyn61*, D50, not adapted S
%100 x LAB*      %#1000 x (r g b c m y o)      %nr.    pos $
%Z004686 006601 004360 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009199 -00820 008496 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005620 -05876 003326 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z004972 -04112 -04173 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z002966 002115 -04227 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004668 007092 -00726 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001306 000070 000109 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009731 -00068 000172 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004686 006601 004360 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009199 -00820 008496 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005620 -05876 003326 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z004972 -04112 -04173 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z002966 002115 -04227 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004668 007092 -00726 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001306 000070 000109 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009731 -00068 000172 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004686 006601 004360 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009199 -00820 008496 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005620 -05876 003326 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z004972 -04112 -04173 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z002966 002115 -04227 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004668 007092 -00726 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001306 000070 000109 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009731 -00068 000172 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z006059 004808 006286 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008856 -01764 008569 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005652 -05428 001178 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004887 -03646 -04787 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003003 003829 -03310 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004618 007008 000409 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001358 000064 000112 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009730 -00067 000187 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z007204 002639 007182 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007362 -03351 006060 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005704 -04950 -00461 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004236 -02161 -04988 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003453 004877 -02560 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004561 006576 001954 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001441 000065 000108 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009722 -00064 000179 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z008311 000667 007881 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006316 -04684 004467 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005687 -04532 -01881 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003306 -00245 -04834 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004027 005891 -01671 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004618 006406 003201 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001362 000065 000117 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009721 -00066 000187 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```


TUB registration: 20091101-GE15/GE15L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta



See original or copy: <http://web.me.com/klaus-richter/GE15/GE15L0NA.TXT> /PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.02; nx=1.0



TUB registration: 20091101-GE15/GE15L0NA.TXT /PS
application for evaluation and measurement of printer or monitor systems



%BEG GE05_22_REM.TXT, Separation cmyn61*, D50, not adapted S
%100 x LAB* 1000 x (r g b c m y 0) %nrr. pos \$
001313 000043 000125 0000 0000 0000 1000 1000 1000 0000 %0972 k01 \$
002153 000027 000083 0125 0125 0125 0875 0875 0875 0000 %0973 k02 \$
003800 -000002 000029 0250 0250 0250 0750 0750 0750 0000 %0974 k03 \$
005047 -000007 000050 0375 0375 0375 0625 0625 0625 0000 %0975 k04 \$
006064 -000016 000067 0500 0500 0500 0500 0500 0500 0000 %0976 k05 \$
007097 -000025 000073 0625 0625 0625 0375 0375 0375 0000 %0977 k06 \$
008014 -000025 000135 0750 0750 0750 0250 0250 0250 0000 %0978 k07 \$
009017 -000040 000174 0875 0875 0875 0125 0125 0125 0000 %0979 k08 \$
009734 -000067 000178 1000 1000 1000 0000 0000 0000 %0980 k09 \$
001359 000055 000134 0000 0000 0000 1000 1000 1000 0000 %0981 l01 \$
002144 000035 000083 0125 0125 0125 0875 0875 0875 0000 %0982 l02 \$
003781 000081 000025 0250 0250 0250 0750 0750 0750 0000 %0983 l03 \$
004998 000005 000045 0375 0375 0375 0625 0625 0625 0000 %0984 l04 \$
006021 -000017 000057 0500 0500 0500 0500 0500 0500 0000 %0985 l05 \$
007093 000022 000089 0625 0625 0625 0375 0375 0375 0000 %0986 l06 \$
007970 -000024 000138 0750 0750 0750 0250 0250 0250 0000 %0987 l07 \$
009003 000043 000182 0875 0875 0875 0125 0125 0125 0000 %0988 l08 \$
009734 000067 000186 1000 1000 1000 0000 0000 0000 %0989 l09 \$
001272 000048 000119 0000 0000 0000 1000 1000 1000 0000 %0990 m01 \$
002158 000030 000088 0125 0125 0125 0875 0875 0875 0000 %0991 m02 \$
003795 000000 000028 0250 0250 0250 0750 0750 0750 0000 %0992 m03 \$
004961 -000007 000045 0375 0375 0375 0625 0625 0625 0000 %0993 m04 \$
006043 -000017 000065 0500 0500 0500 0500 0500 0500 0000 %0994 m05 \$
007056 -000025 000096 0625 0625 0625 0375 0375 0375 0000 %0995 m06 \$
007981 -000027 000148 0750 0750 0750 0250 0250 0250 0000 %0996 m07 \$
009002 -000043 000187 0875 0875 0875 0125 0125 0125 0000 %0997 m08 \$
009735 -000071 000199 1000 1000 1000 0000 0000 0000 %0998 m09 \$
001235 000050 000141 0000 0000 0000 1000 1000 1000 0000 %0999 n01 \$
002092 000025 000087 0125 0125 0125 0875 0875 0875 0000 %1000 n02 \$
003712 000002 000040 0250 0250 0250 0750 0750 0750 0000 %1001 n03 \$
004925 -000007 000062 0375 0375 0375 0625 0625 0625 0000 %1002 n04 \$
005972 -000014 000066 0500 0500 0500 0500 0500 0500 0000 %1003 n05 \$
006904 -000021 000097 0625 0625 0625 0375 0375 0375 0000 %1004 n06 \$
007931 -000023 000147 0750 0750 0750 0250 0250 0250 0000 %1005 n07 \$
008989 -000041 000193 0875 0875 0875 0125 0125 0125 0000 %1006 n08 \$
009721 -000063 000173 1000 1000 1000 0000 0000 0000 %1007 n09 \$
001323 000064 000109 0000 0000 0000 1000 1000 1000 0000 %1008 k10 \$
001687 000052 000098 0066 0066 0066 0933 0933 0933 0000 %1009 k11 \$
002491 000021 000020 0133 0133 0133 0866 0866 0866 0000 %1010 k12 \$
003348 000010 000002 0200 0200 0200 0800 0800 0800 0000 %1011 k13 \$
004215 000006 000023 0266 0266 0266 0733 0733 0733 0000 %1012 k14 \$
004729 000005 000041 0333 0333 0333 0666 0666 0666 0000 %1013 k15 \$
005340 -000002 000049 0400 0400 0400 0600 0600 0600 0000 %1014 k16 \$
005838 000008 000097 0466 0466 0466 0533 0533 0533 0000 %1015 k17 \$
006382 000004 000112 0533 0533 0533 0466 0466 0466 0000 %1016 k18 \$
006980 -000022 000104 0600 0600 0600 0399 0399 0399 0000 %1017 k19 \$
007409 -000024 000122 0666 0666 0666 0333 0333 0333 0000 %1018 k20 \$
007900 -000025 000154 0733 0733 0733 0266 0266 0266 0000 %1019 k21 \$
008361 -000025 000168 0800 0800 0800 0199 0199 0199 0000 %1020 k22 \$
008815 -000035 000179 0866 0866 0866 0133 0133 0133 0000 %1021 k23 \$
009345 -000049 000179 0933 0933 0933 0066 0066 0066 0000 %1022 k24 \$
009724 -000061 000169 1000 1000 1000 0000 0000 0000 %1023 k25 \$
001332 000065 000116 0000 0000 0000 1000 1000 1000 0000 %1024 l10 \$
001687 000059 000112 0066 0066 0066 0933 0933 0933 0000 %1025 l11 \$
002494 000025 000031 0133 0133 0133 0866 0866 0866 0000 %1026 l12 \$
003290 000015 000022 0200 0200 0200 0800 0800 0800 0000 %1027 l13 \$
004164 000006 000031 0266 0266 0266 0733 0733 0733 0000 %1028 l14 \$
004705 000006 000047 0333 0333 0333 0666 0666 0666 0000 %1029 l15 \$
005331 000001 000052 0400 0400 0400 0600 0600 0600 0000 %1030 l16 \$
005836 -000001 000066 0466 0466 0466 0533 0533 0533 0000 %1031 l17 \$
006405 000010 000079 0533 0533 0533 0466 0466 0466 0000 %1032 l18 \$
006919 000015 000089 0600 0600 0600 0399 0399 0399 0000 %1033 l19 \$
007358 -000014 000114 0666 0666 0666 0333 0333 0333 0000 %1034 l20 \$
007861 -000018 000139 0733 0733 0733 0266 0266 0266 0000 %1035 l21 \$
008260 -000017 000169 0800 0800 0800 0199 0199 0199 0000 %1036 l22 \$
008760 -000030 000178 0866 0866 0866 0133 0133 0133 0000 %1037 l23 \$
009317 -000048 000184 0933 0933 0933 0066 0066 0066 0000 %1038 l24 \$
009727 -000062 000179 1000 1000 1000 0000 0000 0000 %1039 l25 \$
001288 000062 000113 0000 0000 0000 1000 1000 1000 0000 %1040 m10 \$
001601 000063 000105 0066 0066 0066 0933 0933 0933 0000 %1041 m11 \$
002481 000025 000031 0133 0133 0133 0866 0866 0866 0000 %1042 m12 \$
003238 000016 000016 0200 0200 0200 0800 0800 0800 0000 %1043 m13 \$
004159 000010 000030 0266 0266 0266 0733 0733 0733 0000 %1044 m14 \$
004690 000007 000054 0333 0333 0333 0666 0666 0666 0000 %1045 m15 \$
005297 000000 000043 0400 0400 0400 0600 0600 0600 0000 %1046 m16 \$
005851 -000003 000076 0466 0466 0466 0533 0533 0533 0000 %1047 m17 \$
006400 -000009 000075 0533 0533 0533 0466 0466 0466 0000 %1048 m18 \$
006846 -000013 000108 0600 0600 0600 0399 0399 0399 0000 %1049 m19 \$
007336 -000014 000113 0666 0666 0666 0333 0333 0333 0000 %1050 m20 \$
007854 -000019 000151 0733 0733 0733 0266 0266 0266 0000 %1051 m21 \$
008278 -000017 000168 0800 0800 0800 0199 0199 0199 0000 %1052 m22 \$



%BEG GE05_22.REM.TXT, Separation cmyn61*, D50, adapted S																			
%1000 x LAB*a										%1000 x (r g b c m y θ)									
%nr. pos \$										%nr. pos \$									
009741	000000	000005	1000	1000	1000	0000	0000	0000	0000	000000	A01	\$	009738	000001	-00010	1000	1000	1000	0000
009046	-00811	-00815	0875	1000	1000	0125	0000	0000	0000	000001	A02	\$	008835	000053	-00916	0875	0875	1000	0125
008458	-01294	-01578	0750	1000	1000	0250	0000	0000	0000	000002	A03	\$	006760	000139	-01741	0750	0750	1000	0250
007968	-01704	-02099	0625	1000	1000	0375	0000	0000	0000	000003	A04	\$	007848	000496	-02443	0625	0625	1000	0375
007431	-02098	-02636	0500	1000	1000	0500	0000	0000	0000	000004	A05	\$	005573	000961	-03142	0500	0500	0500	0000
006856	-02500	-03066	0375	1000	1000	0625	0000	0000	0000	000005	A06	\$	004614	001493	-03593	0375	0375	1000	0625
006032	-03221	-03563	0250	1000	1000	0750	0000	0000	0000	000006	A07	\$	003742	001906	-04020	0250	0250	1000	0750
005413	-03821	-03917	0125	1000	1000	0875	0000	0000	0000	000007	A08	\$	003392	001935	-04168	0125	0125	1000	0875
004972	-04122	-04309	0000	1000	1000	1000	0000	0000	0000	000008	A09	\$	002966	002071	-04349	0000	1000	1000	0000
009173	000483	001056	1000	0875	0875	0000	0125	0125	0000	000009	B01	\$	009669	-00425	001638	1000	1000	0875	0000
008906	000007	000036	0875	0875	0875	0125	0125	0125	0000	000010	B02	\$	009041	000012	000009	0875	0875	0125	0125
008512	-00978	-01131	0750	0875	0875	0250	0125	0125	0000	000011	B03	\$	007941	-00060	-01248	0750	0750	0875	0250
008101	-01548	-01736	0625	0875	0875	0375	0125	0125	0000	000012	B04	\$	006951	000339	-02034	0625	0625	0875	0375
007531	-02052	-02270	0500	0875	0875	0500	0125	0125	0000	000013	B05	\$	005978	000713	-02872	0500	0500	0875	0500
006930	-02471	-02876	0375	0875	0875	0625	0125	0125	0000	000014	B06	\$	004821	001276	-03540	0375	0375	0875	0625
006308	-02840	-03172	0250	0875	0875	0750	0125	0125	0000	000015	B07	\$	003895	001647	-04007	0250	0250	0875	0750
005619	-03692	-03629	0125	0875	0875	0875	0125	0125	0000	000016	B08	\$	003417	001783	-04192	0125	0125	0875	0875
004892	-04281	-04120	0000	0875	0875	1000	0125	0125	0000	000017	B09	\$	002777	002078	-04419	0000	0000	0875	1000
008688	001043	001593	1000	0750	0750	0000	0250	0250	0000	000018	C01	\$	009606	-00675	002975	1000	1000	0750	0000
008149	000606	000872	0875	0750	0750	0125	0250	0250	0000	000019	C02	\$	009010	-00291	001403	0875	0875	0750	0125
007866	000011	-00020	0750	0750	0750	0250	0250	0250	0000	000020	C03	\$	008015	000000	-00014	0750	0750	0250	0250
007500	-00918	-01158	0625	0750	0750	0375	0250	0250	0000	000021	C04	\$	006950	000090	-01342	0625	0625	0750	0375
007041	-01562	-01748	0500	0750	0750	0500	0250	0250	0000	000022	C05	\$	005918	000400	-02000	0500	0500	0500	0250
006519	-02092	-02367	0375	0750	0750	0625	0250	0250	0000	000023	C06	\$	005015	000684	-02689	0375	0375	0750	0625
005892	-02463	-02854	0250	0750	0750	0750	0250	0250	0000	000024	C07	\$	004318	001195	-03284	0250	0250	0750	0750
005412	-03304	-03373	0125	0750	0750	0875	0250	0250	0000	000025	C08	\$	003569	001595	-03968	0125	0125	0750	0875
004900	-04484	-03789	0000	0750	0750	1000	0250	0250	0000	000026	C09	\$	002596	001999	-04544	0000	0000	0750	1000
007975	001930	002212	1000	0625	0625	0000	0375	0375	0000	000027	D01	\$	009426	-00561	003753	1000	1000	0625	0000
007598	001207	001758	0875	0625	0625	0125	0375	0375	0000	000028	D02	\$	008927	-00328	002847	0875	0875	0625	0125
007314	000762	000694	0750	0625	0625	0250	0375	0375	0000	000029	D03	\$	008102	-00227	001141	0750	0750	0625	0250
006951	000000	-00065	0625	0625	0625	0375	0375	0375	0000	000030	D04	\$	007065	000001	-00072	0625	0625	0375	0375
006593	-00912	-01304	0500	0625	0625	0500	0375	0375	0000	000031	D05	\$	005943	000141	-01483	0500	0500	0625	0500
006091	-01572	-01789	0375	0625	0625	0625	0375	0375	0000	000032	D06	\$	004974	000496	-02255	0375	0375	0625	0625
005489	-02104	-02459	0250	0625	0625	0750	0375	0375	0000	000033	D07	\$	004221	000946	-02884	0250	0250	0625	0750
005112	-02777	-03062	0125	0625	0625	0875	0375	0375	0000	000034	D08	\$	003393	001552	-03638	0125	0125	0625	0875
004693	-04254	-03766	0000	0625	0625	1000	0375	0375	0000	000035	D09	\$	002446	002027	-04635	0000	0000	0625	1000
007368	002744	003019	1000	0500	0500	0000	0500	0500	0000	000036	E01	\$	009386	-00673	004705	1000	1000	0500	0000
007021	001982	002243	0875	0500	0500	0125	0500	0500	0000	000037	E02	\$	008872	-00392	003965	0875	0875	0500	0125
006701	001263	001641	0750	0500	0500	0250	0500	0500	0000	000038	E03	\$	008126	-00457	002797	0750	0750	0500	0250
006335	000758	000659	0625	0500	0500	0375	0500	0500	0000	000039	E04	\$	007154	-00313	001055	0625	0625	0500	0375
006019	-00011	-00068	0500	0500	0500	0500	0500	0500	0000	000040	E05	\$	006072	-00004	-00075	0500	0500	0500	0500
005600	-00969	-01322	0375	0500	0500	0625	0500	0500	0000	000041	E06	\$	004903	000110	-01677	0375	0375	0500	0625
005152	-01686	-02084	0250	0500	0500	0750	0500	0500	0000	000042	E07	\$	004073	000406	-02490	0250	0250	0500	0750
004675	-02344	-02987	0125	0500	0500	0875	0500	0500	0000	000043	E08	\$	003377	001031	-03092	0125	0125	0500	0875
004200	-03732	-03716	0000	0500	0500	1000	0500	0500	0000	000044	E09	\$	002428	001420	-04567	0000	0000	0500	1000
006602	003982	003632	1000	0375	0375	0000	0625	0625	0000	000045	F01	\$	009333	-00709	005573	1000	1000	0375	0000
006315	003018	002779	0875	0375	0375	0125	0625	0625	0000	000046	F02	\$	008858	-00508	005037	0875	0875	0375	0125
006025	002183	002236	0750	0375	0375	0250	0625	0625	0000	000047	F03	\$	008107	-00509	003947	0750	0750	0375	0250
005610	001544	001559	0625	0375	0375	0375	0625	0625	0000	000048	F04	\$	007169	-00485	002742	0625	0625	0375	0375
005285	000794	000785	0500	0375	0375	0500	0625	0625	0000	000049	F05	\$	006188	-00447	001257	0500	0500	0375	0500
005090	-00010	-00086	0375	0375	0375	0625	0625	0625	0000	000050	F06	\$	005110	-00005	-00089	0375	0375	0625	0625
004624	-01181	-01603	0250	0375	0375	0750	0625	0625	0000	000051	F07	\$	003907	000125	-01863	0250	0250	0375	0750
004377	-01850	-02354	0125	0375	0375	0875	0625	0625	0000	000052	F08	\$	003630	000551	-02647	0125	0125	0375	0875
003717	-03336	-03342	0000	0375	0375	1000	0625	0625	0000	000053	F09	\$	002351	000797	-03754	0000	0000	0375	1000
006062	004864	004554	1000	0250	0250	0000	0750	0750	0000	000054	G01	\$	009213	-00617	006255				

009721	000003	-00011	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
008979	-004094	-009336	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
008399	-01043	-01647	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
007545	-01178	-02462	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
006738	-01241	-03114	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
006014	-01326	-03665	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
005287	-01644	-04283	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
004709	-02031	-04806	0125	0500	1000	0875	0500	0000	0000	%0169	S08	\$
004236	-02182	-05126	0000	0437	1000	1000	0500	0000	0000	%0170	S09	\$
003441	-00010	-001360	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
008876	000010	000019	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
008095	-00378	-01169	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
007457	-00619	-01856	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
006742	-00845	-02514	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
006017	-01147	-03078	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
005388	-01434	-03653	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
004801	-01767	-04326	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
004062	-01814	-05107	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
003195	-00096	-002367	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
008563	-000237	-001109	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
007918	000009	-00018	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
007133	-00321	-01211	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
006528	-00528	-01848	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
005746	-00886	-02551	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
005170	-01129	-03068	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
004654	-01411	-03644	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
003780	-01565	-04845	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
008718	000661	-003003	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
008238	000518	-002267	0875	0750	0875	0625	0125	0250	0375	%0190	V02	\$
007684	000218	-000888	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
007010	-00002	-00062	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
006261	-00372	-01389	0500	0750	0562	0500	0437	0375	0000	%0193	V05	\$
005501	-00671	-02155	0375	0500	0625	0625	0500	0375	0000	%0194	V06	\$
004932	-01069	-02755	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
004417	-01180	-03320	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
003439	-01449	-04517	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
008467	-00836	-004031	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
007956	-00604	-003073	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
007386	-00048	-002286	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
006754	-000271	-000884	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
006039	-00012	-00067	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
005332	-00432	-01499	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$
004667	-00787	-02368	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
004171	-01042	-02980	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
003128	-01240	-04203	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
008117	-001274	-004685	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
007593	-001026	-003830	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
007033	-000660	-003174	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
006403	-000446	-002282	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
005836	-000122	-001089	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
005487	-00014	-00095	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
004269	-00589	-01587	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
003824	-00959	-02476	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
002928	-01368	-03783	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
007772	-001758	-005378	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
007310	-001311	-004348	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
006878	-001050	-003659	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
006032	-000814	-002995	0625	0437	0250	0375	0625	0750	0000	%0219	Y04	\$
005410	-000504	-002131	0000	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
004773	-000290	-001146	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
004032	-00021	-00110	0250	0250	0250	0750	0750	0750	0000	%0222	Y07	\$
003435	-000696	-01805	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
002652	-01254	-03320	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
007499	-002144	-006502	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
006969	-001899	-005902	0875	0500	0125	0125	0500	0875	0000	%0226	Z02	\$
006221	-001667	-005279	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
005472	-001414	-004353	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
005036	-000991	-003547	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
004437	-000702	-002564	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
003834	-000325	-001592	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
002450	-00011	-00055	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
002531	-000988	-02438	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$
007204	-002664	-007025	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
006725	-002411	-006557	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
005737	-002049	-005553	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
004697	-001816	-004487	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
004012	-001598	-003603	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
003437	-001447	-002827	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
002794	-001325	-002026	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
002382	-000774	-001095	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$
001399	-000002	-000001	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009725	-000044	-000019	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
009000	-000456	-000605	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
008239	-001033	-01093	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
007395	-001889	-01436	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
006445	-002606	-01888	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
005461	-003298	-02310	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
004607	-003834	-02668	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
003708	-004426	-02710	0562	0250	1000	0437	0875	0000	0000	%0493	S17	\$
003435	-004543	-02685	0500	1000	0500	1000	0500	0000	0000	%0494	S18	\$
002407	-00710	-001063	0937	1000	0875	0062	0000	0125	0000	%0495	T10	\$
009024	-000010	-000015	0875	0875	0875	0125	0125	0125	0000	%0496	T11	\$
008105	-000512	-00967	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
007384	-001119	-01450	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
006511	-001931	-01899	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
005640	-002857	-02312	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
004743	-003646	-02688	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
003866	-004370	-02838	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
003222	-004396	-02723	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
009179	-01145	-02038	0875	1000	0750	0125	0000	0250	0000	%0504	T19	\$
008741	-000736	-00802	0812	0875	0750	0187	0125	0250	0000	%05		


```
%BEG GE05_22_REM.TXT, Separation cmyn61*, D50, adapted $
%100 x LAB*a      %1000 x (r g b c m y o)      %nr. pos $
%z004686 006586 004225 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z009199 -00760 008327 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z005620 -05876 003184 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z004972 -04122 -04309 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z002966 002071 -04349 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z004668 007077 -00861 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z001306 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009731 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%z004686 006586 004225 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z009199 -00760 008327 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z005620 -05876 003184 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z004972 -04122 -04309 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z002966 002071 -04349 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z004668 007077 -00861 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z001306 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009731 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%z004686 006586 004225 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z009199 -00760 008327 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z005620 -05876 003184 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z004972 -04122 -04309 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z002966 002071 -04349 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z004668 007077 -00861 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z001306 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009731 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%z006059 004817 006131 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z008856 -01710 008389 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005652 -05425 001028 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z004887 -03654 -04930 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003003 003790 -03437 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z004618 006995 000268 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z001358 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009730 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%z007204 002664 007025 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z007362 -03323 005901 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005704 -04949 -00606 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z004236 -02182 -05120 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z003453 004843 -02685 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004561 006560 001819 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z001441 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009722 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%z008311 000711 007706 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z006316 -04671 004308 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005687 -04528 -02034 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z003306 -00279 -04968 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z004027 005868 -01811 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004618 006393 003056 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z001362 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009721 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE15/GE15L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.02; nx=1.0

```
%BEG GE05_22_REM.TXT, Separation cmyn61*, D50, adapted S
%100 x LAB*a      1000 x (r g b   c m y 0)      %nr. pos $
001313 -00011 000037 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002153 -00016 -00014 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003800 -00023 -00089 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
005047 -00010 -00083 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
006064 -00004 -00078 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
007097 -00000 -00065 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
008014 -00033 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
009117 -00007 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009734 -00012 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
001359 00000 000045 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002144 -00008 -00014 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003781 -00018 -00092 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004998 -00009 -00087 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
006021 -00006 -00087 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
007093 -00003 -00069 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
007970 -00013 -00030 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
009003 -00009 00000 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009734 -00004 -00003 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
001272 -00007 000032 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002158 -00012 -00010 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003795 -00021 -00089 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004961 -00011 -00087 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
006043 -00006 -00080 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
007056 00000 -00061 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
007981 -00011 -00020 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
009002 -00009 00000 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009735 -00007 00000 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
001235 -00006 000054 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002092 -00018 -00010 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003712 -00019 -00076 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004925 -00012 -00069 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005972 -00004 -00077 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006904 -00009 00059 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
007931 -00014 -00020 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008989 -00011 00012 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009721 -00000 -00016 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
001323 -00009 000020 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
001687 -00002 00000 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002491 -00017 -00081 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
003348 -00015 -00110 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
004215 -00008 -00099 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
004729 -00001 -00087 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
005340 -00001 -00087 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005838 -00017 -00045 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
006382 -00020 -00037 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006980 -00001 -00052 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
007409 -00006 -00040 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007900 -00011 -00014 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
008361 -00018 -00005 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
008815 -00015 00000 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
009345 -00008 -00005 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009724 -00001 -00021 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
001332 -00009 000028 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
001687 -00008 000019 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
002494 -00013 -00071 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
003290 -00011 -00089 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
004164 -00009 -00091 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
004905 -00003 -00082 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
005331 -00000 -00084 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005836 -00006 -00076 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
006405 -00005 -00079 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006919 -00008 -00066 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
007358 -00014 -00046 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007861 -00018 -00028 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
008260 -00024 -00003 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
008760 -00019 00000 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
009317 -00008 -00001 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009727 -00000 -00010 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
001288 00006 000025 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
001601 -00011 000013 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002481 -00013 -00070 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
003238 -00012 -00095 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
004159 -00004 -00092 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
004690 -00000 -00074 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
005297 -00000 -00093 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005851 -00004 -00066 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
006400 -00006 -00074 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006846 -00009 -00047 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
007336 -00014 -00047 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007854 -00017 -00016 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
008278 -00025 -00004 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE15; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: ->olv* setrgbcolor

TUB registration: 20091101-GE15/GE15L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta