

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.01; nx=1.33

TUB registration: 20091101-GE16/GE16L0NA.TXT /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

X,BEG	GE06	22.REM.TXT,	Separation	cmyn62	D65,	not	adapted	%
%100	LAB"		1000	x (r g b	c m y	g)		%nrr.
000696	-00105	-000217	1000	1000	1000	0000	0000	0000
0009283	-00586	-002522	0875	1000	0000	0125	0000	0000
000809	-00903	-00924	0750	1000	1000	0250	0000	0000
008365	-01227	-01444	0625	1000	1000	0375	0000	0000
007816	-01555	-02041	0500	1000	1000	0500	0000	0000
007278	-01913	-02498	0375	1000	1000	0625	0000	0000
006412	-02562	-03112	0250	1000	1000	0750	0000	0000
005818	-03034	-03470	0125	1000	1000	0875	0000	0000
005429	-03138	-03864	0000	1000	1000	0000	0000	0000
009134	000245	001186	1000	0875	0875	0000	0125	0125
009363	-00090	002038	0875	0875	0875	0125	0125	0125
009114	-00672	-00550	0750	0875	0875	0250	0125	0125
008583	-01027	-01190	0625	0875	0875	0375	0125	0125
007973	-01424	-01837	0500	0875	0875	0500	0125	0125
007445	-01717	-02344	0375	0875	0875	0750	0125	0125
006783	-02243	-02900	0250	0875	0875	0875	0125	0125
006072	-02835	-03276	0125	0875	0875	0875	0125	0125
005350	-03262	-03776	0000	0875	0875	1000	0125	0125
008659	-00702	001689	1000	0750	0750	0000	0250	0250
008494	000524	001049	0875	0750	0750	0125	0250	0250
008452	-00751	-00558	0625	0750	0750	0375	0250	0250
008017	-01340	-01231	0500	0750	0750	0500	0250	0250
007416	-01751	-01868	0375	0750	0750	0625	0250	0250
006807	-02169	-02455	0250	0750	0750	0750	0250	0250
006136	-02790	-02886	0125	0750	0750	0875	0250	0250
005323	-03454	-03600	0000	0750	0750	1000	0250	0250
007915	001552	002294	1000	0625	0625	0000	0375	0375
008010	000951	002038	0875	0625	0625	0125	0375	0375
007823	000651	000907	0750	0625	0625	0250	0375	0375
007756	-00052	000156	0625	0625	0625	0375	0375	0375
007510	-00750	-00767	0500	0625	0625	0500	0375	0375
007064	-01338	-01395	0375	0625	0625	0625	0375	0375
006340	-01654	-02287	0250	0625	0625	0750	0375	0375
005801	-02444	-02732	0125	0625	0625	0875	0375	0375
005309	-03877	-03180	0000	0625	0625	1000	0375	0375
007254	002306	003082	1000	0500	0500	0000	0500	0500
007387	-001737	002534	0875	0500	0500	0125	0500	0500
007249	000987	002010	0750	0500	0500	0250	0500	0500
007069	000660	000900	0625	0500	0500	0375	0500	0500
006886	-00047	000112	0500	0500	0500	0500	0500	0500
006611	-00686	-00910	0375	0500	0500	0625	0500	0500
005888	-01361	-01786	0250	0500	0500	0750	0500	0500
005406	-01918	-02515	0125	0500	0500	0875	0500	0500
005025	-03052	-03330	0000	050				

0909685	0901054	0902123	1000	1000	1000	0000	0000	0000	0000	%0324	A10
0909039	0902185	0904200	0875	0875	1000	0125	0125	0000	0000	%0325	A11
0908141	0904966	0911877	0570	0570	1000	0250	0250	0000	0000	%0326	A12
0907038	0909052	0919463	0625	0625	1000	0375	0375	0000	0000	%0327	A13
0905818	0901508	092372	0500	0500	1000	0500	0500	0000	0000	%0328	A14
0904806	0902121	0902739	0375	0375	1000	0625	0625	0000	0000	%0329	A15
0903923	0902594	0903728	0250	0250	1000	0750	0750	0000	0000	%0330	A16
0903510	0902697	0903869	0125	0125	1000	0875	0875	0000	0000	%0331	A17
0903181	0902722	0904035	0000	0000	1000	1000	1000	0000	0000	%0332	A18
0909630	0906555	0901740	1000	1000	0875	0000	0000	0125	0000	%0333	B10
0909468	090093	0902300	0875	0875	0875	0125	0125	0125	0000	%0334	B11
0908565	0903312	0907278	0750	0750	0875	0250	0250	0125	0000	%0335	B11
0907635	0907073	0901519	0625	0625	0875	0375	0375	0125	0000	%0336	B13
0906411	0901288	0902304	0500	0500	0875	0500	0500	0125	0000	%0337	B14
0905075	0901969	0901139	0375	0375	0875	0625	0625	0125	0000	%0338	B15
0904023	0902500	0903659	0250	0250	0875	0750	0750	0125	0000	%0339	B16
0903557	0902645	0903869	0125	0125	0875	0875	0875	0125	0000	%0340	B17
0903023	0902708	0904084	0000	0000	0875	1000	1000	0125	0000	%0341	B18
0905976	0901020	0902991	1000	1000	0750	0000	0000	0250	0000	%0342	C10
0909463	0905549	0901618	0875	0875	0750	0125	0125	0250	0000	%0343	C11
0908723	0900939	0902008	0775	0750	0750	0250	0250	0250	0000	%0344	C12
0907590	0904397	0908400	0625	0625	0750	0375	0375	0250	0000	%0345	C13
0906688	0908982	091709	0500	0500	0750	0500	0500	0250	0000	%0346	C14
0905622	0901292	0902650	0375	0375	0750	0625	0625	0250	0000	%0347	C15
0904527	0902913	0903472	0250	0250	0750	0750	0750	0250	0000	%0348	C16
0907382	0902373	0903886	0125	0125	0750	0875	0875	0250	0000	%0349	C17
0902914	0902803	0904172	0000	0000	0750	1000	1000	0250	0000	%0350	C18
0909402	090996	0903726	1000	1000	0625	0000	0000	0375	0000	%0351	D10
0909321	090845	0903103	0875	0875	0625	0125	0125	0375	0000	%0352	D11
0908770	090433	0901546	0750	0750	0625	0250	0250	0375	0000	%0353	D12
0907795	09047	0901848	0625	0625	0625	0375	0375	0375	0000	%0354	D13
0906772	090491	0901331	0500	0500	0625	0500	0500	0375	0000	%0355	D14
0905658	090808	091921	0375	0375	0625	0625	0625	0375	0000	%0356	D15
0904780	0901383	0902604	0250	0250	0625	0750	0750	0375	0000	%0357	D16
0903897	0901964	0903467	0125	0125	0						

009674	-00100	000213	1000	1000	1000	0000	0000	0000	0000	00648	A19
009130	000804	-00153	1000	0875	1000	0000	0125	0000	0000	00649	A20
008541	-001709	-00395	1000	0750	1000	0000	0250	0000	0000	00650	A21
007898	002625	-00975	1000	0625	1000	0000	0037	0000	0000	00651	A22
007232	003606	-00718	1000	0500	1000	0000	0500	0000	0000	00652	A23
006537	004764	-00807	1000	0375	1000	0000	0625	0000	0000	00653	A24
005772	005761	-00936	1000	0250	1000	0000	0750	0000	0000	00654	A25
004966	006982	-00851	1000	0125	1000	0000	0875	0000	0000	00655	A26
004629	007225	-00108	1000	0000	1000	0000	1000	0000	0000	00656	A27
009316	-00906	002808	0875	1000	0875	0125	0000	0125	0000	00657	B19
009410	-00090	002225	0875	0875	0875	0125	0125	0125	0000	00658	B20
008765	001027	-00391	0875	0750	0875	0125	0250	0125	0000	00659	B21
008122	001992	-00605	0875	0625	0875	0125	0375	0125	0000	00660	B22
007378	003021	-00845	0875	0500	0875	0125	0500	0125	0000	00661	B23
006567	004223	-01068	0875	0375	0875	0125	0625	0125	0000	00662	B24
005789	005228	-01268	0875	0250	0875	0125	0750	0125	0000	00663	B25
004834	006332	-01338	0875	0125	0875	0125	0875	0125	0000	00664	B26
004417	006938	-00965	0875	0000	0875	0125	1000	0125	0000	00665	B27
008971	-01499	001669	0750	1000	0750	0250	0000	0250	0000	00666	C19
009161	-01154	001174	0750	0875	0750	0250	0125	0250	0000	00667	C20
009001	-00050	001008	0750	0750	0750	0250	0250	0250	0000	00668	C21
007969	001076	-00432	0750	0625	0750	0250	0375	0250	0000	00669	C22
007241	002094	-00649	0750	0500	0750	0250	0500	0250	0000	00670	C23
006383	003163	-00892	0750	0375	0750	0250	0625	0250	0000	00671	C24
005544	004366	-01093	0750	0250	0750	0250	0750	0250	0000	00672	C25
004709	005948	-01266	0750	0125	0750	0250	0875	0250	0000	00673	C26
004016	006307	-01168	0750	0000	0750	0250	1000	0250	0000	00674	C27
008487	-02103	001991	0625	1000	0625	0375	0000	0375	0000	00675	D19
008681	-01896	001911	0625	0875	0625	0375	0125	0375	0000	00676	D20
008376	-01163	001642	0625	0750	0625	0375	0250	0375	0000	00677	D21
007748	-00047	001044	0625	0625	0625	0375	0375	0375	0000	00678	D22
006949	001214	-00581	0625	0500	0625	0375	0500	0375	0000	00679	D23
006101	002471	-00806	0625	0375	0625	0375	0625	0375	0000	00680	D24
005127	003771	-01017	0625	0250	0625	0375	0750	0375	0000	00681	D25
004261	005224	-01102	0625	0125	0625	0375	0875	0375	0000	00682	D26
003588	005654	-00908									

TUB-test chart GE16; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

input: w *setgray*

output: no change compared to input

%BEG GE06_22_REM.TXT, Separation cmyn62*, D65, not adapted S
%100 x LAB* %1000 x (r g b c m y o)
%nr. pos \$
%z004556 006162 004041 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 \$
%z009153 -01490 008657 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 \$
%z005814 -06136 003809 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 \$
%z005429 -03138 -03864 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 \$
%z003181 002722 -04035 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 \$
%z004629 007225 -00821 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 \$
%z001574 000044 000110 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 \$
%z009685 -00103 000214 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W1 7 \$
%\$
%z004556 006162 004041 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 \$
%z009153 -01490 008657 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 \$
%z005814 -06136 003809 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 \$
%z005429 -03138 -03864 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 \$
%z003181 002722 -04035 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 \$
%z004629 007225 -00821 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 \$
%z001574 000044 000110 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 \$
%z009685 -00103 000214 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W2 7 \$
%\$
%z004556 006162 004041 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 \$
%z009153 -01490 008657 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 \$
%z005814 -06136 003809 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 \$
%z005429 -03138 -03864 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 \$
%z003181 002722 -04035 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 \$
%z004629 007225 -00821 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 \$
%z001574 000044 000110 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 \$
%z009685 -00103 000214 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W001 7 \$
%\$
%z005899 004261 006082 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 \$
%z009006 -02207 008912 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 \$
%z005871 -05484 001543 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 \$
%z005360 -02555 -04552 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 \$
%z003166 004217 -03222 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 \$
%z004478 006829 000049 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 \$
%z001682 000045 000098 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 \$
%z009691 -00106 000227 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %W251 7 \$
%\$
%z007074 002024 007186 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 \$
%z007674 -03577 006764 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 \$
%z005982 -04698 -00096 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 \$
%z004664 -01111 -04751 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 \$
%z003620 005168 -02436 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 \$
%z004430 006288 001582 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 \$
%z001786 000043 000099 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 \$
%z009708 -00101 000212 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %W501 7 \$
%\$
%z008243 000003 008035 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 \$
%z006653 -04810 005144 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 \$
%z005989 -04035 -01574 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 \$
%z003653 000749 -04553 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 \$
%z004145 006145 -01571 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 \$
%z004484 006049 002790 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 \$
%z001760 000041 000096 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 \$
%z009793 -00101 000212 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %W751 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

%BEG GE06_22_REM.TXT, Separation cmyn62*, D65, not adapted S																			
%100 x LAB*																			
1000 x (r g b c m y θ)																			
nrr. pos \$																			
0001527	000025	000100	0000	0000	0000	0000	1000	1000	0000	000972	k01	\$							
0002674	000000	000033	0125	0125	0125	0875	0875	0875	0000	000973	k02	\$							
0004526	-000021	000017	0250	0250	0250	0750	0750	0750	0000	000974	k03	\$							
0005786	-000034	000051	0375	0375	0375	0625	0625	0625	0000	000975	k04	\$							
0006965	-000046	000076	0500	0500	0500	0500	0500	0500	0000	000976	k05	\$							
0007932	-000054	000135	0625	0625	0625	0375	0375	0375	0000	000977	k06	\$							
0008725	-000065	000181	0750	0750	0750	0250	0250	0250	0000	000978	k07	\$							
0009473	-000078	000204	0875	0875	0875	0125	0125	0125	0000	000979	k08	\$							
0010725	-000101	000208	1000	1000	1000	0000	0000	0000	0000	000980	k09	\$							
001498	000028	000101	0000	0000	0000	1000	1000	1000	0000	000981	l01	\$							
002625	000006	000027	0125	0125	0125	0875	0875	0875	0000	000982	l02	\$							
004510	-000015	000014	0250	0250	0250	0750	0750	0750	0000	000983	l03	\$							
005767	-000032	000045	0375	0375	0375	0625	0625	0625	0000	000984	l04	\$							
006939	-000044	000073	0500	0500	0500	0500	0500	0500	0000	000985	l05	\$							
007931	-000054	000137	0625	0625	0625	0375	0375	0375	0000	000986	l06	\$							
008686	-000066	000184	0750	0750	0750	0250	0250	0250	0000	000987	l07	\$							
009469	-000089	000210	0875	0875	0875	0125	0125	0125	0000	000988	l08	\$							
009728	-000100	000207	1000	1000	1000	0000	0000	0000	0000	000989	l09	\$							
001362	000030	000104	0000	0000	0000	1000	1000	1000	0000	000990	m01	\$							
002552	000006	000052	0125	0125	0125	0875	0875	0875	0000	000991	m02	\$							
004468	-000014	000026	0250	0250	0250	0750	0750	0750	0000	000992	m03	\$							
005744	-000029	000064	0375	0375	0375	0625	0625	0625	0000	000993	m04	\$							
006923	-000043	000090	0500	0500	0500	0500	0500	0500	0000	000994	m05	\$							
007896	-000056	000148	0625	0625	0625	0375	0375	0375	0000	000995	m06	\$							
008701	-000066	000189	0750	0750	0750	0250	0250	0250	0000	000996	m07	\$							
009467	-000090	000216	0875	0875	0875	0125	0125	0125	0000	000997	m08	\$							
009717	-000106	000225	1000	1000	1000	0000	0000	0000	0000	000998	m09	\$							
001322	000029	000092	0000	0000	0000	1000	1000	1000	0000	000999	n01	\$							
002578	000005	000052	0125	0125	0125	0875	0875	0875	0000	001000	n02	\$							
004468	-000013	000044	0250	0250	0250	0750	0750	0750	0000	001001	n03	\$							
005737	-000029	000078	0375	0375	0375	0625	0625	0625	0000	001002	n04	\$							
006905	-000042	000107	0500	0500	0500	0500	0500	0500	0000	001003	n05	\$							
007865	-000049	000142	0625	0625	0625	0375	0375	0375	0000	001004	n06	\$							
008690	-000063	000191	0750	0750	0750	0250	0250	0250	0000	001005	n07	\$							
009472	-000091	000218	0875	0875	0875	0125	0125	0125	0000	001006	n08	\$							
009721	-000094	000199	1000	1000	1000	0000	0000	0000	0000	001007	n09	\$							
001906	000037	000082	0000	0000	0000	1000	1000	1000	0000	001008	k10	\$							
002129	000034	000065	0066	0066	0066	0933	0933	0933	0000	001009	k11	\$							
003056	000008	000003	0133	0133	0133	0866	0866	0866	0000	001010	k12	\$							
004075	-000002	-000002	0200	0200	0200	0800	0800	0800	0000	001011	k13	\$							
004799	-000010	000031	0266	0266	0266	0733	0733	0733	0000	001012	k14	\$							
005538	-000021	000033	0333	0333	0333	0666	0666	0666	0000	001013	k15	\$							
006236	-000028	000056	0400	0400	0400	0600	0600	0600	0000	001014	k16	\$							
006854	-000041	000077	0466	0466	0466	0533	0533	0533	0000	001015	k17	\$							
007298	-000051	000108	0533	0533	0533	0466	0466	0466	0000	001016	k18	\$							
007789	-000058	000143	0600	0600	0600	0399	0399	0399	0000	001017	k19	\$							
008205	-000057	000169	0666	0666	0666	0333	0333	0333	0000	001018	k20	\$							
008629	-000062	000187	0733	0733	0733	0266	0266	0266	0000	001019	k21	\$							
009031	-000072	000201	0800	0800	0800	0199	0199	0199	0000	001020	k22	\$							
009328	-000080	000202	0866	0866	0866	0133	0133	0133	0000	001021	k23	\$							
009677	-000095	000194	0933	0933	0933	0066	0066	0066	0000	001022	k24	\$							
009700	-000096	000196	1000	1000	1000	0000	0000	0000	0000	001023	k25	\$							
001867	000038	000090	0000	0000	0000	1000	1000	1000	0000	001024	l10	\$							
002054	000035	000078	0066	0066	0066	0933	0933	0933	0000	001025	l11	\$							
003015	000008	000013	0133	0133	0133	0866	0866	0866	0000	001026	l12	\$							
004071	-000004	000005	0200	0200	0200	0800	0800	0800	0000	001027	l13	\$							
004824	-000010	000034	0266	0266	0266	0733	0733	0733	0000	001028	l14	\$							
005573	-000020	000039	0333	0333	0333	0666	0666	0666	0000	001029	l15	\$							
006237	-000028	000058	0400	0400	0400	0600	0600	0600	0000	001030	l16	\$							
006824	-000035	000071	0466	0466	0466	0533	0533	0533	0000	001031	l17	\$							
007289	-000041	000090	0533	0533	0533	0466	0466	0466	0000	001032	l18	\$							
007738	-000046	000121	0600	0600	0600	0399	0399	0399	0000	001033	l19	\$							
008141	-000051	000156	0666	0666	0666	0333	0333	0333	0000	001034	l20	\$							
008574	-000057	000176	0733	0733	0733	0266	0266	0266	0000	001035	l21	\$							
008985	-000069	000196	0800	0800	0800	0199	0199	0199	0000	001036	l22	\$							
009299	-000075	000194	0866	0866	0866	0133	0133	0133	0000	001037	l23	\$							
009678	-000093	000197	0933	0933	0933	0066	0066	0066	0000	001038	l24	\$							
009716	-000098	000201	1000	1000	1000	0000	0000	0000	0000	001039	l25	\$							
001670	000040	000092	0000	0000	0000	1000	1000	1000	0000	001040	m10	\$							
001946	000033	000083	0066	0066	0066	0933	0933	0933	0000	001041	m11	\$							
002986	000012	000014	0133	0133	0133	0866	0866	0866	0000	001042	m12	\$							
004019	000000	000019	0200	0200	0200	0800	0800	0800	0000	001043	m13	\$							
004774	-000003	000040	0266	0266	0266	0733	0733	0733	0000	001044	m14	\$							
005510	-000017	000050	0333	0333	0333	0666	0666	0666	0000	001045	m15	\$							
006203	-000023	000063	0400	0400	0400	0600	0600	0600	0000	001046	m16								

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart GE16; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

TUB registration: 20091101-GE16/GE16L0NA.TXT/.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NA.TXT> / PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfl=1.00; nt=0.01; nx=1.33

[illegible]

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009704	-00001	000004	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009338	-00391	-00497	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008856	-00764	-01114	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
008291	-00960	-01775	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
007696	-01185	-02413	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
007237	-01432	-02931	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006497	-01594	-03631	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
005824	-02048	-04123	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005368	-02521	-04710	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
009258	000190	000093	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
009351	000018	-00007	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
009095	-00442	-00753	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
008474	-00627	-01478	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
007895	-00978	-02166	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
007265	-00657	-02782	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
006449	-01525	-03322	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
005767	-01838	-03834	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
005289	-02499	-04633	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
008891	000359	001822	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
008774	000291	001034	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
008613	000021	-00012	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
008290	-00397	-00829	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
007735	-00621	-01481	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
006966	-01068	-02359	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
006258	-01281	-02985	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
005600	-01656	-03425	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
005128	-02514	-04403	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
004827	000700	002696	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
008309	000585	002099	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
008065	000355	000894	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
007824	000009	-00025	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
007355	-00365	-01010	0500	0593	0625	0500	0406	0375	0000	00112	M05	\$
006707	-00740	-01781	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
005955	-01066	-02563	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
005394	-01408	-03164	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
004840	-02299	-04333	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007843	001378	003197	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
007836	001029	002733	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
007602	000585	002102	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
007269	000450	000836	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
006896	000063	-00083	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
006375	-00306	-01200	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
005612	-00812	-02139	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
005071	-01152	-02826	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
004337	-01741	-04140	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
007312	002056	003899	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
007023	001637	003391	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
007330	001054	002665	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
006746	000714	002085	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
006334	000402	001083	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
005888	000097	-00097	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
005352	-00561	-01469	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
004798	-00896	-02389	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003869	-01511	-03675	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
006787	002783	004883	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
006807	002465	004724	0875	0406	0250	0125	0593	0750	0000	00136	P02	\$
006452	001713	003309	0750	0375	0250	0250	0625	0625	0000	00137	P03	\$
006064	001273	002734	0625	0343	0250	0375	0656	0750	0000	00138	P04	\$
005654	000950	002045	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
005214	000426	001168	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
004647	000000	-00092	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
004278	-00666	-01790	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
003524	-01472	-03277	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
006333	003491	005758	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
006246	003365	005486	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
005827	002598	004198	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
005339	002316	003783	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
004901	001761	003101	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
004450	001241	002316	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
004037	000672	001540	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
002979	-00005	-00101	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
003061	-01270	-02695	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
005899	004295	005916	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
005861	004010	005840	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
005373	003766	005205	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
004570	003594	004197	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
003841	003082	003289	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
003359	002645	002637	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
002845	002093	001814	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
002391	001308	000986	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
001761	000000	-00012	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009683	000004	-00009	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
009078	000467	-00568	0800	0875	1000	0093	0125	0000	0000	00406	J11	\$
008336	000939	-01086	0812	0750	1000	0818	0250	0000	0000	00407	J12	\$
007325	001572	-01664	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
006321	002124	-02264	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
005237	002749	-02838	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
004234	003536	-03232	0347	0250	1000	0562	0750	0000	0000	00411	J16	\$
003646	004008	-03352	0343	0250	1000	0875	0875	0000	0000	00412	J17	\$
003165	004200	-03444	0250	1000	1000	0750	1000	0000	0000	00413	J18	\$
002641	-00495	001277	0068	1000	0875	0031	0000	0125	0000	00414	K01	\$
009482	000008	000004	0875	0875	0875	0125	0125	0125	0000	00415	K11	\$
007872	000542	-00822	0781	0750	0875	0218	0250	0125	0000	00416	K12	\$
007842	001089	-01425	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
006675	001858	-02076	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
005443	002501	-02801	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
004290	003310	-03302	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
003587	003963	-03399	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
002964	004081	-03378	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
009538	-00929	002533	0937	1000	0750	0062	0000	0250	0000	00423	L10	\$
0092												

See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.01; nx=1.33

See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

```
%BEG GE06_22_REM.TXT, Separation cmyn62*, D65, adapted $
%100 x LAB*a      %1000 x (r g b c m y o)      %nr. pos $
%z004556 006172 003892 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z009153 -01396 008449 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z005814 -06103 003645 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005429 -03113 -04023 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z003181 002707 -04166 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z004629 007236 -00970 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z001574 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009685 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%z004556 006172 003892 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z009153 -01396 008449 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z005814 -06103 003645 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005429 -03113 -04023 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z003181 002707 -04166 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z004629 007236 -00970 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z001574 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009685 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%z004556 006172 003892 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z009153 -01396 008449 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z005814 -06103 003645 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005429 -03113 -04023 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z003181 002707 -04166 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z004629 007236 -00970 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z001574 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009685 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%z005899 004295 005916 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z009006 -02114 008695 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005871 -05450 001377 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z005360 -02531 -04710 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003166 004200 -03344 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z004478 006836 -00093 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z001682 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009691 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%z007074 002077 007011 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z007674 -03514 006581 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005982 -04665 -00256 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z004664 -01102 -04892 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z003620 005157 -02562 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004430 006292 001445 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z001786 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009708 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%z008243 000078 007844 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z006653 -04764 004976 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005989 -04001 -01732 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z003653 000742 -04677 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z004145 006146 -01702 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004484 006057 002653 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z001760 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009793 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

%BEG GE06_22_REM.TXT, Separation cmyn62*, D65, adapted S																			
%100 x LAB*a																			
1000 x (r g b c m y θ)																			
%nr. pos \$																			
001527	-00012	-00022	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$							
002674	-00019	-00061	0125	0125	0125	0875	0875	0875	0000	%0977	k02	\$							
004526	-00010	-00106	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$							
005786	-00002	-00091	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$							
006965	-00004	-00084	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$							
007932	-00012	-00048	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$							
008725	-00014	-00006	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$							
009473	-00004	-00005	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$							
009725	-00004	-00005	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$							
010149	-00010	-00023	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$							
002625	-00014	-00067	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$							
004510	-00005	-00109	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$							
005767	-00000	-00097	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$							
006939	-00005	-00087	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$							
007931	-00012	-00038	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$							
008686	-00013	-00002	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$							
009469	-00003	-00011	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$							
009728	-00002	-00004	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$							
010136	-00010	-00028	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$							
002552	-00015	-00041	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$							
004468	-00004	-00096	0250	0250	0250	0750	0750	0750	0000	%0992	m03	\$							
005744	-00001	-00078	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$							
006923	-00006	-00069	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$							
007896	-00009	-00026	0625	0625	0625	0375	0375	0375	0000	%0995	m06	\$							
008701	-00013	-00002	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$							
009467	-00001	-00001	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$							
009717	-00009	-00023	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$							
010132	-00013	-00017	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$							
002578	-00015	-00041	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$							
004468	-00003	-00078	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$							
005737	-00001	-00063	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$							
006906	-00007	-00072	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$							
007865	-00015	-00032	0625	0625	0625	0375	0375	0375	0000	%1004	n06	\$							
008690	-00015	-00009	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$							
009472	-00001	-00019	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$							
009721	-00001	-00003	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$							
010196	-00005	-00002	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$							
002129	-00005	-00021	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$							
003056	-00005	-00098	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$							
004075	-00001	-00119	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$							
004799	-00004	-00096	0266	0266	0266	0733	0733	0733	0000	%1012	k14	\$							
005538	-00006	-00105	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$							
006236	-00010	-00093	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$							
006854	-00007	-00081	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$							
007298	-00005	-00057	0533	0533	0533	0466	0466	0466	0000	%1016	k18	\$							
007789	-00006	-00029	0600	0600	0600	0399	0399	0399	0000	%1017	k19	\$							
008205	-00013	-00010	0666	0666	0666	0333	0333	0333	0000	%1018	k20	\$							
008629	-00016	-00001	0733	0733	0733	0266	0266	0266	0000	%1019	k21	\$							
009031	-00012	-00009	0800	0800	0800	0199	0199	0199	0000	%1020	k22	\$							
009328	-00009	-00005	0866	0866	0866	0133	0133	0133	0000	%1021	k23	\$							
009677	-00000	-00007	0933	0933	0933	0066	0066	0066	0000	%1022	k24	\$							
009700	-00000	-00005	1000	1000	1000	0000	0000	0000	0000	%1023	k25	\$							
010186	-00005	-00006	0000	0000	0000	1000	1000	1000	0000	%1024	l10	\$							
002054	-00005	-00008	0066	0066	0066	0933	0933	0933	0000	%1025	l11	\$							
003015	-00005	-00087	0133	0133	0133	0866	0866	0866	0000	%1026	l12	\$							
004071	-00001	-00111	0200	0200	0200	0800	0800	0800	0000	%1027	l13	\$							
004824	-00005	-00094	0266	0266	0266	0733	0733	0733	0000	%1028	l14	\$							
005573	-00007	-00100	0333	0333	0333	0666	0666	0666	0000	%1029	l15	\$							
006237	-00010	-00091	0400	0400	0400	0600	0600	0600	0000	%1030	l16	\$							
006824	-00013	-00086	0466	0466	0466	0533	0533	0533	0000	%1031	l17	\$							
007289	-00015	-00075	0533	0533	0533	0466	0466	0466	0000	%1032	l18	\$							
007738	-00017	-00059	0600	0600	0600	0399	0399	0399	0000	%1033	l19	\$							
008141	-00019	-00022	0666	0666	0666	0333	0333	0333	0000	%1034	l20	\$							
008574	-00020	-00009	0733	0733	0733	0266	0266	0266	0000	%1035	l21	\$							
008985	-00014	-00004	0800	0800	0800	0199	0199	0199	0000	%1036	l22	\$							
009299	-00014	-00001	0866	0866	0866	0133	0133	0133	0000	%1037	l23	\$							
009678	-00002	-00004	0933	0933	0933	0066	0066	0066	0000	%1038	l24	\$							
009716	-00001	-00001	1000	1000	1000	0000	0000	0000	0000	%1039	l25	\$							
010167	-00003	-00011	0000	0000	0000	1000	1000	1000	0000	%1040	m10	\$							
001946	-00001	-00001	0066	0066	0066	0933	0933	0933	0000	%1041	m11	\$							
002986	-00001	-00085	0133	0133	0133	0866	0866	0866	0000	%1042	m12	\$							
004019	-00002	-00096	0200	0200	0200	0800	0800	0800	0000	%1043	m13	\$							
004774	-00011	-00087	0266	0266	0266	0733	0733	0733	0000	%1044	m14	\$							
005510	-00010	-00088	0333	0333	0333	0666	0666	0666	0000	%1045	m15	\$							
006203	-00014	-00085	0400	0400	0400	0600	0600	0600	0000	%1046	m16	\$							
006765	-00015	-00073	0466	0466	0466	0533	0533	0533	0000	%1047	m17	\$							
007271	-00016	-00063	0533	0533	0533	0466	0466	0466	0000	%1048	m18	\$							

See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

```
%BEG GE06_22_REM.TXT, Separation cmyn62*, D50, not adapted S
%100 x LAB*      %#1000 x (r g b c m y o)      %nr.    pos $
%Z004748 006516 004326 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009202 -00822 008457 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005739 -05672 003424 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005272 -03854 -04198 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003146 002277 -04054 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004805 007258 -00429 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001577 000060 000113 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009686 -00073 000207 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004748 006516 004326 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009202 -00822 008457 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005739 -05672 003424 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005272 -03854 -04198 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003146 002277 -04054 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004805 007258 -00429 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001577 000060 000113 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009686 -00073 000207 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004748 006516 004326 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009202 -00822 008457 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005739 -05672 003424 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005272 -03854 -04198 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003146 002277 -04054 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004805 007258 -00429 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001577 000060 000113 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009686 -00073 000207 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z006049 004797 006191 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z009042 -01544 008666 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005782 -05243 001216 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005193 -03409 -04894 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003202 003956 -03098 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004655 006935 000425 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001685 000059 000101 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009692 -00074 000220 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z007180 002647 007157 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007667 -02977 006474 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005882 -04684 -00392 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004517 -01929 -05031 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003705 005035 -02219 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004609 006518 001920 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001789 000058 000103 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009709 -00071 000205 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z008314 000664 007902 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006611 -04272 004811 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005873 -04270 -01864 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003550 000075 -04724 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004276 006117 -01267 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004666 006356 003098 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001762 000055 000100 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009704 -00071 000204 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

%BEG GE06_22_REM.TXT, Separation cmyn62*, D50, not adapted S																			
%100 x LAB*										1000 x (r g b c m y θ) %nrr. pos \$									
0001529	0000039	000103	0000	0000	0000	0000	1000	1000	0000	000972	k01	\$							
0002675	0000005	000035	0125	0125	0125	0125	0875	0875	0875	000000	k02	\$							
0004526	-000019	000017	0250	0250	0250	0250	0750	0750	0750	000000	000974	k03	\$						
0005786	-000026	000050	0375	0375	0375	0625	0625	0625	0625	000000	000975	k04	\$						
0006965	-000036	000073	0500	0500	0500	0500	0500	0500	0500	000000	000976	k05	\$						
0007933	-000035	000132	0625	0625	0625	0625	0375	0375	0375	000000	000977	k06	\$						
0008726	-000041	000176	0750	0750	0750	0750	0250	0250	0250	000000	000978	k07	\$						
0009474	-000050	000198	0875	0875	0875	0875	0125	0125	0125	000000	000979	k08	\$						
0008727	-000072	000200	1000	1000	1000	1000	0000	0000	0000	000000	000980	k09	\$						
0001500	000043	000104	0000	0000	0000	0000	1000	1000	1000	000000	000981	l01	\$						
0002625	000010	000028	0125	0125	0125	0875	0875	0875	0875	000000	000982	l02	\$						
0004510	-000013	000014	0250	0250	0250	0750	0750	0750	0750	000000	000983	l03	\$						
0005767	-000025	000044	0375	0375	0375	0625	0625	0625	0625	000000	000984	l04	\$						
0006939	-000034	000070	0500	0500	0500	0500	0500	0500	0500	000000	000985	l05	\$						
0007932	-000035	000133	0625	0625	0625	0625	0375	0375	0375	000000	000986	l06	\$						
0008688	-000040	000180	0750	0750	0750	0750	0250	0250	0250	000000	000987	l07	\$						
0009470	-000060	000203	0875	0875	0875	0875	0125	0125	0125	000000	000988	l08	\$						
0009729	-000071	000200	1000	1000	1000	1000	0000	0000	0000	000000	000989	l09	\$						
0001365	000045	000106	0000	0000	0000	0000	1000	1000	1000	000000	000990	m01	\$						
0002553	000013	000053	0125	0125	0125	0875	0875	0875	0875	000000	000991	m02	\$						
0004468	-000010	000026	0250	0250	0250	0750	0750	0750	0750	000000	000992	m03	\$						
0005744	-000020	000063	0375	0375	0375	0625	0625	0625	0625	000000	000993	m04	\$						
0006924	-000031	000088	0500	0500	0500	0500	0500	0500	0500	000000	000994	m05	\$						
0007897	-000036	000144	0625	0625	0625	0625	0375	0375	0375	000000	000995	m06	\$						
0008703	-000040	000185	0750	0750	0750	0750	0250	0250	0250	000000	000996	m07	\$						
0009468	-000061	000209	0875	0875	0875	0875	0125	0125	0125	000000	000997	m08	\$						
0009718	-000075	000218	1000	1000	1000	1000	0000	0000	0000	000000	000998	m09	\$						
0001324	000042	000095	0000	0000	0000	0000	1000	1000	1000	000000	000999	n01	\$						
0002579	000013	000054	0125	0125	0125	0875	0875	0875	0875	000000	000999	n02	\$						
0004468	-000006	000044	0250	0250	0250	0750	0750	0750	0750	000000	000999	n03	\$						
0005737	-000018	000077	0375	0375	0375	0625	0625	0625	0625	000000	000999	n04	\$						
0006905	-000030	000135	0500	0500	0500	0500	0500	0500	0500	000000	000999	n05	\$						
0007867	-000038	000138	0625	0625	0625	0625	0375	0375	0375	000000	000999	n06	\$						
0008692	-000037	000186	0750	0750	0750	0750	0250	0250	0250	000000	000999	n07	\$						
0009473	-000061	000212	0875	0875	0875	0875	0125	0125	0125	000000	000999	n08	\$						
0009721	-000067	000192	1000	1000	1000	1000	0000	0000	0000	000000	000999	n09	\$						
0001908	000049	000085	0000	0000	0000	0000	1000	1000	1000	000000	000999	k10	\$						
0002121	000043	000068	0066	0066	0066	0066	0933	0933	0933	000000	000999	k11	\$						
0003057	000009	000004	0133	0133	0133	0866	0866	0866	0866	000000	000999	k12	\$						
0004075	-000002	-000001	0200	0200	0200	0800	0800	0800	0800	000000	000999	k13	\$						
0004799	-000006	000031	0266	0266	0266	0733	0733	0733	0733	000000	000999	k14	\$						
0005538	-000016	000033	0333	0333	0333	0666	0666	0666	0666	000000	000999	k15	\$						
0006236	-000020	000055	0400	0400	0400	0600	0600	0600	0600	000000	000999	k16	\$						
0006854	-000031	000075	0466	0466	0466	0533	0533	0533	0533	000000	000999	k17	\$						
0007298	-000036	000105	0533	0533	0533	0466	0466	0466	0466	000000	000999	k18	\$						
0007790	-000038	000140	0600	0600	0600	0600	0399	0399	0399	000000	000999	k19	\$						
0008206	-000034	000165	0666	0666	0666	0666	0333	0333	0333	000000	000999	k20	\$						
0008631	-000036	000183	0733	0733	0733	0733	0266	0266	0266	000000	000999	k21	\$						
0009032	-000044	000196	0800	0800	0800	0800	0199	0199	0199	000000	000999	k22	\$						
0009329	-000052	000197	0866	0866	0866	0866	0133	0133	0133	000000	000999	k23	\$						
0009678	-000067	000187	0933	0933	0933	0933	0066	0066	0066	000000	000999	k24	\$						
0009701	-000069	000189	1000	1000	1000	1000	0000	0000	0000	000000	000999	k25	\$						
0001869	000052	000093	0000	0000	0000	0000	1000	1000	1000	000000	000999	k26	\$						
0002058	000046	000081	0066	0066	0066	0066	0933	0933	0933	000000	000999	k27	\$						
0003015	000010	000015	0133	0133	0133	0866	0866	0866	0866	000000	000999	k28	\$						
0004071	-000003	000006	0200	0200	0200	0800	0800	0800	0800	000000	000999	k29	\$						
0004825	-000005	000034	0266	0266	0266	0733	0733	0733	0733	000000	000999	k30	\$						
0005573	-000014	000038	0333	0333	0333	0666	0666	0666	0666	000000	000999	k31	\$						
0006237	-000019	000056	0400	0400	0400	0600	0600	0600	0600	000000	000999	k32	\$						
0006825	-000025	000069	0466	0466	0466	0533	0533	0533	0533	000000	000999	k33	\$						
0007289	-000028	000087	0533	0533	0533	0466	0466	0466	0466	000000	000999	k34	\$						
0007738	-000029	000118	0600	0600	0600	0600	0399	0399	0399	000000	000999	k35	\$						
0008142	-000029	000152	0666	0666	0666	0666	0333	0333	0333	000000	000999	k36	\$						
0008575	-000033	000172	0733	0733	0733	0733	0266	0266	0266	000000	000999	k37	\$						
0008987	-000042	000191	0800	0800	0800	0800	0199	0199	0199	000000	000999	k38	\$						
0009300	-000048	000189	0866	0866	0866	0866	0133	0133	0133	000000	000999	k39	\$						
0009679	-000065	000190	0933	0933	0933	0933	0066	0066	0066	000000	000999	k40	\$						
0009717	-000070	000194	1000	1000	1000	1000	0000	0000	0000	000000	000999	k41	\$						
0001672	000053	000095	0000	0000	0000	0000	1000	1000	1000	000000	000999	m10	\$						
0001948	000045	000086	0066	0066	0066	0066	0933	0933	0933	000000	000999	m11	\$						
0002987	000015	000016	0133	0133	0133	0866	0866	0866	0866	000000	000999	m12	\$						
0004019	000003	000020	0200	0200	0200	0800	0800	0800	0800	000000	000999	m13	\$						
0004774	000002	000040	0266	0266	0266	0733	0733	0733	0733	000000	000999	m14	\$						
0005511	-000009	000049	0333	0333	0333	0666	0												

%BEG GE06_22.REM.TXT, Separation cmyn62*, D50, adapted S																			
%100 x LAB*a																			
1000 x (r g b c m y θ)																			
%nr. pos \$																			
000967	000001	000002	1000	1000	1000	0000	0000	0000	0000	000000	0000	0000	0000	0000	0000	0000	0000	0000	0000
000966	000543	000499	0875	1000	1000	0125	0000	0000	0000	000001	A01	\$							
000873	000952	001200	0750	1000	1000	0250	0000	0000	0000	000002	A02	\$							
000833	001354	001748	0625	1000	1000	0375	0000	0000	0000	000003	A03	\$							
000744	001781	002377	0500	1000	1000	0500	0000	0000	0000	000004	A04	\$							
000788	002226	002868	0375	1000	1000	0625	0000	0000	0000	000005	A05	\$							
000629	003039	003538	0250	1000	1000	0750	0000	0000	0000	000006	A06	\$							
000576	003627	003936	0125	1000	1000	0875	0000	0000	0000	000007	A07	\$							
000527	003853	004355	0000	1000	1000	1000	0000	0000	0000	000008	A08	\$							
000915	000497	000989	1000	0875	0875	0000	0125	0125	0000	000009	B01	\$							
000964	000010	000028	0875	0875	0875	0125	0125	0125	0000	000010	B02	\$							
000990	000670	000805	0750	0875	0875	0250	0125	0125	0000	000011	B03	\$							
000848	001113	001478	0625	0875	0875	0375	0125	0125	0000	000012	B04	\$							
000798	001612	002161	0500	0875	0875	0500	0125	0125	0000	000013	B05	\$							
000736	002026	002700	0375	0875	0875	0625	0125	0125	0000	000014	B06	\$							
000676	002615	003299	0250	0875	0875	0750	0125	0125	0000	000015	B07	\$							
000590	003060	003723	0125	0875	0875	0875	0125	0125	0000	000016	B08	\$							
000513	003967	004270	0000	0875	0875	1000	0125	0125	0000	000017	B09	\$							
000895	001029	001517	1000	0750	0750	0000	0250	0250	0000	000018	C01	\$							
000858	000761	000872	0875	0750	0750	0125	0250	0250	0000	000019	C02	\$							
000854	000019	000003	0750	0750	0750	0250	0250	0250	0000	000020	C03	\$							
000846	000759	000811	0625	0750	0750	0375	0250	0250	0000	000021	C04	\$							
000796	001434	001537	0500	0750	0750	0500	0250	0250	0000	000022	C05	\$							
000734	001949	002210	0375	0750	0750	0625	0250	0250	0000	000023	C06	\$							
000671	002487	002835	0250	0750	0750	0750	0250	0250	0000	000024	C07	\$							
000616	003227	003314	0125	0750	0750	0875	0250	0250	0000	000025	C08	\$							
000516	004129	004096	0000	0750	0750	1000	0250	0250	0000	000026	C09	\$							
000795	001931	002166	1000	0625	0625	0000	0375	0375	0000	000027	D01	\$							
000805	001313	001884	0875	0625	0625	0125	0375	0375	0000	000028	D02	\$							
000789	000863	000744	0750	0625	0625	0250	0375	0375	0000	000029	D03	\$							
000757	000018	000031	0625	0625	0625	0375	0375	0375	0000	000030	D04	\$							
000740	000808	001014	0500	0625	0625	0500	0375	0375	0000	000031	D05	\$							
000709	001473	001693	0375	0625	0625	0625	0375	0375	0000	000032	D06	\$							
000625	001958	002621	0250	0625	0625	0750	0375	0375	0000	000033	D07	\$							
000591	002862	003128	0125	0625	0625	0875	0375	0375	0000	000034	D08	\$							
000517	004482	003678	0000	0625	0625	1000	0375	0375	0000	000035	D09	\$							
000739	002781	002992	1000	0500	0500	0000	0500	0500	0000	000036	E01	\$							
000745	002157	002420	0875	0500	0500	0125	0500	0500	0000	000037	E02	\$							
000725	001329	001867	0750	0500	0500	0250	0500	0500	0000	000038	E03	\$							
000705	000857	000748	0625	0500	0500	0375	0500	0500	0000	000039	E04	\$							
000687	000805	000655	0500	0500	0500	0500	0500	0500	0000	000040	E05	\$							
000658	000761	001149	0375	0500	0500	0625	0500	0500	0000	000041	E06	\$							
000584	001577	002085	0250	0500	0500	0750	0500	0500	0000	000042	E07	\$							
000532	002348	002828	0125	0500	0500	0875	0500	0500	0000	000043	E08	\$							
000490	004089	003777	0000	0500	0500	1000	0500	0500	0000	000044	E09	\$							
000587	004012	003603	1000	0375	0375	0000	0625	0625	0000	000045	F01	\$							
000676	003349	003120	0875	0375	0375	0125	0625	0625	0000	000046	F02	\$							
000655	002313	002269	0750	0375	0375	0250	0625	0625	0000	000047	F03	\$							
000632	001594	001732	0625	0375	0375	0375	0625	0625	0000	000048	F04	\$							
000601	000850	000908	0500	0375	0375	0500	0625	0625	0000	000049	F05	\$							
000581	000906	001012	0375	0375	0375	0625	0625	0625	0000	000050	F06	\$							
000548	000948	001455	0250	0375	0375	0750	0625	0625	0000	000051	F07	\$							
000487	001836	002349	0125	0375	0375	0875	0625	0625	0000	000052	F08	\$							
000438	003395	003672	0000	0375	0375	1000	0625	0625	0000	000053	F09	\$							
000610	004959	004548	1000	0250	0250	0000	0750	0750	0000	000054	G01	\$							
000608	004657	004089	0875	0250	0250	0125	0750	0750	0000	000055	G02	\$							
000574	003547	002917	0750	0250	0250	0250	0750	0750	0000	000056	G03	\$							
000545	002763	002434	0625	0250	0250	0375	0750	0750	0000	000057	G04	\$							
000513	001883	001842	0500	0250	0250	0500	0750	0750	0000	000058	G05	\$							
000481	001111	000974	0375	0250	0250	0625	0750	0750	0000	000059	G06	\$							
000454	000743	000908	0250	0250	0250	0750	0750	0750	0000	000060	G07	\$							
000433	001248	001838	0125	0250	0250	0875	0750	0750	0000	000061	G08	\$							
000364	002879	003315	0000	0250	0250	1000	0750	0750	0000	000062	G09	\$							
000529	006395	004938	1000	0125	0125	0000	0875	0875	0000	000063	H01	\$							
000599	006213	004725	0875	0125	0125	0125	0875	0875	0000	000064	H02	\$							
000513	004695	003756	0750	0125	0125	0250	0875	0875	0000	000065	H03	\$							
000414	004161	003163	0625	0125	0125	0375	0875	0875	0000	000066	H04	\$							
000412	003511	002898	0500	0125	0125	0500	0875	0875	0000	000067	H05	\$							
000395	002443	002012	0375	0125	0125	0625	0875	0875	0000	000068	H06	\$							
000371	001435	001275	0250	0125	0125	0750	0875	0875	0000	000069	H07	\$							
000298	000022	000095	0125	0125	0125	0875	0875	0875	0000	000070	H08	\$							
000319	002221	002608	0000	0125	0125	1000	0875	0875	0000	000071	H09	\$							
000478	006507	004175	1000	0000	0000	0000	1000	1000	0000	000072	T01	\$							
000454	006135	003862	0875	0000	0000	0125	1000	1000	0000	000073	T02	\$							
000418	005617	003181	0750	0000	0000	0250	1000	1000	0000	000074	T03	\$							
000365	005066	002889	0625	0000	0000	0375	1000	1000	0000	000075	T								

See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

TUB registration: 20091101-GE16/GE16L0NA.TXT / PS TUB material: code=rh4ta
application for evaluation and measurement of printer or monitor systems

097035	006000	006004	1090	1000	1000	0000	0000	0000	0000	#0081	J01 \$
097203	-0451-	-0528	0875	0968	1000	0125	0031	0000	0000	#0082	J02 \$
008822	-08999	-01182	0750	0937	1000	0250	0662	0000	0000	#0083	J03 \$
082840	-01179	-01874	0625	0906	1000	0375	0093	0000	0000	#0084	J04 \$
076727	-01496	-02548	0590	0875	1000	0500	0125	0000	0000	#0085	J05 \$
007150	-01834	-03101	0375	0843	1000	0625	0156	0000	0000	#0086	J06 \$
006368	-02132	-03843	0250	0812	1000	0750	0187	0000	0000	#0087	J07 \$
005689	-02723	-04390	0125	0871	1000	0875	0218	0000	0000	#0088	J08 \$
005193	-03410	-05047	0000	0750	1000	1000	0250	0000	0000	#0089	J09 \$
009276	000342	000997	0000	0906	0875	0000	0093	0125	0000	#0090	K01 \$
009352	000616	-00005	0875	0875	0875	0125	0125	0125	0000	#0091	K02 \$
009075	-00529	-00793	0750	0843	0875	0250	0156	0125	0000	#0092	K03 \$
008436	-00796	-01550	0625	0812	0875	0375	0187	0125	0000	#0093	K04 \$
007835	-01245	-02282	0500	0781	0875	0500	0218	0125	0000	#0094	K05 \$
007185	-01264	-02937	0375	0750	0875	0625	0250	0125	0000	#0095	K06 \$
006360	-02093	-03517	0250	0718	0875	0750	0281	0125	0000	#0096	K07 \$
006945	-02451	-04074	0125	0687	0875	0875	0312	0125	0000	#0097	K08 \$
005916	-02606	-04390	0000	0812	0875	1000	0187	0250	0000	#0098	K09 \$
008922	006020	018131	1000	0812	0875	0000	0187	0250	0000	#0099	L01 \$
008795	000453	001043	0875	0750	0750	0125	0128	0250	0000	#0100	L02 \$
008615	000019	-00001	0750	0750	0750	0250	0250	0250	0000	#0101	L03 \$
008269	-00489	-00870	0625	0718	0750	0375	0281	0250	0000	#0102	L04 \$
007696	-00784	-01556	0500	0687	0750	0500	0312	0250	0000	#0103	L05 \$
006900	-01369	-02487	0375	0656	0750	0625	0343	0250	0000	#0104	L06 \$
006171	-01694	-03152	0250	0625	0750	0750	0375	0250	0000	#0105	L07 \$
005492	-02177	-03637	0125	0593	0750	0875	0406	0250	0000	#0106	L08 \$
004971	-03333	-04722	0000	0562	0750	1000	0437	0250	0000	#0107	L09 \$
008475	001063	002715	1000	0718	0625	0000	0281	0375	0000	#0108	M01 \$
008349	000882	002187	0875	0687	0625	0125	0312	0375	0000	#0109	M02 \$
008086	000502	000907	0750	0656	0625	0250	0343	0375	0000	#0110	M03 \$
007826	000005	-00024	0625	0625	0625	0375	0375	0375	0000	#0111	M04 \$
007331	-00476	-01053	0590	0593	0625	0500	0406	0375	0000	#0112	M05 \$
006660	-00948	-01872	0375	0562	0625	0625	0437	0375	0000	#0113	M06 \$
005883	-01403	-02760	0250	0531	0625	0750	0468	0375	0000	#0114	M07 \$
005299	-01875	-03349	0125	0500	0625	0875	0500	0375	0000	#0115	M08 \$
004690	-03031	-04633	0000	0468	0						

TUB-test chart GE16; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```



```
%BEG GE06_22_REM.TXT, Separation cmyn62*, D50, adapted $
%100 x LAB*a          %1000 x (r g b c m y o)          %nr.   pos $
%z004748 006507 004175 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z009202 -00757 008256 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z005739 -05664 003262 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005272 -03853 -04355 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z003146 002242 -04185 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z004805 007250 -00580 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z001577 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009686 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W1 7 $
%S
%z004748 006507 004175 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z009202 -00757 008256 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z005739 -05664 003262 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005272 -03853 -04355 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z003146 002242 -04185 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z004805 007250 -00580 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z001577 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009686 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W2 7 $
%S
%z004748 006507 004175 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z009202 -00757 008256 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z005739 -05664 003262 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005272 -03853 -04355 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z003146 002242 -04185 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z004805 007250 -00580 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M00 5 $
%z001577 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009686 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W001 7 $
%S
%z006049 004811 006025 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z009042 -01480 008455 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005782 -05234 001054 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z005193 -03410 -05047 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003202 003922 -03222 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z004655 006925 000280 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z001685 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009692 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %W251 7 $
%S
%z007180 002677 006984 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z007667 -02939 006295 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005882 -04675 -00548 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z004517 -01943 -05169 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z003705 005008 -02347 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004609 006505 001780 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z001789 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009709 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %W501 7 $
%S
%z008314 000713 007715 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z006611 -04250 004647 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005873 -04260 -02019 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z003550 000048 -04848 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z004276 006102 -01400 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004666 006346 002960 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z001762 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009704 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %W751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE16/GE16L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

```
%BEG GE06_22_REM.TXT, Separation cmyn62*, D50, adapted S
%100 x LAB*a      1000 x (r g b   c m y 0)      %nr. pos $
001529 -00010 000021 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002675 -00028 -00062 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
004526 -00026 -00106 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
005786 -00015 -00090 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
006965 -00007 -00083 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
007933 000006 -00038 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
008726 000013 -00005 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
009474 000004 000006 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009727 -00004 000005 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
001500 000002 000023 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002625 -00024 00068 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
004510 -00020 -00108 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
005767 -00014 -00096 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
006939 -00006 -00086 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
007932 000006 -00036 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
008688 000012 000000 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
009470 000004 000011 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009729 -00002 000004 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
001365 -00006 000027 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002553 -00021 -00042 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
004468 -00018 -00095 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
005744 -00009 -00077 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
006924 -00003 -00068 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
007897 000005 -00025 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
008703 000013 000003 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
009468 000003 000017 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009718 -00006 000022 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
001324 -00011 000016 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002579 -00021 -00042 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
004468 -00014 -00078 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
005737 -00007 -00062 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
006905 -00002 -00071 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
007867 000011 -00030 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
008692 000015 000005 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
009473 000003 000020 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009721 000001 -00003 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
001908 000005 -00001 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
002121 000002 -00021 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
003057 -00019 -00098 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
004075 -00015 -00119 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
004799 -00009 -00095 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
005538 -00008 -00104 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
006236 -00002 -00091 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
006854 -00004 -00080 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
007298 -00003 -00056 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
007790 000001 -00028 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
008206 000012 -00009 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
008631 000016 000003 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
009032 000013 000010 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
009329 000010 000006 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
009678 000000 -00007 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009701 000000 -00005 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
001869 000006 000007 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
002056 000004 -00007 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
003015 -00017 -00087 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
004071 -00016 -00110 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
004825 -00008 -00093 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
005573 -00006 000009 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
006237 -00001 -00090 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
006825 000001 -00085 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
007289 000004 -00074 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
007738 000010 -00049 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
008142 000016 -00020 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
008575 000018 -00007 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
008987 000015 000005 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
009309 000013 000000 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
009679 000002 -00004 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009717 -00001 -00001 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
001672 000005 000011 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
001948 000001 000000 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002987 -00013 -00085 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
004019 -00011 -00095 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
004774 000000 -00086 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
005511 -00002 -00087 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
006203 000003 -00084 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
006766 000004 -00071 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
007271 000008 -00062 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
007733 000011 -00038 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
008116 000016 -00016 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
008597 000018 000003 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
008988 000014 000011 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE16; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: -> olv* setrgbcolor

TUB registration: 20091101-GE16/GE16L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta