

1. $\frac{1}{2}$ 2. $(-1, 1)$ 3. $(-\infty, 0)$ 4. $(-\infty, 0)$ 5. $(-\infty, 0)$

See original or copy: <http://web.me.com/klaus.richter/GEE39/GEE39L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfi=1.00; nt=

application for evaluation and measurement of printer or monitor systems

IOB material: code=rna4ta

[illegible]

TUB-test chart GE39; Relative Device Colour System CIE
1080 spectral reflexions R → LAB* for D65 and D50

input: w *setgray*
output: no change compared to input

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaustrichter/GE39/GE39L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

001717	002411	000724	0375	0000	0000	00625	1000	1000	0000	%0243	A10	\$	002120	003272	001345	0500	0000	0000	00500	0500	1000	1000	0000	%0324	J10	\$	002591	004279	002099	0625	0000	0000	0375	1000	1000	0000	0000	%0405	S10	\$
001819	003059	-01258	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$	002215	003822	-00726	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$	002677	004700	-00966	0625	0000	0125	0375	1000	0875	0000	0000	%0406	S11	\$	
001914	003600	-02423	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$	002280	004277	-01944	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$	002729	005062	-01332	0625	0000	0250	0375	1000	0750	0000	0000	%0407	S12	\$	
001984	004201	-03406	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$	002356	004754	-02942	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$	002783	005455	-02391	0625	0000	0375	0375	1000	0625	0000	0000	%0408	S13	\$	
002059	004786	-04301	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$	002411	005274	-03871	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$	002833	005889	-03339	0625	0000	0500	0375	1000	0500	0000	0000	%0409	S14	\$	
002122	005365	-05068	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$	002492	005792	-04666	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$	002900	006352	-04172	0625	0000	0625	0375	1000	0375	0000	0000	%0410	S15	\$	
002179	005798	-05591	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$	002555	006183	-05194	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$	002944	006685	-04714	0625	0000	0750	0375	1000	0250	0000	0000	%0411	S16	\$	
002202	006004	-05838	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$	002584	006370	-05455	0500	0000	0875	0500	1000	0125	0000	%0331	J17	\$	002943	006843	-04969	0625	0000	0750	0375	1000	0125	0000	0000	%0412	S17	\$	
002212	006025	-05839	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$	002658	006382	-05461	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$	002961	006860	-04978	0625	0000	1000	0375	1000	0000	0000	0000	%0413	S18	\$	
002453	001261	001609	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$	002829	002179	-02186	0500	0125	0000	0875	1000	0000	0000	%0333	K10	\$	003305	003253	002942	0625	0125	0000	0375	0875	1000	0000	0000	%0414	T10	\$	
002608	001797	-00496	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$	002962	002629	-00012	0500	0125	0125	0500	0875	0875	0000	%0334	K11	\$	003440	003592	000614	0625	0125	0125	0375	0875	0875	0000	0000	%0415	T11	\$	
002712	002315	-01784	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$	003057	003014	-01302	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$	003518	003912	-00738	0625	0125	0250	0375	0875	0750	0000	0000	%0416	T12	\$	
002809	002878	-02844	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$	003149	003507	-02422	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$	003594	004296	-01895	0625	0125	0375	0375	0875	0625	0000	0000	%0417	T13	\$	
002881	003497	-03859	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$	003218	004053	-03470	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$	003656	004758	-02960	0625	0125	0500	0375	0875	0500	0000	0000	%0418	T14	\$	
002958	004124	-04735	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$	003306	004625	-04380	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$	003723	005263	-03923	0625	0125	0625	0375	0875	0375	0000	0000	%0419	T15	\$	
003032	004632	-05370	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$	003364	005084	-05039	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$	003770	005663	-04950	0625	0125	0750	0375	0875	0250	0000	0000	%0420	T16	\$	
003051	004902	-05693	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$	003370	005339	-05375	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$	003778	005896	-04944	0625	0125	0875	0375	0875	0125	0000	0000	%0421	T17	\$	
003053	004937	-05712	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$	003384	005371	-05394	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$	003790	005915	-04965	0625	0125	1000	0375	0875	0000	0000	0000	%0422	T18	\$	
003268	-00099	002653	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$	003611	000864	-03209	0500	0250	0000	0500	0750	1000	0000	%0342	L10	\$	004121	001990	003962	0625	0250	0000	0375	0750	1000	0000	0000	%0423	U10	\$	
003428	000337	000432	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$	003773	001212	000913	0500	0250	0125	0500	0750	0875	0000	%0343	L11	\$	004281	002223	001553	0625	0250	0125	0375	0750	0875	0000	0000	%0424	U11	\$	
003560	000794	-00964	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$	003808	001558	-00493	0500	0250	0250	0500	0750	0750	0000	%0344	L12	\$	004382	002500	000049	0625	0250	0250	0375	0750	0750	0000	0000	%0425	U12	\$	
003664	001295	-02039	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$	003877	001797	-00964	0375	0250	0375	0500	0750	0625	0000	%0345	L13	\$	004432	002500	000049	0625	0250	0250	0375	0750	0750	0000	0000	%0426	U13	\$	
003738	001906	-03125	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$	004062	002513	-00738	0500	0250	0500	0500	0750	0500	0000	%0346	L14	\$	004532	003310	-02260	0625	0250	0500	0375	0750	0500	0000	0000	%0427	U14	\$	
003816	002575	-04132	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$	004158	003127	-03781	0500	0250	0625	0500	0750	0375	0000	%0347	L15	\$	004600	003855	-03347	0625	0250	0250	0375	0750	0375	0000	0000	%0428			

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

003105	005338	002985	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003149	005632	000752	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
003181	005905	-000579	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
003224	006224	-01693	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
003260	006585	-02709	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
003299	006955	-03565	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
003340	007247	-04127	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
003339	007395	-04390	0750	0000	0875	0250	1000	0000	0000	%0493	A26	\$
003347	007416	-04418	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$
003389	004486	003807	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$
003918	004711	001400	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
003987	004948	-00031	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
004031	005261	-01235	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
004085	005629	-02359	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
004123	006052	-03358	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
004158	006393	-04047	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
004147	006621	-04428	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
004130	006668	-04467	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
004622	003335	-004772	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
004726	003478	002278	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
004803	003681	000736	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
004866	003960	-004091	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
004915	004320	-01685	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
004958	004776	-02812	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
004982	005199	-03659	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
004981	005458	-04140	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
004969	005522	-04202	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
005405	002132	005780	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
005517	002240	003219	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005582	002429	001598	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005607	002699	000327	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005667	003065	-00152	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
005718	003522	-02183	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
005740	003963	-03134	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
005730	004297	-03727	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
005726	004360	-03804	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
006198	000950	006817	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
006293	001002	004231	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
006355	001168	002570	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006401	001409	001243	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006460	001725	-00067	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
006498	002167	-01376	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
006536	002640	-02476	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
006545	002975	-03169	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
006532	003044	-03269	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
006888	-00051	007768	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
006975	-00059	005172	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
007057	000030	003514	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
007115	000201	002209	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
007166	000495	000830	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
007223	000891	-00565	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
007275	001336	-01747	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
007277	001711	-02558	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
007261	001788	-02680	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
007462	-00877	008575	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
007607	-01017	006026	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
007698	-01015	004407	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
007775	-00805	003777	0750	0750	0375	0250	0250	0500	0000	%0543	G22	\$
007851	-00680	001700	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007944	-00378	000302	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
008002	000027	-00953	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$
008007	000401	-01858	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$
008010	000472	-01996	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$
007918	-01519	009262	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$
008136	-01832	006825	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$
008268	-01908	005191	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$
008364	-01872	003898	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$
008465	-01743	002534	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$
008560	-01540	001145	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$
008659	-01206	-00172	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$
008709	-00903	-01096	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$
008715	-00854	-01234	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$
007948	-01526	009319	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$
008169	-01858	006864	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$
008290	-01944	005254	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$
008402	-01910	003935	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$
008492	-01789	002578	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$
008603	-01590	001191	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$
008701	-01265	-00121	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$
008748	-00964	-01049	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$
008759	-00917	-01190	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$
003441	005971	003469	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$
003487	006260	001152	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$
003526	006527	-00201	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$
003559	006812	-01295	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$
003600	007139	-02308	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$
003630	007465	-03135	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$
003669	007719	-03685	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$
003664	007870	-03867	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$
003670	007878	-03899	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$
004206	005199	004342	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$
004284	005420	001863	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$
004340	005658	000393	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$
004394	005936	-00798	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$
004429	006267	-01919	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$
004470	006647	-02897	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$
004503	006962	-03593	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$
004484	007177	-03995	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$
004489	007210	-04032	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$
004989	004152	005304	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$
005090	004318	002723	0875	0250	0125	0125	0750	0875	0000			

See original or copy: <http://web.me.com/klaus.richter/GE39/GE39L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

009302	000000	-00599	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$	009247	000016	-00617	1000	1000	1000	0000	0000	0000	0000	0000	%0891	b10	\$
009252	-00080	-00649	0875	1000	1000	0125	0000	0000	0000	%0730	b02	\$	009209	000091	-00666	1000	0875	1000	0000	0125	0000	0000	0000	%0892	b09	\$
008838	00897	-01152	0750	1000	1000	0250	0000	0000	0000	%0731	b03	\$	008525	001299	-01424	1000	0675	1000	0000	0250	0000	0000	0000	%0893	b21	\$
008254	-01661	-01774	0625	1000	1000	0375	0000	0000	0000	%0732	b04	\$	007774	002563	-02148	1000	0250	1000	0000	0375	0000	0000	0000	%0894	b22	\$
007689	-02184	-02290	0500	1000	1000	0500	0000	0000	0000	%0733	b05	\$	007001	003808	-02780	1000	0500	1000	0000	0500	0000	0000	0000	%0895	b23	\$
007186	-02525	-02690	0375	1000	1000	0625	0000	0000	0000	%0734	b06	\$	006717	005073	-03330	1000	0375	1000	0000	0625	0000	0000	0000	%0896	b24	\$
006636	-02762	-03065	0250	1000	1000	0750	0000	0000	0000	%0735	b07	\$	005421	006148	-03718	1000	0250	1000	0000	0750	0000	0000	0000	%0897	b25	\$
005978	-02941	-03435	0125	1000	1000	0875	0000	0000	0000	%0736	b08	\$	004561	007243	-03999	1000	0125	1000	0000	0875	0000	0000	0000	%0898	b26	\$
005251	-02870	-03732	0000	1000	1000	1000	0000	0000	0000	%0737	b09	\$	003714	007928	-03950	1000	0000	1000	0000	1000	0000	0000	0000	%0899	b27	\$
009263	000032	-00523	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$	009204	-00115	-00529	0875	1000	0875	0125	0000	0125	0000	0000	%0900	c19	\$
009215	-00056	-00569	0875	0875	0875	0125	0125	0125	0000	%0739	c02	\$	009163	-00043	-00573	0875	0875	0875	0125	0125	0125	0125	0000	%0901	c20	\$
008798	-00877	-01081	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$	008499	001146	-01332	0875	0750	0875	0125	0250	0125	0250	0000	%0902	c21	\$
008218	-01656	-01702	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$	007747	002411	-02067	0875	0625	0875	0125	0375	0125	0000	%0903	c22	\$	
007663	-02184	-02217	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$	006978	003676	-02717	0875	0500	0875	0125	0500	0125	0000	%0904	c24	\$	
007156	-02540	-02636	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$	006157	004947	-03284	0875	0375	0875	0125	0625	0125	0000	%0905	c26	\$	
006615	-02805	-03011	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$	005387	006061	-03701	0875	0250	0875	0125	0750	0125	0000	%0906	c25	\$	
005965	-02970	-03376	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$	004534	007166	-03987	0875	0125	0875	0125	0875	0125	0000	%0907	c26	\$	
005241	-02908	-03675	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$	003691	007867	-03955	0875	0000	0875	0125	1000	0125	0000	%0908	c27	\$	
008544	000951	-00482	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$	008735	-01255	-00158	0750	1000	0750	0250	0000	0250	0000	0000	%0909	d19	\$
008504	000849	-00492	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$	006892	-01157	-00222	0750	0875	0750	0250	0125	0250	0000	%0910	d20	\$	
008106	000022	-00994	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$	007303	001250	-01722	0750	0375	0750	0250	0250	0375	0250	0000	%0911	d21	\$
007598	-00870	-01573	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$	007374	001270	-01722	0750	0625	0750	0250	0375	0250	0000	%0912	d22	\$	
007103	-01552	-02057	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$	006627	002574	-02452	0750	0500	0750	0250	0500	0250	0000	%0913	d23	\$	
006687	-02026	-02467	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$	005821	003928	-03112	0750	0375	0750	0250	0625	0250	0000	%0914	d24	\$	
006208	-02429	-02825	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$	005046	005167	-03646	0750	0250	0750	0250	0750	0250	0000	%0915	d25	\$	
005638	-02721	-03188	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$	004182	006417	-04049	0750	0125	0750	0250	0875	0250	0000	%0916	d26	\$	
004986	-02795	-03458	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$	003356	007270	-04107	0750	0000	0750	0250	1000	0250	0000	%0917	d27	\$	
007753	001835	-00156	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$	008703	-02431	-00381	0625	1000	0625	0375	0000	0375	0000	%0918	e19	\$	
007712	001740	-00160	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$	008044	-02374	-00340	0625	0875	0625	0375	0125	0375	0000	%0919	e20	\$	
007360	000845	-00589	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$	007481	-01350	-00338	0625	0750	0625	0375	0250	0375	0000	%0920	e21	\$	
006865	-00153	-01153	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$	006819	-00119	-01145	0625	0625	0625	0375	0375	0375	0000	%0921	e22	\$	
006414	-00935	-01651	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$	006107	001143	-01912	0625	0500	0625	0375	0500	0375	0000	%0922	e23	\$	
006048	-01529	-02061	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$	005304	002574	-02707	0625	0375	0625	0375	0625	0375	0000	%0923	e24	\$	
005638	-02056	-02410	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$	004513	003938	-03369	0625	0250	0625	0375	0750	0375	0000	%0924	e25	\$	
005116	-02482	-02769	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$	003655	003341	-03924	0625	0125	0625	0375	0875	0375	0000	%0925	e26	\$	
004564	-02694	-03032	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$	002875	006352	-04132	0625	0000	0625	0375	1000	0375	0000	%0926	e27	\$	
006947	002695	-008273	1000	0500	0500	0000	0500	0500																		

%BEG GE29(7)_22_REM.TXT, Separation cmyn62*, D65, not adapted \$
%100 x LAB*
%#1000 x (r g b c m y 0) %nr. pos \$
%z003455 006029 003493 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008436 -00460 010064 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z004369 -06196 004029 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005222 -02845 -03739 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z001340 005229 -06400 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003694 007913 -03951 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z000823 000116 -00689 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009224 000014 -00616 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z003528 006057 003481 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008437 -00438 010001 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z004333 -06182 003905 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005251 -02870 -03732 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z001328 005239 -06402 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003714 007928 -03950 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z000812 000122 -00696 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009268 000013 -00612 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/GE39/GE39L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG GE29(7)_22.REM.TXT, Separation		cmyn62*, D65, not adapted S		LAB*		1000 x (r g b		c m y θ)		%nrr. pos \$																		
000877	000097	-00692	0000	0000	0000	1000	1000	1000	0000	0000	0000	000972	k01	\$	0009110	-00074	-00550	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$	
0001984	000171	-01382	0125	0125	0125	0875	0875	0875	0000	0000	0000	000973	k02	\$	0009241	000003	-00600	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$	
0003268	-00022	-01355	0250	0250	0250	0750	0750	0750	0000	0000	0000	000974	k03	\$	0009237	000012	-00595	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$	
0004488	-00192	-01174	0375	0375	0375	0625	0625	0625	0000	0000	0000	000975	k04	\$	0008010	000110	-00733	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$	
0005707	-00295	-01144	0500	0500	0500	0500	0500	0500	0000	0000	0000	000976	k05	\$	001316	000261	-01209	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$	
0006910	-00175	-01129	0625	0625	0625	0375	0375	0375	0000	0000	0000	000977	k06	\$	0020004	000174	-01442	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$	
0008132	-00029	-00953	0750	0750	0750	0250	0250	0250	0000	0000	0000	000978	k07	\$	002680	-00031	-01386	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$	
0009189	-00049	-00584	0875	0875	0875	0125	0125	0125	0000	0000	0000	000979	k08	\$	003374	-00072	-01334	0266	0266	0266	0333	0333	0333	0000	%1060	n14	\$	
0009267	000014	-00615	1000	1000	1000	1000	1000	1000	0000	0000	0000	000980	k09	\$	004053	-00134	-01207	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$	
0008073	000096	-00694	0000	0000	0000	1000	1000	1000	0000	0000	0000	000981	l01	\$	004687	-00230	-01196	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$	
0001985	000170	-01368	0125	0125	0125	0875	0875	0875	0000	0000	0000	000982	l02	\$	005343	-00318	-01130	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$	
0003266	-00013	-01370	0250	0250	0250	0750	0750	0750	0000	0000	0000	000983	l03	\$	005996	-00343	-01064	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$	
0004488	-00185	-01183	0375	0375	0375	0625	0625	0625	0000	0000	0000	000984	l04	\$	006614	-00216	-01079	0600	0600	0600	0400	0400	0400	0000	%1065	n19	\$	
0005704	-00292	-01154	0500	0500	0500	0500	0500	0500	0000	0000	0000	000985	l05	\$	007261	-00064	-01096	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$	
0006915	-00163	-01149	0625	0625	0625	0375	0375	0375	0000	0000	0000	000986	l06	\$	007917	-00003	-00969	0734	0734	0734	0266	0266	0266	0000	%1067	n21	\$	
0008130	-00025	-00968	0750	0750	0750	0250	0250	0250	0000	0000	0000	000987	l07	\$	008515	000017	-00823	0800	0800	0800	0200	0200	0200	0000	%1068	n22	\$	
0009190	-00052	-00582	0875	0875	0875	0125	0125	0125	0000	0000	0000	000988	l08	\$	009102	-00071	-00552	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$	
0009266	000012	-00617	1000	1000	1000	1000	1000	1000	0000	0000	0000	000989	l09	\$	009233	000005	-00598	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$	
0008061	000102	-00707	0000	0000	0000	1000	1000	1000	0000	0000	0000	000990	m01	\$	009225	000012	-00598	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$	
0001962	000183	-01388	0125	0125	0125	0875	0875	0875	0000	0000	0000	000991	m02	\$	000820	000131	-00664	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$	
0003224	-00011	-01369	0250	0250	0250	0750	0750	0750	0000	0000	0000	000992	m03	\$	009229	000008	-00592	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$	
0004449	-00190	-01189	0375	0375	0375	0625	0625	0625	0000	0000	0000	000993	m04	\$	003488	000060	003551	1000	0000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
0005668	-00296	-01152	0500	0500	0500	0500	0500	0500	0000	0000	0000	000994	m05	\$	005269	-02880	-03720	0000	1000	1000	0000	0000	0000	0000	%1075	l27	\$	
0006882	-00157	-01143	0625	0625	0625	0375	0375	0375	0000	0000	0000	000995	m06	\$	008421	-00438	010070	1000	1000	0000	0000	1000	1000	0000	%1076	m26	\$	
0008114	-00017	-00982	0750	0750	0750	0250	0250	0250	0000	0000	0000	000996	m07	\$	001338	005250	-06400	0000	0000	0000	1000	1000	1000	0000	%1077	m27	\$	
0009187	-00051	-00584	0875	0875	0875	0125	0125	0125	0000	0000	0000	000997	m08	\$	004354	-00195	004042	0000	1000	0000	0000	1000	1000	0000	%1078	n26	\$	
0009266	000015	-00615	1000	1000	1000	1000	1000	1000	0000	0000	0000	000998	m09	\$	003719	007916	-03948	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$	
0008064	000095	-00694	0000	0000	0000	1000	1000	1000	0000	0000	0000	000999	n01	\$														
0001948	000193	-01398	0125	0125	0125	0875	0875	0875	0000	0000	0000	01000	n02	\$	%003488 000600 003551 %1000 0000 0000 0000 1000 1000 0000 0000 %1074 l26 %03 0 \$													
0003224	-00001	-01377	0250	0250	0250	0750	0750	0750	0000	0000	0000	01001	n03	\$	%008421 -00438 010070 %1000 1000 0000 0000 0000 1000 0000 0000 %1076 m26 %Y3 1 \$													
0004433	-00180	-01197	0375	0375	0375	0625	0625	0625	0000	0000	0000	01002	n04	\$	%004354 -00195 004042 %0000 1000 0000 0000 1000 0000 0000 0000 %1078 n26 %L3 2 \$													
0005662	-00295	-01152	0500	0500	0500	0500	0500	0500	0000	0000	0000	01003	n05	\$	%005269 -02880 -03720 %0000 1000 0000 0000 0000 0000 0000 0000 %1075 l27 %C3 3 \$													
0006885	-00157	-01143	0625	0625	0625	0375	0375	0375	0000	0000	0000	01004	n06	\$	%001338 005250 -06400 %0000 0000 1000 1000 0000 0000 0000 0000 %1077 m27 %V3 4 \$													
0008108	-00025	-00961	0750	0750	0750	0250	0250	0250	0000	0000	0000	01005	n07	\$	%003719 007916 -03948 %1000 0000 0000 0000 0000 1000 0000 0000 %1079 n27 %M3 5 \$													
0009186	-00049	-00583	0875	0875	0875	0125	0125	0125	0000	0000	0000	01006	n08	\$	%000820 000131 -00664 %0000 0000 0000 1000 1000 0000 0000 %1072 k26 %N3 6 \$													
0009266	000014	-00615	1000	1000	1000	1000	1000	1000	0000	0000	0000	01007	n09	\$	%009229 000008 -00592 %1000 1000 0000 0000 0000 0000 0000 0000 %1073 k27 %W3 7 \$													
0008029	000105	-00729	000																									

001717	002395	001405	0375	0000	0000	0625	1000	1000	0000	%0243	A10 \$
001819	002954	-00577	0375	0000	0125	0625	1000	0875	0000	%0244	A11 \$
001914	003497	-01743	0375	0000	0250	0625	1000	0750	0000	%0245	A12 \$
001984	004099	-02727	0375	0000	0375	0625	1000	0625	0000	%0246	A13 \$
002059	004684	-03622	0375	0000	0500	0625	1000	0500	0000	%0247	A14 \$
002122	005264	-04390	0375	0000	0625	0625	1000	0375	0000	%0248	A15 \$
002179	005698	-04913	0375	0000	0750	0625	1000	0250	0000	%0249	A16 \$
002202	005904	-05161	0375	0000	0875	0625	1000	0125	0000	%0250	A17 \$
002212	005925	-05162	0375	0000	1000	0625	1000	0000	0000	%0251	A18 \$
002453	001164	002284	0375	0125	0000	0625	0875	1000	0000	%0252	B10 \$
002608	001702	000177	0375	0125	0125	0625	0875	0875	0000	%0253	B11 \$
002712	002222	-01111	0375	0125	0250	0625	0875	0750	0000	%0254	B12 \$
002809	002786	-02172	0375	0125	0375	0625	0875	0625	0000	%0255	B13 \$
002881	003405	-03179	0375	0125	0500	0625	0875	0500	0000	%0256	B14 \$
002958	004033	-04065	0375	0125	0625	0625	0875	0375	0000	%0257	B15 \$
003032	004542	-04700	0375	0125	0750	0625	0875	0250	0000	%0258	B16 \$
003051	004812	-05023	0375	0125	0875	0625	0875	0125	0000	%0259	B17 \$
003053	004847	-05042	0375	0125	1000	0625	0875	0000	0000	%0260	B18 \$
003268	-00186	003321	0375	0250	0000	0625	0750	1000	0000	%0261	C10 \$
003428	000252	001098	0375	0250	0125	0625	0750	0875	0000	%0262	C11 \$
003560	000710	-00298	0375	0250	0250	0625	0750	0750	0000	%0263	C12 \$
003664	001213	-01374	0375	0250	0375	0625	0750	0625	0000	%0264	C13 \$
003738	001824	-02461	0375	0250	0500	0625	0750	0500	0000	%0265	C14 \$
003816	002495	-03468	0375	0250	0625	0625	0750	0375	0000	%0266	C15 \$
003895	003061	-04210	0375	0250	0750	0625	0750	0250	0000	%0267	C16 \$
003904	003384	-04607	0375	0250	0875	0625	0750	0125	0000	%0268	C17 \$
003907	003433	-04642	0375	0250	1000	0625	0750	0000	0000	%0269	C18 \$
004040	-01459	004306	0375	0375	0000	0625	0625	1000	0000	%0270	D10 \$
004214	-01114	002047	0375	0375	0125	0625	0625	0875	0000	%0271	D11 \$
004435	-00712	006095	0375	0375	0250	0625	0625	0750	0000	%0272	D12 \$
004432	-00214	-00541	0375	0375	0375	0625	0625	0625	0000	%0273	D13 \$
004515	000372	-01710	0375	0375	0500	0625	0625	0500	0000	%0274	D14 \$
004599	001044	-02093	0375	0375	0625	0625	0625	0375	0000	%0275	D15 \$
004674	001643	-03634	0375	0375	0750	0625	0625	0250	0000	%0276	D16 \$
004676	002007	-04106	0375	0375	0875	0625	0625	0125	0000	%0277	D17 \$
004686	002050	-04149	0375	0375	1000	0625	0625	0000	0000	%0278	D18 \$
004773	-02621	005266	0375	0500	0000	0625	0500	1000	0000	%0279	D19 \$
004975	-02366	003008	0375	0500	0125	0625	0500	0875	0000	%0280	E11 \$
005109	-02031	001525	0375	0500	0250	0625	0500	0750	0000	%0281	E12 \$
005174	-01574	000326	0375	0500	0375	0625	0500	0625	0000	%0282	E13 \$
005263	-01040	-00895	0375	0500	0500	0625	0500	0500	0000	%0283	E14 \$
005354	-00409	-02039	0375	0500	0625	0625	0500	0375	0000	%0284	E15 \$
005422	000229	-02998	0375	0500	0750	0625	0500	0250	0000	%0285	E16 \$
005449	000607	-03523	0375	0500	0875	0625	0500	0125	0000	%0286	E17 \$
005456	000657	-03584	0375	0500	1000	0625	0500	0000	0000	%0287	E18 \$
005375	-03484	006053	0375	0625	0000	0625	0375	1000	0000	%0288	F10 \$
005563	-03324	003763	0375	0625	0125	0625	0375	0875	0000	%0289	F11 \$
005710	-03060	002285	0375	0625	0250	0625	0375	0750	0000	%0290	F12 \$
005810	-02679	001087	0375	0625	0375	0625	0375	0625	0000	%0291	F13 \$
005880	-02197	-00161	0375	0625	0500	0625	0375	0500	0000	%0292	F14 \$
005979	-01590	-01383	0375	0625	0625	0625	0375	0375	0000	%0293	F15 \$
006066	-00981	-02398	0375	0625	0750	0625	0375	0250	0000	%0294	F16 \$
006086	-00611	-02979	0375	0625	0875	0625	0375	0125	0000	%0295	F17 \$
006096	-00554	-03045	0375	0625	1000	0625	0375	0000	0000	%0296	F18 \$
005823	-04118	006695	0375	0750	0000	0625	0250	1000	0000	%0297	G10 \$
006050	-04078	004426	0375	0750	0125	0625	0250	0875	0000	%0298	G11 \$
006196	-03916	002971	0375	0750	0250	0625	0250	0750	0000	%0299	G12 \$
006301	-03593	001751	0375	0750	0375	0625	0250	0625	0000	%0300	G13 \$
006395	-03175	000484	0375	0750	0500	0625	0250	0500	0000	%0301	G14 \$
006513	-02642	-00771	0375	0750	0625	0250	0250	0375	0000	%0302	G15 \$
006621	-02068	-01821	0375	0750	0750	0625	0250	0250	0000	%0303	G16 \$
006651	-01708	-02452	0375	0750	0875	0625	0250	0125	0000	%0304	G17 \$
006662	-01652	-02525	0375	0750	1000	0625	0250	0000	0000	%0305	G18 \$
006903	-04525	007124	0375	0875	0000	0625	0125	1000	0000	%0306	H10 \$
006388	-04627	004965	0375	0875	0125	0625	0125	0875	0000	%0307	H11 \$

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

003105	005249	003655	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003149	005543	001422	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
003181	005817	000089	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
003224	006136	-01024	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
003260	006497	-02041	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
003299	006868	-02898	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
003340	007168	-03460	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
003339	007309	-03731	0750	0000	0875	0250	1000	0000	0000	%0493	A26	\$
003347	007330	-03751	0750	0000	0900	0250	1000	0000	0000	%0494	A27	\$
003389	004406	004471	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$
003918	004632	002063	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
003987	004869	000630	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
004031	005183	-00573	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
004085	005552	-01698	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
004123	005976	-02697	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
004158	006317	-03387	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
004147	006545	-03768	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
004130	006591	-03806	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
004622	003265	005428	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
004726	003408	002933	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
004803	003613	001391	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
004866	003892	001622	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
004915	004252	-01031	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
004958	004709	-02159	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
004982	005133	-03006	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
004981	005392	-03487	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
004969	005455	-03548	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
005405	002071	006430	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
005517	002180	003867	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005582	002370	002246	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005607	002641	000975	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005667	003007	-00305	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
005719	003464	-01536	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
005740	003906	-02487	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
005730	004239	-03081	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
005726	004303	-03158	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
006198	000898	007460	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
006293	000952	004873	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
006355	001118	003212	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006401	001360	001884	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006460	001676	000573	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
006498	002119	-00736	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
006536	002593	-01836	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
006545	002928	-02529	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
006532	002997	-02629	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
006888	-00094	008404	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
006975	-00101	005808	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
007057	-00010	004150	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
007115	000160	002844	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
007166	000455	001465	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
007223	000852	000068	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
007275	001298	-01114	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
007277	001672	-01925	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
007261	001750	-02046	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
007462	-00913	009207	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
007607	-01051	006656	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
007698	-01048	005937	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
007775	-00927	003706	0750	0750	0375	0250	0250	0500	0000	%0543	G22	\$
007851	-00712	002329	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007944	-00408	000930	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
008002	-00081	-00										

009302	-00013	000012	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009252	-00094	-00037	0875	1000	1000	0125	0000	0000	%0730	b02	\$
008838	-00916	-00535	0750	1000	1000	0250	0000	0000	%0731	b03	\$
008254	-01688	-01152	0625	1000	1000	0375	0000	0000	%0732	b04	\$
007689	-02218	-01661	0500	1000	1000	0500	0000	0000	%0733	b05	\$
007186	-02565	-02057	0375	1000	1000	0625	0000	0000	%0734	b06	\$
006636	-02830	-02426	0250	1000	1000	0750	0000	0000	%0735	b07	\$
005978	-02987	-02789	0125	1000	1000	0875	0000	0000	%0736	b08	\$
005251	-02385	-03079	0000	1000	1000	1000	0000	0000	%0737	b09	\$
009263	000019	000088	1000	0875	0875	0000	0125	0125	%0738	c01	\$
009215	-00070	000043	0875	0875	0875	0125	0125	0125	%0739	c02	\$
008798	-00897	-00464	0750	0875	0875	0250	0125	0125	%0740	c03	\$
008218	-01683	-01079	0625	0875	0875	0375	0125	0125	%0741	c04	\$
007663	-02218	-01588	0500	0875	0875	0500	0125	0125	%0742	c05	\$
007156	-02581	-02003	0375	0875	0875	0625	0125	0125	%0743	c06	\$
006615	-02853	-02372	0250	0875	0875	0750	0125	0125	%0744	c07	\$
005965	-03025	-02730	0125	0875	0875	0875	0125	0125	%0745	c08	\$
005241	-02973	-03022	0000	0875	0875	1000	0125	0125	%0746	c09	\$
008544	000928	000137	1000	0750	0750	0000	0250	0250	%0747	d01	\$
008504	000825	000127	0875	0750	0750	0125	0250	0250	%0748	d02	\$
008106	-00005	-00370	0750	0750	0750	0250	0250	0250	%0749	d03	\$
007598	-00905	-00944	0625	0750	0750	0375	0250	0250	%0750	d04	\$
007103	-01593	-01423	0500	0750	0750	0500	0250	0250	%0751	d05	\$
006687	-02072	-01829	0375	0750	0750	0625	0250	0250	%0752	d06	\$
006208	-02481	-02182	0250	0750	0750	0750	0250	0250	%0753	d07	\$
005638	-02781	-02539	0125	0750	0750	0875	0250	0250	%0754	d08	\$
004986	-02863	-02803	0000	0750	0750	1000	0250	0250	%0755	d09	\$
007753	001802	000470	1000	0625	0625	0000	0375	0375	%0756	e01	\$
007712	001706	000467	0875	0625	0625	0125	0375	0375	%0757	e02	\$
007369	000807	000042	0750	0625	0625	0250	0375	0375	%0758	e03	\$
006865	-00197	-00517	0625	0625	0625	0375	0375	0375	%0759	e04	\$
006414	-00985	-01010	0500	0625	0625	0500	0375	0375	%0760	e05	\$
006048	-01584	-01417	0375	0625	0625	0625	0375	0375	%0761	e06	\$
005638	-02116	-01768	0250	0625	0625	0750	0375	0375	%0762	e07	\$
005116	-02549	-02115	0125	0625	0625	0875	0375	0375	%0763	e08	\$
004564	-02768	-02373	0000	0625	0625	1000	0375	0375	%0764	e09	\$
006947	002652	000908	1000	0500	0500	0000	0500	0500	%0765	f01	\$
006929	002532	000945	0875	0500	0500	0125	0500	0500	%0766	f02	\$
006576	001626	000528	0750	0500	0500	0250	0500	0500	%0767	f03	\$
006090	000523	-00001	0625	0500	0500	0375	0500	0500	%0768	f04	\$
005630	-00368	-00483	0500	0500	0500	0500	0500	0500	%0769	f05	\$
005329	-01070	-00886	0375	0500	0500	0625	0500	0500	%0770	f06	\$
004935	-01704	-01262	0250	0500	0500	0750	0500	0500	%0771	f07	\$
004479	-02242	-01634	0125	0500	0500	0875	0500	0500	%0772	f08	\$
003989	-02584	-01842	0000	0500	0500	1000	0500	0500	%0773	f09	\$
006101	003571	001345	1000	0375	0375	0000	0625	0625	%0774	g01	\$
006060	003478	001350	0875	0375	0375	0125	0625	0625	%0775	g02	\$
005724	002586	000962	0750	0375	0375	0250	0625	0625	%0776	g03	\$
005224	001453	000387	0625	0375	0375	0375	0625	0625	%0777	g04	\$
004793	000513	-00113	0500	0375	0375	0500	0625	0625	%0778	g05	\$
004448	-00270	-00534	0375	0375	0375	0625	0625	0625	%0779	g06	\$
004086	-00986	-00936	0250	0375	0375	0750	0625	0625	%0780	g07	\$
003671	-01595	-01305	0125	0375	0375	0875	0625	0625	%0781	g08	\$
003241	-01996	-01541	0000	0375	0375	1000	0625	0625	%0782	g09	\$
002581	004494	001738	1000	0250	0250	0000	0750	0750	%0783	h01	\$
005256	004398	001759	0875	0250	0250	0125	0750	0750	%0784	h02	\$
004893	003579	001358	0750	0250	0250	0250	0750	0750	%0785	h03	\$
004303	002456	000737	0625	0250	0250	0375	0750	0750	%0786	h04	\$
003939	001485	000202	0500	0250	0250	0500	0750	0750	%0787	h05	\$
003580	000654	-00289	0375	0250	0250	0625	0750	0750	%0788	h06	\$
003231	-00132	-00715	0250	0250	0250	0750	0750	0750	%0789	h07	\$
002845	-00805	-01079	0125	0250	0250	0875	0750	0750	%0790	h08	\$
002465	-01245	-01348	0000	0250	0250	1000	0750	0750	%0791	h09	\$
004393	005395	002475	1000	0125	0125	0000	0875	0875	%0792	i01	\$
004363	005330	002473	0875	0125	0125	0125	0875	0875	%0793	i02	\$
004012	004584	002056	0750	0125	0125	0250	0875	0875	%0794	i03	\$
003476	003491	001370	0625	0125	0125	0375	0875	0875	%0795	i04	\$
003011	002517	000732	0500	0125	0125	0500	0875	0875	%0796	i05	\$
002637	001626	000165	0375	0125	0125	0625	0875	0875	%0797	i06	\$
002279	000803	-00322	0250	0125	0125	0750	0875	0875	%0798	i07	\$
001933	000078	-00718									

%BEG GE29(7)_22_REM.TXT, Separation cmyn62*, D65, adapted \$
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos \$
%z003455 005944 004159 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008436 -00484 010687 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z004369 -06270 004687 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005222 -02908 -03087 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z001340 005118 -05715 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003694 007831 -03287 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z000823 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009224 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z003528 005970 004150 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008437 -00462 010622 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z004333 -06259 004657 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005251 -02935 -03079 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z001328 005124 -05710 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003714 007843 -03282 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z000812 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009268 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/GE39/GE39L0NA.TXT> / PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.0

TUB registration: 20091101-GE39/GE39L0NA.TXT /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

KBEG GE29(7) 22.REM.TXT, Separation cmy62*, D65, adapted S									
%100 x LAB*a	1000 x	(r g b	c m y o)	%nr.	pos	\$			
000877 -00032	-00028	0000	0000	0000	1000	1000	0000	0000	00972 k01
001984 -00057	-00727	0125	0125	0125	0875	0875	0000	0000	00973 k02
003268 -00118	-00711	0250	0250	0250	0750	0750	0000	0000	00974 k03
004488 -00270	-00540	0375	0375	0375	0625	0625	0000	0000	00975 k04
005070 -00355	-00521	0500	0500	0500	0500	0500	0000	0000	00976 k05
006910 -00218	-00516	0625	0625	0625	0375	0375	0000	0000	00977 k06
008132 -00054	-00350	0750	0750	0750	0250	0250	0000	0000	00978 k07
009189 -00059	000009	0875	0875	0875	0125	0125	0000	0000	00979 k08
009267 -00006	-00023	1000	1000	1000	0000	0000	0000	0000	00980 k09
000073 -00034	-00030	0000	0000	0000	1000	1000	0000	0000	00981 l01
001985 -00055	-00713	0125	0125	0125	0875	0875	0000	0000	00982 l02
003266 -00108	-00726	0250	0250	0250	0750	0750	0000	0000	00983 l03
004488 -00263	-00549	0375	0375	0375	0625	0625	0000	0000	00984 l04
005704 -00352	-00531	0500	0500	0500	0500	0500	0000	0000	00985 l05
006915 -00206	-00536	0625	0625	0625	0375	0375	0000	0000	00986 l06
008130 -00059	-00365	0750	0750	0750	0250	0250	0000	0000	00987 l07
009190 -00061	000011	0875	0875	0875	0125	0125	0000	0000	00988 l08
009266 -00004	-00024	1000	1000	1000	0000	0000	0000	0000	00989 l09
000061 -00027	-00043	0000	0000	0000	1000	1000	0000	0000	00990 m01
001962 -00068	-00733	0125	0125	0125	0875	0875	0000	0000	00991 m02
003274 -00258	-00725	0250	0250	0250	0750	0750	0000	0000	00992 m03
004449 -00268	-00535	0375	0375	0375	0625	0625	0000	0000	00993 m04
005668 -00357	-00529	0500	0500	0500	0500	0500	0000	0000	00994 m05
006882 -00210	-00536	0625	0625	0625	0375	0375	0000	0000	00995 m06
008114 -00042	-00380	0750	0750	0750	0250	0250	0000	0000	00996 m07
009187 -00060	000009	0875	0875	0875	0125	0125	0000	0000	00997 m08
009266 -00006	-00022	1000	1000	1000	0000	0000	0000	0000	00998 m09
000064 -00035	-00030	0000	0000	0000	1000	1000	0000	0000	00999 n01
001948 -00078	-00742	0125	0125	0125	0875	0875	0000	0000	01000 n02
003224 -00097	-00733	0250	0250	0250	0750	0750	0000	0000	01001 n03
004433 -00258	-00563	0375	0375	0375	0625	0625	0000	0000	01002 n04
005662 -00355	-00528	0500	0500	0500	0500	0500	0000	0000	01003 n05
006885 -00200	-00530	0625	0625	0625	0375	0375	0000	0000	01004 n06
008108 -00050	-00358	0750	0750	0750	0250	0250	0000	0000	01005 n07
009186 -00059	000009	0875	0875	0875	0125	0125	0000	0000	01006 n08
009266 -00006	-00023	1000	1000	1000	0000	0000	0000	0000	01007 n09
000020 -00025	-00065	0000	0000	0000	1000	1000	0000	0000	01008 k10
001349 -000125									

TUB-test chart GE39; Relative Device Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```

%BEG GE29(7)_22.REM.TXT, Separation cmyn62*, D50, not adapted S																			
%100 x LAB*																			
1000 x (r g b																			
c m y θ)																			
%nrr. pos \$																			
000810	000021	-00675	0000	0000	0000	1000	1000	1000	0000	%0000	A01	\$							
000879	000837	-02369	0000	0000	0125	1000	1000	0875	0000	%0001	A02	\$							
000939	001555	-03430	0000	0000	0250	1000	1000	0750	0000	%0002	A03	\$							
000999	002197	-04257	0000	0000	0375	1000	1000	0625	0000	%0003	A04	\$							
001067	002858	-05037	0000	0000	0500	1000	1000	0500	0000	%0004	A05	\$							
001159	003454	-05726	0000	0000	0625	1000	1000	0375	0000	%0005	A06	\$							
001205	003898	-06208	0000	0000	0750	1000	1000	0250	0000	%0006	A07	\$							
001244	004089	-06422	0000	0000	0875	1000	1000	0125	0000	%0007	A08	\$							
001236	004132	-06455	0000	0000	1000	1000	1000	0000	0000	%0008	A08	\$							
001451	-01279	001002	0000	0125	0000	1000	0875	1000	0000	%0009	B01	\$							
001558	-00615	001085	0000	0125	0125	1000	0875	0875	0000	%0010	B02	\$							
001632	000063	-02889	0000	0125	0250	1000	0875	0750	0000	%0011	B03	\$							
001708	000067	-03777	0000	0125	0375	1000	0875	0625	0000	%0012	B04	\$							
001784	001359	-04641	0000	0125	0500	1000	0875	0500	0000	%0013	B05	\$							
001876	002015	-05444	0000	0125	0625	1000	0875	0375	0000	%0014	B06	\$							
001933	002494	-05995	0000	0125	0750	1000	0875	0250	0000	%0015	B07	\$							
001964	002738	-06264	0000	0125	0875	1000	0875	0125	0000	%0016	B08	\$							
001958	002787	-06300	0000	0125	1000	1000	0875	0000	0000	%0017	B09	\$							
002181	-02646	001038	0000	0250	0000	1000	0750	1000	0000	%0018	C01	\$							
002294	-02147	-00862	0000	0250	0125	1000	0750	0875	0000	%0019	C02	\$							
002358	-01516	-02118	0000	0250	0250	1000	0750	0750	0000	%0020	C03	\$							
002433	-00945	-03086	0000	0250	0375	1000	0750	0625	0000	%0021	C04	\$							
002521	-00289	-04013	0000	0250	0500	1000	0750	0500	0000	%0022	C05	\$							
002604	000399	-04906	0000	0250	0625	1000	0750	0375	0000	%0023	C06	\$							
002677	000914	-05535	0000	0250	0750	1000	0750	0250	0000	%0024	C07	\$							
002700	001194	-05852	0000	0250	0875	1000	0750	0125	0000	%0025	C08	\$							
002697	001247	-05903	0000	0250	1000	1000	0750	0000	0000	%0026	C09	\$							
002829	-03765	001874	0000	0375	0000	1000	0625	1000	0000	%0027	D01	\$							
002957	-03409	-00068	0000	0375	0125	1000	0625	0875	0000	%0028	D02	\$							
003041	-02929	-01286	0000	0375	0250	1000	0625	0750	0000	%0029	D03	\$							
003114	-02385	-02338	0000	0375	0375	1000	0625	0625	0000	%0030	D04	\$							
003208	-01755	-03348	0000	0375	0500	1000	0625	0500	0000	%0031	D05	\$							
003305	-01098	-04318	0000	0375	0625	1000	0625	0375	0000	%0032	D06	\$							
003372	-00570	-05001	0000	0375	0750	1000	0625	0250	0000	%0033	D07	\$							
003390	-00267	-05382	0000	0375	0875	1000	0625	0125	0000	%0034	D08	\$							
003392	-00215	-05416	0000	0375	1000	1000	0625	0000	0000	%0035	D09	\$							
003435	-04733	002653	0000	0500	0000	1000	0500	1000	0000	%0036	E01	\$							
003567	-04503	000691	0000	0500	0125	1000	0500	0875	0000	%0037	E02	\$							
003653	-04113	-00562	0000	0500	0250	1000	0500	0750	0000	%0038	E03	\$							
003736	-03633	-01658	0000	0500	0375	1000	0500	0625	0000	%0039	E04	\$							
003832	-03074	-02686	0000	0500	0500	1000	0500	0500	0000	%0040	E05	\$							
003919	-02429	-03706	0000	0500	0625	1000	0500	0375	0000	%0041	E06	\$							
004010	-01919	-04454	0000	0500	0750	1000	0500	0250	0000	%0042	E07	\$							
004028	-01603	-04852	0000	0500	0875	1000	0500	0125	0000	%0043	E08	\$							
004032	-01548	-04911	0000	0500	1000	1000	0500	0000	0000	%0044	E09	\$							
003866	-05406	003195	0000	0625	0000	1000	0375	1000	0000	%0045	F01	\$							
004008	-05269	001277	0000	0625	0125	1000	0375	0875	0000	%0046	F02	\$							

See original or copy: <http://web.me.com/klaustrichter/GE39/GE39L0NA.TXT> /PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

001783	002523	000874	0375	0000	0000	0625	1000	1000	0000	%0243	A10 \$	002215	003427	001547	0500	0000	0000	0500	1000	1000	0000	%0324	J10 \$	002721	004476	002363	0625	0000	0000	0375	1000	1000	0000	%0405	S10 \$
001871	002978	-01096	0375	0000	0125	0625	1000	0875	0000	%0244	A11 \$	002299	003819	-00507	0500	0000	0125	0500	1000	0875	0000	%0325	J11 \$	002797	004770	000214	0625	0000	0125	0375	1000	0875	0000	%0406	S11 \$
001954	003357	-02265	0375	0000	0250	0625	1000	0750	0000	%0245	A12 \$	003253	004131	-01727	0500	0000	0250	0500	1000	0750	0000	%0326	J12 \$	002838	005010	-01950	0625	0000	0250	0375	1000	0750	0000	%0407	S12 \$
002013	003802	-03253	0375	0000	0375	0625	1000	0625	0000	%0246	A13 \$	002419	004469	-02729	0500	0000	0375	0500	1000	0625	0000	%0327	J13 \$	002883	005278	-02113	0625	0000	0375	0375	1000	0625	0000	%0408	S13 \$
002076	004230	-04156	0375	0000	0500	0625	1000	0500	0000	%0247	A14 \$	002462	004842	-03665	0500	0000	0500	0500	1000	0500	0000	%0328	J14 \$	002922	005580	-03065	0625	0000	0500	0375	1000	0500	0000	%0409	S14 \$
002177	004669	-04932	0375	0000	0625	0625	1000	0375	0000	%0248	A15 \$	002533	005224	-04465	0500	0000	0625	0500	1000	0375	0000	%0329	J15 \$	002980	005914	-03901	0625	0000	0625	0375	1000	0375	0000	%0410	S15 \$
002177	005006	-05458	0375	0000	0750	0625	1000	0250	0000	%0249	A16 \$	002590	005522	-04995	0500	0000	0750	0500	1000	0250	0000	%0330	J16 \$	003018	006157	-04445	0625	0000	0750	0375	1000	0250	0000	%0411	S16 \$
002195	005165	-05708	0375	0000	0875	0625	1000	0000	0000	%0250	A17 \$	002605	005659	-05258	0500	0000	0875	0500	1000	0125	0000	%0331	J17 \$	003013	006271	-04701	0625	0000	0875	0375	1000	0125	0000	%0412	S17 \$
002207	005106	-05707	0375	0000	1000	0625	1000	0000	0000	%0251	A18 \$	002632	005869	-05233	0500	0000	1000	0500	1000	0000	0000	%0332	J18 \$	003032	006286	-04709	0625	0000	1000	0375	1000	0000	0000	%0413	S18 \$
002497	001444	001693	0375	0125	0000	0625	0875	1000	0000	%0252	B10 \$	002901	002405	002318	0500	0125	0000	0500	0875	1000	0000	%0333	K10 \$	003410	003525	003131	0625	0125	0000	0375	0875	1000	0000	%0414	T10 \$
002638	001806	-00399	0375	0125	0125	0625	0875	0875	0000	%0253	B11 \$	003021	002711	000135	0500	0125	0125	0500	0875	0875	0000	%0334	K11 \$	003532	003746	000820	0625	0125	0125	0375	0875	0875	0000	%0415	T11 \$
002730	002160	-01690	0375	0125	0250	0625	0875	0750	0000	%0254	B12 \$	003104	002957	-01157	0500	0125	0250	0500	0875	0750	0000	%0335	K12 \$	003600	003947	-00534	0625	0125	0250	0375	0875	0750	0000	%0416	T12 \$
002816	002566	-02756	0375	0125	0375	0625	0875	0625	0000	%0255	B13 \$	003184	003303	-02282	0500	0125	0375	0500	0875	0625	0000	%0336	K13 \$	003665	004202	-01695	0625	0125	0375	0375	0875	0625	0000	%0417	T13 \$
002875	003016	-03770	0375	0125	0500	0625	0875	0500	0000	%0256	B14 \$	003242	003690	-03337	0500	0125	0500	0500	0875	0500	0000	%0337	K14 \$	003716	004521	-02764	0625	0125	0500	0375	0875	0500	0000	%0418	T14 \$
002941	003485	-04662	0375	0125	0625	0875	0875	0375	0000	%0257	B15 \$	003319	004112	-04252	0500	0125	0625	0500	0875	0375	0000	%0338	K15 \$	003771	004882	-03731	0625	0125	0625	0375	0875	0375	0000	%0419	T15 \$
003007	003879	-05300	0375	0125	0750	0625	0875	0250	0000	%0258	B16 \$	003369	004456	-04914	0500	0125	0750	0500	0875	0250	0000	%0339	K16 \$	003811	005172	-04401	0625	0125	0750	0375	0875	0250	0000	%0420	T16 \$
003022	004089	-05626	0375	0125	0875	0625	0875	0125	0000	%0259	B17 \$	003371	004649	-05251	0500	0125	0875	0500	0875	0125	0000	%0340	K17 \$	003816	005344	-04755	0625	0125	0875	0375	0875	0125	0000	%0421	T17 \$
003024	004120	-05643	0375	0125	1000	0625	0875	0000	0000	%0260	B18 \$	003366	004677	-05269	0500	0125	1000	0500	0875	0000	0000	%0341	K18 \$	003827	005359	-04775	0625	0125	1000	0375	0875	0000	0000	%0422	T18 \$
003293	000135	-002671	0375	0250	0000	0625	0750	1000	0000	%0261	C10 \$	003661	001145	-03269	0500	0250	0000	0500	0750	1000	0000	%0342	L10 \$	004203	002323	004074	0625	0250	0000	0375	0750	1000	0000	%0423	U10 \$
003439	000413	-000468	0375	0250	0125	0625	0750	0875	0000	%0262	C11 \$	003810	001363	-000994	0500	0250	0125	0500	0750	0875	0000	%0343	L11 \$	004348	002451	001687	0625	0250	0125	0375	0750	0875	0000	%0424	U11 \$
003558	000708	-00930	0375	0250	0250	0625	0750	0750	0000	%0263	C12 \$	003922	001571	-00414	0500	0250	0250	0500	0750	0750	0000	%0344	L12 \$	004437	002606	000181	0625	02							

003273	005579	003313	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003307	005774	001100	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
003330	005946	-00229	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
003363	006156	-01345	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
003389	006396	-02365	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
003419	006648	-03224	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
003454	006854	-03786	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
003450	006958	-04058	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$
003458	006975	-04076	0750	0000	0875	0250	1000	0000	0000	%0494	A27	\$
003984	004803	-00462	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$
004051	004937	001675	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
004108	005075	000242	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
004142	005277	-00963	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
004184	005517	-02092	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
004212	005806	-03095	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
004240	006043	-03785	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
004256	006209	-04165	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
004210	006248	-04202	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
004743	003718	004949	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
004833	003779	002478	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
004897	003884	000937	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
004950	004056	-00293	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
004988	004287	-01491	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
005020	004599	-02622	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
005036	004899	-03469	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
005030	005083	-03950	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
005018	005136	-04010	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
005504	002560	005885	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
005602	002595	003355	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005655	002688	001738	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005678	002856	000466	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005720	003093	-00816	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
005751	003400	-02050	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
005772	003710	-03093	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
005757	003955	-03596	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
005753	004007	-03672	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
006280	001403	006859	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
006360	001394	004309	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
006411	001473	002655	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006447	001617	001328	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006495	001810	000014	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
006521	002105	-01299	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
006550	002435	-02401	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
006551	002671	-03097	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
006538	002726	-03195	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
006957	000413	007759	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
007029	000354	005205	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
007099	000366	003554	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
007148	000450	002248	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
007187	000628	000867	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
007232	000878	-00535	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
007272	001179	-01722	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
007267	001445	-02536	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
007250	001506	-02657	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
007521	-00418	008528	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
007650	-00592	006020	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
007730	-00659	004408	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
007795	-00619	003378	0750	0750	0375	0250	0250	0500	0000	%0543	G22	\$
007860	-00512	001697	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007939	-00346	000290	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
007986	-00082	-00973	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$
007983	000176	-01884	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$
007984	000230	-02022	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$
007971	-01054	009187	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$
008172	-01403	006790	0750	0875	0125	0						

009292	-00059	-00621	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009240	-00151	-00676	0875	1000	1000	0000	0125	0000	0000	%0730	b02	\$
008800	-01086	-01223	0750	1000	1000	0000	0250	0000	0000	%0731	b03	\$
008188	-01995	-01891	0625	1000	1000	0000	0375	0000	0000	%0732	b04	\$
007602	-02649	-02441	0500	1000	1000	0000	0500	0000	0000	%0733	b05	\$
007083	-03101	-02868	0375	1000	1000	0000	0625	0000	0000	%0734	b06	\$
006519	-03474	-03266	0250	1000	1000	0000	0750	0000	0000	%0735	b07	\$
005847	-03756	-03659	0125	1000	1000	0000	0875	0000	0000	%0736	b08	\$
005140	-03700	-03971	0000	1000	1000	0000	1000	0000	0000	%0737	b09	\$
009256	-00015	-00542	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
009204	-00115	-00593	0875	0875	0875	0000	0125	0125	0125	%0739	c02	\$
008761	-01056	-01149	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
008154	-01979	-01816	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
007578	-02636	-02366	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
007054	-03108	-02813	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
006498	-03488	-03211	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005835	-03774	-03599	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
005101	-03808	-03913	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008556	-00059	-00455	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
008514	-00049	-00469	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
008090	-00093	-01016	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
007551	-01129	-01645	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
007033	-01942	-02170	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
006590	-02534	-02612	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
006102	-03056	-02999	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005516	-03475	-03389	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
004854	-03646	-03679	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007789	-001925	-00078	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007747	-001824	-00085	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
007367	-000826	-00561	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006841	-00307	-01180	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
006364	-01220	-01721	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
005977	-01935	-02169	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
005549	-02583	-02557	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
005008	-03140	-02941	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004444	-03453	-03228	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007099	-002866	-000403	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006990	-002744	-000434	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006609	-001753	-000333	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$
006090	-000534	-000624	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005635	-00473	-01159	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005270	-01286	-01605	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
004864	-02039	-02021	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004388	-02708	-02433	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
003885	-03140	-02671	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006192	-003858	-000888	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
006149	-003761	-000888	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005786	-002800	-000450	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005251	-001565	-00190	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004791	-000521	-00747	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
004420	-00367	-01215	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004036	-01203	-01661	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
003600	-01943	-02072	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003155	-02444	-02340	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
005403	-004822	-001326	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005376	-004725	-001350	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
004986	-003851	-000900	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
004642	-002642	-000210	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
003963	-001584	-00383	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
003577	-000654	-000926	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$

%BEG GE29(7)_22_REM.TXT, Separation cmyn62*, D50, not adapted \$
%100 x LAB*
%#1000 x (r g b c m y 0) %nr. pos \$
%z003647 006303 003862 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008515 000054 010030 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z004308 -06071 003807 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005081 -03755 -03977 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z001236 004132 -06455 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003837 007577 -03554 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z000810 000021 -00675 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009214 -00045 -00638 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z003720 006338 003852 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008517 000074 009972 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z004272 -06059 003775 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005110 -03780 -03971 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z001223 004143 -06458 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003858 007594 -03552 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z000799 000025 -00683 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009259 -00046 -00634 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

TUB-test chart GE39; Relative Device Colour System G
1080 spectral reflexions R -> LAB* for D65 and D50

input: w *setgray*
output: -> *olv* setrgbcolor*

TUB registration: 20091101-GE39/GE39L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

\$BEG	LAB27(7)	22	REM.TXT	Separation	cmyne2*	D50	not adapted	\$	
\$100 x	GEAR*			1000 x	(r g b		c m y 0		
000864	000000	00679	0090	0090	0090	1000	1000	1000	0000
001958	00035	01384	0125	0125	0125	0875	0875	0875	0000
003240	00219	01367	0250	0250	0250	0750	0750	0750	0000
004461	00361	01193	0375	0375	0375	0625	0625	0625	0000
005679	00460	01172	0500	0500	0500	0500	0500	0500	0000
006886	00327	01156	0625	0625	0625	0375	0375	0375	0000
008115	00143	00976	0750	0750	0750	0250	0250	0250	0000
009178	00109	00607	0875	0875	0875	0125	0125	0125	0000
009257	00045	00637	1000	1000	1000	0000	0000	0000	0000
000860	00001	00681	0000	0000	0000	1000	1000	1000	0000
001959	00033	01369	0125	0125	0125	0875	0875	0875	0000
003238	00212	01383	0250	0250	0250	0750	0750	0750	0000
004461	00354	01202	0375	0375	0375	0625	0625	0625	0000
005676	00458	01181	0500	0500	0500	0500	0500	0500	0000
006891	00317	01176	0625	0625	0625	0375	0375	0375	0000
008113	00141	00991	0750	0750	0750	0250	0250	0250	0000
009179	00112	00605	0875	0875	0875	0125	0125	0125	0000
009257	00047	00639	1000	1000	1000	0000	0000	0000	0000
000848	000004	00694	0000	0000	0000	1000	1000	1000	0000
001936	00023	01389	0125	0125	0125	0875	0875	0875	0000
003240	00219	01367	0250	0250	0250	0750	0750	0750	0000
004422	00361	01208	0375	0375	0375	0625	0625	0625	0000
005640	00463	01180	0500	0500	0500	0500	0500	0500	0000
006857	00321	01176	0625	0625	0625	0375	0375	0375	0000
008096	00134	01006	0750	0750	0750	0250	0250	0250	0000
009177	00111	00607	0875	0875	0875	0125	0125	0125	0000
009257	00044	00637	1000	1000	1000	0000	0000	0000	0000
000851	00001	00681	0000	0000	0000	1000	1000	1000	0000
001922	00015	01399	0125	0125	0125	0875	0875	0875	0000
003196	00201	01389	0250	0250	0250	0750	0750	0750	0000
004406	00351	01216	0375	0375	0375	0625	0625	0625	0000
005634	00461	01179	0500	0500	0500	0500	0500	0500	0000
006861	00310	01170	0625	0625	0625	0375	0375	0375	0000
008091	00140	00984	0750	0750	0750	0250	0250	0250	0000
009175	00109	00606	0875	0875	0875	0125	0125	0125	0000
009256	00045	00637	1000	1000	1000	0000	0000	0000	0000
000806	000002	00717	0000	0000	0000	1000	1000	1000	0000
001328	000069	01201	0066	0066	0066	0933	0933	0933	0000
002005	00069	01423	0133	0133	0133	0866	0866	0866	0000
002693	00271	01377	0200	0200	0200	0800			

TUB-test chart GE39; Relative Device Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

TUB registration: 20091101-GE39/GE39L0NA.TXT /.PS
application for evaluation and measurement of printer or

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klau.s.richter/GE39/GE39L0NA.TXT> /PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

001783	002509	001545	0375	0000	0000	0625	1000	1000	0000	%0243	A10	\$
001871	002965	-00424	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$
001954	003345	-01594	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$
002013	003790	-02583	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$
002076	004218	-03486	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$
002127	004658	-04261	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$
002177	004995	-04788	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$
002195	005154	-05039	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$
002207	005175	-05037	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$
002497	001436	002362	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$
002638	001799	002688	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$
002730	002154	-01022	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$
002816	002560	-02089	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$
002875	003010	-03103	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$
002941	003480	-03996	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$
003007	003875	-04634	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$
003022	004085	-04960	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$
003024	004116	-04976	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$
003293	000133	003336	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$
003439	000412	001132	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$
003558	000708	-00267	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$
003651	001062	-01347	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$
003714	001502	-02439	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$
003779	002001	-03453	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$
003851	002438	-04197	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$
003855	002689	-04597	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$
003858	002731	-04629	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$
004049	-01115	004266	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$
004209	-00909	002032	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$
004328	-00658	000591	0375	0375	0250	0625	0625	0750	0000	%0272	D12	\$
004405	-00304	-00557	0375	0375	0375	0625	0625	0625	0000	%0273	D13	\$
004477	000111	-01731	0375	0375	0500	0625	0625	0500	0000	%0274	D14	\$
004549	000606	-02830	0375	0375	0625	0625	0625	0375	0000	%0275	D15	\$
004615	001065	-03664	0375	0375	0750	0625	0625	0250	0000	%0276	D16	\$
004613	001345	-04139	0375	0375	0875	0625	0625	0125	0000	%0277	D17	\$
004622	001382	-04188	0375	0375	1000	0625	0625	0000	0000	%0278	D18	\$
004770	-02265	005177	0375	0500	0000	0625	0500	1000	0000	%0279	D10	\$
004959	-02129	002950	0375	0500	0125	0625	0500	0875	0000	%0280	E11	\$
005081	-01930	001470	0375	0500	0250	0625	0500	0750	0000	%0281	E12	\$
005136	-01610	000271	0375	0500	0375	0625	0500	0625	0000	%0282	E13	\$
005213	-01242	-00955	0375	0500	0500	0625	0500	0500	0000	%0283	E14	\$
005293	-00785	-02105	0375	0500	0625	0625	0500	0375	0000	%0284	E15	\$
005351	-00300	-03069	0375	0500	0750	0625	0500	0250	0000	%0285	E16	\$
005373	-00010	-03597	0375	0500	0875	0625	0500	0125	0000	%0286	E17	\$
005380	000028	-03657	0375	0500	1000	0625	0500	0000	0000	%0287	E18	\$
005365	-03121	005929	0375	0625	0000	0625	0375	1000	0000	%0288	F10	\$
005538	-03067	003673	0375	0625	0125	0625	0375	0875	0000	%0289	F11	\$
005673	-02927	002199	0375	0625	0250	0625	0375	0750	0000	%0290	F12	\$
005764	-02674	001001	0375	0625	0375	0625	0375	0625	0000	%0291	F13	\$
005822	-02350	-00252	0375	0625	0500	0625	0375	0500	0000	%0292	F14	\$
005908	-01917	-01481	0375	0625	0625	0625	0375	0375	0000	%0293	F15	\$
005986	-01464	-02502	0375	0625	0750	0625	0375	0250	0000	%0294	F16	\$
005999	-01189	-03087	0375	0625	0875	0625	0375	0125	0000	%0295	F17	\$
006008	-01143	-03154	0375	0625	1000	0625	0375	0000	0000	%0296	F18	\$
006080	-03743	006536	0375	0750	0000	0625	0250	1000	0000	%0297	G10	\$
006019	-03806	004311	0375	0750	0125	0625	0250	0875	0000	%0298	G11	\$
006153	-03756	002800	0375	0750	0250	0625	0250	0750	0000	%0299	G12	\$
006253	-03563	001641	0375	0750	0375	0625	0250	0500	0000	%0300	G13	\$
006330	-03287	000368	0375	0750	0500	0625	0250	0500	0000	%0301	G14	\$
006435	-02925	-00896	0375	0750	0625	0250	0250					

See original or copy: <http://web.me.com/klaustrichter/GE39/GE39L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

003273	005577	003978	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
003307	005772	001765	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
003330	005944	000434	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
003363	006155	-00680	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
003389	006395	-01700	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
003419	006647	-02560	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
003454	006854	-03122	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
003450	006957	-03393	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$
003458	006974	-03412	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$
003984	004807	004734	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$
004051	004941	002377	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
004108	005080	000903	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
004142	005282	-00302	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
004184	005523	-01431	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
004212	005812	-02434	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
004240	006049	-03125	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
004258	006215	-03504	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
004210	006254	-03541	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
004743	003728	005607	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
004833	003789	003136	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
004897	003895	001594	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
004950	004067	000364	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
004988	004298	-00834	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
005020	004611	-01964	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
005036	004912	-02812	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
005030	005095	-03293	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
005018	005148	-03353	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
005004	005276	006541	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
005502	002612	004009	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005655	002705	002392	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005678	002873	001121	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005720	003111	-01062	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
005751	003418	-01306	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
005772	003728	-02349	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
005757	003973	-02942	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
005753	004025	-03018	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
006280	001425	007511	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
006360	001417	004961	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
006411	001496	003306	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006447	001640	001979	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006495	001834	000665	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
006521	002129	-00648	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
006550	002460	-01751	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
006551	002696	-02446	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
006538	002750	-02545	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
006957	000441	008408	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
007029	000382	005853	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
007099	000395	004202	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
007148	000479	002896	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
007187	000657	001515	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
007232	000907	000112	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
007272	001209	-01075	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
007267	001475	-01889	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
007250	001536	-02010	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
007521	-00378	009175	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
007650	-00559	006666	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
007730	-00625	005953	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
007796	-00658	003723	0750	0750	0375	0250	0250	0500	0000	%0543	G22	\$
007860	-00477	002342	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007939	-0031											

See original or copy: <http://web.me.com/klaus.richter/GE39/GE39L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

009292	-00012	000012	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009240	-00104	-00041	0875	1000	1000	0125	0000	0000	0000	%0730	b02	\$
008800	-01043	-00586	0750	1000	1000	0250	0000	0000	0000	%0731	b03	\$
008188	-01958	-01250	0625	1000	1000	0375	0000	0000	0000	%0732	b04	\$
007602	-02616	-01797	0500	1000	1000	0500	0000	0000	0000	%0733	b05	\$
007083	-03073	-02221	0375	1000	1000	0625	0000	0000	0000	%0734	b06	\$
006519	-03451	-02616	0250	1000	1000	0750	0000	0000	0000	%0735	b07	\$
005847	-03738	-03005	0125	1000	1000	0875	0000	0000	0000	%0736	b08	\$
005140	-03768	-03312	0000	1000	1000	1000	0000	0000	0000	%0737	b09	\$
009256	000031	000091	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
009204	-00069	000041	0875	0875	0875	0125	0125	0125	0000	%0739	c02	\$
008761	-01013	-00512	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
008154	-01942	-01175	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
007578	-02604	-01722	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
007054	-03080	-02165	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
006498	-03465	-02561	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005835	-03756	-02944	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
005101	-03796	-03254	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008556	000099	000313	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
008514	000089	000168	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
008090	-00057	-00375	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
007551	-01097	-01000	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
007033	-01915	-01522	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
006599	-02510	-01962	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
006102	-03037	-02346	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005516	-03460	-02733	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
004854	-03637	-03019	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007789	001959	000564	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007747	001858	000557	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
007367	000856	000083	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006841	-00281	-00531	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
006364	-01198	-01070	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
005977	-01916	-01515	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
005549	-02567	-01901	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
005008	-03129	-02282	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004444	-03447	-02566	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007099	002894	001050	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006990	002772	001082	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006609	001777	000616	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$
006090	000553	000028	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005635	-00457	-00503	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005270	-01273	-00947	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
004864	-02030	-01362	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004388	-02703	-01771	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
003885	-03139	-02006	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006192	003878	001540	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
006149	003781	001541	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005786	002817	001105	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005251	001577	000467	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004790	000530	-00087	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
004420	-00361	-00552	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004036	-01200	-00997	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
003600	-01944	-01405	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003155	-02450	-01671	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
005403	004836	001983	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005376	004739	002007	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
004986	003061	001559	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
004642	002648	000873	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
003963	001586	000281	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
003577	000652	-00259	0375	0250	0250</							

%BEG GE29(7)_22_REM.TXT, Separation cmyn62*, D50, adapted \$
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos \$
%z003647 006303 004526 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008515 000094 010671 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z004308 -06064 004468 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005081 -03742 -03320 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z001236 004113 -05781 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003837 007579 -02891 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z000810 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009214 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z003720 006338 004518 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008517 000115 010611 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z004272 -06055 004438 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005110 -03768 -03313 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z001223 004121 -05777 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003858 007594 -02886 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z000799 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009259 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/GE39/GE39L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

TUB registration: 20091101-GE39/GE39L0NA.TXT /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

BEG GE29(7) 22.REM.TXT, Separation										cmycn62*, D50, adapted S									
0.00	LAB*	0.00	0.00	0.00	0.00	0.00	0.00	0.00	0.00	100x	(n	b	c	m	y	0.00	pos	\$	
000064	00039	-00029	00100	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
000064	00039	-00029	00100	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001958	-00063	-00739	0125	0125	0125	0875	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003240	-00234	-00728	0250	0250	0250	0750	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004461	-00363	-00558	0375	0375	0375	0625	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005679	-00449	-00542	0500	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006886	-00303	-00531	0625	0625	0625	0625	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008115	-00106	-00357	0750	0750	0750	0250	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009178	-00061	-00007	0875	0875	0875	0125	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009257	000003	-00023	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
000860	-00041	-00031	0000	0000	0000	1000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001959	-00061	-00724	0125	0125	0125	0875	0875	0875	0875	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
003238	-00227	-00743	0250	0250	0250	0750	0750	0750	0750	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
004461	-00356	-00567	0375	0375	0375	0625	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
005676	-00447	-00552	0500	0500	0500	0500	0500	0500	0500	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
006891	-00293	-00551	0625	0625	0625	0625	0625	0625	0625	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
008113	-00104	-00372	0750	0750	0750	0250	0250	0250	0250	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009179	-00063	-00009	0875	0875	0875	0125	0125	0125	0125	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
009257	000001	-00025	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
000848	-00036	-00044	0000	0000	0000	1000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
001936	-00052	-00744	0125	0125	0125	0875	0875	0875	0875	0000	0000	0000	0000						

TUB-test chart GE39; Relative Device Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```