

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE50/GE50L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.00

TUB registration: 20091101-GE50/GE50L0NP.PDF /.PS TUB material: code=rha4ta
- application for evaluation and measurement of printer or monitor systems

[illegible]

TUB-test chart GE50; Relative Device Colour System C
1080 spectral reflexions R -> LAB* for D65 and D50

input: w *setgray*
output: no change compared to input

009725	-00109	000236	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009089	-00467	-00410	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008342	-00802	-00731	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
007857	-01159	-00805	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
007517	-01504	-00245	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
007309	-02327	-01502	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006134	-02121	-01815	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
005643	-02403	-02163	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005262	-02803	-02305	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
009102	000300	000892	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
008474	000004	000086	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
007946	-00405	-00413	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
007418	-00925	-00675	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
006846	-01177	-00905	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
006329	-00469	-01184	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
005685	-01702	-01599	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
005253	-02088	-01936	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
004764	-02214	-02309	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
008633	001000	001082	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
008073	000298	000725	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
007489	-00050	000134	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
006879	-00363	-00262	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
006355	-00442	-00595	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
005924	-01092	-00864	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
005416	-01468	-01208	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
004903	-01659	-01646	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
004467	-01907	-01921	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
008150	001358	001847	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
007598	000806	001323	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
007156	000457	000718	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
006331	000053	000128	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
005905	-00173	-00129	0500	0593	0625	0500	0406	0375	0000	00112	M05	\$
005663	-00774	-00541	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
004883	-00973	-00787	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
004477	-01344	-01352	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
004051	-01480	-01663	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007189	001856	002307	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
007695	001264	001999	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
006690	000817	001404	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
005960	000458	000698	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
005445	-00005	-00073	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
004811	-00139	-00099	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
004595	-00649	-00508	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
004206	-01208	-01049	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
003708	-00294	-01328	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
007152	002439	003169	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
006725	001746	002479	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
006145	001376	001989	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
005517	000943	001446	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
005025	000469	000821	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
004469	000102	000183	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
004250	-00349	-00163	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
003719	-00557	-00484	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003332	-01128	-01094	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
006694	003108	003817	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
006245	002313	002987	0875	0406	0500	0125	0593	0750	0000	00136	P02	\$
005732	001789	002431	0750	0375	0250	0250	0625	0750	0000	00137	P03	\$
005076	001420	002011	0625	0343	0250	0375	0656	0750	0000	00138	P04	\$
004610	000991	001362	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
004231	000408	000774	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
003569	000093	000244	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
003337	-00189	-00152	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
002967	-00548	-00504	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
006294	003691	004440	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
005791	002913	003558	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
005218	002553	003169	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
004647	001950	002527	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
004226	001357	001977	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
003736	000960	001342	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
003314	000368	000748	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
002939	000003	000046	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
002598	-00126	-00111	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
005738	004127	005141	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
005420	003630	004682	0750	0218	0000	0125	0781	1000	0000	00154	R02	\$
004792	003124	003873	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
004236	002496	003205	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
003665	002138	002442	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
003194	001633	001800	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
002844	001117	001206	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
002533	000533	000664	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
002099	000032	000117	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009723	-00097	000209	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
008921	000140	-00540	0806	0875	1000	0093	0125	0000	0000	00406	J11	\$
008163	000099	-00954	0812	0750	1000	0818	0250	0000	0000	00407	J12	\$
007635	000267	-01414	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
006804	000454	-01661	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
006144	000612	-02306	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
005459	000731	-02733	0347	0250	1000	0562	0750	0000	0000	00411	J16	\$
004763	000518	-03389	0543	0250	1000	0875	0875	0000	0000	00412	J17	\$
004231	000917	-03783	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
004045	-00427	000846	0968	1000	0875	0031	0000	0125	0000	00414	J19	\$
008665	-00010	000124	0875	0875	0875	0125	0125	0125	0000	00415	K10	\$
007887	000076	-00354	0781	0750	0875	0218	0250	0125	0000	00416	K12	\$
007265	000938	-00836	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
006456	000346	-01463	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
005801	000436	-01769	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
005223	000588	-02272	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
004600	000794	-02784	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
004043	000838	-03207	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
003917	-00750	001707	0937	1000	0750	0062	0000	0250	0000	00423	L10	\$
008463</												

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-GE50/GE50L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IOB material: code=rha4ta

TUB-test chart GE50; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE50/GE50L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=

009739	-00099	0002603	1000	1000	1000	0000	0000	0000	0000	%0162	S01
008952	-02728	-00636	0875	0937	1000	0125	0062	0000	0000	%0163	S02
008263	-00600	-00902	0750	0875	1000	0250	0125	0000	0000	%0164	S03
007601	-00864	-01067	0625	0812	1000	0375	0187	0000	0000	%0165	S04
007111	-00998	-01610	0500	0750	1000	0500	0250	0000	0000	%0166	S05
006529	-01235	-01790	0375	0687	1000	0625	0312	0000	0000	%0167	S06
005834	-01455	-02327	0250	0625	1000	0750	0375	0000	0000	%0168	S07
005349	-01700	-02613	0125	0562	1000	0875	0437	0000	0000	%0169	S08
004681	-01849	-02992	0000	0500	1000	1000	0500	0000	0000	%0170	S09
009278	000171	000810	1000	0937	0875	0000	0062	0125	0000	%0171	T01
008509	-00009	000105	0875	0875	0875	0125	0125	0125	0000	%0172	T02
007939	-00336	-00428	0750	0812	0875	0250	0187	0125	0000	%0173	T03
007341	-00641	-00770	0625	0750	0875	0375	0250	0125	0000	%0174	T04
006756	-00854	-01189	0500	0687	0875	0500	0312	0125	0000	%0175	T05
006176	-00998	-01519	0375	0625	0875	0625	0375	0125	0000	%0176	T06
005561	-01279	-01870	0250	0562	0875	0750	0437	0125	0000	%0177	T07
005083	-01524	-02028	0125	0500	0875	0875	0500	0125	0000	%0178	T08
004550	-01662	-02632	0000	0437	0875	1000	0562	0125	0000	%0179	T09
008844	000637	001290	1000	0875	0750	0000	0125	0250	0000	%0180	U01
008185	000246	000735	0875	0812	0750	0125	0187	0250	0000	%0181	U02
007571	-00054	000126	0750	0750	0750	0250	0250	0250	0000	%0182	U03
006858	-00252	-00347	0625	0687	0750	0375	0312	0250	0000	%0183	U04
006319	-00601	-00709	0500	0625	0750	0500	0375	0250	0000	%0184	U05
005773	-00711	-01094	0375	0562	0750	0625	0437	0250	0000	%0185	U06
005212	-01010	-01554	0250	0500	0750	0750	0500	0250	0000	%0186	U07
004743	-01264	-01876	0125	0437	0750	0875	0562	0250	0000	%0187	U08
004311	-01359	-02221	0000	0375	0750	1000	0625	0250	0000	%0188	U09
008543	000688	001293	1000	0812	0625	0000	0187	0375	0000	%0189	V01
007847	000418	002442	0875	0750	0625	0125	0250	0375	0000	%0190	V02
007258	000283	000722	0750	0687	0625	0250	0312	0375	0000	%0191	V03
006389	000053	000089	0625	0625	0625	0375	0375	0375	0000	%0192	V04
005923	-01335	-00175	0500	0562	0625	0500	0437	0375	0000	%0193	V05
005212	-00622	-00733	0375	0500	0625	0625	0500	0375	0000	%0194	V06
004735	-00740	-01125	0250	0437	0625	0750	0562	0375	0000	%0195	V07
004414	-01025	-01635	0125	0437	0625	0875	0625	0375	0000	%0196	V08
003921	-01127	-01907	0000	0312	0625	1000	0687				

099727	-00189	000234	1000	1000	1000	0000	0000	0000	0000	00486
098988	000276	-00411	0937	0875	1000	0062	0125	0000	0000	00487
098258	000375	-00809	0875	0750	1000	0125	0250	0000	0000	00488
007783	000721	-01184	0812	0625	1000	0187	0375	0000	0000	00489
007063	000895	-01261	0750	0500	1000	0250	0500	0000	0000	00490
006405	001353	-01849	0687	0375	1000	0312	0625	0000	0000	00491
005516	001688	-02284	0625	0250	1000	0375	0750	0000	0000	00492
005429	001936	-02899	0562	0125	1000	0437	0875	0000	0000	00493
004303	002264	-03274	0500	0000	1000	0500	1000	0000	0000	00494
009397	-000586	000608	0937	1000	0875	0062	0000	0125	0000	00495
008782	-000209	000115	0875	0875	0875	0125	0125	0125	0000	00496
008025	000215	-00322	0812	0750	0875	0187	0250	0125	0000	00497
004734	000409	-00648	0750	0625	0875	0250	0375	0125	0000	00498
006659	000707	-01161	0687	0500	0875	0312	0500	0125	0000	00499
006104	001444	-01444	0625	0250	0875	0375	0625	0125	0000	00500
005269	001473	-01943	0562	0250	0875	0437	0750	0125	0000	00501
004658	001703	-02284	0500	0125	0875	0500	0875	0125	0000	00502
003964	002067	-02804	0437	0000	0875	0562	1000	0125	0000	00503
009189	-01144	001477	0875	1000	0750	0125	0000	0250	0000	00504
008382	-00427	000576	0812	0875	0750	0187	0125	0250	0000	00505
007703	-00058	000134	0750	0750	0750	0250	0250	0250	0000	00506
006964	000248	-00330	0687	0625	0750	0312	0375	0250	0000	00507
006212	000586	-00712	0625	0500	0750	0375	0500	0250	0000	00508
005582	000861	-01118	0562	0375	0750	0437	0625	0250	0000	00509
004924	001117	-01590	0500	0250	0750	0500	0500	0250	0000	00510
004255	001436	-02003	0437	0125	0750	0562	0875	0250	0000	00511
003644	001809	-02364	0375	0000	0750	0625	1000	0250	0000	00512
008881	-011430	001899	0812	1000	0625	0187	0000	0375	0000	00513
008190	-01055	001385	0750	0875	0625	0250	0125	0375	0000	00514
007400	-00493	000666	0687	0750	0625	0312	0250	0375	0000	00515
006496	000301	000077	0625	0625	0625	0375	0375	0375	0000	00516
005938	000293	-00307	0562	0500	0625	0437	0500	0375	0000	00517
005413	000472	-00763	0500	0375	0625	0500	0625	0375	0000	00518
004537	000899	-01164	0437	0250	0625	0562	0750	0375	0000	00519
004112	001055	-01583	0375	0125	0625	0625	0875	0375	0000	00520
003332	001566	-01947	0312	0000	0625	0687	1000	0375	0000	00521
008544	-01851	002692	0750	1000	0500	0250	0000	0500	0000	00522
007798	-01476	001597	0687	0875	050					

[illegible]

009745	-00103	000204	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$	009732	-00094	000198	1000	1000	1000	0000	0000	0000	%0567	b10	\$	009719	-00099	000215	1000	1000	1000	0000	0000	0000	0000	0000	%0891	b19	\$	
008906	-00122	-00665	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$	009076	000468	-00315	0968	0875	1000	0031	0125	0000	0000	%0568	b11	\$	008997	000627	000458	1000	0875	0906	0000	0125	0093	0000	%0892	b20	\$	
008119	-00381	-00943	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$	008367	000859	-00662	0937	0750	1000	0062	0250	0000	0000	%0569	b12	\$	008454	001402	000635	1000	0750	0812	0000	0250	0187	0000	%0893	b21	\$	
007519	-00504	-01347	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$	007851	-001293	-00900	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$	007810	002261	000835	1000	0625	0718	0000	0375	0281	0000	%0894	b22	\$	
006307	-00670	-01823	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$	007151	-001727	-00965	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$	007169	002932	001474	1000	0500	0625	0000	0500	0375	0000	%0895	b23	\$	
006308	-00828	-02185	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$	006646	002208	-01337	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$	006482	003908	001808	1000	0375	0531	0000	0625	0468	0000	%0896	b24	\$	
005596	-00930	-02766	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$	005940	002769	-01623	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$	005942	004709	002257	1000	0250	0437	0000	0750	0562	0000	%0897	b25	\$	
005073	-01056	-03118	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$	005159	003367	-01903	0781	0125	1000	0217	0875	0000	0000	%0574	b17	\$	005334	005237	002714	1000	0125	0343	0000	0875	0556	0000	%0898	b26	\$	
004522	-01156	-03596	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$	004529	003317	-02578	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$	004708	006143	002822	1000	0000	0250	1000	0750	0556	0000	%0899	b27	\$	
003471	-00904	-000794	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$	003951	-00755	-006538	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$	009239	-00668	-00122	0875	1000	0968	0125	0000	0031	0000	%0900	c19	\$	
008525	-00015	000117	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$	008675	-00013	-000089	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$	008612	-00022	000081	0875	0875	0875	0125	0125	0125	0000	%0901	c20	\$	
007850	-00231	-00415	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$	008063	000407	-00387	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$	008007	000611	000391	0875	0750	0781	0125	0250	0218	0000	%0902	c21	\$	
007212	-00437	-00932	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$	007385	000861	-00597	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$	007382	001328	000760	0875	0625	0687	0125	0375	0312	0000	%0903	c22	\$	
006564	-00543	-01374	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$	006814	001418	-00816	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$	006826	002031	001100	0875	0500	0593	0125	0500	0406	0000	%0904	c23	\$	
006006	-00627	-01746	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$	006101	001815	-01038	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$	006139	002798	001475	0875	0375	0500	0125	0625	0500	0000	%0905	c24	\$	
005380	-00853	-02223	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$	005459	002376	-01369	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$	005476	003669	001853	0875	0250	0406	0125	0750	0593	0000	%0906	c25	\$	
004819	-00920	-02683	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$	004760	002846	-01719	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$	004834	004589	002278	0875	0125	0312	0125	0875	0687	0000	%0907	c26	\$	
004237	-01076	-03050	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$	004150	003356	-02067	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$	004293	005380	002512	0875	0000	0218	0125	1000	0781	0000	%0908	c27	\$	
009094	-000188	-001589	1000	0937	0750	0000	0602	0250	0000	%0261	d01	\$	009065	-01233	-001059	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$	008637	-01084	-00276	0750	1000	0937	0250	0000	0602	0000	%0909	d19	\$	
008299	-00006	-000834	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$	008363	-00636	-000539	0781	0875	0750	0218	0125	0250	0000	%0586	d11	\$	008141	-00564	-00205	0750	0875	0843	0250	0125	0156	0000	%0910	d20	\$	
007525	-00049	-000114	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$	007736	-00057	-000122	0750	0750	0750	0250	0250	0250	0000	%0587	d12	\$	007670	-00047	-000114	0750	0750	0750	0250	0250	0250	0000	%0911	d21	\$	
006777	-00172	-00429	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$	007076	-000373	-00270	0718	0625	0750	0281	0375	0250	0000	%0588	d13	\$	007049	-000782	-000399	0750	0625	0656	0250	0375	0343	0000	%0912	d22	\$	
006216	-00479	-00886	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$	006311	000959	-00599	0687	0500	0750	0312	0500	0250	0000	%0589	d14	\$	006394	001443	000780	0750	0500	0562	0250	0500	0437	0000	%0913	d23	\$	
005659	-00592	-01349	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$	005677	-001377	-00772	0656	0375	0750	0343	0625	0250	0000	%0590	d15	\$	005714	002006	001199	0750	0375	0468	0250	0625	0531	0000	%0914	d24	\$	
004989	-00702	-01902	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$	005040	-001822	-01197	0625	0250	0750	0375	0750	0250	0000	%0591	d16	\$	004991	002856	001573	0750	0250	0375	0250	0750	0625	0000	%0915	d25	\$	
004547	-00840	-02246	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$	004388	002395	-01496	0593	0125	0750	0406	0875	0250	0000	%0592	d17	\$	004392	003639	001965	0750	0125	0281	0250	0875	0718	0000	%0916	d26	\$	
003977	-00769	-02698	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$	003801	-002912	-01758	0562	0000	0750	0437	1000	0250	0000	%0593	d18	\$	003789	004445	002122	0750	0000	0187	0250	1000	0812	0000	%0917	d27	\$	
008885	-000128	-002569	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$	008569	-01626	-001598	0718	1000	0625	0281	0000	0375	0000	%0594	e10	\$	008320	-01488	-00126	0625	1000	0906	0375	0000	0093	0000	%0918	e19	\$	
008093	-00015	-001804	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$	008024	-01346	-001259	0687	0875	0625	0312	0125	0375	0000	%0595	e11	\$	007697	-01174	-00057	0625	0875	0812	0375	0125	0187	0000	%0919	e20	\$	
007398	-00067	-000845	0750	0718	0625	0250	0250	0281	0375	0000	%0272	e03	\$	007337	-00636	-000627	0656	0750	0625	0343	0250	0375	0000	%0596	e12	\$	007070	-00430	-00071	0625	0750	0718	0375	0250	0281	0000	%0920	e21	\$
006340	-00061	-000556	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$	006516	-000037	-000059	0625	0625	0625	0375	0375	0375	0000	%0597	e13	\$	006375	-000605	-000072	0625	0625	0625	0375	0375	0375	0000	%0921	e22	\$	
005900	-00008	-00206	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$	005973	-00049	-00201	0593	0500	0625	0406	0500	0375	0000	%0598	e14	\$	005824	-000680	-000520	0625	0500	0531	0375	0600	0468	0000	%0922	e23	\$	
005466	-00472	-00902	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$	005463	-000828	-00517	0562	0375	0625	0437	0625	0375	0000	%0599	e15	\$	005193	-001309	-000943	0625	0375	0437	0375	0625	0562	0000	%0923	e24	\$	
004483	-00385	-01442	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$	004926	-001441	-00848	0531	0250	0625	0468	0750	0375	0000	%0600	e16	\$	004485	-002128	-001250	0625	0250	0343	0375	0750	0656	0000	%0924	e25	\$	
004196	-00752	-01882	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$	004126	-001799	-01166	0500	0125	0625	0500	0875	0375	0000	%0601	e17	\$	003938	-002846	-001570											

See original or copy: <http://web.me.com/klaus.richter/GE50/GE50L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG GE40_22.TXT, Separation olv*, cfi=0.90, D65, not adapted $
%100 x LAB*      %1000 x (r g b c m y 0)      %nr.      pos $
%z004751 006172 004059 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z009299 -01722 009313 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z006051 -05756 003861 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005894 -03979 -01940 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z004047 -00366 -04439 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z004677 006766 -01265 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z001913 000031 000157 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009726 -00101 000214 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%z004751 006172 004059 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z009299 -01722 009313 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z006051 -05756 003861 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005894 -03979 -01940 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z004047 -00366 -04439 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z004677 006766 -01265 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z001913 000031 000157 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009726 -00101 000214 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%z004751 006172 004059 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z009299 -01722 009313 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z006051 -05756 003861 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005894 -03979 -01940 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z004047 -00366 -04439 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z004677 006766 -01265 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z001913 000031 000157 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009726 -00101 000214 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%z005738 004127 005141 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z008233 -02935 007497 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005952 -05077 001177 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z005262 -02889 -02385 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z004231 000917 -03783 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z004719 006538 000563 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z001979 000033 000143 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009723 -00104 000224 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%z006661 002874 006116 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z007230 -04095 005966 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005984 -04963 000380 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z004861 -01849 -02992 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z004303 002264 -03274 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004705 006319 001878 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z002013 000028 000139 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009732 -00101 000212 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%z007693 000982 007407 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z006550 -04908 004833 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005739 -04389 -00785 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z004522 -01156 -03586 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z004695 003917 -02578 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004708 006143 002822 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z001879 000034 000154 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009732 -00099 000206 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE50/GE50L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG GE40.22.TXT, Separation olv*, cfi=0.90, D65, not adapted S
%100 x LAB*      1000 x (r g b      c m y 0)      %nr. pos $
001671 000008 000172 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002524 -00007 000102 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003198 000092 000261 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004184 000103 000233 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005264 000012 000098 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006352 000059 000098 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
007609 -00046 000123 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008638 -00028 000114 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009755 -00008 000100 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
001729 000017 000166 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002579 -00002 000074 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003193 000098 000222 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004181 000114 000170 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005260 000024 000065 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006383 000057 000067 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
007634 -00045 000118 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
008670 -00013 000111 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009751 -00101 000211 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
001749 000018 000155 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002543 -00006 000069 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003207 000094 000221 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004197 000117 000176 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
005296 000012 000076 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006352 -00045 000078 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
007665 -00048 000118 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
008691 -00018 000115 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009750 -00101 000210 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
001689 000018 000153 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002507 -00005 000092 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003204 000088 000251 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004237 000103 000186 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005332 000006 000089 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006442 000058 000083 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
007682 -00051 000112 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008683 -00018 000121 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009751 -00098 000195 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
002103 000022 000128 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
002204 000170 000170 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002854 000006 000039 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
003117 000064 000119 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
003557 000104 000186 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
004161 000023 000151 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
004468 000107 000250 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005288 -00004 000134 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
005647 000068 000209 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006215 000118 000160 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
006836 -00003 000125 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007466 000031 000101 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
007961 000075 000098 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
008411 000035 000044 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
009088 -00027 000162 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009743 -00096 000191 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
002158 000024 000120 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
002237 000184 000174 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
002891 000007 000033 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
003155 000070 000096 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
003598 000107 000164 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
004202 000026 000133 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
004553 000111 000227 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005352 000002 000088 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
005653 000083 000150 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006231 000128 000097 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
006802 -00001 000095 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007459 000030 000085 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
007949 000078 000085 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
008434 000036 000033 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
009122 -00024 000156 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009734 -00099 000185 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
002141 000023 000117 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
002243 000180 000161 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002868 000006 000017 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
003154 000062 000102 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
003570 000113 000149 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
004196 000023 000125 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
004545 000097 000223 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005333 -00012 000100 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
005657 000073 000159 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006239 000115 000120 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
006813 000000 000089 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007451 000027 000089 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
007990 000055 000099 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE50; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: -> olv* setrgbcolor

TUB registration: 20091101-GE50/GE50L0NP.PDF /.PS
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE50/GE50L0NP.PDF> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=

TUB registration: 20091101-GE50/GE50L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IUB material: code=rh4ta

[illegible]

TUB-test chart GE50; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> oly* setrgbcolor
```

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009725	-00005	000012	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009089	-00373	-00628	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008342	-00721	-00941	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
007857	-01088	-01010	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
007517	-01439	-00446	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
007309	-02266	-01702	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006134	-02081	-02002	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
005643	-02371	-02345	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005262	-02864	-02564	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
009102	000394	000674	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
008474	000087	-00125	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
007946	-00332	-00619	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
007418	-00861	-00876	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
006846	-01123	-01179	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
006329	-01416	-01373	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
005685	-01669	-01782	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
005253	-02063	-02114	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
004764	-02198	-02482	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
008633	001085	000869	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
008073	000373	000517	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
007489	000014	-00066	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
006879	-00308	-00457	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
006355	-00797	-00784	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
005924	-01055	-01049	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
005416	-01440	-01388	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
004903	-01640	-01821	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
004467	-01896	-02091	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
008150	001434	001638	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
007598	000873	001121	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
007156	000516	000513	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
006331	000097	-00061	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
005905	-00136	-00314	0500	0593	0625	0500	0406	0375	0000	00112	M05	\$
005663	-00741	-00723	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
004883	-00954	-00961	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
004477	-01333	-01522	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
004051	-01477	-01828	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007699	001925	002104	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
007185	001323	001801	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
006690	000868	001211	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
005960	000496	000513	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
005445	000034	-00106	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
004811	-00122	-00263	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
004595	-00635	-00679	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
004206	-01202	-01217	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
003508	-01299	-01487	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
007172	002498	002971	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
006725	001792	002286	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
006145	001417	001802	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
005517	000973	001266	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
005025	000490	000646	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
004469	000114	000013	0375	0375	0375	0375	0625	0625	0000	00131	O06	\$
004250	-00341	-00331	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
003719	-00559	-00646	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003332	-01129	-01162	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
006694	003158	003624	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
006245	002356	002799	0875	0406	0500	0125	0593	0750	0000	00136	P02	\$
005732	001823	002248	0750	0375	0250	0250	0625	0750	0000	00137	P03	\$
005076	001448	001825	0625	0343	0250	0375	0656	0750	0000	00138	P04	\$
004610	001005	001191	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
004231	000415	000607	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
003569	000088	000084	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
003367	-00198	-00310	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
002937	-00555	-00658	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
006294	003735	004251	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
005791	002948	003380	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
005218	002577	002982	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
004647	001964	002355	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
004226	001364	001810	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
003736	000958	001180	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
003314	000359	000590	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
002939	-00012	-00107	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
002598	-00148	-00261	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
005738	004161	004958	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
005420	003655	004504	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
004792	003139	003701	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
004236	002503	003037	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
003665	002135	002281	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
003194	001621	001643	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
002844	001099	001953	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
002533	000510	000515	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
002099	000011	-00028	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009723	000007	-00014	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
008921	000230	-00756	0906	0875	1000	0093	0125	0000	0000	00406	J11	\$
008163	000176	-01163	0812	0750	1000	0187	0250	0000	0000	00407	J12	\$
007635	000335	-01617	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
006804	000507	-01856	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
006144	000653	-02493	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
005459	000760	-02913	0347	0250	1000	0562	0750	0000	0000	00411	J16	\$
005783	000535	-03562	0433	0250	1000	0875	0875	0000	0000	00412	J17	\$
004231	000824	-03951	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
004945	-00326	-00624	0968	1000	0875	0031	0000	0125	0000	00414	K01	\$
008665	000075	-00089	0875	0875	0875	0125	0125	0125	0000	00415	K11	\$
007887	000148	-00559	0812	0750	0875	0218	0250	0125	0000	00416	K12	\$
007265	000099	-01035	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
006456	000393	-01654	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
005801	000471	-01953	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
005223	000613	-02450	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
004600	000808	-02955	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
004043	000841	-03372	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
009317	-00652	001487	0937	1000	0750	0062	0000	0250	0000	00423	L10	\$
0084												

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-GE50/GE50L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

TUB-test chart GE50; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE50/GE50L0NP.PDF> / PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cf1=0.90; nt=0.18; nx=1.00

[illegible]

TUB registration: 20091101-GE50/GE50LONP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

TUB-test chart GE50; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE50/GE50L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=

[illegible]

See original or copy: <http://web.me.com/klaus.richter/GE50/GE50L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG GE40_22.TXT, Separation olv*, cfi=0.90, D65, adapted $
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr.    pos $
%Z004751 006189 003881 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009299 -01627 009102 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z006051 -05717 003674 %1000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005894 -03943 -02126 %1000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z004047 -00361 -04612 %1000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004677 006782 -01442 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001913 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009726 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%$
%Z004751 006189 003881 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009299 -01627 009102 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z006051 -05717 003674 %1000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005894 -03943 -02126 %1000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z004047 -00361 -04612 %1000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004677 006782 -01442 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001913 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009726 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%$
%Z004751 006189 003881 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009299 -01627 009102 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z006051 -05717 003674 %1000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005894 -03943 -02126 %1000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z004047 -00361 -04612 %1000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004677 006782 -01442 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001913 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009726 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%$
%Z005738 004161 004958 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008233 -02856 007288 %1000 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005952 -05039 000991 %1000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005262 -02864 -02564 %1000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z004231 000924 -03951 %1000 0250 0000 1000 0750 1000 0000 %0413 J18 %V25M 4 $
%Z004719 006553 000390 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001979 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009723 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%$
%Z006661 002924 005933 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007230 -04035 005777 %1000 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005984 -04925 000203 %1000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004861 -01830 -03159 %1000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z004303 002274 -03435 %1000 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004705 006336 001713 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z002013 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009732 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%$
%Z007693 001046 007214 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006550 -04863 004648 %1000 0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005739 -04358 -00965 %1000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z004522 -01146 -03758 %1000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004695 003931 -02751 %1000 0750 0000 1000 0250 1000 0000 %0575 b18 %V75M 4 $
%Z004708 006157 002649 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001879 000000 000000 %1000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009732 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%$
```

See original or copy: <http://web.me.com/klaus.richter/GE50/GE50L0NP.PDF> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0



<http://130.149.60.45/~farbmetrik/GE50/GE50L0NP.PDF> / .PS, Page 12/24; FRS09_92, L*=09_92
N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)


%BEG GE40_22.TXT, Separation olv*, cfi=0.90, D65, adapted \$
%100 x LAB*a 1000 x (r g b c m y 0) %nr. pos \$
001671 -00024 000025 0000 0000 0000 1000 1000 1000 0000 %0972 k01 \$
002524 -00025 -00051 0125 0125 0125 0875 0875 0875 0000 %0973 k02 \$
003198 000086 000102 0250 0250 0250 0750 0750 0750 0000 %0974 k03 \$
004184 000113 000067 0375 0375 0375 0625 0625 0625 0000 %0975 k04 \$
005264 000041 -00075 0500 0500 0500 0500 0500 0500 0000 %0976 k05 \$
006352 000106 -00092 0625 0625 0625 0375 0375 0375 0000 %0977 k06 \$
007608 000022 -00069 0750 0750 0750 0250 0250 0250 0000 %0978 k07 \$
008638 000005 -00086 0875 0875 0875 0125 0125 0125 0000 %0979 k08 \$
009755 000007 -00099 1000 1000 1000 0000 0000 0000 %0980 k09 \$
010728 -00014 000018 0000 0000 0000 1000 1000 1000 0000 %0981 l01 \$
002579 -00019 00078 0125 0125 0125 0875 0875 0875 0000 %0982 l02 \$
003193 000091 000063 0250 0250 0250 0750 0750 0750 0000 %0983 l03 \$
004181 000124 000004 0375 0375 0375 0625 0625 0625 0000 %0984 l04 \$
005260 000053 -00108 0500 0500 0500 0500 0500 0500 0000 %0985 l05 \$
006383 000105 -00115 0625 0625 0625 0375 0375 0375 0000 %0986 l06 \$
007634 000023 -00074 0750 0750 0750 0250 0250 0250 0000 %0987 l07 \$
008670 000072 -00089 0875 0875 0875 0125 0125 0125 0000 %0988 l08 \$
009751 000003 000001 1000 1000 1000 0000 0000 0000 %0989 l09 \$
010749 -00012 000007 0000 0000 0000 1000 1000 1000 0000 %0990 m01 \$
002543 -00024 -00083 0125 0125 0125 0875 0875 0875 0000 %0991 m02 \$
003207 000088 000062 0250 0250 0250 0750 0750 0750 0000 %0992 k03 \$
004197 000128 000010 0375 0375 0375 0625 0625 0625 0000 %0993 k04 \$
005296 000042 -00098 0500 0500 0500 0500 0500 0500 0000 %0994 m05 \$
006352 000092 -00104 0625 0625 0625 0375 0375 0375 0000 %0995 m06 \$
007665 000021 -00075 0750 0750 0750 0250 0250 0250 0000 %0996 m07 \$
008691 000069 -00085 0875 0875 0875 0125 0125 0125 0000 %0997 m08 \$
009750 000003 000001 1000 1000 1000 0000 0000 0000 %0998 m09 \$
010689 -00013 000006 0000 0000 0000 1000 1000 1000 0000 %0999 n01 \$
002507 -00023 -00061 0125 0125 0125 0875 0875 0875 0000 %1000 n02 \$
003204 000081 000092 0250 0250 0250 0750 0750 0750 0000 %1001 n03 \$
004237 000115 000019 0375 0375 0375 0625 0625 0625 0000 %1002 n04 \$
005332 000036 -00086 0500 0500 0500 0500 0500 0500 0000 %1003 n05 \$
006442 000009 -00100 0625 0625 0625 0375 0375 0375 0000 %1004 n06 \$
007682 000018 -00080 0750 0750 0750 0250 0250 0250 0000 %1005 n07 \$
008683 000068 -00079 0875 0875 0875 0125 0125 0125 0000 %1006 n08 \$
009751 000006 -00013 1000 1000 1000 0000 0000 0000 %1007 n09 \$
002103 -00002 -00021 0000 0000 0000 1000 1000 1000 0000 %1008 k10 \$
002204 000147 000019 0066 0066 0066 0933 0933 0933 0000 %1009 k11 \$
002854 -00006 -00116 0133 0133 0133 0866 0866 0866 0000 %1010 k12 \$
003117 000056 -00038 0200 0200 0200 0800 0800 0800 0000 %1011 k13 \$
003557 000104 000025 0266 0266 0266 0733 0733 0733 0000 %1012 k14 \$
004161 000033 -00014 0333 0333 0333 0666 0666 0666 0000 %1013 k15 \$
004468 000122 000081 0400 0400 0400 0600 0600 0600 0000 %1014 k16 \$
005288 000024 -00040 0466 0466 0466 0533 0533 0533 0000 %1015 k17 \$
005647 000104 000031 0533 0533 0533 0466 0466 0466 0000 %1016 k18 \$
006215 000163 -00021 0600 0600 0600 0399 0399 0399 0000 %1017 k19 \$
006836 000051 -00060 0666 0666 0666 0333 0333 0333 0000 %1018 k20 \$
007466 000097 -00090 0733 0733 0733 0266 0266 0266 0000 %1019 k21 \$
007961 000149 -00096 0800 0800 0800 0199 0199 0199 0000 %1020 k22 \$
008411 000117 -00154 0866 0866 0866 0133 0133 0133 0000 %1021 k23 \$
009088 000066 -00041 0933 0933 0933 0066 0066 0066 0000 %1022 k24 \$
009743 000008 -00017 1000 1000 1000 0000 0000 0000 %1023 k25 \$
002158 000000 -00029 0000 0000 0000 1000 1000 1000 0000 %1024 l10 \$
002237 000161 000023 0066 0066 0066 0933 0933 0933 0000 %1025 l11 \$
002891 -00004 -00122 0133 0133 0133 0866 0866 0866 0000 %1026 l12 \$
003155 000063 -00062 0200 0200 0200 0800 0800 0800 0000 %1027 l13 \$
003598 000108 000002 0266 0266 0266 0733 0733 0733 0000 %1028 l14 \$
004202 000037 -00032 0333 0333 0333 0666 0666 0666 0000 %1029 l15 \$
004553 000128 000058 0400 0400 0400 0600 0600 0600 0000 %1030 l16 \$
005352 000032 -00086 0466 0466 0466 0533 0533 0533 0000 %1031 l17 \$
005653 000118 -00027 0533 0533 0533 0466 0466 0466 0000 %1032 l18 \$
006231 000173 -00085 0600 0600 0600 0399 0399 0399 0000 %1033 l19 \$
006802 000053 -00090 0666 0666 0666 0333 0333 0333 0000 %1034 l20 \$
007459 000096 -00106 0733 0733 0733 0266 0266 0266 0000 %1035 l21 \$
007949 000152 -00110 0800 0800 0800 0199 0199 0199 0000 %1036 l22 \$
008434 000118 -00165 0866 0866 0866 0133 0133 0133 0000 %1037 l23 \$
009122 000070 -00048 0933 0933 0933 0066 0066 0066 0000 %1038 l24 \$
009734 000005 -00023 1000 1000 1000 0000 0000 0000 %1039 l25 \$
002141 000000 -00032 0000 0000 0000 1000 1000 1000 0000 %1040 m10 \$
002243 000157 000009 0066 0066 0066 0933 0933 0933 0000 %1041 m11 \$
002868 -00005 -00138 0133 0133 0133 0866 0866 0866 0000 %1042 m12 \$
003154 000054 -00055 0200 0200 0200 0800 0800 0800 0000 %1043 m13 \$
003570 000113 -00011 0266 0266 0266 0733 0733 0733 0000 %1044 m14 \$
004196 000034 -00040 0333 0333 0333 0666 0666 0666 0000 %1045 m15 \$
004545 000114 000054 0400 0400 0400 0600 0600 0600 0000 %1046 m16 \$
005333 000017 -00074 0466 0466 0466 0533 0533 0533 0000 %1047 m17 \$
005657 000109 -00018 0533 0533 0533 0466 0466 0466 0000 %1048 m18 \$
006239 000160 -00061 0600 0600 0600 0399 0399 0399 0000 %1049 m19 \$
006813 000054 -00097 0666 0666 0666 0333 0333 0333 0000 %1050 m20 \$
007451 000093 -00102 0733 0733 0733 0266 0266 0266 0000 %1051 m21 \$
007990 000130 -00096 0800 0800 0800 0199 0199 0199 0000 %1052 m22 \$

TUB-test chart GE50; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: ->olv* setrgbcolor



TUB registration: 20091101-GE50/GE50L0NP.PDF / .PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta



N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

%BEG	GE40	22.TXT	Separation	olv*	cf1=0.90	D50	not adapted	S	%nr.	pos	\$	%BEG	GE40	22.TXT	Separation	olv*	cf1=0.90	D50	not adapted	S	%nr.	pos	\$
%100 x LAB*			1000 x (r g b									%100 x LAB*			1000 x (r g b								
009736	-00073	000212	1000	1000	1000	0000	0000	0000	0000	0000	0000	009732	-00072	000199	1000	1000	1000	0000	0000	0000	0000	0000	0000
009180	-00767	-00197	0875	1000	1000	0125	0000	0000	0000	0000	0000	008909	-00135	-00675	0875	0875	1000	0125	0000	0000	0000	0000	0000
008468	-01066	-00662	0750	1000	1000	0250	0000	0000	0000	0000	0000	007993	-00329	-01146	0750	0750	1000	0250	0000	0000	0000	0000	0000
008075	-01575	-00574	0625	1000	1000	0375	0000	0000	0000	0000	0000	007512	-00428	-01650	0625	0625	1000	0375	0000	0000	0000	0000	0000
007499	-01982	-00899	0500	1000	1000	0500	0000	0000	0000	0000	0000	006522	-00446	-02214	0500	0500	1000	0500	0000	0000	0000	0000	0000
007231	-02548	-01741	0375	1000	1000	0625	0000	0000	0000	0000	0000	005813	-00611	-02817	0375	0375	1000	0625	0000	0000	0000	0000	0000
006554	-03352	-01713	0250	1000	1000	0750	0000	0000	0000	0000	0000	005193	-00799	-03395	0250	0250	1000	0750	0000	0000	0000	0000	0000
006121	-04269	-02020	0125	1000	1000	0875	0000	0000	0000	0000	0000	004532	-00856	-03857	0125	0125	1000	0875	0000	0000	0000	0000	0000
005771	-04281	-02240	0000	1000	1000	1000	0000	0000	0000	0000	0000	003924	-01088	-04651	0000	1000	1000	0000	0000	0000	0000	0000	0000
008978	000005	000675	1000	0875	0875	0000	0125	0125	0000	0000	0000	009669	-00288	001061	1000	1000	0875	0000	0000	0125	0000	0000	0000
008444	000006	000146	0875	0875	0875	0125	0125	0125	0000	0000	0000	008652	-00008	000140	0875	0875	0125	0125	0125	0000	0000	0000	0000
007975	-00539	-00230	0750	0875	0875	0250	0125	0125	0000	0000	0000	007890	-00311	-00443	0750	0750	0875	0250	0250	0125	0000	0000	0000
007480	-01167	-00405	0625	0875	0875	0375	0125	0125	0000	0000	0000	007183	-00415	-01150	0625	0625	0875	0375	0125	0125	0000	0000	0000
006924	-01550	-00785	0500	0875	0875	0500	0125	0125	0000	0000	0000	006332	-00480	-01763	0500	0500	0875	0500	0500	0125	0000	0000	0000
006444	-01997	-01073	0375	0875	0875	0625	0125	0125	0000	0000	0000	005585	-00406	-02154	0375	0375	0875	0625	0625	0125	0000	0000	0000
005847	-02342	-01551	0250	0875	0875	0750	0125	0125	0000	0000	0000	004953	-00718	-02790	0250	0250	0875	0750	0750	0125	0000	0000	0000
005446	-03043	-01652	0125	0875	0875	0875	0125	0125	0000	0000	0000	004325	-00860	-03426	0125	0125	0875	0875	0875	0125	0000	0000	0000
006047	-03875	-01997	0000	0875	0875	1000	0125	0125	0000	0000	0000	003665	-00947	-03973	0000	0000	0875	1000	1000	0125	0000	0000	0000
008459	001565	000940	1000	0750	0750	0000	0250	0250	0000	0000	0000	009531	-00300	001937	1000	1000	0750	0000	0000	0250	0000	0000	0000
007924	000691	000495	0875	0750	0750	0125	0250	0250	0000	0000	0000	008625	-00104	001004	0875	0875	0750	0125	0125	0250	0000	0000	0000
007443	-00024	000135	0750	0750	0750	0250	0250	0250	0000	0000	0000	007627	-00033	001042	0750	0750	0250	0250	0250	0250	0000	0000	0000
006892	-00461	-00178	0625	0750	0750	0375	0250	0250	0000	0000	0000	006782	-00137	-00450	0625	0625	0750	0375	0375	0250	0000	0000	0000
006424	-01107	-00449	0500	0750	0750	0500	0250	0250	0000	0000	0000	006099	-00337	-01116	0500	0500	0750	0500	0500	0250	0000	0000	0000
005990	-01465	-00742	0375	0750	0750	0625	0250	0250	0000	0000	0000	005459	-00390	-01716	0375	0375	0750	0625	0625	0250	0000	0000	0000
005517	-01890	-01094	0250	0750	0750	0750	0250	0250	0000	0000	0000	004736	-00499	-02276	0250	0250	0750	0750	0250	0250	0000	0000	0000
005120	-02536	-01299	0125	0750	0750	0875	0250	0250	0000	0000	0000	004189	-00650	-02835	0125	0125	0750	0875	0875	0250	0000	0000	0000
004547	-02810	-01549	0000	0750	0750	1000	0250	0250	0000	0000	0000	003511	-00738	-03391	0000	0000	0750	1000	1000	0250	0000	0000	0000
007777	002422	001454	1000	0625	0625	0000	0375	0375	0000	0000	0000	009340	-00233	002848	1000	1000	0625	0000	0000	0375	0000	0000	0000
007351	001529	000956	0875	0625	0625	0125	0375	0375	0000	0000	0000	008574	-00155	002688	0875	0875	0625	0125	0125	0375	0000	0000	0000
007605	000829	000572	0750	0625	0625	0250	0375	0375	0000	0000	0000	007672	-00092	000948	0750	0750	0625	0250	0250	0375	0000	0000	0000
006300	000095	000092	0625	0625	0625	0375	0375	0375	0000	0000	0000	006595	000055	000066	0625	0625	0625	0375	0375	0375	0000	0000	0000
005951	-00207	-00077	0500	0125	0125	0500	0375	0375	0000	0000	0000	005987	-00012	-00378	0500	0500	0625	0500	0500	0375	0000	0000	0000
005652	-00079	-00047	0375	0625	0625	0625	0375	0375	0000	0000	0000	005147	-00261	-01311	0375	0375	0625	0625	0625	0375	0000	0000	0000
005013	-01366	-00752	0250	0625	0625	0750	0375	0375	0000	0000	0000	004412	-00293	-01790	0250	0250	0625	0750	0750	0375	0000	0000	0000
004662	-01968	-01141	0125	0625	0625	0875	0375	0375	0000	0000	0000	003908	-00545	-02456	0125	0125	0625	0875	0875	0375	0000	0000	0000
004260	-02193	-01310	0000	0625	0625	1000	0375	0375	0000	0000	0000	003249	-00749	-02951	0000	0000	0625	1000	1000	0375	0000	0000	0000
007180	003250	002073	1000	0500	0500	0000	0500	0500	0000	0000	0000	009306	-00395	003884	1000	1000	0500	0000	0000	0500	0000	0000	0000
006888	002356	001626	0875	0500	0500	0125	0500	0500	0000	0000	0000	008482	-00292	003138	0875	0875	0500	0125	0125	0500	0000	0000	0000
006451	001561	001177	0750	0500	0500	0500	0250	0500	0000	0000	0000	007630	-00164	002196	0750	0750	0500	0250	0250	0500	0000	0000	0000
005865	000773	000654	0625	0500	0500	0375	0500	0500	0000	0000	0000	006455	-00091	001101	0625	0625	0500	0375	0375	0500	0000	0000	0000
005417	000026	000100	0500	0500	0500	0500	0500	0500	0000	0000	0000	005483	000027	000089	0500	0500	0500	0500	0500	0500	0000	0000	0000
004931	-00258	-00069	0375	0500	0500	0625	0500	0500	0000	0000	0000	004768	000056	-00360	0375	0375	0500	0625	0625	0500	0000	0000	0000
004701	-00870	-00343	0250	0500	0500	0750	0500	0500	0000	0000	0000	004267	-00243	-01298	0250	0250	0500	0750	0750	0500	0000	0000	0000
004263	-01572	-00917	0125	0500	0500	0875	0500	0500	0000	0000	0000	003515	-00321	-01779	0125	0125	0500	0875	0875	0500	0000	0000	0000
003659	-01793	-01042	0000	0500	0500	1000	0500	0500	0000	0000	0000	002843	-00616	-02383	0000	0000	0500	1000	1000	0500	0000	0000	0000
006698	003971	002603	1000	0375	0375	0000	0625	0625	0000	0000	0000	009252	-00548	005225	1000	1000	0375	0000	0000	0625	0000	0000	0000
006336	002957	002147	0875	0375	0375	0125	0625	0625	0000	0000	0000	008473	-00442	004411	0875	0875	0375	0125	0125	0625	0000	0000	0000
005882	002208	001673	0750	0375	0375	0250	0625	0625	0000	0000	0000	007560	-00243	003299	0750	0750	0375	0250	0250	0625	0000	0000	0000
005354	001549	001250	0625	0375	0375	0375	0625	0625	0000	0000	0000	006514	-00314	002467	0625	0625	0375	0375	0375	0625	0000	0000	0000
004953	000789	000793	0500	0375	0375	0500	0625	0625	0000	0000	0000	005613	-00175	001345	0500	0500	0375	0500	0500	0625	0000	0000	0000
004508	000145	000210	0375	0375	0375	0625	0625	0625	0000	0000	0000	004494	000138	000210	0375	0375	0375	0625	0625	0625	0000	0000	0000
004305	-00421	-00106	0250	0375	0375	0750	0625	0625	0000	0000	0000												

009726	-00076	000228	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009071	-00498	-00454	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008312	-00879	-00800	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
007818	-01247	-00899	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
007479	-01511	-00653	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
007221	-02504	-01693	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006052	-02364	-01999	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
05548	-02718	-02375	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005150	-03269	-02636	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
009120	000454	000898	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
008475	000025	000082	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
007930	-00444	-00450	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
007385	-00998	-00750	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
006803	-01290	-01084	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
006276	-01601	-01307	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
005617	-01905	-01750	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
005169	-02364	-02121	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
004668	-02571	-02517	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
008667	001213	001118	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
008089	000426	000733	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
007490	-00931	000131	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
006866	-00384	-00293	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
006326	-00898	-00665	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
005884	-01183	-00957	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
005361	-01613	-01333	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
004834	-01880	-01796	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
004386	-02183	-02097	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
008202	001670	001900	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
007632	001034	001353	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
007175	000589	000727	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
006334	000078	000129	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
005899	-00186	-00143	0500	0593	0625	0500	0406	0375	0000	00112	M05	\$
005636	-00920	-00696	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
004847	-01052	-00871	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
004422	-01517	-01473	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
003986	-01708	-01804	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007767	002227	002383	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
007236	001017	002049	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
006725	001050	001437	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
005979	000587	000717	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
005446	000019	000073	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
004806	-00148	-00100	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
004571	-00687	-00566	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
004159	-01323	-01157	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
003453	-01457	-01450	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
007261	002887	003264	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
006791	002116	002548	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
006198	001683	002045	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
005555	001177	001486	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
005046	000610	000841	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
004474	000138	000187	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
004240	-00363	-00189	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
003698	-00595	-00535	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003288	-01229	-01105	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
006804	003596	003932	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
006329	002725	003075	0875	0406	0500	0125	0593	0750	0000	00136	P02	\$
05798	002139	002501	0750	0375	0250	0250	0625	0750	0000	00137	P03	\$
005130	001723	002068	0625	0343	0250	0375	0656	0750	0000	00138	P04	\$
004648	001210	001404	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
004249	000538	000792	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
003574	000135	000249	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
003332	-00199	-00168	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
002946	-00580	-00555	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
006422	004201	004569	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
005893	003356	003668	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
005300	002952	003253	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
004717	002288	002600	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
004278	001635	002030	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
003773	001166	001383	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
003331	000489	000764	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
002940	000009	000047	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
002593	-00131	-00122	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
005880	004634	005268	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
005356	004098	004792	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
004810	003538	003976	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
004324	002863	003289	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
003739	002444	002523	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
003250	001881	001866	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
002882	001304	001254	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
002502	000645	000689	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
002152	000050	000120	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009724	-00067	000202	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
008914	000111	-00554	0806	0875	1000	0093	0125	0000	0000	00406	J11	\$
008148	000027	-00982	0812	0750	1000	0818	0250	0000	0000	00407	J12	\$
007615	000157	-01448	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
006783	000327	-01695	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
006112	000417	-02357	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
005418	000484	-02797	0347	0250	1000	0562	0750	0000	0000	00411	J16	\$
004718	000473	-03497	0343	0250	1000	0875	0875	0000	0000	00412	J17	\$
004161	000478	-03893	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
004048	-00318	000822	0968	1000	0875	0031	0000	0125	0000	00414	K00	\$
008667	00013	000120	0875	0875	0875	0125	0125	0125	0000	00415	K11	\$
007882	000058	-00364	0781	0750	0875	0218	0250	0125	0000	00416	K12	\$
007250	-00626	-00861	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
006435	000233	-01495	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
005776	000292	-01807	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
005190	000390	-02324	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
004558	000533	-02850	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
003989	000499	-03292	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
009324	-00544	001669	0937	1000	0750	0062	0000	0250	0000	00423	L10	\$

See original or copy: <http://web.me.com/klaus.richter/GE50/GE50L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG GE40_22.TXT, Separation olv*, cfi=0.90, D50, not adapted $
%100 x LAB*      %#1000 x (r g b c m y 0)      %nr.      pos $
%z004943 006541 004341  %#1000 0000 0000 0000 1000 1000 0000  %0072 I01  %01 0 $
%z009348 -01043 009083  %#1000 1000 0000 0000 0000 1000 0000  %0396 I10  %Y1 1 $
%z005982 -05281 003490  %#0000 1000 0000 1000 0000 1000 0000  %0720 I19  %L1 2 $
%z005771 -04281 -02240  %#0000 1000 1000 1000 0000 0000 0000  %0008 A09  %C1 3 $
%z003924 -01080 -04661  %#0000 0000 1000 1000 1000 0000 0000  %0332 A18  %V1 4 $
%z004830 006774 -00918  %#1000 0000 1000 0000 1000 0000 0000  %0656 A27  %M1 5 $
%z001916 000053 000160  %#0000 0000 0000 1000 1000 1000 0000  %0080 I09  %N1 6 $
%z009727 -00072 000206  %#1000 1000 1000 0000 0000 0000 0000  %0000 A01  %M1 7 $
%S
%z004943 006541 004341  %#1000 0000 0000 0000 1000 1000 0000  %0072 I01  %02 0 $
%z009348 -01043 009083  %#1000 1000 0000 0000 0000 1000 0000  %0396 I10  %Y2 1 $
%z005982 -05281 003490  %#0000 1000 0000 1000 0000 1000 0000  %0720 I19  %L2 2 $
%z005771 -04281 -02240  %#0000 1000 1000 1000 0000 0000 0000  %0008 A09  %C2 3 $
%z003924 -01080 -04661  %#0000 0000 1000 1000 1000 0000 0000  %0332 A18  %V2 4 $
%z004830 006774 -00918  %#1000 0000 1000 0000 1000 0000 0000  %0656 A27  %M2 5 $
%z001916 000053 000160  %#0000 0000 0000 1000 1000 1000 0000  %0080 I09  %N2 6 $
%z009727 -00072 000206  %#1000 1000 1000 0000 0000 0000 0000  %0000 A01  %M2 7 $
%S
%z004943 006541 004341  %#1000 0000 0000 0000 1000 1000 0000  %0072 I01  %000Y 0 $
%z009348 -01043 009083  %#1000 1000 0000 0000 0000 1000 0000  %0396 I10  %Y00L 1 $
%z005982 -05281 003490  %#0000 1000 0000 1000 0000 1000 0000  %0720 I19  %L00C 2 $
%z005771 -04281 -02240  %#0000 1000 1000 1000 0000 0000 0000  %0008 A09  %C00V 3 $
%z003924 -01080 -04661  %#0000 0000 1000 1000 1000 0000 0000  %0332 A18  %V00M 4 $
%z004830 006774 -00918  %#1000 0000 1000 0000 1000 0000 0000  %0656 A27  %M000 5 $
%z001916 000053 000160  %#0000 0000 0000 1000 1000 1000 0000  %0080 I09  %N001 6 $
%z009727 -00072 000206  %#1000 1000 1000 0000 0000 0000 0000  %0000 A01  %M001 7 $
%S
%z005880 004634 005268  %#1000 0250 0000 0000 0750 1000 0000  %0153 R01  %025Y 0 $
%z008244 -02309 007232  %#0750 1000 0000 0250 0000 1000 0000  %0477 R10  %Y25L 1 $
%z005865 -04878 000869  %#0000 1000 0250 1000 0000 0750 0000  %0801 R19  %L25C 2 $
%z005150 -03269 -02636  %#0000 0750 1000 1000 0250 0000 0000  %0089 J09  %C25V 3 $
%z004161 000478 -03893  %#0250 0000 1000 0750 1000 0000 0000  %0413 J18  %V25M 4 $
%z004892 006706 000913  %#1000 0000 0750 0000 1000 0250 0000  %0737 J27  %M250 5 $
%z001982 000054 000147  %#0000 0000 0000 1000 1000 1000 0000  %0161 R09  %N251 6 $
%z009724 -00073 000216  %#1000 1000 1000 0000 0000 0000 0000  %0081 J01  %M251 7 $
%S
%z006779 003462 006153  %#1000 0500 0000 0000 0500 1000 0000  %0234 a01  %050Y 0 $
%z007207 -03529 005659  %#0500 1000 0000 0500 0000 1000 0000  %0558 a10  %Y50L 1 $
%z005887 -04875 000073  %#0000 1000 0500 1000 0000 0500 0000  %0882 a19  %L50C 2 $
%z004756 -02328 -03207  %#0000 0500 1000 1000 0500 0000 0000  %0170 S09  %C50V 3 $
%z004282 001996 -03282  %#0500 0000 1000 0500 1000 0000 0000  %0494 S18  %V50M 4 $
%z004885 006583 002210  %#1000 0000 0500 0000 1000 0500 0000  %0818 S27  %M500 5 $
%z002015 000048 000142  %#0000 0000 0000 1000 1000 1000 0000  %0242 a09  %N501 6 $
%z009733 -00072 000204  %#1000 1000 1000 0000 0000 0000 0000  %0162 S01  %M501 7 $
%S
%z007779 001630 007323  %#1000 0750 0000 0000 0250 1000 0000  %0315 j01  %075Y 0 $
%z006504 -04378 004493  %#0250 1000 0000 0750 0000 1000 0000  %0639 j10  %Y75L 1 $
%z005632 -04489 -01077  %#0000 1000 0750 1000 0000 0250 0000  %0963 j19  %L75C 2 $
%z004413 -01721 -03795  %#0000 0250 1000 1000 0750 0000 0000  %0251 b09  %C75V 3 $
%z004737 003802 -02457  %#0750 0000 1000 0250 1000 0000 0000  %0575 b18  %V75M 4 $
%z004891 006461 003131  %#1000 0000 0250 0000 1000 0750 0000  %0899 b27  %M750 5 $
%z001882 000056 000157  %#0000 0000 0000 1000 1000 1000 0000  %0323 j09  %N751 6 $
%z009733 -00070 000198  %#1000 1000 1000 0000 0000 0000 0000  %0243 b01  %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE50/GE50L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG GE40.22.TXT, Separation olv*, cfi=0.90, D50, not adapted S
%100 x LAB*      1000 x (r g b c m y o)      %nr. pos $
001674 000032 000174 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002525 000006 000103 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003204 000136 000266 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004189 000145 000238 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005266 000029 000099 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006354 000078 000091 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
007601 -000028 000120 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008639 000001 000110 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009756 000063 000193 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
010731 000040 000168 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
012580 000007 000076 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
013198 000137 000227 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
014186 000148 000175 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
015262 000037 000066 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
016385 000074 000069 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
017635 -000028 000115 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
018671 000007 000108 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
019752 -000071 000203 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
020752 000040 000157 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
021544 000003 000070 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
022122 000134 000226 0250 0250 0250 0750 0750 0750 0000 %0992 k03 $
023212 000134 000226 0250 0250 0250 0750 0750 0750 0000 %0992 k03 $
024202 000152 000182 0375 0375 0375 0625 0625 0625 0000 %0993 k04 $
025298 000026 000076 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
026354 000062 000079 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
027665 -000031 000114 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
028692 000003 000111 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
029751 -000071 000203 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
030691 000040 000156 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
031691 000007 000093 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
032609 000130 000255 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
033609 000139 000191 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
034633 000021 000089 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
035644 000068 000084 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
036782 -000035 000109 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
037864 000003 000117 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
038972 -000070 000188 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
039972 000040 000131 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
040972 000204 000178 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
041972 000011 000040 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
042972 000086 000123 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
043972 000139 000192 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
044972 000048 000153 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
045972 000152 000254 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
046972 000015 000134 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
047972 000105 000211 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
048972 000151 000164 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
049972 000016 000125 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
050972 000050 000101 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
051972 000097 000100 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
052972 000052 000041 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
053972 -000001 000158 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
054972 -000069 000184 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
055972 000042 000123 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
056972 000219 000183 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
057972 000012 000035 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
058972 000089 000100 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
059972 000139 000169 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
060972 000049 000135 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
061972 000153 000231 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
062972 000016 000089 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
063972 000112 000153 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
064972 000153 000101 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
065972 000014 000094 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
066972 000047 000085 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
067972 000098 000086 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
068972 000051 000030 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
069972 000124 000001 000152 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
070972 -000072 000178 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
071972 000144 000041 000120 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
072972 000213 000170 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
073972 000009 000018 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
074972 000081 000106 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
075972 000143 000155 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
076972 000045 000126 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
077972 000138 000227 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
078972 000003 000100 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
079972 000103 000162 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
080972 000142 000124 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
081972 000015 000088 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
082972 000044 000089 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
083972 000076 000099 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE50; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: ->olv* setrgbcolor

TUB registration: 20091101-GE50/GE50L0NP.PDF /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

%BEG	GE40	22.TXT	Separation	olv*	cf1=0.90	D50	adapted	%nr.	pos	\$	%BEG	GE40	22.TXT	Separation	olv*	cf1=0.90	D50	adapted	%nr.	pos	\$	
%100 x	LAB*a		1000 x	(r g b	c m y θ)						%100 x	LAB*a		1000 x	(r g b	c m y θ)						
009736	-00001	000005	1000	1000	1000	0000	0000	0000	0000	0000	009732	000000	-00007	1000	1000	1000	0000	0000	0000	0000	0000	
009180	-00703	-00400	0875	1000	1000	0125	0000	0000	0000	0000	008909	-00076	-00877	0875	0875	1000	0125	0000	0000	0000	0000	
008468	-01014	-00861	0750	1000	1000	0250	0000	0000	0000	0000	007993	-00285	-01343	0750	0750	1000	0250	0000	0000	0000	0000	
008075	-01529	-00771	0625	1000	1000	0375	0000	0000	0000	0000	007512	-00392	-01843	0625	0625	1000	0375	0000	0000	0000	0000	
007499	-01946	-01092	0500	1000	1000	0500	0000	0000	0000	0000	006522	-00425	-02402	0500	0500	1000	0500	0000	0000	0000	0000	
007231	-02508	-01932	0375	1000	1000	0625	0000	0000	0000	0000	005813	-00602	-03001	0375	0375	1000	0625	0000	0000	0000	0000	
006554	-03331	-01901	0250	1000	1000	0750	0000	0000	0000	0000	005193	-00800	-03565	0250	0250	1000	0750	0000	0000	0000	0000	
006121	-03855	-02215	0125	1000	1000	0875	0000	0000	0000	0000	004532	-00968	-04127	0125	0125	1000	0875	0000	0000	0000	0000	
005771	-04273	-02423	0000	1000	1000	1000	0000	0000	0000	0000	003924	-01181	-04534	0000	0000	1000	1000	0000	0000	0000	0000	
008978	000475	000473	1000	0875	0875	0000	0125	0125	0000	0000	009669	-00217	00085	1000	1000	0875	0000	0125	0000	0125	0000	
008444	000057	-00052	0875	0875	0875	0125	0125	0125	0000	0000	008652	000046	-00060	0875	0875	0125	0125	0125	0000	0125	0000	
007975	-00495	-00427	0750	0875	0875	0250	0125	0125	0000	0000	007890	-00269	-00639	0750	0750	0875	0250	0250	0125	0000	0000	
007480	-01131	-00599	0625	0875	0875	0375	0125	0125	0000	0000	007180	-00385	-01341	0625	0625	0875	0375	0125	0000	0125	0000	
006924	-01523	-00975	0500	0875	0875	0500	0125	0125	0000	0000	006332	-00462	-01950	0500	0500	0875	0500	0125	0000	0125	0000	
006444	-01977	-01260	0375	0875	0875	0625	0125	0125	0000	0000	005585	-00400	-02336	0375	0375	0875	0625	0625	0125	0000	0000	
005847	-02332	-01735	0250	0875	0875	0750	0125	0125	0000	0000	004953	-00722	-02968	0250	0250	0875	0750	0125	0000	0125	0000	
005446	-03039	-01833	0125	0875	0875	0875	0125	0125	0000	0000	004325	-00875	-03601	0125	0125	0875	0875	0125	0000	0125	0000	
006047	-03862	-02182	0000	0875	0875	1000	0125	0125	0000	0000	003665	-00972	-04144	0000	0000	0875	1000	0125	0000	0125	0000	
008459	001617	000741	1000	0750	0750	0000	0250	0250	0000	0000	009531	-00231	-001731	1000	1000	0750	0000	0250	0000	0250	0000	
007924	000734	000299	0875	0750	0750	0125	0250	0250	0000	0000	008625	-00049	-000804	0875	0875	0750	0125	0250	0000	0250	0000	
007443	000010	-00057	0750	0750	0750	0250	0250	0250	0000	0000	007627	000005	-00051	0750	0750	0250	0250	0250	0000	0250	0000	
006892	-00434	-00368	0625	0750	0750	0375	0250	0250	0000	0000	006782	-00112	-00639	0625	0625	0750	0375	0375	0250	0000	0000	
006424	-01088	-00636	0500	0750	0750	0500	0250	0250	0000	0000	006099	-00323	-01301	0500	0500	0750	0500	0250	0000	0250	0000	
005990	-01453	-00926	0375	0750	0750	0625	0250	0250	0000	0000	005459	-00387	-01897	0375	0375	0750	0625	0625	0250	0000	0000	
005517	-01885	-01275	0250	0750	0750	0750	0250	0250	0000	0000	004736	-00508	-02453	0250	0250	0750	0750	0250	0000	0250	0000	
005120	-02538	-01478	0125	0750	0750	0875	0250	0250	0000	0000	004189	-00667	-03009	0125	0125	0750	0875	0250	0000	0250	0000	
004547	-02821	-01725	0000	0750	0750	1000	0250	0250	0000	0000	003511	-00766	-03561	0000	0000	0750	1000	0250	0000	0250	0000	
007777	002463	001259	1000	0625	0625	0000	0375	0375	0000	0000	009340	-00167	-002643	1000	1000	0625	0000	0375	0000	0375	0000	
007351	001563	000763	0875	0625	0625	0125	0375	0375	0000	0000	008574	-00101	-001888	0875	0875	0625	0125	0375	0000	0375	0000	
007605	000858	000382	0750	0625	0625	0250	0375	0375	0000	0000	007672	-00053	-000754	0750	0750	0625	0250	0250	0375	0000	0000	
006300	000112	-00093	0625	0625	0625	0375	0375	0375	0000	0000	006505	-00076	-00120	0625	0625	0625	0375	0375	0000	0375	0000	
005951	-00275	-02051	0500	0625	0625	0500	0375	0375	0000	0000	005987	-00022	-00562	0500	0500	0625	0500	0375	0000	0375	0000	
005652	-00973	-00600	0375	0625	0625	0625	0375	0375	0000	0000	005147	-00263	-01490	0375	0375	0625	0625	0375	0000	0375	0000	
005013	-01369	-00931	0250	0625	0625	0750	0375	0375	0000	0000	004412	-00307	-01965	0250	0250	0625	0750	0375	0000	0375	0000	
004662	-01978	-01318	0125	0625	0625	0875	0375	0375	0000	0000	003908	-00567	-02629	0125	0125	0625	0875	0375	0000	0375	0000	
004260	-02209	-01484	0000	0625	0625	1000	0375	0375	0000	0000	003249	-00782	-03119	0000	0000	0625	1000	0375	0000	0375	0000	
007180	003281	001882	1000	0500	0500	0000	0500	0500	0000	0000	009306	-00330	-003680	1000	1000	0500	0000	0500	0000	0500	0000	
006888	002263	001436	0875	0500	0500	0125	0500	0500	0000	0000	008482	-00240	-02938	0875	0875	0500	0125	0125	0000	0125	0000	
006451	001580	000990	0750	0500	0500	0250	0500	0500	0000	0000	007630	-00126	-002002	0750	0750	0500	0250	0250	0000	0250	0000	
005865	000783	000471	0625	0500	0500	0375	0500	0500	0000	0000	006455	-00072	-000913	0625	0625	0500	0375	0375	0000	0375	0000	
005417	000029	-00080	0500	0500	0500	0500	0500	0500	0000	0000	005483	000031	-00092	0500	0500	0500	0500	0500	0000	0500	0000	
004931	-00263	-00247	0375	0500	0500	0625	0500	0500	0000	0000	004768	000048	-00538	0375	0375	0500	0625	0625	0000	0625	0000	
004701	-00878	-00519	0250	0500	0500	0750	0500	0500	0000	0000	004267	-00259	-01472	0250	0250	0500	0750	0500	0000	0500	0000	
004263	-01588	-01091	0125	0500	0500	0875	0500	0500	0000	0000	003515	-00349	-01949	0125	0125	0500	0875	0875	0000	0875	0000	
003659	-01818	-01213	0000	0500	0500	1000	0500	0500	0000	0000	002843	-00655	-02549	0000	0000	0500	1000	0500	0000	0500	0000	
006698	003995	002414	1000	0375	0375	0000	0625	0625	0000	0000	009252	-00483	-005021	1000	1000	0375	0000	0625	0000	0625	0000	
006336	002974	001961	0875	0375	0375	0125	0625	0625	0000	0000	008473	-00390	-004212	0875	0875	0375	0125	0125	0000	0125	0000	
005882	002218	001489	0750	0375	0375	0250	0625	0625	0000	0000	007560	-00205	-003105	0750	0750	0375	0250	0250	0000	0250	0000	
005354	001550	001069	0625	0375	0375	0375	0625	0625	0000	0000	006514	-00293	-002280	0625	0625	0375	0375	0375	0000	0625	0000	
004953	000785	000615	0500	0375	0375	0500	0625	0625	0000	0000	005613	-00169	-001163	0500	0500	0375	0500	0625	0000	0625	0000	
004508	000134	000034	0375	0375	0375	0625	0625	0625	0000	0000	004494	000126	-000035	0375	0375	0375	0625	0625	0000	0625	0000	
004305	-00436	-00280	0250	0375	0375	0750	0625	0625	0000	0000	004139	-00176	-00672	0250	0250	0375	0750	0625	0000	0625	0000	
003845	-00814	-00534	0125	0375	0375	0875	0625	0625	0000	0000	003394	-00193	-01248	0125	0125	0375	0875	0625	0000	0625	0000	
003402	-01411	-00983	0000	0375	0375	1000	0625	0625	0000	0000	002731	-00290	-01942	0000	0000	0375	1000	0625	0000	0625	0000	
006157	004866	003104	1000	0250	0250	0000	0750	0750	0000	0000	009198	-00546	-006086	1000	1000	0250	0000	0750	0000	0750	0000	
005776	003778	002347	0875	0250	0250	0125	0750	0750	0000	0000	008389	-00448	-005182	0875	0875	0250	0125	0125	0000	0125	0000	
005270	003109	001																				

```
input: w setgray
output: ->oly* setrgbcolor
```

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009740	000001	-000008	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$	009728	-000004	-000022	1000	1000	1000	0000	0000	0000	%0486	S10 \$	009732	000003	-000014	1000	1000	1000	0000	0000	0000	0000	0000	%0810	S19 \$	
008934	-00271	-000872	0875	0937	1000	0125	0062	0000	0000	%0163	S02 \$	008986	000325	-000614	0937	0875	1000	0062	0125	0000	0000	%0487	S11 \$	008986	000779	000142	1000	0875	0937	0000	0125	0062	0000	%0811	S20 \$	
008234	-000648	-011555	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$	008251	000379	-010111	0875	0750	1000	0125	0250	0000	0000	%0488	S12 \$	008460	001716	000113	1000	0750	0875	0000	0250	0125	0000	%0812	S21 \$	
007564	-00954	-01332	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$	007776	000697	-01377	0812	0625	1000	0187	0375	0000	0000	%0489	S13 \$	007961	002390	000533	1000	0625	0812	0000	0375	0187	0000	%0813	S22 \$	
007659	-01158	-01899	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$	007959	000860	-01441	0750	0500	1000	0250	0500	0000	0000	%0490	S14 \$	007323	003336	000698	1000	0500	0750	0000	0500	0250	0000	%0814	S23 \$	
006468	-01439	-02095	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$	006400	001269	-02021	0687	0375	1000	0312	0625	0000	0000	%0491	S15 \$	006694	004250	001237	1000	0375	0687	0000	0625	0312	0000	%0815	S24 \$	
005756	-01764	-02659	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$	005508	001552	-02448	0625	0250	1000	0375	0750	0000	0000	%0492	S16 \$	006179	005040	001598	1000	0250	0625	0000	0750	0375	0000	%0816	S25 \$	
004258	-02304	-02908	0125	0500	1000	0875	0500	0000	0000	%0169	S08 \$	005412	001721	-03075	0500	0125	1000	0875	0500	0000	0000	%0493	S17 \$	005491	005506	001706	1000	0125	0500	0000	0875	0500	0000	%0817	S26 \$	
004756	-02334	-03372	0000	0250	1000	1000	0500	0000	0000	%0170	S09 \$	004282	001983	-03442	0000	0000	1000	0500	1000	0000	0000	%0494	S18 \$	004895	005679	002044	1000	0000	0500	0000	1000	0500	0000	%0818	S27 \$	
003292	000372	000610	1000	0937	0875	0000	0062	0125	0000	%0171	T01 \$	003935	-003938	000446	0937	1000	0875	0062	0000	0125	0000	%0495	T10 \$	009225	-000644	-00220	0875	1000	0937	0125	0000	0062	0000	%0819	T10 \$	
008511	000065	-00092	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$	008703	000048	-000085	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$	008645	000053	-00135	0875	0875	0875	0875	0125	0125	0125	0000	%0820	T10 \$
007924	-00330	-00651	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$	008024	000252	-00515	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$	008060	000824	000004	0875	0750	0812	0125	0250	0187	0000	%0821	T21 \$	
007313	-00683	-01017	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$	007432	000413	-00836	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$	007405	001585	000397	0875	0625	0750	0125	0375	0250	0000	%0822	T22 \$	
006716	-00970	-01452	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$	006654	000667	-01305	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$	006848	002386	000530	0875	0500	0687	0125	0500	0312	0000	%0823	T23 \$	
006118	-01156	-01755	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$	005927	001035	-01507	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$	006262	003189	000911	0875	0375	0625	0125	0625	0375	0000	%0824	T24 \$	
005496	-01510	-02176	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$	005264	001363	-02104	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$	005630	003984	001146	0875	0250	0562	0125	0750	0437	0000	%0825	T25 \$	
005005	-01831	-02537	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$	004650	001560	-02443	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$	004989	004959	001518	0875	0125	0500	0125	0875	0500	0000	%0826	T26 \$	
004457	-02072	-02983	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$	003951	001839	-02960	0437	0000	0875	0562	1000	0125	0000	%0503	T18 \$	004226	006043	001848	0875	0000	0437	0125	1000	0562	0000	%0827	T27 \$	
008874	000917	001112	1000	0875	0750	0000	0125	0250	0000	%0180	U01 \$	009185	-00892	001211	0875	1000	0750	0125	0000	0250	0000	%0504	U10 \$	008623	-01091	-00298	0750	1000	0875	0250	0000	0125	0000	%0828	U19 \$	
008200	000420	000549	0875	0812	0750	0125	0187	0250	0000	%0181	U02 \$	008381	-00299	000358	0812	0875	0750	0187	0125	0250	0000	%0505	U11 \$	008090	-00543	-00210	0750	0875	0812	0250	0125	0187	0000	%0829	U20 \$	
007571	000001	-00064	0750	0750	0750	0250	0250	0250	0000	%0182	U03 \$	007704	000001	-00057	0750	0750	0750	0250	0250	0250	0000	%0506	U12 \$	007633	000007	-00060	0750	0750	0750	0250	0250	0250	0000	%0830	U21 \$	
006846	-00257	-00553	0625	0687	0750	0375	0312	0250	0000	%0183	U04 \$	006963	000264	-00511	0687	0625	0750	0312	0375	0250	0000	%0507	U13 \$	007056	000969	000129	0750	0625	0687	0250	0375	0312	0000	%0831	U22 \$	
006292	-00646	-00945	0500	0625	0750	0500	0500	0375	0250	0000	%0184	U05 \$	006212	000571	-00881	0625	0500	0750	0375	0500	0250	0000	%0508	U14 \$	006416	001698	000323	0750	0500	0625	0250	0500	0375	0000	%0832	U23 \$
005737	-00820	-01341	0375	0562	0750	0625	0437	0250	0000	%0185	U06 \$	005580	000812	-01281	0562	0375	0750	0437	0625	0250	0000	%0509	U15 \$	005751	002395	000618	0750	0375	0562	0250	0625	0437	0000	%0833	U24 \$	
005160	-01199	-01828	0250	0500	0750	0750	0500	0250	0000	%0186	U07 \$	004918	001022	-01753	0500	0250	0750	0500	0750	0250	0000	%0510	U16 \$	005074	003164	000900	0750	0250	0500	0250	0750	0500	0000	%0834	U25 \$	
004678	-01519	-02174	0125	0437	0750	0875	0562	0250	0000	%0187	U08 \$	004246	001295	-02161	0437	0125	0750	0562	0875	0250	0000	%0511	U17 \$	004484	003966	001197	0750	0125	0437	0250	0875	0562	0000	%0835	U26 \$	
004235	-01685	-02537	0000	0375	0750	1000	0625	0250	0000	%0188	U09 \$	003635	001622	-02514	0375	0000	0750	0625	1000	0250	0000	%0512	U18 \$	003920	004710	001504	0750	0000	0375	0250	1000	0625	0000	%0836	U27 \$	
005855	001071	002058	1000	0812	0625	0000	0187	0375	0000	%0189	V01 \$	008876	-01136	001620	0812	1000	0625	0187	0000	0375	0000	%0513	V10 \$	008307	-01499	-00112	0625	1000	0812	0375	0000	0187	0000	%0837	V19 \$	
007875	000692	001314	0875	0750	0625	0125	0250	0375	0000	%0190	V02 \$	008186	-00831	001133	0750	0875	0625	0250	0125	0375	0000	%0514	V11 \$	007678	-01142	-00045	0625	0875	0750	0375	0125	0250	0000	%0838	V20 \$	
007274	000441	000547	0750	0687	0625	0250	0312	0375	0000	%0191	V03 \$	007398	-00371	000453	0687	0750	0625	0312	0250	0375	0000	%0515	V12 \$	007067	-00562	-00068	0625	0750	0687	0375	0250	0312	0000	%0839	V19 \$	
006391	000092	-00086	0625	0625	0625	0375	0375	0375	0000	%0192	V04 \$	006497	000069	-00109	0625	0625	0625	0375	0375	0375	0000	%0516	V13 \$	006421	000116	-00097	0625	0625	0625	0375	0375	0375	0000	%0840	V22 \$	
005917	-00139	-00361	0500	0562	0625	0500	0437	0375	0000	%0193	V05 \$	005939	000295	-00476	0562	0500	0625	0437	0500	0375	0000	%0517	V14 \$	005857	000843	000254	0625	0500	0562	0375	0500	0437	0000	%0841	V23 \$	
005585	-00682	-00965	0375	0500	0625	0625	0625	0375	0000	%0194	V06 \$	005409	000293	-00833	0500	0375	0625	0500	0625	0375	0000	%0518	V15 \$	005228	001592	000451	0625	0375	0500	0375	0625	0500	0000	%0842	V24 \$	
004697	-00869	-01368	0250	0437	0625	0750	0562	0375	0000	%0195	V07 \$	004535	000829	-01320	0437	0250	0625	0562	0750	0500	0375	%0519	V16 \$	004573	002424	000753	0625	0500	0437	0375	0750	0562	0000	%0843	V25 \$	
004359	-01246	-01910	0125	0375	0625	0875	0625	0375	0000	%0196	V08 \$	004104	000941	-01744	0375	0125	0625	0625	0875	0375	0000	%0520	V17 \$	004018	003064	000986	0625	0125	0375	0375	0875	0625	0000	%0844	V26 \$	
003857	-01407	-02194	0000	0312	0625	1000	0687	0375	0000	%0197	V09 \$	003328	001413	-02090	0312	0000	0625	0687	1000	0375	0000	%0521	V18 \$													

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-GE50/GE50L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IOB material: code=rha4ta

TUB-test chart GE50; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrabcOLOR
```

See original or copy: <http://web.me.com/klaus.richter/GE50/GE50L0NP.PDF> / PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cf1=0.90; nt=0.18; nx=1.00

[illegible]

See original or copy: <http://web.me.com/klaus.richter/GE50/GE50L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG GE40_22.TXT, Separation olv*, cfi=0.90, D50, adapted $
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr.   pos $
%Z004943 006536 004162 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009348 -00976 008879 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005982 -05269 003306 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005771 -04273 -02423 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003924 -01101 -04834 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004830 006768 -01095 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001916 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009727 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%$
%Z004943 006536 004162 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009348 -00976 008879 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005982 -05269 003306 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005771 -04273 -02423 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003924 -01101 -04834 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004830 006768 -01095 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001916 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009727 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%$
%Z004943 006536 004162 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009348 -00976 008879 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005982 -05269 003306 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005771 -04273 -02423 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003924 -01101 -04834 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004830 006768 -01095 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001916 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009727 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%$
%Z005880 004645 005086 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z008244 -02269 007028 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005865 -04868 000687 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005150 -03271 -02811 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z004161 000459 -04059 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004892 006700 00739 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001982 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009724 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%$
%Z006779 003487 005973 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007207 -03487 005474 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005887 -04863 -00100 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004756 -02334 -03372 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z004282 001983 -03442 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004885 006579 002044 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z002015 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009733 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%$
%Z007779 001668 007134 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006504 -04360 004311 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005632 -04485 -01254 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z004413 -01737 -03966 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004737 003791 -02629 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004891 006453 002958 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001882 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009733 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%$
```

%BEG GE40.22.TXT, Separation olv*, cf1=0.90, D50, adapted \$
%100 x LAB*a 1000 x (r g b c m y o) %nrr. pos \$

001674	-00021	000024	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$	008448	000105	-00159	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$	
002525	-00033	-00052	0125	0125	0125	0125	0875	0875	0875	0000	%0973	k02	\$	009100	000071	-00040	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$
003204	000108	000106	0250	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$	009735	000002	-00002	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$
004189	000132	000072	0375	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$	002147	-00004	-00032	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$
005266	000033	-00073	0500	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	002252	000180	000034	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$
006354	000100	-00088	0625	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$	002907	-00026	-00120	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$
007601	000012	-00067	0750	0750	0750	0250	0250	0250	0250	0000	%0978	k07	\$	003190	000052	-00035	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$
008639	000059	-00094	0875	0875	0875	0125	0125	0125	0125	0000	%0979	k08	\$	003598	000113	000037	0266	0266	0266	0733	0733	0733	0000	%1060	n14	\$
009756	000005	-00093	1000	1000	1000	1300	0000	0000	0000	0000	%0980	k09	\$	004259	000035	-00017	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$
010731	-00011	000018	0000	0000	0000	1000	1000	1000	1000	0000	%0981	l01	\$	004562	000130	000091	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$
002580	-00031	-00079	0125	0125	0125	0875	0875	0875	0875	0000	%0982	l02	\$	005391	000012	-00053	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$
003198	000108	000067	0250	0250	0250	0750	0750	0750	0750	0000	%0983	l03	\$	005728	000110	000021	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$
004186	000135	000009	0375	0375	0375	0625	0625	0625	0625	0000	%0984	l04	\$	006327	000157	-00036	0600	0600	0600	0399	0399	0399	0000	%1065	n19	\$
005262	000041	-00106	0500	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	006920	000043	-00073	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$
006385	000096	-00110	0625	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$	007495	000089	-00095	0733	0733	0733	0266	0266	0266	0000	%1067	n21	\$
007635	000013	-00073	0750	0750	0750	0250	0250	0250	0250	0000	%0987	l07	\$	008001	000147	-00096	0800	0800	0800	0199	0199	0199	0000	%1068	n22	\$
008671	000066	-00086	0875	0875	0875	0125	0125	0125	0125	0000	%0988	l08	\$	008437	000143	-00157	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$
009752	000004	-00002	1000	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$	009124	000092	-00048	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$
010752	-00011	000007	0000	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$	009745	000005	-00016	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$
002544	-00036	-00084	0125	0125	0125	0875	0875	0875	0875	0000	%0991	m02	\$	001690	000000	000000	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$
003212	000105	000066	0250	0250	0250	0750	0750	0750	0750	0000	%0992	m03	\$	009756	000000	000000	0000	1000	1000	1000	0000	0000	0000	%1073	k27	\$
004202	000139	000015	0375	0375	0375	0625	0625	0625	0625	0000	%0993	m04	\$	004931	006518	004360	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
005298	000031	-00096	0500	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$	005682	-04745	-02038	0000	1000	1000	1000	0000	0000	0000	%1075	l27	\$
006354	000084	-00100	0625	0625	0625	0625	0375	0375	0375	0000	%0995	m06	\$	009351	-00961	009191	1000	1000	0000	0000	0000	1000	0000	%1076	m26	\$
007665	000010	-00073	0750	0750	0750	0250	0250	0250	0250	0000	%0996	m07	\$	003782	-01009	-04753	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$
008692	000062	-00083	0875	0875	0875	0125	0125	0125	0125	0000	%0997	m08	\$	005871	-05571	003421	0000	1000	0000	1000	0000	1000	0000	%1078	n26	\$
009751	000004	000001	1000	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$	004819	006736	-01138	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$
010691	-00013	000006	0000	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$													
002509	-00032	-00062	0125	0125	0125	0875	0875	0875	0875	0000	%1000	n02	\$	%z004931	006518	004360	##1000	0000	0000	0000	1000	1000	0000	%1074	l26	%03 0 0 \$
003209	000102	000096	0250	0250	0250	0750	0750	0750	0750	0000	%1001	n03	\$	%z009351	-00961	009191	##1000	1000	0000	0000	0000	1000	0000	%1076	m26	%Y3 1 0 \$
004242	000127	000024	0375	0375	0375	0625	0625	0625	0625	0000	%1002	n04	\$	%z005871	-05571	003421	##0000	1000	0000	1000	0000	1000	0000	%1078	n26	%L3 2 0 \$
005333	000027	-00084	0500	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$	%z005682	-04745	-02038	##0000	1000	1000	0000	0000	0000	0000	%1075	l27	%C3 3 0 \$
006444	000091	-00095	0625	0625	0625	0625	0375	0375	0375	0000	%1004	n06	\$	%z004819	006736	-01138	##0000	0000	1000	1000	1000	0000	0000	%1077	m27	%V3 4 0 \$
007682	000007	-00079	0750	0750	0750	0250	0250	0250	0250	0000	%1005	n07	\$	%z001690	000000	000000	##0000	0000	0000	1000	1000	1000	0000	%1072	k26	%M3 6 0 \$
008684	000062	-00077	0875	0875	0875	0125	0125	0125	0125	0000	%1006	n08	\$	%z009756	000000	000000	##1000	1000	1000	0000	0000	0000	0000	%1073	k27	%W3 7 0 \$
009752	000005	-00013	1000	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$													
002106	-00005	-00021	0000	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$	%z001674	-00021	000024	##0000	0000	0000	1000	1000	1000	0000	%0972	k01	%N4 6 0 \$
002218	000160	000025	0066	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$	%z009756	000006	-00008	##1000	1000	1000	0000	0000	0000	0000	%0980	k09	%W4 7 0 \$
002855	-00022	-00116	0133	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$													
003120	000055	-00035	0200	0200	0200	0800	0800	0800	0800	0000	%1011	k13	\$	%z001731	-00011	000018	##0000	0000	0000	1000	1000	1000	0000	%0981	l01	%N5 6 0 \$
003561	000116	000029	0266	0266	0266	0733	0733	0733	0733	0000	%1012	k14	\$	%z009752	000004	000002	##1000	1000	1000	0000	0000	0000	0000	%0989	l09	%W5 7 0 \$
004164	000035	-00012	0333	0333	0333	0666	0666	0666	0666	0000	%1013	k15	\$													
004474	000144	000086	0400	0400	0400	0600	0600	0600	0600	0000	%1014	k16	\$	%z001752	-00011	000007	##0000	0000	0000	1000	1000	1000	0000	%0990	m01	%N6 6 0 \$
005289	000020	-00039	0466	0466	0466	0533	0533	0533	0533	0000	%1015	k17	\$	%z009751	000004	000001	##1000	1000	1000	0000	0000	0000	0000	%0998	m09	%W6 7 0 \$
005651	000116	000036	0533	0533	0533	0466	0466	0466	0466	0000	%1016	k18	\$													
006220	000171	-00014	0600	0600	0600	0600	0399	0399	0399	0000	%1017	k19	\$	%z001691	-00013	000006	##0000	0000	0000	1000	1000	1000	0000	%0999	n01	%N7 6 0 \$
006838	000046	-00058	0666	0666	0666	0666	0333	0333	0333	0000	%1018	k20	\$	%z009752	000005	-00013	##1000	1000	1000	0000	0000	0000	0000	%1007	n09	%W7 7 0 \$
007468	000089	-00085	0733	0733	0733	0266	0266	0266	0266	0000	%1019	k21	\$													
007964	000144	-00090	0800	0800	0800	0199	0199	0199	0199	0000	%1020	k22	\$													
008412	000106	-00151	0866	0866	0866	0133	0133	0133	0133	0000	%1021	k23	\$													
009089	000064	-00038	0933	0933	0933	0066	0066	0066	0066	0000	%1022	k24	\$													
009744	000006	-00016	1000	1000	1000	1000	0000	0000	0000	0000	%1023	k25	\$			</										