

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart GE54; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w *setgray*

output: no change compared to input

TUB registration: 20091101-GE54/GE54L0NP.PDF /.PSS
application for evaluation and measurement of printer on

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/GE54/GE54L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.00

009596	-00096	000222	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
008703	-00317	-00426	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008146	-00425	-00847	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
007459	-00566	-01151	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
006917	-00731	-01599	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
006406	-00980	-02132	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
005865	-01142	-02617	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
005291	-01367	-03092	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
004550	-01574	-03693	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
008812	000475	000815	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
008472	-00911	000173	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
007930	-00375	-00537	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
007121	-00925	-00901	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
006625	-00557	-01221	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
006102	-00759	-01659	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
005520	-01056	-02178	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
004892	-01268	-02631	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
004374	-01467	-03074	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
004848	-000958	001254	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
008041	-000352	000677	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
007544	000010	000114	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
006809	-00323	-00429	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
006345	-00470	-00949	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
005785	-00615	-01418	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
005212	-00891	-01805	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
004051	-00929	-02278	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
004670	-01163	-02611	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
008136	001433	001775	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
007539	-009933	001181	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
007015	-000340	000712	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
006458	-000016	000224	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
006031	-00326	-00544	0500	0593	0625	0500	0406	0375	0000	00112	M05	\$
005495	-00512	-00922	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
004865	-00687	-01493	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
004277	-00834	-01863	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
003842	-01065	-02156	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007667	001892	002400	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
007127	001189	001919	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
006602	000797	001476	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
005889	000503	000720	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
005465	000051	000139	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
005041	-00290	-00553	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
004513	-00506	-01067	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
003974	-00820	-01525	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
003596	-00981	-01833	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
007213	002417	003085	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
006643	001764	002425	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
006070	001325	001950	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
005417	000968	001585	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
004945	000410	000754	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
004579	000023	000120	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
004330	-00207	-00598	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
003691	-00498	-01085	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003269	-00835	-01542	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
006697	003140	003737	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
006044	002249	002900	0875	0406	0500	0125	0593	0750	0000	00136	P02	\$
005636	001840	002440	0750	0375	0250	0250	0625	0625	0000	00137	P03	\$
004936	001405	001808	0625	0343	0250	0375	0656	0750	0000	00138	P04	\$
004393	001139	001227	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
004202	000480	000762	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
003859	000307	000014	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
003399	-00290	-00592	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
003146	-00586	-01096	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
002635	003655	004279	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
005567	002776	003381	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
005010	002352	002874	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
004472	001949	002419	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
004068	001394	001858	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
003670	001066	001200	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
003362	000410	000584	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
002744	000006	000034	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
002640	000194	-01117	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
005657	000493	004765	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
005101	003136	003695	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
004572	002733	003181	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
004067	002306	002667	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
003616	001835	002319	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
003329	001414	001993	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
003147	000961	001575	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
002933	000553	001127	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
002242	000539	000404	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009657	-00091	000202	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
008624	000221	-00372	0906	0875	1000	0093	0125	0000	0000	00406	J11	\$
008177	000503	-00639	0812	0750	1000	0187	0250	0000	0000	00407	J12	\$
007363	000856	-00986	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
006527	001249	-01427	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
005774	001734	-01822	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
005025	002152	-02377	0347	0250	1000	0562	0750	0000	0000	00411	J16	\$
004345	002526	-02908	0043	0250	1000	0687	0875	0000	0000	00412	J17	\$
003680	002782	-03375	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
002927	-00363	000881	0906	1000	0875	0031	0000	0125	0000	00414	K10	\$
008659	-00029	000191	0875	0875	0875	0125	0125	0125	0000	00415	K11	\$
007951	000250	-00351	0781	0750	0875	0218	0250	0125	0000	00416	K12	\$
007204	000633	-00669	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
006256	001001	-01069	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
005501	001456	-01557	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
004794	001821	-01980	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
004035	002205	-02493	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
003276	002722	-03020	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
000910	-00683	001546	0937	1000	0750	0602	0000	0250	0000	00423	L10	\$
0084												

%09593	-00092	000230	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
%08478	-00002	-00390	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
%08028	000071	-00821	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
%07237	000255	-01202	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
%06549	000379	-01649	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
%05923	000422	-02081	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$
%05327	000385	-02578	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
%04521	000587	-03290	0125	0343	1000	0875	0656	0000	0000	%0250	b08	\$
%03877	000806	-03922	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
%03003	000133	000932	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
%08390	-000005	000195	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
%07803	000069	-00348	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
%06965	000105	-00872	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
%06309	000264	-01307	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
%05660	000677	-01764	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
%04985	000334	-02219	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
%04256	000536	-02789	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
%03741	000570	-03237	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
%08885	000290	-001636	1000	0937	0750	0000	0602	0250	0000	%0261	d01	\$
%08245	000109	000128	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
%07543	000000	000785	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$
%06656	-000008	-00276	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
%06085	000069	-00908	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
%05395	000215	-01368	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
%04660	000399	-01809	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
%04113	000386	-02244	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
%03480	000479	-02733	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
%08772	000213	002680	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
%08042	000084	-001553	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
%07359	000026	-000863	0750	0718	0625	0250	0281	0375	0000	%0272	e03	\$
%06469	-00013	000171	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
%05863	000055	-00396	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
%05255	000163	-00977	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$
%04334	000092	-01474	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$
%03845	000282	-01840	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
%03196	000443	-02381	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
%08543	000404	-003300	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
%07833	000212	-02568	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
%07049	000191	-001794	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
%06254	000049	-000944	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
%05458	000053	-000114	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
%04942	000016	-00460	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
%04369	000102	-01073	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
%03649	000247	-01591	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
%02944	000331	-01847	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
%08281	000536	-004134	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
%07531	000342	-003152	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
%06702	000269	-002550	0750	0656	0375	0250	0343	0625	0000	%0290	g03	\$
%05900	000116	-002033	0625	0656	0375	0375	0437	0625	0000	%0291	g04	\$
%05104	000089	-000907	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
%04538	000013	-000116	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
%04134	000109	-00587	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
%03423	000111	-01093	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
%02817	000317	-01606	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
%08032	000712	-005066	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
%07229	000425	-004131	0875	0718	0250	0125	0281	0750	0000	%0298	h02	\$
%06396	000302	-003501	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
%05655	000330	-002600	0625	0531	0250	0375	0406	0750	0000	%0300	h04	\$
%04866	000180	-001804	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
%04291	000047	-000870	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
%03740	000032	-000003	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
%03228	000098	-00644	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
%02809	000342	-01309	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
%07831	000898	-005928	1000	0781	0125	0000	0218	0875	0000	%0306	i01	\$
%06960	000538	-004763	0875	0687	0125	0125	0312	0875	0000	%0307	i02	\$
%06173	000420	-004016	0750	0593	0125	0250	0406	0875	0000	%0308	i03	\$
%05332	000400	-003384	0625	0500	0125	0375	0500	0875	0000	%0309	i04	\$
%04590	000424	-002510	0500	0406	0125	0500	0593	0875	0000	%0310	i05	\$
%04147	000200	-001738	0375	0312	0125	0625	0687	0875	0000	%0311	i06	\$
%03546	-00074	-000824	0250	0218	0125	0750	0781	0875	0000	%0312	i07	\$
%02668	000074	-000052	0125	0125	0125	0875	0875	0875	0000	%0313	i08	\$
%02456	000787	-01119	0000	0031	0125	1000	0968	0875	0000	%0314	i09	\$
%02150	001089	-006281	1000	0750	0000	0000	0250	1000	0000	%0315	j01	\$
%06662	000628	-005534	0781	0656	0000	0125	0343	1000	0000	%0316	j02	\$
%05908	000583	-004743	0750	0562	0000	0250	0437	1000	0000	%0317	j03	\$
%05150	000515	-004123	0625	0468	0000	0375	0531	1000	0000	%0318	j04	\$
%04325	000597	-003322	0500	0375	0000	0500	0625	1000	0000	%0319	j05	\$
%03911	000252	-002666	0375	0281	0000	0625	0718	1000	0000	%0320	j06	\$
%03494	000012	-002081	0250	0187	0000	0750	0812	1000	0000	%0321	j07	\$
%03167	-00061	001460	0125	0093	0000	0875	0906	1000	0000	%0322	j08	\$
%02601	000613	000368	0000	0000	0000	1000	1000	1000	0000	%0323	j09	\$
%009649	-000088	000216	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
%08713	000439	-00471	0808	0875	1000	0031	0125	0000	0000	%0568	b11	\$
%08206	000134	-00259	0937	0750	1000	0062	0250	0000	0000	%0569	b12	\$
%07665	0001624	-00567	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$
%07919	0002163	-00812	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
%06411	0002635	-00948	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
%05709	0003349	-01219	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
%04978	000013	-01462	0781	0250	1000	0218	0875	0000	0000	%0574	b17	\$
%04215	000462	-01523	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
%08963	-00726	000633	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$
%08569	-00011	000185	0875	0875	0125	0125	0125	0125	0000	%0577	c11	\$
%08031	000492	-00307	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
%07340	0001097	-00382	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
%06786	0001684	-00512	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
%06025	0002310	-00830	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
%05172	0002985	-01122	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$
%04501	0003530	-01362	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
%03775	0004278	-01722	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
%08705	-01165	000879	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$
%08239	-00594	000476	0781	0875	0750	0218	0125	0250	0000	%0586	d11	\$
%07689	-00017	000143	0750	0750	0750	0250	0250	0250	0000	%0587	d12	\$
%06947	000448	-00276										

See original or copy: <http://web.me.com/klaus.richter/GE54/GE54L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG GE44_22.TXT, Separation cmyn5*, cfi=0.90, D65, not adapted $
%100 x LAB*      %#1000 x (r g b c m y 0)      %nr.      pos $
%Z004719 005681 003795 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008734 -01318 007479 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005665 -05829 003290 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005644 -03372 -03563 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003222 002592 -04091 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004579 006454 -01028 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z002159 000573 000423 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009625 -00093 000201 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004719 005681 003795 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008734 -01318 007479 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005665 -05829 003290 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005644 -03372 -03563 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003222 002592 -04091 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004579 006454 -01028 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z002159 000573 000423 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009625 -00093 000201 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004719 005681 003795 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008734 -01318 007479 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005665 -05829 003290 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005644 -03372 -03563 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003222 002592 -04091 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004579 006454 -01028 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z002159 000573 000423 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009625 -00093 000201 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005657 004093 004765 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z007809 -02672 006315 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005558 -05342 001054 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004550 -01574 -03693 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003603 002702 -03375 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004619 006108 000294 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z002201 000542 000421 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009634 -00096 000216 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z006518 002653 005576 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006933 -03936 005138 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005415 -04747 -00602 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004215 -00457 -03823 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003931 003524 -02635 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004608 005887 001670 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z002154 000567 000390 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009624 -00091 000209 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z007425 001089 006281 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006429 -05272 004695 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005356 -04440 -02107 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003877 000896 -03922 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004215 004652 -01923 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004613 005837 002750 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z002063 000597 000398 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009624 -00091 000225 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

%BEG GE44.22.TXT, Separation cmyn5*, cfi=0.90, D65, not adapted S
%100 x LAB* 1000 x (r g b c m y 0) %nr. pos \$
001910 000565 000403 0000 0000 0000 1000 1000 1000 0000 %0972 k01 \$
002470 000001 000060 0125 0125 0125 0875 0875 0875 0000 %0973 k02 \$
003595 000033 000012 0250 0250 0250 0750 0750 0750 0000 %0974 k03 \$
004341 000015 000137 0375 0375 0375 0625 0625 0625 0000 %0975 k04 \$
005391 000049 000125 0500 0500 0500 0500 0500 0500 0000 %0976 k05 \$
006505 -000016 000157 0625 0625 0625 0375 0375 0375 0000 %0977 k06 \$
007655 -000020 000113 0750 0750 0750 0250 0250 0250 0000 %0978 k07 \$
008593 -000025 000168 0875 0875 0875 0125 0125 0125 0000 %0979 k08 \$
009366 -000031 000199 1000 1000 1000 0000 0000 0000 0000 %0980 k09 \$
001889 000540 000367 0000 0000 0000 1000 1000 1000 0000 %0981 l01 \$
002427 000006 000060 0125 0125 0125 0875 0875 0875 0000 %0982 l02 \$
003577 000032 000009 0250 0250 0250 0750 0750 0750 0000 %0983 l03 \$
004319 000025 000139 0375 0375 0375 0625 0625 0625 0000 %0984 l04 \$
005351 000047 000106 0500 0500 0500 0500 0500 0500 0000 %0985 l05 \$
006467 -000015 000141 0625 0625 0625 0375 0375 0375 0000 %0986 l06 \$
007632 -000025 000118 0750 0750 0750 0250 0250 0250 0000 %0987 l07 \$
008593 -000035 000176 0875 0875 0875 0125 0125 0125 0000 %0988 l08 \$
009660 -000091 000203 1000 1000 1000 0000 0000 0000 0000 %0989 l09 \$
001847 000559 000352 0000 0000 0000 1000 1000 1000 0000 %0990 m01 \$
002388 000007 000081 0125 0125 0125 0875 0875 0875 0000 %0991 m02 \$
003513 000039 000017 0250 0250 0250 0750 0750 0750 0000 %0992 k03 \$
004312 000024 000134 0375 0375 0375 0625 0625 0625 0000 %0993 k04 \$
005300 000054 000131 0500 0500 0500 0500 0500 0500 0000 %0994 m05 \$
006430 -000017 000163 0625 0625 0625 0375 0375 0375 0000 %0995 m06 \$
007637 -000019 000127 0750 0750 0750 0250 0250 0250 0000 %0996 m07 \$
008580 -000023 000179 0875 0875 0875 0125 0125 0125 0000 %0997 m08 \$
009645 -000094 000212 1000 1000 1000 0000 0000 0000 0000 %0998 m09 \$
001850 000575 000373 0000 0000 0000 1000 1000 1000 0000 %0999 n01 \$
002404 000006 000084 0125 0125 0125 0875 0875 0875 0000 %1000 n02 \$
003545 000042 000025 0250 0250 0250 0750 0750 0750 0000 %1001 n03 \$
004292 000033 000141 0375 0375 0375 0625 0625 0625 0000 %1002 n04 \$
005295 000070 000116 0500 0500 0500 0500 0500 0500 0000 %1003 n05 \$
006491 -000087 000147 0625 0625 0625 0375 0375 0375 0000 %1004 n06 \$
007648 -000012 000119 0750 0750 0750 0250 0250 0250 0000 %1005 n07 \$
008608 -000010 000177 0875 0875 0875 0125 0125 0125 0000 %1006 n08 \$
009657 -000087 000191 1000 1000 1000 0000 0000 0000 0000 %1007 n09 \$
002139 000572 000373 0000 0000 0000 1000 1000 1000 0000 %1008 k10 \$
002518 000024 000041 0066 0066 0066 0933 0933 0933 0000 %1009 k11 \$
002765 000012 000024 0133 0133 0133 0866 0866 0866 0000 %1010 k12 \$
003154 000011 000019 0200 0200 0200 0800 0800 0800 0000 %1011 k13 \$
003937 000022 000038 0266 0266 0266 0733 0733 0733 0000 %1012 k14 \$
004342 000047 000089 0333 0333 0333 0666 0666 0666 0000 %1013 k15 \$
004582 000043 000047 0400 0400 0400 0600 0600 0600 0000 %1014 k16 \$
005295 000008 000119 0466 0466 0466 0533 0533 0533 0000 %1015 k17 \$
005913 000044 000124 0533 0533 0533 0466 0466 0466 0000 %1016 k18 \$
006391 -000047 000191 0600 0600 0600 0399 0399 0399 0000 %1017 k19 \$
006852 -000061 000175 0666 0666 0666 0333 0333 0333 0000 %1018 k20 \$
007502 -000003 000123 0733 0733 0733 0266 0266 0266 0000 %1019 k21 \$
008049 -000046 000169 0800 0800 0800 0199 0199 0199 0000 %1020 k22 \$
008471 -000051 000186 0866 0866 0866 0133 0133 0133 0000 %1021 k23 \$
008778 -000058 000194 0933 0933 0933 0066 0066 0066 0000 %1022 k24 \$
009559 -000081 000193 1000 1000 1000 0000 0000 0000 0000 %1023 k25 \$
002158 000535 000372 0000 0000 0000 1000 1000 1000 0000 %1024 l10 \$
002521 000020 000062 0066 0066 0066 0933 0933 0933 0000 %1025 l11 \$
002751 000016 000039 0133 0133 0133 0866 0866 0866 0000 %1026 l12 \$
003138 000013 000037 0200 0200 0200 0800 0800 0800 0000 %1027 l13 \$
003932 000021 000048 0266 0266 0266 0733 0733 0733 0000 %1028 l14 \$
004342 000051 000193 0333 0333 0333 0666 0666 0666 0000 %1029 l15 \$
004545 000045 000056 0400 0400 0400 0600 0600 0600 0000 %1030 l16 \$
005255 000023 000101 0466 0466 0466 0533 0533 0533 0000 %1031 l17 \$
005803 000059 000113 0533 0533 0533 0466 0466 0466 0000 %1032 l18 \$
006314 000022 000142 0600 0600 0600 0399 0399 0399 0000 %1033 l19 \$
006773 000044 000153 0666 0666 0666 0333 0333 0333 0000 %1034 l20 \$
007412 000006 000114 0733 0733 0733 0266 0266 0266 0000 %1035 l21 \$
007993 -000039 000166 0800 0800 0800 0199 0199 0199 0000 %1036 l22 \$
008395 -000042 000176 0866 0866 0866 0133 0133 0133 0000 %1037 l23 \$
008748 -000056 000192 0933 0933 0933 0066 0066 0066 0000 %1038 l24 \$
009561 -000081 000194 1000 1000 1000 0000 0000 0000 0000 %1039 l25 \$
002157 000555 000341 0000 0000 0000 1000 1000 1000 0000 %1040 m10 \$
002516 000026 000053 0066 0066 0066 0933 0933 0933 0000 %1041 m11 \$
002740 000017 000043 0133 0133 0133 0866 0866 0866 0000 %1042 m12 \$
003185 000015 000047 0200 0200 0200 0800 0800 0800 0000 %1043 m13 \$
003904 000029 000050 0266 0266 0266 0733 0733 0733 0000 %1044 m14 \$
004295 000049 000123 0333 0333 0333 0666 0666 0666 0000 %1045 m15 \$
004565 000049 000063 0400 0400 0400 0600 0600 0600 0000 %1046 m16 \$
005216 000018 000130 0466 0466 0466 0533 0533 0533 0000 %1047 m17 \$
005754 000064 000118 0533 0533 0533 0466 0466 0466 0000 %1048 m18 \$
006237 -000029 000189 0600 0600 0600 0399 0399 0399 0000 %1049 m19 \$
006688 -000051 000188 0666 0666 0666 0333 0333 0333 0000 %1050 m20 \$
007346 000016 000128 0733 0733 0733 0266 0266 0266 0000 %1051 m21 \$
007921 -000036 000168 0800 0800 0800 0199 0199 0199 0000 %1052 m22 \$

TUB-test chart GE54; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: ->olv* setrgbcolor

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE54/GE54L0NP.PDF> / <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=

TUB registration: 20091101-GE54/GE54L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IUB material: code=rha4ta

[illegible]

TUB-test chart GE54; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```


N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-GE54/GE54L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

TUB-test chart GE54; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE54/GE54L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.00

#09596	#08003	#00004	1000	1000	1000	0000	0000	0000	0000	#0081	J01 \$	#09657	#00006	-00013	1000	1000	1000	0000	0000	0000	0000	#0405	J10 S	#09649	-00002	-00049	1000	1000	1000	0000	0000	0000	#0729	J19 \$	
#08376	-03081	-06668	0875	0968	1000	0125	0031	0000	0000	#0082	J02 \$	#08624	#00230	-00617	0906	0875	1000	0093	0125	0000	0000	#0406	J11 S	#08737	#00842	-00440	1000	0875	0968	0000	0125	0031	0000	#0730	J20 \$
#08146	-04056	01105	0750	0937	1000	0250	0062	0000	0000	#0083	J03 \$	#08177	#00474	-00896	0812	0750	1000	0187	0250	0000	0000	#0407	J12 S	#08254	#01439	#00110	1000	0750	0937	0000	0250	0062	0000	#0731	J21 \$
#07459	-06657	-01427	0625	0906	1000	0375	0093	0000	0000	#0084	J04 \$	#07363	#00758	-01265	0718	0625	1000	0281	0375	0000	0000	#0408	J13 S	#07880	#02304	-00029	1000	0625	0906	0000	0375	0093	0000	#0732	J22 \$
#06917	-08688	-01891	0500	0875	1000	0500	0125	0000	0000	#0085	J05 \$	#06527	#01078	-01729	0625	0500	1000	0373	0500	0000	0000	#0409	J14 S	#07252	#02981	-00019	1000	0500	0875	0000	0500	0125	0000	#0733	J23 \$
#06406	-01161	-02438	0375	0843	1000	0625	0156	0000	0000	#0086	J06 \$	#05774	#01498	-02145	0631	0375	1000	0468	0625	0000	0000	#0410	J15 S	#06571	#02380	-00097	1000	0375	0843	0000	0625	0156	0000	#0734	J24 \$
#05861	-01370	-02938	0250	0812	1000	0750	0187	0000	0000	#0087	J07 \$	#05025	#01852	-02721	0437	0250	1000	0562	0750	0000	0000	#0411	J16 S	#05918	#04409	-00055	1000	0250	0812	0000	0750	0187	0000	#0735	J25 \$
#05291	-01644	-03428	0125	0781	1000	0875	0218	0000	0000	#0088	J08 \$	#04345	#02167	-03271	0343	0125	1000	0656	0875	0000	0000	#0412	J17 S	#05315	#05019	#00030	1000	0125	0781	0000	0875	0218	0000	#0736	J26 \$
#04550	-01915	-04050	0000	0750	1000	1000	0250	0000	0000	#0089	J09 \$	#03603	#02280	-03757	0250	0000	1000	0750	1000	0000	0000	#0413	J18 S	#04619	#05773	-00059	1000	0000	0750	0000	1000	0250	0000	#0737	J27 \$
#008812	#00501	#00576	1000	0906	0875	0000	0093	0125	0000	#0090	K01 \$	#09297	-02096	#00655	0968	1000	0875	0931	0000	0125	0000	#0414	K10 S	#08881	-00723	-01338	0875	1000	0906	0125	0000	0093	0000	#0738	K19 \$
#08472	-00015	-00075	0875	0875	0875	0125	0125	0125	0000	#0091	K02 \$	#08659	-00016	-00051	0875	0875	0875	0125	0125	0125	0000	#0415	K11 S	#08580	-00011	-00073	0875	0875	0875	0125	0125	0125	0000	#0739	K20 \$
#07930	-03026	-00800	0750	0843	0875	0250	0156	0125	0000	#0092	K03 \$	#07951	#00201	-00614	0781	0750	0875	0218	0250	0125	0000	#0416	K12 S	#07997	#00789	-02059	0875	0750	0843	0125	0250	0156	0000	#0740	K21 \$
#07121	-00515	-01187	0625	0812	0875	0375	0187	0125	0000	#0093	K04 \$	#07204	#00520	-00953	0687	0625	0875	0312	0375	0125	0000	#0417	K13 S	#07499	#01389	-00009	0875	0625	0812	0125	0375	0187	0000	#0741	K22 \$
#06625	-00719	-01521	0500	0781	0875	0500	0218	0125	0000	#0094	K05 \$	#06250	#00807	-01378	0593	0500	0875	0406	0500	0125	0000	#0418	K14 S	#06751	#01959	#00011	0875	0500	0781	0125	0500	0218	0000	#0742	K23 \$
#06102	-00967	-01973	0375	0750	0875	0625	0250	0125	0000	#0095	K06 \$	#05501	#01197	-01887	0500	0375	0875	0500	0625	0125	0000	#0419	K15 S	#06133	#02655	-00067	0875	0375	0750	0125	0625	0250	0000	#0743	K24 \$
#05520	-01313	-02508	0250	0718	0875	0750	0812	0125	0000	#0096	K07 \$	#04794	#01501	-02330	0406	0250	0875	0593	0750	0125	0000	#0420	K16 S	#05410	#03514	-01005	0875	0250	0718	0125	0750	0812	0000	#0744	K25 \$
#04892	-01579	-02978	0125	0687	0875	0875	0312	0125	0000	#0097	K08 \$	#04035	#02182	-02864	0312	0125	0875	0687	0875	0125	0000	#0421	K17 S	#04831	#04021	-00026	0875	0125	0687	0125	0875	0312	0000	#0745	K26 \$
#04374	-01822	-03435	0000	0656	0875	1000	0343	0125	0000	#0098	K09 \$	#03276	#02722	-03411	0218	0000	0875	0781	1000	0125	0000	#0422	K18 S	#04176	#04025	#00024	0875	0000	0656	0125	1000	0343	0000	#0746	K27 \$
#08488	#00956	#01006	1000	0812	0750	0000	0187	0250	0000	#0099	L01 \$	#09010	-00640	#01312	0937	1000	0750	0662	0000	0250	0000	#0423	L10 S	#08074	-01304	#00025	0750	1000	0812	0250	0000	0187	0000	#0747	L19 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417	0875	0781	0875	0125	0128	0250	0000	#0100	L02 \$	#08451	-00289	#00462	0843	0875	0750	0156	0125	0250	0000	#0424	L11 S	#08003	-00692	-01068	0750	0875	0781	0250	0125	0128	0000	#0748	L20 \$
#08041	#00311	#00417																																	

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-GE54/GE54L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

TUB-test chart GE54; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE54/GE54L0NP.PDF> / <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=

[illegible]

See original or copy: <http://web.me.com/klaus.richter/GE54/GE54L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG GE44_22.TXT, Separation cmyn5*, cfi=0.90, D65, adapted S
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr.    pos $
%Z004719 005337 003447 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008734 -01304 007251 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005665 -06089 002971 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005644 -03634 -03883 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003222 002114 -04483 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004579 006097 -01380 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z002159 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009625 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004719 005337 003447 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008734 -01304 007251 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005665 -06089 002971 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005644 -03634 -03883 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003222 002114 -04483 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004579 006097 -01380 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z002159 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009625 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004719 005337 003447 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008734 -01304 007251 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005665 -06089 002971 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005644 -03634 -03883 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003222 002114 -04483 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004579 006097 -01380 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z002159 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009625 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005657 003847 004439 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z007809 -02733 006048 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005558 -05596 000725 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004550 -01915 -04050 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003603 002280 -03757 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004619 005773 -00059 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z002201 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009634 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z006518 002470 005291 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006933 -04082 004864 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005415 -05027 -00913 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004215 -00843 -04164 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003931 003114 -02983 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004608 005536 001339 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z002154 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009624 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z007425 000980 006005 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006429 -05471 004396 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005356 -04737 -02430 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003877 000464 -04280 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004215 004251 -02273 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004613 005472 002410 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z002063 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009624 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```


See original or copy: <http://web.me.com/klaus.richter/GE54/GE54L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG GE44.22.TXT, Separation cmyn5*, cfi=0.90, D65, adapted S
%100 x LAB*a      1000 x (r g b   c m y 0)      %nrr. pos $
001910 -00013 -00062 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002470 -00527 -00386 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003595 -00397 -00396 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004341 -00350 -00246 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005391 -00225 -00222 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006505 -00193 -00152 0625 0625 0625 0625 0375 0375 0000 %0977 k06 $
007655 -00097 -00157 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008593 -00020 -00069 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009366 -00006 -00081 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
001889 -00039 -00099 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002427 -00526 -00387 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003577 -00399 -00399 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004319 -00342 -00253 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005351 -00238 -00242 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006467 -00195 -00169 0625 0625 0625 0625 0375 0375 0000 %0986 l06 $
007632 -00104 -00152 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
008593 -00030 -00061 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009660 -00006 -00002 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
001847 -00024 -00115 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002388 -00528 -00368 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003513 -00398 -00393 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004312 -00344 -00250 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
005300 -00227 -00218 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006430 -00201 -00148 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
007637 -00097 -00143 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
008580 -00019 -00059 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009645 -00002 -00010 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
001850 -00008 -00094 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002404 -00528 -00364 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003545 -00392 -00384 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004292 -00336 -00242 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005295 -00212 -00233 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006491 -00106 -00162 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
007648 -00090 -00151 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008608 -00004 -00060 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009657 -00010 -00010 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
002139 -00013 -00085 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
002518 -00500 -00403 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002765 -00491 -00412 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
003154 -00458 -00403 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
003937 -00379 -00358 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
004342 -00318 -00293 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
004582 -00301 -00327 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005295 -00274 -00231 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
005913 -00184 -00204 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006391 -00234 -00121 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
006852 -00208 -00122 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007502 -00093 -00152 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
008049 -00088 -00087 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
008471 -00057 -00055 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
008778 -00037 -00037 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009559 -00007 -00011 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
002158 -00021 -00085 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
002521 -00504 -00383 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
002751 -00487 -00398 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
003138 -00457 -00387 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
003932 -00308 -00348 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
004342 -00314 -00279 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
004545 -00302 -00320 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005255 -00262 -00250 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
005803 -00179 -00219 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006314 -00215 -00173 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
006773 -00197 -00146 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007412 -00091 -00163 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
007993 -00087 -00092 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
008395 -00055 -00068 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
008748 -00037 -00039 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009561 -00007 -00010 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
002157 -00001 -00115 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
002516 -00499 -00392 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002740 -00488 -00394 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
003185 -00451 -00375 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
003904 -00374 -00347 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
004295 -00320 -00260 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
004565 -00296 -00311 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005216 -00271 -00223 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
005754 -00178 -00216 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006237 -00229 -00129 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
006688 -00212 -00115 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007346 -00087 -00152 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
007921 -00089 -00092 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```



```
input: w setgray
output: ->oly* setrgbcolor
```



```
input: w setgray
output: ->olv* setrgbcolo
```

009594	-00060	000224	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
008471	-00023	-00406	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008015	000012	-00846	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
007221	000166	-01230	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
006526	000248	-01686	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
005891	000243	-02132	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$
005282	000131	-02652	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
004469	000221	-03300	0125	0343	1000	0875	0656	0000	0000	%0250	b08	\$
003891	000493	-04243	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
003018	000283	-000930	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
003093	000225	000192	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
007797	-00008	-00362	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
006952	000040	-00895	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
006291	000162	-01337	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
005632	000122	-01810	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
004947	000120	-02280	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
004207	000243	-02868	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
003678	000187	-03338	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
008912	000538	-001638	1000	0937	0750	0000	0602	0250	0000	%0261	d01	\$
008258	000236	-000787	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
007545	000021	000124	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$
006651	-00026	-00286	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
006070	-00004	-00934	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
005374	000100	-01402	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
004633	000240	-01851	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
004074	000160	-02306	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
003429	000170	-02814	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
008809	000570	-002674	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
008064	000307	-001549	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
007371	000156	-000860	0750	0718	0875	0250	0281	0375	0000	%0272	e03	\$
006471	000013	-000169	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
005857	000028	-00405	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
005244	000083	-00999	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$
004307	-00039	-01521	0250	0343	0625	0750	0656	0375	0000	%0276	e07	\$
003813	000106	-01890	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
003153	000186	-02450	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
008591	000824	-003300	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
007869	000550	-002565	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
007076	000442	-001796	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
006268	000188	-000944	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
005450	000067	-000116	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
004944	-00020	-00473	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
004350	000014	-01104	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
003623	000103	-01635	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
002912	000146	-01897	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
008338	000126	-004129	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
007574	000737	-003149	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
006738	000597	-002550	0750	0656	0375	0250	0343	0625	0000	%0290	g03	\$
005927	000381	-002030	0625	0656	0375	0375	0437	0625	0000	%0291	g04	\$
005118	000224	-000909	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
004540	000033	-000117	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
004125	000063	-000598	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
003404	000018	-01125	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
002791	000165	-01648	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
008100	001265	-005052	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
007283	000893	-004116	0875	0718	0500	0125	0281	0750	0000	%0298	h02	\$
006441	000705	-003489	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
005693	000650	-002489	0625	0531	0250	0375	0468	0750	0000	%0300	h04	\$
004892	000417	-001805	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
004303	000174	-000870	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
003741	000036	-000005	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
003219	000048	-00659	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
002791	000236	-01339	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
007908	001495	-005897	1000	0781	0125	0000	0218	0875	0000	%0306	i01	\$
007020	000142	-004738	0875	0687	0125	0125	0312	0875	0000	%0307	i02	\$
006224	000863	-003998	0750	0593	0125	0250	0406	0875	0000	%0308	i03	\$
005377	000778	-003374	0625	0500	0125	0375	0500	0875	0000	%0309	i04	\$
004627	000726	-002514	0500	0406	0125	0500	0593	0875	0000	%0310	i05	\$
004172	000223	-001740	0375	0312	0125	0625	0687	0875	0000	%0311	i06	\$
003555	000039	-000819	0250	0218	0125	0750	0781	0875	0000	%0312	i07	\$
002669	000014	-000053	0125	0125	0125	0875	0875	0875	0000	%0313	i08	\$
002451	000713	-01115	0000	0031	0125	1000	0968	0875	0000	%0314	i09	\$
007508	001691	-006242	1000	0750	0000	0000	0250	1000	0000	%0315	j01	\$
006728	001163	-005488	0875	0656	0000	0125	0343	1000	0000	%0316	j02	\$
005967	001057	-004711	0750	0562	0000	0250	0437	1000	0000	%0317	j03	\$
005202	000934	-004098	0625	0468	0000	0375	0531	1000	0000	%0318	j04	\$
004372	000951	-003316	0500	0375	0000	0500	0625	1000	0000	%0319	j05	\$
003945	000548	-002656	0375	0281	0000	0625	0718	1000	0000	%0320	j06	\$
003518	000250	-002069	0250	0187	0000	0750	0812	1000	0000	%0321	j07	\$
003177	000112	-001396	0125	0093	0000	0875	0906	1000	0000	%0322	j08	\$
002085	000692	-000396	0000	0000	0000	1000	1000	1000	0000	%0323	j09	\$
009650	-00057	000209	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
008714	000430	-00468	0875	1000	0031	0125	0000	0000	0000	%0568	b11	\$
008226	000177	-00218	0937	0750	1000	0602	0250	0000	0000	%0569	b12	\$
007690	001651	-00507	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$
007052	002188	-00729	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
006453	002662	-00844	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
005764	003365	-01083	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
005046	003555	-01295	0781	0250	1000	0281	0875	0000	0000	%0574	b17	\$
004294	004692	-01739	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
003956	-00638	000588	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$
008572	000017	-000182	0875	0875	0125	0125	0125	0125	0000	%0577	c11	\$
008035	000502	-00298	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
007357	001123	-00344	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
006814	001716	-00446	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
006062	002334	-00739	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
005221	002997	-01001	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$
004560	003527	-01217	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
003848	004235	-01542	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
008692	-01041	000807	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$
008233	-00525	000439	0781	0875	07							

```
%BEG GE44_22.TXT, Separation cmyn5*, cfi=0.90, D50, not adapted $
%100 x LAB*      %#1000 x (r g b c m y o)      %nr.      pos $
%Z004894 006053 004050 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008779 -00694 007320 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005590 -05409 002928 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005492 -04026 -03891 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003182 002144 -04124 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004727 006484 -00695 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z002177 000657 000450 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009626 -00064 000194 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004894 006053 004050 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008779 -00694 007320 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005590 -05409 002928 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005492 -04026 -03891 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003182 002144 -04124 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004727 006484 -00695 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z002177 000657 000450 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009626 -00064 000194 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004894 006053 004050 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008779 -00694 007320 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005590 -05409 002928 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005492 -04026 -03891 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003182 002144 -04124 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004727 006484 -00695 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z002177 000657 000450 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009626 -00064 000194 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005796 004584 004901 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z007817 -02103 006093 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005466 -05171 000736 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004429 -02199 -03930 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003590 002415 -03361 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004776 006262 000617 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z002218 000625 000446 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009635 -00065 000209 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z006628 003214 005620 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006907 -03404 004852 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005306 -04834 -00906 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004112 -01022 -04011 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003962 003373 -02537 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004774 006145 001976 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z002171 000647 000417 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009625 -00061 000202 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z007508 001691 006242 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006375 -04747 004335 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005220 -04830 -02433 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003801 000409 -04043 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004294 004602 -01730 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004787 006154 003042 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z002081 000678 000426 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009626 -00058 000218 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```


See original or copy: <http://web.me.com/klaus.richter/GE54/GE54L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

%BEG	GE44	22.TXT	Separation	cmyn5*	cfi=0.90	D50	not	adapted	S
%100 x	LAB*	1000 x	(r g b	c m y θ				%nr.	pos \$
001927	000045	000429	0000	0000	0000	1000	1000	0000	%0972 k01 \$
002471	000010	000061	0125	0125	0125	0875	0875	0875	0000
003596	000037	000014	0250	0250	0250	0750	0750	0750	0000
004343	000038	000138	0375	0375	0375	0625	0625	0625	0000
005394	000072	000127	0500	0500	0500	0500	0500	0500	0000
006506	000008	000155	0625	0625	0625	0375	0375	0375	0000
007656	000002	000110	0750	0750	0750	0250	0250	0250	0000
008595	000001	000105	0875	0875	0875	0125	0125	0125	0000
009367	000061	000193	1000	1000	1000	0000	0000	0000	0000
001905	000615	000392	0000	0000	0000	1000	1000	1000	0000
002428	000015	000062	0125	0125	0125	0875	0875	0875	0000
003578	000037	000011	0250	0250	0250	0750	0750	0750	0000
004322	000047	000131	0375	0375	0375	0625	0625	0625	0000
005353	000068	000108	0500	0500	0500	0500	0500	0500	0000
006469	000007	000140	0625	0625	0625	0375	0375	0375	0000
007633	000007	000116	0750	0750	0750	0250	0250	0250	0000
008595	000008	000172	0875	0875	0875	0125	0125	0125	0000
009661	000062	000196	1000	1000	1000	0000	0000	0000	0000
001863	000633	000379	0000	0000	0000	1000	1000	1000	0000
002389	000019	000082	0125	0125	0125	0875	0875	0875	0000
003514	000045	000019	0250	0250	0250	0750	0750	0750	0000
004314	000047	000135	0375	0375	0375	0625	0625	0625	0000
005302	000079	000133	0500	0500	0500	0500	0500	0500	0000
006432	000008	000161	0625	0625	0625	0375	0375	0375	0000
007638	000000	000125	0750	0750	0750	0250	0250	0250	0000
008582	000004	000176	0875	0875	0875	0125	0125	0125	0000
009646	000064	000205	1000	1000	1000	0000	0000	0000	0000
001867	000651	000400	0000	0000	0000	1000	1000	1000	0000
002406	000018	000086	0125	0125	0125	0875	0875	0875	0000
003546	000049	000028	0250	0250	0250	0750	0750	0750	0000
004295	000057	000143	0375	0375	0375	0625	0625	0625	0000
005298	000004	000119	0500	0500	0500	0500	0500	0500	0000
006493	000015	000146	0625	0625	0625	0375	0375	0375	0000
007650	000000	000117	0750	0750	0750	0250	0250	0250	0000
008610	000017	000174	0875	0875	0875	0125	0125	0125	0000
009658	000060	000184	1000	1000	1000	0000	0000	0000	0000
002156	000650	000400	0000	0000	0000	1000	1000	1000	0000
002519	000031	000043	0066	0066	0066	0933	0933	0933	0000
002766	000016	000025	0133	0133	0133	0866	0866	0866	0000
003155	000015	000021	0200	0200	0200	0800	0800	0800	0000
003938	000029	000039	0266	0266	0266	0733	0733	0733	0000
004344	000064	000092	0333	0333	0333	0666	0666	0666	0000
004584	000054	000049	0400	0400	0400	0600	0600	0600	0000
005296	000028	000119	0466	0466	0466	0533	0533	0533	0000
005916	000067	000126	0533	0533	0533	0466	0466	0466	0000
006392	000019	000189	0600	0600	0600	0399	0399	0399	0000
006854	000037	000172	0666	0666	0666	0333	0333	0333	0000
007504	000016	000121	0733	0733	0733	0266	0266	0266	0000
008051	000022	000166	0800	0800	0800	0199	0199	0199	0000
008473	000024	000182	0866	0866	0866	0133	0133	0133	0000
008779	000030	000189	0933	0933	0933	0066	0066	0066	0000
009560	000054	000186	1000	1000	1000	0000	0000	0000	0000
002175	000612	000397	0000	0000	0000	1000	1000	1000	0000
002523	000030	000064	0066	0066	0066	0933	0933	0933	0000
002752	000023	000040	0133	0133	0133	0866	0866	0866	0000
003138	000019	000038	0200	0200	0200	0800	0800	0800	0000
003933	000029	000050	0266	0266	0266	0733	0733	0733	0000
004344	000070	000106	0333	0333	0333	0666	0666	0666	0000
004547	000056	000058	0400	0400	0400	0600	0600	0600	0000
005257	000041	000102	0466	0466	0466	0533	0533	0533	0000
005806	000081	000115	0533	0533	0533	0466	0466	0466	0000
006316	000090	000140	0600	0600	0600	0399	0399	0399	0000
006775	000022	000151	0666	0666	0666	0333	0333	0333	0000
007414	000025	000113	0733	0733	0733	0266	0266	0266	0000
007995	000015	000163	0800	0800	0800	0199	0199	0199	0000
008396	000017	000172	0866	0866	0866	0133	0133	0133	0000
008750	000028	000188	0933	0933	0933	0066	0066	0066	0000
009562	000053	000188	1000	1000	1000	0000	0000	0000	0000
002173	000629	000367	0000	0000	0000	1000	1000	1000	0000
002517	000035	000055	0066	0066	0066	0933	0933	0933	0000
002741	000024	000045	0133	0133	0133	0866	0866	0866	0000
003186	000023	000049	0200	0200	0200	0800	0800	0800	0000
003905	000039	000052	0266	0266	0266	0733	0733	0733	0000
004297	000071	000126	0333	0333	0333	0666	0666	0666	0000
004567	000062	000066	0400	0400	0400	0600	0600	0600	0000
005218	000039	000131	0466	0466	0466	0533	0533	0533	0000
005757	000087	000120	0533	0533	0533	0466	0466	0466	0000
006239	000001	000187	0600	0600	0600	0399	0399	0399	0000
006689	000024	000185	0666	0666	0666	0333	0333	0333	0000
007348	000037	000127	0733	0733	0733	0266	0266	0266	0000
007923	000011	000165	0800	0800	0800	0199	0199	0199	0000

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE54/GE54L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfl=0.90, nt=

TUB registration: 20091101-GE54/GE54LONP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

[illegible]

TUB-test chart GE54; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE54/GE54L0NP.PDF> / <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=

[illegible]

TUB-test chart GE54; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

input: w *setgray*
output: $\rightarrow$ *oly** *setrgbcolor*

009595	000000	-00011	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
008490	-00239	-00706	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
007282	-00338	-01132	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
007963	-00493	-01569	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
006637	-00547	-01982	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
006609	-00756	-02467	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
005451	-00970	-02978	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
004827	-01221	-03546	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$
004112	-01484	-04372	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
008888	-00507	006060	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
008425	-00841	-00555	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
007820	-00335	-00695	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
007009	-00379	-01204	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
006380	-00522	-01677	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
005826	-00678	-02131	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
005188	-01064	-02618	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
004524	-01080	-03151	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
003910	-01296	-03714	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
006876	000876	001264	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
008101	000296	000486	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
007540	-00129	-00127	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
006708	-00416	-00550	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
006166	-00519	-01285	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
005540	-00699	-01784	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
004877	-00891	-02178	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
004329	-01035	-02718	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
003758	-01328	-03222	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
008515	001088	002121	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
007751	000646	001139	0875	0750	0875	0625	0125	0250	0375	%0190	V02	\$
007152	000594	000594	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
006355	-00234	-00804	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
005846	-00431	-00771	0500	0687	0625	0500	0437	0375	0000	%0193	V05	\$
005314	-00649	-01346	0375	0562	0625	0625	0625	0375	0000	%0194	V06	\$
004517	-00816	-01951	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
003963	-00972	-02259	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
003433	-01179	-02876	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
008158	001477	002591	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
007457	000997	001886	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
006816	000533	001353	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
006026	000125	004048	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
005417	-00247	-00187	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
004933	-00540	-00898	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$
004396	-00763	-01468	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
003782	-00851	-02107	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
003221	-01188	-02233	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
007819	001803	003461	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
007117	001092	002634	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
006456	000181	002039	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
005659	000534	001417	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
005093	000033	000543	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
004563	-00389	-00209	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
004234	-00547	-01015	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
003549	-00841	-01452	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
003049	-01096	-01973	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
007394	002363	004053	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
006709	001619	003357	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
006038	001229	002659	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
005278	000627	001075	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
004724	000509	001245	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
004330	-00046	-000524	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
003829	-00484	-00365	0250	0250	0250	0750	0750	0750	0000	%0222	Y07	\$
003320	-00673	-01036	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
003023	-00756	-01542	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
007081	002836	004680	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
006269	001951	003595	0875	0500	0125	0125	0500	0875	0000	%0226	Z02	\$
005634	001541	003139	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
004969	001189	002503	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
004352	000851	001813	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
003943	000354	001107	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
003424	-00207	-000294	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
002698	-00503	-00346	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
002570	-00219	-01536	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$
006628	002991	005332	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
005951	002146	004165	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
005296	001843	003667	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
004661	001504	002997	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
004052	001037	002412	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
003675	000701	001902	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
003409	000149	001492	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
003086	-00253	-000841	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$
002193	-000002	-000033	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009652	-00002	-000022	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
008608	000275	-00652	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
008192	000657	-00805	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
007532	000998	-01036	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
006853	001341	-01271	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
006056	001703	-01615	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
005224	002333	-02025	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
004632	002306	-02452	0562	0250	1000	0875	0875	0000	0000	%0493	S17	\$
003962	002396	-02803	0500	1000	0500	1000	0500	0000	0000	%0494	S18	\$
009046	-00460	-00427	0937	1000	0875	0062	0000	0125	0000	%0495	T10	\$
008624	-00033	-00049	0875	0875	0875	0125	0125	0125	0000	%0496	T11	\$
008019	000686	-00720	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
007296	000299	-00807	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
006493	001103	-01130	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
005620	001582	-01472	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
004870	002086	-01926	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
004205	002456	-02236	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
003583	002763	-02652	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
008809	-00825	-00921	0875	1000	0750	0125	0000	0250	0000	%0504	U10	\$
008337	-00476	-00401	0812	0875	0750	0187	0125	0250	0000	%0		

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-GE54/GE54LONP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

TUB-test chart GE54; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE54/GE54L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.00

[illegible]

096050	090003	-090808	1000	1000	1000	0000	0000	0000	0000	056567	b100
098714	090399	-097112	0968	0875	1000	0031	0125	0000	0000	0568	b100
098260	091099	-094775	0937	0750	1000	0062	0250	0000	0000	0569	b100
097690	091521	-097779	0906	0625	1000	0093	0375	0000	0000	0570	b100
097052	091995	-01019	0875	0500	1000	0125	0500	0000	0000	0571	b100
096453	092411	-011159	0843	0375	1000	0156	0625	0000	0000	0572	b100
095764	093048	-014048	0812	0250	1000	0187	0750	0000	0000	0573	b100
095094	093626	-022078	0781	0125	1000	0218	0875	0000	0000	0574	b100
094294	094119	-022078	0750	0000	1000	0250	0000	0000	0000	0575	b100
098056	-096444	090350	0906	1000	0875	0093	0000	0125	0000	0576	b100
098572	-090826	090655	0875	0875	0875	0125	0125	0125	0000	0577	b100
098035	090405	-09561	0843	0750	0875	0156	0250	0125	0000	0578	b100
097357	090960	-09625	0812	0625	0875	0187	0375	0125	0000	0579	b100
096814	091500	-09742	0781	0500	0875	0218	0500	0125	0000	0580	b100
096062	092044	-01056	0750	0375	0875	0250	0625	0125	0000	0581	b100
095221	092625	-01342	0718	0250	0875	0312	0750	0125	0000	0582	b100
094560	093090	-01576	0687	0125	0875	0312	0875	0125	0000	0583	b100
093848	093729	-01952	0656	0000	0875	0343	1000	0125	0000	0584	b100
098692	-01074	090562	0812	1000	0750	0187	0000	0250	0000	0585	b100
098233	-09603	090181	0781	0875	0750	0218	0125	0250	0000	0586	b100
097690	-09124	-09139	0750	0750	0750	0250	0250	0250	0000	0587	b100
096951	090253	-09558	0718	0625	0750	0281	0375	0250	0000	0588	b100
096178	090844	-09684	0687	0500	0750	0312	0500	0250	0000	0589	b100
094429	-01442	090562	0750	0000	0750	0343	0500	0250	0000	0590	b100
094235	092039	-01173	0625	0250	0750	0375	0750	0250	0000	0591	b100
094920	092584	-01411	0931	0125	0750	0406	0875	0250	0000	0592	b100
093566	093157	-01668	0562	0000	0750	0437	1000	0250	0000	0593	b100
098320	-01669	091333	0718	1000	0625	0281	0000	0375	0000	0594	b100
097708	-01161	090763	0687	0875	0625	0312	0125	0375	0000	0595	b100
097159	-09725	090266	0656	0750	0625	0343	0250	0375	0000	0596	b100
096593	-09234	-09160	0625	0625	0625	0375	0375	0375	0000	0597	b100
095883	090253	-09668	0593	0500	0625	0406	0500	0375	0000	0598	b100
095304	090814	-09668	0562	0375	0625	0437	0625	0375	0000	0599	b100
094560	091501	-01044	0531	0250	0625	0468	0750	0375	0000	0600	b100
093992	092104	-01283	0500	0125	0625	0500	0875	0375	0000	0601	b100
093274	092766										

[illegible]

```
%BEG GE44.22.TXT, Separation cmyn5*, cfi=0.90, D50, adapted S
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr.   pos $
%Z004894 005659 003693 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008779 -00712 007097 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005590 -05735 002595 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005492 -04363 -04227 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003182 001584 -04540 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004727 006073 -01058 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z002177 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009626 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004894 005659 003693 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008779 -00712 007097 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005590 -05735 002595 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005492 -04363 -04227 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003182 001584 -04540 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004727 006073 -01058 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z002177 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009626 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004894 005659 003693 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008779 -00712 007097 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005590 -05735 002595 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005492 -04363 -04227 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003182 001584 -04540 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004727 006073 -01058 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z002177 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009626 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005796 004292 004569 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z007817 -02207 005826 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005466 -05494 000393 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004429 -02619 -04306 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003590 001917 -03764 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004776 005874 000252 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z002218 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009635 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z006628 002991 005332 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006907 -03601 004571 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005306 -05183 -01233 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004112 -01484 -04372 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003962 002896 -02903 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004774 005745 001634 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z002171 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009625 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z007508 001543 005965 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006375 -05006 004027 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005220 -05202 -02773 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003801 -00100 -04422 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004294 004139 -02096 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004787 005740 002690 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z002081 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009626 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```


KBEG GE44 22.TXT, Separation cmyb* , cf1=0.90, D50, adapted \$					
%100 x LAB*a	1000 x r g b	c m y b	\$nrr.	pos \$	
001297 -00020 -00063 0090 0000 1000 1000 1000 0000	00972 k01 \$	008409 -00070 -00053 0866 0866 0866 0133 0133 0133 0000	%1053 m23 \$		
001241 -00064 -00411 0125 0125 0125 0875 0875 0875 0000	00973 k02 \$	008707 -00051 -00022 0933 0933 0933 0066 0066 0066 0000	%1054 m24 \$		
003596 -00469 -00414 0250 0250 0250 0750 0750 0750 0000	00974 k03 \$	009547 00000 000015 1000 1000 1000 0000 0000 0000 0000	%1055 m25 \$		
004343 -00397 -00261 0375 0375 0375 0625 0625 0625 0000	00975 k04 \$	002160 -00001 -00076 0000 0000 0000 1000 1000 1000 0000	%1056 n10 \$		
005394 -00263 -00232 0500 0500 0500 0500 0500 0500 0000	00976 k05 \$	002485 -00579 -00416 0066 0066 0066 0933 0933 0933 0000	%1057 n11 \$		
006506 -00221 -00160 0625 0625 0625 0375 0375 0375 0000	00977 k06 \$	002732 -00571 -00414 0133 0133 0133 0866 0866 0866 0000	%1058 n12 \$		
007656 -00123 -00161 0750 0750 0750 0250 0250 0250 0000	00978 k07 \$	003086 -00533 -00404 0200 0200 0200 0800 0800 0800 0000	%1059 n13 \$		
008595 -00030 -00069 0875 0875 0875 0125 0125 0125 0000	00979 k08 \$	003912 -00437 -00344 0266 0266 0266 0733 0733 0733 0000	%1060 n14 \$		
009667 000007 -00001 1000 1000 1000 0000 0000 0000 0000	00980 k09 \$	004285 -00358 -00281 0333 0333 0333 0666 0666 0666 0000	%1061 n15 \$		
001905 -00053 -00181 0000 0000 0000 1000 1000 1000 0000	00981 l01 \$	004534 -00345 -00320 0400 0400 0400 0600 0600 0600 0000	%1062 n16 \$		
002428 -00603 -00411 0125 0125 0125 0875 0875 0875 0000	00982 l02 \$	005240 -00312 -00218 0466 0466 0466 0533 0533 0533 0000	%1063 n17 \$		
003578 -00472 -00417 0250 0250 0250 0750 0750 0750 0000	00983 l03 \$	005792 -00215 -00188 0533 0533 0533 0466 0466 0466 0000	%1064 n18 \$		
004322 -00391 -00268 0375 0375 0375 0625 0625 0625 0000	00984 l04 \$	006306 -00253 -00115 0600 0600 0600 0399 0399 0399 0000	%1065 n19 \$		
005353 -00271 -00252 0500 0500 0500 0500 0500 0500 0000	00985 l05 \$	006739 -00231 -00121 0666 0666 0666 0333 0333 0333 0000	%1066 n20 \$		
006469 -00226 -00177 0625 0625 0625 0375 0375 0375 0000	00986 l06 \$	007380 -00090 -00157 0733 0733 0733 0266 0266 0266 0000	%1067 n21 \$		
007633 -00130 -00156 0750 0750 0750 0250 0250 0250 0000	00987 l07 \$	007983 -00106 -00081 0800 0800 0800 0199 0199 0199 0000	%1068 n22 \$		
008592 -00040 -00062 0875 0875 0875 0125 0125 0125 0000	00988 l08 \$	008434 -00068 -00041 0866 0866 0866 0133 0133 0133 0000	%1069 n23 \$		
00181 00000 000002 -00010 1000 1000 1000 0000 0000 0000	00989 l09 \$	008744 -00044 -00031 0933 0933 0933 0066 0066 0066 0000	%1070 n24 \$		
001806 -00116 0000 0000 0000 1000 1000 1000 0000	00990 m01 \$	009560 000005 -00093 1000 1000 1000 0000 0000 0000 0000	%1071 n25 \$		
002389 -00603 -00392 0125 0125 0125 0875 0875 0875 0000	00991 m02 \$	002091 000000 000000 0000 0000 0000 1000 1000 1000 0000	%1072 k26 \$		
003514 -00470 -00412 0250 0250 0250 0750 0750 0750 0000	00992 m03 \$	009518 000000 000000 1000 1000 1000 0000 0000 0000 0000	%1073 k27 \$		
004314 -00392 -00265 0375 0375 0375 0625 0625 0625 0000	00993 m04 \$	004753 005740 003800 1000 0000 0000 0000 1000 1000 0000	%1074 l26 \$		
005302 -00265 -00229 0500 0500 0500 0500 0500 0500 0000	00994 m05 \$	005514 -04588 -03982 0000 1000 1000 1000 0000 0000 0000	%1075 l27 \$		
006432 -00229 -00157 0625 0625 0625 0375 0375 0375 0000	00995 m06 \$	008619 -00668 007364 1000 1000 0000 0000 0000 1000 0000	%1076 m26 \$		
007638 -00122 -00147 0750 0750 0750 0250 0250 0250 0000	00996 m07 \$	002963 001693 -04614 0000 0000 1000 1000 1000 0000 0000	%1077 m27 \$		
008582 -00028 -00060 0875 0875 0875 0125 0125 0125 0000	00997 m08 \$	005333 -06114 002611 0000 1000 0000 0000 1000			

TUB-test chart GE54; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

TUB material: code=rha4ta
r systems