

[illegible]

See original or copy: <http://web.me.com/klaus.richter/GE55/GE55L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.02; nx=1.0

```
%BEG GE45.22.TXT, Separation cmyn61*, cfi=0.90, D65, not adapted $
%100 x LAB*      %1000 x (r g b c m y o)      %nr.      pos $
%z004648 005804 003952 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008721 -01306 007563 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z005667 -05965 003485 %1000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005372 -03648 -03490 %1000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z003186 002651 -04121 %1000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z004598 006422 -01214 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z002212 000397 000457 %1000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009686 -00087 000194 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%z004648 005804 003952 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008721 -01306 007563 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z005667 -05965 003485 %1000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005372 -03648 -03490 %1000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z003186 002651 -04121 %1000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z004598 006422 -01214 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z002212 000397 000457 %1000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009686 -00087 000194 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%z004648 005804 003952 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008721 -01306 007563 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z005667 -05965 003485 %1000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005372 -03648 -03490 %1000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z003186 002651 -04121 %1000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z004598 006422 -01214 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z002212 000397 000457 %1000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009686 -00087 000194 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%z005543 004124 004755 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z007858 -02610 006561 %1000 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005554 -05430 001086 %1000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z004604 -01525 -03637 %1000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003557 002944 -03362 %1000 0250 0000 1000 0750 1000 0000 %0413 J18 %V25M 4 $
%z004640 006156 000340 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z002274 000392 000448 %1000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009673 -00087 000212 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%z006510 002717 005742 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z007053 -03874 005701 %1000 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005480 -04843 -00572 %1000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z004233 -00495 -03896 %1000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z003892 003672 -02662 %1000 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004644 005919 001539 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z002238 000387 000432 %1000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009663 -00087 000207 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%z007426 000989 006514 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z006476 -05245 004862 %1000 0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005389 -04779 -01958 %1000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z003919 000878 -03945 %1000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z004231 004773 -01969 %1000 0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004682 005817 002783 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z002073 000394 000436 %1000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009678 -00087 000208 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

TUB registration: 20091101-GE55/GE55L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/GE55/GE55L0NA.TXT> / .PSS
 Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0, cfi=0.90; nt=0

TUB registration: 20091101-GE55/GE55L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

[illegible]

TUB-test chart GE55; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE55/GE55L0NA.TXT> / PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.02; nx=1.0

See original or copy: <http://web.me.com/klaus.richter/GE55/GE55L0NA.TXT> / PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.02; nx=1.0

See original or copy: <http://web.me.com/klaus.richter/GE55/GE55L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.02; nx=1.0

```
%BEG GE45.22.TXT, Separation cmyn61*, cfi=0.90, D65, adapted $
%100 x LAB*a      %1000 x (r g b c m y o)      %nr.      pos $
%Z004648 005564 003580 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008721 -01281 007335 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005667 -06138 003149 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005372 -03840 -03836 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003186 002317 -04545 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004598 006179 -01588 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z002212 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009686 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%$
%Z004648 005564 003580 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008721 -01281 007335 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005667 -06138 003149 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005372 -03840 -03836 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003186 002317 -04545 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004598 006179 -01588 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z002212 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009686 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%$
%Z004648 005564 003580 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008721 -01281 007335 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005667 -06138 003149 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005372 -03840 -03836 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003186 002317 -04545 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004598 006179 -01588 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z002212 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009686 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%$
%Z005543 003944 004411 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z007858 -02640 006290 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005554 -05610 000742 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004604 -01760 -04011 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003557 002634 -03770 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004640 005917 -00032 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z002274 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009673 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%$
%Z006510 002603 005439 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007053 -03954 005415 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005480 -05023 -00906 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004233 -00755 -04268 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003892 003391 -03045 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004644 005685 001180 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z002238 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009663 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%$
%Z007426 000933 006237 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006476 -05361 004557 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005389 -04963 -02295 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003919 000600 -04327 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004231 004515 -02342 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004682 005588 002425 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z002073 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009678 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%$
```

See original or copy: <http://web.me.com/klaus.richter/GE55/GE55L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.02; nx=1.0

```
%BEG GE45.22.TXT, Separation cmyn61*, cfi=0.90, D65, adapted $
%100 x LAB*a      1000 x (r g b c m y 0)      %nr. pos $
001943 000010 -00044 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002432 -00379 -00353 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003266 -00322 -00390 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004290 -00237 -00243 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005274 -00105 -00204 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006419 -00118 -00153 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
007558 -00043 -00164 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008596 -00043 -00043 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009700 -00003 00000 1000 1000 1000 0000 0000 0000 0000 %0980 m00 $
010968 -00009 00009 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
020458 -00367 -00385 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
03294 -00320 -00397 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
04357 -00226 -00268 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
05306 -00102 -00244 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
06454 -00120 -00195 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
07613 -00043 -00170 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
08624 -00042 -00038 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
09712 000003 000014 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
10931 000001 -00048 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
12402 -00376 -00371 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
13283 -00321 -00399 0250 0250 0250 0750 0750 0750 0000 %0992 k03 $
14334 -00242 -00257 0375 0375 0375 0625 0625 0625 0000 %0993 k04 $
15307 -00127 -00214 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
16413 -00134 -00148 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
17561 -00058 -00156 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
18581 -00046 -00036 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
19711 -00003 000007 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
20981 -00008 -00040 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
22445 -00378 -00366 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
23323 -00317 -00395 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
24326 -00239 -00245 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
25301 -00111 -00211 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
26461 -00119 -00162 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
27592 -00047 -00164 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
28622 -00042 -00038 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
29708 -00003 -00004 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
30208 -00005 -00001 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
32452 -00350 -00389 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
32714 -00341 -00405 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
33059 -00326 -00388 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
33652 -00287 -00359 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
34244 -00199 -00317 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
34587 -00201 -00256 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
35186 -00178 -00229 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
35667 -00080 -00159 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
36314 -00174 -00093 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
36728 -00137 -00054 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
37346 -00053 -00154 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
37851 -00071 -00095 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
38412 -00005 -00072 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
38750 -00033 -00029 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
39643 000014 -00013 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
40254 000029 -00061 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
402504 -00348 -00398 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
402773 -00342 -00405 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
403153 -00318 -00381 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
403718 -00290 -00361 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
404270 -00193 -00340 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
404655 -00196 -00279 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
405226 -00166 -00265 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
405757 -00064 -00218 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
406362 -00146 -00170 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
406765 -00108 -00118 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
407396 -00044 -00179 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
407892 -00067 -00105 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
408438 -00006 -00075 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
408792 -00032 -00032 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
409648 000014 -00016 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
42228 000019 -00046 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
42456 -00346 -00397 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
42766 -00338 -00407 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
43122 -00318 -00378 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
43725 -00281 -00354 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
44270 -00197 -00304 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
44634 -00190 -00266 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
45202 -00164 -00234 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
45578 -00078 -00193 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
46272 -00166 -00133 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
46702 -00121 -00098 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
47336 -00050 -00165 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
47801 -00070 -00106 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```


See original or copy: <http://web.me.com/klaus.richter/GE55/GE55L0NA.TXT> / .PSS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfi=0.90; m=0

See original or copy: <http://web.me.com/klaus.richter/GE55/GE55L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.02; nx=1.0

```
%BEG GE45.22.TXT, Separation cmyn61*, cfi=0.90, D50, not adapted $
%100 x LAB*          %1000 x (r g b c m y o)          %nr.      pos $
%Z004828 006172 004211 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008766 -00680 007400 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005592 -05529 003111 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005216 -04317 -03832 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003146 002199 -04153 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004742 006435 -00888 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z002227 000479 000476 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009687 -00059 000187 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004828 006172 004211 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008766 -00680 007400 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005592 -05529 003111 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005216 -04317 -03832 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003146 002199 -04153 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004742 006435 -00888 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z002227 000479 000476 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009687 -00059 000187 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004828 006172 004211 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008766 -00680 007400 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005592 -05529 003111 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005216 -04317 -03832 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003146 002199 -04153 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004742 006435 -00888 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z002227 000479 000476 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009687 -00059 000187 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005682 004608 004893 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z007870 -02032 006336 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005460 -05255 000763 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004486 -02131 -03866 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003551 002600 -03332 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004799 006313 000665 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z002288 000473 000466 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009674 -00056 000205 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z006623 003284 005783 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007033 -03317 005406 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005370 -04924 -00881 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004127 -01080 -04089 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003926 003520 -02556 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004810 006168 001847 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z002251 000465 000450 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009664 -00056 000199 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z007507 001598 006460 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006424 -04712 004500 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005250 -05150 -02298 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003842 000384 -04067 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004311 004721 -01771 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004855 006140 003071 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z002087 000473 000454 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009679 -00057 000201 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```


TUB registration: 20091101-GE55/GE55L0NA.TXT/.PS TUB material: code=rh4ta
application for evaluation and measurement of printer or monitor systems

See original or copy: <http://web.me.com/klaus.richter/GE55/GE55L0NA.TXT> / PS
Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.02; nx=1.00

TUB-test chart GE55; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```


See original or copy: <http://web.me.com/klaus.richter/GE55/GE55L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.02; nx=1.00

TUB registration: 20091101-GE55/GE55L0NA.TXT /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

TUB-test chart GE55; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

IOB material: code=rha4ta

```
%BEG GE45_22.TXT, Separation cmyn61*, cfi=0.90, D50, adapted $
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr.      pos $
%z004828 005881 003836 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008766 -00687 007177 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z005592 -05766 002765 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005216 -04580 -04192 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z003146 001786 -04593 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z004742 006138 -01266 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z002227 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009687 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%$
%z004828 005881 003836 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008766 -00687 007177 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z005592 -05766 002765 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005216 -04580 -04192 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z003146 001786 -04593 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z004742 006138 -01266 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z002227 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009687 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%$
%z004828 005881 003836 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008766 -00687 007177 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z005592 -05766 002765 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005216 -04580 -04192 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z003146 001786 -04593 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z004742 006138 -01266 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z002227 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009687 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%$
%z005682 004378 004546 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z007870 -02105 006066 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z005460 -05501 000408 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z004486 -02447 -04255 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z003551 002278 -03754 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z004799 006019 000287 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z002288 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009674 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%$
%z006623 003127 005480 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z007033 -03445 005117 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z005370 -05170 -01226 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z004127 -01413 -04476 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z003926 003172 -02950 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z004810 005883 001482 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z002251 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009664 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%$
%z007507 001504 006185 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z006424 -04882 004190 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z005250 -05403 -02647 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z003842 000033 -04464 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z004311 004403 -02152 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z004855 005860 002709 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z002087 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009679 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%$
```

See original or copy: <http://web.me.com/klaus.richter/GE55/GE55L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.02; nx=1.0

```
%BEG GE45.22.TXT, Separation cmyn61*, cfi=0.90, D50, adapted $
%100 x LAB*a      1000 x (r g b c m y 0)      %nr. pos $
001958 000005 -00043 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002434 -00444 -00370 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003267 -00390 -00403 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004293 -00279 -00254 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005277 -00134 -00208 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006421 -00143 -00158 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
007559 -00068 -00166 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008597 -00048 -00044 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009701 -00008 -00000 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
010182 -00017 -00070 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
020459 -00436 -00401 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
03294 -00389 -00411 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
04359 -00271 -00277 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
05310 -00137 -00249 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
06456 -00151 -00200 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
07614 -00068 -00172 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
08626 -00050 -00040 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
09714 -00006 -00015 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
101945 -00003 -00048 0000 0000 0000 0000 1000 1000 0000 %0990 m01 $
02403 -00444 -00388 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
03283 -00390 -00413 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
04336 -00287 -00267 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
05310 -00160 -00220 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
06415 -00159 -00154 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
07562 -00082 -00158 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
08582 -00054 -00037 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
09712 -00002 -00007 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
101995 -00012 -00040 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
02446 -00445 -00383 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
03324 -00384 -00399 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
04328 -00282 -00255 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
05305 -00142 -00215 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
06463 -00146 -00167 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
07594 -00072 -00166 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
08623 -00050 -00040 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
09709 -00003 -00004 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
10222 -00000 -00060 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
02453 -00419 -00404 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
02715 -00412 -00420 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
03060 -00394 -00402 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
03653 -00350 -00371 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
04246 -00251 -00325 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
04590 -00244 -00264 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
05188 -00217 -00236 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
05672 -00102 -00162 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
06316 -00194 -00100 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
06730 -00150 -00060 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
07348 -00077 -00156 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
07852 -00089 -00098 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
08415 -00016 -00072 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
08752 -00040 -00030 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
09644 -00013 -00013 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
10226 -00025 -00059 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
02505 -00418 -00413 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
02774 -00413 -00420 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
03154 -00384 -00395 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
03718 -00353 -00373 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
04279 -00243 -00348 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
04657 -00242 -00287 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
05228 -00208 -00272 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
05760 -00094 -00221 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
06363 -00176 -00176 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
06768 -00128 -00122 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
07398 -00070 -00181 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
07894 -00085 -00107 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
08440 -00017 -00075 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
08794 -00039 -00033 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
09649 -00012 -00015 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
102242 -00016 -00044 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
02457 -00416 -00412 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
02767 -00410 -00421 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
03123 -00384 -00392 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
03726 -00343 -00366 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
04272 -00247 -00312 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
04636 -00235 -00274 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
05205 -00202 -00241 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
05682 -00105 -00196 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
06274 -00191 -00140 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
06704 -00139 -00103 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
07338 -00075 -00167 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
07803 -00089 -00108 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```