

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE57/GE57L0NP.PDF> / <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.95, nt=

TUV registration: 20091101-GE57/GE57L0NP.PDF /.PS TUV ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

[illegible]

TUB-test chart GE57; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

input: *w setgray*
output: no change compared to input

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009123	-00015	-00613	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
008469	000062	-01176	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
007765	000048	-01683	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
007013	000154	-02174	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
006428	000097	-02650	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
005449	000059	-03095	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
005193	000112	-03601	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
004508	000055	-04108	0125	0562	1000	0875	0500	0000	0000	%0169	S08	\$
003908	000013	-04537	0000	0500	1000	1000	0500	0000	0000	%0170	S09	\$
008634	000457	000074	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
008086	000048	-00722	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
007360	000104	-01284	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
006662	000098	-01703	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
006092	000079	-02171	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
005478	000083	-02606	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
004848	000037	-03044	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
004151	000052	-03606	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
003524	000115	-04098	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
008193	000938	000049	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
007637	000557	-00035	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
007018	000077	-00697	0570	0750	0750	0250	0250	0250	0000	%0182	U03	\$
006349	000067	-01185	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
005775	000079	-01633	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
005171	000054	-02118	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
004494	000056	-02593	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
003815	000027	-03128	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
003239	000013	-03617	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
007710	001358	001570	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
007232	000875	000868	0875	0750	0625	0125	0250	0375	0000	%0190	V02	\$
006603	000482	000048	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
006033	000099	-00732	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
005460	000106	-01215	0500	0562	0625	0500	0437	0375	0000	%0193	V05	\$
004777	000053	-01682	0375	0500	0625	0625	0500	0375	0000	%0194	V06	\$
004127	000115	-02184	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
003474	000023	-02677	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
002856	000052	-03150	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
007275	001689	002548	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
006797	001233	001718	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
006162	000805	000918	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
005571	000462	000118	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
005086	000116	-00688	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
004352	000153	-01232	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$
003758	000084	-01650	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
003090	-00002	-02127	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
002467	000011	-02625	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
006885	002062	003326	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
006310	001652	002531	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
005732	001216	001200	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
005088	000882	000958	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
004576	000576	000098	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
004015	000122	-00699	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
003388	000165	-01238	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
002760	000034	-01707	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
002102	000015	-02190	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
006428	002405	004134	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
005896	002024	003422	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
005228	001673	002570	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
004645	001208	001752	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
004199	000877	000064	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
003570	000498	000095	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
003023	000111	-00757	0250	0250	0250	0750	0750	0750	0000	%0222	Y07	\$
002401	000051	-01241	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
001698	000169	-01801	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
005991	002418	004936	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
005391	002420	004152	0875	0500	0125	0125	0500	0875	0000	%0226	Z02	\$
004803	002045	003313	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
004197	001712	002519	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
003691	001333	001737	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
003130	000878	000874	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
002602	000525	000002	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
002009	000110	-00804	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
001280	000262	-01463	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$
005531	003317	005855	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
004969	002851	005078	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
004373	002492	004243	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
003758	002141	003387	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
003276	001760	002604	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
002671	001332	001732	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
002114	000975	000862	0250	0125	0000	0750	0875	0875	0000	%0240	A07	\$
001504	000569	000813	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$
000994	000223	-00862	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009077	000009	-00628	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
008314	000815	-01196	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
007513	001575	-01739	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
006707	002257	-02260	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
005833	003114	-02876	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
004978	003877	-03426	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
004156	004717	-03998	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
003335	005506	-04547	0562	0250	1000	0570	0875	0000	0000	%0493	S17	\$
002536	006290	-05039	0600	1000	0500	1000	0000	0000	0000	%0494	S18	\$
008731	003739	-000177	0937	1000	0875	0062	0000	0125	0000	%0495	T10	\$
008080	000029	-00601	0875	0875	0125	0125	0125	0000	0000	%0496	T11	\$
007270	000823	-01249	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
006446	001553	-01776	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
005549	002334	-02309	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
004734	003110	-02861	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
003934	003975	-03498	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
003132	004801	-04021	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
002358	005472	-04497	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
008353	-00875	-008107	0875	1000	0750	0125	0000	0250	0000	%0504	T19	\$
007714	-00416	-000219	0812	0875	07							

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009152	-00027	-00593	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
008414	000254	-01205	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
007625	000474	-01795	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
006768	000737	-02381	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
006088	000894	-02895	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
005383	001135	-03456	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$
004610	001349	-03996	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
003798	001557	-04596	0125	0343	1000	0875	0656	0000	0000	%0250	b08	\$
003086	001775	-05152	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
002849	000291	000285	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
008134	000034	-00722	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
007319	000295	-01329	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
006515	000578	-01855	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
005844	000707	-02317	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
005137	000935	-02893	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
004386	001142	-03442	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
003561	001325	-04040	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
002887	001510	-04582	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
008497	000435	-001294	1000	0937	0750	0000	0662	0250	0000	%0261	d01	\$
007832	000294	-000282	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
007041	000071	-00702	0750	0750	0750	0250	0437	0250	0000	%0263	d03	\$
006293	000289	-01256	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
005580	000498	-01804	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
004881	000693	-02341	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
004107	000978	-02916	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
003320	001184	-03560	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
002619	001373	-04103	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
001759	000595	-002169	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
008130	000554	-001159	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
006772	000275	-000218	0750	0718	0875	0625	0250	0281	0375	%0272	e03	\$
006047	000107	-00729	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
005378	000349	-01321	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
004570	000595	-01801	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$
003843	000728	-02389	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$
003065	000947	-02990	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
002339	001208	-03569	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
007806	000895	-003249	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
007228	000714	-002247	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
006517	000422	-001305	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
005717	000294	-000316	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
005129	000123	-00685	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
004327	000340	-01277	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
003580	000522	-01810	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
002810	000678	-02391	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
002047	000967	-02997	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
007534	001087	-004325	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
006949	000886	-003398	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
006199	000659	-002370	0750	0656	0375	0250	0343	0625	0000	%0290	g03	\$
005436	000475	-001376	0250	0562	0375	0375	0437	0625	0000	%0291	g04	\$
004789	000379	-000333	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
004047	000120	-00688	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
003308	000331	-01254	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
002552	000521	-01924	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
001775	000772	-02452	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
007265	001334	-005358	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
006651	001106	-004390	0875	0718	0500	0125	0281	0750	0000	%0298	h02	\$
005895	000392	-003392	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
005122	000730	-002344	0625	0531	0250	0375	0500	0750	0000	%0300	h04	\$
004480	000519	-001354	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
003780	000272	-000316	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
003053	000181	-00737	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
002289	000326	-01368	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
001472	000684	-02002	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
007009	001593	-006258	1000	0781	0125	0000	0218	0875	0000	%0306	i01	\$
006350	001296	-005408	0875	0687	0125	0125	0312	0875	0000	%0307	i02	\$
005619	001071	-004426	0750	0593	0125	0250	0406	0875	0000	%0308	i03	\$
004813	000925	-003275	0625	0500	0125	0375	0500	0875	0000	%0309	i04	\$
004193	000726	-002340	0500	0406	0125	0500	0593	0875	0000	%0310	i05	\$
003466	000533	-001250	0375	0312	0125	0625	0687	0875	0000	%0311	i06	\$
002777	000295	-000269	0250	0218	0125	0750	0781	0875	0000	%0312	i07	\$
002039	000190	-000869	0125	0125	0125	0875	0875	0875	0000	%0313	i08	\$
001185	000474	-01509	0000	0031	0125	1000	0968	0875	0000	%0314	i09	\$
000736	001738	-007437	1000	0750	0000	0000	0250	1000	0000	%0315	j01	\$
006048	001483	-006486	0875	0656	0000	0125	0343	1000	0000	%0316	j02	\$
005287	001315	-005424	0750	0562	0000	0250	0437	1000	0000	%0317	j03	\$
004550	001197	-004366	0625	0468	0000	0375	0531	1000	0000	%0318	j04	\$
003892	001025	-003382	0500	0375	0000	0500	0625	1000	0000	%0319	j05	\$
003193	000734	-002391	0375	0281	0000	0625	0718	1000	0000	%0320	j06	\$
002458	000544	-001363	0250	0187	0000	0750	0812	1000	0000	%0321	j07	\$
001673	000359	-000201	0125	0093	0000	0875	0906	1000	0000	%0322	j08	\$
000927	000199	-000851	0000	0000	0000	1000	1000	1000	0000	%0323	j09	\$
009097	000000	-000616	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
008408	000854	-01112	0968	0875	1000	0031	0125	0000	0000	%0568	b11	\$
007712	001703	-01566	0937	0750	1000	0062	0250	0000	0000	%0569	b12	\$
006979	002501	-02028	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$
006242	003374	-02546	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
005483	004231	-03031	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
004701	005155	-03527	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
003905	005399	-04049	0781	0250	1000	0218	0875	0000	0000	%0574	b17	\$
003122	006890	-04422	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
008652	-000536	-00003	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$
008124	000020	-00699	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$
007401	000872	-01129	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
006678	001652	-01605	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
005906	002558	-02073	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
005128	003439	-02580	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
004353	004324	-03084	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$
003608	005249	-03560	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
002862	006070	-03992	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
008156	-01173	000714	1000	0750	0187	0000	0250	0500	0000	%0585	d10	\$
007603	-00536	0000031	0781	0875	0750							

See original or copy: <http://web.me.com/klaus.richter/GE57/GE57L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.95; nt=0.18; nx=1.0

```
%BEG GE47 22.TXT, Separation olv*, cfi=0.95, D65, not adapted $
%100 x LAB*      %1000 x (r g b c m y 0)      %nr.      pos $
%Z003542 005859 003249 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008296 -00468 009429 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z004347 -05942 003739 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005196 -02696 -03641 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z001405 005074 -06137 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z003695 007632 -03812 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z000912 000207 -00843 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009089 -00017 -00620 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z003542 005859 003249 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008296 -00468 009429 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z004347 -05942 003739 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005196 -02696 -03641 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z001405 005074 -06137 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z003695 007632 -03812 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z000912 000207 -00843 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009089 -00017 -00620 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z003542 005859 003249 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008296 -00468 009429 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z004347 -05942 003739 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005196 -02696 -03641 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z001405 005074 -06137 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z003695 007632 -03812 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z000912 000207 -00843 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009089 -00017 -00620 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z004507 004618 004559 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z006947 -02228 007660 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z004688 -04515 000607 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004541 -01312 -04106 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z002061 005618 -05616 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z003607 006985 -01689 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z000871 000208 -00795 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009092 000012 -00632 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z005531 003317 005855 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006064 -03547 006306 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z004914 -03810 -01051 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z003909 000013 -04537 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z002556 006209 -05039 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z003530 006526 000095 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z000888 000212 -00816 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009088 000000 -00623 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z006736 001738 007437 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z005194 -04794 004997 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005070 -03331 -02284 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003086 001775 -05152 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003125 006890 -04422 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z003534 006265 001597 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z000918 000197 -00824 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009106 -00008 -00614 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

%BEG GE47 22.TXT, Separation olv*, cf1=0.95, D65, not adapted \$		%100 x LAB*		1000 x (r g b c m y o)		%nr. pos \$																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																							
001008	000156	-00795	0000	0000	0000	1000	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE57/GE57L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cf1=0.95; nt=

TUB registration: 20091101-GE57/GE57L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

[illegible]

TUB-test chart GE57; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-GE57/GE57L0NP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IOB material: code=rha4ta

TUB-test chart GE57; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE57/GE57L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.95; nt=0.18; nx=1.00

009131	00018	000014	1000	1000	1000	0000	0000	0000	0000	#0081	J01 \$	000974	040010	-00611	1000	1000	1000	0000	0000	0000	0000	#0405 J10 \$	000972	000008	-00002	1000	1000	1000	0000	0000	0000	0000	0000	#0729 J19 \$	
008563	-00115	-00447	0875	0968	1000	0125	0031	0000	0000	#0082	J02 \$	008236	000748	-00054	0060	0875	1000	0093	0125	0000	0000	#0406 J11 \$	008389	009925	-00189	1000	0875	0968	0000	0125	0031	0000	0000	#0730 J20 \$	
007938	-00296	-00940	0750	0937	1000	0250	0062	0000	0000	#0083	J03 \$	007372	013637	-01213	0812	0750	1000	0187	0250	0000	0000	#0407 J12 \$	007699	001813	-00357	1000	0750	0937	0000	0250	0062	0000	0000	#0731 J21 \$	
007725	-00403	-01371	0625	0906	1000	0375	0093	0000	0000	#0084	J04 \$	006438	002031	-01856	0718	0625	1000	0281	0375	0000	0000	#0408 J13 \$	007070	002603	-00417	1000	0625	0906	0000	0375	0093	0000	0000	#0732 J22 \$	
006738	-00587	-01764	0500	0875	1000	0500	0125	0000	0000	#0085	J05 \$	005488	002768	-02495	0625	0500	1000	0375	0500	0000	0000	#0409 J14 \$	006394	003431	-00534	1000	0500	0875	0000	0500	0125	0000	0000	#0733 J23 \$	
006206	-00785	-02154	0375	0843	1000	0625	0156	0000	0000	#0086	J06 \$	004617	003449	-03094	0531	0375	1000	0468	0625	0000	0000	#0410 J15 \$	005695	004349	-00613	1000	0375	0843	0000	0625	0156	0000	0000	#0734 J24 \$	
005665	-00986	-02573	0250	0812	1000	0750	0187	0000	0000	#0087	J07 \$	003772	004185	-03695	0347	0250	1000	0562	0750	0000	0000	#0411 J16 \$	004998	005261	-00791	1000	0250	0812	0000	0750	0187	0000	0000	#0735 J25 \$	
005677	-12322	-03004	0125	0871	1000	0875	0218	0000	0000	#0088	J08 \$	002867	004883	-04325	0343	0125	1000	0566	0875	0000	0000	#0412 J17 \$	004307	006120	-00904	1000	0125	0871	0000	0875	0218	0000	0000	#0736 J26 \$	
004541	-01433	-03383	0000	0750	1000	1000	0250	0000	0000	#0089	J09 \$	002061	005438	-04844	0250	0000	1000	0750	1000	0000	0000	#0413 J18 \$	003607	006842	-00948	1000	0000	0750	0000	1000	0250	0000	0000	#0737 J27 \$	
008513	000617	000539	1000	0906	0875	0000	0093	0125	0000	#0090	K01 \$	008822	-00242	000945	0968	1000	0875	0031	0000	0125	0000	#0414 K10 \$	008523	-00517	000128	0875	1000	0906	0625	0125	0000	0093	0000	#0738 K19 \$	
008070	000018	-00067	0875	0875	0875	0125	0125	0125	0000	#0091	K02 \$	008061	000024	-00063	0875	0875	0875	0125	0125	0125	0000	#0415 K11 \$	008024	000036	-00074	0875	0875	0875	0875	0125	0125	0125	0000	#0739 K20 \$	
007434	-00100	-00545	0750	0843	0875	0250	0156	0125	0000	#0092	K03 \$	007173	000698	-00631	0781	0750	0875	0218	0250	0125	0000	#0416 K12 \$	007346	000920	-00181	0875	0750	0843	0125	0250	0156	0000	0000	#0740 K21 \$	
006808	-00217	-00959	0625	0812	0875	0375	0187	0125	0000	#0093	K04 \$	006227	001353	-01228	0687	0625	0875	0312	0375	0125	0000	#0417 K13 \$	006017	001695	-00234	0875	0625	0812	0125	0375	0187	0000	0000	#0741 K22 \$	
006305	-00476	-01315	0500	0781	0875	0500	0218	0125	0000	#0094	K05 \$	005238	002938	-01836	0593	0500	0875	0406	0500	0125	0000	#0418 K14 \$	006703	002551	-00360	0875	0500	0781	0125	0500	0218	0000	0000	#0742 K23 \$	
005753	-00684	-01698	0375	0750	0875	0625	0250	0125	0000	#0095	K06 \$	004488	002737	-02452	0508	0375	0875	0500	0625	0125	0000	#0419 K15 \$	005308	003511	-00545	0875	0375	0750	0125	0625	0250	0000	0000	#0743 K24 \$	
005203	-00869	-02085	0250	0718	0875	0750	0281	0125	0000	#0096	K07 \$	003626	003459	-03866	0406	0250	0875	0593	0750	0125	0000	#0420 K16 \$	004619	004369	-00664	0875	0250	0718	0125	0750	0281	0000	0000	#0744 K25 \$	
004648	-01085	-02555	0125	0887	0875	0875	0312	0125	0000	#0097	K08 \$	002698	004159	-03762	0312	0125	0875	0687	0875	0125	0000	#0421 K17 \$	003920	005231	-00764	0875	0125	0687	0125	0875	0312	0000	0000	#0745 K26 \$	
004127	-00169	-02555	0125	0887	0875	0875	0312	0125	0000	#0098	K09 \$	001886	004159	-03762	0312	0125	0875	0687	0875	0125	0000	#0422 K18 \$	004172	006120	-00904	1000	0125	0887	0125	0875	0312	0000	0000	#0746 K27 \$	
007902	-00185	-02225	1000	0812	1000	0750	0000	0187	0250	0000	#0099	L01 \$	005205	002056	-00537	1000	0500	0625	0000	0250	0000	#0423 L1 \$	007902	-01175	000303	0500	1000	0812	0125	0000	0187	0000	0000	#0747 L19 \$	
007480	000591	000592	0875	0781	0750	0125	0128	0250	0000	#0100	L02 \$	007797	-00256	001020	0843	0875	0750	0156	0125	0250	0000	#0424 L11 \$	007404	-00548	000155	0750	0875	0781	0250	0125	0218	0000	0000	#0748 L20 \$	
006964	000027	-00036	0750	0750	0750	0250	0250	0250	0000	#0101	L03 \$	006982	000006	000015	0750	0750	0750	0250	0250	0250	0000	#0425 L12 \$	006904	000045	-00012	0750	0750	0750	0750	0250	0250	0000	0000	#0749 L21 \$	
006378	-00194	-00467	0625	0718	0750	0375	0281	0250	0000	#0102	L04 \$	006047	000644	-00573	0656	0625	0750	0343	0375	0250	0000	#0426 L13 \$	006251	000835	-00122	0750	0625	0718	0250	0375	0281	0000	0000	#0750 L22 \$	
005881	-00334	-00879	0500	0687	0750	0500	0312	0250	0000	#0103	L05 \$	005197	001354	-01236	0562	0500	0750	0347	0500	0250	0000	#0427 L14 \$	005548	001772	-00296	0750	0500	0687	0250	0500	0312	0000	0000	#0751 L23 \$	
005316	-00549	-01262	0375	0656	0750	0625	0343	0250	0000	#0104	L06 \$	004368	002092	-01854	0468	0375	0750	0531	0625	0250	0000	#0428 L15 \$	004859	002615	-00437	0750	0375	0656	0250	0625	0343	0000	0000	#0752 L24 \$	
004764	-00726	-01656	0250	0625	0750	0750	0375	0250	0000	#0105	L07 \$	003461	002776	-02507	0375	0250	0750	0625	0750	0250	0000	#0429 L16 \$	004147	003547	-00549	0750	0250	0625	0625	0250	0750	0375	0000	0000	#0753 L25 \$
004184	-00927	-02147	0125	0593	0750	0875	0406	0250	0000	#0106	L08 \$	002573	003474	-03114	0281	0125	0750	0718	0875	0250	0000	#0430 L17 \$	003476	004306	-00593	0750	0125	0593	0250	0875	0406	0000	0000	#0754 L26 \$	
003641	-01107	-02544	0000	0562	0750	1000	0437	0250	0000	#0107	L09 \$	001724	004114	-03641	0187	0000	0750	0812	1000	0250	0000	#0431 L18 \$	002850	005115	-00662	0750	0000	0562	0250	1000	0437	0000	0000	#0755 L27 \$	
007338	001722	001801	1000	0718	0625	0000	0281	0375	0000	#0108	M01 \$	008314	-00806	003001	0906	1000	0625	0093	0000	0375	0000	#0432 M10 \$	007323	-01760	000221	0625	1000	0718	0375	0000	0281	0000	0000	#0756 M19 \$	
006939	001120	001233	0875	0687	0625	0125	0312	0375	0000	#0109	M02 \$	007568	-00504	001959	0812	0875	0625	0187	0125	0375	0000	#0433 M11 \$	006796	-01113	000575	0625	0875	0687	0375	0125	0312	0000	0000	#0757 M20 \$	
006425	000553	000605	0750	0656	0625	0250	0343	0375	0000	#0110	M03 \$	006739	-00290	001049	0718	0750	0625	0281	0250	0375	0000	#0434 M12 \$	006368	-00611	000189	0625	0750	0656	0375	0250	0343	0000	0000	#0758 M21 \$	
005955	000004	-00040	0625	0625	0625	0375	0375	0375	0000	#0111	M04 \$	000952	-00023	-000013	0625	0625	0625	0375	0375	0375	0000	#0435 M13 \$	005888	-00003	-000024	0625	0625	0625	0625	0375	0375	0375	0000	0000	#0759 M22 \$
005465	-00138	-00487	0500	0593	0625	0500	0406	0375	0000	#0112	M05 \$	005138	000654	-00620	0531	0500	0625	0468	0500	0375	0000	#0436 M14 \$	005172	000876	-00199	0625	0500	0593	0375	0500	0406	0000	0000	#0760 M23 \$	
004901	-00390	-00832	0375	0562	0625	0625	0437	0375	0000	#0113	M06 \$	004248	001366	-01279	0347	0375	0625	0562	0625	0375	0000	#0437 M15 \$	004514	001760	-00304	0625	0375	0562	0375	0625	0437	0000	0000	#0761 M24 \$	
004336	-00546	-01250	0250	0531	0625	0750	0468	0375	0000	#0114	M07 \$	003336	002029	-01872	0343	0250	0625	0656	0750	0375	0000	#0438 M16 \$	003814	002637	-00399	0625	0250	0531	0375	0750	0468	0000	0000	#0762 M25 \$	
003732	-00706	-01769	0125	0500	0625	0875	0500	0375	0000	#0115	M08 \$	002460	002793	-02480	0250	0125	0625	0750	0875	0375	0000	#0439 M17 \$	003139	003472	-00558	0625	0125	0500	0375	0750	0500	0000	0000	#0763 M26 \$	
003208	-00296	-02155	0000	0468	0625	0500	1000	0371	0375	0000	#0116	M09 \$	001601	003475	-03060	0156	0000	0625	0843	1000	0375	0000	#0440 M18 \$	002483	004264	-00555	0625	0000	0468	0375	1000	0371	0000	0000	#0764 M27 \$
006782	002206	002554	1000	0625	0500	0000	0375	0500	0000	#0																									

000123	00014	000008	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$	009077	000008	-00005	1000	1000	1000	0000	0000	0000	0000	%0486	S10 \$	009065	000005	-00003	1000	1000	1000	0000	0000	0000	0000	0000	%0810	S19 \$
000849	00046	-00538	0875	0937	1000	0000	0125	0062	0000	0000	%0163	S02 \$	008314	000795	-00555	0937	0875	1000	0062	0125	0000	0000	008376	000839	-00060	1000	0875	0937	0000	0125	0062	0000	0000	0000	%0811	S20 \$
007765	000013	-01028	0750	0875	1000	0250	0125	0125	0000	0000	%0164	S03 \$	007513	001534	-01078	0875	0750	1000	0125	0250	0000	0000	007696	001680	-00108	1000	0750	0875	0000	0250	0125	0250	0000	0000	%0812	S21 \$
007013	000100	-01502	0625	0812	1000	0375	0187	0000	0000	0000	%0165	S04 \$	006707	002159	-01580	0812	0625	1000	0187	0375	0000	0000	007048	002393	-00335	1000	0625	0812	0000	0375	0187	0000	0000	0000	%0813	S22 \$
006428	000028	-01963	0500	0750	1000	0500	0250	0000	0000	0000	%0166	S05 \$	005833	003029	-02176	0750	0500	1000	0250	0500	0000	0000	006332	003280	-00343	1000	0500	0750	0000	0500	0050	0250	0000	0000	%0814	S23 \$
005449	-00024	-02395	0375	0687	1000	0625	0312	0000	0000	0000	%0167	S06 \$	004978	003770	-02706	0687	0375	1000	0312	0625	0000	0000	005654	004093	-00308	1000	0375	0687	0000	0625	0312	0000	0000	0000	%0815	S24 \$
005193	000011	-02885	0250	0625	1000	0750	0375	0000	0000	0000	%0168	S07 \$	004156	004589	-03258	0625	0250	1000	0375	0750	0000	0000	004931	004927	-00549	1000	0250	0625	0000	0750	0375	0000	0000	0000	%0816	S25 \$
004508	-00062	-03377	0125	0652	1000	0875	0437	0000	0000	0000	%0169	S08 \$	003335	005387	-03788	0562	0125	1000	0437	0875	0000	0000	00493	S17 \$	0											
003909	-00121	-03792	0000	0500	1000	1000	0500	0000	0000	0000	%0170	S09 \$	002556	006039	-04261	0500	0000	1000	0500	1000	0000	0000	00494	S18 \$	0											
008634	000445	000708	1000	0937	0875	0000	0062	0125	0000	0000	%0171	T01 \$	008751	-00388	000809	0937	1000	0875	0062	0000	0125	0000	00495	T10 \$	0											
008086	000022	-00075	0875	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$	008080	000003	-00043	0875	0875	0875	0125	0125	0125	0000	00496	T11 \$	0											
007360	000059	-00620	0750	0812	0875	0250	0187	0125	0000	0000	%0173	T03 \$	007270	0000776	-00582	0812	0750	0875	0187	0250	0125	0000	00497	T12 \$	0											
006662	000035	-01023	0625	0750	0875	0375	0250	0125	0000	0000	%0174	T04 \$	006446	001484	-01091	0750	0625	0875	0250	0375	0125	0000	00498	T13 \$	0											
006092	000081	-01476	0500	0687	0875	0500	0312	0125	0000	0000	%0175	T05 \$	005549	002242	-01602	0687	0500	0875	0312	0500	0125	0000	00499	T14 \$	0											
005478	-00009	-01897	0375	0625	0875	0625	0375	0125	0000	0000	%0176	T06 \$	004734	002997	-02135	0625	0375	0875	0375	0625	0125	0000	00500	T15 \$	0											
004848	-00072	-02320	0250	0562	0875	0750	0437	0125	0000	0000	%0177	T07 \$	003934	003842	-02753	0562	0250	0875	0437	0750	0125	0000	00501	T16 \$	0											
004151	-00075	-02866	0125	0590	0875	0875	0500	0125	0000	0000	%0178	T08 \$	003132	004647	-03257	0500	0125	0875	0500	0875	0125	0000	00502	T17 \$	0											
003524	-00028	-03343	0000	0437	0875	1000	0562	0125	0000	0000	%0179	T09 \$	002358	005289	-03715	0437	0000	0875	0562	1000	0125	0000	00503	T18 \$	0											
002634	000019	-00800	0875	0750	0875	0750	0250	0254	0000	0000	%0180	T10 \$	003535	005000	-04000	0875	0750	0875	0250	0250	0000	00504	T19 \$	0												
007637	000519	000605	0625	0750	0875	0500	0125	0111	0000	0000	%0181	U02 \$	003535	-00452	000000	0812	0750	0877	0812	0250	0000	00505	U11 \$	0												
007018	000024	-00025	0750	0750	0750	0250	0250	0250	0000	0000	%0182	U03 \$	007024	000004	000024	0750	0750	0750	0250	0250	0250	0000	00506	U12 \$	0											
006349	-00003	-00497	0625	0687	0750	0375	0312	0250	0000	0000	%0183	U04 \$	006184	000701	-00468	0687	0625	0750	0312	0375	0250	0000	00507	U13 \$	0											
005775	-00006	-00931	0500	0625	0750	0500	0375	0250	0000	0000	%0184	U05 \$	005374	001491	-01052	0625	0500	0750	0375	0500	0250	0000	00508	U14 \$	0											
005171	-00047	-01402	0375	0562	0750	0625	0437	0250	0000	0000	%0185	U06 \$	004589	002774	-01624	0562	0375	0750	0437	0625	0250	0000	00509	U15 \$	0											
004944	-00062	-01861	0250	0500	0750	0750	0500	0250	0000	0000	%0186	U07 \$	003801	003283	-02199	0500	0250	0750	0500	0750	0250	0000	00510	U16 \$	0											
003815	-00109	-02380	0125	0437	0750	0875	0562	0250	0000	0000	%0187	U08 \$	002973	003843	-02726	0437	0125	0750	0562	0875	0250	0000	00511	U17 \$	0											
003239	-00138	-02856	0000	0375	0750	1000	0625	0250	0000	0000	%0188	U09 \$	002137	004573	-03245	0375	0000	0750	0625	1000	0250	0000	00512	U18 \$	0											
007710	001322	002227	1000	0812	0625	0000	0187	0375	0000	0000	%0189	V01 \$	007959	-01354	002461	0812	1000	0625	0187	0000	0375	0000	00513	V10 \$	0											
007232	000827	-001536	0875	0750	0625	0125	0250	0375	0000	0000	%0190	V02 \$	007301	-00389	0001678	0750	0875	0625	0250	0125	0375	0000	00514	V11 \$	0											
006603	000417	-000730	0750	0687	0625	0250	0312	0375	0000	0000	%0191	V03 \$	006628	-00438	000829	0687	0750	0625	0312	0250	0375	0000	00515	V12 \$	0											
006063	000020	-00036	0625	0625	0625	0375	0375	0375	0000	0000	%0192	V04 \$	006013	-00019	-00013	0625	0625	0250	0375	0375	0375	0000	00516	V13 \$	0											
005460	000012	-00506	0500	0562	0625	0500	0437	0375	0000	0000	%0193	V05 \$	005237	000705	-00560	0562	0500	0625	0437	0500	0375	0000	00517	V14 \$	0											
004777	-00058	-00967	0375	0500	0625	0625	0500	0375	0000	0000	%0194	V06 \$	004246	001549	-01114	0500	0375	0250	0500	0625	0375	0000	00518	V15 \$	0											
004127	-00013	-01454	0250	0437	0625	0750	0562	0375	0000	0000	%0195	V07 \$	003585	002280	-01622	0437	0250	0625	0562	0750	0375	0000	00519	V16 \$	0											
003474	-00122	-01921	0125	0375	0625	0875	0562	0375	0000	0000	%0196	V08 \$	002743	003050	-02193	0375	0125	0625	0625	0875	0375	0000	00520	V17 \$	0											
002856	-00109	-02380	0000	0312	0625	1000	0687	0375	0000	0000	%0197	V09 \$	001929	003826	-02709	0312	0000	0625	0687	1000	0375	0000	00521	V18 \$	0											
007275	001642	003214	1000	0750	0500	0000	0250	0500	0000	0000	%0198	W01 \$	007132	-01804	003374	0750	1000	0500	0250	0000	0500	0000	00522	W10 \$	0											
006797	001173	002397	0875	0687	0500	0125	0312	0500	0000	0000	%0199	W02 \$	006851	-01325	002504	0687	0875	0500	0312	0125	0500	0000	00523	W11 \$	0											
006162	000729	001611	0750	0625	0500	0250	0375	0500	0000	0000	%0200	W03 \$	006255	-00959	001696	0625	0750	0500	0375	0250	0500	0000	00524	W12 \$	0											
005571	000370	000824	0625	0562	0500	0375	0437	0500	0000	0000	%0201	W04 \$	005664	-00442	000846	0562	0625	0500	0437	0375	0500	0000	00525	W13 \$	0											
005086	000013	000029	0500	0500	0500	0500	0500	0500	0000	0000	%0202	W05 \$	005069	-00015	000831	0500	0500	0500	0500	0500	0500	0000	00526	W14 \$	0											
004352	000031	-00497	0375	0437	0500	0625	0625	0500	0000	0000	%0203	W06 \$	004224	000710	-00485	0437	0375	0500	0562	0625	0500	0000	00527	W15 \$	0											
003758	-00053	-00900	0250	0375	0500	0750	0562	0500	0000	0000	%0204	W07 \$	003475	001463	-01001	0375	0250	0500	0625	0750	0500	0000	00528	W16 \$	0											
003090	-00158	-01361	0125	0312	0500	0875	0687	0500	0000	0000	%0205	W08 \$	002540	003268	-01060	0312	0125	0500	0687	0875	0500	0000	00529	W17 \$	0											
002467	-00160	-00466	0000	0250	0500	1000	0750	0500	0000	0000	%0206	W09 \$	001734	003689	-02129	0250	0000	0500	0750	1000	0500	0000	00530	W18 \$	0											
006805	000042	-00002	0000	0687	0375	0000	0125	0625	0000	0000	%0207	W10 \$	007147	-02211	000266	0687	0750	0375	0312	0000	0000	00531	W19 \$	0												
005189	000232	000125	0625	0625	0625	0375	0125	0375	0000	0000	%0208	X02 \$	005469	-00141	003361	0625	0375	0375	0125	0625	0000	0000	00532	X10 \$	0											
005732	001129	000303	0750	0562	0375	0250	0437	0625	0000	0000	%0209	X03 \$	005896	-01384	002591	0562	0750</																			

```
input: w setgray
output: -> oly* setrgbcolor
```

```
input: w setgray
output: -> oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE57/GE57L0NP.PDF> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.95; nt=0.18; nx=1.0

See original or copy: <http://web.me.com/klaus.richter/GE57/GE57L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.95; nt=0.18; nx=1.0

```
%BEG GE47 22.TXT, Separation olv*, cfi=0.95, D65, adapted $
%100 x LAB*a          %1000 x (r g b c m y 0)      %nr.   pos $
%Z003542 005724 004021 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008296 -00472 010072 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z004347 -06055 004489 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005196 -02785 -02914 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z001405 004880 -05307 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z003695 007501 -03044 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z000912 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009089 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z003542 005724 004021 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008296 -00472 010072 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z004347 -06055 004489 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005196 -02785 -02914 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z001405 004880 -05307 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z003695 007501 -03044 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z000912 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009089 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z003542 005724 004021 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008296 -00472 010072 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z004347 -06055 004489 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005196 -02785 -02914 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z001405 004880 -05307 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z003695 007501 -03044 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z000912 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009089 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z004507 004496 005282 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z006947 -02292 008336 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z004688 -04632 001327 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004541 -01433 -03383 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z002061 005438 -04844 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z003607 006842 -00948 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z000871 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009092 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z005531 003225 006562 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006064 -03626 007001 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z004914 -03918 -00329 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z003909 -00121 -03792 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z002556 006039 -04261 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z003530 006382 000849 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z000888 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009088 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z006736 001687 008112 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z005194 -04884 005711 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005070 -03424 -01566 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003086 001633 -04383 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003125 006748 -03654 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z003534 006134 002355 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z000918 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009106 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE57/GE57L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.95; nt=0.18; nx=1.0

```
%BEG GE47 22.TXT, Separation olv*, cfi=0.95, D65, adapted $
%100 x LAB*a      1000 x (r g b   c m y 0)      %nr. pos $
001008 -00043 000002 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002093 -00098 -00078 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003095 -00009 000005 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004058 000012 000036 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005154 000027 000015 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006083 000014 -00055 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
007075 000008 -00026 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008131 000012 -00105 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009115 000002 -00025 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
010100 -00031 -00018 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
020709 -00103 -00075 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
030373 -00023 000020 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
040427 000019 000022 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
05123 000050 -00010 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
060606 000023 -00061 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
070605 000010 -00026 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
08131 000014 -00097 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
09119 000004 -00024 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
1001 -00031 -00019 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
2073 -00103 -00057 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
3062 -00033 000040 0250 0250 0250 0750 0750 0750 0000 %0992 k03 $
4027 000008 000050 0375 0375 0375 0625 0625 0625 0000 %0993 k04 $
5125 000039 000010 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
6058 000020 -00055 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
7057 000008 -00027 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
8127 000019 -00103 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
9108 000004 -00025 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
9986 -00030 -00012 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
2065 -00098 -00062 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
3059 -00020 000027 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
4027 000023 000024 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
5131 000048 000000 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
6058 000030 -00065 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
7065 000022 -00040 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
8117 000023 -00116 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
9114 000004 -00029 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
9928 000002 -00064 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
11497 -00002 -00111 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
2083 000053 -00095 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
2588 -00007 -00070 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
3164 -00018 000044 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
3714 -00027 000043 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
4213 -00025 000031 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
4795 000015 000009 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
5339 -00003 -00056 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
5832 000034 -00048 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
6304 -00007 -00015 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
6881 000004 -00009 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
7435 000065 -00053 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
8012 000018 -00078 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
8579 000070 -00070 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
9096 000010 -00013 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
90916 000005 -00068 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
11487 -00009 -00105 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
2056 -00049 -00098 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
2589 -00003 -00078 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
3153 -00013 000034 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
3694 -00023 000025 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
4191 -00026 000030 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
4785 000023 000001 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
5327 000005 -00068 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
5816 000042 -00061 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
6306 000000 -00010 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
6872 000006 -00003 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
7435 000075 -00063 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
8003 000016 -00076 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
8567 000068 -00079 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
9101 000003 -00009 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
9918 000001 -00066 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
101479 000009 -00127 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
12053 -00038 -00122 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
12582 -00011 -00054 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
13150 -00006 000030 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
13693 -00007 000021 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
14177 -00019 000016 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
14773 000034 -00016 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
15325 000000 -00057 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
15817 000044 -00061 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
16301 000010 -00030 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
16869 000009 -00005 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
17422 000078 -00009 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE57; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: -> olv* setrgbcolor

TUB registration: 20091101-GE57/GE57L0NP.PDF /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

TUB registration: 20091101-GE57/GE57L0NP.PDF/.PS TUB material: code=rh4ta
application for evaluation and measurement of printer or monitor systems

[illegible]

```
input: w setgray
output: -> olv* setrabcOLOR
```

009121	-00069	-00639	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
008542	-00226	-01122	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
007904	-00480	-01643	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
007230	-00653	-02099	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
006680	-00914	-02520	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
006135	-01199	-02940	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
005578	-01507	-03392	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
004972	-01895	-03895	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
004418	-02216	-04289	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
003854	-02601	-04803	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
003058	-00021	-00734	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
002411	-00283	-01236	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
001675	-00381	-01675	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
001259	-00509	-02059	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
000594	-00997	-02471	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
000130	-01275	-02890	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
000456	-01624	-03400	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
003972	-01939	-03800	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
007935	-001348	-00630	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
007491	-000680	-00043	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
006953	-00013	-00717	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
006354	-00271	-01176	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
005846	-00476	-01611	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
005268	-00766	-02024	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
004703	-01029	-02447	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
004106	-01360	-02977	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
003545	-01668	-03414	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
007392	-001999	-001231	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
006971	-001318	-00622	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
006435	-000662	-00047	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
005942	-000009	-00737	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
005441	-001019	-01207	0500	0593	0593	0500	0406	0375	0000	00112	M05	\$
004865	-00521	-01582	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
004287	-00750	-02803	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
003666	-01035	-02583	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
003126	-01347	-03007	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
002656	-002572	-00205	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
002143	-001892	-001402	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
001591	-001288	-000712	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
000932	-000655	-00036	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
000506	-000042	-00708	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
000439	-00238	-01163	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
003830	-00463	-01593	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
003270	-00854	-02065	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
002692	-01116	-02495	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
002348	-003151	-002744	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
001874	-002519	-002092	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
001532	-001965	-001354	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
001180	-001382	-000634	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
000842	-000762	-00014	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
000366	-000040	-00090	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
000343	-00188	-01177	0250	0343	0375	0750	0625	0625	0000	00132	O07	\$
002831	-00526	-01660	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
002275	-00857	-02081	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
001774	-003796	-003779	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
001500	-003147	-002740	0875	0406	0250	0125	0593	0750	0000	00136	P02	\$
001279	-002512	-002029	0750	0375	0250	0250	0625	0750	0000	00137	P03	\$
001033	-00173	-001329	0625	0343	0250	0375	0625	0750	0000	00138	P04	\$
000922	-001350	-000686	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
000340	-000687	-00008	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
002976	-002022	-00738	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
002429	-00253	-01244	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
001812	-00508	-01701	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
001525	-004355	-004067	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
001475	-003718	-003389	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
001278	-003153	-002695	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
001033	-002548	-001981	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
000738	-002009	-001333	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
000593	-001347	-000596	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
000433	-000736	-00131	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
000191	-000097	-00855	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
000131	-00182	-01359	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
000460	-004997	-004814	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
000467	-004342	-004092	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
000365	-003760	-003357	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
000324	-003199	-002716	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
000297	-002663	-002086	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
000231	-001993	-001360	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
000185	-001468	-000850	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
000149	-000757	-00120	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
000876	-000093	-00003	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
000964	-00041	-00665	1000	1000	1000	0000	0000	0000	0000	00096	J10	\$
0008230	-000664	-01309	0800	0875	1000	0093	0125	0000	0000	00406	J11	\$
0007369	-001248	-01854	0812	0750	1000	0187	0250	0000	0000	00407	J12	\$
0006437	-001859	-02494	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
0005489	-002537	-03129	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
0004620	-003148	-03726	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
0003776	-003801	-04326	0347	0250	1000	0562	0750	0000	0000	00411	J16	\$
0002866	-004379	-05043	0250	0250	1000	0875	0875	0000	0000	00412	J17	\$
0002049	-00503	-05993	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
0008821	-00182	-00297	0968	1000	0875	0031	0000	0125	0000	00414	K10	\$
0008049	-00013	-00730	0875	0875	0125	0125	0125	0125	0000	00415	K11	\$
0007165	-000632	-01292	0781	0750	0875	0218	0250	0125	0000	00416	K12	\$
0006223	-001248	-01886	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
0005336	-001884	-02490	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
0004488	-002519	-03104	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
0003627	-003158	-03737	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
0002695	-003750	-04360	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
0001874	-004212	-04907	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
0008572	-00350	-001412	0937	1000	0750	0062	0000	0250	0000	00423	L10	\$
0												

009113	-00078	-00635	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
008450	-00076	-01202	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
007736	-00172	-01718	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
006976	-00145	-02213	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
006379	-00297	-02702	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
005788	-00435	-03163	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
005119	-00504	-03685	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
004415	-00715	-04220	0125	0602	1000	0875	0507	0000	0000	%0169	S08	\$
003796	-00911	-04632	0000	0560	1000	1000	0500	0000	0000	%0170	S09	\$
008644	000506	000090	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
008074	-00929	-00736	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
007339	-00953	-01304	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
006633	-01028	-01731	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
006053	-00232	-02209	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
005428	-01017	-02655	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
004785	-00469	-03110	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
004070	-00607	-03696	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
003425	-00700	-04216	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
002824	-001098	-000901	1000	0875	0750	0000	0125	0250	0000	%0180	U01	\$
007648	000603	000060	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
007007	000002	-00704	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
006329	-00080	-01200	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
005746	-00141	-01655	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
005130	-00258	-02153	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
004442	-00360	-02642	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
003746	-00530	-03200	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
003151	-00698	-03717	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
007760	001605	-001653	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
007262	-001029	-000922	0875	0750	0625	0125	0250	0375	0000	%0190	V02	\$
006612	-000523	-000074	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
006021	000019	-00734	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
005439	-00047	-01226	0500	0687	0625	0500	0437	0375	0000	%0193	V05	\$
004745	-00186	-01714	0375	0560	0625	0625	0375	0375	0000	%0194	V06	\$
004084	-00221	-02227	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
003416	-00439	-02731	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
002782	-00552	-03227	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
007344	-002024	-02655	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
006846	-001478	-001801	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
006190	-000956	-000973	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
005580	-000509	-000149	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
005074	-000041	-00685	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
004331	-00004	-01237	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$
003727	-00154	-01666	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
003044	-00354	-02162	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
002406	-00478	-02682	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
006969	-002453	-003455	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
006376	-001969	-002638	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
005780	-001458	-001884	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
005118	-001036	-001020	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
004587	-000625	-000138	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
004003	-000044	-00092	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
003366	-000001	-01240	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
002724	-00233	-01726	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
002052	-00381	-02229	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
006526	-002834	-003479	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
005979	-002395	-003448	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
005294	-001973	-002680	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
004993	-001526	-001842	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
004228	-001025	-001029	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
003579	-000542	-000135	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
003009	-000021	-00748	0250	0250	0250	0750	0750	0750	0000	%0222	Y07	\$
002376	-00129	-01245	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
001661	-00135	-01818	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
006103	-002618	-005095	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
005488	-003283	-004294	0875	0500	0125	0125	0625	0875	0000	%0226	Z02	\$
004884	-002381	-003439	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
004262	-001989	-002630	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
003739	-001548	-001828	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
003158	-001012	-000941	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
002610	-000557	-000045	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
001993	-00003	-00055	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
001253	-000028	-01463	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$
005559	-003770	-006024	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
005080	-003255	-005229	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
004469	-002846	-004381	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
003839	-002444	-003512	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
003342	-002016	-002714	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
002719	-001528	-001822	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
002144	-001108	-000934	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
001514	-000599	-000599	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$
000890	-000102	-000846	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
009067	-000054	-00649	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
008310	-000716	-01189	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
007516	-001434	-01704	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
006716	-002068	-02199	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
005849	-002860	-02784	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
005000	-003555	-03307	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
004186	-004313	-03847	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
003373	-005031	-04363	0562	0250	1000	0500	0875	0000	0000	%0493	S17	\$
002598	-005581	-04827	0500	1000	0500	1000	0000	0000	0000	%0494	S18	\$
008725	-003633	-000159	0937	1000	0875	0062	0000	0125	0000	%0495	T10	\$
008068	-004044	-00705	0875	0875	0125	0125	0125	0000	0000	%0496	T11	\$
007265	-000711	-01235	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
006447	-001398	-01737	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
005558	-002131	-02240	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
004749	-002845	-02766	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
003956	-003624	-03373	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
003163	-004362	-03863	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
002393	-004920	-04311	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
008349	-00787	-000996	0875	1000	0750	0125	0000	0250	0000	%0504	U10	\$
007707	-00397	-00205	0812	0875	0750	0187	0125	0250				

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009142	-00088	-00615	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$	009087	-00062	-00637	1000	1000	1000	0000	0000	0000	%0567	b10	\$	009057	-00064	-00654	1000	1000	1000	0000	0000	0000	0000	0000	%0891	b19	\$
008398	000121	-01224	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$	008407	000769	-01101	0980	0875	1000	0031	0125	0000	0000	%0568	b11	\$	008412	000822	-00373	1000	0875	0906	0000	0125	0093	0000	%0892	b20	\$
007603	000261	-01812	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$	007722	001597	-01521	0937	0750	1000	0062	0250	0000	0000	%0569	b12	\$	007725	001708	-00046	1000	0750	0812	0000	0250	0187	0000	%0893	b21	\$
006739	000436	-02397	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$	006998	002364	-01951	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$	007099	002444	-000278	1000	0625	0718	0000	0375	0281	0000	%0894	b22	\$
006051	000503	-02916	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$	006272	003195	-02434	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$	006419	003335	-000523	1000	0500	0625	0000	0500	0375	0000	%0895	b23	\$
005336	000638	-03484	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$	005524	004804	-02881	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$	005733	004154	-000903	1000	0375	0531	0000	0625	0468	0000	%0896	b24	\$
004550	000738	-04036	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$	004757	004879	-03334	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$	005063	004990	-001199	1000	0250	0437	0000	0750	0562	0000	%0897	b25	\$
003721	000773	-04660	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$	003958	005724	-03737	0781	0125	1000	0250	0875	0000	0000	%0574	b17	\$	004358	005774	-01602	1000	0125	0343	0000	0875	0556	0000	%0898	b26	\$
002984	000812	-05253	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$	003217	006429	-04122	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$	003719	006474	-01938	1000	0000	0250	0000	1000	0750	0000	%0899	b27	\$
008859	000355	-000276	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$	008640	-00551	-00031	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$	008602	-00514	-00090	0875	1000	0968	0125	0000	0031	0000	%0900	c19	\$
008122	-00044	-00737	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$	008112	-00055	-00714	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$	008062	-00036	-00722	0875	0875	0875	0125	0125	0125	0000	%0901	c20	\$
007302	000141	-01342	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$	007400	000780	-01111	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$	007408	000830	-00375	0875	0750	0781	0125	0250	0218	0000	%0902	c21	\$
006493	000346	-01863	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$	006685	001530	-01558	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$	006769	001574	-00029	0875	0625	0687	0125	0375	0312	0000	%0903	c22	\$
005814	000408	-02329	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$	005925	002407	-01989	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$	006088	002468	-000239	0875	0500	0593	0125	0500	0406	0000	%0904	c23	\$
005099	000534	-02910	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$	005158	003242	-02460	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$	005357	003314	-000549	0875	0375	0500	0125	0625	0500	0000	%0905	c24	\$
004337	000627	-03469	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$	004395	004070	-02925	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$	004692	004117	-000883	0875	0250	0406	0125	0750	0593	0000	%0906	c25	\$
003494	000652	-04090	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$	003667	004927	-03354	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$	003988	004926	-001222	0875	0125	0312	0125	0750	0687	0000	%0907	c26	\$
002798	000668	-04664	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$	002938	005657	-03734	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$	003350	005659	-001509	0875	0000	0218	0125	1000	0781	0000	%0908	c27	\$
008524	000617	-001330	1000	0937	0750	0000	0662	0250	0000	%0261	d01	\$	008142	-01135	-000675	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$	008037	-00978	-01103	0750	1000	0937	0250	0000	0662	0000	%0909	d19	\$
007841	000357	-000299	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$	007591	-00546	-000010	0781	0875	0750	0218	0125	0250	0000	%0586	d11	\$	007494	-00468	-000928	0750	0875	0843	0250	0125	0156	0000	%0910	d20	\$
007029	-00055	-00709	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$	007031	-00011	-00681	0750	0750	0750	0250	0250	0250	0000	%0587	d12	\$	006976	-00015	-00676	0750	0750	0750	0250	0250	0250	0000	%0911	d21	\$
006276	001043	-01262	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$	006299	000797	-01104	0718	0625	0750	0281	0375	0250	0000	%0588	d13	\$	006325	-000808	-00361	0750	0625	0656	0250	0375	0343	0000	%0912	d22	\$
005556	000273	-01811	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$	005533	-001619	-01574	0687	0500	0750	0312	0500	0250	0000	%0589	d14	\$	005641	-001632	-00041	0750	0500	0562	0250	0500	0437	0000	%0913	d23	\$
004849	000379	-02352	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$	004826	002488	-02063	0656	0375	0750	0343	0625	0250	0000	%0590	d15	\$	004947	002528	-000280	0750	0375	0468	0250	0625	0531	0000	%0914	d24	\$
004067	000558	-02933	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$	004110	003317	-02549	0625	0250	0750	0375	0750	0250	0000	%0591	d16	\$	004281	003329	-000554	0750	0250	0375	0250	0750	0625	0000	%0915	d25	\$
003263	000609	-03595	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$	003369	004151	-02963	0593	0125	0750	0406	0875	0250	0000	%0592	d17	\$	003603	004132	-000884	0750	0125	0281	0250	0875	0718	0000	%0916	d26	\$
002542	000633	-04166	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$	002641	004911	-03333	0562	0000	0750	0437	1000	0250	0000	%0593	d18	\$	002972	004875	-001229	0750	0000	0187	0250	1000	0812	0000	%0917	d27	\$
007181	000930	-002227	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$	007612	-01646	-001311	0718	1000	0625	0281	0000	0375	0000	%0594	e10	\$	007467	-01439	-01352	0625	1000	0906	0375	0000	0093	0000	%0918	e19	\$
007527	000723	-001202	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$	007028	-01037	-000617	0687	0875	0625	0312	0125	0375	0000	%0595	e11	\$	006931	-00088	-01165	0625	0875	0812	0375	0125	0187	0000	%0919	e20	\$
006780	000327	-000238	0750	0718	0625	0250	0281	0375	0000	%0272	e03	\$	006543	-00567	-000005	0656	0750	0625	0343	0250	0375	0000	%0596	e12	\$	006446	-00492	-000865	0625	0750	0718	0375	0250	0281	0000	%0920	e21	\$
006035	000027	-00730	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$	006022	-00010	-00706	0625	0625	0625	0375	0375	0375	0000	%0597	e13	\$	005950	-00016	-00706	0625	0625	0625	0375	0375	0375	0000	%0921	e22	\$
005361	000192	-01322	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$	005203	000800	-01178	0593	0500	0625	0406	0500	0375	0000	%0598	e14	\$	005258	000867	-00436	0625	0500	0531	0375	0600	0468	0000	%0922	e23	\$
004546	000353	-01893	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$	004561	001630	-01642	0562	0375	0625	0437	0625	0375	0000	%0599	e15	\$	004506	001739	-00045	0625	0375	0437	0375	0625	0562	0000	%0923	e24	\$
003809	000393	-02389	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$	003832	002563	-02091	0531	0250	0625	0468	0750	0375	0000	%0600	e16	\$	003926	002559	-000240	0625	0250	0343	0375	0750	0656	0000	%0924	e25	\$
003018	000479	-03813	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$	003078	003440	-02503	0500	0125	0625	0500	0875	0375	000																

See original or copy: <http://web.me.com/klaus.richter/GE57/GE57L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.95; nt=0.18; nx=1.0

```
%BEG GE47 22.TXT, Separation olv*, cfi=0.95, D50, not adapted $
%100 x LAB*      %1000 x (r g b c m y 0)      %nr.      pos $
%Z003727 006135 003607 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008372 000040 009409 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z004287 -05826 003532 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005061 -03573 -03865 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z001317 004033 -06164 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z003831 007315 -03434 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z000898 000089 -00828 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009079 -00081 -00642 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z003727 006135 003607 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008372 000040 009409 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z004287 -05826 003532 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005061 -03573 -03865 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z001317 004033 -06164 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z003831 007315 -03434 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z000898 000089 -00828 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009079 -00081 -00642 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z003727 006135 003607 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008372 000040 009409 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z004287 -05826 003532 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005061 -03573 -03865 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z001317 004033 -06164 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z003831 007315 -03434 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z000898 000089 -00828 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009079 -00081 -00642 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z004660 004997 004814 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z006975 -01825 007568 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z004613 -04675 000449 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004418 -02216 -04289 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z002049 004803 -05503 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z003771 006938 -01293 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z000859 000089 -00779 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009082 -00051 -00653 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z005659 003770 006024 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z006060 -03229 006170 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z004821 -04212 -01220 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z003796 -00911 -04683 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z002598 005581 -04827 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z003708 006638 000492 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z000875 000099 -00801 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009078 -00063 -00644 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z006840 002239 007516 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z005160 -04573 004823 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z004958 -03953 -02475 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z002984 000812 -05253 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003217 006429 -04122 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z003719 006474 001988 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z000905 000081 -00809 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009095 -00071 -00636 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE57/GE57L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.95; nt=0.18; nx=1.0

```
%BEG GE47 22.TXT, Separation olv*, cfi=0.95, D50, not adapted S
%100 x LAB*      1000 x (r g b c m y o)      %nr. pos $
000994 000045 -00781 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002076 -00040 -00840 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003082 000048 -00727 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004047 000055 -00673 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005143 000043 -00669 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006071 -00002 -00723 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
007064 -00027 -00671 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008119 -00057 -00731 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009105 -00078 -00631 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
009996 000055 -00802 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002063 -00044 -00838 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003060 000036 -00713 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004016 000061 -00687 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005112 000064 -00696 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006054 000006 -00729 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
007054 -00025 -00672 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
008119 -00054 -00723 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009108 -00077 -00630 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
009987 000054 -00804 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002057 -00040 -00819 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003050 000029 -00693 0250 0250 0250 0750 0750 0750 0000 %0992 k03 $
004016 000053 -00659 0375 0375 0375 0625 0625 0625 0000 %0993 k04 $
005114 000055 -00675 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006046 000004 -00723 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
007045 -00026 -00673 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
008115 -00049 -00728 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009098 -00077 -00631 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
009972 000057 -00797 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002049 -00036 -00824 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003046 000041 -00705 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004016 000065 -00685 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005121 000064 -00695 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006046 000013 -00733 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
007054 -00014 -00685 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008105 -00047 -00742 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009104 -00077 -00635 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
009913 000082 -00850 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
001482 000063 -00883 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002067 000004 -00856 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
002574 000048 -00816 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
003152 000043 -00686 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
003701 000021 -00675 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
004201 000010 -00676 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
004784 000037 -00684 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
005326 -00004 -00740 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
005820 000025 -00719 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
006292 -00024 -00677 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
006869 -00024 -00659 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
007425 000020 -00689 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
008000 -00044 -00705 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
008569 -00001 -00684 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009086 -00068 -00618 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
009092 000085 -00855 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
001472 000058 -00878 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
002040 000008 -00859 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
002574 000051 -00824 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
003140 000047 -00696 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
003682 000034 -00694 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
004179 000010 -00678 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
004774 000044 -00692 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
005314 000003 -00752 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
005805 000032 -00733 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
006294 -00016 -00672 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
006861 -00021 -00653 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
007424 000029 -00699 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
007991 -00046 -00703 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
008557 -00004 -00693 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009091 -00075 -00615 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
009903 000080 -00852 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
001464 000073 -00900 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002037 000016 -00883 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
002568 000047 -00800 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
003138 000053 -00700 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
003680 000040 -00697 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
004164 000015 -00692 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
004762 000054 -00710 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
005313 000000 -00741 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
005805 000034 -00732 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
006290 -00007 -00692 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
006857 -00018 -00654 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
007411 000032 -00705 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE57; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: -> olv* setrgbcolor

TUB registration: 20091101-GE57/GE57L0NP.PDF /.PS
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE57/GE57L0NP.PDF> / <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.95, nt=

TUV registration: 20091101-GE57/GE57L0NP.PDF /.PS TUV ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

XREG GE47_2D.TXT, Separation objlv*, cfi=0.95, D50, adapted \$																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																											
*100 x Lab*A*	1000 x r	c m y o	%nr.	pos \$																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																							

TUB-test chart GE57; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-GE57/GE57LONP.PDF /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

IOB material: code=rha4ta

TUB-test chart GE57; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE57/GE57L0NP.PDF> / .PS
 Technical information: <http://www.ps.ban.de> V 2.1, io=1,1, Cx=0; cfl=0.95; nt=0.18; nx=1.00

[illegible]

[illegible]

See original or copy: <http://web.me.com/klaus.richter/GE57/GE57L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.95; nt=0.18; nx=1.0

```
%BEG GE47 22.TXT, Separation olv*, cfi=0.95, D50, adapted $
%100 x LAB*a          %1000 x (r g b c m y 0)          %nr. pos $
%z003727 006105 004371 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008372 000107 010068 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z004287 -05844 004283 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005061 -03575 -03131 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z001317 003953 -05345 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z003831 007287 -02672 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z000898 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z009079 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%z003727 006105 004371 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008372 000107 010068 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z004287 -05844 004283 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005061 -03575 -03131 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z001317 003953 -05345 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z003831 007287 -02672 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z000898 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z009079 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%z003727 006105 004371 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008372 000107 010068 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z004287 -05844 004283 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005061 -03575 -03131 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z001317 003953 -05345 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z003831 007287 -02672 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M00 5 $
%z000898 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z009079 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%z004660 004968 005535 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z006975 -01812 008254 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z004613 -04705 001171 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z004418 -02250 -03564 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z002049 004726 -04742 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z003771 006893 -00558 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z000859 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z009082 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%z005659 003766 006734 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z006060 -03225 006872 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z004821 -04233 -00494 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z003796 -00952 -03937 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z002598 005516 -04058 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z003708 006595 001239 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z000875 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z009078 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%z006840 002269 008200 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z005160 -04575 005542 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z004958 -03959 -01751 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z002984 000769 -04488 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z003217 006391 -03361 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z003719 006445 002738 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z000905 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z009095 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE57/GE57L0NP.PDF> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.95; nt=0.18; nx=1.0

```
%BEG GE47 22.TXT, Separation olv*, cfi=0.95, D50, adapted $
%100 x LAB*a      1000 x (r g b   c m y 0)      %nrr. pos $
000994 -00044 000001 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002076 -00107 -00080 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003082 000001 000009 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004047 000028 000042 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005143 000039 000022 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006071 000012 -00051 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
007064 000009 -00021 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008119 000008 -00104 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009105 000006 -00026 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
009996 -00035 -00019 0000 0000 0000 0000 1000 1000 0000 %0981 l01 $
02063 -00112 -00078 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
03060 -00011 000024 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
04016 000034 000028 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
05112 000059 -00003 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
06054 000021 -00057 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
07054 000010 -00022 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
08119 000003 -00096 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
09108 000001 -00025 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
09987 -00036 -00021 0000 0000 0000 0000 1000 1000 0000 %0990 m01 $
02057 -00109 -00059 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
03050 -00018 000044 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
04016 000026 000057 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
05114 000050 000017 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
06046 000019 -00051 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
07045 000008 -00022 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
08115 000008 -00101 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
09098 000001 -00026 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
09972 -00033 -00013 0000 0000 0000 0000 1000 1000 0000 %0999 n01 $
02049 -00105 -00064 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
03046 -00006 000031 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
04016 000038 000031 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
05121 000059 000006 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
06046 000028 -00060 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
07054 000021 00035 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
08105 000010 -00115 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
09104 000001 -00029 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
09913 -00009 -00065 0000 0000 0000 0000 1000 1000 0000 %1008 k10 $
091482 -00017 -00111 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
02067 -00063 -00096 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
02574 -00008 -00068 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
03152 -00002 000049 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
03701 -00012 000048 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
04201 -00012 000036 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
04784 000026 000015 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
05326 -00004 -00052 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
05820 000035 -00042 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
06292 -00004 -00010 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
06869 000007 -00004 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
07425 000064 -00047 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
08000 000010 -00076 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
08569 000065 -00067 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
09086 000009 -00012 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
09902 -00007 -00070 0000 0000 0000 0000 1000 1000 0000 %1024 l10 $
091472 -00022 -00105 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
02040 -00060 -00099 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
02574 -00006 -00076 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
03140 000001 000039 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
03682 000003 000029 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
04179 000013 000034 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
04774 000033 000008 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
05314 000003 -00064 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
05805 000042 -00056 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
06294 000003 -00005 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
06861 000010 000001 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
07424 000073 -00057 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
07991 000008 -00074 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
08557 000062 -00076 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
09091 000002 -00009 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
09903 -00011 -00067 0000 0000 0000 0000 1000 1000 0000 %1040 m10 $
091464 -00007 -00127 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
02037 -00052 -00122 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
02568 -00009 -00052 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
03138 000008 000035 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
03680 000006 000026 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
04164 -00008 000021 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
04762 000042 -00010 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
05313 -00001 -00053 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
05805 000044 -00055 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
06290 000012 -00025 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
06857 000013 000000 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
07411 000075 -00063 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE57; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: -> olv* setrgbcolor

TUB registration: 20091101-GE57/GE57L0NP.PDF /.PS
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta