

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE58/GE58L0NA.TXT> / .PSS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1.1, Cx=0, cfi=1.00, m=c=

TUB registration: 20091101-GE58/GE58L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

[illegible]

TUB-test chart GE58; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

input: *w setgray*
output: no change compared to input

```
input: w setgray
output: ->olv* setrgbcolor
```

008901	000055	-006666	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
008269	000080	-01163	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
007556	000113	-016560	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
006847	000186	-02139	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
006295	000120	-025858	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
005753	000072	-02995	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
005149	000111	-03439	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
004484	000038	-03890	0125	0562	1000	0875	0507	0000	0000	%0169	S08	\$
003942	000064	-04336	0000	0500	1000	1000	0507	0000	0000	%0170	S09	\$
003439	000035	-04845	0000	0500	1000	0500	0500	0000	0000	%0171	S10	\$
008439	000456	000035	1000	0937	0875	0000	0062	0125	0000	%0172	T01	\$
007899	000060	-00720	0875	0875	0875	0125	0125	0125	0000	%0173	T02	\$
007199	000120	-01210	0750	0812	0875	0250	0187	0125	0000	%0174	T03	\$
006536	000085	-01645	0625	0750	0875	0375	0250	0125	0000	%0175	T04	\$
006002	000058	-02039	0500	0687	0875	0500	0312	0125	0000	%0176	T05	\$
005417	000065	-02505	0375	0625	0875	0625	0375	0125	0000	%0177	T06	\$
004810	000097	-02949	0250	0562	0875	0750	0437	0125	0000	%0178	T07	\$
004159	000010	-03412	0125	0500	0875	0875	0500	0125	0000	%0179	T08	\$
003580	000105	-03895	0000	0437	0875	1000	0562	0125	0000	%0180	T09	\$
008020	000835	000873	1000	0875	0750	0000	0125	0250	0000	%0181	U01	\$
007460	000454	000045	0875	0812	0750	0125	0187	0250	0000	%0182	U02	\$
006859	000072	-00670	0750	0750	0750	0250	0250	0250	0000	%0183	U03	\$
006217	000058	-01170	0625	0687	0750	0375	0312	0250	0000	%0184	U04	\$
005670	000085	-01595	0500	0625	0750	0500	0375	0250	0000	%0185	U05	\$
005069	000070	-02064	0375	0562	0750	0625	0437	0250	0000	%0186	U06	\$
004454	000099	-02498	0250	0500	0750	0750	0500	0250	0000	%0187	U08	\$
003810	000074	-03029	0125	0437	0750	0875	0562	0250	0000	%0188	U09	\$
003280	000086	-03466	0000	0375	0750	1000	0625	0250	0000	%0189	V01	\$
007570	001283	001507	1000	0812	0625	0000	0187	0375	0000	%0190	V02	\$
007066	000773	000771	0875	0750	0625	0125	0250	0375	0000	%0191	V03	\$
006445	000423	000034	0750	0687	0625	0250	0312	0375	0000	%0192	V04	\$
005890	000085	-00710	0625	0625	0625	0375	0375	0375	0000	%0193	V05	\$
005357	000131	-01216	0500	0812	0625	0500	0437	0375	0000	%0194	V06	\$
004733	000094	-01635	0375	0562	0625	0625	0562	0375	0000	%0195	V07	\$
004114	000148	-02127	0250	0437	0625	0750	0562	0375	0000	%0196	V08	\$
003468	000052	-02575	0125	0375	0625	0875	0625	0375	0000	%0197	V09	\$
002905	000129	-03041	0000	0312	0625	1000	0687	0375	0000	%0198	W01	\$
007142	001665	002331	1000	0750	0500	0000	0250	0500	0000	%0199	W02	\$
006636	001158	001652	0875	0687	0500	0125	0312	0500	0000	%0200	W03	\$
006023	000791	000804	0750	0625	0500	0250	0375	0500	0000	%0201	W04	\$
005433	000460	000051	0625	0562	0500	0375	0437	0500	0000	%0202	W05	\$
005006	000110	-00695	0500	0500	0500	0500	0500	0500	0000	%0203	W06	\$
004320	000122	-01195	0375	0437	0500	0625	0562	0500	0000	%0204	W07	\$
003718	000119	-01642	0250	0375	0500	0750	0625	0500	0000	%0205	W08	\$
003084	000081	-02102	0125	0312	0500	0875	0687	0500	0000	%0206	W09	\$
002543	000093	-02513	0000	0250	0500	1000	0750	0500	0000	%0207	X01	\$
006769	001955	003235	1000	0687	0375	0000	0312	0625	0000	%0208	X02	\$
006184	001551	002412	0875	0625	0375	0125	0375	0625	0000	%0209	X03	\$
005611	001189	001683	0750	0562	0375	0250	0437	0625	0000	%0210	X04	\$
005006	000885	000848	0625	0500	0375	0375	0500	0625	0000	%0211	X05	\$
004536	000527	-00610	0500	0437	0375	0500	0562	0625	0000	%0212	X06	\$
003981	000108	-00691	0375	0375	0375	0625	0625	0625	0000	%0213	X07	\$
003379	000127	-01195	0250	0312	0375	0750	0687	0625	0000	%0214	X08	\$
002778	000056	-01655	0125	0250	0375	0875	0750	0625	0000	%0215	X09	\$
002195	000109	-02145	0000	0187	0375	1000	0812	0625	0000	%0216	Y01	\$
006338	002351	003934	1000	0625	0250	0000	0375	0750	0000	%0217	Y02	\$
005804	001861	003220	0875	0562	0250	0125	0437	0750	0000	%0218	Y03	\$
005168	001577	002429	0750	0500	0250	0250	0500	0750	0000	%0219	Y04	\$
004596	001254	002959	0625	0437	0250	0375	0500	0750	0000	%0220	Y05	\$
004133	000838	000081	0500	0375	0250	0500	0625	0750	0000	%0221	Y06	\$
003558	000467	000059	0375	0312	0250	0625	0687	0750	0000	%0222	Y07	\$
003062	000132	-00726	0250	0250	0250	0750	0750	0750	0000	%0223	Y08	\$
002448	000063	-01235	0125	0187	0250	0875	0812	0750	0000	%0224	Y09	\$
001837	000159	-01698	0000	0125	0250	1000	0875	0750	0000	%0225	Z01	\$
005936	002716	004761	1000	0562	0125	0000	0437	0875	0000	%0226	Z02	\$
005333	002320	003893	0875	0500	0125	0125	0625	0875	0000	%0227	Z03	\$
004766	001968	003137	0750	0437	0125	0250	0562	0875	0000	%0228	Z04	\$
004196	001604	002331	0625	0375	0125	0375	0625	0875	0000	%0229	Z05	\$
003708	001271	001586	0500	0312	0125	0500	0687	0875	0000	%0230	Z06	\$
003169	000803	000808	0375	0250	0125	0625	0750	0875	0000	%0231	Z07	\$
002652	000513	000002	0250	0187	0125	0750	0812	0875	0000	%0232	Z08	\$
002109	000146	-00868	0125	0125	0125	0875	0875	0875	0000	%0233	Z09	\$
001444	000224	-01377	0000	0062	0125	1000	0937	0875	0000	%0234	A01	\$
005525	003141	005625	1000	0500	0000	0000	0500	1000	0000	%0235	A02	\$
004927	002697	004812	0875	0437	0000	0125	0562	1000	0000	%0236	A03	\$
004358	002338	003949	0750	0375	0000	0250	0625	1000	0000	%0237	A04	\$
003793	001990	003178	0625	0312	0000	0375	0687	1000	0000	%0238	A05	\$
003309	001665	002409	0500	0250	0000	0500	0750	1000	0000	%0239	A06	\$
002744	001218	001611	0375	0187	0000	0625	0812	1000	0000	%0240	A07	\$
002220	000902	000800	0250	0125	0000	0750	0875	1000	0000	%0241	A08	\$
001635	000524	-00995	0125	0062	0000	0875	0937	1000	0000	%0242	A09	\$
001074	000227	-00870	0000	0000	0000	1000	1000	1000	0000	%0243	A10	\$
008859	000051	-00665	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
008134	000774	-01174	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
007343	001477	-01657	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
006574	002192	-02222	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
005741	002988	-02781	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
004933	003746	-03329	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
004132	004521	-03866	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
003358	005251	-04534	0562	0250	1000	0875	0500	0000	0000	%0493	S17	\$
002514	005990	-04845	0000	1000	0500	0500	1000	0000	0000	%0494	S18	\$
008506	-00333	000100	0937	1000	0875	0062	0100	0125	0000	%0495	T10	\$
007907	000039	-00695	0875	0875	0875	0125	0125	0125	0000	%0496	T11	\$
007108	000777	-01202	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
006290	001475	-01686	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
005479	002245	-02241	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
004724	003014	-02806	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
003951	003792	-03349	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
003199	004505	-03824	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
002409	005283	-04345	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
008128	-00828	000946	0875	1000	0750							

See original or copy: <http://web.me.com/klaus.richter/GE58/GE58L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE48.22.TXT, Separation olv*, cfi=0.90, D65, not adapted $
%100 x LAB*      %#1000 x (r g b c m y 0)      %nr.      pos $
%Z003572 005626 003030 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008099 -00374 009023 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z004306 -05659 003503 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005141 -02541 -03507 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z001543 004918 -05889 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z003719 007303 -03655 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001023 000251 -00879 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z008858 000045 -00670 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W1 7 $
%S
%Z003572 005626 003030 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008099 -00374 009023 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z004306 -05659 003503 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005141 -02541 -03507 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z001543 004918 -05889 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z003719 007303 -03655 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001023 000251 -00879 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z008858 000045 -00670 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W2 7 $
%S
%Z003572 005626 003030 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008099 -00374 009023 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z004306 -05659 003503 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005141 -02541 -03507 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z001543 004918 -05889 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z003719 007303 -03655 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001023 000251 -00879 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z008858 000045 -00670 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W001 7 $
%S
%Z004525 004420 004300 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z006770 -02098 007113 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z004665 -04239 000461 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004483 -01191 -03945 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z002066 005418 -05409 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z003636 006788 -01663 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001030 000261 -00869 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z008851 000070 -00683 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %W251 7 $
%S
%Z005525 003141 005625 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z005981 -03395 006011 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z004858 -03589 -01007 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z003942 000064 -04336 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z002614 005990 -04848 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z003585 006377 -00038 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001051 000233 -00852 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z008867 000054 -00665 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %W501 7 $
%S
%Z006657 001652 007075 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z005162 -04542 004676 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005033 -03108 -02182 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003154 001733 -04885 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003174 006636 -04282 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z003591 006026 001501 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001135 000205 -00833 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z008903 000034 -00654 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %W751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE58/GE58L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE48.22.TXT, Separation olv*, cfi=0.90, D65, not adapted S
%100 x LAB*      1000 x (r g b      c m y 0)      %nr. pos $
001202 000164 -00801 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002194 000089 -00797 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003173 000123 -00636 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004065 000117 -00671 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005102 000090 -00641 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
005990 000068 -00676 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
006951 000022 -00608 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
007957 000018 -00696 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
008913 000033 -00647 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
009199 000167 -00831 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002198 000082 -00790 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003163 000128 -00640 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004045 000127 -00677 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005097 000090 -00636 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
005976 000062 -00665 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
006941 000028 -00620 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
007957 000013 -00694 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
008912 000030 -00655 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
009199 000166 -00814 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002204 000084 -00796 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003178 000115 -00636 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004049 000118 -00674 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
005115 000097 -00644 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
005979 000067 -00678 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
006945 000021 -00614 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
007955 000007 -00693 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
008907 000029 -00655 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
009121 000155 -00797 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002201 000088 -00807 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003170 000094 -00608 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004059 000103 -00665 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005117 000024 -00655 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
005982 000054 -00679 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
006962 000009 -00682 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
007963 000020 -00693 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
008906 000020 -00649 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
009105 000219 -00896 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
001667 000201 -00891 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002194 000123 -00847 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
002689 000102 -00782 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
003205 000097 -00676 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
003754 000048 -00647 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
004216 000090 -00665 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
004782 000092 -00721 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
005302 000060 -00691 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
005735 000074 -00734 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
006215 000070 -00644 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
006736 000033 -00639 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
007286 000058 -00629 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
007838 000023 -00679 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
008343 000096 -00691 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
008881 000050 -00658 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
009102 000208 -00876 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
001664 000199 -00886 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
002193 000123 -00850 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
002681 000103 -00784 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
003194 000106 -00687 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
003746 000033 -00654 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
004205 000095 -00664 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
004785 000081 -00696 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
005308 000055 -00680 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
005726 000070 -00735 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
006220 000069 -00643 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
006752 000029 -00637 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
007282 000058 -00627 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
007827 000022 -00679 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
008357 000080 -00681 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
008883 000049 -00659 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
009128 000201 -00868 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
001675 000194 -00902 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002213 000112 -00834 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
002693 000091 -00764 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
003203 000097 -00681 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
003754 000061 -00670 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
004229 000093 -00667 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
004796 000095 -00722 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
005319 000051 -00679 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
005735 000065 -00736 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
006236 000061 -00634 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
006752 000021 -00629 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
007297 000047 -00624 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart GE58; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w *setgray*
output: -> *olv* setrgbcolor*

TUB registration: 20091101-GE58/GE58L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

See original or copy: <http://web.me.com/klaus.richter/GE58/GE58L0NA.TXT> / <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0, cfl=1.00; nt=

TUB registration: 20091101-GE58/GE58L0NA.TXT /.PS TUB material application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

[illegible]

TUB-test chart GE58; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```


TUB registration: 20091101-GE58/GE58L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

TUB-test chart GE58; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE58/GE58L0NA.TXT> / .PSS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1.1, Cx=0, cfi=1.00, m=c=

See original or copy: <http://web.me.com/klaus.richter/GE58/GE58L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE48.22.TXT, Separation olv*, cfi=0.90, D65, adapted $
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr. pos $
%Z003572 005442 003841 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008099 -00439 009713 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z004306 -05824 004295 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005141 -02684 -02737 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z001543 004680 -05023 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z003719 007123 -02847 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001023 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z008858 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z003572 005442 003841 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008099 -00439 009713 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z004306 -05824 004295 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005141 -02684 -02737 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z001543 004680 -05023 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z003719 007123 -02847 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001023 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z008858 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z003572 005442 003841 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008099 -00439 009713 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z004306 -05824 004295 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005141 -02684 -02737 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z001543 004680 -05023 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z003719 007123 -02847 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001023 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z008858 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z004525 004244 005086 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z006770 -02219 007846 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z004665 -04412 001245 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004483 -01368 -03157 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z002066 005182 -04564 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z003636 006590 -00856 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001030 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z008851 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z005525 003010 006370 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z005981 -03515 006745 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z004858 -03735 -00245 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z003942 -00102 -03553 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z002614 005792 -04034 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z003585 006202 000753 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001051 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z008867 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z006657 001568 007781 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z005162 -04658 005417 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005033 -03228 -01438 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003154 001572 -04098 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003174 006475 -03495 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z003591 005875 002278 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001135 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z008903 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE58/GE58L0NA.TXT> / PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

TUB registration: 20091101-GE58/GE58L0NA.TXT / PS TUB material: code=rha4ta
- application for evaluation and measurement of printer or monitor systems

KBEG	GE48.22.TXT	Separation	olv*	cf=1.0	m.90	D65	adapted	%nr	pos
%	x LAB*	1000	x (r	g b	c y	m)			
001282	-00046	000034	0000	0000	0000	1000	1000	0000	%0972 k01
001294	-00100	000013	0125	0125	0125	0875	0875	0875	%0973 k02
001317	-00044	000150	0250	0250	0250	0750	0750	0875	%0974 k03
004065	-00031	000092	0375	0375	0375	0625	0625	0625	%0975 k04
005182	-00035	000096	0500	0500	0500	0500	0500	0500	%0976 k05
005990	-00037	000038	0625	0625	0625	0375	0375	0375	%0977 k06
006951	-00063	000081	0750	0750	0750	0250	0250	0250	%0978 k07
007957	-00045	-00031	0875	0875	0875	0125	0125	0125	%0979 k08
008913	-00009	-00007	1000	1000	1000	0000	0000	0000	%0980 k09
001199	-00044	000005	0000	0000	0000	1000	1000	1000	%0981 l01
001298	-00107	000021	0125	0125	0125	0875	0875	0875	%0982 l02
003163	-00039	000145	0250	0250	0250	0750	0750	0750	%0983 l03
004045	-00021	000087	0375	0375	0375	0625	0625	0625	%0984 l04
005097	-00035	000101	0500	0500	0500	0500	0500	0500	%0985 l05
005976	-00044	000049	0625	0625	0625	0375	0375	0375	%0986 l06
006941	-00057	000070	0750	0750	0750	0250	0250	0250	%0987 l07
007957	-00049	-00029	0875	0875	0875	0125	0125	0125	%0988 l08
008912	-00112	-00014	1000	1000	1000	0000	0000	0000	%0989 l09
001195	-00044	000022	0000	0000	0000	1000	1000	1000	%0990 m01
002026	-00104	000015	0125	0125	0125	0875	0875	0875	%0991 m02
003163	-00039	000145	0250	0250	0250	0750	0750	0750	%0992 m03
004049	-00030	000089	0375	0375	0375	0625	0625	0625	%0993 m04
005115	-00028	000092	0500	0500	0500	0500	0500	0500	%0994 m05
005979	-00039	000036	0625	0625	0625	0375	0375	0375	%0995 m06
006945	-00064	000075	0750	0750	0750	0250	0250	0250	%0996 m07
007955	-00055	-00029	0875	0875	0875	0125	0125	0125	%0997 m08
008907	-00113	-00014	1000	1000	1000	0000	0000	0000	%0998 m09
001215	-00055	000039	0000	0000	0000	1000	1000	1000	%0999 m10
002021	-00100	000003	0125	0125	0125	0875	0875	0875	%1000 n02
003170	-00073	000178	0250	0250	0250	0750	0750	0750	%1001 n03
004059	-00044	000038	0375	0375	0375	0625	0625	0625	%1002 n04
005117	-00031	000081	0500	0500	0500	0500	0500	0500	%1003 n05
005982	-00051	000035	0625	0625	0625	0375	0375	0375	%1004 n06
006962	-00076	000087	0750	0750	0750	0250	0250	0250	%1005 n07
007963	-00063	-00028	0875	0875	0875	0125	0125	0125	%1006 n08
008906	-00022	-00008	1000	1000	1000	0000	0000	0000	%1007 n09
001105	000006	-00057	0000	0000	0000	1000	1000	1000	%1008 k10
001667	000000	-00066	0066	0066	0066	0933	0933	0933	%1009 k11
002194	-00066	-0003							

0087838	-00053	-00018	0866	0866	0866	0863	0133	0133	0133	0000	%1053	m23	%
0087602	0000007	-00006	0933	0933	0933	0166	0666	0666	0666	0000	%1054	m24	%
0088886	-00004	-00015	1000	1000	1000	0000	0000	0000	0000	0000	%1055	m25	%
0011115	-00015	-00036	0000	0000	0000	0000	1000	1000	1000	0000	%1056	m10	%
001686	-00021	-00051	0666	0666	0666	0933	0933	0933	0933	0000	%1057	n11	%
0022210	-00070	-00037	0133	0133	0133	0866	0866	0866	0000	0000	%1058	n12	%
002698	-00090	0000333	0200	0200	0200	0800	0800	0800	0800	0000	%1059	n13	%
0032129	-00075	000109	0266	0266	0266	0733	0733	0733	0000	0000	%1060	n14	%
003760	-00092	0000933	0333	0333	0333	0666	0666	0666	0000	0000	%1061	n15	%
004235	-00059	000092	0400	0400	0400	0600	0600	0600	0000	0000	%1062	n16	%
004807	-00047	000024	0466	0466	0466	0533	0533	0533	0533	0000	%1063	n17	%
005323	-00078	000054	0533	0533	0533	0466	0466	0466	0466	0000	%1064	n18	%
005738	-00054	-00013	0600	0600	0600	0399	0399	0399	0399	0000	%1065	n19	%
006233	-00049	000074	0666	0666	0666	0333	0333	0333	0333	0000	%1066	n20	%
006753	-00077	000066	0733	0733	0733	0266	0266	0266	0266	0000	%1067	n21	%
007299	-00087	000074	0800	0800	0800	0199	0199	0199	0199	0000	%1068	n22	%
007554	-00054	-00016	0866	0866	0866	0133	0133	0133	0133	0000	%1069	n23	%
008359	-00023	-00008	0933	0933	0933	0000	0000	0000	0000	0000	%1070	n24	%
008896	00011	-00005	1000	1000	1000	0000	0000	0000	0000	0000	%1071	n25	%
001098	000000	000000	0000	0000	0000	1000	1000	1000	1000	0000	%1072	k26	%
008858	000000	000000	0000	1000	1000	0000	0000	0000	0000	0000	%1073	k27	%
003561	005495	003818	1000	0000	0000	0000	1000	1000	1000	0000	%1074	l26	%
005160	-02667	-02759	0000	1000	1000	0000	0000	0000	0000	0000	%1075	l27	%
008137	-00424	-009790	0000	1000	0000	0000	0000	0000	1000	0000	%1076	m26	%
001593	004688	-05065	0000	0000	1000	1000	1000	0000	0000	0000	%1077	m27	%
004378	-05826	-04370	0000	1000	0000	0000	0000	1000	0000	0000	%1078	n26	%
003782	007194	-02907	1000	0000	1000	0000	1000	0000	0000	0000	%1079	n27	%

[illegible]

TUB-test chart GE58; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```

TUB material: code=rha4ta

1UB registration: 20091101-GE58/GE58L0NA.1X1/.PS 1UB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

```
input: w setgray
output: ->olv* setrgbcolor
```

008890	-00010	-00685	1000	1000	1000	0000	0000	0000	0000	%0162	S01	\$
008250	-00056	-01187	0875	0937	1000	0125	0062	0000	0000	%0163	S02	\$
007529	-00098	-01679	0750	0875	1000	0250	0125	0000	0000	%0164	S03	\$
006811	-00106	-02175	0625	0812	1000	0375	0187	0000	0000	%0165	S04	\$
006248	-00263	-02637	0500	0750	1000	0500	0250	0000	0000	%0166	S05	\$
005695	-00403	-03059	0375	0687	1000	0625	0312	0000	0000	%0167	S06	\$
005049	-00470	-03517	0250	0625	1000	0750	0375	0000	0000	%0168	S07	\$
004397	-00680	-03983	0125	0625	1000	0875	0500	0000	0000	%0169	S08	\$
003837	-00787	-04466	0000	0625	1000	1000	0500	0000	0000	%0170	S09	\$
008449	000500	000051	1000	0937	0875	0000	0062	0125	0000	%0171	T01	\$
007887	-00016	-00733	0875	0875	0875	0125	0125	0125	0000	%0172	T02	\$
007179	-00026	-01227	0750	0812	0875	0250	0187	0125	0000	%0173	T03	\$
006507	-00133	-01671	0625	0750	0875	0375	0250	0125	0000	%0174	T04	\$
005964	-00233	-02074	0500	0687	0875	0500	0312	0125	0000	%0175	T05	\$
005368	-00137	-02552	0375	0625	0875	0625	0375	0125	0000	%0176	T06	\$
004751	-00385	-03009	0250	0562	0875	0750	0437	0125	0000	%0177	T07	\$
004084	-00605	-03495	0125	0500	0875	0875	0500	0125	0000	%0178	T08	\$
003489	-00652	-04002	0000	0437	0875	1000	0562	0125	0000	%0179	T09	\$
008049	-00092	-00922	1000	0875	0750	0000	0125	0250	0000	%0180	T01	\$
007469	-00046	-00067	0875	0812	0750	0125	0187	0250	0000	%0181	U02	\$
006848	-00000	-00676	0750	0750	0750	0250	0250	0250	0000	%0182	U03	\$
006197	-00008	-01184	0625	0687	0750	0375	0312	0250	0000	%0183	U04	\$
005642	-00129	-01616	0500	0625	0750	0500	0375	0250	0000	%0184	U05	\$
005030	-00232	-02096	0375	0562	0750	0625	0437	0250	0000	%0185	U06	\$
004405	-00294	-02542	0250	0500	0750	0750	0500	0250	0000	%0186	U07	\$
003745	-00454	-03095	0125	0437	0750	0875	0562	0250	0000	%0187	U08	\$
003199	-00575	-03554	0000	0375	0750	1000	0625	0250	0000	%0188	U09	\$
007617	000152	001586	1000	0812	0625	0000	0187	0375	0000	%0189	V01	\$
007692	000122	000820	0875	0750	0625	0125	0250	0375	0000	%0190	V02	\$
006453	-00060	-00059	0750	0687	0625	0250	0312	0375	0000	%0191	V03	\$
005878	-00006	-00712	0625	0625	0625	0375	0375	0375	0000	%0192	V04	\$
005337	-00021	-01225	0500	0687	0625	0500	0437	0375	0000	%0193	V05	\$
004703	-00132	-01653	0375	0500	0625	0625	0375	0375	0000	%0194	V06	\$
004073	-00172	-02156	0250	0437	0625	0750	0562	0375	0000	%0195	V07	\$
003414	-00384	-02624	0125	0375	0625	0875	0625	0375	0000	%0196	V08	\$
002836	-00435	-03109	0000	0312	0625	1000	0687	0375	0000	%0197	V09	\$
007207	-001382	-02436	1000	0750	0500	0000	0250	0500	0000	%0198	W01	\$
006682	-001984	-001729	0875	0687	0500	0125	0312	0500	0000	%0199	W02	\$
006050	-000936	-000919	0750	0625	0500	0250	0375	0500	0000	%0200	W03	\$
005442	-000500	-000082	0625	0562	0500	0375	0437	0500	0000	%0201	W04	\$
004994	-000034	-00692	0500	0500	0500	0500	0500	0500	0000	%0202	W05	\$
004299	-00031	-01200	0375	0437	0500	0625	0562	0500	0000	%0203	W06	\$
003688	-00116	-01657	0250	0375	0500	0750	0625	0500	0000	%0204	W07	\$
003041	-00258	-02132	0125	0312	0500	0875	0687	0500	0000	%0205	W08	\$
002487	-00357	-02560	0000	0250	0500	1000	0750	0500	0000	%0206	W09	\$
006850	-002335	-003359	1000	0687	0375	0000	0312	0625	0000	%0207	X01	\$
006247	-001854	-002514	0875	0625	0375	0125	0375	0625	0000	%0208	X02	\$
005657	-001420	-001765	0750	0562	0375	0250	0437	0625	0000	%0209	X03	\$
005035	-001027	-000910	0625	0500	0375	0375	0500	0625	0000	%0210	X04	\$
004546	-000575	-000142	0500	0437	0375	0500	0562	0625	0000	%0211	X05	\$
003969	-000031	-00684	0375	0375	0375	0625	0625	0625	0000	%0212	X06	\$
003357	-000031	-01197	0250	0312	0375	0750	0687	0625	0000	%0213	X07	\$
002744	-00197	-01671	0125	0250	0375	0875	0750	0625	0000	%0214	X08	\$
002149	-00263	-02177	0000	0187	0375	1000	0812	0625	0000	%0215	X09	\$
006433	-002767	-004076	1000	0625	0250	0000	0375	0750	0000	%0216	Y01	\$
005881	-002215	-00339	0875	0562	0250	0125	0437	0750	0000	%0217	Y02	\$
005231	-001868	-002533	0750	0500	0250	0250	0500	0750	0000	%0218	Y03	\$
004642	-001448	-001895	0625	0437	0250	0375	0500	0750	0000	%0219	Y04	\$
004161	-000978	-000943	0500	0375	0250	0500	0625	0750	0000	%0220	Y05	\$
003566	-000505	-000096	0375	0312	0250	0625	0687	0750	0000	%0221	Y06	\$
003049	-000048	-00716	0250	0250	0250	0750	0500	0750	0000	%0222	Y07	\$
002423	-00115	-01238	0125	0187	0250	0875	0812	0750	0000	%0223	Y08	\$
001803	-00118	-01711	0000	0125	0250	1000	0875	0750	0000	%0224	Y09	\$
006044	-002157	-004916	1000	0562	0125	0000	0437	0875	0000	%0225	Z01	\$
005425	-003701	-004031	0875	0500	0125	0125	0500	0875	0000	%0226	Z02	\$
004843	-002312	-003261	0750	0437	0125	0250	0562	0875	0000	%0227	Z03	\$
004256	-001868	-002437	0625	0375	0125	0375	0625	0875	0000	%0228	Z04	\$
003754	-001475	-001674	0500	0312	0125	0500	0687	0875	0000	%0229	Z05	\$
003195	-000930	-000870	0375	0250	0125	0625	0750	0875	0000	%0230	Z06	\$
002659	-000545	-000044	0250	0187	0125	0750	0812	0875	0000	%0231	Z07	\$
002094	-000035	-000858	0125	0125	0125	0875	0875	0875	0000	%0232	Z08	\$
001419	-000010	-01376	0000	0062	0125	1000	0937	0875	0000	%0233	Z09	\$
005648	-003588	-005787	1000	0500	0000	0000	0500	1000	0000	%0234	A01	\$
005033	-003092	-004958	0875	0437	0000	0125	0562	1000	0000	%0235	A02	\$
004449	-002683	-004082	0750	0375	0000	0250	0625	1000	0000	%0236	A03	\$
003869	-002287	-003298	0625	0312	0000	0375	0687	1000	0000	%0237	A04	\$
003371	-001913	-002515	0500	0250	0000	0500	0750	1000	0000	%0238	A05	\$
002787	-001407	-001695	0375	0187	0000	0625	0812	1000	0000	%0239	A06	\$
002248	-001021	-000868	0250	0125	0000	0750	0875	1000	0000	%0240	A07	\$
001642	-000540	-000552	0125	0062	0000	0875	0937	1000	0000	%0241	A08	\$
001059	-000107	-000855	0000	0000	0000	1000	1000	1000	0000	%0242	A09	\$
008849	-00015	-00684	1000	1000	1000	0000	0000	0000	0000	%0486	S10	\$
008130	-000675	-01166	0937	0875	1000	0062	0125	0000	0000	%0487	S11	\$
007346	-001342	-01623	0875	0750	1000	0125	0250	0000	0000	%0488	S12	\$
006581	-002004	-02163	0812	0625	1000	0187	0375	0000	0000	%0489	S13	\$
005756	-002743	-02693	0750	0500	1000	0250	0500	0000	0000	%0490	S14	\$
004954	-003443	-03214	0687	0375	1000	0312	0625	0000	0000	%0491	S15	\$
004160	-004132	-03723	0625	0250	1000	0375	0750	0000	0000	%0492	S16	\$
003303	-004778	-04169	0562	0250	1000	0500	0875	0000	0000	%0493	S17	\$
002555	-005390	-04643	0500	1000	0500	1000	0000	0000	0000	%0494	S18	\$
008500	-00323	-000083	0937	1000	0875	0062	0100	0125	0000	%0495	T10	\$
007895	-00034	-00708	0875	0875	0125	0125	0125	0000	0000	%0496	T11	\$
007103	-000669	-01189	0812	0750	0875	0187	0250	0125	0000	%0497	T12	\$
006291	-001329	-01647	0750	0625	0875	0250	0375	0125	0000	%0498	T13	\$
005487	-002047	-02175	0687	0500	0875	0312	0500	0125	0000	%0499	T14	\$
004738	-002753	-02714	0625	0375	0875	0375	0625	0125	0000	%0500	T15	\$
003972	-003460	-03229	0562	0250	0875	0437	0750	0125	0000	%0501	T16	\$
003226	-004094	-03677	0500	0125	0875	0500	0875	0125	0000	%0502	T17	\$
002444	-004760	-04165	0437	0000	0875	0562	1000	0125	0000	%0503	T18	\$
008124	-00746	-000926	0875	1000	0750	0125	0000	0250	0000	%0504	U10	\$
007486	-003097	-000077	0812	0875	0750	0187	0125	0250	0000	%0505	U11	\$
006862	-0001											

See original or copy: <http://web.me.com/klaustrichter/GE58/GE58L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

008933	00031	-00670	1000	1000	0000	0000	0000	0000	0000	%0567	b10	\$
008187	000096	-01241	0875	0906	1000	0125	0093	0000	0000	%0568	b11	\$
007393	000288	-01758	0750	0812	1000	0250	0187	0000	0000	%0569	b12	\$
006615	000386	-02306	0625	0718	1000	0375	0281	0000	0000	%0570	b13	\$
005934	000541	-02834	0500	0625	1000	0500	0375	0000	0000	%0571	b14	\$
005280	000596	-03240	0375	0531	1000	0625	0468	0000	0000	%0572	b15	\$
004531	000728	-03870	0250	0437	1000	0750	0562	0000	0000	%0573	b16	\$
003757	000781	-04418	0125	0343	1000	0875	0556	0000	0000	%0574	b17	\$
003063	000847	-04969	0000	0250	1000	1000	0750	0000	0000	%0575	b18	\$
008641	000321	-000234	1000	0968	0875	0000	0031	0125	0000	%0576	c10	\$
007928	-00037	-00743	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$
007143	000140	-01278	0750	0781	0875	0250	0218	0125	0000	%0578	c12	\$
006365	000296	-01789	0625	0687	0875	0375	0312	0125	0000	%0579	c13	\$
005699	000415	-02258	0500	0593	0875	0500	0406	0125	0000	%0580	c14	\$
005039	000493	-02802	0375	0500	0875	0625	0500	0125	0000	%0581	c15	\$
004261	000619	-03325	0250	0406	0875	0750	0593	0125	0000	%0582	c16	\$
003507	000676	-03894	0125	0312	0875	0875	0687	0125	0000	%0583	c17	\$
002853	000692	-04421	0000	0218	0875	1000	0781	0125	0000	%0584	c18	\$
008353	000624	-001240	1000	0937	0750	0000	0602	0250	0000	%0585	d10	\$
007670	000324	-000249	0875	0843	0750	0125	0156	0250	0000	%0586	d11	\$
006904	-00004	-00667	0750	0750	0750	0250	0500	0250	0000	%0587	d12	\$
006148	000094	-01160	0625	0656	0750	0375	0343	0250	0000	%0588	d13	\$
005495	000242	-01723	0500	0562	0750	0500	0437	0250	0000	%0589	d14	\$
004777	000361	-02261	0375	0468	0750	0625	0531	0250	0000	%0590	d15	\$
004033	000505	-02825	0250	0375	0750	0750	0625	0250	0000	%0591	d16	\$
003264	000620	-03432	0125	0281	0750	0875	0718	0250	0000	%0592	d17	\$
002616	000617	-03937	0000	0187	0750	1000	0812	0250	0000	%0593	d18	\$
008064	000931	-002123	1000	0906	0625	0000	0093	0375	0000	%0594	e10	\$
007382	000669	-001144	0875	0812	0625	0125	0187	0375	0000	%0595	e11	\$
006645	000278	-000247	0750	0718	0625	0250	0281	0375	0000	%0596	e12	\$
005914	000018	-00692	0625	0625	0625	0375	0375	0375	0000	%0597	e13	\$
005293	000149	-01198	0500	0531	0625	0500	0468	0375	0000	%0598	e14	\$
004535	000294	-01764	0375	0437	0625	0625	0500	0375	0000	%0599	e15	\$
003789	000515	-02300	0250	0343	0625	0750	0566	0375	0000	%0600	e16	\$
003041	000521	-02904	0125	0250	0625	0875	0750	0375	0000	%0601	e17	\$
002359	000563	-03410	0000	0156	0625	1000	0843	0375	0000	%0602	e18	\$
007763	001268	-003142	1000	0875	0500	0000	0125	0500	0000	%0603	f10	\$
007156	000905	-002257	0875	0781	0500	0125	0218	0500	0000	%0604	f11	\$
006399	000556	-001341	0750	0687	0500	0250	0312	0500	0000	%0605	f12	\$
005648	000341	-000292	0625	0593	0500	0375	0406	0500	0000	%0606	f13	\$
005063	000035	-00667	0500	0500	0500	0500	0500	0500	0000	%0607	f14	\$
004282	000161	-01239	0375	0406	0500	0625	0593	0500	0000	%0608	f15	\$
003560	000247	-01720	0250	0312	0500	0750	0687	0500	0000	%0609	f16	\$
002811	000290	-02266	0125	0218	0500	0875	0781	0500	0000	%0610	f17	\$
002107	000447	-02844	0000	0125	0500	1000	0875	0500	0000	%0611	f18	\$
007498	001501	-00410	1000	0843	0375	0000	0156	0625	0000	%0612	g10	\$
006883	001173	-003266	0875	0750	0375	0125	0250	0625	0000	%0613	g11	\$
006125	000889	-002326	0750	0656	0375	0250	0343	0625	0000	%0614	g12	\$
005367	000663	-001333	0625	0652	0375	0375	0437	0625	0000	%0615	g13	\$
004741	000368	-000341	0500	0468	0375	0500	0531	0625	0000	%0616	g14	\$
004030	000030	-00667	0375	0375	0375	0625	0625	0625	0000	%0617	g15	\$
003331	000158	-01174	0250	0281	0375	0750	0718	0625	0000	%0618	g16	\$
002603	000165	-01745	0125	0187	0375	0875	0812	0625	0000	%0619	g17	\$
001874	000365	-02317	0000	0093	0375	1000	0906	0625	0000	%0620	g18	\$
007278	001720	-005184	1000	0812	0250	0000	0187	0750	0000	%0621	h10	\$
006621	001399	-004273	0875	0718	0250	0125	0281	0750	0000	%0622	h11	\$
005860	001156	-003200	0750	0625	0250	0250	0375	0750	0000	%0623	h12	\$
005114	000873	-002308	0625	0531	0250	0375	0406	0750	0000	%0624	h13	\$
004469	000660	-001332	0500	0437	0250	0500	0562	0750	0000	%0625	h14	\$
003808	000268	-000372	0375	0343	0250	0625	0656	0750	0000	%0626	h15	\$
003096	000203	-00662	0250	0250	0250	0750	0750	0750	0000	%0627	h16	\$
002356	000946	-01292	0125	0156	0250	0875	0843	0750	0000	%0628	h17	\$
001616	000348	-01878	0000	0062	0250	1000	0937	0750	0000	%0629	h18	\$
007009	001402	-006029	1000	0781	0125	0000	0218	0875	0000	%0630	i10	\$
006323	001600	-005146	0875	0687	0125	0125	0312	0875	0000	%0631	i11	\$
005590	001393	-004189	0750	0593	0125	0250	0406	0875	0000	%0632	i12	\$
004840	001222	-003114	0625	0500	0125	0375	0500	0875	0000	%0633	i13	\$
004253	000890	-002260	0500	0406	0125	0500	0593	0875	0000	%0634	i14	\$
003521	000654	-001238	0375	0312	0125	0625	0687	0875	0000	%0635	i15	\$
002866	000322	-000260	0250	0218	0125	0750	0781	0875	0000	%0636	i16	\$
002142	000004	-00823	0125	0125	0125	0875	0875	0875	0000	%0637	i17	\$
001358	000187	-01418	0000	0031	0125	1000	0968	0875	0000	%0638	i18	\$
006757	002144	-007157	1000	0750	0000	0000	0250	1000	0000	%0639	i19	\$
006045	001858	-006192	0875	0656	0000	0125	0343	1000	0000	%0640	j10	\$
005307	001635	-005159	0750	0562	0000	0250	0437	1000	0000	%0641	j11	\$
004610	001468	-004098	0625	0468	0000	0375	0531	1000	0000	%0642	j13	\$
003992	001210	-003279	0500	0375	0000	0500	0625	1000	0000	%0643	j14	\$
003294	000913	-002242	0375	0281	0000	0625	0718	1000	0000	%0644	j15	\$
002621	000606	-001333	0250	0187	0000	0750	0812	1000	0000	%0645	j16	\$
001883	000298	-000231	0125	0093	0000	0875	0906	1000	0000	%0646	j17	\$
001153	000087	-00835	0000	0000	0000	1000	1000	1000	0000	%0647	j18	\$
008890	-00033	-00677	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
008214	000775	-01099	0968	0875	1000	0000	0031	0125	0000	%0568	b11	\$
007526	001544	-01456	0937	0750	1000	0062	02					

See original or copy: <http://web.me.com/klaus.richter/GE58/GE58L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE48.22.TXT, Separation olv*, cfi=0.90, D50, not adapted $
%100 x LAB*      %#1000 x (r g b c m y 0)      %nr.      pos $
%z003748 005900 003371 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%z008174 000132 009008 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%z004248 -05548 003308 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%z005013 -03376 -03717 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%z001471 003942 -05889 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%z003847 007009 -03299 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%z001009 000131 -00863 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%z008847 -00021 -00689 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%z003748 005900 003371 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%z008174 000132 009008 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%z004248 -05548 003308 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%z005013 -03376 -03717 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%z001471 003942 -05889 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%z003847 007009 -03299 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%z001009 000131 -00863 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%z008847 -00021 -00689 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%z003748 005900 003371 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%z008174 000132 009008 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%z004248 -05548 003308 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%z005013 -03376 -03717 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%z001471 003942 -05889 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%z003847 007009 -03299 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%z001009 000131 -00863 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%z008847 -00021 -00689 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%z004672 004795 004546 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%z006797 -01701 007034 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%z004592 -04403 000311 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%z004367 -02045 -04113 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%z002056 004641 -05296 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%z003793 006746 -01284 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%z001017 000143 -00852 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%z008840 000003 -00701 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%z005648 003588 005787 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%z005977 -03079 005885 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%z004770 -03966 -01165 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%z003837 -00797 -04466 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%z002655 005399 -04643 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%z003755 006485 000343 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%z001038 000116 -00835 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%z008857 -00011 -00683 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%z006757 002144 007157 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%z005129 -04324 004517 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%z004928 -03688 -02359 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%z003063 000847 -04969 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%z003260 006199 -03997 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%z003767 006235 001871 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%z001121 000091 -00818 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%z008893 -00031 -00673 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/GE58/GE58L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

%BEG GE48 22.TXT, Separation olv*, cfi=0.90, D50, not adapted S																											
%100 x LAB*																											
1000 x (r g b c m y o)																											
nrr. pos \$																											
001188	000055	-00787	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$															
002178	-00013	-00788	0125	0125	0125	0875	0875	0875	0000	%0973	k02	\$						%1053	m23	\$							
003162	000052	-00624	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$						%1054	m24	\$							
004053	000042	-00664	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$						%1055	m25	\$							
005090	000020	-00638	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$						%1056	n10	\$							
005979	-00005	-00678	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$						%1057	n11	\$							
006940	-00043	-00615	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$						%1058	n12	\$							
007945	-00057	-00710	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$						%1059	n13	\$							
008903	-00032	-00666	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$						%1060	n14	\$							
001185	000053	-00817	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$						%1061	n15	\$							
002182	-00019	-00781	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$						%1062	n16	\$							
003152	000057	-00629	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$						%1063	n17	\$							
004034	000053	-00669	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$						%1064	n18	\$							
005086	000021	-00633	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$						%1065	n19	\$							
005965	-00010	-00667	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$						%1066	n20	\$							
006930	-00038	-00627	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$						%1067	n21	\$							
007944	-00061	-00708	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$						%1068	n22	\$							
008902	-00035	-00674	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$						%1069	n23	\$							
001181	000056	-00800	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$						%1070	n24	\$							
002189	-00018	-00786	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$						%1071	n25	\$							
003167	000044	-00625	0250	0250	0250	0750	0750	0750	0000	%0992	k03	\$						%1072	k26	\$							
004038	000044	-00667	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$						%1073	k27	\$							
005104	000028	-00641	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$						%1074	l26	\$							
005967	-00007	-00680	0625	0625	0625	0375	0375	0375	0000	%0995	m06	\$						%1075	l27	\$							
006934	-00045	-00621	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$						%1076	m26	\$							
007942	-00068	-00708	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$						%1077	m27	\$							
008897	-00036	-00674	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$						%1078	n26	\$							
001201	000047	-00782	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$						%1079	n27	\$							
002185	-00015	-00798	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$	%003738	005927	003385	##1000	0000	0000	0000	1000	1000	0000	%1074	l26	%03 0 0 \$		
003159	000026	-00597	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$	%008212	000144	009115	##1000	1000	0000	0000	0000	1000	0000	0000	%1076	m26	%Y3 1 2 \$	
004048	000030	-00658	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$	%004321	-05567	003419	##0000	1000	0000	0000	1000	0000	1000	0000	%1078	n26	%L3 2 3 \$	
005106	000023	-00652	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$	%005032	-03374	-03704	##0000	1000	1000	1000	0000	0000	0000	0000	%1075	l27	%C3 3 3 \$	
005970	-00019	-00682	0625	0625	0625	0375	0375	0375	0000	%1004	n06	\$	%001522	003915	-05892	##0000	0000	1000	1000	1000	1000	0000	0000	%1077	m27	%V3 4 4 \$	
006951	-00056	-00609	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$	%003910	007055	-03322	##1000	0000	1000	0000	1000	0000	0000	0000	%1079	n27	%M3 5 5 \$	
007951	-00076	-00708	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$	%001084	000099	-00824	##0000	0000	0000	1000	1000	1000	1000	0000	%1072	k26	%M3 6 5 \$	
008896	-00045	-00668	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$	%008848	-00019	-00659	##1000	1000	1000	0000	0000	0000	0000	0000	%1073	k27	%W3 7 5 \$	
001090	000094	-00882	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$															
001652	000084	-00878	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$	%001139	000075	-00834	##0000	0000	0000	1000	1000	1000	1000	0000	0000	%0972	k01	%N4 6 5 \$
002178	000014	-00838	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$	%008887	-00023	-00671	##1000	1000	1000	0000	0000	0000	0000	0000	0000	%0980	k09	%W4 7 5 \$
002675	000006	-00773	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$															
003193	000019	-00666	0266	0266	0266	0733	0733	0733	0000	%1012	k14	\$	%001136	000070	-00839	##0000	0000	0000	1000	1000	1000	1000	0000	0000	%0981	l01	%N5 6 5 \$
003742	-00026	-00641	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$	%008887	-00026	-00676	##1000	1000	1000	0000	0000	0000	0000	0000	0000	%0989	l09	%W5 7 5 \$
004204	000016	-00660	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$															
004769	000011	-00718	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$	%001147	000069	-00827	##0000	0000	0000	1000	1000	1000	1000	0000	0000	%0990	m01	%N6 6 5 \$
005289	-00017	-00691	0533	0533	0533	0466	0466	0466	0000	%1016	k18	\$	%008886	-00032	-00675	##1000	1000	1000	0000	0000	0000	0000	0000	0000	%0998	m09	%W6 7 5 \$
005722	-00008	-00736	0600	0600	0600	0399	0399	0399	0000	%1017	k19	\$															
006204	000001	-00646	0666	0666	0666	0333	0333	0333	0000	%1018	k20	\$	%001151	000061	-00822	##0000	0000	0000	1000	1000	1000	1000	0000	0000	%0999	n01	%N7 6 5 \$
006724	-00035	-00645	0733	0733	0733	0266	0266	0266	0000	%1019	k21	\$	%008891	-00039	-00668	##1000	1000	1000	0000	0000	0000	0000	0000	0000	%1007	n09	%W7 7 5 \$
007276	-00007	-00637	0800	0800	0800	0199	0199	0199	0000	%1020	k22	\$															
007826	-00050	-00692	0866	0866	0866	0133	0133	0133	0000	%1021	k23	\$															
008333	000026	-00705	0933	0933	0933	0066	0066	0066	0000	%1022	k24	\$															
008871	-00014	-00676	1000	1000	1000	0000	0000	0000	0000	%1023	k25	\$															
001087	000087	-00862	0000	0000	0000	1000	1000	1000	0000	%1024	l10	\$															
001649	000083	-00873	0066	0066	0066	0933	0933	0933	0000	%1025	l11	\$															
002178	000013	-00840	0133	0133	0133	0866	0866	0866	0000	%1026	l12	\$															
002667	000006	-00775	0200	0200	0200	0800	0800	0800	0000	%1027	l13	\$															
003182	000027	-00677	0266	0266	0266	0733	0733	0733	0000	%1028	l14	\$															
003734	-00012	-00658	0333	0333	0333	0666	0666	0666	0000	%1029	l15	\$															
004193	000021	-00658	0400	0400	0400	0600	0600	0600	0000	%1030	l16	\$															

TUB registration: 20091101-GE58/GE58L0NA.TXT/.PS TUB material: code=rhatha
application for evaluation and measurement of printer or monitor systems

```
input: w setgray
output: ->oly* setrgbcolor
```

TUB registration: 20091101-GE58/GE58L0NA.TXT /.PS TUB material: code=rh4ta
application for evaluation and measurement of printer or monitor systems

A target diagram consisting of concentric circles. The center is labeled '8' and the outer ring is labeled '-8'.

```
input: w setgray
output: ->oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE58/GE58L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

TUB registration: 20091101-GE58/GE58L.ONA.TXT /.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

[illegible]

TUB-test chart GE58; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

See original or copy: <http://web.me.com/klaus.richter/GE58/GE58L0NA.TXT> / .PS
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=1.00; nt=0.18; nx=1.00

TUB registration: 20091101-GE58/GE58L0NA.TXT/.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

[illegible]

TUB-test chart GE58; Relative Device Colour System C
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: ->olv* setrgbcolor
```

IOB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/GE58/GE58L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.18; nx=1.0

```
%BEG GE48.22.TXT, Separation olv*, cfi=0.90, D50, adapted $
%100 x LAB*a      %1000 x (r g b c m y 0)      %nr. pos $
%Z003748 005823 004173 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z008174 000140 009713 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z004248 -05615 004100 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005013 -03429 -02942 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z001471 003819 -05036 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z003847 006933 -02499 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001009 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z008847 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z003748 005823 004173 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z008174 000140 009713 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z004248 -05615 004100 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005013 -03429 -02942 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z001471 003819 -05036 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z003847 006933 -02499 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001009 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z008847 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z003748 005823 004173 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z008174 000140 009713 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z004248 -05615 004100 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005013 -03429 -02942 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z001471 003819 -05036 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z003847 006933 -02499 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001009 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z008847 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z004672 004717 005328 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z006797 -01741 007775 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z004592 -04482 001095 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z004367 -02128 -03325 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z002056 004517 -04464 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z003793 006652 -00485 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001017 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z008840 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z005648 003547 006534 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z005977 -03115 006624 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z004770 -04022 -00402 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z003837 -00867 -03685 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z002655 005308 -03839 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z003755 006412 001126 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001038 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z008857 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z006757 002142 007870 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z005129 -04352 005260 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z004928 -03720 -01611 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003063 000786 -04186 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z003260 006141 -03219 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z003767 006185 002640 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001121 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z008893 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```

%BEG GE48.22.TXT, Separation olv*, cf1=0.90, D50, adapted \$
%100 x LAB*a 1000 x (r g b c m y 0) %nr. pos \$
001188 -00042 000034 0000 0000 0000 1000 1000 1000 0000 %0972 k01 \$ %1053 m23 \$
002178 -00095 000012 0125 0125 0125 0875 0875 0875 0000 %0973 k02 \$ %1054 m24 \$
003162 -00014 000155 0250 0250 0250 0750 0750 0750 0000 %0974 k03 \$ %1055 m25 \$
004053 -00010 000097 0375 0375 0375 0625 0625 0625 0000 %0975 k04 \$ %1056 n10 \$
005090 -00016 000101 0500 0500 0500 0500 0500 0500 0000 %0976 k05 \$ %1057 n11 \$
005979 -00029 000041 0625 0625 0625 0375 0375 0375 0000 %0977 k06 \$ %1058 n12 \$
006940 -00052 000085 0750 0750 0750 0250 0250 0250 0000 %0978 k07 \$ %1059 n13 \$
007845 -00051 -00031 0875 0875 0875 0125 0125 0125 0000 %0979 k08 \$ %1060 n14 \$
008903 -00011 000090 1000 1000 1000 0000 0000 0000 0000 %0980 k09 \$ %1061 n15 \$
001185 -00044 000004 0000 0000 0000 1000 1000 1000 0000 %0981 l01 \$ %1062 n16 \$
002182 -00101 000019 0125 0125 0125 0875 0875 0875 0000 %0982 l02 \$ %1063 n17 \$
003152 -00009 000151 0250 0250 0250 0750 0750 0750 0000 %0983 l03 \$ %1064 n18 \$
004034 000000 000092 0375 0375 0375 0625 0625 0625 0000 %0984 l04 \$ %1065 n19 \$
005086 -00016 000106 0500 0500 0500 0500 0500 0500 0000 %0985 l05 \$ %1066 n20 \$
005965 -00035 000053 0625 0625 0625 0375 0375 0375 0000 %0986 l06 \$ %1067 n21 \$
006930 -00048 000073 0750 0750 0750 0250 0250 0250 0000 %0987 l07 \$ %1068 n22 \$
007944 -00055 -00029 0875 0875 0875 0125 0125 0125 0000 %0988 l08 \$ %1069 n23 \$
008902 -00015 -00015 1000 1000 1000 0000 0000 0000 0000 %0989 l09 \$ %1070 n24 \$
001181 -00041 000021 0000 0000 0000 1000 1000 1000 0000 %0990 m01 \$ %1071 n25 \$
002189 -00100 000013 0125 0125 0125 0875 0875 0875 0000 %0991 m02 \$ %1072 k26 \$
003167 -00022 000154 0250 0250 0250 0750 0750 0750 0000 %0992 k03 \$ %1073 k27 \$
004038 -00009 000094 0375 0375 0375 0625 0625 0625 0000 %0993 k04 \$ %1074 l26 \$
005104 -00009 000097 0500 0500 0500 0500 0500 0500 0000 %0994 m05 \$ %1075 l27 \$
005967 -00031 000039 0625 0625 0625 0375 0375 0375 0000 %0995 m06 \$ %1076 m26 \$
006934 -00055 000078 0750 0750 0750 0250 0250 0250 0000 %0996 m07 \$ %1077 m27 \$
007942 -00062 -00029 0875 0875 0875 0125 0125 0125 0000 %0997 m08 \$ %1078 n26 \$
008897 -00016 -00015 1000 1000 1000 0000 0000 0000 0000 %0998 m09 \$ %1079 n27 \$
001201 -00049 000038 0000 0000 0000 1000 1000 1000 0000 %0999 n01 \$ %\$
002185 -00097 000002 0125 0125 0125 0875 0875 0875 0000 %1000 n02 \$ %z003738 005869 004153 %01000 0000 0000 0000 1000 1000 0000 %1074 l26 %03 0 0 \$
003159 -00041 000103 0250 0250 0250 0750 0750 0750 0000 %1001 n03 \$ %z008212 000154 009788 %01000 1000 0000 0000 0000 1000 0000 %1076 m26 %Y3 1 1 \$
004048 -00023 000103 0375 0375 0375 0625 0625 0625 0000 %1002 n04 \$ %z004321 000154 %0000 1000 0000 0000 0000 1000 0000 %1078 n26 %L3 2 2 \$
005106 -00014 000006 0500 0500 0500 0500 0500 0500 0000 %1003 n05 \$ %z005032 -03413 -02964 %0000 1000 1000 0000 0000 0000 0000 %1075 l27 %C3 3 3 \$
005970 -00043 000038 0625 0625 0625 0375 0375 0375 0000 %1004 n06 \$ %z001522 003823 -05077 %0000 1000 1000 0000 0000 0000 0000 %1077 m27 %V3 4 4 \$
006951 -00065 000090 0750 0750 0750 0250 0250 0250 0000 %1005 n07 \$ %z003910 007000 -02558 %01000 1000 0000 0000 0000 1000 0000 %1079 n27 %M3 5 5 \$
007951 -00069 000029 0875 0875 0875 0125 0125 0125 0000 %1006 n08 \$ %z001084 000000 000000 %00000 0000 0000 1000 1000 0000 %1072 k26 %N3 6 6 \$
008896 -00024 -00010 1000 1000 1000 0000 0000 0000 0000 %1007 n09 \$ %z008848 000000 000000 %01000 1000 1000 0000 0000 0000 0000 %1073 k27 %W3 7 7 \$
001090 -00004 -00058 0000 0000 0000 1000 1000 1000 0000 %1008 k10 \$ %\$
001652 -00006 -00066 0000 0000 0000 0933 0933 0933 0000 %1009 k11 \$ %z001188 -00042 000034 %00000 0000 0000 1000 1000 0000 0000 %0972 k01 %N4 6 6 \$
002178 -00068 -00037 0133 0133 0133 0866 0866 0866 0000 %1010 k12 \$ %z008903 -00011 -00008 %01000 1000 1000 0000 0000 0000 0000 %0980 k09 %W4 7 7 \$
002675 -00068 000017 0200 0200 0200 0800 0800 0800 0000 %1011 k13 \$ %\$
003193 -00047 000112 0266 0266 0266 0733 0733 0733 0000 %1012 k14 \$ %z001185 -00044 000004 %00000 0000 0000 1000 1000 0000 0000 %0981 l01 %N5 6 6 \$
003742 -00084 000126 0333 0333 0333 0666 0666 0666 0000 %1013 k15 \$ %z008902 -00015 -00015 %01000 1000 1000 0000 0000 0000 0000 %0989 l09 %W5 7 7 \$
004204 -00034 000097 0400 0400 0400 0600 0600 0600 0000 %1014 k16 \$ %\$
004769 -00031 000027 0466 0466 0466 0533 0533 0533 0000 %1015 k17 \$ %z001181 -00041 000021 %00000 0000 0000 1000 1000 0000 0000 %0990 m01 %N6 6 6 \$
005289 -00051 000043 0533 0533 0533 0466 0466 0466 0000 %1016 k18 \$ %z008897 -00016 -00015 %01000 1000 1000 0000 0000 0000 0000 %0998 m09 %W6 7 7 \$
005722 -00036 -00010 0600 0600 0600 0399 0399 0399 0000 %1017 k19 \$ %\$
006204 -00019 000069 0666 0666 0666 0333 0333 0333 0000 %1018 k20 \$ %z001201 -00049 000038 %00000 0000 0000 1000 1000 0000 0000 %0999 n01 %N7 6 6 \$
006724 -00048 000058 0733 0733 0733 0266 0266 0266 0000 %1019 k21 \$ %z008896 -00024 -00010 %01000 1000 1000 0000 0000 0000 0000 %1007 n09 %W7 7 7 \$
007276 -00012 000055 0800 0800 0800 0199 0199 0199 0000 %1020 k22 \$ %\$
007826 -00046 -00011 0866 0866 0866 0133 0133 0133 0000 %1021 k23 \$
008333 000038 -00034 0933 0933 0933 0066 0066 0066 0000 %1022 k24 \$
008871 000005 -00017 1000 1000 1000 0000 0000 0000 0000 %1023 k25 \$
001087 -00011 -00038 0000 0000 0000 1000 1000 1000 0000 %1024 l10 \$
001649 -00007 -00061 0000 0000 0000 0933 0933 0933 0000 %1025 l11 \$
002178 -00068 -00039 0133 0133 0133 0866 0866 0866 0000 %1026 l12 \$
002667 -00068 000015 0200 0200 0200 0800 0800 0800 0000 %1027 l13 \$
003182 -00039 000101 0266 0266 0266 0733 0733 0733 0000 %1028 l14 \$
003734 -00071 000109 0333 0333 0333 0666 0666 0666 0000 %1029 l15 \$
004193 -00030 000099 0400 0400 0400 0600 0600 0600 0000 %1030 l16 \$
004773 -00039 000051 0466 0466 0466 0533 0533 0533 0000 %1031 l17 \$
005295 -00055 000054 0533 0533 0533 0466 0466 0466 0000 %1032 l18 \$
005713 -00040 -00011 0600 0600 0600 0399 0399 0399 0000 %1033 l19 \$
006209 -00020 000070 0666 0666 0666 0333 0333 0333 0000 %1034 l20 \$
006741 -00052 000060 0733 0733 0733 0266 0266 0266 0000 %1035 l21 \$
007272 -00011 000058 0800 0800 0800 0199 0199 0199 0000 %1036 l22 \$
007816 -00046 -00011 0866 0866 0866 0133 0133 0133 0000 %1037 l23 \$
008347 -00023 -00025 0933 0933 0933 0066 0066 0066 0000 %1038 l24 \$
008873 -00003 -00018 1000 1000 1000 0000 0000 0000 0000 %1039 l25 \$
001114 -00015 -00030 0000 0000 0000 1000 1000 1000 0000 %1040 m10 \$
001659 -00014 -00078 0000 0000 0000 0933 0933 0933 0000 %1041 m11 \$
002198 -00076 -00025 0133 0133 0133 0866 0866 0866 0000 %1042 m12 \$
002679 -00076 000034 0200 0200 0200 0800 0800 0800 0000 %1043 m13 \$
003191 -00048 000106 0266 0266 0266 0733 0733 0733 0000 %1044 m14 \$
003741 -00074 000103 0333 0333 0333 0666 0666 0666 0000 %1045 m15 \$
004217 -00031 000096 0400 0400 0400 0600 0600 0600 0000 %1046 m16 \$
004783 -00028 000025 0466 0466 0466 0533 0533 0533 0000 %1047 m17 \$
005307 -00059 000055 0533 0533 0533 0466 0466 0466 0000 %1048 m18 \$
005722 -00046 -00012 0600 0600 0600 0399 0399 0399 0000 %1049 m19 \$
006225 -00027 000078 0666 0666 0666 0333 0333 0333 0000 %1050 m20 \$
006740 -00059 000068 0733 0733 0733 0266 0266 0266 0000 %1051 m21 \$
007287 -00022 000060 0800 0800 0800 0199 0199 0199 0000 %1052 m22 \$