

See original or copy: <http://web.me.com/klaus.richter/GE73/GE73L0NA.TXT> /PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

TUB registration: 20091101-GE73/GE73L0NA.TXT /PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

%BEG GE63 22.TXT, Separation cmydn4*, cfi=0.90, D65, not adapted S																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																			
%100 x LAB*																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																			
1000 x (r g b c m y 0)																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																			
nmr. pos \$																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																																			
0001266	000030	000100	0000	0000	0000	0000	0000	0000	0000	000000	A01	\$	002237	000165	000304	0125	0000	0000	0875	1000	1000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000

003928	000844	000827	0375	0000	0000	0625	1000	1000	0000	%0243	A10	\$
003932	001104	000244	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$
003812	001038	000104	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$
003457	001464	-00173	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$
004219	001601	-00796	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$
004298	002796	-01819	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$
004244	002869	-01851	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$
004153	003257	-02377	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$
003914	003632	-03378	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$
004033	000825	000891	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$
004013	000768	000861	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$
003925	001068	000296	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$
003934	000985	-00417	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$
004160	001300	-00962	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$
004298	001652	-00902	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$
004137	002296	-02275	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$
004171	002380	-02317	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$
004318	002709	-02841	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$
004601	000313	001502	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$
004063	000756	000935	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$
004126	000666	000599	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$
004130	000739	000353	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$
004140	000850	-00677	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$
004408	001121	-01161	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$
004529	001637	-01685	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$
004667	001783	-02158	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$
004996	002064	-02530	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$
005070	-00794	001664	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$
004955	-00142	001605	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$
004655	-00206	001104	0375	0375	0250	0625	0625	0750	0000	%0272	D12	\$
004580	-00012	000102	0375	0375	0375	0625	0625	0625	0000	%0273	D13	\$
004809	000242	-00323	0375	0375	0500	0625	0625	0500	0000	%0274	D14	\$
005005	000508	-00806	0375	0375	0625	0625	0625	0375	0000	%0275	D15	\$
005264	000757	-01300	0375	0375	0750	0625	0625	0250	0000	%0276	D16	\$
005429	001104	-01764	0375	0375	0875	0625	0625	0125	0000	%0277	D17	\$
005615	001156	-02235	0375	0375	1000	0625	0625	0000	0000	%0278	D18	\$
005767	-01644	002090	0375	0500	0000	0625	0500	1000	0000	%0279	D19	\$
005299	-01073	001653	0375	0500	0125	0625	0500	0875	0000	%0280	E11	\$
005322	-00993	001282	0375	0500	0250	0625	0500	0750	0000	%0281	E12	\$
005270	-00757	000294	0375	0500	0375	0625	0500	0625	0000	%0282	E13	\$
005106	-00383	-00436	0375	0500	0500	0625	0500	0500	0000	%0283	E14	\$
005384	-00114	-01018	0375	0500	0625	0625	0500	0375	0000	%0284	E15	\$
005471	000094	-01348	0375	0500	0750	0625	0500	0250	0000	%0285	E16	\$
005639	000329	-01795	0375	0500	0875	0625	0500	0125	0000	%0286	E17	\$
005862	000613	-02168	0375	0500	1000	0625	0500	0000	0000	%0287	E18	\$
006085	-02361	002697	0375	0625	0000	0625	0375	1000	0000	%0288	F10	\$
005769	-01661	002069	0375	0625	0125	0625	0375	0875	0000	%0289	F11	\$
005647	-01648	001466	0375	0625	0250	0625	0375	0750	0000	%0290	F12	\$
005701	-01454	000757	0375	0625	0375	0625	0375	0625	0000	%0291	F13	\$
005632	-01036	-00238	0375	0625	0500	0625	0375	0500	0000	%0292	F14	\$
005554	-00877	-00810	0375	0625	0625	0625	0375	0375	0000	%0293	F15	\$
005667	-00478	-01381	0375	0625	0750	0625	0375	0250	0000	%0294	F16	\$
005797	-00175	-01888	0375	0625	0875	0625	0375	0125	0000	%0295	F17	\$
005696	-00025	-02109	0375	0625	1000	0625	0375	0000	0000	%0296	F18	\$
006439	-03236	003145	0375	0750	0000	0625	0250	1000	0000	%0297	G10	\$
006106	-02411	002630	0375	0750	0125	0625	0250	0875	0000	%0298	G11	\$
005964	-02508	001896	0375	0750	0250	0625	0250	0750	0000	%0299	G12	\$
006115	-02248	000905	0375	0750	0375	0625	0250	0625	0000	%0300	G13	\$
006007	-01786	000030	0375	0750	0500	0625	0250	0500	0000	%0301	G14	\$
005937	-01502	-00690	0375	0750	0625	0625	0250	0375	0000	%0302	G15	\$
005871	-01188	-01336	0375	0750	0750	0625	0250	0250	0000	%0303	G16	\$
006935	-00765	-01771	0375	0750	0875	0625	0250	0125	0000	%0304	G17	\$
006273	-00458	-02072	0375	0750	1000	0625	0250	0000	0000	%0305	G18	\$
006984	-02893	004334	0375	0875	0000	0625	0125	1000	0000	%0306	H10	\$
006433	-03336	003190	0375	0875	0125	0625	0125	0875	0000	%0307	H11	\$
006407	-03270	002331	0375	0875	0250	0625	0125	0750	0000	%0308	H12	\$
006447	-03931	001426	0375	0875	0375	0625	0125	0625	0000	%0309	H13	\$
006417	-02577	000340	0375	0875	0500	0625	0125	0500	0000	%0310	H14	\$
006435	-02278	-00287	0375	0875	0625	0625	0125	0375	0000	%0311	H15	\$
006305	-01915	-01107	0375	0875	0750	0625	0125	0250	0000	%0312	H16	\$
006294	-01631	-01633	0375	0875	0875	0625	0125	0125	0000	%0313	H17	\$
006447	-01091	-02182	0375	0875	1000	0625	0125	0000	0000	%0314	H18	\$
006912	-04595	004881	0375	1000	0000	0625	0000	1000	0000	%0315	I10	\$
006835	-03949	003585	0375	1000	0125	0625	0000	0875	0000	%0316	I11	\$
006880	-03915	002853	0375	1000	0250	0625	0000	0750	0000	%0317	I12	\$
006973	-03704	001930	0375	1000	0375	0625	0000	0625	0000	%0318	I13	\$
006882	-03153	000614	0375	1000	0500	0625	0000	0500	0000	%0319	I14	\$
006810	-02845	-00002	0375	1000	0625	0000	0000	0375	0000	%0320	I15	\$
006723	-02525	-00768	0375	1000	0750	0625	0000	0250	0000	%0321	I16	\$
006733	-02194	-01421	0375	1000	0875	0625	0000	0125	0000	%0322	I17	\$
006806	-01900	-02131	0375	1000	1000	0625	0000	0000	0000	%0323	I18	\$
004751	002478	001732	0500	0000	0000	0500	1000	1000	0000	%0324	J10	\$
004784	002671	000951	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$
004762	002692	000932	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$
004821	002985	000183	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$
004573	003111	-01433	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$
004570	003098	-01428	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$
004377	003705	-01952	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$
004375	003705	-01952	0500	0000	0750	0500	1000	0250	0000	%0331	J17	\$
004120	003440	-02506	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$
004780	002338	002308	0500	0125	0000	0500	0875	1000	0000	%0333	K10	\$
004584	001518	001711	0500	0125	0125	0500	0875	0000	0000	%0334	K11	\$
004384	001493	000712	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$
004558	001941	000323	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$
004370	001866	-00636	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$
004461	002102	-01341	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$
004285	002870	-01876	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$
004260	002896	-01998	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$
004478	003024	-02399	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$
005331	001451	002688	0500	0250	0000	0500	0750	1000	0000	%0342	L10	\$
004584	001468	001744	0500	0250	0125	0500	0750	0875	0000	%0343	L11	\$
004445	001293	001156	0									

004812	003575	002389	0750	0000	0000	0250	0250	1000	1000	0000	0000	%0486	A19	\$
004737	003750	001737	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$		
004672	003776	001766	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$		
004624	003980	001044	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$		
004643	004303	0060310	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$		
004551	004459	-00324	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$		
004419	004797	-01340	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$		
004432	004768	-01350	0750	0000	0875	0250	1000	0000	0000	%0493	A26	\$		
003906	004475	-01379	0750	0000	0925	0250	1000	0000	0000	%0494	A27	\$		
004884	003511	003013	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$		
004789	003656	002383	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$		
004723	003819	001759	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$		
004678	003998	001058	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$		
004603	004025	001085	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$		
004598	004205	000460	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$		
004465	004533	-00327	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$		
004374	003751	-01223	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$		
004516	003835	-01756	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$		
005452	002513	003388	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$		
004888	002813	002744	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$		
004966	002880	002050	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$		
004975	002969	001418	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$		
004891	002999	000922	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$		
004775	003188	000233	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$		
004653	003381	-00376	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$		
004787	003380	-01199	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$		
005116	003180	-01511	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$		
006019	001606	003756	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$		
005380	001971	003021	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$		
005518	001954	002516	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$		
005579	002060	001629	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$		
005552	002133	001087	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$		
005431	002361	000337	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$		
005338	002483	-00166	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$		
005569	002353	-00964	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$		
005853	002290	-01266	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$		
006499	000848	004388	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$		
005932	001622	003825	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$		
005946	001257	003070	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$		
006117	001232	002151	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$		
006194	001326	001241	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$		
006156	001435	000552	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$		
006120	001611	-00057	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$		
006301	001524	-00775	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$		
006520	001763	-01121	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$		
007040	000081	005199	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$		
006459	000875	004416	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$		
006375	000388	003541	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$		
006551	000446	002650	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$		
006585	000593	001674	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$		
006728	000725	000677	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$		
006704	000878	000113	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$		
006952	001003	-00652	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$		
007063	001044	-01008	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$		
007576	-00540	005659	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$		
007210	-01002	004521	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$		
007050	-00750	004255	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$		
007137	-00517	003275	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$		
007208	-00414	002498	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$		
007217	-00276	001145	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$		
007257	000002	000214	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$		
007544	000233	-00416	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$		
007767	000442	-00903	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$		
008078	-01140	006222	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$		
007744	-01604	005608	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$		
007514	-01599	004692	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$		
007523	-01398	003788	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$		
007589	-01292	002742	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$		
007633	-01035	001541	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$		
007805	-00832	000669	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$		
007799	-00587	-00541	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$		
007880	-00221	-00886	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$		
007851	-02734	006711	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$		
007898	-02437	005389	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$		
007928	-02346	004653	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$		
008010	-02231	003859	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$		
008066	-02036	002977	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$		
008118	-01822	002029	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$		
008328	-01740	001084	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$		
008182	-01284	-00017	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$		
008120	-00853	-00989	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$		
004703	005423	003298	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$		
004647	005543	002571	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$		
004568	005755	001865	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$		
004536	005760	001884	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$		
004487	005948	001170	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$		
004623	006423	000580	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$		
004575	006487	-01006	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$		
004611	005131	-01051	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$		
004377	005181	-01523	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$		
004888	003790	003194	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$		
004884	003942	002751	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$		
004831	004140	002122	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$		
004839	004251	001567	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$		
004772	004347	001121	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$		
004770	004422	000574	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$		
004716	004643	000015	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$		
004759	004613	-00638	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$		
004911	004510	-01362	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$		
005237	003079	003407	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$		
005371	003037	003143	0875	0250	0125	0125	0750	0875	0000	%0586	L20	\$		
005426	003280	002316	0875	0250	0									

006965	-008088	000200	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
008904	-00564	-00589	0875	1000	1000	00125	0000	0000	0000	%0730	b02	\$
008314	-00775	-00903	0750	1000	1000	00250	0000	0000	0000	%0731	b03	\$
007811	-01067	-01213	0625	1000	1000	00375	0000	0000	0000	%0732	b04	\$
007392	-01580	-01541	0500	1000	1000	00500	0000	0000	0000	%0733	b05	\$
006875	-01867	-02210	0375	1000	1000	00625	0000	0000	0000	%0734	b06	\$
006306	-02330	-02744	0250	1000	1000	00750	0000	0000	0000	%0735	b07	\$
005869	-02516	-03000	0125	1000	1000	00875	0000	0000	0000	%0736	b08	\$
005508	-02814	-03522	0000	1000	1000	00900	0000	0000	0000	%0737	b09	\$
008755	-006669	000527	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
008367	-00667	000604	0875	0875	0875	00125	0125	0125	0000	%0739	c02	\$
008025	-00501	-00519	0750	0875	0875	00250	0125	0125	0000	%0740	c03	\$
007246	-00792	-00888	0625	0875	0875	00375	0125	0125	0000	%0741	c04	\$
006773	-01069	-01339	0500	0875	0875	00500	0125	0125	0000	%0742	c05	\$
006298	-01580	-01675	0375	0875	0875	00625	0125	0125	0000	%0743	c06	\$
005792	-01861	-02228	0250	0875	0875	00750	0125	0125	0000	%0744	c07	\$
005551	-01979	-02372	0125	0875	0875	00875	0125	0125	0000	%0745	c08	\$
005499	-02717	-03048	0000	0875	0875	00900	0125	0125	0000	%0746	c09	\$
008340	001227	001091	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
007906	000602	004050	0875	0750	0750	00125	0250	0250	0000	%0748	d02	\$
007494	-00002	000129	0750	0750	0750	00250	0250	0250	0000	%0749	d03	\$
006878	-00359	-00296	0625	0750	0750	00375	0250	0250	0000	%0750	d04	\$
006333	-00694	-00921	0500	0750	0750	00500	0250	0250	0000	%0751	d05	\$
005897	-01107	-01361	0375	0750	0750	00625	0250	0250	0000	%0752	d06	\$
005431	-01494	-01697	0250	0750	0750	00750	0250	0250	0000	%0753	d07	\$
005223	-01466	-01970	0125	0750	0750	00875	0250	0250	0000	%0754	d08	\$
005530	-01766	-02367	0000	0750	0750	00900	0250	0250	0000	%0755	d09	\$
007812	001939	001491	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007318	001251	000852	0875	0625	0625	00125	0375	0375	0000	%0757	e02	\$
006915	000641	000593	0750	0625	0625	00250	0375	0375	0000	%0758	e03	\$
006420	-00024	-00079	0625	0625	0625	00375	0375	0375	0000	%0759	e04	\$
005970	-00302	-00334	0500	0625	0625	00500	0375	0375	0000	%0760	e05	\$
005536	-00840	-00810	0375	0625	0625	00625	0375	0375	0000	%0761	e06	\$
005002	-01124	-01416	0250	0625	0625	00750	0375	0375	0000	%0762	e07	\$
004787	-01169	-01637	0125	0625	0625	00875	0375	0375	0000	%0763	e08	\$
004711	-01130	-01588	0000	0625	0625	00900	0375	0375	0000	%0764	e09	\$
007307	002532	001977	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006771	001893	001490	0875	0500	0500	00125	0500	0500	0000	%0766	f02	\$
006297	001247	001123	0750	0500	0500	00250	0500	0500	0000	%0767	f03	\$
005790	000711	000578	0625	0500	0500	00375	0500	0500	0000	%0768	f04	\$
005307	-00022	-00080	0500	0500	0500	00500	0500	0500	0000	%0769	f05	\$
005082	-00368	-00434	0375	0500	0500	00625	0500	0500	0000	%0770	f06	\$
004567	-00778	-00985	0250	0500	0500	00750	0500	0500	0000	%0771	f07	\$
004251	-01056	-01054	0125	0500	0500	00875	0500	0500	0000	%0772	f08	\$
004078	-00731	-00808	0000	0500	0500	00900	0500	0500	0000	%0773	f09	\$
006557	003663	002326	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
005505	002776	001748	0875	0375	0375	00125	0625	0625	0000	%0775	g02	\$
005921	002093	001499	0750	0375	0375	00250	0625	0625	0000	%0776	g03	\$
005073	001404	001137	0625	0375	0375	00375	0625	0625	0000	%0777	g04	\$
004760	000726	000567	0500	0375	0375	00500	0625	0625	0000	%0778	g05	\$
004465	-00007	-00019	0375	0375	0375	00625	0625	0625	0000	%0779	g06	\$
004189	-00327	-00438	0250	0375	0375	00750	0625	0625	0000	%0780	g07	\$
003824	-00590	-01010	0125	0375	0375	00875	0625	0625	0000	%0781	g08	\$
003817	-00590	-01026	0000	0375	0375	00900	0625	0625	0000	%0782	g09	\$
006034	004296	003204	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005310	003339	003111	0875	0250	0250	00125	0750	0750	0000	%0784	h02	\$
004817	002870	002026	0750	0250	0250	00250	0750	0750	0000	%0785	h03	\$
004468	002416	001440	0625	0250	0250	00375	0750	0750	0000	%0786	h04	\$
004234	001272	001153	0500	0250	0250	00500	0750	0750	0000	%0787	h05	\$
004017	000670	000535	0375	0250	0250	00625	0750	0750	0000	%0788	h06	\$
003645	000010	000080	0250	0250	0250	00750	0750	0750	0000	%0789	h07	\$
003079	-00207	-00279	0125	0250	0250	00875	0750	0750	0000	%0790	h08	\$
002549	-00932	-00113	0000	0250	0250	00900	0750	0750	0000	%0791	h09	\$
005274	005112	003618	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004771	003820	002797	0875	0125	0125	00125	0875	0875	0000	%0793	i02	\$
004699	003622	002484	0750	0125	0125	00250	0875	0875	0000	%0794	i03	\$
004563	002494	001753	0625	0125	0125	00375	0875	0875	0000	%0795	i04	\$
004353	001529	001717	0500	0125	0125	00500	0875	0875	0000	%0796	i05	\$
003862	000757	000823	0375	0125	0125	00625	0875	0875	0000	%0797	i06	\$
003350	000381	000463	0250	0125	0125	00750	0875	0875	0000	%0798	i07	\$
002823	000021	000054	0125	0125	0125	00875	0875	0875	0000	%0799	i08	\$
002328	000018	000046	0000	0125	0125	00900	0875	0875	0000	%0800	i09	\$
004592	005497	003935	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
004595	005421	003410	0875	0000	0000	00125	1000	1000	0000	%0802	j02	\$
004641	003608	002412	0750	0000	0000	00250	1000	1000	0000	%0803	j03	\$
004709	003527	002399	0625	0000	0000	00375	1000	1000	0000	%0804	j04	\$
004580	002505	001666	0500	0000	0000	00500	1000	1000	0000	%0805	j05	\$
003816	000871	000763	0375	0000	0000	00625	1000	1000	0000	%0806	j06	\$
003031	000359	000359	0250	0000	0000	00750	1000	1000	0000	%0807	j07	\$
002117	000171	000129	0125	0000	0000	00875	1000	1000	0000	%0808	j08	\$
002456	000049	000237	0000	0000	0000	00900	1000	1000	0000	%0809	j09	\$
009704	-000888	000196	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
008688	000168	-00355	0875	0875	0875	00125	0125	0125	0000	%0811	b11	\$
008122	000352	-00821	0750	0750	0750	00250	0250	0250	0000	%0812	b12	\$
007201	000619	-01144	0625	0625	0625	00375	0375	0375	0000	%0813	b13	\$
006418	000974	-01618	0500	0500	0500	00500	0500	0500	0000	%0814	b14	\$
005682	001100	-02201	0375	0375	0375	00625	0625	0625	0000	%0815	b15	\$
004931	001524	-02800	0250	0250	0250	00750	0750	0750	0000	%0816	b16	\$
004022	001025	-04139	0125	0250	0250	00875	0875	0875	0000	%0817	b17	\$
003333	002497	-04139	0000	1000	1000	00900	1000	1000	0000	%0818	b18	\$
009478	-00171	000804	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$
008542	-00060	000182	0875	0875	0875	00125	0125	0125	0000	%0820	c11	\$
007926	000173	-00348	0750	0750	0750	00250	0250	0125	0000	%0821	c12	\$
006985	000441	-00795	0625	0625	0875	00375	0375	0125	0000	%0822	c13	\$
006242	000727	-01280	0500	0500	0875	00500	0500	0125	0000	%0823	c14	\$
005404	001082	-01778	0375	0375	0875	00625	0625	0125	0000	%0824	c15	\$
004503	001266	-02451	0250	0250	0875	00750	0750	0125	0000	%0825	c16	\$
004100	001722	-02650	0125	0125	0875	00875	0875	0125	0000	%0826	c17	\$
003720	002226	-04024	0000	0000	0875	00900	0900	0125	0000	%0827	c18	\$
009307	-00160	001612	1000	1000	0750	0000	0250	0000	0000	%0828	d10	\$
008580	-00											

%BEG GE63_22.TXT, Separation cmyn4*, cfi=0.90, D65, not adapted \$
%100 x LAB* %1000 x (r g b c m y 0) %nr. pos \$
%z004715 005416 003856 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008679 -01295 007727 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005830 -06387 003519 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005483 -02831 -03530 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z003398 002603 -04154 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z004545 006506 -01091 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001266 000030 000100 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009642 -00086 000207 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004592 005497 003935 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008693 -01313 007623 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005820 -06337 003454 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005508 -02814 -03522 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003332 002497 -04189 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z004590 006530 -01064 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z001116 000054 000121 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009691 -00090 000201 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/GE73/GE73L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG GE63.22.TXT, Separation cmyn4*, cfi=0.90, D65, not adapted S
%100 x LAB*      1000 x (r g b   c m y 0)   %nrr. pos $
0001169 000030 000120 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
0002502 000007 000089 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
0003405 000007 000108 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
0004268 -00001 000124 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
0005225 -00008 000103 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
0006388 -00014 000095 0625 0625 0625 0625 0375 0375 0000 %0977 k06 $
0007523 000009 000132 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
0008522 -00053 000175 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
0009794 -00079 000195 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
0011150 000028 000124 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
0002437 000011 000065 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
0003406 000003 000102 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
0004272 -00003 000123 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
0005225 -00011 000088 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
0006381 -00017 000082 0625 0625 0625 0625 0375 0375 0000 %0986 l06 $
0007545 -00013 000134 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
0008504 -00055 000174 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
0009696 -00085 000190 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
0011178 000037 000113 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
0002557 000015 000082 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
0003454 000003 000086 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
0004324 -00012 000118 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
0005245 -00010 000092 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
0006395 -00024 000086 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
0007544 -00013 000136 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
0008550 -00059 000185 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
0009711 -00091 000200 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
0011166 000030 000117 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
0002517 000009 000096 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
0003449 000018 000097 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
0004353 -00006 000130 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
0005250 -00014 000102 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
0006440 -00022 000095 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
0007525 000000 000135 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
0008499 000056 000185 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
0009708 -00084 000183 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
0011214 000043 000113 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
0002492 000023 000039 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
0002757 000017 000049 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
0003109 000020 000059 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
0003844 -00008 000079 0266 0266 0266 0333 0333 0333 0000 %1012 k14 $
0004266 000024 000061 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
0004523 -00014 000174 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
0005198 000016 000071 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
0005528 -00013 000205 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
0006225 -00036 000126 0600 0600 0600 0400 0400 0400 0000 %1017 k19 $
0006656 -00048 000286 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
0007236 -00035 000140 0734 0734 0734 0266 0266 0266 0000 %1019 k21 $
0007903 -00040 000166 0800 0800 0800 0200 0200 0200 0000 %1020 k22 $
0008346 -00045 000185 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
0008690 -00055 000190 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
0009640 -00072 000180 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
0011307 000042 000100 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
0002485 000018 000049 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
0002728 000015 000038 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
0003077 000022 000052 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
0003849 -00012 000078 0266 0266 0266 0333 0333 0333 0000 %1028 l14 $
0004271 000023 000059 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
0004532 -00009 000147 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
0005215 000014 000046 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
0005538 000005 000157 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
0006197 -00018 000086 0600 0600 0600 0400 0400 0400 0000 %1033 l19 $
0006617 -00019 000208 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
0007258 -00031 000119 0734 0734 0734 0266 0266 0266 0000 %1035 l21 $
0007907 -00037 000158 0800 0800 0800 0200 0200 0200 0000 %1036 l22 $
0008359 -00048 000176 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
0008717 -00058 000190 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
0009646 -00073 000182 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
0011291 000044 000100 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
0002543 000018 000050 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
0002766 000020 000034 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
0003125 000023 000047 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
0003890 -00005 000061 0266 0266 0266 0333 0333 0333 0000 %1044 m14 $
0004330 000015 000060 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
0004607 -00012 000151 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
0005229 000012 000058 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
0005529 -00002 000178 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
0006227 -00025 000093 0600 0600 0600 0400 0400 0400 0000 %1049 m19 $
0006656 -00022 000216 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
0007264 -00033 000125 0734 0734 0734 0266 0266 0266 0000 %1051 m21 $
0007902 -00040 000158 0800 0800 0800 0200 0200 0200 0000 %1052 m22 $
```

%BEG GE63.22.TXT, Separation cmydn4*, cfi=0.90, D65, adapted S																						
%100 x LAB*a																						
1000 x (r g b c m y o)																						
nmr. pos \$																						
%001266	%000000	%000000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%002237	%000148	%000191	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00081	J01	\$
%002258	%000134	-%003222	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%002375	%000321	-%000519	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00812	J02	\$
%002548	%000230	-%005448	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%002448	%000337	-%002719	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00803	J03	\$
%003268	%000291	-%001330	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%002888	%000634	-%010009	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00804	J04	\$
%003347	%000302	-%012222	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%003719	%000625	-%012511	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00805	J05	\$
%004123	%001188	-%021444	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004038	%001189	-%022411	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00806	J06	\$
%004095	%001273	-%029667	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%003920	%002265	-%034337	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00807	J07	\$
%003772	%002261	-%041619	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%003960	%002253	-%033934	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00808	J08	\$
%003398	%002602	-%042882	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%003803	%002945	-%038447	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	J09	\$
%002449	-%00112	%000288	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%002398	-%00112	%000281	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	K01	\$
%002123	-%00001	%000108	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%002490	%000000	-%000118	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	K02	\$
%002560	%000229	-%005660	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%002910	%000344	-%000512	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	K03	\$
%003257	%000294	-%013644	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%003190	%000391	-%011004	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	K04	\$
%003356	%000285	-%013566	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%003487	%000366	-%015099	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	K05	\$
%003785	%000371	-%020339	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004130	%001124	-%021717	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	K06	\$
%004114	%001255	-%029911	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004112	%001160	-%021933	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	K07	\$
%004138	%001276	-%029668	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004143	%001735	-%027446	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	K08	\$
%003668	%001702	-%044534	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004005	%001949	-%035227	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	K09	\$
%002989	-%00276	%000404	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%003727	-%00343	%000805	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L01	\$
%002597	-%00238	%000149	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%003026	-%00303	%000138	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L02	\$
%002445	-%00047	-%002000	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%002905	-%00216	-%00391	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L03	\$
%003530	-%00183	-%01257	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%003349	-%00137	-%01071	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L04	\$
%003416	%000250	-%01379	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%003558	%000059	-%015096	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L05	\$
%003788	%000307	-%020667	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004093	%000456	-%01025	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L06	\$
%003984	%000480	-%02256	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004059	%000733	-%015230	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L07	\$
%004441	%000573	-%035229	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004449	%001079	-%020409	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L08	\$
%004330	%001040	-%042559	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004661	%001184	-%024224	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L09	\$
%004280	-%01497	%000481	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%005029	%001458	-%02853	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L10	\$
%003697	-%00787	%000166	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004667	-%00850	%001408	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L11	\$
%003779	-%00727	%000381	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004633	-%00802	%001370	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L12	\$
%003745	-%00615	-%01176	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004200	-%00706	%000251	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L13	\$
%004026	-%00705	-%01365	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004140	-%00313	-%00561	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L14	\$
%004045	-%00135	-%01919	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004500	-%00187	-%01055	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L15	\$
%004406	%000052	-%02422	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004516	%000057	-%01562	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L16	\$
%004687	-%00186	-%03445	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004650	%000454	-%02018	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L17	\$
%004626	%000146	-%04406	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004787	%000720	-%02523	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L18	\$
%004763	-%02472	%000938	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%005183	%000865	-%02822	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L19	\$
%004825	-%02250	%000168	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%005173	-%01151	%00173	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L20	\$
%004361	-%01478	-%00253	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004611	-%01195	%000956	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L21	\$
%004249	-%01277	-%01140	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004636	-%01426	%000686	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L22	\$
%003973	-%00776	-%01082	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004655	-%01007	-%00344	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L23	\$
%004370	-%00675	-%01885	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004531	-%00734	-%01092	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L24	\$
%004649	-%00495	-%02407	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004731	-%00405	-%01513	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L25	\$
%004623	-%00140	-%03502	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%004853	-%00216	-%02026	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L26	\$
%004675	-%00140	-%03465	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%005009	%000087	-%02533	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L27	\$
%005214	-%03305	%001531	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%005324	%000358	-%02777	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L28	\$
%004763	-%02501	%000907	%0000	%0000	%0000	%0000	%0000	%0000	%0000	%005557	-%02833	%002122	%0125	%0000	%0000	%0085	%0000	%0000	%0000	%00809	L29	\$
%004878	-%02286	%000173	%0000	%0000	%0000	%0000	%0000	%00000														

003928	000851	000692	0375	0000	0000	00625	1000	1000	0000	%0243	A10	\$
003932	001110	000109	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$
003812	001043	-00028	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$
004157	001474	-00311	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$
004219	001612	-00935	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$
004298	002808	-01959	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$
004244	002808	-01990	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$
004153	003264	-02514	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$
003914	003638	-03512	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$
004033	000833	000755	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$
004013	000776	000625	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$
003925	001075	000072	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$
003934	000992	-00552	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$
004160	001310	-01100	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$
004298	001664	-01042	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$
004137	002305	-02412	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$
004171	002390	-02455	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$
004318	002722	-02981	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$
004601	000329	001358	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$
004063	000765	000798	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$
004126	000676	000461	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$
004130	000749	-00102	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$
004140	000860	-00815	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$
004408	001135	-01302	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$
004529	001653	-01827	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$
004667	001800	-02302	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$
004996	002085	-02679	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$
005070	-00772	001515	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$
004955	-00121	001457	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$
004655	-00269	000960	0375	0375	0250	0625	0625	0750	0000	%0272	D12	\$
004580	-000003	-00041	0375	0375	0375	0625	0625	0625	0000	%0273	D13	\$
004809	000261	-00469	0375	0375	0500	0625	0625	0500	0000	%0274	D14	\$
005005	000530	-01009	0375	0375	0625	0625	0625	0375	0000	%0275	D15	\$
005264	000782	-01452	0375	0375	0750	0625	0625	0250	0000	%0276	D16	\$
005429	001131	-01918	0375	0375	0875	0625	0625	0125	0000	%0277	D17	\$
005615	001187	-02391	0375	0375	1000	0625	0625	0000	0000	%0278	D18	\$
005767	-01612	001932	0375	0500	0000	0625	0500	1000	0000	%0279	D19	\$
005299	-01847	001501	0375	0500	0125	0625	0500	0875	0000	%0280	E11	\$
005322	-00967	001130	0375	0500	0250	0625	0500	0750	0000	%0281	E12	\$
005270	-00731	000142	0375	0500	0375	0625	0500	0625	0000	%0282	E13	\$
005106	-00360	-00586	0375	0500	0500	0625	0500	0500	0000	%0283	E14	\$
005384	-00087	-01171	0375	0500	0625	0625	0500	0375	0000	%0284	E15	\$
005471	000122	-01503	0375	0500	0750	0625	0500	0250	0000	%0285	E16	\$
005639	000360	-01952	0375	0500	0875	0625	0500	0125	0000	%0286	E17	\$
005862	000646	-02324	0375	0500	1000	0625	0500	0000	0000	%0287	E18	\$
006085	-02324	002537	0375	0625	0000	0625	0375	1000	0000	%0288	F10	\$
005769	-01629	001911	0375	0625	0125	0625	0375	0875	0000	%0289	F11	\$
005647	-01617	001309	0375	0625	0250	0625	0375	0750	0000	%0290	F12	\$
005701	-01422	000600	0375	0625	0375	0625	0375	0625	0000	%0291	F13	\$
005632	-01005	-00395	0375	0625	0500	0625	0375	0500	0000	%0292	F14	\$
005554	-00847	-00965	0375	0625	0625	0625	0375	0375	0000	%0293	F15	\$
005667	-00447	-01538	0375	0625	0750	0625	0375	0250	0000	%0294	F16	\$
005797	-00142	-02047	0375	0625	0875	0625	0375	0125	0000	%0295	F17	\$
005696	000011	-02271	0375	0625	1000	0625	0375	0000	0000	%0296	F18	\$
006439	-03194	002978	0375	0750	0000	0625	0250	1000	0000	%0297	G10	\$
006106	-02374	002467	0375	0750	0125	0625	0250	0875	0000	%0298	G11	\$
005964	-02541	001736	0375	0750	0250	0625	0250	0750	0000	%0299	G12	\$
006115	-02231	000832	0375	0750	0375	0625	0250	0500	0000	%0300	G13	\$
006007	-01750	00130	0375	0750	0500	0625	0250	0500	0000	%0301	G14	\$
005937	-01467	-00850	0375	0750	0625	0250	0250	0375	0000	%0302	G15	\$
005871	-01155	-01496	0375	0750	0750	0625	0250	0250	0000	%0303	G16	\$
006035	-00729	-01932	0375	0750	0875	0625	0250	0125	0000	%0304	G17	\$
006273	-00419	-02237	0375	0750	1000	0625	0250	0000	0000	%0305	G18	\$
006984	-02844	-004160	0375	0875	0000	0625	0125	1000	0000	%0306	H10	\$
006433	-03294	003023	0375	0875	0125	0625	0125	0875	0000	%0307	H11	\$
006407	-03229	002165	0375	0875	0250	0625	0125	0750	0000	%0308	H12	\$
006447	-02989	001259	0375	0875	0375	0625	0125	0625	0000	%0309	H13	\$
006417	-02535	000173	0375	0875	0500	0625	0125	0500	0000	%0310	H14	\$
006435	-02237	-00453	0375	0875	0625	0625	0125	0375	0000	%0311	H15	\$
006305	-01875	-01272	0375	0875	0750	0625	0125	0250	0000	%0312	H16	\$
006294	-01591	-01798	0375	0875	0875	0625	0125	0125	0000	%0313	H17	\$
006447	-01049	-02349	0375	0875	1000	0625	0125	0000	0000	%0314	H18	\$
006912	-04547	-004708	0375	1000	0000	0625	0000	1000	0000	%0315	I10	\$
006835	-03902	-003413	0375	1000	0125	0625	0000	0875	0000	%0316	I11	\$
006880	-03867	-002680	0375	1000	0250	0625	0000	0750	0000	%0317	I12	\$
006973	-03655	-001756	0375	1000	0375	0625	0000	0625	0000	%0318	I13	\$
006882	-03105	-000442	0375	1000	0500	0625	0000	0500	0000	%0319	I14	\$
006810	-02798	-00173	0375	1000	0625	0000	0000	0250	0000	%0320	I15	\$
006723	-02479	-00938	0375	1000	0750	0625	0000	0250	0000	%0321	I16	\$
006733	-02148	-01592	0375	1000	0875	0625	0000	0125	0000	%0322	I17	\$
006806	-01853	-02303	0375	1000	1000	0625	0000	0000	0000	%0323	I18	\$
004751	002496	0001586	0500	0000	0000	0500	1000	1000	0000	%0324	J10	\$
004784	002690	000805	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$
004762	002711	000786	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$
004821	003005	000037	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$
004573	003126	-01576	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$
004570	003113	-01571	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$
004377	003718	-02092	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$
004378	003736	-02098	0500	0000	0875	0500	1000	0125	0000	%0331	J17	\$
004120	003966	-02644	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$
004780	002357	002162	0500	0125	0000	0500	0875	1000	0000	%0333	K10	\$
004584	001534	001568	0500	0125	0125	0500	0875	0875	0000	%0334	K11	\$
004384	001507	000572	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$
004558	001956	000180	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$
004370	001879	-00776	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$
004461	002117	-01482	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$
004285	002882	-02016	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$
004260	002907	-02137	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$
004478	003038	-02541	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$
005331	001478	002535	0500	0250	0000	0500	0750	1000	0000	%0342	L10	\$
004584	001484	001601	0500	0250	0125	0500	0750	0875	0000	%0343	L11	\$
004445	001307	001014	0									

004812	003594	002243	0750	0000	0000	0250	0000	1000	1000	0000	0000	%0486	A19	\$
004737	003768	001592	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$		
004672	003793	001621	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$		
004624	003997	000900	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$		
004643	004320	000166	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$		
004551	004474	-00467	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$		
004419	004810	-01481	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$		
004432	004782	-01492	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$		
003906	004483	-02115	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$		
004884	003531	002866	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$		
004789	003675	002237	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$		
004723	003837	001614	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$		
004678	004015	000913	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$		
004603	004041	000941	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$		
004598	004221	000317	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$		
004465	004547	-00468	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$		
004374	003764	-01363	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$		
004516	003850	-01898	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$		
005452	002541	003234	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$		
004888	002833	002597	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$		
004966	002901	001902	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$		
004975	002991	001270	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$		
004891	003020	000775	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$		
004775	003207	000088	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$		
004653	003398	-00520	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$		
004787	003399	-01344	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$		
005116	003203	-01661	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$		
006019	001642	003594	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$		
005380	001998	002867	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$		
005518	001983	002361	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$		
005579	002089	001473	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$		
005552	002162	000931	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$		
005431	002308	000193	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$		
005338	002510	00319	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$		
005569	002383	-01120	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$		
005853	002324	-01425	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$		
006499	000891	004221	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$		
005932	001657	003665	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$		
005946	001292	002910	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$		
006117	001270	001989	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$		
006194	001364	001077	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$		
006156	001473	000389	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$		
006120	001648	-00220	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$		
006301	001563	-00940	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$		
006520	001805	-01289	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$		
007040	000131	005015	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$		
006459	000917	004249	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$		
006375	000429	003375	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$		
006551	000489	002482	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$		
006585	000636	001506	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$		
006728	000771	000507	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$		
006704	000923	-00056	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$		
006952	001052	-00825	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$		
007063	001094	-01182	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$		
007516	-00483	005478	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$		
007210	-00950	004344	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$		
007050	-00609	004079	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$		
007137	-00466	003900	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$		
007208	-00361	002321	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$		
007217	-00224	000968	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$		
007257	-00056	000037	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$		
007544	-000290	-00597	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$		
007767	-000502	-01087	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$		
008078	-01076	006035	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$		
007744	-01544	005424	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$		
007514	-01542	004512	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$		
007523	-01341	003607	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$		
007589	-01234	002561	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$		
007633	-00977	001359	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$		
007805	-00771	0004084	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$		
007799	-00527	-00726	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$		
007880	-00159	-01071	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$		
007851	-02673	006527	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$		
007898	-02375	005204	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$		
007928	-02283	004467	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$		
008010	-02168	003672	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$		
008066	-01972	002790	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$		
008118	-01757	001841	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$		
008328	-01672	000893	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$		
008182	-01218	-00206	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$		
008120	-00788	-01177	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$		
004703	005441	003153	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$		
004647	005559	002427	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$		
004568	005770	001722	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$		
004536	005775	001741	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$		
004487	005962	001828	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$		
004623	006460	000436	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$		
004575	006863	-00249	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$		
004611	005146	-01193	0875	0000	1000	0125	1000	0125	0000	%0574	J26	\$		
004370	005194	-01569	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$		
004888	003810	003047	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$		
004884	003963	002604	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$		
004831	004160	001975	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$		
004839	004271	001420	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$		
004772	004365	000975	0875	0125	0500	0125	08							

009665	000001	-00001	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009894	-00487	-00783	0875	1000	1000	0000	0125	0000	0000	%0730	b02	\$
008314	-00708	-01092	0750	1000	1000	0000	0250	0000	0000	%0731	b03	\$
007811	-01009	-01397	0625	1000	1000	0000	0375	0000	0000	%0732	b04	\$
007392	-01528	-01721	0500	1000	1000	0000	0500	0000	0000	%0733	b05	\$
006875	-01824	-02295	0375	1000	1000	0000	0625	0000	0000	%0734	b06	\$
006306	-02297	-02914	0250	1000	1000	0000	0750	0000	0000	%0735	b07	\$
005868	-02491	-03247	0125	1000	1000	0000	0875	0000	0000	%0736	b08	\$
005608	-02705	-03684	0000	1000	1000	0000	1000	0000	0000	%0737	b09	\$
008755	000743	000334	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
008367	000000	000015	0875	0875	0875	0000	0125	0125	0000	%0739	c02	\$
008025	-00439	-00705	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
007246	-00743	-01067	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
006773	-01028	-01514	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
006298	-01547	-01845	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
005792	-01836	-02393	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005551	-01958	-02535	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
005499	-02697	-03711	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008340	001295	000902	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
007906	000662	000265	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
007494	000050	-00052	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
006878	-00316	-00472	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
006333	-00660	-01092	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
005897	-01081	-01528	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
005431	-01476	-01860	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005223	-01451	-02130	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
005530	-01746	-02530	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007812	001998	001307	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007318	001301	000673	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
006915	000085	000407	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006420	000018	-00092	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
005970	-00354	-00591	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
005636	-00920	-00973	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
005002	-01113	-01575	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
004787	-01161	-01793	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004711	-01124	-01743	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007307	002582	001797	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006721	001933	001306	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006297	001279	000953	0750	0500	0500	0250	0500	0500	0000	%0767	f03	\$
005790	000735	000413	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005307	-00006	-00080	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005082	-00356	-00593	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
004567	-00774	-01139	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004251	-01058	-01205	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
004078	-00736	-01048	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006557	003701	002154	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
005905	002803	001581	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005521	002113	001336	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005073	001416	000978	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004760	000733	000411	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
004465	-00005	-00033	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004189	-00330	-00588	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
003824	-00599	-01157	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003817	-00599	-01173	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
006034	004325	003036	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005310	003355	002150	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
004817	001278	001069	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
004468	002148	001206	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
004234	001707	001082	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
004017	000665	000386	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
003645	-00001	-00064	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
003079	-00228	-00419	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
002549	-00962	-00248	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
005274	005128	003458	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004771	003827	002641	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
004699	003627	002329	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
004563	002498	001599	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
004353	001529	001565	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
003862	000749	000675	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
003350	000364	000320	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
002823	-00004	-00082	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
002328	-00015	-00086	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
004592	005501	003781	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
004595	005425	003256	0875	0000	0000	0125	1000	1000	0000	%0802	j02	\$
004641	003613	002257	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
004709	003533	002244	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
004580	002509	001512	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
003816	000862	000616	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
003031	000328	000219	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
002117	000138	000105	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
002456	-00004	-000005	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009704	000001	-00005	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
008688	000242	-00547	0875	0875	0875	0100	0125	0125	0000	%0811	b11	\$
008122	000416	-01008	0750	0750	0750	0250	0250	0250	0000	%0812	b12	\$
007201	000667	-01322	0625	0625	0625	0375	0375	0375	0000	%0813	b13	\$
006418	001009	-01789	0500	0500	0500	0500	0500	0500	0000	%0814	b14	\$
005682	001123	-02366	0375	0375	0375	0625	0625	0625	0000	%0815	b15	\$
004931	001534	-03037	0250	0250	0250	0750	0750	0750	0000	%0816	b16	\$
004022	001020	-03592	0125	0250	0250	0875	0875	0875	0000	%0817	b17	\$
003333	002479	-04332	0000	1000	1000	1000	1000	1000	0000	%0818	b18	\$
009478	-00004	-00604	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$
008542	000010	-00008	0875	0875	0875	0125	0125	0125	0000	%0820	c11	\$
007926	000233	-00533	0750	0750	0750	0250	0250	0125	0000	%0821	c12	\$
006985	000485	-00972	0625	0625	0625	0375	0375	0125	0000	%0822	c13	\$
006242	000759	-01449	0500	0500	0500	0500	0125	0000	0000	%0823	c14	\$
005404	001100	-01940	0375	0375	0375	0625	0625	0125	0000	%0824	c15	\$
004503	001268	-02604	0250	0250	0250	0750	0750	0125	0000	%0825	c16	\$
004100	001718	-02800	0125	0125	0125	0875	0875	0125	0000	%0826	c17	\$
003720	002216	-04170	0000	0000	0750	1000	1000	0125	0000	%0827	c18	\$
009307	-00077	-001414	1000	1000	1000	0500	0000	0250	0000	%0828	d10	\$
008580	-00090	-00093	0750	0875	0750	0125	0125	0250	0000	%0829	d11	

%BEG GE63_22.TXT, Separation cmyn4*, cfi=0.90, D65, adapted \$
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos \$
%z004715 005433 003711 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008679 -01222 007532 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005830 -06354 003360 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005483 -02802 -03685 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z003398 002602 -04282 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z004545 006521 -01234 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001266 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009642 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004592 005501 003781 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008693 -01240 007431 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005820 -06312 003288 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005508 -02795 -03684 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003332 002479 -04332 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z004590 006534 -01218 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z001116 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009691 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/GE73/GE73L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

%BEG GE63.22.TXT, Separation cmy4*, cfi=0.90, D65, adapted S		%100 x LAB*a		1000 x (r g b c m y 0)		%nrr. pos \$																					
0001169	-00021	000036	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$	0008386	000011	000000	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$		
0002502	-00024	-00012	0125	0125	0125	0875	0875	0875	0875	0000	%0973	k02	\$	0008701	000007	000007	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$	
0003405	-00009	-00006	0250	0250	0250	0750	0750	0750	0750	0000	%0974	k03	\$	0009636	000000	-00002	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$	
0004268	-00004	-00002	0375	0375	0375	0625	0625	0625	0625	0000	%0975	k04	\$	001236	-00011	000028	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$	
0005225	000004	-00036	0500	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	002518	-00006	-00044	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$	
0006388	000016	-00061	0625	0625	0625	0625	0625	0625	0625	0000	%0977	k06	\$	002768	-00005	-00045	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$	
0007523	000058	-00040	0750	0750	0750	0250	0250	0250	0000	0000	%0978	k07	\$	003151	000003	-00049	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$	
0008522	000012	-00011	0875	0875	0875	0125	0125	0125	0000	0000	%0979	k08	\$	003909	-00023	-00028	0266	0266	0266	0333	0333	0333	0000	%1060	n14	\$	
0009794	000004	-00017	1000	1000	1000	1000	1000	1000	1000	0000	%0980	k09	\$	004337	000018	-00054	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$	
0011150	-00024	000041	0000	0000	0000	1000	1000	1000	1000	0000	%0981	l01	\$	004562	-00014	000067	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$	
002437	-00020	-00036	0125	0125	0125	0875	0875	0875	0875	0000	%0982	l02	\$	005235	000025	-00050	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$	
003406	-00016	-00012	0250	0250	0250	0750	0750	0750	0750	0000	%0983	l03	\$	005571	000024	000039	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$	
004272	-00006	-00004	0375	0375	0375	0625	0625	0625	0625	0000	%0984	l04	\$	006257	-00002	-00032	0600	0600	0600	0400	0400	0400	0000	%1065	n19	\$	
005225	000000	-00052	0500	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	006651	000009	000072	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$	
006381	000013	-00074	0625	0625	0625	0625	0625	0625	0625	0000	%0986	l06	\$	007248	000007	-00030	0734	0734	0734	0266	0266	0266	0000	%1067	n21	\$	
007545	000036	-00038	0750	0750	0750	0250	0250	0250	0000	0000	%0987	l07	\$	007902	000013	-00011	0800	0800	0800	0200	0200	0200	0000	%1068	n22	\$	
008504	000009	-00012	0875	0875	0875	0125	0125	0125	0000	0000	%0988	l08	\$	008337	000011	000006	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$	
009696	000000	-00012	1000	1000	1000	1000	1000	1000	1000	0000	%0989	l09	\$	008698	000013	000006	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$	
001178	-00015	000029	0000	0000	0000	1000	1000	1000	1000	0000	%0990	m01	\$	009655	000001	-00017	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$	
002557	-00014	-00020	0125	0125	0125	0875	0875	0875	0875	0000	%0991	m02	\$	001099	000000	000000	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$	
003454	-00012	-00029	0250	0250	0250	0750	0750	0750	0750	0000	%0992	m03	\$	009611	000000	000000	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$	
004324	-00014	-00009	0375	0375	0375	0625	0625	0625	0625	0000	%0993	m04	\$	004558	005404	003851	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$	
005245	000002	-00047	0500	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$	005389	-03046	-03510	0000	1000	1000	0000	0000	0000	0000	%1075	l27	\$	
006395	000007	-00070	0625	0625	0625	0375	0375	0375	0375	0000	%0995	m06	\$	008539	-01198	007699	1000	1000	0000	0000	0000	0000	1000	0000	%1076	m26	\$
007544	000035	-00035	0750	0750	0750	0250	0250	0250	0000	0000	%0996	m07	\$	003221	002609	-04402	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$	
008550	000006	-00001	0875	0875	0875	0125	0125	0125	0000	0000	%0997	m08	\$	005695	-06585	003318	1000	0000	0000	0000	1000	1000	0000	%1078	n26	\$	
009711	-00006	-00002	1000	1000	1000	1000	1000	1000	1000	0000	%0998	m09	\$	004504	006620	-01278	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$	
001166	-00022	000033	0000	0000	0000	1000	1000	1000	1000	0000	%0999	n01	\$														
002517	-00021	-00005	0125	0125	0125	0875	0875	0875	0875	0000	%1000	n02	\$	%z004558	005404	003851	##1000	0000	0000	0000	1000	1000	0000	%1074	l26	%03 0 \$	
003449	-00005	000018	0250	0250	0250	0750	0750	0750	0750	0000	%1001	n03	\$	%z008539	-01198	007699	##1000	1000	0000	0000	0000	1000	0000	%1076	m26	%Y3 1 \$	
004353	-00007	000002	0375	0375	0375	0625	0625	0625	0625	0000	%1002	n04	\$	%z005695	-06585	003318	##0000	1000	0000	1000	0000	0000	0000	%1078	n26	%L3 2 \$	
005250	-00001	-00038	0500	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$	%z005389	-03046	-03510	##0000	1000	1000	0000	0000	0000	0000	%1075	l27	%C3 3 \$	
006440	000009	-00062	0625	0625	0625	0375	0375	0375	0375	0000	%1004	n06	\$	%z003221	002609	-04402	##0000	0000	1000	1000	1000	0000	0000	%1077	m27	%V3 4 \$	
007525	000049	-00036	0750	0750	0750	0250	0250	0250	0000	0000	%1005	n07	\$	%z004504	006620	-01278	##1000	0000	1000	0000	1000	0000	0000	%1079	n27	%W3 5 \$	
008499	000008	000000	0875	0875	0875	0125	0125	0125	0000	0000	%1006	n08	\$	%z001099	000000	000000	##0000	0000	0000	1000	1000	1000	0000	%1072	k26	%W3 6 \$	
009708	000000	-00019	1000	1000	1000	1000	1000	1000	1000	0000	%1007	n09	\$	%z009611	000000	000000	##1000	1000	1000	0000	0000	0000	0000	%1073	k27	%W3 7 \$	
001214	-00008	000029	0000	0000	0000	1000	1000	1000	1000	0000	%1008	k10	\$														
002492	-00008	-00062	0066	0066	0066	0666	0666	0666	0666	0000	%1009	k11	\$	%z001169	-00021	000036	##0000	0000	0000	1000	1000	0000	0000	%0972	k01	%N4 6 \$	
002757	-00009	-00056	0133	0133	0133	0866	0866	0866	0866	0000	%1010	k12	\$	%z009704	000004	-00017	##1000	1000	1000	0000	0000	0000	0000	%0980	k09	%W4 7 \$	
003100	-00001	-00050	0200	0200	0200	0800	0800	0800	0800	0000	%1011	k13	\$														
003844	-00018	-00041	0266	0266	0266	0333	0333	0333	0333	0000	%1012	k14	\$	%z001150	-00024	000041	##0000	0000	0000	1000	1000	1000	0000	%0981	l01	%N5 6 \$	
004266	000021	-00065	0333	0333	0333	0666	0666	0666	0666	0000	%1013	k15	\$	%z009696	000000	-00012	##1000	1000	1000	0000	0000	0000	0000	%0989	l09	%W5 7 \$	
005123	-00013	000043	0400	0400	0400	0600	0600	0600	0600	0000	%1014	k16	\$														
005198	000028	-00068	0466	0466	0466	0533	0533	0533	0533	0000	%1015	k17	\$	%z001178	-00015	000029	##0000	0000	0000	1000	1000	1000	0000	%0990	m01	%N6 6 \$	
005528	000003	000060	0533	0533	0533	0466	0466	0466	0466	0000	%1016	k18	\$	%z009711	-00006	-00002	##1000	1000	1000	0000	0000	0000	0000	%0998	m09	%W6 7 \$	
006225	-00008	-00028	0600	0600	0600	0600	0600	0600	0600	0000	%1017	k19	\$														
006656	-00012	000126	0666	0666	0666	0666	0666	0666	0666	0000	%1018	k20	\$	%z001166	-00022	000033	##0000	0000	0000	1000	1000	1000	0000	%0999	n01	%N7 6 \$	
007236	000009	-00027	0734	0734	0734	0266	0266	0266	0266	0000	%1019	k21	\$	%z009708	000000	-00019	##1000	1000	1000	0000	0000	0000	0000	%1007	n09	%W7 7 \$	

003957	000997	000864	0375	0000	0000	0025	1000	1000	0000	%0243	A10	\$
003958	001197	000293	0375	0000	0125	0625	1000	0875	0000	%0244	A11	\$
003836	001111	000156	0375	0000	0250	0625	1000	0750	0000	%0245	A12	\$
004186	001526	-00112	0375	0000	0375	0625	1000	0625	0000	%0246	A13	\$
004240	001598	-00739	0375	0000	0500	0625	1000	0500	0000	%0247	A14	\$
004319	002729	-01732	0375	0000	0625	0625	1000	0375	0000	%0248	A15	\$
004175	002798	-01761	0375	0000	0750	0625	1000	0250	0000	%0249	A16	\$
004282	003135	-02205	0375	0000	0875	0625	1000	0125	0000	%0250	A17	\$
003927	003382	-03307	0375	0000	1000	0625	1000	0000	0000	%0251	A18	\$
004062	000984	000928	0375	0125	0000	0625	0875	1000	0000	%0252	B10	\$
004040	000923	000894	0375	0125	0125	0625	0875	0875	0000	%0253	B11	\$
003950	001156	000254	0375	0125	0250	0625	0875	0750	0000	%0254	B12	\$
003948	001000	-00382	0375	0125	0375	0625	0875	0625	0000	%0255	B13	\$
004171	001271	-00926	0375	0125	0500	0625	0875	0500	0000	%0256	B14	\$
004318	001643	-00846	0375	0125	0625	0625	0875	0375	0000	%0257	B15	\$
004144	002162	-02235	0375	0125	0750	0625	0875	0250	0000	%0258	B16	\$
004179	002244	-02274	0375	0125	0875	0625	0875	0125	0000	%0259	B17	\$
004321	002520	-02801	0375	0125	1000	0625	0875	0000	0000	%0260	B18	\$
004626	000521	001512	0375	0250	0000	0625	0750	1000	0000	%0261	C10	\$
004091	000918	000968	0375	0250	0125	0625	0750	0875	0000	%0262	C11	\$
004148	000786	000628	0375	0250	0250	0625	0750	0750	0000	%0263	C12	\$
004146	000793	000665	0375	0250	0375	0625	0750	0625	0000	%0264	C13	\$
004146	000832	-00655	0375	0250	0500	0625	0750	0500	0000	%0265	C14	\$
004411	001067	-01141	0375	0250	0625	0625	0750	0375	0000	%0266	C15	\$
004533	001552	-01657	0375	0250	0750	0625	0750	0250	0000	%0267	C16	\$
004664	001652	-02142	0375	0250	0875	0625	0750	0125	0000	%0268	C17	\$
004992	001899	-02513	0375	0250	1000	0625	0750	0000	0000	%0269	C18	\$
005074	-00604	001622	0375	0375	0000	0625	0625	1000	0000	%0270	D10	\$
004972	000061	001594	0375	0375	0125	0625	0625	0875	0000	%0271	D11	\$
004663	-00144	001088	0375	0375	0250	0625	0625	0750	0000	%0272	D12	\$
004581	000002	001022	0375	0375	0375	0625	0625	0625	0000	%0273	D13	\$
004809	000226	-00320	0375	0375	0500	0625	0625	0500	0000	%0274	D14	\$
005003	000456	-00851	0375	0375	0625	0625	0625	0375	0000	%0275	D15	\$
005256	000675	-01304	0375	0375	0750	0625	0625	0250	0000	%0276	D16	\$
005419	000992	-01768	0375	0375	0875	0625	0625	0125	0000	%0277	D17	\$
005596	000994	-02254	0375	0375	1000	0625	0625	0000	0000	%0278	D18	\$
005759	-01391	001990	0375	0500	0000	0625	0500	1000	0000	%0279	D19	\$
005298	-00875	001592	0375	0500	0125	0625	0500	0875	0000	%0280	E11	\$
005318	-00832	001226	0375	0500	0250	0625	0500	0750	0000	%0281	E12	\$
005257	-00708	000247	0375	0500	0375	0625	0500	0625	0000	%0282	E13	\$
005090	-00418	-00473	0375	0500	0500	0625	0500	0500	0000	%0283	E14	\$
005362	-00205	-01057	0375	0500	0625	0625	0500	0375	0000	%0284	E15	\$
005447	-00021	-01388	0375	0500	0750	0625	0500	0250	0000	%0285	E16	\$
005611	000175	-01839	0375	0500	0875	0625	0500	0125	0000	%0286	E17	\$
005833	000432	-02212	0375	0500	1000	0625	0500	0000	0000	%0287	E18	\$
006069	-02038	002548	0375	0625	0000	0625	0375	1000	0000	%0288	F10	\$
005760	-01409	001967	0375	0625	0125	0625	0375	0875	0000	%0289	F11	\$
005631	-01453	001365	0375	0625	0250	0625	0375	0750	0000	%0290	F12	\$
005680	-01338	000666	0375	0625	0375	0625	0375	0625	0000	%0291	F13	\$
005605	-01049	-00313	0375	0625	0500	0625	0375	0500	0000	%0292	F14	\$
005520	-00962	-00887	0375	0625	0625	0625	0375	0375	0000	%0293	F15	\$
005631	-00624	-01451	0375	0625	0750	0625	0375	0250	0000	%0294	F16	\$
005756	-00368	-01961	0375	0625	0875	0625	0375	0125	0000	%0295	F17	\$
006023	-00233	-02184	0375	0625	1000	0625	0375	0000	0000	%0296	F18	\$
006409	-02854	002936	0375	0750	0000	0625	0250	1000	0000	%0297	G10	\$
006087	-02091	002477	0375	0750	0125	0625	0250	0875	0000	%0298	G11	\$
005933	-02323	001735	0375	0750	0250	0625	0250	0750	0000	%0299	G12	\$
006080	-02112	000652	0375	0750	0375	0625	0250	0500	0000	%0300	G13	\$
005969	-01754	-00090	0375	0750	0500	0625	0250	0500	0000	%0301	G14	\$
005892	-01572	-00804	0375	0750	0625	0250	0250	0375	0000	%0302	G15	\$
005820	-01351	-01445	0375	0750	0750	0625	0250	0250	0000	%0303	G16	\$
005984	-00978	-01868	0375	0750	0875	0625	0250	0125	0000	%0304	G17	\$
006222	-00689	-02166	0375	0750	1000	0625	0250	0000	0000	%0305	G18	\$
006972	-02432	004133	0375	0875	0000	0625	0125	1000	0000	%0306	H10	\$
006402	-02948	002974	0375	0875	0125	0625	0125	0875	0000	%0307	H11	\$
006368	-02957	002126	0375	0875	0250	0625	0125	0750	0000	%0308	H12	\$
006401	-02814	001236	0375	0875	0375	0625	0125	0625	0000	%0309	H13	\$
006366	-02495	000171	0375	0875	0500	0625	0125	0500	0000	%0310	H14	\$
006379	-02284	-00445	0375	0875	0625	0625	0125	0375	0000	%0311	H15	\$
006243	-02045	-01257	0375	0875	0750	0625	0125	0250	0000	%0312	H16	\$
006227	-01838	-01779	0375	0875	0875	0625	0125	0125	0000	%0313	H17	\$
006381	-01373	-02312	0375	0875	1000	0625	0125	0000	0000	%0314	H18	\$
006872	-04061	004558	0375	1000	0000	0625	0000	1000	0000	%0315	I10	\$
006796	-03515	003327	0375	1000	0125	0625	0000	0875	0000	%0316	I11	\$
006834	-03541	002606	0375	1000	0250	0625	0000	0750	0000	%0317	I12	\$
006921	-03423	001701	0375	1000	0375	0625	0000	0625	0000	%0318	I13	\$
006823	-03028	000411	0375	1000	0500	0625	0000	0500	0000	%0319	I14	\$
006748	-02805	-00193	0375	1000	0625	0000	0000	0375	0000	%0320	I15	\$
006654	-02597	-00952	0375	1000	0750	0625	0000	0250	0000	%0321	I16	\$
006659	-02369	-01598	0375	1000	0875	0625	0000	0125	0000	%0322	I17	\$
006724	-02187	-02310	0375	1000	1000	0625	0000	0000	0000	%0323	I18	\$
004827	002766	001841	0500	0000	0000	0500	1000	1000	0000	%0324	J10	\$
004855	002895	001073	0500	0000	0125	0500	1000	0875	0000	%0325	J11	\$
004834	002914	001055	0500	0000	0250	0500	1000	0750	0000	%0326	J12	\$
004891	003136	000822	0500	0000	0375	0500	1000	0625	0000	%0327	J13	\$
004619	003090	-01314	0500	0000	0500	0500	1000	0500	0000	%0328	J14	\$
004616	003077	-01309	0500	0000	0625	0500	1000	0375	0000	%0329	J15	\$
004428	003643	-01817	0500	0000	0750	0500	1000	0250	0000	%0330	J16	\$
004307	003708	-01779	0500	0000	1000	0500	1000	0125	0000	%0331	J17	\$
004151	003586	-01408	0500	0000	1000	0500	1000	0000	0000	%0332	J18	\$
004858	002669	002404	0500	0125	0000	0500	0875	1000	0000	%0333	K10	\$
004638	001785	001774	0500	0125	0125	0500	0875	0875	0000	%0334	K11	\$
004426	001660	000779	0500	0125	0250	0500	0875	0750	0000	%0335	K12	\$
004605	002078	000411	0500	0125	0375	0500	0875	0625	0000	%0336	K13	\$
004400	001889	-00561	0500	0125	0500	0500	0875	0500	0000	%0337	K14	\$
004484	002064	-01274	0500	0125	0625	0500	0875	0375	0000	%0338	K15	\$
004316	002800	-01788	0500	0125	0750	0500	0875	0250	0000	%0339	K16	\$
004288	002813	-01913	0500	0125	0875	0500	0875	0125	0000	%0340	K17	\$
004560	002903	-02322	0500	0125	1000	0500	0875	0000	0000	%0341	K18	\$
005393	001806	002739	0500	0250	0000	0500	0750	1000	0000	%0342	L10	\$
004636	001736	001805	0500	0250	0125	0500	0750	0875	0000	%0343	L11	\$
0												

004920	003917	002548	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$	004868	005781	003548	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$	004883	005796	004093	1000	0000	0000	0000	1000	1000	0000	%0648	S19	\$
004845	004045	001912	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$	004811	005861	002842	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$	004720	006616	003444	1000	0000	0125	0000	1000	0875	0000	%0649	S20	\$
004780	004072	001942	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$	004732	006024	002159	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$	004763	006743	002979	1000	0000	0250	0000	1000	0750	0000	%0650	S21	\$
004738	004218	001237	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$	004700	006028	002180	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$	004794	006824	002520	1000	0000	0375	0000	1000	0625	0000	%0651	S22	\$
004749	004477	000522	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$	004650	006163	001483	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$	004771	006890	001878	1000	0000	0500	0000	1000	0500	0000	%0652	S23	\$
004652	004569	001017	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$	004741	004819	000810	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$	004743	006764	001237	1000	0000	0625	0000	1000	0375	0000	%0653	S24	\$
004512	004804	-01119	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$	004690	004976	000136	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$	004711	006563	000766	1000	0000	0750	0000	1000	0250	0000	%0654	S25	\$
004525	004774	-01132	0750	0000	0875	0250	1000	0000	0000	%0493	A26	\$	004619	005170	-00805	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$	004752	006582	000768	1000	0000	0875	0000	1000	0125	0000	%0655	S26	\$
004068	004413	-01708	0750	0000	0975	0250	1000	0000	0000	%0494	A27	\$	004471	005171	-01290	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$	004694	006522	-00756	1000	0000	1000	0000	1000	0000	0000	%0656	S27	\$
004996	003892	003158	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$	005008	004179	003351	0875	0125	0000	0125	0875	1000	0000	%0576	K10	\$	005333	005283	004562	1000	0125	0000	0000	0875	1000	0000	%0657	T10	\$
004900	003997	002547	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$	005005	004307	002923	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$	005477	005518	003718	1000	0125	0125	0000	0875	0875	0000	%0658	T20	\$
004832	004116	001938	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$	004952	004463	002314	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$	005468	005582	003061	1000	0125	0250	0000	0875	0750	0000	%0659	T21	\$
004784	004239	001251	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$	004957	004535	001771	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$	005372	005784	002443	1000	0125	0375	0000	0875	0625	0000	%0660	T22	\$
004711	004265	001280	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$	004889	004594	001334	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$	005403	005623	001893	1000	0125	0500	0000	0875	0500	0000	%0661	T23	\$
004703	004399	000666	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$	004882	004622	000793	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$	005387	005678	001367	1000	0125	0625	0000	0875	0375	0000	%0662	T24	\$
004568	004642	-00105	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$	004826	004789	000246	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$	005361	005614	000822	1000	0125	0750	0000	0875	0250	0000	%0663	T25	\$
004441	003766	-01063	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$	004858	004699	-00417	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$	005391	005626	000181	1000	0125	0875	0000	0875	0125	0000	%0664	T26	\$
004574	003801	-01608	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$	004996	004523	-01162	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$	005379	005685	-00623	1000	0125	1000	0000	0875	0000	0000	%0665	T27	\$
005543	002932	003477	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$	005342	003494	003523	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$	005771	004502	005081	1000	0250	0000	0000	0750	1000	0000	%0666	U19	\$
004980	003179	002857	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$	005472	003443	003262	0875	0250	0125	0125	0750	0875	0000	%0586	L20	\$	006051	004711	004258	1000	0250	0125	0000	0750	0875	0000	%0667	U20	\$
005054	003201	002176	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$	005526	003636	002459	0875	0250	0250	0125	0750	0750	0000	%0587	L21	\$	006165	004748	003247	1000	0250	0250	0000	0750	0750	0000	%0668	U21	\$
005059	003242	001554	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$	005535	003732	001496	0875	0250	0375	0125	0750	0625	0000	%0588	L22	\$	006135	004808	002544	1000	0250	0375	0000	0750	0625	0000	%0669	U22	\$
004970	003226	001062	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$	005511	003747	001939	0875	0250	0500	0125	0750	0500	0000	%0589	L23	\$	006123	004799	001997	1000	0250	0500	0000	0750	0500	0000	%0670	U23	\$
004850	003346	000383	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$	005463	003767	000964	0875	0250	0625	0125	0750	0375	0000	%0590	L24	\$	006114	004839	001421	1000	0250	0625	0000	0750	0375	0000	%0671	U24	\$
004725	003478	-00220	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$	005412	003906	000318	0875	0250	0750	0125	0750	0250	0000	%0591	L25	\$	006085	004717	000895	1000	0250	0750	0000	0750	0250	0000	%0672	U25	\$
004844	003389	-01058	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$	005393	003952	-00264	0875	0250	0875	0125	0750	0125	0000	%0592	L26	\$	006084	004612	000289	1000	0250	0875	0000	0750	0125	0000	%0673	U26	\$
005161	003161	-01394	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$	005353	003698	-01803	0875	0250	1000	0125	0750	0000	0000	%0593	L27	\$	006081	004598	-00323	1000	0250	1000	0000	0750	0000	0000	%0674	U27	\$
006093	002050	003797	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$	006110	004249	004200	0875	0375	0000	0125	0625	1000	0000	%0594	M19	\$	006139	003982	005598	1000	0375	0000	0000	0625	1000	0000	%0675	V19	\$
005456	002360	003089	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$	005849	002912	003569	0875	0375	0125	0125	0625	0875	0000	%0595	M20	\$	006408	004076	004556	1000	0375	0125	0000	0625	0875	0000	%0676	V20	\$
005881	002311	002591	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$	005939	003072	002931	0875	0375	0250	0125	0625	0750	0000	%0596	M21	\$	006585	004024	003569	1000	0375	0250	0000	0625	0750	0000	%0677	V21	\$
005544	002346	001718	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$	006041	003078	001999	0875	0375	0375	0125	0625	0625	0000	%0597	M22	\$	006649	004049	002562	1000	0375	0375	0000	0625	0625	0000	%0678	V22	\$
005612	002368	001181	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$	006066	003051	001507	0875	0375	0500	0125	0625	0500	0000	%0598	M23	\$	006718	004038	002072	1000	0375	0500	0000	0625	0500	0000	%0679	V23	\$
005487	002519	000444	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$	006045	003048	000923	0875	0375	0625	0125	0625	0375	0000	%0599	M24	\$	006708	004077	001570	1000	0375	0625	0000	0625	0375	0000	%0680	V24	\$
005390	002584	-00055	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$	005989	003121	000352	0875	0375	0750	0125	0625	0250	0000	%0600	M25	\$	006669	004155	000906	1000	0375	0750	0000	0625	0250	0000	%0681	V25	\$
005605	002363	-00073	0750	0375	0875	025																																

See original or copy: <http://web.me.com/klaus.richter/GE73/GE73L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfl=0.90; nt=0.18; nx=1.0

009666	-00059	000193	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009881	-00614	-00643	0875	1000	1000	1000	0125	0000	0000	%0730	b02	\$
008282	-00877	-00974	0750	1000	1000	0000	0250	0000	0000	%0731	b03	\$
007766	-01215	-01308	0625	1000	1000	0000	0375	0000	0000	%0732	b04	\$
007329	-01768	-01681	0500	1000	1000	0000	0500	0000	0000	%0733	b05	\$
006794	-02148	-02286	0375	1000	1000	0000	0625	0000	0000	%0734	b06	\$
006200	-02739	-02973	0250	1000	1000	0000	0750	0000	0000	%0735	b07	\$
005746	-03011	-03334	0125	1000	1000	0000	0875	0000	0000	%0736	b08	\$
005368	-03431	-03816	0000	1000	1000	0000	1000	0000	0000	%0737	b09	\$
008776	-00692	-00050	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
008368	-00638	-00020	0875	0875	0875	0000	0125	0125	0000	%0739	c02	\$
008005	-00549	-00566	0750	0875	0875	0250	0125	0125	0000	%0740	c03	\$
007213	-00890	-00960	0625	0875	0875	0375	0125	0125	0000	%0741	c04	\$
006725	-01234	-01439	0500	0875	0875	0500	0125	0125	0000	%0742	c05	\$
006232	-01792	-01820	0375	0875	0875	0625	0125	0125	0000	%0743	c06	\$
005707	-02180	-02407	0250	0875	0875	0750	0125	0125	0000	%0744	c07	\$
005460	-02330	-02564	0125	0875	0875	0875	0125	0125	0000	%0745	c08	\$
005361	-03334	-03838	0000	0875	0875	1000	0125	0125	0000	%0746	c09	\$
008381	-001450	-001140	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
007925	-000709	-000472	0875	0750	0750	0125	0250	0250	0000	%0748	d02	\$
007495	-000019	-000127	0750	0750	0750	0250	0250	0250	0000	%0749	d03	\$
006865	-00386	-00327	0625	0750	0750	0375	0250	0250	0000	%0750	d04	\$
006301	-00788	-00990	0500	0750	0750	0500	0250	0250	0000	%0751	d05	\$
005847	-01272	-01466	0375	0750	0750	0625	0250	0250	0000	%0752	d06	\$
005365	-01709	-01840	0250	0750	0750	0750	0250	0250	0000	%0753	d07	\$
005152	-01727	-02120	0125	0750	0750	0875	0250	0250	0000	%0754	d08	\$
005443	-02114	-02545	0000	0750	0750	1000	0250	0250	0000	%0755	d09	\$
007873	-002233	-001573	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007356	-001442	-000904	0875	0625	0625	0125	0375	0375	0000	%0757	e02	\$
006936	-000767	-000608	0750	0625	0625	0250	0375	0375	0000	%0758	e03	\$
006420	-00011	-000077	0625	0625	0625	0375	0375	0375	0000	%0759	e04	\$
005956	-00413	-00367	0500	0625	0625	0500	0375	0375	0000	%0760	e05	\$
005603	-00925	-00805	0375	0625	0625	0625	0375	0375	0000	%0761	e06	\$
004950	-01295	-01526	0250	0625	0625	0750	0375	0375	0000	%0762	e07	\$
004730	-01378	-01756	0125	0625	0625	0875	0375	0375	0000	%0763	e08	\$
004656	-01330	-01704	0000	0625	0625	1000	0375	0375	0000	%0764	e09	\$
007387	-002887	-002087	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006781	-002175	-001561	0875	0500	0500	0125	0500	0500	0000	%0766	f02	\$
006338	-001463	-001176	0750	0500	0500	0000	0250	0500	0000	%0767	f03	\$
005812	-000837	-000608	0625	0500	0500	0375	0500	0500	0000	%0768	f04	\$
005308	-00010	-000079	0500	0500	0500	0500	0500	0500	0000	%0769	f05	\$
005066	-00404	-00470	0375	0500	0500	0625	0500	0500	0000	%0770	f06	\$
004531	-00881	-01062	0250	0500	0500	0750	0500	0500	0000	%0771	f07	\$
004208	-01172	-01150	0125	0500	0500	0875	0500	0500	0000	%0772	f08	\$
004045	-00821	-00971	0000	0500	0500	1000	0500	0500	0000	%0773	f09	\$
006667	-004055	-002489	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
005988	-003094	-001870	0875	0375	0375	0125	0625	0625	0000	%0775	g02	\$
005585	-002368	-001590	0750	0375	0375	0250	0625	0625	0000	%0776	g03	\$
005117	-001619	-001197	0625	0375	0375	0375	0625	0625	0000	%0777	g04	\$
004783	-000847	-000597	0500	0375	0375	0500	0625	0625	0000	%0778	g05	\$
004467	-000011	-000119	0375	0375	0375	0625	0625	0625	0000	%0779	g06	\$
004174	-00363	-00471	0250	0375	0375	0750	0625	0625	0000	%0780	g07	\$
003791	-00601	-01079	0125	0375	0375	0875	0625	0625	0000	%0781	g08	\$
003385	-00698	-01095	0000	0375	0375	1000	0625	0625	0000	%0782	g09	\$
006167	-004733	-003399	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005412	-003693	-002456	0875	0250	0250	0125	0750	0750	0000	%0784	h02	\$
004904	-003187	-002150	0750	0250	0250	0250	0750	0750	0000	%0785	h03	\$
004532	-002374	-001542	0625	0250	0250	0375	0750	0750	0000	%0786	h04	\$
004276	-001477	-001207	0500	0250	0250	0500	0750	0750	0000	%0787	h05	\$
004038	-000783	-000564	0375	0250	0250	0625	0750	0750	0000	%0788	h06	\$
003646	-000024	-000081	0250	0250	0250	0750	0750	0750	0000	%0789	h07	\$
003969	-00227	-00301	0125	0250	0250	0875	0750	0750	0000	%0790	h08	\$
002547	-00039	-00118	0000	0250	0250	1000	0750	0750	0000	%0791	h09	\$
005432	-005526	-003844	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004889	-004184	-002960	0875	0125	0125	0125	0875	0875	0000	%0793	i02	\$
004810	-003966	-002643	0750	0125	0125	0250	0875	0875	0000	%0794	i03	\$
004639	-002782	-001861	0625	0125	0125	0375	0875	0875	0000	%0795	i04	\$
004407	-001794	-001779	0500	0125	0125	0500	0875	0875	0000	%0796	i05	\$
003889	-000907	-000855	0375	0125	0125	0625	0875	0875	0000	%0797	i06	\$
003864	-000468	-000479	0250	0125	0125	0750	0875	0875	0000	%0798	i07	\$
002824	-000030	-000056	0125	0125	0125	0875	0875	0875	0000	%0799	i08	\$
002330	-000025	-000048	0000	0125	0125	1000	0875	0875	0000	%0800	i09	\$
004763	-005870	-004174	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
004761	-005777	-003657	0875	0000	0000	0125	1000	1000	0000	%0802	j02	\$
004751	-003946	-002571	0750	0000	0000	0250	1000	1000	0000	%0803	j03	\$
004816	-003867	-002553	0625	0000	0000	0375	1000	1000	0000	%0804	j04	\$
004656	-002786	-001775	0500	0000	0000	0500	1000	1000	0000	%0805	j05	\$
003845	-001018	-000801	0375	0000	0000	0625	1000	1000	0000	%0806	j06	\$
003943	-000422	-000375	0250	0000	0000	0750	1000	1000	0000	%0807	j07	\$
002424	-000215	-000247	0125	0000	0000	0875	1000	1000	0000	%0808	j08	\$
005159	-000067	-000131	0000	0000	0000	1000	1000	1000	0000	%0809	j09	\$
009705	-00060	-000189	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
008685	-000157	-00362	0875	0875	0875	0100	0125	0125	0000	%0811	b11	\$
008115	-000304	-00831	0750	0750	0750	0250	0250	0250	0000	%0812	b12	\$
007194	-000550	-01150	0625	0625	0625	0375	0375	0375	0000	%0813	b13	\$
006408	-000874	-01623	0500	0500	0500	0500	0500	0500	0000	%0814	b14	\$
005662	-000940	-02223	0375	0375	0375	0625	0625	0625	0000	%0815	b15	\$
004905	-001289	-02908	0250	0250	0250	0750	0750	0750	0000	%0816	b16	\$
004305	-001490	-03483	0125	0250	0250	0875	0875	0875	0000	%0817	b17	\$
003285	-002030	-04234	0000	1000	1000	1000	1000	1000	0000	%0818	b18	\$
009486	-000057	-000791	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$
008544	-000304	-000177	0875	0875	0875	0125	0125	0125	0000	%0820	c11	\$
007923	-000160	-00353	0750	0750	0750	0250	0250	0125	0000	%0821	c12	\$
006981	-000395	-00709	0625	0625	0875	0375	0375	0125	0000	%0822	c13	\$
006234	-000649	-01285	0500	0500	0875	0500	0500	0125	0000	%0823	c14	\$
005393	-000969	-01784	0375	0375	0875	0625	0625	0125	0000	%0824	c15	\$
004480	-001076	-02476	0250	0250	0875	0750	0750	0125	0000	%0825	c16	\$
004083	-001517	-02659	0125	0125	0875	0875	0125	0000	0000	%0826	c17	\$
003674	-001797	-04072	0000	0000	0875	1000	1000	0125	0000	%0827	c18	\$
003235	-000059	-001599	1000	1000	0750	0000	0250	0000	0000	%0828	d10	\$
008587	-000051	-000773	0875	0875	0750	0						

%BEG GE63_22.TXT, Separation cmyn4*, cfi=0.90, D50, not adapted \$
%100 x LAB*
%#1000 x (r g b c m y 0) %nr. pos \$
%z004883 005796 004093 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008726 -00664 007558 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005748 -05942 003121 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005343 -03455 -03825 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z003357 002153 -04188 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z004694 006526 -00756 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001269 000044 000104 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009643 -00056 000200 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004763 005870 004174 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008739 -00685 007456 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005739 -05895 003059 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005368 -03431 -03816 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003285 002030 -04234 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z004740 006554 -00727 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z001119 000072 000126 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009692 -00061 000194 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/GE73/GE73L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

```
%BEG GE63.22.TXT, Separation cmy4*, cfi=0.90, D50, not adapted S
%100 x LAB*      1000 x (r g b c m y 0) %nrr. pos $
001171 000047 000123 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002503 000020 000091 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003407 000025 000109 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004269 000017 000125 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005227 000007 000103 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006389 000000 000093 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
007525 000032 000131 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008523 -000028 000171 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009705 -000052 000178 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
001152 000045 000127 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002438 000022 000066 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003407 000016 000103 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004274 000015 000123 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005226 000002 000087 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006382 -000004 000081 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
007547 000008 000132 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
008505 -000030 000170 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009697 -000057 000183 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
001181 000053 000116 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002559 000028 000084 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003455 000017 000087 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004326 000005 000118 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
005246 000004 000092 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006396 -000010 000084 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
007546 000008 000134 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
008551 -000033 000180 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009712 -000062 000193 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
001169 000046 000120 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002518 000024 000098 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003450 000025 000098 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004355 000013 000130 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005252 000001 000102 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006441 000007 000093 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
007526 000022 000134 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008501 000030 000181 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009709 000058 000176 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
001217 000059 000117 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
002493 000030 000041 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002758 000025 000051 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
003102 000030 000061 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
003845 000002 000080 0266 0266 0266 0333 0333 0333 0000 %1012 k14 $
004268 000034 000063 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
004525 000011 000174 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005199 000028 000072 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
005531 000017 000204 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006226 -000019 000124 0600 0600 0600 0400 0400 0400 0000 %1017 k19 $
006659 -000005 000283 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007237 -000014 000138 0734 0734 0734 0266 0266 0266 0000 %1019 k21 $
007905 -000017 000163 0800 0800 0800 0200 0200 0200 0000 %1020 k22 $
008348 -000019 000181 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
008692 -000028 000186 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009641 -000045 000174 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
001309 000057 000103 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
002486 000026 000051 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
002729 000021 000039 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
003078 000031 000053 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
003850 000000 000079 0266 0266 0266 0333 0333 0333 0000 %1028 l14 $
004272 000034 000061 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
004534 000012 000147 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005216 000022 000047 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
005540 000030 000157 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006198 000005 000085 0600 0600 0600 0400 0400 0400 0000 %1033 l19 $
006619 000012 000207 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007259 000013 000117 0734 0734 0734 0266 0266 0266 0000 %1035 l21 $
007909 -000015 000155 0800 0800 0800 0200 0200 0200 0000 %1036 l22 $
008360 000022 000173 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
008719 -000031 000186 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009647 -000046 000175 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
001293 000059 000104 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
002545 000026 000052 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002767 000026 000036 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
003126 000032 000049 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
003891 000004 000061 0266 0266 0266 0333 0333 0333 0000 %1044 m14 $
004332 000026 000061 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
004609 000010 000151 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005230 000023 000059 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
005532 000025 000178 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006228 -000011 000092 0600 0600 0600 0400 0400 0400 0000 %1049 m19 $
006658 000010 000214 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007265 -000015 000123 0734 0734 0734 0266 0266 0266 0000 %1051 m21 $
007903 -000018 000156 0800 0800 0800 0200 0200 0200 0000 %1052 m22 $
```

TUB-test chart GE73; Relative Device Colour System G
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: ->olv* setrgbcolor

TUB registration: 20091101-GE73/GE73L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

TUB registration: 20091101-GE73/GE73L0NA.TXT/.ps TUB material: code=rh4ta
application for evaluation and measurement of printer or monitor systems

input: w *setgray*
output: $\rightarrow$ *olv** *setrgbcolor*

See original or copy: <http://web.me.com/klaus.richter/GE73/GE73L0NA.TXT /.PS>
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

003957	000984	000729	0375	0000	0000	0025	1000	1000	0000	%0243	A10 \$	004827	002764	001696	0500	0000	0000	0500	1000	1000	0000	%0324	J10 \$	005011	003816	002325	0625	0000	0000	0375	1000	1000	0000	%0405	S10 \$	
003958	001185	000158	0375	0000	0125	0625	1000	0875	0000	%0244	A11 \$	004855	002893	000927	0500	0000	0125	0500	1000	0875	0000	%0325	J11 \$	004989	003947	001685	0625	0000	0125	0375	1000	0875	0000	%0406	S11 \$	
003836	001097	000016	0375	0000	0250	0625	1000	0750	0000	%0245	A12 \$	004834	002912	000910	0500	0000	0250	0500	1000	0750	0000	%0326	J12 \$	004997	004105	000885	0625	0000	0250	0375	1000	0750	0000	%0407	S12 \$	
004186	001517	-02650	0375	0000	0375	0625	1000	0625	0000	%0246	A13 \$	004891	003135	000176	0500	0000	0375	0500	1000	0625	0000	%0327	J13 \$	004949	004111	000919	0625	0000	0375	0375	1000	0625	0000	%0408	S13 \$	
004240	001589	-00878	0375	0000	0500	0625	1000	0500	0000	%0247	A14 \$	004619	003086	-01457	0500	0000	0500	0500	1000	0500	0000	%0328	J14 \$	005021	004311	000219	0625	0000	0500	0375	1000	0500	0000	%0409	S14 \$	
004319	002721	-01872	0375	0000	0625	0625	1000	0375	0000	%0248	A15 \$	004616	003072	-01452	0500	0000	0625	0500	1000	0375	0000	%0329	J15 \$	004990	004486	-00335	0625	0000	0625	0375	1000	0375	0000	%0410	S15 \$	
004275	002790	-01900	0375	0000	0750	0625	1000	0250	0000	%0249	A16 \$	004428	003636	-01958	0500	0000	0750	0500	1000	0250	0000	%0330	J16 \$	004691	004086	-01574	0625	0000	0750	0375	1000	0250	0000	%0411	S16 \$	
004182	003125	-02423	0375	0000	0875	0625	1000	0125	0000	%0250	A17 \$	004397	003711	-01920	0500	0000	0875	0500	1000	0125	0000	%0331	J17 \$	004415	003655	-01962	0625	0000	0875	0375	1000	0125	0000	%0412	S17 \$	
003927	003639	-03442	0375	0000	1000	0625	1000	0000	0000	%0251	A18 \$	004151	003296	-02545	0500	0000	1000	0500	1000	0000	0000	%0332	J18 \$	004270	003858	-02209	0625	0000	1000	0375	1000	0000	0000	%0413	S18 \$	
004062	000973	000791	0375	0125	0000	0625	0875	1000	0000	%0252	B10 \$	004858	002668	002258	0500	0125	0000	0500	0875	1000	0000	%0333	K10 \$	004911	002598	002296	0625	0125	0000	0375	0875	1000	0000	%0414	T10 \$	
004040	000911	000758	0375	0125	0125	0625	0875	0875	0000	%0253	B11 \$	004638	001781	001631	0500	0125	0125	0500	0875	0875	0000	%0334	K11 \$	004917	002700	001650	0625	0125	0125	0375	0875	0875	0000	%0415	T11 \$	
003950	001143	000118	0375	0125	0250	0625	0875	0750	0000	%0254	B12 \$	004426	001653	000639	0500	0125	0250	0500	0875	0750	0000	%0335	K12 \$	004827	002920	000876	0625	0125	0250	0375	0875	0750	0000	%0416	T12 \$	
003948	000987	-00518	0375	0125	0375	0625	0875	0625	0000	%0255	B13 \$	004605	002073	000268	0500	0125	0375	0500	0875	0625	0000	%0336	K13 \$	004837	002884	000877	0625	0125	0375	0375	0875	0625	0000	%0417	T13 \$	
004171	001262	-01064	0375	0125	0500	0625	0875	0500	0000	%0256	B14 \$	004400	001882	-00701	0500	0125	0500	0500	0875	0500	0000	%0337	K14 \$	004909	003143	000177	0625	0125	0500	0375	0875	0500	0000	%0418	T14 \$	
004318	001635	-00986	0375	0125	0625	0625	0875	0375	0000	%0257	B15 \$	004484	002058	-01416	0500	0125	0625	0500	0875	0375	0000	%0338	K15 \$	005000	003260	-00302	0625	0125	0625	0375	0875	0375	0000	%0419	T15 \$	
004144	002152	-02372	0375	0125	0750	0625	0875	0250	0000	%0258	B16 \$	004316	002792	-01927	0500	0125	0750	0500	0875	0250	0000	%0339	K16 \$	004627	003079	-01482	0625	0125	0750	0375	0875	0250	0000	%0420	T16 \$	
004179	002235	-02412	0375	0125	0875	0625	0875	0125	0000	%0259	B17 \$	004288	002805	-02052	0500	0125	0875	0500	0875	0125	0000	%0340	K17 \$	004640	003206	-01531	0625	0125	0875	0375	0875	0125	0000	%0421	T17 \$	
004321	002512	-02941	0375	0125	1000	0625	0875	0000	0000	%0260	B18 \$	004500	002897	-02464	0500	0125	1000	0500	0875	0000	0000	%0341	K18 \$	004760	003282	-01995	0625	0125	1000	0375	0875	0000	0000	%0422	T18 \$	
004626	000517	001369	0375	0250	0000	0000	0625	0750	1000	0000	%0261	C10 \$	005393	001811	-02587	0500	0250	0000	0500	0750	1000	0000	%0342	L10 \$	004882	002602	002305	0625	0250	0000	0375	0750	1000	0000	%0423	U10 \$
004091	000908	000431	0375	0250	0125	0625	0750	0875	0000	%0262	C11 \$	004636	001732	001662	0500	0250	0125	0500	0750	0875	0000	%0343	L11 \$	004923	002579	002302	0625	0250	0125	0375	0750	0875	0000	%0424	U11 \$	
004148	000776	000090	0375	0250	0250	0625	0750	0750	0000	%0263	C12 \$	004487	001494	001071	0500	0250	0250	0500	0750	0750	0000	%0344	L12 \$	004791	002328	001302	0625	0250	0250	0375	0750	0750	0000	%0425	U12 \$	
004146	000783	-00071	0375	0250	0375	0625	0750	0625	0000	%0264	C13 \$	004486	001578	000466	0500	0250	0375	0500	0750	0625	0000	%0345	L13 \$	004746	002343	000807	0625	0250	0375	0375	0750	0625	0000	%0426	U13 \$	
004146	000822	-00793	0375	0250	0500	0625	0750	0500	0000	%0265	C14 \$	004404	001673	-00185	0500	0250	0500	0500	0750	0500	0000	%0346	L14 \$	004862	002301	000313	0625	0250	0500	0375	0750	0500	0000	%0427	U14 \$	
004411	001060	-01282	0375	0250	0625	0625	0750	0375	0000	%0266	C15 \$	004490	001651	-00810	0500	0250	0625	0500	0750	0375	0000	%0347	L15 \$	004851	002383	-00212	0625	0250	0625	0375	0750	0375	0000	%0428	U15 \$	
004533	001546	-01799	0375	0250	0750	0625	0750	0250	0000	%0267	C16 \$	004687	001835	-01335	0500	0250	0750	0500	0750	0250	0000	%0348	L16 \$	004971	002375	-01016	0625	0250	0750	0375	0750	0250	0000	%0429	U16 \$	
004664	001648	-02285	0375	0250	0875	0625	0750	0125	0000	%0268	C17 \$	004846	002217	-01821	0500	0250	0875	0500	0750	0125	0000	%0349	L17 \$	005027	002733	-01445	0625	0250	0875	0375	0750	0125	0000	%0430	U17 \$	
004992	001899	-02661	0375	0250	1000	0625	0750	0000	0000	%0269	C18 \$	005125	002212	-02223	0500	0250	1000	0500	0750	0000	0000	%0350	L18 \$	005307	002625	-01837	0625	0250	1000	0375	0750	0000	0000	%0431	U18 \$	
005074	-00603	001474	0375	0375	0000	0625	0625	1000	0000	%0270	D10 \$	005859	001194	002943	0500	0375	0000	0500	0625	1000	0000	%0351	M10 \$	006110	001978	003710	0625	0375	0000	0375	0625	1000	0000	%0432	V10 \$	
004972	000061	001447	0375	0375	0125	0625	0625	0875	0000	%0271	D11 \$	005826	001146	001899	0500	0375	0125	0500	0625	0875	0000	%0352	M11 \$	005377	001843	002632	0625	0375	0125	0375	0625	0875	0000	%0433	V11 \$	
004663	-00147	000945	0375	0375	0250	0625	0625	0750	0000	%0272	D12 \$	004855	000875	001355	0500	0375																				

004920	003916	002401	0750	0000	0000	0250	1000	1000	0000	%0486	A19	\$
004845	004044	001766	0750	0000	0125	0250	1000	0875	0000	%0487	A20	\$
004780	004069	001797	0750	0000	0250	0250	1000	0750	0000	%0488	A21	\$
004738	004215	001093	0750	0000	0375	0250	1000	0625	0000	%0489	A22	\$
004749	004474	000377	0750	0000	0500	0250	1000	0500	0000	%0490	A23	\$
004652	004565	-00251	0750	0000	0625	0250	1000	0375	0000	%0491	A24	\$
004512	004798	-01261	0750	0000	0750	0250	1000	0250	0000	%0492	A25	\$
004525	004769	-01273	0750	0000	0875	0250	1000	0125	0000	%0493	A26	\$
004468	004403	-01934	0750	0000	1000	0250	1000	0000	0000	%0494	A27	\$
004496	003892	003031	0750	0125	0000	0250	0875	1000	0000	%0495	B10	\$
004900	003996	002401	0750	0125	0125	0250	0875	0875	0000	%0496	B20	\$
004832	004114	001792	0750	0125	0250	0250	0875	0750	0000	%0497	B21	\$
004784	004236	001106	0750	0125	0375	0250	0875	0625	0000	%0498	B22	\$
004711	004262	001136	0750	0125	0500	0250	0875	0500	0000	%0499	B23	\$
004703	004387	000522	0750	0125	0625	0250	0875	0375	0000	%0500	B24	\$
004568	004637	-00247	0750	0125	0750	0250	0875	0250	0000	%0501	B25	\$
004441	003759	-01204	0750	0125	0875	0250	0875	0125	0000	%0502	B26	\$
004574	003796	-01750	0750	0125	1000	0250	0875	0000	0000	%0503	B27	\$
005543	002939	003323	0750	0250	0000	0250	0750	1000	0000	%0504	C19	\$
004980	003179	002710	0750	0250	0125	0250	0750	0875	0000	%0505	C20	\$
005054	003202	002028	0750	0250	0250	0250	0750	0750	0000	%0506	C21	\$
005059	003243	001406	0750	0250	0375	0250	0750	0625	0000	%0507	C22	\$
004970	003226	000915	0750	0250	0500	0250	0750	0500	0000	%0508	C23	\$
004850	003345	000237	0750	0250	0625	0250	0750	0375	0000	%0509	C24	\$
004725	003475	-00364	0750	0250	0750	0250	0750	0250	0000	%0510	C25	\$
004844	003387	-01203	0750	0250	0875	0250	0750	0125	0000	%0511	C26	\$
005161	003163	-01543	0750	0250	1000	0250	0750	0000	0000	%0512	C27	\$
006093	002063	003637	0750	0375	0000	0250	0625	1000	0000	%0513	D19	\$
005456	002365	002937	0750	0375	0125	0250	0625	0875	0000	%0514	D20	\$
005581	002318	002437	0750	0375	0250	0250	0625	0750	0000	%0515	D21	\$
005644	002354	001563	0750	0375	0375	0250	0625	0625	0000	%0516	D22	\$
005612	002376	001027	0750	0375	0500	0250	0625	0500	0000	%0517	D23	\$
005487	002525	000291	0750	0375	0625	0250	0625	0375	0000	%0518	D24	\$
005390	002580	-00207	0750	0375	0750	0250	0625	0250	0000	%0519	D25	\$
005605	002370	-01028	0750	0375	0875	0250	0625	0125	0000	%0520	D26	\$
005881	002284	-01347	0750	0375	1000	0250	0625	0000	0000	%0521	D27	\$
005653	001344	004220	0750	0500	0000	0250	0500	1000	0000	%0522	E19	\$
006007	002080	003707	0750	0500	0125	0250	0500	0875	0000	%0523	E20	\$
006107	001660	002948	0750	0500	0250	0250	0500	0750	0000	%0524	E21	\$
006169	001565	002037	0750	0500	0375	0250	0500	0625	0000	%0525	E22	\$
006238	001573	001135	0750	0500	0500	0250	0500	0500	0000	%0526	E23	\$
006194	001606	000452	0750	0500	0625	0250	0500	0375	0000	%0527	E24	\$
006153	001710	-00150	0750	0500	0750	0250	0500	0250	0000	%0528	E25	\$
006320	001540	-00885	0750	0500	0875	0250	0500	0125	0000	%0529	E26	\$
006538	001761	-01233	0750	0500	1000	0250	0500	0000	0000	%0530	E27	\$
007094	000621	004965	0750	0625	0000	0250	0375	1000	0000	%0531	F19	\$
005623	001373	004247	0750	0625	0125	0250	0375	0875	0000	%0532	F20	\$
006423	000814	003368	0750	0625	0250	0250	0375	0750	0000	%0533	F21	\$
006591	000808	002490	0750	0625	0375	0250	0375	0625	0000	%0534	F22	\$
006618	000866	001528	0750	0625	0500	0250	0375	0500	0000	%0535	F23	\$
006752	000888	000538	0750	0625	0625	0250	0375	0375	0000	%0536	F24	\$
006723	000971	-00019	0750	0625	0750	0250	0375	0250	0000	%0537	F25	\$
006962	001019	-00794	0750	0625	0875	0250	0375	0125	0000	%0538	F26	\$
007068	001031	-01159	0750	0625	1000	0250	0375	0000	0000	%0539	F27	\$
007622	000026	005392	0750	0750	0000	0250	0250	1000	0000	%0540	G19	\$
007238	-00529	004263	0750	0750	0125	0250	0250	0875	0000	%0541	G20	\$
007087	-00292	004013	0750	0750	0250	0250	0250	0750	0000	%0542	G21	\$
007164	-00125	003949	0750	0750	0375	0250	0250	0625	0000	%0543	G22	\$
007230	-00086	002284	0750	0750	0500	0250	0250	0500	0000	%0544	G23	\$
007226	-00093	000954	0750	0750	0625	0250	0250	0375	0000	%0545	G24	\$
007260	000065	000039	0750	0750	0750	0250	0250	0250	0000	%0546	G25	\$
007542	002047	-00597	0750	0750	0875	0250	0250	0125	0000	%0547	G26	\$
007760	000424	-01091	0750	0750	1000	0250	0250	0000	0000	%0548	G27	\$
008118	-00547	005915	0750	0875	0000	0250	0125	1000	0000	%0549	H19	\$
007770	-01062	005295	0750	0875	0125	0250	0125	0875	0000	%0550	H20	\$
007533	-01115	004400	0750	0875	0250	0250	0125	0750	0000	%0551	H21	\$
007538	-00977	003529	0750	0875	0375	0250	0125	0625	0000	%0552	H22	\$
007596	-00951	002488	0750	0875	0500	0250	0125	0500	0000	%0553	H23	\$
007631	-00811	001303	0750	0875	0625	0250	0125	0375	0000	%0554	H24	\$
007797	-00704	000438	0750	0875	0750	0250	0125	0250	0000	%0555	H25	\$
007777	-00604	-00773	0750	0875	0875	0250	0125	0125	0000	%0556	H26	\$
007859	-00265	-01107	0750	0875	1000	0250	0125	0000	0000	%0557	H27	\$
007861	-02111	006288	0750	1000	0000	0250	0000	1000	0000	%0558	I19	\$
007905	-01881	005026	0750	1000	0125	0250	0000	0875	0000	%0559	I20	\$
007931	-01833	004309	0750	1000	0250	0250	0000	0750	0000	%0560	I21	\$
008008	-01773	003532	0750	1000	0375	0250	0000	0625	0000	%0561	I22	\$
008060	-01650	002669	0750	1000	0500	0250	0000	0500	0000	%0562	I23	\$
008105	-01526	001735	0750	1000	0625	0250	0000	0375	0000	%0563	I24	\$
008305	-01542	000789	0750	1000	0750	0250	0000	0250	0000	%0564	I25	\$
008153	-01229	-00290	0750	1000	0875	0250	0000	0125	0000	%0565	I26	\$
008084	-00930	-01249	0750	1000	1000	0250	0000	0000	0000	%0566	I27	\$
004868	005780	003402	0875	0000	0000	0125	1000	1000	0000	%0567	J19	\$
004811	005859	002696	0875	0000	0125	0125	1000	0875	0000	%0568	J20	\$
004732	006021	002015	0875	0000	0250	0125	1000	0750	0000	%0569	J21	\$
004700	006025	002036	0875	0000	0375	0125	1000	0625	0000	%0570	J22	\$
004650	006159	001340	0875	0000	0500	0125	1000	0500	0000	%0571	J23	\$
004741	004816	000666	0875	0000	0625	0125	1000	0375	0000	%0572	J24	\$
004690	004973	-00007	0875	0000	0750	0125	1000	0250	0000	%0573	J25	\$
004619	005105	-00409	0875	0000	0875	0125	1000	0125	0000	%0574	J26	\$
004471	005164	-01431	0875	0000	1000	0125	1000	0000	0000	%0575	J27	\$
005008	004180	003203	0875	0125	0000	0125	0875	1000	0000	%0576	K19	\$
005005	004307	002776	0875	0125	0125	0125	0875	0875	0000	%0577	K20	\$
004952	004463	002168	0875	0125	0250	0125	0875	0750	0000	%0578	K21	\$
004957	004535	001624	0875	0125	0375	0125	0875	0625	0000	%0579	K22	\$
004889	004593	001188	0875	0125	0500	0125	0875	0500	0000	%0580	K23	\$
004882	004621	000647	0875	0125	0625	0125	0875	0375	0000	%0581	K24	\$
004826	004787	000100	0875	0125	0750	0125	0875	0250	0000	%0582	K25	\$
004858	004697	-00563	0875	0125	0875	0125	0875	0125	0000	%0583	K26	\$
004996	004523	-01309	0875	0125	1000	0125	0875	0000	0000	%0584	K27	\$
005342	003499	003372	0875	0250	0000	0125	0750	1000	0000	%0585	L19	\$
005472	003449	003109	0875	0250	0125	0125	0750	0875	0000	%0586	L20	\$
005526	003643	002305	0875	0250	0250	0125	0					

009666	000001	-000001	1000	1000	1000	0000	0000	0000	0000	%0729	b01	\$
009881	-00566	-00831	0875	1000	1000	00125	0000	0000	0000	%0730	b02	\$
008282	-00837	-01157	0750	1000	1000	00250	0000	0000	0000	%0731	b03	\$
007766	-01184	-01487	0625	1000	1000	00375	0000	0000	0000	%0732	b04	\$
007329	-01744	-01857	0500	1000	1000	00500	0000	0000	0000	%0733	b05	\$
006794	-02132	-02458	0375	1000	1000	00625	0000	0000	0000	%0734	b06	\$
006200	-02732	-03139	0250	1000	1000	00750	0000	0000	0000	%0735	b07	\$
005746	-03011	-03497	0125	1000	1000	00875	0000	0000	0000	%0736	b08	\$
005368	-03437	-03976	0000	1000	1000	00900	0000	0000	0000	%0737	b09	\$
008776	000839	000362	1000	0875	0875	0000	0125	0125	0000	%0738	c01	\$
008368	000001	000016	0875	0875	0875	0007	0125	0125	0000	%0739	c02	\$
008005	-00514	-00747	0750	0875	0875	00250	0125	0125	0000	%0740	c03	\$
007213	-00867	-01135	0625	0875	0875	00375	0125	0125	0000	%0741	c04	\$
006725	-01219	-01610	0500	0875	0875	00500	0125	0125	0000	%0742	c05	\$
006232	-01785	-01987	0375	0875	0875	00625	0125	0125	0000	%0743	c06	\$
005707	-02181	-02569	0250	0875	0875	00750	0125	0125	0000	%0744	c07	\$
005460	-02334	-02725	0125	0875	0875	00875	0125	0125	0000	%0745	c08	\$
005361	-03340	-03998	0000	0875	0875	00900	0125	0125	0000	%0746	c09	\$
008381	001491	000955	1000	0750	0750	0000	0250	0250	0000	%0747	d01	\$
007925	000743	000291	0875	0750	0750	00125	0250	0250	0000	%0748	d02	\$
007495	000046	-00049	0750	0750	0750	00250	0250	0250	0000	%0749	d03	\$
006865	-00369	-00499	0625	0750	0750	00375	0250	0250	0000	%0750	d04	\$
006301	-00780	-01158	0500	0750	0750	00500	0250	0250	0000	%0751	d05	\$
005847	-01271	-01630	0375	0750	0750	00625	0250	0250	0000	%0752	d06	\$
005365	-01715	-02000	0250	0750	0750	00750	0250	0250	0000	%0753	d07	\$
005152	-01736	-02278	0125	0750	0750	00875	0250	0250	0000	%0754	d08	\$
005443	-02119	-02706	0000	0750	0750	00900	0250	0250	0000	%0755	d09	\$
007873	002266	001393	1000	0625	0625	0000	0375	0375	0000	%0756	e01	\$
007356	001466	000728	0875	0625	0625	00125	0375	0375	0000	%0757	e02	\$
006936	000785	000436	0750	0625	0625	00250	0375	0375	0000	%0758	e03	\$
006420	-00001	-00091	0625	0625	0625	00375	0375	0375	0000	%0759	e04	\$
005956	-00418	-00532	0500	0625	0625	00500	0375	0375	0000	%0760	e05	\$
005503	-00929	-01046	0375	0625	0625	00625	0375	0375	0000	%0761	e06	\$
004950	-01308	-01683	0250	0625	0625	00750	0375	0375	0000	%0762	e07	\$
004730	-01394	-01911	0125	0625	0625	00875	0375	0375	0000	%0763	e08	\$
004656	-01347	-01858	0000	0625	0625	00900	0375	0375	0000	%0764	e09	\$
007387	002913	001910	1000	0500	0500	0000	0500	0500	0000	%0765	f01	\$
006781	002190	001390	0875	0500	0500	00125	0500	0500	0000	%0766	f02	\$
006338	001472	001008	0750	0500	0500	00250	0500	0500	0000	%0767	f03	\$
005812	000837	000444	0625	0500	0500	00375	0500	0500	0000	%0768	f04	\$
005308	-00017	-00080	0500	0500	0500	00500	0500	0500	0000	%0769	f05	\$
005066	-00414	-00628	0375	0500	0500	00625	0500	0500	0000	%0770	f06	\$
004531	-00900	-01215	0250	0500	0500	00750	0500	0500	0000	%0771	f07	\$
004208	-01196	-01301	0125	0500	0500	00875	0500	0500	0000	%0772	f08	\$
004045	-00847	-01121	0000	0500	0500	00900	0500	0500	0000	%0773	f09	\$
006667	004069	000239	1000	0375	0375	0000	0625	0625	0000	%0774	g01	\$
005588	003097	001705	0875	0375	0375	00125	0625	0625	0000	%0775	g02	\$
005095	002365	001428	0750	0375	0375	00250	0625	0625	0000	%0776	g03	\$
005117	001609	001039	0625	0375	0375	00375	0625	0625	0000	%0777	g04	\$
004783	000832	000442	0500	0375	0375	00500	0625	0625	0000	%0778	g05	\$
004467	-00008	-00032	0375	0375	0375	00625	0625	0625	0000	%0779	g06	\$
004174	-00388	-00622	0250	0375	0375	00750	0625	0625	0000	%0780	g07	\$
003791	-00721	-01226	0125	0375	0375	00875	0625	0625	0000	%0781	g08	\$
003785	-00721	-01243	0000	0375	0375	00900	0625	0625	0000	%0782	g09	\$
006167	004739	003222	1000	0250	0250	0000	0750	0750	0000	%0783	h01	\$
005412	003688	002296	0875	0250	0250	00125	0750	0750	0000	%0784	h02	\$
004904	003173	001994	0750	0250	0250	00250	0750	0750	0000	%0785	h03	\$
004532	002532	001388	0625	0250	0250	00375	0750	0750	0000	%0786	h04	\$
004276	001454	001086	0500	0250	0250	00500	0750	0750	0000	%0787	h05	\$
004038	000756	000415	0375	0250	0250	00625	0750	0750	0000	%0788	h06	\$
003646	-00008	-00064	0250	0250	0250	00750	0750	0750	0000	%0789	h07	\$
003969	-00269	-00442	0125	0250	0250	00875	0750	0750	0000	%0790	h08	\$
002547	-00089	-00255	0000	0250	0250	00900	0750	0750	0000	%0791	h09	\$
005432	005521	003679	1000	0125	0125	0000	0875	0875	0000	%0792	i01	\$
004889	004171	002804	0875	0125	0125	00125	0875	0875	0000	%0793	i02	\$
004810	003951	002487	0750	0125	0125	00250	0875	0875	0000	%0794	i03	\$
004639	002764	001707	0625	0125	0125	00375	0875	0875	0000	%0795	i04	\$
004407	001773	001626	0500	0125	0125	00500	0875	0875	0000	%0796	i05	\$
003889	000878	000706	0375	0125	0125	00625	0875	0875	0000	%0797	i06	\$
003364	000431	000335	0250	0125	0125	00750	0875	0875	0000	%0798	i07	\$
002824	-00015	-00082	0125	0125	0125	00875	0875	0875	0000	%0799	i08	\$
002330	-00028	-00087	0000	0125	0125	00900	0875	0875	0000	%0800	i09	\$
004763	005855	004018	1000	0000	0000	0000	1000	1000	0000	%0801	j01	\$
004761	005761	003502	0875	0000	0000	00125	1000	1000	0000	%0802	j02	\$
004751	003930	002416	0750	0000	0000	00250	1000	1000	0000	%0803	j03	\$
004816	003853	002398	0625	0000	0000	00375	1000	1000	0000	%0804	j04	\$
004656	002769	001621	0500	0000	0000	00500	1000	1000	0000	%0805	j05	\$
003845	000989	000653	0375	0000	0000	00625	1000	1000	0000	%0806	j06	\$
003943	000379	000233	0250	0000	0000	00750	1000	1000	0000	%0807	j07	\$
002454	000163	000111	0125	0000	0000	00875	1000	1000	0000	%0808	j08	\$
001129	-00003	-00005	0000	0000	0000	00900	1000	1000	0000	%0809	j09	\$
009705	000001	-00005	1000	1000	1000	0000	0000	0000	0000	%0810	b10	\$
008685	000202	-00549	0875	0875	0875	00125	0125	0125	0000	%0811	b11	\$
008115	000340	-01013	0750	0750	0750	00250	0250	0250	0000	%0812	b12	\$
007194	000572	-01825	0625	1000	0375	0375	0000	0000	0000	%0813	b13	\$
006408	000884	-01792	0500	0500	0500	0500	0000	0000	0000	%0814	b14	\$
005662	000939	-02385	0375	0375	1000	0625	0625	0000	0000	%0815	b15	\$
004905	001276	-03065	0250	0250	0750	0750	0000	0000	0000	%0816	b16	\$
004395	001469	-03632	0125	0250	1000	0875	0875	0000	0000	%0817	b17	\$
003228	001991	-04377	0000	1000	1000	0900	0000	0000	0000	%0818	b18	\$
000486	000000	000598	1000	1000	0875	0000	0125	0000	0000	%0819	c10	\$
008544	000008	-00007	0875	0875	0875	0125	0125	0125	0000	%0820	c11	\$
007923	000193	-00534	0750	0750	0875	0250	0250	0125	0000	%0821	c12	\$
006981	000414	-00972	0625	0625	0875	0375	0375	0125	0000	%0822	c13	\$
006234	000656	-01452	0500	0500	0875	0500	0500	0125	0000	%0823	c14	\$
005393	000963	-01945	0375	0375	0875	0625	0625	0125	0000	%0824	c15	\$
004480	001056	-02629	0250	0250	0875	0750	0750	0125	0000	%0825	c16	\$
004083	001491	-02809	0125	0125	0875	0875	0125	0000	0000	%0826	c17	\$
003674	001764	-04218	0000	0000	0750	1000	1000	0125	0000	%0827	c18	\$
003925	000114	-001407	1000	1000	0750	0000	0250	0000	0000	%0828	d10	\$
008587	-00007	000587										

%BEG GE63_22.TXT, Separation cmyn4*, cfi=0.90, D50, adapted \$
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos \$
%z004883 005795 003947 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008726 -00619 007367 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005748 -05933 002965 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005343 -03451 -03976 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z003357 002134 -04316 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z004694 006522 -00900 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z001269 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009643 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004763 005855 004018 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008739 -00639 007269 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005739 -05896 002896 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005368 -03437 -03976 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003285 001991 -04377 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z004740 006538 -00882 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z001119 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009692 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/GE73/GE73L0NA.TXT> / .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.18; nx=1.0

%BEG GE63.22.TXT, Separation cmyn4*, cfi=0.90, D50, adapted S		%100 x LAB*a		1000 x (r g b c m y o)		%nrr. pos \$																																	
001171	-00017	000036	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$	008388	000011	000001	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$	008703	000008	000008	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$	
002503	-00025	-00013	0125	0125	0125	0125	0875	0875	0875	0000	%0973	k02	\$	009637	000000	-00002	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$	001239	-00007	000027	0000	0000	0000	1000	1000	0000	%1056	n10	\$	
003407	-00008	-00006	0250	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$	002519	-00012	-00045	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$	002769	-00011	-00046	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$
004269	-00003	-00001	0375	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$	003153	-00002	-00048	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$	003900	-00027	-00028	0266	0266	0266	0333	0333	0333	0000	%1060	n14	\$
005227	000000	-00036	0500	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	004339	000011	-00053	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$	004565	-00004	000067	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$
006389	000009	-00060	0625	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$	005237	000019	-00049	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$	005574	000032	000041	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$
007525	000056	-00037	0750	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$	006258	-00007	-00031	0600	0600	0600	0600	0600	0600	0400	%1065	n19	\$	006653	000021	000073	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$
008523	000018	-00010	0875	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$	007249	000002	-00029	0734	0734	0734	0266	0266	0266	0000	%1067	n21	\$	007903	000011	-00010	0800	0800	0800	0200	0200	0200	0000	%1068	n22	\$
009705	000002	-00017	1000	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$	008338	000012	000008	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$	008700	000013	000007	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$
010152	-00019	000040	0000	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$	009656	000000	-00017	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$	010102	000000	000000	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$
002438	-00025	-00036	0125	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$	009613	000000	000000	0000	1000	1000	0000	0000	0000	0000	%1073	k27	\$	004727	005760	004082	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
003407	-00016	-00012	0250	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$	005249	-03677	-03806	0000	1000	1000	0000	0000	0000	0000	%1075	l27	\$	008586	-00591	007525	1000	1000	0000	0000	1000	0000	0000	%1076	m26	\$
004274	-00006	-00003	0375	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$	003174	002104	-04445	0000	0000	1000	1000	0000	0000	0000	%1077	m27	\$	005609	-06168	002912	1000	1000	0000	1000	0000	0000	%1078	n26	\$	
005226	-00005	-00051	0500	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	004655	006613	-00937	1000	0000	1000	0000	0000	0000	0000	%1079	n27	\$	006455	006613	-00937	1000	0000	1000	0000	0000	0000	%1079	n27	\$	
006382	000004	-00073	0625	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$	% \$														% \$											
007547	000032	-00036	0750	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$	%z004727 005760 004082 ##1000 0000 0000 0000 1000 1000 0000 %1074 l26 %03 0 \$														%z008586 -00591 007525 ##1000 1000 0000 0000 0000 1000 0000 %1076 m26 %Y3 1 \$											
008505	000007	-00011	0875	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$	%z005609 -06168 002912 ##0000 1000 0000 1000 0000 0000 0000 %1078 n26 %L3 2 \$														%z005249 -03677 -03806 ##0000 1000 1000 0000 0000 0000 0000 %1075 l27 %C3 3 \$											
009697	-00002	-00012	1000	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$	%z008102 000000 000000 ##0000 0000 0000 1000 1000 0000 %1072 k26 %M3 5 \$														%z009613 000000 000000 ##1000 1000 0000 0000 0000 0000 %1073 k27 %M3 7 \$											
010181	-00011	000028	0000	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$	% \$														%z001171 -00017 000036 ##0000 0000 0000 1000 1000 0000 %0972 k01 %N4 6 \$											
002559	-00016	-00020	0125	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$	%z009705 000002 -00017 ##1000 1000 1000 0000 0000 0000 0000 %0980 k09 %W4 7 \$														%z001152 -00019 000040 ##0000 0000 0000 1000 1000 0000 0000 %0981 l01 %N5 6 \$											
003455	-00006	-00018	0250	0250	0250	0250	0750	0750	0750	0000	%0992	m03	\$	% \$														%z009697 -00002 -00012 ##1000 1000 1000 0000 0000 0000 0000 %0989 l09 %W5 7 \$											
004355	-00006	-00002	0375	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$	%z001181 -00011 000028 ##0000 0000 0000 1000 1000 0000 0000 %0990 m01 %N6 6 \$														%z009712 -00006 -00003 ##1000 1000 1000 0000 0000 0000 0000 %0998 m09 %W6 7 \$											
005252	-00006	-00037	0500	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$	% \$														% \$											
006441	-00001	-00061	0625	0625	0625	0625	0375	0375	0375	0000	%1004	n06	\$	%z001169 -00018 000032 ##0000 0000 0000 1000 1000 0000 0000 %0999 n01 %N7 6 \$														%z009709 -00002 -00019 ##1000 1000 1000 0000 0000 0000 0000 %1007 n09 %W7 7 \$											
007526	000046	-00034	0750	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$																										
008501	000008	000000	0875	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$																										
009709	-00002	-00019	1000	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$																										
010121	-00004	000029	0000	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$																										
002493	-00016	-00063	0066	0066	0066	0066	0333	0333	0333	0000	%1009	k11	\$																										
002758	-00017	-00056	0133	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$																										
003102	-00007	-00050	0200	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$																										
003845	-00024	-00041	0266	0266	0266	0266	0333	0333	0333	0000	%1012	k14	\$																										
004268	000013	-00063	0333	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$																										
004525	-00006	-00043	0400	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$																										
005199	000020	-00066	0466	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$																										
005531	000013	000061	0533	0533	0533	0533	0666	0666	0666	0000	%1016	k18	\$																										
006226	-00012	-00027	0600	0600	0600	0600	0800	0800	0800	0000	%1017	k19	\$																										
007237	000005	-00026	0666	0666	0666	0666	0333	0333	0333	0000	%1018	k20	\$																										
007327	000005	-00026	0734	0734	0734	0734	0266	0266	0266	0000	%1019	k21	\$																										
007905	000012	-00009	0800	0800	0800	0800	0200	0200	0200	0000	%1020	k22	\$																										
008348	000016	-00002	0866	0866	0866	0866	0133	0133	0133	0000	%1021	k23	\$																										
008692	000012	000002	0933	0933	0933	0933	0666	0666	0666	0000	%1022	k24	\$																										
009641	-00008	-00021	1000	1000	1000	1000	0000	0000	0000	0000	%1023	k25	\$																										
0101309	-00005	000014	0000	0000	0000	0000	1000	1000	1000	0000	%1024	l10	\$																										
002486	-00020	-00053	0066	0066	0066	0066	0333	0333	0333	0000	%1025	l11	\$																										
002729	-00021	-00067	0133	0133	0133	0133	0866	0866	0866	0000	%1026	l12	\$																										
003078	-00006	-00058	0200	0200	0200	0200	0800	0800	0800	0000	%1027	l13	\$																										
003859	-00028	-00042	0266	0266	0266	0266	0333	0333	0333	0000	%1028	l14	\$																										
004272	000012	-00065	0333	0333	0333	0333	0666	0666	0666	0000	%1029	l15	\$																										
004534	-00005	000016	0400	0400	0400	0400	0600	0600	0600	0000	%1030	l16	\$																										
005216	-00014	-00092	0466	0466	0466	0466	0533	0533	0533	0000	%1031	l17	\$																										
005540	000027	000014	0533	0533	0533	0533	0666	0666	0666	0000	%1032	l18	\$																										
006198	000000	-00065	0600	0600	0600	0600	0800	0800	0800	0000	%1033	l19	\$																										
006619	000023	000049	0666	0666	0666	0666	0333	0333	0333	0000	%1034	l20	\$																										
007259	000006	-00047	0734	0734	0734	0734	0266	0266	0266	0000	%1035	l21	\$																										
007909	000014	-00018	0800	0800	0800	0800	0200	0200	0200	0000	%1036	l22	\$																										
008360	000013	-00006	0866	0866	0866	0866	0133	0133	0133	0000	%1037	l23	\$																										
0087719	000009	000002	0																																				