

http://xxx/HE76/HE76L0NA.TXT/ .PS, Page 1/24; FRS09_92, L*=09_92
N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB registration: 20091101-HE76/HE76L0NA.TXT/.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

TUB-test chart HE76; Relative Elementary Colour System G
1080 spectral reflexions R → LAB* for D65 and D50

input: w *setgray*
output: no change compared to input

See original or copy: <http://web.me.com/klaus.richter/HE76/HE76L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cf1=0.90; nt=0.01; nx=1.33

[illegible]

0262617	001557	0016044	0250	0000	0000	0750	1000	1000	0000	00162	S91
0262517	001918	-00083	0250	0000	0125	0750	1000	0875	0000	00163	S92
0262637	001347	-0149	0250	0000	0250	0750	1000	0750	0000	00164	S93
0262594	001264	-0105	0250	0000	0375	0750	1000	0625	0000	00165	S94
0262600	001161	-02098	0250	0000	0500	0750	1000	0500	0000	00166	S95
0262849	001030	-02435	0250	0000	0625	0750	1000	0375	0000	00167	S96
0263248	000966	-02792	0250	0000	0750	0750	1000	0250	0000	00168	S97
0263641	000868	-03206	0250	0000	0875	0750	1000	0125	0000	00169	S98
0263808	001254	-03839	0250	0000	1000	0750	1000	0000	0000	00170	S99
0263151	000690	001831	0250	0125	0000	0750	0875	1000	0000	00171	T01
0262998	000890	000448	0250	0125	0125	0750	0875	0875	0000	00172	T02
0263179	000695	-00520	0250	0125	0250	0750	0875	0750	0000	00173	T03
0263263	000644	-01193	0250	0125	0375	0750	0875	0625	0000	00174	T04
0263357	000437	-01528	0250	0125	0500	0750	0875	0500	0000	00175	T05
0263605	000414	-02054	0250	0125	0625	0750	0875	0375	0000	00176	T06
0264011	000385	-02409	0250	0125	0750	0750	0875	0250	0000	00177	T07
0264256	000556	-02870	0250	0125	0875	0750	0875	0125	0000	00178	T08
0264543	000480	-03317	0250	0125	1000	0750	0875	0000	0000	00179	T09
0263678	-00371	002523	0250	0250	0000	0750	0750	1000	0000	00180	U01
0263501	-00113	001027	0250	0250	0125	0750	0750	0875	0000	00181	U02
0263594	-00009	000802	0250	0250	0250	0750	0750	0750	0000	00182	U03
0264030	000008	-00652	0250	0250	0375	0750	0750	0625	0000	00183	U04
0264201	-00159	-01270	0250	0250	0500	0750	0750	0500	0000	00184	U05
0264687	-00163	-01562	0250	0250	0625	0750	0750	0375	0000	00185	U06
0264771	-00162	-01943	0250	0250	0750	0750	0750	0250	0000	00186	U07
0265145	-00154	-02251	0250	0250	0875	0750	0750	0125	0000	00187	U08
0265404	-00097	-02577	0250	0250	1000	0750	0750	0000	0000	00188	U09
0264073	-01096	002879	0250	0375	0000	0750	0625	1000	0000	00189	V01
0264008	-00892	001423	0250	0375	0125	0750	0625	0875	0000	00190	V02
0264156	-00598	000209	0250	0375	0250	0750	0625	0750	0000	00191	V03
0264164	-00425	-00398	0250	0375	0375	0750	0625	0625	0000	00192	V04
0264583	-00679	-01144	0250	0375	0500	0750	0625	0500	0000	00193	V05
0264938	-00590	-01373	0250	0375	0625	0750	0625	0375	0000	00194	V06
0264988	-00521	-01894	0250	0375	0750	0750	0625	0250	0000	00195	V07
0265311	-00497	-02180	0250	0375	0875	0750	0625	0125	0000	00196	V08

%BEG HE66_22.TXT, Separation cmyn62*, cf1=0.90, D65, not adapted \$
%100 x LAB*
%#1000 x (r g b c m y 0) %nr. pos \$
%z004592 006021 002923 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008189 -00401 007067 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005553 -05218 001979 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005655 -04150 -02405 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z004108 000259 -04046 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003667 004097 -02486 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z002960 000490 000366 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009187 -00083 000216 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004518 006029 003081 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008199 -00409 007096 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005621 -05197 001782 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005559 -04132 -02519 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003989 000256 -04136 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003655 004094 -02464 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z002098 000549 000380 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009333 -00085 000208 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/HE76/HE76L0NA.TXT/> .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.01; nx=1.3

%BEG HE66.22.TXT, Separation cmyn62*, cfi=0.90, D65, not adapted \$
%100 x LAB* 1000 x (r g b c m y 0) %nrr. pos \$
001939 0000545 000355 0000 0000 0000 1000 1000 1000 0000 %0972 k01 \$
002657 000006 000144 0125 0125 0125 0875 0875 0875 0000 %0973 k02 \$
003544 -00009 000027 0250 0250 0250 0750 0750 0750 0000 %0974 k03 \$
004528 000021 000054 0375 0375 0375 0625 0625 0625 0000 %0975 k04 \$
005473 -00044 000111 0500 0500 0500 0500 0500 0500 0000 %0976 k05 \$
006540 000002 000066 0625 0625 0625 0625 0625 0625 0000 %0977 k06 \$
007482 -00046 000121 0750 0750 0750 0250 0250 0250 0000 %0978 k07 \$
008489 -00056 000185 0875 0875 0875 0125 0125 0125 0000 %0979 k08 \$
009373 -00082 000195 1000 1000 1000 0000 0000 0000 0000 %0980 k09 \$
001934 000538 000340 0000 0000 0000 1000 1000 1000 0000 %0981 l01 \$
002661 000012 000130 0125 0125 0125 0875 0875 0875 0000 %0982 l02 \$
003545 -00006 000028 0250 0250 0250 0750 0750 0750 0000 %0983 l03 \$
004480 000022 000041 0375 0375 0375 0625 0625 0625 0000 %0984 l04 \$
005434 -00029 000087 0500 0500 0500 0500 0500 0500 0000 %0985 l05 \$
006508 000001 000059 0625 0625 0625 0625 0625 0625 0000 %0986 l06 \$
007459 -00042 000120 0750 0750 0750 0250 0250 0250 0000 %0987 l07 \$
008498 -00057 000185 0875 0875 0875 0125 0125 0125 0000 %0988 l08 \$
009366 -00085 000204 1000 1000 1000 0000 0000 0000 0000 %0989 l09 \$
001911 000544 000359 0000 0000 0000 1000 1000 1000 0000 %0990 m01 \$
002554 000008 000152 0125 0125 0125 0875 0875 0875 0000 %0991 m02 \$
003459 000005 000040 0250 0250 0250 0750 0750 0750 0000 %0992 m03 \$
004461 000030 000059 0375 0375 0375 0625 0625 0625 0000 %0993 m04 \$
005338 -00028 000116 0500 0500 0500 0500 0500 0500 0000 %0994 m05 \$
006414 000000 000096 0625 0625 0625 0375 0375 0375 0000 %0995 m06 \$
007412 -00046 000143 0750 0750 0750 0250 0250 0250 0000 %0996 m07 \$
008479 -00058 000196 0875 0875 0875 0125 0125 0125 0000 %0997 m08 \$
009369 -00086 000208 1000 1000 1000 0000 0000 0000 0000 %0998 m09 \$
001920 000530 000351 0000 0000 0000 1000 1000 1000 0000 %0999 n01 \$
002656 000003 000160 0125 0125 0125 0875 0875 0875 0000 %1000 n02 \$
003551 -00003 000033 0250 0250 0250 0750 0750 0750 0000 %1001 n03 \$
004561 000019 000065 0375 0375 0375 0625 0625 0625 0000 %1002 n04 \$
005453 -00033 000097 0500 0500 0500 0500 0500 0500 0000 %1003 n05 \$
006509 000000 000062 0625 0625 0625 0375 0375 0375 0000 %1004 n06 \$
007474 -00047 000136 0750 0750 0750 0250 0250 0250 0000 %1005 n07 \$
008490 -00056 000190 0875 0875 0875 0125 0125 0125 0000 %1006 n08 \$
009366 -00080 000194 1000 1000 1000 0000 0000 0000 0000 %1007 n09 \$
002133 000546 000332 0000 0000 0000 1000 1000 1000 0000 %1008 k10 \$
003214 000187 000257 0066 0066 0066 0933 0933 0933 0000 %1009 k11 \$
002951 000027 000062 0133 0133 0133 0866 0866 0866 0000 %1010 k12 \$
003352 000012 000022 0200 0200 0200 0800 0800 0800 0000 %1011 k13 \$
003780 000007 000043 0266 0266 0266 0333 0333 0333 0000 %1012 k14 \$
004395 000000 000059 0333 0333 0333 0666 0666 0666 0000 %1013 k15 \$
004977 000001 000121 0400 0400 0400 0600 0600 0600 0000 %1014 k16 \$
005287 000019 000110 0466 0466 0466 0533 0533 0533 0000 %1015 k17 \$
005952 000020 000080 0533 0533 0533 0466 0466 0466 0000 %1016 k18 \$
006418 000003 000141 0600 0600 0600 0400 0400 0400 0000 %1017 k19 \$
006876 -00040 000126 0666 0666 0666 0333 0333 0333 0000 %1018 k20 \$
007329 -00004 000179 0734 0734 0734 0266 0266 0266 0000 %1019 k21 \$
007536 -00036 000140 0800 0800 0800 0200 0200 0200 0000 %1020 k22 \$
008192 -00038 000195 0866 0866 0866 0133 0133 0133 0000 %1021 k23 \$
008896 -00061 000192 0933 0933 0933 0066 0066 0066 0000 %1022 k24 \$
009186 -00069 000193 1000 1000 1000 0000 0000 0000 0000 %1023 k25 \$
002087 000564 000336 0000 0000 0000 1000 1000 1000 0000 %1024 l10 \$
002350 000198 000276 0066 0066 0066 0933 0933 0933 0000 %1025 l11 \$
002995 000030 000077 0133 0133 0133 0866 0866 0866 0000 %1026 l12 \$
003354 000009 000057 0200 0200 0200 0800 0800 0800 0000 %1027 l13 \$
003811 000000 000052 0266 0266 0266 0333 0333 0333 0000 %1028 l14 \$
004397 000004 000071 0333 0333 0333 0666 0666 0666 0000 %1029 l15 \$
005013 000012 000138 0400 0400 0400 0600 0600 0600 0000 %1030 l16 \$
005323 000028 000106 0466 0466 0466 0533 0533 0533 0000 %1031 l17 \$
005970 000037 000056 0533 0533 0533 0466 0466 0466 0000 %1032 l18 \$
006391 000027 000087 0600 0600 0600 0400 0400 0400 0000 %1033 l19 \$
006874 -00028 000099 0666 0666 0666 0333 0333 0333 0000 %1034 l20 \$
007317 000014 000150 0734 0734 0734 0266 0266 0266 0000 %1035 l21 \$
007501 000030 000144 0800 0800 0800 0200 0200 0200 0000 %1036 l22 \$
008222 -00036 000199 0866 0866 0866 0133 0133 0133 0000 %1037 l23 \$
008923 -00060 000195 0933 0933 0933 0066 0066 0066 0000 %1038 l24 \$
009218 -00070 000197 1000 1000 1000 0000 0000 0000 0000 %1039 l25 \$
002077 000580 000330 0000 0000 0000 1000 1000 1000 0000 %1040 m10 \$
002299 000192 000274 0066 0066 0066 0933 0933 0933 0000 %1041 m11 \$
002948 000037 000072 0133 0133 0133 0866 0866 0866 0000 %1042 m12 \$
003323 000012 000057 0200 0200 0200 0800 0800 0800 0000 %1043 m13 \$
003749 000013 000062 0266 0266 0266 0333 0333 0333 0000 %1044 m14 \$
004370 -00001 000095 0333 0333 0333 0666 0666 0666 0000 %1045 m15 \$
004966 000011 000126 0400 0400 0400 0600 0600 0600 0000 %1046 m16 \$
005271 000030 000124 0466 0466 0466 0533 0533 0533 0000 %1047 m17 \$
005903 000032 000056 0533 0533 0533 0466 0466 0466 0000 %1048 m18 \$
006331 000030 000106 0600 0600 0600 0400 0400 0400 0000 %1049 m19 \$
006810 -00026 000114 0666 0666 0666 0333 0333 0333 0000 %1050 m20 \$
007283 000012 000159 0734 0734 0734 0266 0266 0266 0000 %1051 m21 \$
007498 -00024 000155 0800 0800 0800 0200 0200 0200 0000 %1052 m22 \$

008339 -00050 000190 0866 0866 0866 0133 0133 0133 0000 %1053 m23 \$
008938 -00064 000204 0933 0933 0933 0066 0066 0066 0000 %1054 m24 \$
009230 -00078 000214 1000 1000 1000 0000 0000 0000 0000 %1055 m25 \$
002092 000542 000345 0000 0000 0000 1000 1000 1000 0000 %1056 n10 \$
002307 000198 000264 0066 0066 0066 0933 0933 0933 0000 %1057 n11 \$
002933 000022 000080 0133 0133 0133 0866 0866 0866 0000 %1058 n12 \$
003322 000012 000045 0200 0200 0200 0800 0800 0800 0000 %1059 n13 \$
003787 000006 000063 0266 0266 0266 0333 0333 0333 0000 %1060 n14 \$
004405 000000 000083 0333 0333 0333 0666 0666 0666 0000 %1061 n15 \$
005006 000003 000153 0400 0400 0400 0600 0600 0600 0000 %1062 n16 \$
005307 000018 000132 0466 0466 0466 0533 0533 0533 0000 %1063 n17 \$
005998 000028 000088 0533 0533 0533 0466 0466 0466 0000 %1064 n18 \$
006429 000012 000133 0600 0600 0600 0400 0400 0400 0000 %1065 n19 \$
006872 -00038 000124 0666 0666 0666 0333 0333 0333 0000 %1066 n20 \$
007307 000004 000176 0734 0734 0734 0266 0266 0266 0000 %1067 n21 \$
007556 -00037 000147 0800 0800 0800 0200 0200 0200 0000 %1068 n22 \$
008281 -00051 000194 0866 0866 0866 0133 0133 0133 0000 %1069 n23 \$
008913 -00063 000198 0933 0933 0933 0066 0066 0066 0000 %1070 n24 \$
009228 -00073 000196 1000 1000 1000 0000 0000 0000 0000 %1071 n25 \$
002008 000528 000443 0000 0000 0000 1000 1000 1000 0000 %1072 k26 \$
009129 -00075 000214 1000 1000 1000 0000 0000 0000 0000 %1073 k27 \$
004451 000590 003226 1000 0000 0000 0000 1000 1000 0000 %1074 l26 \$
005589 -04596 -02162 0000 1000 1000 1000 0000 0000 0000 %1075 l27 \$
008014 -00309 007268 1000 1000 0000 0000 1000 1000 0000 %1076 m26 \$
003847 000288 -04082 0000 0000 1000 1000 1000 0000 0000 %1077 m27 \$
005390 -05433 002001 0000 1000 0000 1000 0000 1000 0000 %1078 n26 \$
003646 000361 -02530 1000 0000 1000 0000 1000 0000 0000 %1079 n27 \$
%\$
%z004451 005990 003226 %01000 0000 0000 0000 1000 1000 0000 %1074 l26 %03 0 \$
%z008014 -00309 007268 %01000 1000 0000 0000 0000 1000 0000 %1076 m26 %Y3 1 \$
%z005390 -05433 002001 %0000 1000 0000 0000 0000 1000 0000 %1078 n26 %L3 2 \$
%z005589 -04596 -02162 %0000 1000 1000 0000 0000 0000 1000 0000 %1075 l27 %C3 3 \$
%z003847 000288 -04082 %0000 0000 1000 1000 1000 0000 0000 %1077 m27 %V3 4 \$
%z003646 000361 -02530 %01000 1000 0000 0000 0000 1000 0000 %1079 n27 %W3 5 \$
%z002008 000528 000443 %0000 0000 0000 1000 1000 0000 %1072 k26 %W3 6 \$
%z009129 -00075 000214 %01000 1000 1000 0000 0000 0000 %1073 k27 %W3 7 \$
%\$
%z002036 000545 000343 %0000 0000 0000 1000 1000 0000 %0972 k01 %N4 6 \$
%z009280 -00076 000394 %01000 1000 1000 0000 0000 0000 %0980 k09 %W4 7 \$
%\$
%z002011 000551 000338 %0000 0000 0000 1000 1000 0000 %0981 l01 %N5 6 \$
%z009292 -00078 000200 %01000 1000 1000 0000 0000 0000 %0989 l09 %W5 7 \$
%\$
%z001994 000562 000344 %0000 0000 0000 1000 1000 0000 %0990 m01 %N6 6 \$
%z009299 -00082 000211 %01000 1000 1000 0000 0000 0000 %0998 m09 %W6 7 \$
%\$
%z002006 000536 000348 %0000 0000 0000 1000 1000 0000 %0999 n01 %N7 6 \$
%z009297 -00076 000195 %01000 1000 1000 0000 0000 0000 %1007 n09 %W7 7 \$
%\$

%BEG HE66.22.TXT, Separation cmyn62*, cf1=0.90, D65, adapted \$			LAB*a			1000 x (r g b c m y o)			nmr. pos \$		
002060	000000	000000	0000	0000	0000	0000	0000	0000	0000	0000	A01 \$
002314	000209	-01330	0000	0000	0125	1000	1000	0875	0000	0000	A02 \$
002457	-00017	-01740	0000	0000	0250	1000	1000	0750	0000	0000	A03 \$
002707	-00253	-02050	0000	0000	0375	1000	1000	0625	0000	0000	A04 \$
003130	-00461	-02292	0000	0000	0500	1000	1000	0500	0000	0000	A05 \$
003423	-00527	-02578	0000	0000	0625	1000	1000	0375	0000	0000	A06 \$
003680	-00472	-03133	0000	0000	0750	1000	1000	0250	0000	0000	A07 \$
003937	-00223	-03587	0000	0000	0875	1000	1000	0125	0000	0000	A08 \$
004108	-00064	-04350	0000	0000	1000	1000	0000	0000	0000	0000	A09 \$
002623	-00891	000508	0000	0125	0000	1000	0875	1000	0000	0000	B01 \$
002474	-00655	-01156	0000	0125	0125	1000	0875	0875	0000	0000	B02 \$
002707	-00808	-01520	0000	0125	0250	1000	0875	0750	0000	0000	B03 \$
002946	-00934	-01933	0000	0125	0375	1000	0875	0625	0000	0000	B04 \$
003284	-01017	-02342	0000	0125	0500	1000	0875	0500	0000	0000	B05 \$
003506	-00927	-02648	0000	0125	0625	1000	0875	0375	0000	0000	B06 \$
003785	-00861	-03137	0000	0125	0750	1000	0875	0250	0000	0000	B07 \$
003993	-00723	-03567	0000	0125	0875	1000	0875	0125	0000	0000	B08 \$
004209	-00663	-04297	0000	0125	1000	1000	0875	0000	0000	0000	B09 \$
003301	-01435	000606	0000	0250	0000	1000	0750	1000	0000	0000	C01 \$
003056	-01404	-00175	0000	0250	0125	1000	0750	0875	0000	0000	C02 \$
003014	-01365	-00923	0000	0250	0250	1000	0750	0750	0000	0000	C03 \$
003133	-01498	-01998	0000	0250	0375	1000	0750	0625	0000	0000	C04 \$
003420	-01382	-02366	0000	0250	0500	1000	0750	0500	0000	0000	C05 \$
003734	-01382	-02552	0000	0250	0625	1000	0750	0375	0000	0000	C06 \$
003912	-01174	-03047	0000	0250	0750	1000	0750	0250	0000	0000	C07 \$
004140	-01170	-03563	0000	0250	0875	1000	0750	0125	0000	0000	C08 \$
004405	-01203	-04090	0000	0250	1000	1000	0750	0000	0000	0000	C09 \$
003634	-02165	-00565	0000	0375	0000	1000	0625	1000	0000	0000	D01 \$
003317	-01945	-00236	0000	0375	0125	1000	0625	0875	0000	0000	D02 \$
003256	-01992	-00712	0000	0375	0250	1000	0625	0750	0000	0000	D03 \$
003245	-01863	-01614	0000	0375	0375	1000	0625	0625	0000	0000	D04 \$
003743	-01792	-02206	0000	0375	0500	1000	0625	0500	0000	0000	D05 \$
003939	-01750	-02420	0000	0375	0625	1000	0625	0375	0000	0000	D06 \$
004067	-01659	-02804	0000	0375	0750	1000	0625	0250	0000	0000	D07 \$
004284	-01554	-03579	0000	0375	0875	1000	0625	0125	0000	0000	D08 \$
004525	-01540	-04048	0000	0375	1000	1000	0625	0000	0000	0000	D09 \$
003778	-02728	000480	0000	0500	0000	1000	0500	1000	0000	0000	E01 \$
003460	-02493	-00216	0000	0500	0125	1000	0500	0875	0000	0000	E02 \$
003415	-02411	-00596	0000	0500	0250	1000	0500	0750	0000	0000	E03 \$
003481	-02341	-01217	0000	0500	0375	1000	0500	0625	0000	0000	E04 \$
003672	-02053	-01886	0000	0500	0500	1000	0500	0500	0000	0000	E05 \$
004159	-02092	-02612	0000	0500	0625	1000	0500	0375	0000	0000	E06 \$
004298	-02091	-02965	0000	0500	0750	1000	0500	0250	0000	0000	E07 \$
004545	-01948	-03509	0000	0500	0875	1000	0500	0125	0000	0000	E08 \$
004648	-01932	-03958	0000	0500	1000	1000	0500	0000	0000	0000	E09 \$
004904	-03291	000782	0000	0625	0000	1000	0375	1000	0000	0000	F01 \$
003898	-03012	000145	0000	0625	0125	1000	0375	0875	0000	0000	F02 \$
003817	-02859	-00392	0000	0625	0250	1000	0375	0750	0000	0000	F03 \$
003809	-02736	-00901	0000	0625	0375	1000	0375	0625	0000	0000	F04 \$
003846	-02483	-01477	0000	0625	0500	1000	0375	0500	0000	0000	F05 \$
004016	-02273	-01992	0000	0625	0625	1000	0375	0375	0000	0000	F06 \$
004420	-02508	-02747	0000	0625	0750	1000	0375	0250	0000	0000	F07 \$
004662	-02549	-03505	0000	0625	0875	1000	0375	0125	0000	0000	F08 \$
004921	-02593	-03875	0000	0625	1000	1000	0375	0000	0000	0000	F09 \$
004502	-03914	001082	0000	0750	0000	1000	0250	1000	0000	0000	G01 \$
004403	-03798	000391	0000	0750	0125	1000	0250	0875	0000	0000	G02 \$
004432	-03546	-00160	0000	0750	0250	1000	0250	0750	0000	0000	G03 \$
004339	-03187	-00833	0000	0750	0375	1000	0250	0625	0000	0000	G04 \$
004420	-02986	-01262	0000	0750	0500	1000	0250	0500	0000	0000	G05 \$
004396	-02867	-01775	0000	0750	0625	1000	0250	0375	0000	0000	G06 \$
004384	-02712	-02306	0000	0750	0750	1000	0250	0250	0000	0000	G07 \$
004811	-03013	-03134	0000	0750	0875	1000	0250	0125	0000	0000	G08 \$
005668	-03567	-03766	0000	0750	1000	1000	0250	0000	0000	0000	G09 \$
005052	-04619	001511	0000	0875	0000	1000	0125	1000	0000	0000	H01 \$
004925	-04626	000644	0000	0875	0125	1000	0125	0875	0000	0000	H02 \$
004883	-04362	000074	0000	0875	0250	1000	0125	0750	0000	0000	H03 \$
004879	-04038	-00532	0000	0875	0375	1000	0125	0625	0000	0000	H04 \$
004854	-03704	-01177	0000	0875	0500	1000	0125	0500	0000	0000	H05 \$
004856	-03412	-01671	0000	0875	0625	1000	0125	0375	0000	0000	H06 \$
004838	-03289	-02098	0000	0875	0750	1000	0125	0250	0000	0000	H07 \$
004907	-03085	-02678	0000	0875	0875	1000	0125	0125	0000	0000	H08 \$
005689	-03549	-03770	0000	0875	1000	1000	0125	0000	0000	0000	H09 \$
005553	-05427	001686	0000	1000	0000	1000	0000	1000	0000	0000	I01 \$
005915	-05799	001144	0000	1000	0125	1000	0000	0875	0000	0000	I02 \$
005458	-05365	000340	0000	1000	0250	1000	0000	0750	0000	0000	I03 \$
005437	-04920	-00277	0000	1000	0375	1000	0000	0625	0000	0000	I04 \$
005419	-04576	-00935	0000	1000	0500	1000	0000	0500	0000	0000	I05 \$
005766	-04993	-01296	0000	1000	0625	1000	0000	0375	0000	0000	I06 \$
005719	-04648	-02094	0000	1000	0750	1000	0000	0250	0000	0000	I07 \$
005961	-03948	-02543	0000	1000	0875	1000	0000	0125	0000	0000	I08 \$
005655	-04351	-02696	0000	1000	1000	1000	0000	0000	0000	0000	I09 \$

TUB-test chart HE76; Relative Elementary Colour System G
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: -> olv* setrgbcolor

%BEG HE66_22.TXT, Separation cmyn62*, cf1=0.90, D65, adapted \$
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos \$
%z004592 005734 002609 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008189 -00398 006829 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005553 -05427 001686 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005655 -04351 -02696 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z004108 -00066 -04369 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003667 003735 -02819 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z002960 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009187 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004518 005693 002758 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008199 -00423 006861 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005621 -05437 001485 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005559 -04377 -02817 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003989 -00126 -04472 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003655 003681 -02808 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z002998 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009333 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

See original or copy: <http://web.me.com/klaus.richter/HE76/HE76L0NA.TXT/> .PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=0.90; nt=0.01; nx=1.3

```
%BEG HE66.22.TXT, Separation cmyn62*, cfi=0.90, D65, adapted $
%100 x LAB*a      1000 x (r g b      c m y 0)      %nrr. pos $
001939 000011 -00091 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002657 -00466 -00278 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
003544 -00407 -00366 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
004528 -00292 -00308 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
005473 -00279 -00220 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
006540 -00141 -00231 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
007482 -00111 -00145 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
008489 -00035 -00049 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
009473 -00012 -00018 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
001934 000003 -00106 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
002661 -00460 -00291 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
003545 -00403 -00366 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
004480 -00296 -00322 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
005434 -00267 -00246 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
006508 -00145 -00239 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
007459 -00108 -00147 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
008498 -00035 -00048 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
009366 000009 -00002 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
001911 000008 -00007 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
002554 -00473 -00273 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
003459 -00400 -00356 0250 0250 0250 0750 0750 0750 0000 %0992 m03 $
004461 -00289 -00305 0375 0375 0375 0625 0625 0625 0000 %0993 m04 $
005338 -00274 -00219 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
006414 -00155 -00205 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
007412 -00116 -00126 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
008479 -00038 -00038 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
009369 000009 000002 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
001920 -00005 -00094 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
002656 -00469 -00262 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
003551 -00400 -00360 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
004561 -00292 -00295 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
005453 -00269 -00235 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
006501 -00139 -00218 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
007474 -00112 -00131 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
008490 -00035 -00044 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
009366 000014 -00011 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
002133 000028 -00107 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
002314 -00314 -00176 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
002951 -00420 -00350 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
003352 -00401 -00378 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
003780 -00370 -00343 0266 0266 0266 0333 0333 0333 0000 %1012 k14 $
004395 -00326 -00307 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
004977 -00275 -00226 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
005287 -00230 -00227 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
005952 -00173 -00236 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
006418 -00150 -00160 0600 0600 0600 0400 0400 0400 0000 %1017 k19 $
006876 -00155 -00160 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
007329 -00082 -00092 0734 0734 0734 0266 0266 0266 0000 %1019 k21 $
007536 -00096 -00125 0800 0800 0800 0200 0200 0200 0000 %1020 k22 $
008192 -00042 -00048 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
008896 -00005 -00029 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
009186 000010 -00018 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
002087 000043 -00105 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
002350 -00300 -00156 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
002995 -00413 -00334 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
003354 -00404 -00342 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
003811 -00365 -00332 0266 0266 0266 0333 0333 0333 0000 %1028 l14 $
004397 000021 -00295 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
005013 -00261 -00208 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
005323 -00218 -00229 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
005970 -00155 -00259 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
006391 -00128 -00215 0600 0600 0600 0400 0400 0400 0000 %1033 l19 $
006874 -00143 -00187 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
007317 -00063 -00121 0734 0734 0734 0266 0266 0266 0000 %1035 l21 $
007501 -00092 -00122 0800 0800 0800 0200 0200 0200 0000 %1036 l22 $
008222 -00038 -00043 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
008923 -00003 -00024 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
009218 000012 -00014 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
002077 000058 -00111 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
002299 -00310 -00160 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
002948 -00410 -00340 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
003323 -00403 -00343 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
003749 -00366 -00324 0266 0266 0266 0333 0333 0333 0000 %1044 m14 $
004370 -00329 -00272 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
004966 -00265 -00221 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
005271 -00221 -00213 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
005903 -00165 -00261 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
006331 -00130 -00197 0600 0600 0600 0400 0400 0400 0000 %1049 m19 $
006810 -00147 -00174 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
007283 -00068 -00113 0734 0734 0734 0266 0266 0266 0000 %1051 m21 $
007498 -00087 -00111 0800 0800 0800 0200 0200 0200 0000 %1052 m22 $
```

%BEG HE66 22.TXT, Separation cmyn62*, cfi=0.90, D50, not adapted \$			%100 x LAB*			1000 x (r g b c m y 0)			%nrr. pos \$		
002075	000564	000389	0000	0000	0000	0000	1000	1000	0000	0000	A01 \$
002310	000624	-00068	0000	0000	0000	0000	1000	1000	0000	0000	A02 \$
002438	000332	-01411	0000	0000	0000	0000	1000	1000	0000	0000	A03 \$
002675	000023	-01754	0000	0000	0000	0000	1000	1000	0000	0000	A04 \$
003087	-002076	-02025	0000	0000	0000	0000	1000	1000	0000	0000	A05 \$
003371	-004414	-02332	0000	0000	0000	0000	1000	1000	0000	0000	A06 \$
003614	-004668	-02917	0000	0000	0000	0000	1000	1000	0000	0000	A07 \$
003861	-004712	-03401	0000	0000	0000	0000	1000	1000	0000	0000	A08 \$
004014	-002209	-04206	0000	0000	0000	0000	1000	1000	0000	0000	A09 \$
002625	-00341	000839	0000	0000	0000	0000	1000	1000	0000	0000	A10 \$
002454	-00257	000841	0000	0000	0000	0000	1000	1000	0000	0000	A11 \$
002674	-00473	-01235	0000	0000	0000	0000	1000	1000	0000	0000	A12 \$
002901	-00685	-01676	0000	0000	0000	0000	1000	1000	0000	0000	A13 \$
003227	-00871	-02112	0000	0000	0000	0000	1000	1000	0000	0000	A14 \$
003444	-00858	-02428	0000	0000	0000	0000	1000	1000	0000	0000	A15 \$
003710	-00892	-02944	0000	0000	0000	0000	1000	1000	0000	0000	A16 \$
003909	-00839	-03392	0000	0000	0000	0000	1000	1000	0000	0000	A17 \$
004104	-00937	-04165	0000	0000	0000	0000	1000	1000	0000	0000	A18 \$
003291	-00915	000881	0000	0000	0000	0000	1000	1000	0000	0000	A19 \$
003036	-00953	000103	0000	0000	0000	0000	1000	1000	0000	0000	A20 \$
002982	-01002	-00655	0000	0000	0000	0000	1000	1000	0000	0000	A21 \$
003075	-01308	-01777	0000	0000	0000	0000	1000	1000	0000	0000	A22 \$
003355	-01282	-02158	0000	0000	0000	0000	1000	1000	0000	0000	A23 \$
003665	-01343	-02357	0000	0000	0000	0000	1000	1000	0000	0000	A24 \$
003834	-01225	-02867	0000	0000	0000	0000	1000	1000	0000	0000	A25 \$
004047	-01332	-03415	0000	0000	0000	0000	1000	1000	0000	0000	A26 \$
004295	-01489	-03978	0000	0000	0000	0000	1000	1000	0000	0000	A27 \$
003607	-01663	-009785	0000	0000	0000	0000	1000	1000	0000	0000	A28 \$
003284	-01517	000000	0000	0000	0000	0000	1000	1000	0000	0000	A29 \$
003214	-01625	-00484	0000	0000	0000	0000	1000	1000	0000	0000	A30 \$
003188	-01633	-01402	0000	0000	0000	0000	1000	1000	0000	0000	A31 \$
003671	-01722	-02104	0000	0000	0000	0000	1000	1000	0000	0000	A32 \$
003665	-01718	-02255	0000	0000	0000	0000	1000	1000	0000	0000	A33 \$
003979	-01704	-02872	0000	0000	0000	0000	1000	1000	0000	0000	A34 \$
004181	-01765	-03457	0000	0000	0000	0000	1000	1000	0000	0000	A35 \$
004409	-01853	-03955	0000	0000	0000	0000	1000	1000	0000	0000	A36 \$
003739	-02239	000660	0000	0000	0000	0000	1000	1000	0000	0000	A37 \$
003416	-02070	-00018	0000	0000	0000	0000	1000	1000	0000	0000	A38 \$
003366	-02039	-00396	0000	0000	0000	0000	1000	1000	0000	0000	A39 \$
003422	-02075	-01027	0000	0000	0000	0000	1000	1000	0000	0000	A40 \$
003604	-01915	-01703	0000	0000	0000	0000	1000	1000	0000	0000	A41 \$
004072	-02118	-02472	0000	0000	0000	0000	1000	1000	0000	0000	A42 \$
004202	-02198	-02843	0000	0000	0000	0000	1000	1000	0000	0000	A43 \$
004437	-02183	-03409	0000	0000	0000	0000	1000	1000	0000	0000	A44 \$
004527	-02263	-03883	0000	0000	0000	0000	1000	1000	0000	0000	A45 \$
004047	-02789	000923	0000	0000	0000	0000	1000	1000	0000	0000	A46 \$
003848	-02574	000304	0000	0000	0000	0000	1000	1000	0000	0000	A47 \$
003762	-02491	-00227	0000	0000	0000	0000	1000	1000	0000	0000	A48 \$
003747	-02444	-00738	0000	0000	0000	0000	1000	1000	0000	0000	A49 \$
003778	-02288	-01313	0000	0000	0000	0000	1000	1000	0000	0000	A50 \$
003940	-02183	-01835	0000	0000	0000	0000	1000	1000	0000	0000	A51 \$
004321	-02600	-02643	0000	0000	0000	0000	1000	1000	0000	0000	A52 \$
004541	-02820	-03443	0000	0000	0000	0000	1000	1000	0000	0000	A53 \$
004789	-02967	-03839	0000	0000	0000	0000	1000	1000	0000	0000	A54 \$
004446	-03407	001176	0000	0000	0000	0000	1000	1000	0000	0000	A55 \$
004340	-03369	000492	0000	0000	0000	0000	1000	1000	0000	0000	A56 \$
004365	-03136	-00050	0000	0000	0000	0000	1000	1000	0000	0000	A57 \$
004274	-03251	-00789	0000	0000	0000	0000	1000	1000	0000	0000	A58 \$
004345	-02806	-01138	0000	0000	0000	0000	1000	1000	0000	0000	A59 \$
004312	-02777	-01657	0000	0000	0000	0000	1000	1000	0000	0000	A60 \$
004291	-02716	-02196	0000	0000	0000	0000	1000	1000	0000	0000	A61 \$
004691	-03234	-03085	0000	0000	0000	0000	1000	1000	0000	0000	A62 \$
005519	-03999	-03799	0000	0000	0000	0000	1000	1000	0000	0000	A63 \$
004987	-04104	001548	0000	0000	0000	0000	1000	1000	0000	0000	A64 \$
004850	-04207	000686	0000	0000	0000	0000	1000	1000	0000	0000	A65 \$
004803	-04019	000128	0000	0000	0000	0000	1000	1000	0000	0000	A66 \$
004796	-03786	-00467	0000	0000	0000	0000	1000	1000	0000	0000	A67 \$
004765	-03553	-01105	0000	0000	0000	0000	1000	1000	0000	0000	A68 \$
004762	-03345	-01593	0000	0000	0000	0000	1000	1000	0000	0000	A69 \$
004737	-03301	-02026	0000	0000	0000	0000	1000	1000	0000	0000	A70 \$
004797	-03215	-02617	0000	0000	0000	0000	1000	1000	0000	0000	A71 \$
005540	-03982	-03802	0000	0000	0000	0000	1000	1000	0000	0000	A72 \$
005474	-04928	001665	0000	0000	0000	0000	1000	1000	0000	0000	A73 \$
005822	-05393	001094	0000	0000	0000	0000	1000	1000	0000	0000	A74 \$
005363	-05037	000325	0000	0000	0000	0000	1000	1000	0000	0000	A75 \$
005340	-04680	-00274	0000	0000	0000	0000	1000	1000	0000	0000	A76 \$
005316	-04438	-00923	0000	0000	0000	0000	1000	1000	0000	0000	A77 \$
005648	-04954	-01232	0000	0000	0000	0000	1000	1000	0000	0000	A78 \$
005592	-04735	-02039	0000	0000	0000	0000	1000	1000	0000	0000	A79 \$
005834	-04134	-02556	0000	0000	0000	0000	1000	1000	0000	0000	A80 \$
005518	-04574	-02728	0000	0000	0000	0000	1000	1000	0000	0000	A81 \$

TUB-test chart HE76; Relative Elementary Colour System G
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: ->ol* setrgbcolor

%BEG HE66_22.TXT, Separation cmyn62*, cf1=0.90, D50, not adapted \$
%100 x LAB* %1000 x (r g b c m y 0) %nr. pos \$
%z004773 006340 003223 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008248 000217 006950 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005474 -04928 001665 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005518 -04574 -02728 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z004014 -00299 -04206 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003717 003969 -02346 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z002075 000564 000389 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009189 -00052 000210 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004700 006350 003377 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008258 000211 006978 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005541 -04929 001469 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005419 -04580 -02846 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003891 -00324 -04304 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003706 003963 -02322 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z002114 000626 000406 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009334 -00055 000202 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

1080 spectral reflexions $R \rightarrow LAB^*$ for $\bar{D}65$ and $D50$

output: $\rightarrow olv^* setrgbcolor$

TUB registration: 20091101-HE76/HE76L0NA.TXT/.PSS
application for evaluation and measurement of printer or

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/HE76/HE76L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1.1, Cx=0; cf1=0.90; nt=0.01; nx=1.3.

See original or copy: <http://web.me.com/klaus.richter/HE76/HE76L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1.1, Cx=0; cf1=0.90; nt=0.01; nx=1.3.

%BEG HE66_22.TXT, Separation cmyn62*, cf1=0.90, D50, adapted \$
%100 x LAB*a %1000 x (r g b c m y 0) %nr. pos \$
%z004773 006010 002901 %#1000 0000 0000 0000 1000 1000 0000 %0648 S19 %01 0 \$
%z008248 000189 006715 %#1000 1000 0000 0000 0000 1000 0000 %0720 a19 %Y1 1 \$
%z005474 -05197 001361 %#0000 1000 0000 1000 0000 1000 0000 %0072 I01 %L1 2 \$
%z005518 -04839 -03031 %#0000 1000 1000 1000 0000 0000 0000 %0080 I09 %C1 3 \$
%z004014 -00695 -04547 %#0000 0000 1000 1000 1000 0000 0000 %0008 A09 %V1 4 \$
%z003717 003547 -02695 %#1000 0000 1000 0000 1000 0000 0000 %0656 S27 %M1 5 \$
%z002075 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0000 A01 %N1 6 \$
%z009189 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0728 a27 %W1 7 \$
%\$
%z004700 005968 003044 %#1000 0000 0000 0000 1000 1000 0000 %0801 j01 %02 0 \$
%z008258 000165 006745 %#1000 1000 0000 0000 0000 1000 0000 %0882 j10 %Y2 1 \$
%z005541 -05231 001159 %#0000 1000 0000 1000 0000 1000 0000 %0963 j19 %L2 2 \$
%z005419 -04894 -03159 %#0000 1000 1000 1000 0000 0000 0000 %0737 b09 %C2 3 \$
%z003891 -00783 -04660 %#0000 0000 1000 1000 1000 0000 0000 %0818 b18 %V2 4 \$
%z003706 003486 -02683 %#1000 0000 1000 0000 1000 0000 0000 %0899 b27 %M2 5 \$
%z002114 000000 000000 %#0000 0000 0000 1000 1000 1000 0000 %0809 j09 %N2 6 \$
%z009334 000000 000000 %#1000 1000 1000 0000 0000 0000 0000 %0729 b01 %W2 7 \$
%\$

