

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart JE73; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

input: w *setgray*
output: no change compared to input

TUB registration: 20100301-JE73/JE73L0NA.TXT/.PS TUB material: code=rha4ta
application for evaluation and measurement of printer or monitor systems

See original or copy: <http://web.me.com/klaus.richter/JE73/JE73L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1, Cx=0, cfl=1.00, nt

TUB material: code=rha4ta

009704	-00108	000232	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009338	-00491	-00275	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008856	-00854	-00900	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
008291	-01040	-01570	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
007696	-01253	-02218	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
007237	-01492	-02743	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006497	-01640	-03455	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
005824	-02074	-03958	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005368	-02565	-04552	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
009258	-00092	001213	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
009351	-00081	000215	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
009095	-00537	-00535	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
008474	-00711	-01270	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
007895	-01050	-01968	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
007265	-01138	-02593	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
006449	-01570	-03147	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
005767	-01870	-03670	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
005289	-02522	-04476	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
008891	-000268	002037	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
008774	000202	001247	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
008613	-00064	000197	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
008290	-00477	-00624	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
007735	-00690	-01285	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
006966	-01122	-02173	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
006258	-01322	-02813	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
005600	-01685	-03264	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
005128	-02534	-04250	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
004827	000618	002294	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
008309	-000505	002915	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
008065	-000280	001095	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
007824	-00061	000172	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
007355	-00427	-00820	0500	0593	0625	0500	0406	0375	0000	00112	M05	\$
006707	-00790	-01601	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
005955	-01181	-02396	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
005394	-01433	-03006	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
004840	-02243	-04184	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007843	-001307	003395	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
007836	-000958	002931	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
007262	000518	002296	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
007609	-000389	001025	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
006896	-00046	000099	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
006375	-00346	-01026	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
005612	-00841	-01669	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
005071	-01171	-02673	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
004337	-01746	-03990	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
007312	-001994	004088	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
007323	001575	003581	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
007030	-000998	002849	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
006746	000664	002265	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
006334	-000359	001257	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
005888	-000027	000069	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
005352	-00585	-01312	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
004798	-00909	-02240	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003869	-01507	-03542	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
006787	002732	005064	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
006807	002413	004455	0875	0406	0250	0125	0593	0750	0000	00136	P02	\$
006452	001608	003484	0750	0375	0250	0250	0625	0750	0000	00137	P03	\$
006064	001336	002903	0625	0343	0250	0375	0656	0750	0000	00138	P04	\$
005654	-000920	002207	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
005214	-000404	001323	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
004647	-00010	000053	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
004278	-00670	-01650	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
003524	-01461	-03149	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
006333	-003448	005931	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
006246	-003324	005658	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
005827	002565	004364	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
005339	-002292	003940	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
004901	001745	003251	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
004450	001233	002459	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
004037	000672	001676	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
002979	-000015	000017	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
003061	-01251	-02575	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
005899	-004261	006082	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
005861	-003977	006006	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
005373	-003741	-005362	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
004570	-003584	-004342	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
003841	-003086	-003422	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
003359	-002659	-002762	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
002845	-002116	-001931	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
002391	-001412	-001096	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
001761	-000042	000087	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009683	-00101	000217	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
009078	-000372	-00350	0875	1000	0093	0125	0000	0000	0000	00406	J11	\$
008336	-000859	-00881	0812	0750	1000	0812	0250	0000	0000	00407	J12	\$
007325	-001510	-01474	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
006321	-002081	-02090	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
005237	-002727	-02683	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
004234	-003533	-03093	0347	0250	1000	0562	0750	0000	0000	00411	J16	\$
003646	-000916	-01387	0433	0250	1000	0875	0875	0000	0000	00412	J17	\$
003166	-004217	-03222	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
002641	-000500	-001504	0968	1000	0875	0031	0000	0125	0000	00414	J19	\$
009482	-00094	000228	0875	0875	0875	0125	0125	0125	0000	00415	K10	\$
007870	-000455	-00610	0781	0750	0875	0218	0250	0125	0000	00416	K12	\$
007842	-001018	-01227	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
006675	-001809	-01897	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
005443	-002475	-02642	0000	0375	0875	0500	0625	0125	0000	00419	K15	\$
004290	-003306	-03162	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
003587	-003972	-03270	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
002964	-004102	-03259	0218	0000	0875	0781	1000	0125	0000	00422	K18	\$
009538	-01032	-02758	0937	1000	0750	0062	0000	0250	0000	00423	L10	\$
009288	-0											

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009716	-00100	000205	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$
009203	-00261	-00412	0875	0937	1000	0125	0062	0000	0000	%0163	S02 \$
008760	-00689	-00985	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$
007948	-00703	-01804	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$
007699	-00685	-02561	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$
006388	-00708	-03179	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$
005627	-00919	-03993	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$
005078	-01120	-04437	0125	0562	1000	0875	0250	0000	0000	%0169	S08 \$
004664	-01111	-04751	0000	0500	1000	1000	0500	0000	0000	%0170	S09 \$
003438	-00256	-001483	1000	0937	0875	0000	0062	0125	0000	%0171	T01 \$
003353	-00989	000223	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$
008856	-00244	-00659	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$
008244	-00345	-01378	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$
007506	-00568	-02159	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$
006679	-00646	-02889	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$
005804	-00883	-03728	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$
005130	-00933	-04293	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$
004487	-00834	-04765	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$
009165	-00249	-002447	1000	0875	0750	0000	0125	0250	0000	%0180	T01 \$
008987	-00025	-001389	0875	0812	0750	0125	0187	0250	0000	%0181	U02 \$
008589	-00067	-000193	0750	0750	0750	0250	0250	0250	0000	%0182	U03 \$
007996	-00166	-00736	0625	0687	0750	0375	0312	0250	0000	%0183	U04 \$
007294	-00244	-01421	0500	0625	0750	0500	0375	0250	0000	%0184	U05 \$
006439	-00522	-02239	0375	0562	0750	0625	0437	0250	0000	%0185	U06 \$
005720	-00676	-02890	0250	0500	0750	0750	0500	0250	0000	%0186	U07 \$
005128	-00868	-03550	0125	0437	0750	0875	0562	0250	0000	%0187	U08 \$
004406	-00676	-04745	0000	0375	0750	1000	0625	0250	0000	%0188	U09 \$
008703	-00065	-003166	1000	0812	0625	0000	0187	0375	0000	%0189	V01 \$
008553	-00081	-002544	0875	0750	0625	0125	0250	0375	0000	%0190	V02 \$
008291	-00015	-001200	0750	0687	0625	0250	0312	0375	0000	%0191	V03 \$
007787	-00054	-000150	0625	0625	0625	0375	0375	0375	0000	%0192	V04 \$
007143	-00156	-00094	0500	0750	0625	0500	0437	0375	0000	%0193	V05 \$
006339	-00238	-01598	0375	0562	0625	0625	0500	0375	0000	%0194	V06 \$
005587	-00521	-02474	0250	0437	0625	0750	0562	0375	0000	%0195	V07 \$
004986	-00679	-03080	0125	0375	0625	0875	0625	0375	0000	%0196	V08 \$
004039	-00563	-04422	0000	0312	0625	1000	0687	0375	0000	%0197	V09 \$
008401	-00031	-004164	1000	0750	0500	0000	0250	0500	0000	%0198	W01 \$
008220	-00301	-003370	0875	0687	0500	0125	0312	0500	0000	%0199	W02 \$
007905	-00015	-002623	0750	0625	0500	0250	0375	0500	0000	%0200	W03 \$
007496	-00061	-001189	0625	0562	0500	0375	0437	0500	0000	%0201	W04 \$
006882	-00046	-000096	0500	0500	0500	0500	0500	0500	0000	%0202	W05 \$
006190	-00086	-01179	0375	0437	0500	0625	0562	0500	0000	%0203	W06 \$
005312	-00366	-02094	0250	0375	0500	0750	0625	0500	0000	%0204	W07 \$
004757	-00492	-02788	0125	0312	0500	0875	0687	0500	0000	%0205	W08 \$
003649	-00367	-04077	0000	0250	0500	1000	0750	0500	0000	%0206	W09 \$
008041	-000719	-004727	1000	0687	0375	0000	0312	0625	0000	%0207	X01 \$
007968	-000509	-004186	0875	0625	0375	0125	0375	0625	0000	%0208	X02 \$
007573	-000385	-0030404	0750	0562	0375	0250	0437	0625	0000	%0209	X03 \$
007137	-000182	-002575	0625	0500	0375	0375	0500	0625	0000	%0210	X04 \$
006546	-000015	-001364	0500	0437	0375	0500	0562	0625	0000	%0211	X05 \$
005126	-00028	-000063	0375	0375	0375	0625	0625	0625	0000	%0212	X06 \$
005185	-00271	-01365	0250	0312	0375	0750	0687	0625	0000	%0213	X07 \$
004550	-00435	-02273	0125	0250	0375	0875	0750	0625	0000	%0214	X08 \$
003332	-00385	-03689	0000	0187	0375	1000	0812	0625	0000	%0215	X09 \$
007673	-00161	-005558	1000	0625	0250	0000	0375	0750	0000	%0216	Y01 \$
007593	-001013	-004796	0875	0562	0250	0125	0437	0750	0000	%0217	Y02 \$
007150	-000643	-004101	0750	0500	0250	0250	0500	0750	0000	%0218	Y03 \$
006664	-00036	-00336	0625	0437	0250	0375	0500	0750	0000	%0219	Y04 \$
006076	-000314	-002612	0500	0375	0250	0500	0625	0750	0000	%0220	Y05 \$
005380	-000096	-001471	0375	0312	0250	0625	0687	0750	0000	%0221	Y06 \$
004584	-00007	-000035	0250	0250	0250	0750	0750	0750	0000	%0222	Y07 \$
004000	-00339	-01734	0125	0187	0250	0875	0812	0750	0000	%0223	Y08 \$
003096	-00499	-03268	0000	0125	0250	1000	0875	0750	0000	%0224	Y09 \$
007362	-00145	-006649	1000	0562	0125	0000	0437	0875	0000	%0225	Z01 \$
007283	-001411	-006440	0875	0500	0125	0125	0125	0800	0875	%0226	Z02 \$
006774	-00150	-005481	0750	0437	0125	0250	0562	0875	0000	%0227	Z03 \$
006140	-00109	-004790	0625	0375	0125	0375	0625	0875	0000	%0228	Z04 \$
005588	-000593	-003919	0500	0312	0125	0500	0687	0875	0000	%0229	Z05 \$
004905	-000472	-003018	0375	0250	0125	0625	0750	0875	0000	%0230	Z06 \$
004344	-000145	-001900	0250	0187	0125	0750	0812	0875	0000	%0231	Z07 \$
002923	-000010	-000022	0125	0125	0125	0875	0875	0875	0000	%0232	Z08 \$
002870	-00731	-02174	0000	0062	0125	1000	0937	0875	0000	%0233	Z09 \$
007074	-002024	-007186	1000	0500	0000	0000	0500	1000	0000	%0234	A01 \$
006921	-001974	-007032	0875	0437	0000	0125	0562	1000	0000	%0235	A02 \$
006413	-001728	-006384	0750	0375	0000	0250	0625	1000	0000	%0236	A03 \$
005443	-001584	-005268	0625	0312	0000	0375	0687	1000	0000	%0237	A04 \$
004544	-001420	-004060	0500	0250	0000	0500	0750	1000	0000	%0238	A05 \$
003911	-001282	-003319	0375	0187	0000	0625	0812	1000	0000	%0239	A06 \$
003225	-001097	-002335	0250	0125	0000	0750	0875	1000	0000	%0240	A07 \$
002600	-000800	-001317	0125	0062	0000	0875	0937	1000	0000	%0241	A08 \$
001902	-000041	-000087	0000	0000	0000	1000	1000	1000	0000	%0242	A09 \$
009705	-00105	-000231	1000	1000	1000	0000	0000	0000	0000	%0486	S10 \$
009159	-000523	-00208	0937	0875	1000	0062	0125	0000	0000	%0487	S11 \$
008452	-001145	-00665	0875	0750	1000	0125	0250	0000	0000	%0488	S12 \$
007638	-002012	-01829	0812	0625	1000	0187	0375	0000	0000	%0489	S13 \$
006663	-002817	-01521	0750	0500	1000	0250	0500	0000	0000	%0490	S14 \$
005589	-003559	-01981	0687	0375	1000	0312	0625	0000	0000	%0491	S15 \$
004793	-004208	-02423	0625	0250	1000	0375	0750	0000	0000	%0492	S16 \$
004049	-004873	-02531	0562	0250	1000	0875	0875	0000	0000	%0493	S17 \$
003620	-005168	-02435	0500	1000	0500	1000	0000	0000	0000	%0494	S18 \$
009546	-00705	-001367	0937	1000	0875	0062	0000	0125	0000	%0495	T10 \$
009473	-00091	-000226	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$
008745	-000664	-00524	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$
008017	-001294	-00979	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$
007933	-002216	-01453	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$
005975	-003180	-01911	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$
004863	-003975	-02455	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$
003983	-004772	-02587	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$
003444	-004946	-02455	0437	0000	0875	0562	1000	0125	0000	%0503	T18 \$
009366	-01207	-02362	0875	1000	0750	0125	0000	0250	0000	%0504	T19 \$
009221	-00745	-001325	0812	0875	0750	0187	0125	0250	0000	%0505	U11 \$
008708	-00071	-000210	0750	0750	0750	0250	0250	0250	0000	%0506	U12 \$
007889	-000779	-00598	0687	0625	0750	0312	0375	0250	0000	%0507	U13 \$
007030	-001528	-01107	0625	0500	0750	0375	0500	0250	0000	%0508	U14 \$
006142	-002336	-01555									

009709	-00104	000220	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
009136	-00085	-00426	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008571	-00195	-01027	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
007542	-00020	-01909	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
006526	-00039	-02632	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
005534	-00076	-03262	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$
004713	000914	-03857	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
004076	000782	-04344	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$
003653	000749	-04543	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
003056	-00445	-001552	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
003063	-00093	000235	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
008770	-00021	-00653	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
007948	-00038	-01474	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
007082	-00188	-02211	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
005948	-00034	-03096	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
004841	-00058	-03892	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
004158	-00094	-04382	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
003635	-00057	-04506	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
003018	-00017	-02265	1000	0937	0750	0000	0062	0250	0000	%0261	d01	\$
001948	-00256	-001475	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
008614	-00064	-000176	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$
007920	-00025	-00833	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
006963	-00281	-01554	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
005997	-00243	-02463	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
005223	-00436	-03287	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
004490	-00457	-04037	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
003490	-00625	-04357	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
009105	-00489	-003539	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
009002	-00423	-002838	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
008541	-00173	-001353	0750	0718	0875	0625	0250	0281	0375	%0272	e03	\$
007847	-00055	-000139	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
007003	-00017	-01023	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
005962	-00024	-01867	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$
005123	-00303	-02580	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$
004546	-00323	-03187	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
003272	-00718	-04154	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
008872	-00366	-004317	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
008732	-00345	-003721	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
008364	-00404	-002795	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
007753	-00207	-001441	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
006937	-00047	-000084	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
006009	-00019	-01280	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
005118	-00161	-02094	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
004429	-00397	-02836	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
003073	-00275	-03917	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
008691	-00734	-005011	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
008500	-00294	-004625	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
008081	-00327	-003809	0750	0656	0375	0250	0343	0625	0000	%0290	g03	\$
007524	-00333	-002891	0625	0562	0375	0375	0437	0625	0000	%0291	g04	\$
006835	-00301	-001585	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
005863	-00028	-000070	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
004913	-000148	-01597	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
004202	-000183	-02401	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
003287	-000558	-03616	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
008536	-00186	-005729	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
008321	-00248	-005367	0875	0718	0500	0125	0281	0750	0000	%0298	h02	\$
007930	-00328	-004823	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
007288	-00358	-004141	0625	0531	0250	0375	0437	0750	0000	%0300	h04	\$
006573	-00415	-003083	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
005701	-00269	-001669	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
004615	-00012	-000037	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
003803	-00163	-01823	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
002655	-00320	-02958	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
008409	-00154	-006827	1000	0781	0125	0000	0218	0875	0000	%0306	h10	\$
008146	-00064	-007215	0875	0687	0125	0125	0312	0875	0000	%0307	h12	\$
007669	-00114	-006644	0750	0593	0125	0250	0406	0875	0000	%0308	h13	\$
007027	-00225	-005823	0625	0500	0125	0375	0500	0875	0000	%0309	h14	\$
006231	-00286	-004577	0500	0406	0125	0500	0593	0875	0000	%0310	h15	\$
005473	-00302	-003507	0375	0312	0125	0625	0687	0875	0000	%0311	h06	\$
004649	-00288	-002160	0250	0218	0125	0750	0781	0875	0000	%0312	h07	\$
002996	-00012	-000019	0125	0125	0125	0875	0875	0875	0000	%0313	h08	\$
002507	-00146	-02168	0000	0031	0125	1000	0968	0875	0000	%0314	h09	\$
008243	-00003	-008035	1000	0750	0000	0000	0250	1000	0000	%0315	h10	\$
008099	-00222	-008325	0875	0656	0000	0125	0343	1000	0000	%0316	h12	\$
007516	-00186	-007584	0750	0562	0000	0250	0437	1000	0000	%0317	h03	\$
006449	-000141	-006477	0625	0468	0000	0375	0531	1000	0000	%0318	h04	\$
005332	-000070	-005168	0500	0375	0000	0500	0625	1000	0000	%0319	h05	\$
004493	-000095	-004124	0375	0281	0000	0625	0718	1000	0000	%0320	h06	\$
003655	-000109	-003109	0250	0187	0000	0750	0812	1000	0000	%0321	h07	\$
002705	-00034	-001760	0125	0093	0000	0875	0906	1000	0000	%0322	h08	\$
001930	-000035	-000082	0000	0000	0000	1000	1000	1000	0000	%0323	h09	\$
009705	-00097	-000202	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
009224	-000621	-00123	0968	0875	1000	0031	0125	0000	0000	%0568	b11	\$
008573	-001481	-00448	0937	0750	1000	0062	0250	0000	0000	%0569	b12	\$
007942	-002209	-00677	0906	0625	1000	0093	0375	0000	0000	%0570	b13	\$
007126	-003069	-01832	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
006200	-003988	-01413	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
005427	-004892	-01625	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
004816	-005181	-01658	0781	0250	1000	0218	0875	0000	0000	%0574	b17	\$
004145	-006145	-01571	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
003418	-00709	-001053	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$
002946	-00088	-000211	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$
008817	-000783	-004046	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
008182	-001575	-00720	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
007345	-002550	-01055	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
006354	-003591	-01461	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
005477	-004602	-01686	0718	0250	0875	0281	0750	0125	0000	%0582	c16	\$
004626	-005598	-01706	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
003971	-005854	-01625	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
002947	-012244	-001924	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$
002964	-00872	-001126	0781	0875	0750	0218	0125	0250	0000	%0586	d11	\$

See original or copy: <http://web.me.com/klaus.richter/JE73/JE73L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

```
%BEG JE73_22_REM.TXT, Separation cmyn62*, D65, not adapted S
%100 x LAB*      %#1000 x (r g b c m y 0)      %nr.   pos $
%Z004556 006162 004041  %#1000 0000 0000 0000 1000 1000 0000  %0072 I01 %01 0 $
%Z009153 -01490 008657  %#1000 1000 0000 0000 0000 1000 0000  %0396 I10 %Y1 1 $
%Z005814 -06136 003809  %#0000 1000 0000 1000 0000 1000 0000  %0720 I19 %L1 2 $
%Z005429 -03138 -03864  %#0000 1000 1000 1000 0000 0000 0000  %0008 A09 %C1 3 $
%Z003181 002722 -04035  %#0000 0000 1000 1000 1000 0000 0000  %0332 A18 %V1 4 $
%Z004629 007225 -00821  %#1000 0000 1000 0000 1000 0000 0000  %0656 A27 %M1 5 $
%Z001574 000044 000110  %#0000 0000 0000 1000 1000 1000 0000  %0080 I09 %N1 6 $
%Z009685 -00103 000214  %#1000 1000 1000 0000 0000 0000 0000  %0000 A01 %W1 7 $
%S
%Z004556 006162 004041  %#1000 0000 0000 0000 1000 1000 0000  %0072 I01 %02 0 $
%Z009153 -01490 008657  %#1000 1000 0000 0000 0000 1000 0000  %0396 I10 %Y2 1 $
%Z005814 -06136 003809  %#0000 1000 0000 1000 0000 1000 0000  %0720 I19 %L2 2 $
%Z005429 -03138 -03864  %#0000 1000 1000 1000 0000 0000 0000  %0008 A09 %C2 3 $
%Z003181 002722 -04035  %#0000 0000 1000 1000 1000 0000 0000  %0332 A18 %V2 4 $
%Z004629 007225 -00821  %#1000 0000 1000 0000 1000 0000 0000  %0656 A27 %M2 5 $
%Z001574 000044 000110  %#0000 0000 0000 1000 1000 1000 0000  %0080 I09 %N2 6 $
%Z009685 -00103 000214  %#1000 1000 1000 0000 0000 0000 0000  %0000 A01 %W2 7 $
%S
%Z004556 006162 004041  %#1000 0000 0000 0000 1000 1000 0000  %0072 I01 %000Y 0 $
%Z009153 -01490 008657  %#1000 1000 0000 0000 0000 1000 0000  %0396 I10 %Y00L 1 $
%Z005814 -06136 003809  %#0000 1000 0000 1000 0000 1000 0000  %0720 I19 %L00C 2 $
%Z005429 -03138 -03864  %#0000 1000 1000 1000 0000 0000 0000  %0008 A09 %C00V 3 $
%Z003181 002722 -04035  %#0000 0000 1000 1000 1000 0000 0000  %0332 A18 %V00M 4 $
%Z004629 007225 -00821  %#1000 0000 1000 0000 1000 0000 0000  %0656 A27 %M000 5 $
%Z001574 000044 000110  %#0000 0000 0000 1000 1000 1000 0000  %0080 I09 %N001 6 $
%Z009685 -00103 000214  %#1000 1000 1000 0000 0000 0000 0000  %0000 A01 %W001 7 $
%S
%Z005899 004261 006082  %#1000 0250 0000 0000 0750 1000 0000  %0153 R01 %025Y 0 $
%Z009006 -02207 008912  %#0750 1000 0000 0250 0000 1000 0000  %0477 R10 %Y25L 1 $
%Z005871 -05484 001543  %#0000 1000 0250 1000 0000 0750 0000  %0801 R19 %L25C 2 $
%Z005360 -02555 -04552  %#0000 0750 1000 1000 0250 0000 0000  %0089 J09 %C25V 3 $
%Z003166 004217 -03222  %#0250 0000 1000 0750 1000 0000 0000  %0413 J18 %C25M 4 $
%Z004478 006829 000049  %#1000 0000 0750 0000 1000 0250 0000  %0737 J27 %M250 5 $
%Z001682 000045 000098  %#0000 0000 0000 1000 1000 1000 0000  %0161 R09 %N251 6 $
%Z009691 -00106 000227  %#1000 1000 1000 0000 0000 0000 0000  %0081 J01 %W251 7 $
%S
%Z007074 002024 007186  %#1000 0500 0000 0000 0500 1000 0000  %0234 a01 %050Y 0 $
%Z007674 -03577 006764  %#0500 1000 0000 0500 0000 1000 0000  %0558 a10 %Y50L 1 $
%Z005982 -04698 -00096  %#0000 1000 0500 1000 0000 0500 0000  %0882 a19 %L50C 2 $
%Z004664 -01111 -04751  %#0000 0500 1000 1000 0500 0000 0000  %0170 S09 %C50V 3 $
%Z003620 005168 -02436  %#0500 0000 1000 0500 1000 0000 0000  %0494 S18 %V50M 4 $
%Z004430 006288 001582  %#1000 0000 0500 0000 1000 0500 0000  %0818 S27 %M500 5 $
%Z001786 000043 000099  %#0000 0000 0000 1000 1000 1000 0000  %0242 a09 %N501 6 $
%Z009708 -00101 000212  %#1000 1000 1000 0000 0000 0000 0000  %0162 S01 %W501 7 $
%S
%Z008243 000003 008035  %#1000 0750 0000 0000 0250 1000 0000  %0315 j01 %075Y 0 $
%Z006653 -04810 005144  %#0250 1000 0000 0750 0000 1000 0000  %0639 j10 %Y75L 1 $
%Z005989 -04035 -01574  %#0000 1000 0750 1000 0000 0250 0000  %0963 j19 %L75C 2 $
%Z003653 000749 -04553  %#0000 0250 1000 1000 0750 0000 0000  %0251 b09 %C75V 3 $
%Z004145 006145 -01571  %#0750 0000 1000 0250 1000 0000 0000  %0575 b18 %V75M 4 $
%Z004484 006049 002790  %#1000 0000 0250 0000 1000 0750 0000  %0899 b27 %M750 5 $
%Z001760 000041 000096  %#0000 0000 0000 1000 1000 1000 0000  %0323 j09 %N751 6 $
%Z009793 -00101 000212  %#1000 1000 1000 0000 0000 0000 0000  %0243 b01 %W751 7 $
%S
```

See original or copy: <http://web.me.com/klaus.richter/JE73/JE73L0NA.TXT/.PS>
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

```
%BEG JE73_22_REM.TXT, Separation cmyn62*, D65, not adapted S
%100 x LAB*      1000 x (r g b   c m y 0)      %nrr. pos $
001527 000025 000100 0000 0000 0000 1000 1000 1000 0000 %0972 k01 $
002674 000000 000033 0125 0125 0125 0875 0875 0875 0000 %0973 k02 $
004526 -000021 000017 0250 0250 0250 0750 0750 0750 0000 %0974 k03 $
005786 -000034 000051 0375 0375 0375 0625 0625 0625 0000 %0975 k04 $
006965 -000046 000076 0500 0500 0500 0500 0500 0500 0000 %0976 k05 $
007932 -000054 000135 0625 0625 0625 0375 0375 0375 0000 %0977 k06 $
008725 -000065 000181 0750 0750 0750 0250 0250 0250 0000 %0978 k07 $
009473 -000088 000204 0875 0875 0875 0125 0125 0125 0000 %0979 k08 $
010161 -000101 000208 1000 1000 1000 0000 0000 0000 0000 %0980 k09 $
011498 000028 000101 0000 0000 0000 1000 1000 1000 0000 %0981 l01 $
026255 000006 000027 0125 0125 0125 0875 0875 0875 0000 %0982 l02 $
045410 -000015 000014 0250 0250 0250 0750 0750 0750 0000 %0983 l03 $
057607 -000032 000045 0375 0375 0375 0625 0625 0625 0000 %0984 l04 $
069399 -000044 000073 0500 0500 0500 0500 0500 0500 0000 %0985 l05 $
079311 -000054 000137 0625 0625 0625 0375 0375 0375 0000 %0986 l06 $
086866 -000066 000184 0750 0750 0750 0250 0250 0250 0000 %0987 l07 $
094969 -000089 000210 0875 0875 0875 0125 0125 0125 0000 %0988 l08 $
097728 -000100 000207 1000 1000 1000 0000 0000 0000 0000 %0989 l09 $
013362 000030 000104 0000 0000 0000 1000 1000 1000 0000 %0990 m01 $
025552 000006 000052 0125 0125 0125 0875 0875 0875 0000 %0991 m02 $
044468 -000014 000026 0250 0250 0250 0750 0750 0750 0000 %0992 k03 $
057444 -000029 000064 0375 0375 0375 0625 0625 0625 0000 %0993 k04 $
069923 -000043 000090 0500 0500 0500 0500 0500 0500 0000 %0994 m05 $
078966 -000056 000148 0625 0625 0625 0375 0375 0375 0000 %0995 m06 $
087011 -000066 000189 0750 0750 0750 0250 0250 0250 0000 %0996 m07 $
094677 -000090 000216 0875 0875 0875 0125 0125 0125 0000 %0997 m08 $
097177 -000106 000225 1000 1000 1000 0000 0000 0000 0000 %0998 m09 $
013222 000029 000092 0000 0000 0000 1000 1000 1000 0000 %0999 n01 $
025758 000005 000052 0125 0125 0125 0875 0875 0875 0000 %1000 n02 $
044468 -000013 000044 0250 0250 0250 0750 0750 0750 0000 %1001 n03 $
057537 -000029 000078 0375 0375 0375 0625 0625 0625 0000 %1002 n04 $
069005 -000042 000087 0500 0500 0500 0500 0500 0500 0000 %1003 n05 $
078655 -000049 000042 0625 0625 0625 0375 0375 0375 0000 %1004 n06 $
086890 -000063 000191 0750 0750 0750 0250 0250 0250 0000 %1005 n07 $
094722 -000091 000218 0875 0875 0875 0125 0125 0125 0000 %1006 n08 $
097721 -000094 000199 1000 1000 1000 0000 0000 0000 0000 %1007 n09 $
011906 000037 000082 0000 0000 0000 1000 1000 1000 0000 %1008 k10 $
021129 000034 000065 0066 0066 0066 0933 0933 0933 0000 %1009 k11 $
030656 000008 000003 0133 0133 0133 0866 0866 0866 0000 %1010 k12 $
040755 -000002 -000002 0200 0200 0200 0800 0800 0800 0000 %1011 k13 $
047799 -000010 000031 0266 0266 0266 0733 0733 0733 0000 %1012 k14 $
055538 -000021 000033 0333 0333 0333 0666 0666 0666 0000 %1013 k15 $
062366 -000028 000056 0400 0400 0400 0600 0600 0600 0000 %1014 k16 $
068544 -000041 000077 0466 0466 0466 0533 0533 0533 0000 %1015 k17 $
077298 -000051 000108 0533 0533 0533 0466 0466 0466 0000 %1016 k18 $
077789 -000058 000143 0600 0600 0600 0399 0399 0399 0000 %1017 k19 $
082055 -000057 000169 0666 0666 0666 0333 0333 0333 0000 %1018 k20 $
086629 -000062 000187 0733 0733 0733 0266 0266 0266 0000 %1019 k21 $
090931 -000072 000201 0800 0800 0800 0199 0199 0199 0000 %1020 k22 $
093228 -000080 000202 0866 0866 0866 0133 0133 0133 0000 %1021 k23 $
096677 -000095 000194 0933 0933 0933 0066 0066 0066 0000 %1022 k24 $
097000 -000096 000196 1000 1000 1000 0000 0000 0000 0000 %1023 k25 $
011867 000038 000090 0000 0000 0000 1000 1000 1000 0000 %1024 l10 $
020540 000035 000078 0066 0066 0066 0933 0933 0933 0000 %1025 l11 $
030915 000008 000013 0133 0133 0133 0866 0866 0866 0000 %1026 l12 $
040871 -000004 000005 0200 0200 0200 0800 0800 0800 0000 %1027 l13 $
048240 -000018 000034 0266 0266 0266 0733 0733 0733 0000 %1028 l14 $
055773 000020 000039 0333 0333 0333 0666 0666 0666 0000 %1029 l15 $
062377 -000028 000058 0400 0400 0400 0600 0600 0600 0000 %1030 l16 $
068824 -000035 000071 0466 0466 0466 0533 0533 0533 0000 %1031 l17 $
072890 -000041 000090 0533 0533 0533 0466 0466 0466 0000 %1032 l18 $
077738 -000046 000121 0600 0600 0600 0399 0399 0399 0000 %1033 l19 $
081441 -000051 000156 0666 0666 0666 0333 0333 0333 0000 %1034 l20 $
085744 -000057 000176 0733 0733 0733 0266 0266 0266 0000 %1035 l21 $
089855 -000069 000196 0800 0800 0800 0199 0199 0199 0000 %1036 l22 $
092999 -000075 000194 0866 0866 0866 0133 0133 0133 0000 %1037 l23 $
096678 -000093 000197 0933 0933 0933 0066 0066 0066 0000 %1038 l24 $
097116 -000098 000201 1000 1000 1000 0000 0000 0000 0000 %1039 l25 $
016700 000040 000092 0000 0000 0000 1000 1000 1000 0000 %1040 m10 $
019466 000033 000083 0066 0066 0066 0933 0933 0933 0000 %1041 m11 $
029866 000012 000014 0133 0133 0133 0866 0866 0866 0000 %1042 m12 $
040109 000000 000019 0200 0200 0200 0800 0800 0800 0000 %1043 m13 $
044774 -000003 000040 0266 0266 0266 0733 0733 0733 0000 %1044 m14 $
055510 -000017 000050 0333 0333 0333 0666 0666 0666 0000 %1045 m15 $
062030 -000023 000063 0400 0400 0400 0600 0600 0600 0000 %1046 m16 $
067655 -000032 000084 0466 0466 0466 0533 0533 0533 0000 %1047 m17 $
072721 -000039 000101 0533 0533 0533 0466 0466 0466 0000 %1048 m18 $
077732 -000046 000132 0600 0600 0600 0399 0399 0399 0000 %1049 m19 $
081144 -000050 000160 0666 0666 0666 0333 0333 0333 0000 %1050 m20 $
085895 -000059 000187 0733 0733 0733 0266 0266 0266 0000 %1051 m21 $
089866 -000071 000202 0800 0800 0800 0199 0199 0199 0000 %1052 m22 $
```

TUB-test chart JE73; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

input: w setgray
output: ->olv* setrgbcolor

TUB registration: 20100301-JE73/JE73L0NA.TXT /.PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart JE73; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> olv* setrgbcolor
```

TUB registration: 20100301-JE73/JE73L0NA.TXT /.PS TUB ma
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/IE73/JE73L0NA.TXT> / .PS
 Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009704	-00001	000004	1000	1000	1000	0000	0000	0000	0000	00081	J01	\$
009338	-00391	-00497	0875	0968	1000	0125	0031	0000	0000	00082	J02	\$
008856	-00764	-01114	0750	0937	1000	0250	0062	0000	0000	00083	J03	\$
008291	-00960	-01775	0625	0906	1000	0375	0093	0000	0000	00084	J04	\$
007696	-01185	-02413	0500	0875	1000	0500	0125	0000	0000	00085	J05	\$
007237	-01432	-02931	0375	0843	1000	0625	0156	0000	0000	00086	J06	\$
006497	-01594	-03631	0250	0812	1000	0750	0187	0000	0000	00087	J07	\$
005829	-02048	-04123	0125	0781	1000	0875	0218	0000	0000	00088	J08	\$
005368	-02521	-04710	0000	0750	1000	1000	0250	0000	0000	00089	J09	\$
009258	000190	000093	1000	0906	0875	0000	0093	0125	0000	00090	K01	\$
009351	000018	-00007	0875	0875	0875	0125	0125	0125	0000	00091	K02	\$
009095	-00442	-00753	0750	0843	0875	0250	0156	0125	0000	00092	K03	\$
008474	-00627	-01478	0625	0812	0875	0375	0187	0125	0000	00093	K04	\$
007895	-00978	-02166	0500	0781	0875	0500	0218	0125	0000	00094	K05	\$
007265	-00657	-02782	0375	0750	0875	0625	0250	0125	0000	00095	K06	\$
006449	-01525	-03322	0250	0718	0875	0750	0281	0125	0000	00096	K07	\$
005767	-01838	-03834	0125	0687	0875	0875	0312	0125	0000	00097	K08	\$
005289	-02499	-04633	0000	0656	0875	1000	0343	0125	0000	00098	K09	\$
008891	000359	001822	1000	0812	0750	0000	0187	0250	0000	00099	L01	\$
008774	000291	001034	0875	0781	0750	0125	0218	0250	0000	00100	L02	\$
008613	000021	-00012	0750	0750	0750	0250	0250	0250	0000	00101	L03	\$
008730	-00397	-00829	0625	0718	0750	0375	0281	0250	0000	00102	L04	\$
007295	-00621	-01481	0500	0687	0750	0500	0312	0250	0000	00103	L05	\$
006966	-01068	-02359	0375	0656	0750	0625	0343	0250	0000	00104	L06	\$
006258	-01281	-02985	0250	0625	0750	0750	0375	0250	0000	00105	L07	\$
005600	-01656	-03425	0125	0593	0750	0875	0406	0250	0000	00106	L08	\$
005128	-02514	-04403	0000	0562	0750	1000	0437	0250	0000	00107	L09	\$
004827	000700	002696	1000	0718	0625	0000	0281	0375	0000	00108	M01	\$
008309	000585	002099	0875	0687	0625	0125	0312	0375	0000	00109	M02	\$
008065	000355	000894	0750	0656	0625	0250	0343	0375	0000	00110	M03	\$
007824	000009	-00025	0625	0625	0625	0375	0375	0375	0000	00111	M04	\$
007355	-00365	-01010	0500	0593	0625	0500	0406	0375	0000	00112	M05	\$
006707	-00740	-01781	0375	0562	0625	0625	0437	0375	0000	00113	M06	\$
005955	-01066	-02503	0250	0531	0625	0750	0468	0375	0000	00114	M07	\$
005394	-01408	-03164	0125	0500	0625	0875	0500	0375	0000	00115	M08	\$
004840	-02229	-04333	0000	0468	0625	1000	0531	0375	0000	00116	M09	\$
007843	001378	003197	1000	0625	0500	0000	0375	0500	0000	00117	N01	\$
007836	001029	002733	0875	0593	0500	0125	0406	0500	0000	00118	N02	\$
007602	000585	002102	0750	0562	0500	0250	0437	0500	0000	00119	N03	\$
007269	000450	000836	0625	0531	0500	0375	0468	0500	0000	00120	N04	\$
006896	000063	-00083	0500	0500	0500	0500	0500	0500	0000	00121	N05	\$
006375	-00306	-01200	0375	0468	0500	0625	0531	0500	0000	00122	N06	\$
005612	-00812	-02139	0250	0437	0500	0750	0562	0500	0000	00123	N07	\$
005071	-01152	-02826	0125	0406	0500	0875	0593	0500	0000	00124	N08	\$
004337	-01741	-04140	0000	0375	0500	1000	0625	0500	0000	00125	N09	\$
007312	002056	003899	1000	0531	0375	0000	0468	0625	0000	00126	O01	\$
007323	001637	003391	0875	0500	0375	0125	0500	0625	0000	00127	O02	\$
007030	001054	002665	0750	0468	0375	0250	0531	0625	0000	00128	O03	\$
006746	000714	002085	0625	0437	0375	0375	0562	0625	0000	00129	O04	\$
006334	000402	001083	0500	0406	0375	0500	0593	0625	0000	00130	O05	\$
005888	000097	-00097	0375	0375	0375	0625	0625	0625	0000	00131	O06	\$
005352	-00561	-01469	0250	0343	0375	0750	0656	0625	0000	00132	O07	\$
004798	-00896	-02389	0125	0312	0375	0875	0687	0625	0000	00133	O08	\$
003869	-01511	-03675	0000	0281	0375	1000	0718	0625	0000	00134	O09	\$
006787	002783	004883	1000	0437	0250	0000	0562	0750	0000	00135	P01	\$
006807	002465	004274	0875	0406	0500	0125	0593	0750	0000	00136	P02	\$
006452	001713	003309	0750	0375	0250	0250	0625	0750	0000	00137	P03	\$
006064	001273	002734	0625	0343	0250	0375	0656	0750	0000	00138	P04	\$
005654	000950	002045	0500	0312	0250	0500	0687	0750	0000	00139	P05	\$
005214	000426	001168	0375	0281	0250	0625	0718	0750	0000	00140	P06	\$
004647	000000	-00092	0250	0250	0250	0750	0750	0750	0000	00141	P07	\$
004278	-00666	-01790	0125	0218	0250	0875	0781	0750	0000	00142	P08	\$
003524	-01472	-03277	0000	0187	0250	1000	0812	0750	0000	00143	P09	\$
006333	003491	005758	1000	0343	0125	0000	0656	0875	0000	00144	Q01	\$
006246	003365	005486	0875	0312	0125	0125	0687	0875	0000	00145	Q02	\$
005827	002598	004198	0750	0281	0125	0250	0718	0875	0000	00146	Q03	\$
005339	002316	003783	0625	0250	0125	0375	0750	0875	0000	00147	Q04	\$
004901	001761	003101	0500	0218	0125	0500	0781	0875	0000	00148	Q05	\$
004450	001241	002316	0375	0187	0125	0625	0812	0875	0000	00149	Q06	\$
004037	000672	001540	0250	0156	0125	0750	0843	0875	0000	00150	Q07	\$
002979	-00005	-00101	0125	0125	0125	0875	0875	0875	0000	00151	Q08	\$
003061	-01270	-02695	0000	0093	0125	1000	0906	0875	0000	00152	Q09	\$
005899	004295	005916	1000	0250	0000	0000	0750	1000	0000	00153	R01	\$
005861	004010	005840	0875	0218	0000	0125	0781	1000	0000	00154	R02	\$
005373	003766	005205	0750	0187	0000	0250	0812	1000	0000	00155	R03	\$
004570	003594	004197	0625	0156	0000	0375	0843	1000	0000	00156	R04	\$
003841	003082	003289	0500	0125	0000	0500	0875	1000	0000	00157	R05	\$
003359	002645	002637	0375	0093	0000	0625	0906	1000	0000	00158	R06	\$
002845	002093	001814	0250	0062	0000	0750	0937	1000	0000	00159	R07	\$
002391	001380	000986	0125	0031	0000	0875	0968	1000	0000	00160	R08	\$
001761	000000	-00012	0000	0000	0000	1000	1000	1000	0000	00161	R09	\$
009683	000064	-00009	1000	1000	1000	0000	0000	0000	0000	00405	J10	\$
009078	000467	-00568	0800	0875	1000	0093	0125	0000	0000	00406	J11	\$
008336	000939	-01086	0812	0750	1000	0818	0250	0000	0000	00407	J12	\$
007325	001572	-01664	0718	0625	1000	0281	0375	0000	0000	00408	J13	\$
006321	002124	-02264	0625	0500	1000	0375	0500	0000	0000	00409	J14	\$
005237	002749	-02838	0531	0375	1000	0468	0625	0000	0000	00410	J15	\$
004234	003536	-03232	0437	0250	1000	0562	0750	0000	0000	00411	J16	\$
003646	004008	-03352	0343	0250	1000	0875	0875	0000	0000	00412	J17	\$
003167	004200	-03344	0250	0000	1000	0750	1000	0000	0000	00413	J18	\$
002641	-00495	001277	0068	1000	0875	0031	0000	0125	0000	00414	K01	\$
009482	000008	000004	0875	0875	0875	0125	0125	0125	0000	00415	K11	\$
007872	000542	-00822	0781	0750	0875	0218	0250	0125	0000	00416	K12	\$
007842	001089	-01425	0687	0625	0875	0312	0375	0125	0000	00417	K13	\$
006675	001858	-02076	0593	0500	0875	0406	0500	0125	0000	00418	K14	\$
005443	002501	-02801	0500	0375	0875	0500	0625	0125	0000	00419	K15	\$
004290	003310	-03302	0406	0250	0875	0593	0750	0125	0000	00420	K16	\$
003587	003963	-03399	0312	0125	0875	0687	0875	0125	0000	00421	K17	\$
002964	004081	-03373	0918	0000	0875	0781	1000	0125	0000	00422	K18	\$
009538	-00929	002533	0237	1000	0750	0062	0000	0250	0000	00423	L10	\$
00928												

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009716	000001	-000007	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$	009705	-000004	000019	1000	1000	1000	0000	0000	0000	%0486	S10 \$	009702	000003	-000011	1000	1000	1000	0000	0000	0000	0000	%0810	S19 \$	
009203	-00169	-00618	0875	0937	1000	0125	0662	0000	0000	%0163	S02 \$	009159	-000614	-00413	0937	0875	1000	0062	0125	0000	%0487	S11 \$	009190	000740	-000663	1000	0875	0937	0000	0125	0662	0000	%0811	S20 \$	
008760	-00605	-01184	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$	008452	-001223	-00859	0875	0750	1000	0125	0250	0000	%0488	S12 \$	008554	001462	-000125	1000	0750	0875	0000	0250	0125	0000	%0812	S21 \$	
007948	-00634	-01992	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$	007638	-002075	-01212	0812	0625	1000	0187	0375	0000	%0489	S13 \$	007948	002149	-000409	1000	0625	0812	0000	0375	0187	0000	%0813	S22 \$	
007699	-00632	-02334	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$	006663	-002863	-01691	0750	0500	1000	0250	0500	0000	%0490	S14 \$	007317	002905	-000754	1000	0500	0750	0000	0500	0250	0000	%0814	S23 \$	
006388	-00667	-03344	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$	005589	-003687	-02136	0687	0375	1000	0312	0625	0000	%0491	S15 \$	006523	004023	-001141	1000	0375	0687	0000	0625	0312	0000	%0815	S24 \$	
005627	-00893	-04057	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$	004793	-004219	-02563	0625	0250	1000	0375	0750	0000	%0492	S16 \$	005653	005412	-001420	1000	0250	0625	0000	0750	0375	0000	%0816	S25 \$	
005078	-01104	-04503	0125	0562	1000	0875	0507	0000	0000	%0169	S08 \$	004409	-004670	-02665	0562	0250	1000	0875	0500	0000	%0493	S17 \$	004937	006639	-001552	1000	0125	0562	0000	0875	0437	0000	%0817	S26 \$	
004654	-01182	-04892	0000	0500	1000	1000	0507	0000	0000	%0170	S09 \$	003622	-005157	-02562	0500	1000	1000	0500	1000	0000	%0494	S18 \$	004430	006292	-001445	1000	0000	0500	0000	1000	0500	0000	%0818	S27 \$	
004348	-00160	-001274	1000	0937	0875	0000	0662	0125	0000	%0171	T01 \$	009546	-006087	-001157	0937	1000	0875	0662	0000	0125	0000	%0495	T10 \$	009325	-005070	-000887	0875	1000	0937	0125	0000	0662	0000	%0819	T19 \$
009353	000005	000016	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$	009473	000004	000017	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$	009426	000012	000000	0875	0875	0875	0125	0125	0125	0000	%0820	T20 \$
008856	-00139	-00860	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$	008745	000747	-00722	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$	008602	000900	000103	0875	0750	0812	0125	0250	0187	0000	%0821	T21 \$
008244	-00271	-01562	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$	008917	-001364	-01168	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$	008041	-001566	000373	0875	0625	0750	0125	0375	0250	0000	%0822	T22 \$
007506	-00507	-02332	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$	007933	-002268	-01627	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$	007367	002472	-000548	0875	0500	0687	0125	0500	0312	0000	%0823	T23 \$
006679	-00601	-03058	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$	005975	003213	-02070	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$	006645	003546	-001082	0875	0375	0625	0125	0625	0375	0000	%0824	T24 \$
005804	-00853	-03885	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$	004863	-003987	-02599	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$	005835	-004773	-001375	0875	0250	0562	0125	0750	0437	0000	%0825	T25 \$
005130	-00196	-04440	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$	003983	-004769	-02718	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$	004952	006250	-001613	0875	0125	0500	0125	0875	0500	0000	%0826	T26 \$
004487	-00829	-04904	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$	003444	-004933	-02578	0437	0000	0875	0562	1000	0125	0000	%0503	T18 \$	004176	005929	-001335	0875	0000	0437	0125	1000	0562	0000	%0827	T27 \$
009165	-00157	-002242	1000	0875	0750	0000	0125	0250	0000	%0180	T01 \$	009366	-011122	-002154	0875	1000	0750	0125	0000	0250	0000	%0504	T19 \$	008886	-011226	-000930	0750	1000	0875	0250	0000	0125	0000	%0828	T28 \$
008987	000112	001187	0875	0812	0750	0125	0187	0250	0000	%0181	U02 \$	009221	-006653	-001119	0812	0875	0750	0187	0125	0250	0000	%0505	U11 \$	009150	-008662	-000156	0750	0875	0812	0250	0125	0187	0000	%0829	U20 \$
008589	000013	-000002	0750	0750	0750	0250	0250	0250	0000	%0182	U03 \$	008708	000011	000012	0750	0750	0750	0250	0250	0250	0000	%0506	U12 \$	008611	000015	000002	0750	0750	0750	0250	0250	0250	0000	%0830	U21 \$
007996	-00097	-00924	0625	0687	0750	0375	0312	0250	0000	%0183	U04 \$	007889	000847	-00785	0687	0625	0750	0312	0375	0250	0000	%0507	U13 \$	007814	000967	-000051	0750	0625	0687	0250	0375	0312	0000	%0831	U22 \$
007294	-00187	-01599	0500	0625	0750	0500	0375	0250	0000	%0184	U05 \$	007030	-001580	-01281	0625	0500	0750	0375	0500	0250	0000	%0508	U14 \$	007106	001651	-000360	0750	0500	0625	0250	0500	0375	0000	%0832	U23 \$
006439	-00481	-02405	0375	0562	0750	0625	0437	0250	0000	%0185	U06 \$	006142	-002371	-01717	0562	0375	0750	0437	0625	0250	0000	%0509	U15 \$	006347	002484	-000601	0750	0375	0562	0250	0625	0437	0000	%0833	U24 \$
005720	-00648	-03046	0250	0500	0750	0750	0500	0250	0000	%0186	U07 \$	005172	-003317	-02200	0500	0250	0750	0500	0750	0250	0000	%0510	U16 \$	005470	003561	-000973	0750	0375	0500	0250	0750	0500	0000	%0834	U25 \$
005128	-00851	-03697	0125	0437	0750	0875	0562	0250	0000	%0187	U08 \$	004126	-004614	-02588	0437	0125	0750	0562	0875	0250	0000	%0511	U17 \$	004568	004906	-001282	0750	0125	0437	0250	0875	0562	0000	%0835	U26 \$
004406	-00672	-04882	0000	0375	0750	1000	0625	0250	0000	%0188	U09 \$	003240	-004585	-02495	0375	0000	0750	0625	1000	0250	0000	%0512	U18 \$	003857	-005381	-001240	0750	0000	0375	0250	1000	0625	0000	%0836	U27 \$
008703	000247	-002967	1000	0812	0625	0000	0187	0375	0000	%0189	V01 \$	009143	-01543	-002964	0812	1000	0625	0187	0000	0375	0000	%0513	V10 \$	008491	-01449	-00271	0625	1000	0812	0375	0000	0187	0000	%0837	V19 \$
008553	000161	-002347	0875	0750	0625	0125	0250	0375	0000	%0190	V02 \$	009140	-01273	-002398	0750	0875	0625	0250	0125	0375	0000	%0514	V11 \$	008452	-01404	-000937	0625	0875	0750	0375	0125	0250	0000	%0838	V20 \$
008291	000090	-001008	0750	0687	0625	0250	0312	0375	0000	%0191	V03 \$	008599	-00686	-000941	0687	0750	0625	0312	0250	0375	0000	%0515	V12 \$	008453	-000970	-000163	0625	0750	0687	0375	0250	0312	0000	%0839	V19 \$
007787	000011	-00034	0625	0625	0625	0375	0375	0375	0000	%0192	V04 \$	007905	000013	-00037	0625	0625	0625	0375	0375	0375	0000	%0516	V13 \$	007823	000016	-00035	0625	0625	0625	0375	0375	0375	0000	%0840	V22 \$
007143	-00102	-01061	0500	0875	0562	0500	0437	0375	0000	%0193	V05 \$	006976	000861	-00025	0562	0500	0625	0437	0500	0375	0000	%0517	V14 \$	007017	000986	-000070	0625	0500	0562	0375	0500	0437	0000	%0841	V23 \$
006339	-00190	-01862	0375	0562	0625	0625	0625	0375	0000	%0194	V06 \$	006103	-001648	-01381	0500	0375	0625	0500	0625	0375	0000	%0518	V15 \$	006251	001777	-000434	0625	0375	0500	0375	0625	0500	0000	%0842	V24 \$
005587	-00495	-02626	0250	0437	0625	0750	0562	0375	0000	%0195	V07 \$	005144	-002589	-01838	0437	0250	0625	0562	0750	0375	0000	%0519	V16 \$	005272	-002707	-000759	0625	0500	0437	0375	0750	0562	0000	%0843	V25 \$
004986	-00664	-03226	0125	0375	0625	0875	0625	0375	0000	%0196	V08 \$	004127	-003698	-02276	0375	0125	0625	0625	0875	0375	0000	%0520	V17 \$	004215	-004008	-001073	0625	0125	0375	0375	0875	0625	0000	%0844	V26 \$
004039	-00566	-04554	0000	0312	0625	1000	0687	0375	0000	%0197	V09 \$	002994	-004282	-02262	0312	0000	0625	0687	1000	0375	0000	%0521	V18 \$	003466	-004794	-001136	0625	0000	0312	0375	1000	0687	0000		

009709	-00003	000008	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$	009705	000003	-00009	1000	1000	1000	0000	0000	%0567	b10	\$	009694	000000	000001	1000	1000	1000	0000	0000	0000	0000	%0891	b19	\$	
009136	000005	-00630	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$	009224	000713	-00329	0880	0875	1000	0031	0125	0000	%0568	b11	\$	009150	000604	000349	1000	0875	0906	0000	0125	0093	0000	%0892	b20	\$
008571	-00115	-01222	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$	008573	001561	-00644	0937	0750	1000	0062	0250	0000	%0569	b12	\$	008650	001095	000725	1000	0750	0812	0000	0250	0187	0000	%0893	b21	\$
007542	000082	-02090	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$	007942	002278	-00864	0936	0625	1000	0093	0375	0000	%0570	b13	\$	008021	001763	001174	1000	0625	0718	0000	0375	0281	0000	%0894	b22	\$
006526	000383	-02798	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$	007126	003124	-01206	0875	0500	1000	0155	0500	0000	%0571	b14	\$	007325	002557	001795	1000	0500	0625	0000	0500	0375	0000	%0895	b23	\$
005534	000786	-03413	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$	006200	004026	-01574	0843	0375	1000	0126	0625	0000	%0572	b15	\$	006465	003825	002200	1000	0375	0531	0000	0625	0468	0000	%0896	b24	\$
004713	000925	-03997	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$	005427	004917	-01775	0812	0250	1000	0187	0750	0000	%0573	b16	\$	005638	005139	002762	1000	0250	0437	0000	0750	0562	0000	%0897	b25	\$
004076	000792	-04475	0125	0343	1000	0875	0556	0000	0000	%0250	b08	\$	004616	005790	-01797	0781	0125	1000	0217	0875	0000	%0574	b17	\$	004928	006363	002981	1000	0125	0343	0000	0875	0556	0000	%0898	b26	\$
003653	000742	-04677	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$	004145	006146	-01782	0750	0000	1000	0250	1000	0000	%0575	b18	\$	004484	006057	002653	1000	0000	0250	0000	1000	0750	0000	%0899	b27	\$
009565	-00347	001342	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$	009418	-00704	000845	0906	1000	0875	0093	0000	0125	%0576	c10	\$	009308	-00515	-00283	0875	1000	0968	0125	0000	0031	0000	%0900	c10	\$
009363	000001	000027	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$	009463	000007	000002	0875	0875	0875	0125	0125	0125	%0577	c11	\$	009418	000002	000020	0875	0875	0875	0125	0125	0125	0000	%0901	c10	\$
007740	000062	-00852	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$	008817	000868	-00605	0843	0750	0875	0156	0250	0125	%0578	c12	\$	008559	000750	000458	0875	0750	0781	0125	0250	0218	0000	%0902	c21	\$
008798	000299	-01660	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$	008182	001649	-00910	0812	0625	0875	0187	0375	0125	%0579	c13	\$	008027	001273	000946	0875	0625	0687	0125	0375	0312	0000	%0903	c22	\$
007082	000242	-02385	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$	007345	002608	-01233	0781	0500	0875	0218	0500	0125	%0580	c14	\$	007442	002034	001529	0875	0500	0593	0125	0500	0406	0000	%0904	c23	\$
005940	000398	-03253	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$	006354	003632	-01625	0750	0375	0875	0250	0625	0125	%0581	c15	\$	006671	003141	002010	0875	0375	0500	0125	0625	0500	0000	%0905	c24	\$
004841	000572	-04033	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$	005477	004627	-01837	0718	0250	0875	0281	0750	0125	%0582	c16	\$	005833	004502	002580	0875	0250	0406	0125	0750	0593	0000	%0906	c25	\$
004158	000595	-04514	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$	004626	005608	-01844	0687	0125	0875	0312	0875	0125	%0583	c17	\$	004977	005920	002877	0875	0125	0312	0125	0875	0687	0000	%0907	c26	\$
003635	000669	-04630	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$	003971	005852	-01754	0656	0000	0875	0343	1000	0125	%0584	c18	\$	004238	005635	002451	0875	0000	0218	0125	1000	0781	0000	%0908	c27	\$
009318	-00423	002458	1000	0937	0750	0000	0602	0250	0000	%0261	d01	\$	009247	-01151	001719	0812	1000	0750	0187	0000	0250	%0585	d10	\$	008832	-00893	-00828	0750	1000	0937	0250	0000	0062	0000	%0909	d19	\$
009148	-00165	001271	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$	009264	-00779	000920	0781	0875	0750	0218	0125	0250	%0586	d11	\$	009096	-00708	-00483	0750	0875	0843	0250	0125	0156	0000	%0910	d20	\$
008614	000016	-00019	0500	0750	0750	0750	0250	0250	0000	%0263	d03	\$	008742	000013	-00002	0750	0750	0750	0250	0250	0250	%0587	d12	\$	008668	000019	-00012	0750	0750	0750	0250	0250	0250	0000	%0911	d21	\$
007920	000093	-01020	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$	008011	000929	-00714	0718	0625	0750	0281	0375	0250	%0588	d13	\$	007893	000771	000442	0750	0625	0656	0250	0375	0343	0000	%0912	d22	\$
006963	000333	-01726	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$	007243	001779	-00990	0687	0500	0750	0312	0500	0250	%0589	d14	\$	007213	001300	001179	0750	0500	0562	0250	0500	0437	0000	%0913	d23	\$
005997	000277	-02621	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$	006400	002699	-01312	0656	0375	0750	0343	0625	0250	%0590	d15	\$	006421	002078	001554	0750	0375	0468	0250	0625	0531	0000	%0914	d24	\$
005223	000456	-03434	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$	005524	003754	-01562	0625	0250	0750	0375	0750	0250	%0591	d16	\$	005520	003261	001928	0750	0250	0375	0250	0750	0625	0000	%0915	d25	\$
004490	000465	-04173	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$	004575	005013	-01765	0503	0125	0750	0406	0875	0250	%0592	d17	\$	004653	004612	002286	0750	0125	0281	0250	0875	0718	0000	%0916	d26	\$
003490	000615	-04479	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$	003713	005055	-01708	0562	0000	0750	0437	1000	0250	%0593	d18	\$	003899	005077	002122	0750	0000	0187	0250	1000	0812	0000	%0917	d27	\$
009105	-00399	003336	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$	008830	-01174	002100	0718	1000	0625	0281	0000	0375	%0594	e10	\$	008366	-01343	-01003	0625	1000	0906	0375	0000	0093	0000	%0918	e19	\$
009002	-00334	002636	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$	008902	-01524	001955	0687	0875	0625	0312	0125	0375	%0595	e11	\$	008607	-01142	-00799	0625	0875	0812	0375	0125	0187	0000	%0919	e20	\$
008531	-00093	001158	0750	0718	0875	0625	0250	0281	0375	%0272	e03	\$	008589	-00845	000845	0656	0750	0625	0343	0250	0375	%0596	e12	\$	008456	-00783	-00435	0625	0750	0718	0375	0250	0281	0000	%0920	e21	\$
007847	000012	-00045	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$	007943	000016	-00055	0625	0625	0625	0375	0375	0375	%0597	e13	\$	007854	000016	-00045	0625	0625	0625	0375	0375	0375	0000	%0921	e22	\$
007003	000224	-01196	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$	007007	001037	-00759	0531	0500	0625	0406	0500	0375	%0598	e14	\$	007107	000819	000417	0625	0500	0531	0375	0600	0468	0000	%0922	e23	\$
005962	000238	-02025	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$	006279	002073	-01805	0562	0375	0625	0437	0625	0375	%0599	e15	\$	006217	001458	001208	0625	0375	0437	0375	0625	0562	0000	%0923	e24	\$
005123	000232	-02726	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$	005334	003220	-01409	0531	0250	0625	0468	0750	0375	%0600	e16	\$	005178	002646	001639	0625	0250	0343	0375	0750	0656	0000	%0924	e25	\$
004546	000332	-03325	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$	004303	004549	-01697	0500	0125	0625	0500	0875	0375	%0601	e17	\$	004273	003866	002025	0625	0125	0250	0375	0875	0750	0000	%0925	e26	\$
003272	000703	-04273	0000	0156	0625	1000	0843	0375	0000	%0278	e																										

See original or copy: <http://web.me.com/klaus.richter/JE73/JE73L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

```
%BEG JE73_22_REM.TXT, Separation cmyn62*, D65, adapted S
%100 x LAB*a      %1000 x (r g b c m y o)      %nr.   pos $
%Z004556 006172 003892 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009153 -01396 008449 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005814 -06103 003645 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005429 -03113 -04023 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003181 002707 -04166 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004629 007236 -00970 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001574 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009685 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004556 006172 003892 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009153 -01396 008449 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005814 -06103 003645 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005429 -03113 -04023 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003181 002707 -04166 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004629 007236 -00970 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001574 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009685 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004556 006172 003892 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009153 -01396 008449 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005814 -06103 003645 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005429 -03113 -04023 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003181 002707 -04166 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004629 007236 -00970 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001574 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009685 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z005899 004295 005916 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z009006 -02114 008695 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005871 -05450 001377 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005360 -02531 -04710 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003166 004200 -03344 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004478 006836 -00093 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001682 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009691 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z007074 002077 007011 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007674 -03514 006581 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005982 -04665 -00256 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004664 -01102 -04892 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003620 005157 -02562 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004430 006292 001445 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001786 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009708 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z008243 000078 007844 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006653 -04764 004976 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005989 -04001 -01732 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003653 000742 -04677 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004145 006146 -01702 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004484 006057 002653 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001760 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009793 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```


See original or copy: <http://web.me.com/klaus.richter/JE73/JE73L0NA.TXT/.PS>
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

%BEG JE73_22.REM.TXT, Separation cmyn62*, D65, adapted S										%nr. pos \$															
%100 x LAB*a 1000 x (r g b c m y θ)																									
001527	-00012	-000022	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$	009334	000007	000015	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$
002674	-00019	-00061	0125	0125	0125	0875	0875	0875	0000	%0973	k02	\$	009676	-00004	000011	0933	0933	0933	0866	0866	0866	0000	%1054	m24	\$
004526	-00010	-00106	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$	009709	-00008	000013	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$
005786	-00002	-00091	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$	001535	-00001	000020	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$
006965	-00004	-00084	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	001915	-00008	000001	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$
007932	-00012	-00040	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$	002958	-00005	-000072	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$
008725	-00014	-00006	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$	004066	000007	-000088	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$
009473	-00004	-000005	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$	004778	000009	-000058	0266	0266	0266	0733	0733	0733	0000	%1060	n14	\$
009726	-00004	-000005	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$	005515	-000008	-000073	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$
001498	-00010	-000023	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$	006183	-000014	-000067	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$
002625	-00014	-00067	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$	006746	000010	-000052	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$
004510	-00005	-00109	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$	007266	000011	-000045	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$
005767	-00000	-00097	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$	007721	-000012	-000022	0600	0600	0600	0666	0666	0666	0000	%1065	n19	\$
006939	-00005	-00087	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	008099	000018	-000066	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$
007931	-00012	-00038	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$	008527	-000017	000000	0733	0733	0733	0266	0266	0266	0000	%1067	n21	\$
008686	-00013	-00002	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$	008994	-000014	000016	0800	0800	0800	0199	0199	0199	0000	%1068	n22	\$
009469	-00003	-00011	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$	009307	-000008	000021	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$
009728	-00002	-00004	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$	009661	-000003	-000007	0933	0933	0933	0866	0866	0866	0000	%1070	n24	\$
001362	-00010	-00028	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$	009715	-000000	-000003	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$
002552	-00015	-00041	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$	001613	-000000	000000	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$
004468	-00003	-00078	0250	0250	0250	0750	0750	0750	0000	%0992	m03	\$	009705	000000	000000	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$
005744	-00001	-00078	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$	004540	-000008	009372	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
006923	-00006	-00069	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$	005481	-03391	-03750	0000	1000	1000	1000	0000	0000	0000	%1075	l27	\$
007896	-00009	-00026	0625	0625	0625	0375	0375	0375	0000	%0995	m06	\$	009148	-01375	086673	1000	1000	0000	0000	0000	1000	0000	%1076	m26	\$
008701	-00013	-00002	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$	003169	002745	-04246	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$
009467	-00001	-00017	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$	005741	-06365	003799	0000	1000	0000	0000	1000	0000	0000	%1078	n26	\$
009717	-00009	-00023	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$	004571	007300	-01061	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$
001322	-00013	-00017	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$													
002578	-00015	-00041	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$	%004540	006098	003742	##1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
004468	-00003	-00078	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$	%009148	-01375	008673	##1000	1000	0000	0000	0000	1000	0000	%1076	m26	\$
005737	-00001	-00063	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$	%005741	-06365	003799	##0000	1000	0000	1000	0000	1000	0000	%1078	n26	\$
006906	-00007	-00072	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$	%005481	-03391	-03759	##0000	1000	1000	1000	0000	0000	0000	%1075	l27	\$
007865	-00016	-00032	0625	0625	0625	0375	0375	0375	0000	%1004	n06	\$	%003169	002745	-04246	##0000	0000	1000	1000	1000	1000	0000	%1077	m27	\$
008690	-00015	-00009	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$	%004571	007300	-01061	##1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$
009472	-00001	-00019	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$	%001613	000000	000000	##0000	0000	0000	1000	1000	1000	0000	%1072	k27	\$
009721	-00001	-00003	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$	%009705	000000	000000	##1000	1000	1000	0000	0000	0000	0000	%1073	k28	\$
001906	-00005	-00002	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$													
002120	-00005	-00021	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$	%001527	-00012	000022	##0000	0000	0000	1000	1000	1000	0000	%0972	k28	\$
003056	-00005	-00098	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$	%009726	-00004	000005	##1000	1000	1000	0000	0000	0000	0000	%0972	k28	\$
004075	-00001	-00119	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$													
004799	-00004	-00096	0266	0266	0266	0733	0733	0733	0000	%1012	k14	\$	%001498	-00010	000023	##0000	0000	0000	1000	1000	1000	0000	%0981	l26	\$
005538	-00006	-00105	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$	%009728	-00002	000004	##1000	1000	1000	0000	0000	0000	0000	%0989	l26	\$
006236	-00010	-00093	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$													
006854	-00007	-00081	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$	%001362	-00010	000028	##0000	0000	0000	1000	1000	1000	0000	%0990	m28	\$
007298	-00005	-00057	0533	0533	0533	0466	0466	0466	0000	%1016	k18	\$	%009717	-00009	000023	##1000	1000	1000	0000	0000	0000	0000	%0998	m28	\$
007789	-00006	-00029	0600	0600	0600	0399	0399	0399	0000	%1017	k19	\$													
008205	-00013	-00010	0666	0666	0666	0333	0333	0333	0000	%1018	k20	\$	%009122	-00013	000017	##0000	0000	0000	1000	1000	0000	0000	%0999	n28	\$
008629	-00016	-00001	0733	0733	0733	0266	0266	0266	0000	%1019	k21	\$	%009721	000001	-00003	##1000	1000	1000	0000	0000	0000	0000	%1007	n28	\$
009031	-00012	-00009	0																						

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart JE73; Relative Device Colour System O
1080 spectral reflexions R → LAB* for D65 and D50

```
input: w setgray
output: -> oly* setrgbcolor
```

TUB registration: 20100301-JE73/JE73L0NA.TXT /.PS
application for evaluation and measurement of printer o

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/IE73/JE73L0NA.TXT> / .PS
Technical information: <http://www.ps.barn.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009705	-00076	000224	1000	1000	1000	0000	0000	0000	0000	00081	J01 \$
009323	-00519	-00313	0875	0968	1000	0125	0031	0000	0000	00082	J02 \$
008822	-00960	-00975	0750	0937	1000	0250	0062	0000	0000	00083	J03 \$
008240	-01230	-01676	0625	0906	1000	0375	0093	0000	0000	00084	J04 \$
007627	-01536	-02359	0500	0875	1000	0500	0125	0000	0000	00085	J05 \$
007150	-01866	-02918	0375	0843	1000	0625	0156	0000	0000	00086	J06 \$
006388	-02151	-03672	0250	0812	1000	0750	0187	0000	0000	00087	J07 \$
005689	-02731	-04229	0125	0781	1000	0875	0218	0000	0000	00088	J08 \$
005193	-03400	-04804	0000	0750	1000	1000	0250	0000	0000	00089	J09 \$
009276	-00074	001211	1000	0906	0875	0000	0093	0125	0000	00090	K01 \$
009352	-00252	000209	0875	0875	0875	0125	0125	0125	0000	00091	K02 \$
009075	-00594	-00582	0750	0843	0875	0250	0156	0125	0000	00092	K03 \$
008436	-00850	-01349	0625	0812	0875	0375	0187	0125	0000	00093	K04 \$
007835	-01288	-02089	0500	0781	0875	0500	0218	0125	0000	00094	K05 \$
007185	-01656	-02754	0375	0750	0875	0625	0250	0125	0000	00095	K06 \$
006350	-02022	-03347	0250	0718	0875	0750	0281	0125	0000	00096	K07 \$
005645	-02458	-03914	0125	0687	0875	0875	0312	0125	0000	00097	K08 \$
005125	-03358	-04811	0000	0656	0875	1000	0343	0125	0000	00098	K09 \$
008922	-00058	002040	1000	0812	0750	0000	0187	0250	0000	00099	L01 \$
008795	000393	001250	0875	0781	0750	0125	0218	0250	0000	00100	L02 \$
008615	-00037	000129	0750	0750	0750	0250	0250	0250	0000	00101	L03 \$
008269	-00540	-00670	0625	0718	0750	0375	0281	0250	0000	00102	L04 \$
007696	-00826	-01365	0500	0687	0750	0500	0312	0250	0000	00103	L05 \$
006900	-01397	-02308	0375	0656	0750	0625	0343	0250	0000	00104	L06 \$
006171	-01709	-02984	0250	0625	0750	0750	0375	0250	0000	00105	L07 \$
005492	-02182	-03479	0125	0593	0750	0875	0406	0250	0000	00106	L08 \$
004971	-03328	-04572	0000	0562	0750	1000	0437	0250	0000	00107	L09 \$
008475	-00108	002917	1000	0718	0625	0000	0281	0375	0000	00108	M01 \$
008349	000830	002307	0875	0687	0625	0125	0312	0375	0000	00109	M02 \$
008086	-000454	001103	0750	0656	0625	0250	0343	0375	0000	00110	M03 \$
007826	-00037	000168	0625	0625	0625	0375	0375	0375	0000	00111	M04 \$
007331	-00711	-00868	0500	0593	0625	0500	0406	0375	0000	00112	M05 \$
006660	-00972	-01696	0375	0562	0625	0625	0437	0375	0000	00113	M06 \$
005883	-01410	-02538	0250	0531	0625	0750	0468	0375	0000	00114	M07 \$
005299	-01877	-03194	0125	0500	0625	0875	0500	0375	0000	00115	M08 \$
004690	-03922	-04487	0000	0468	0625	1000	0531	0375	0000	00116	M09 \$
007910	001756	003436	1000	0625	0500	0000	0375	0500	0000	00117	N01 \$
007891	001357	002958	0875	0593	0500	0125	0406	0500	0000	00118	N02 \$
007641	000838	002039	0750	0562	0500	0250	0437	0500	0000	00119	N03 \$
007291	000559	001308	0625	0531	0500	0375	0468	0500	0000	00120	N04 \$
006896	-00033	000096	0500	0500	0500	0500	0500	0500	0000	00121	N05 \$
006349	-00448	-01077	0375	0468	0500	0625	0531	0500	0000	00122	N06 \$
005555	-01075	-02082	0250	0437	0500	0750	0562	0500	0000	00123	N07 \$
004989	-01544	-02834	0125	0406	0500	0875	0593	0500	0000	00124	N08 \$
004201	-02469	-04267	0000	0375	0500	1000	0625	0500	0000	00125	N09 \$
007399	002500	004148	1000	0531	0375	0000	0468	0625	0000	00126	O01 \$
007397	002037	003628	0875	0500	0375	0125	0500	0625	0000	00127	O02 \$
007085	001381	002880	0750	0468	0375	0250	0531	0625	0000	00128	O03 \$
006787	000979	002285	0625	0437	0375	0375	0562	0625	0000	00129	O04 \$
006358	000552	001269	0500	0406	0375	0500	0593	0625	0000	00130	O05 \$
005889	-00017	000067	0375	0375	0375	0625	0625	0625	0000	00131	O06 \$
005314	-00727	-01387	0250	0343	0375	0750	0656	0625	0000	00132	O07 \$
004732	-01201	-02368	0125	0312	0375	0875	0687	0625	0000	00133	O08 \$
003741	-02126	-03775	0000	0281	0375	1000	0718	0625	0000	00134	O09 \$
006897	003284	005130	1000	0437	0250	0000	0562	0750	0000	00135	P01 \$
006906	002933	004522	0875	0406	0500	0125	0593	0750	0000	00136	P02 \$
006526	002107	003534	0750	0375	0250	0250	0625	0750	0000	00137	P03 \$
006125	001718	002946	0625	0343	0250	0375	0625	0750	0000	00138	P04 \$
005690	001228	002239	0500	0312	0250	0500	0687	0750	0000	00139	P05 \$
005239	000601	001338	0375	0281	0250	0625	0718	0750	0000	00140	P06 \$
004648	000083	000053	0250	0250	0250	0750	0750	0750	0000	00141	P07 \$
004231	-00859	-01744	0125	0218	0250	0875	0781	0750	0000	00142	P08 \$
003416	-02091	-03361	0000	0187	0250	1000	0812	0750	0000	00143	P09 \$
006463	004014	006001	1000	0343	0125	0000	0656	0875	0000	00144	Q01 \$
006372	003876	005729	0875	0312	0125	0125	0687	0875	0000	00145	Q02 \$
005927	003047	004432	0750	0281	0125	0250	0718	0875	0000	00146	Q03 \$
005428	002734	004003	0625	0250	0125	0375	0750	0875	0000	00147	Q04 \$
004972	002131	003302	0500	0218	0125	0500	0781	0875	0000	00148	Q05 \$
004504	001549	002500	0375	0187	0125	0625	0812	0875	0000	00149	Q06 \$
004071	000905	001700	0250	0156	0125	0750	0843	0875	0000	00150	Q07 \$
002979	000018	000019	0125	0125	0125	0875	0875	0875	0000	00151	Q08 \$
002974	-01664	-02749	0000	0093	0125	1000	0906	0875	0000	00152	Q09 \$
006049	004797	006191	1000	0250	0000	0000	0750	1000	0000	00153	R01 \$
006003	004511	006099	0875	0218	0000	0125	0781	1000	0000	00154	R02 \$
005506	004231	005461	0750	0187	0000	0250	0812	1000	0000	00155	R03 \$
004692	004001	004458	0625	0156	0000	0375	0843	1000	0000	00156	R04 \$
003944	003440	003531	0500	0125	0000	0500	0875	1000	0000	00157	R05 \$
003447	002969	002861	0375	0093	0000	0625	0906	1000	0000	00158	R06 \$
002914	002368	002015	0250	0062	0000	0750	0937	1000	0000	00159	R07 \$
002435	001587	001157	0125	0031	0000	0875	0968	1000	0000	00160	R08 \$
001764	000055	000090	0000	0000	0000	1000	1000	1000	0000	00161	R09 \$
009684	-00071	000210	1000	1000	1000	0000	0000	0000	0000	00405	J10 \$
009080	000370	-00248	0800	0875	1000	0093	0125	0000	0000	00406	J11 \$
008339	000829	-00869	0812	0750	1000	0818	0250	0000	0000	00407	J12 \$
007331	001454	-01448	0718	0625	1000	0281	0375	0000	0000	00408	J13 \$
006327	001981	-02056	0625	0500	1000	0375	0500	0000	0000	00409	J14 \$
005245	002573	-02636	0531	0375	1000	0468	0625	0000	0000	00410	J15 \$
004253	003334	-03016	0437	0250	1000	0562	0750	0000	0000	00411	J16 \$
003676	003701	-03081	0531	0250	1000	0687	0875	0000	0000	00412	J17 \$
003202	003556	-03305	0250	0000	1000	0750	1000	0000	0000	00413	J18 \$
009649	-00418	001474	0968	1000	0875	0031	0000	0125	0000	00414	J19 \$
009483	-00062	000222	0875	0875	0875	0125	0125	0125	0000	00415	K10 \$
008700	000433	-00610	0781	0750	0875	0218	0250	0125	0000	00416	K11 \$
007842	000965	-01218	0687	0625	0875	0312	0375	0125	0000	00417	K12 \$
006679	001721	-01870	0593	0500	0875	0406	0500	0125	0000	00418	K13 \$
005446	002318	-02607	0500	0375	0875	0500	0625	0125	0000	00419	K14 \$
004390	003091	-03101	0406	0250	0875	0593	0750	0125	0000	00420	K15 \$
003614	003732	-03170	0312	0125	0875	0687	0875	0125	0000	00421	K16 \$
002996	003817	-03141	0218	0000	0875	0781	1000	0125	0000	00422	K17 \$
009551	-00722	002704	0937	1000	0750	0062	0000	0250	0000	00423	L10 \$
009295	-00457	001451	0843	0875	0750	0156	0125	0250	0000	00424	L11 \$
008717	-00039	000200	0750	0750	0750	0250	0250	0250	0000	00425	L12 \$
007875	000460	-00707	0656	0625	0750	0343	0375	0250	0000	00426	L13 \$
006899	001165	-01364	0562	0500							

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009717	-000071	000197	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$	009706	-000073	000224	1000	1000	1000	0000	0000	0000	%0486	S10 \$	009703	-000069	000193	1000	1000	1000	0000	0000	0000	0000	%0810	S19 \$	
009190	-00295	-00442	0875	0937	1000	0125	0062	0000	0000	%0163	S02 \$	009166	000540	-00195	0937	0875	1000	0062	0125	0000	0000	%0487	S11 \$	009205	000715	000163	1000	0875	0937	0000	0125	0062	0000	%0811	S20 \$
008728	-00797	-01054	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$	008464	0001147	-00632	0875	0750	1000	0125	0250	0000	0000	%0488	S12 \$	008587	001513	000376	1000	0750	0875	0000	0250	0125	0000	%0812	S21 \$
007899	-00904	-01901	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$	007664	0002017	-00963	0812	0625	1000	0187	0375	0000	0000	%0489	S13 \$	008080	002275	000686	1000	0625	0812	0000	0375	0187	0000	%0813	S22 \$
007633	-00905	-02687	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$	006699	0002802	-01427	0750	0500	1000	0250	0500	0000	0000	%0490	S14 \$	007392	003184	001960	1000	0500	0750	0000	0500	0250	0000	%0814	S23 \$
006305	-01107	-03335	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$	005735	0003513	-01861	0687	0375	1000	0312	0625	0000	0000	%0491	S15 \$	006630	004285	001495	1000	0375	0687	0000	0625	0312	0000	%0815	S24 \$
005518	-01408	-04109	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$	004847	0004115	-02278	0625	0250	1000	0375	0750	0000	0000	%0492	S16 \$	005801	005691	001843	1000	0250	0625	0000	0750	0375	0000	%0816	S25 \$
004937	-01848	-04689	0125	0562	1000	0875	0500	0000	0000	%0169	S08 \$	004111	0004765	-02475	0562	0125	1000	0875	0500	0000	0000	%0512	S17 \$	005124	006885	002049	1000	0125	0562	0000	0875	0437	0000	%0817	S26 \$
004517	-01929	-05031	0000	0500	1000	1000	0500	0000	0000	%0170	S09 \$	003705	0005035	-02219	0500	0000	1000	0500	1000	0000	0000	%0494	S18 \$	004609	006518	001820	1000	0000	0500	0000	1000	0500	0000	%0818	S27 \$
003452	-00058	-001466	1000	0937	0875	0000	0062	0125	0000	%0171	T01 \$	009550	-00536	000230	0937	1000	0875	0062	0000	0125	0000	%0495	T10 \$	009312	-00640	000074	0875	1000	0937	0125	0000	0062	0000	%0819	T10 \$
003355	-00058	000217	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$	009475	-00061	000320	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$	009427	-00054	000203	0875	0875	0875	0125	0125	0125	0000	%0820	T10 \$
008839	-00280	-00694	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$	008749	000658	-00511	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$	008622	000917	000329	0875	0750	0812	0125	0250	0187	0000	%0821	T21 \$
008212	-00478	-01434	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$	008927	001275	-00949	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$	008080	001662	000624	0875	0625	0750	0125	0375	0250	0000	%0822	T22 \$
007452	-00804	-02254	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$	007056	002188	-01389	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$	006729	002634	000834	0875	0500	0687	0125	0500	0312	0000	%0823	T23 \$
006606	-00992	-03028	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$	006011	003134	-01810	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$	006739	003796	001413	0875	0375	0625	0125	0625	0375	0000	%0824	T24 \$
005701	-01402	-03922	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$	004909	003876	-02326	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$	005965	005054	001762	0875	0250	0562	0125	0750	0437	0000	%0825	T25 \$
005007	-01598	-04525	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$	004051	004643	-02409	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$	005128	006508	002083	0875	0125	0500	0125	0875	0500	0000	%0826	T26 \$
004345	-01638	-05033	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$	003522	004804	-02251	0437	0000	0875	0562	1000	0125	0000	%0503	T18 \$	004343	006148	001787	0875	0000	0437	0125	1000	0562	0000	%0827	T27 \$
009191	000062	002425	1000	0875	0750	0000	0125	0250	0000	%0180	T09 \$	009372	-00930	002296	0875	1000	0750	0125	0000	0250	0000	%0504	T19 \$	008862	-01164	000449	0750	1000	0875	0250	0000	0125	0000	%0828	U19 \$
009005	0000225	001384	0875	0812	0750	0125	0187	0250	0000	%0181	U02 \$	009223	-00580	001284	0812	0875	0750	0187	0125	0250	0000	%0505	U11 \$	009134	-00895	000298	0750	0875	0812	0250	0125	0187	0000	%0829	U20 \$
008590	-00040	000109	0750	0750	0750	0250	0250	0250	0000	%0182	U03 \$	008710	-00042	000206	0750	0750	0750	0250	0250	0250	0000	%0506	U12 \$	008613	-00037	000195	0750	0750	0750	0250	0250	0250	0000	%0830	U21 \$
007979	-00278	-00770	0625	0687	0750	0375	0312	0250	0000	%0183	U04 \$	007895	000769	-00581	0687	0625	0750	0312	0375	0250	0000	%0507	U13 \$	007836	000992	000271	0750	0625	0687	0250	0375	0312	0000	%0831	U22 \$
007262	-00739	-01481	0500	0625	0750	0500	0375	0250	0000	%0184	U05 \$	007043	001504	-01066	0625	0500	0750	0375	0500	0250	0000	%0508	U14 \$	007147	001761	000604	0750	0500	0625	0250	0500	0375	0000	%0832	U23 \$
006384	-00774	-02344	0375	0562	0750	0625	0437	0250	0000	%0185	U06 \$	006165	002296	-01487	0562	0375	0750	0437	0625	0250	0000	%0509	U15 \$	006411	002661	000875	0750	0375	0562	0250	0625	0437	0000	%0833	U24 \$
005644	-01039	-03033	0250	0500	0750	0750	0500	0250	0000	%0186	U07 \$	005209	003231	-01947	0500	0250	0750	0500	0750	0250	0000	%0510	U16 \$	005565	003798	001292	0750	0250	0500	0250	0750	0500	0000	%0834	U25 \$
005028	-01374	-03736	0125	0437	0750	0875	0562	0250	0000	%0187	U08 \$	004191	004595	-02282	0437	0125	0750	0562	0875	0250	0000	%0511	U17 \$	004703	005154	001667	0750	0125	0437	0250	0875	0562	0000	%0835	U26 \$
004268	-01467	-05003	0000	0375	0750	1000	0625	0250	0000	%0188	U09 \$	003310	004461	-02189	0375	0000	0750	0625	1000	0250	0000	%0512	U18 \$	004008	005596	001656	0750	0000	0375	0250	1000	0625	0000	%0836	U27 \$
008744	000564	003157	1000	0812	0625	0000	0187	0375	0000	%0189	V01 \$	009148	-01278	003075	0812	1000	0625	0187	0000	0375	0000	%0513	V10 \$	004856	-01511	-00185	0625	1000	0812	0375	0000	0187	0000	%0837	V19 \$
008586	000415	002536	0875	0750	0625	0125	0250	0375	0000	%0190	V02 \$	009145	-01062	002525	0750	0875	0625	0250	0125	0375	0000	%0514	V11 \$	008595	-01431	000133	0625	0875	0750	0375	0125	0250	0000	%0838	V20 \$
008307	000189	001196	0750	0687	0625	0250	0312	0375	0000	%0191	V03 \$	008599	-00622	001094	0687	0750	0625	0312	0250	0375	0000	%0515	V12 \$	008435	-00987	000289	0625	0750	0687	0375	0250	0312	0000	%0839	V21 \$
007788	-00033	000147	0625	0625	0625	0375	0375	0375	0000	%0192	V04 \$	007906	-00034	000146	0625	0625	0625	0375	0375	0375	0000	%0516	V13 \$	007824	-00029	000146	0625	0625	0625	0375	0375	0375	0000	%0840	V22 \$
007123	-00237	-00942	0500	0562	0625	0500	0437	0375	0000	%0193	V05 \$	005980	000784	-00735	0562	0500	0625	0437	0500	0375	0000	%0517	V14 \$	007048	-01027	000282	0625	0500	0562	0375	0500	0437	0000	%0841	V23 \$
006302	-00400	-01767	0375	0562	0625	0625	0625	0375	0000	%0194	V06 \$	006116	001577	-01177	0500	0375	0625	0500	0625	0375	0000	%0518	V15 \$	006298	-001913	000673	0625	0375	0500	0375	0625	0500	0000	%0842	V24 \$
005525	-00812	-02590	0250	0437	0625	0750	0562	0375	0000	%0195	V07 \$	005171	002516	-01612	0437	0250	0625	0562	0750	0375	0000	%0519	V16 \$	005346	003003	001036	0625	0500	0437	0375	0750	0562	0000	%0843	V25 \$
004904	-01089	-03234	0125	0375	0625	0875	0625	0375	0000	%0196	V08 \$	004174	003609	-02014	0375	0125	0625	0625	0875	0375	0000	%0520	V17 \$	004327	004333	001409	0625	0125	0375	0375	0875	0625	0000	%0844	V26 \$
003911	-01290	-04657	0000	0312	0625	1000	0687	0375	0000	%0197	V09 \$	003061	004180	-01969	0312	0000	0625	0687	1000	0375	0000	%0521	V18 \$	003601	005004	001									

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

009710	-00073	000212	1000	1000	1000	0000	0000	0000	0000	%0243	b01	\$
009127	-00112	-00448	0875	0906	1000	0125	0093	0000	0000	%0244	b02	\$
008548	-00285	-01072	0750	0812	1000	0250	0187	0000	0000	%0245	b03	\$
007506	-00154	-01974	0625	0718	1000	0375	0281	0000	0000	%0246	b04	\$
006481	0000089	-02710	0500	0625	1000	0500	0375	0000	0000	%0247	b05	\$
005481	000434	-03347	0375	0531	1000	0625	0468	0000	0000	%0248	b06	\$
004643	000475	-03967	0250	0437	1000	0750	0562	0000	0000	%0249	b07	\$
003985	000210	-04494	0125	0343	1000	0875	0562	0000	0000	%0250	b08	\$
003550	000075	-04724	0000	0250	1000	1000	0750	0000	0000	%0251	b09	\$
009576	-00249	-001528	1000	0968	0875	0000	0031	0125	0000	%0252	c01	\$
009365	-00061	000228	0875	0875	0875	0125	0125	0125	0000	%0253	c02	\$
008757	-00067	-00678	0750	0781	0875	0250	0218	0125	0000	%0254	c03	\$
007917	000115	-01513	0625	0687	0875	0375	0312	0125	0000	%0255	c04	\$
007042	-00102	-01280	0500	0593	0875	0500	0406	0125	0000	%0256	c05	\$
005883	000046	-03194	0375	0500	0875	0625	0500	0125	0000	%0257	c06	\$
004762	000094	-04023	0250	0406	0875	0750	0593	0125	0000	%0258	c07	\$
004061	-00097	-04545	0125	0312	0875	0875	0687	0125	0000	%0259	c08	\$
003531	000008	-04680	0000	0218	0875	1000	0781	0125	0000	%0260	c09	\$
003041	-00196	-002633	1000	0937	0750	0000	0602	0250	0000	%0261	d01	\$
009162	-00060	0001459	0875	0843	0750	0125	0156	0250	0000	%0262	d02	\$
008615	-00040	000172	0750	0750	0750	0250	0250	0250	0000	%0263	d03	\$
007906	-00038	-000660	0625	0656	0750	0375	0343	0250	0000	%0264	d04	\$
006940	000158	-01592	0500	0562	0750	0500	0437	0250	0000	%0265	d05	\$
005952	000007	-02539	0375	0468	0750	0625	0531	0250	0000	%0266	d06	\$
005161	000083	-03393	0250	0375	0750	0750	0625	0250	0000	%0267	d07	\$
004403	-00058	-04184	0125	0281	0750	0875	0718	0250	0000	%0268	d08	\$
003390	-00021	-04526	0000	0187	0750	1000	0812	0250	0000	%0269	d09	\$
009138	-00082	003502	1000	0906	0625	0000	0093	0375	0000	%0270	e01	\$
009028	-00080	-002808	0875	0812	0625	0125	0187	0375	0000	%0271	e02	\$
008545	000009	001341	0750	0718	0875	0625	0250	0281	0375	%0272	e03	\$
008748	-00036	0006135	0625	0625	0625	0375	0375	0375	0000	%0273	e04	\$
006988	000094	-01048	0500	0531	0625	0500	0468	0375	0000	%0274	e05	\$
005930	000043	-01021	0375	0437	0625	0625	0625	0375	0000	%0275	e06	\$
005075	000009	-02661	0250	0343	0625	0750	0566	0375	0000	%0276	e07	\$
004481	-00035	-03297	0125	0250	0625	0875	0750	0375	0000	%0277	e08	\$
003180	000109	-04307	0000	0156	0625	1000	0843	0375	0000	%0278	e09	\$
008913	000109	-004275	1000	0875	0500	0000	0125	0500	0000	%0279	f01	\$
008769	000081	-003686	0875	0781	0500	0125	0218	0500	0000	%0280	f02	\$
008390	-00070	-002766	0750	0687	0500	0250	0312	0500	0000	%0281	f03	\$
007767	-00016	-001428	0625	0593	0500	0375	0406	0500	0000	%0282	f04	\$
006938	-00035	-000082	0500	0500	0500	0500	0500	0500	0000	%0283	f05	\$
005989	000088	-01313	0375	0406	0500	0625	0593	0500	0000	%0284	f06	\$
005080	-00041	-02160	0250	0312	0500	0750	0687	0500	0000	%0285	f07	\$
004375	000091	-02923	0125	0218	0500	0875	0781	0500	0000	%0286	f08	\$
002988	000168	-04055	0000	0125	0500	1000	0875	0500	0000	%0287	f09	\$
008740	000252	004961	1000	0843	0375	0000	0156	0625	0000	%0288	g01	\$
008545	000202	004579	0875	0750	0375	0125	0250	0625	0000	%0289	g02	\$
008118	000100	-003771	0750	0656	0375	0250	0343	0625	0000	%0290	g03	\$
007551	000007	-002862	0625	0562	0375	0375	0437	0625	0000	%0291	g04	\$
006849	-00100	001568	0500	0468	0375	0500	0531	0625	0000	%0292	g05	\$
005863	-00019	0000668	0375	0375	0375	0625	0625	0625	0000	%0293	g06	\$
004885	-00004	-01643	0250	0281	0375	0750	0718	0625	0000	%0294	g07	\$
004155	-00072	-02480	0125	0187	0375	0875	0812	0625	0000	%0295	g08	\$
002806	000029	-03749	0000	0093	0375	1000	0906	0625	0000	%0296	g09	\$
008591	000386	-005605	1000	0812	0250	0000	0187	0750	0000	%0297	h01	\$
008373	000297	-005608	0875	0718	0500	0125	0281	0750	0000	%0298	h02	\$
007975	000100	-004769	0750	0625	0250	0250	0375	0750	0000	%0299	h03	\$
007325	000070	-004054	0625	0531	0250	0500	0468	0375	0000	%0300	h04	\$
006600	-00070	-003048	0500	0437	0250	0500	0562	0750	0000	%0301	h05	\$
005717	-00061	-001653	0375	0343	0250	0625	0656	0750	0000	%0302	h06	\$
004615	-00007	000037	0250	0250	0250	0750	0750	0750	0000	%0303	h07	\$
003769	-00015	-01880	0125	0156	0250	0875	0843	0750	0000	%0304	h08	\$
002590	-00087	-03068	0000	0062	0250	1000	0937	0750	0000	%0305	h09	\$
008472	000459	-006732	1000	0781	0125	0000	0218	0875	0000	%0306	i01	\$
008212	000578	-007106	0875	0687	0125	0125	0312	0875	0000	%0307	i02	\$
007729	000478	-006545	0750	0593	0125	0250	0406	0875	0000	%0308	i03	\$
007078	000309	-005738	0625	0500	0125	0375	0500	0875	0000	%0309	i04	\$
006272	000160	-004517	0500	0406	0125	0500	0593	0875	0000	%0310	i05	\$
005505	000061	-003466	0375	0312	0125	0625	0687	0875	0000	%0311	i06	\$
004669	-00041	-002139	0250	0218	0125	0750	0781	0875	0000	%0312	i07	\$
002996	000015	-000021	0125	0125	0125	0875	0875	0875	0000	%0313	i08	\$
002461	-00122	-02246	0000	0031	0125	1000	0968	0875	0000	%0314	i09	\$
008314	000664	-007902	1000	0750	0000	0000	0250	1000	0000	%0315	j01	\$
008176	000886	-008189	0875	0656	0000	0125	0343	1000	0000	%0316	j02	\$
007587	000805	-007465	0750	0562	0000	0250	0437	1000	0000	%0317	j03	\$
006509	000682	-006381	0625	0468	0000	0375	0531	1000	0000	%0318	j04	\$
005382	000520	-005102	0500	0375	0000	0500	0625	1000	0000	%0319	j05	\$
004535	000473	-004084	0375	0281	0000	0625	0718	1000	0000	%0320	j06	\$
003689	000413	-003990	0250	0187	0000	0750	0812	1000	0000	%0321	j07	\$
002757	000553	-001768	0125	0093	0000	0875	0906	1000	0000	%0322	j08	\$
001907	000047	-000085	0000	0000	0000	1000	1000	1000	0000	%0323	j09	\$
009706	-00069	0000195	1000	1000	1000	0000	0000	0000	0000	%0567	b10	\$
009234	000649	-00103	0968	0875	1000	0031	0125	0000	0000	%0568	b11	\$
008597	0001514	-00393	0937	0750	1000	0602	0250	0000	0000	%0569	b12	\$
007978	0002252	-00591	0968	0625	1000	0093	0375	0000	0000	%0570	b13	\$
007177	003107	-00909	0875	0500	1000	0125	0500	0000	0000	%0571	b14	\$
006267	004010	-01250	0843	0375	1000	0156	0625	0000	0000	%0572	b15	\$
005515	004900	-01414	0812	0250	1000	0187	0750	0000	0000	%0573	b16	\$
004731	005769	-01389	0781	0250	1000	0237	0875	0000	0000	%0574	b17	\$
004276	006117	-01267	0750	0000	1000	0250	1000	0000	0000	%0575	b18	\$
009415	-00664	0001008	0906	1000	0875	0093	0000	0125	0000	%0576	c10	\$
009465	-00059	0002005	0875	0875	0875	0125	0125	0125	0000	%0577	c11	\$
008826	000792	-00385	0843	0750	0875	0156	0250	0125	0000	%0578	c12	\$
008204	001591	-00666	0812	0625	0875	0187	0375	0125	0000	%0579	c13	\$
007382	002571	-00961	0781	0500	0875	0218	0500	0125	0000	%0580	c14	\$
006410	003602	-01323	0750	0375	0875	0250	0625	0125	0000	%0581	c15	\$
005556	004602	-01496	0781	0250	0875	0281	0750	0125	0000	%0582	c16	\$
004736	005583	-01449	0687	0125	0875	0312	0875	0125	0000	%0583	c17	\$
004093	005817	-01340	0656	0000	0875	0343	1000	0125	0000	%0584	c18	\$
009246	-01009	-001855	0812	1000	0750	0187	0000	0250	0000	%0585	d10	\$
009261	-00727	-001076	0781	0875	0750	0218	0125					

See original or copy: <http://web.me.com/klaus.richter/JE73/JE73L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

```
%BEG JE73_22_REM.TXT, Separation cmyn62*, D50, not adapted S
%100 x LAB*      %#1000 x (r g b c m y o)      %nr.    pos $
%Z004748 006516 004326 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009202 -00822 008457 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005739 -05672 003424 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005272 -03854 -04198 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003146 002277 -04054 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004805 007258 -00429 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001577 000060 000113 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009686 -00073 000207 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M1 7 $
%S
%Z004748 006516 004326 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009202 -00822 008457 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005739 -05672 003424 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005272 -03854 -04198 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003146 002277 -04054 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004805 007258 -00429 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001577 000060 000113 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009686 -00073 000207 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M2 7 $
%S
%Z004748 006516 004326 %#1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009202 -00822 008457 %#1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005739 -05672 003424 %#0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005272 -03854 -04198 %#0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003146 002277 -04054 %#0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004805 007258 -00429 %#1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001577 000060 000113 %#0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009686 -00073 000207 %#1000 1000 1000 0000 0000 0000 0000 %0000 A01 %M001 7 $
%S
%Z006049 004797 006191 %#1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z009042 -01544 008666 %#0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005782 -05243 001216 %#0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005193 -03409 -04894 %#0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003202 003956 -03098 %#0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004655 006935 000425 %#1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001685 000059 000101 %#0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009692 -00074 000220 %#1000 1000 1000 0000 0000 0000 0000 %0081 J01 %M251 7 $
%S
%Z007180 002647 007157 %#1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007667 -02977 006474 %#0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005882 -04684 -00392 %#0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004517 -01929 -05031 %#0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003705 005035 -02219 %#0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004609 006518 001920 %#1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001789 000058 000103 %#0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009709 -00071 000205 %#1000 1000 1000 0000 0000 0000 0000 %0162 S01 %M501 7 $
%S
%Z008314 000664 007902 %#1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006611 -04272 004811 %#0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005873 -04270 -01864 %#0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003550 000075 -04724 %#0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004276 006117 -01267 %#0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004666 006356 003098 %#1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001762 000055 000100 %#0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009704 -00071 000204 %#1000 1000 1000 0000 0000 0000 0000 %0243 b01 %M751 7 $
%S
```


See original or copy: <http://web.me.com/klaus.richter/JE73/JE73L0NA.TXT/.PS>
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

%BEG JE73_22_REM.TXT, Separation cmyn62*, D50, not adapted S																										
%100 x LAB*																										
1000 x (r g b c m y θ)																										
nrr. pos \$																										
0001529	0000039	000103	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$	0009335	-000053	000206	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$	
0002675	0000005	000035	0125	0125	0125	0875	0875	0875	0000	%0973	k02	\$	0009677	-000071	000206	0933	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$
0004526	-000019	000017	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$	0009710	-000075	000208	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$	
0005786	-000026	000050	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$	0001537	0000050	000102	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$	
0006965	-000036	000073	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	0001917	0000054	0000089	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$	
0007933	-000035	000132	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$	0002959	0000014	000029	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$	
0008726	-000041	000176	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$	0004067	0000008	0000029	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$	
0009474	-000060	000198	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$	0004779	0000004	0000009	0266	0266	0266	0733	0733	0733	0000	%1060	n14	\$	
0009727	-000072	000200	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$	0005516	-000009	0000085	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$	
0001500	000043	000104	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$	0006184	-000012	0000080	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$	
0002625	000010	000028	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$	0006747	-000022	0001013	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$	
0004510	-000013	000014	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$	0007267	-000028	0000116	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$	
0005767	-000025	000044	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$	0007722	-000030	0000146	0600	0600	0600	0399	0399	0399	0000	%1065	n19	\$	
0006939	-000034	000070	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	0008100	-000028	0000167	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$	
0007932	-000035	000133	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$	0008528	-000034	0000180	0733	0733	0733	0266	0266	0266	0000	%1067	n21	\$	
0008688	-000040	000180	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$	0008996	-000041	0000202	0800	0800	0800	0199	0199	0199	0000	%1068	n22	\$	
0009470	-000060	000203	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$	0009308	-000051	0000212	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$	
0009729	-000071	000200	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$	0009662	-000065	0000187	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$	
0001365	000045	000106	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$	0009716	-000069	0000191	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$	
0002553	000013	000053	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$	0001615	0000049	0000083	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$	
0004468	-000006	000044	0250	0250	0250	0750	0750	0750	0000	%0992	m03	\$	0009706	-000068	0000195	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$	
0005744	-000020	000063	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$	0004729	0006437	0004153	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$	
0006924	-000031	000088	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$	0005325	-040097	-03955	0000	1000	1000	1000	0000	0000	0000	%1075	l27	\$	
0007897	-000036	000144	0625	0625	0625	0375	0375	0375	0000	%0995	m06	\$	0009199	-007090	0006662	1000	0000	0000	0000	0000	1000	0000	%1076	m26	\$	
0008703	-000040	000185	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$	0003131	0002297	-04167	0000	1000	0000	1000	1000	1000	0000	%1077	m27	\$	
0009468	-000061	000209	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$	0005664	-059205	0003539	1000	0000	0000	1000	0000	1000	0000	%1078	n26	\$	
0009718	-000075	000218	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$	0004747	0007306	-00542	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$	
0001324	000042	000095	0000	0000	0000	1000	1000	1000	0000	%0999	n01	\$														
0002579	000013	000054	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$	%0004729	0006437	0004153	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$	
0004468	-000006	000044	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$	%0009199	-007090	0006662	1000	0000	0000	0000	1000	1000	0000	%1076	m26	\$	
0005737	-000018	000077	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$	%0005664	-059205	0003539	1000	0000	1000	0000	1000	1000	0000	%1078	n26	\$	
0006905	-000038	000135	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$	%0005325	-040097	-03955	1000	1000	1000	1000	0000	0000	0000	%1075	l27	\$	
0007867	-000039	000138	0625	0625	0625	0375	0375	0375	0000	%1004	n06	\$	%0003131	0002297	-04167	1000	0000	1000	1000	1000	0000	0000	%1077	m27	\$	
0008692	-000037	000186	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$	%0004747	0007306	-00542	1000	0000	1000	1000	1000	0000	0000	%1079	n27	\$	
0009473	-000061	000212	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$	%0001615	000049	0000083	1000	0000	1000	1000	1000	1000	0000	%1072	k26	\$	
0009721	-000067	000192	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$	%0009706	-000068	0000195	1000	1000	0000	0000	0000	0000	0000	%1073	k26	\$	
0001908	000049	000085	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$														
0002121	000043	000068	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$	%0001719	0000044	0000094	1000	0000	1000	1000	1000	1000	0000	%0972	k01	\$	
0003057	000009	000004	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$	%0009714	-000071	0000195	1000	1000	0000	0000	0000	0000	0000	%0980	k09	\$	
0004075	-000002	-000001	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$														
0004799	-000006	000031	0266	0266	0266	0733	0733	0733	0000	%1012	k14	\$	%0001685	0000047	0000099	1000	0000	1000	1000	1000	1000	0000	%0981	l06	\$	
0005538	-000016	000033	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$	%0009723	-000070	0000197	1000	1000	0000	0000	0000	0000	0000	%0989	l06	\$	
0006236	-000020	000055	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$														
0006854	-000031	000075	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$	%0001518	0000049	0000101	1000	0000	1000	1000	1000	1000	0000	%0990	m01	\$	
0007298	-000036	000105	0533	0533	0533	0466	0466	0466	0000	%1016	k18	\$	%0009714	-000075	0000213	1000	1000	0000	0000	0000	0000	0000	%0998	k09	\$	
0007790	-000038	000140	0600	0600	0600	0399	0399	0399	0000	%1017	k19	\$														
0008206	-000034	000165	0666	0666	0666	0333	0333	0333	0000	%1018	k20	\$	%0001431	0000046	0000099	1000	0000	1000	1000	1000	1000	0000	%0999	m01	\$	
0008631	-000036	000183	0733	0733	0733	0266	0266	0266	0000	%1019	k21	\$	%0009719	-000068	0000191	1000	1000	0000	0000	0000	0000	0000	%1007	n09	\$	
0009032	-000044	000196	0800	0800	0800	0199	0																			

N: No Output Linearization (OL) data in File (F), Startup (S) or Device (D)

TUB-test chart JE73; Relative Device Colour System O
1080 spectral reflexions R -> LAB* for D65 and D50

```
input: w setgray
output: ->oly* setrgbcolor
```

TUB registration: 20100301-JE73/JE73L0NA.TXT /.PS TUB n
application for evaluation and measurement of printer or monitor system

TUB material: code=rha4ta

See original or copy: <http://web.me.com/klaus.richter/JE73/JE73L0NA.TXT/.PS>
 Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cf1=1.00; nt

009717	000000	-00007	1000	1000	1000	0000	0000	0000	0000	%0162	S01 \$	009706	-00002	000019	1000	1000	1000	0000	0000	0000	%0486	S10 \$	009703	000001	-000011	1000	1000	1000	0000	0000	0000	0000	0000	%0810	S19 \$
009190	-00232	-00641	0875	0937	1000	0125	0062	0000	0000	%0163	S02 \$	009166	-000603	-00393	0937	0875	1000	0062	0125	0000	0000	%0487	S11 \$	009205	000778	-00035	1000	0875	0937	0000	0125	0062	0000	%0811	S20 \$
008728	-00741	-01246	0750	0875	1000	0250	0125	0000	0000	%0164	S03 \$	008464	-001198	-00821	0875	0750	1000	0125	0250	0000	0000	%0488	S12 \$	008587	001567	-000185	1000	0750	0875	0000	0250	0125	0000	%0812	S21 \$
007899	-00862	-02083	0625	0812	1000	0375	0187	0000	0000	%0165	S04 \$	007664	-002054	-01142	0812	0625	1000	0187	0375	0000	0000	%0489	S13 \$	008080	002319	000503	1000	0625	0812	0000	0375	0187	0000	%0813	S22 \$
007633	-00958	-02858	0500	0750	1000	0500	0250	0000	0000	%0166	S05 \$	006699	-002824	-01594	0750	0500	1000	0250	0500	0000	0000	%0490	S14 \$	007392	003137	000885	1000	0500	0750	0000	0500	0250	0000	%0814	S23 \$
006305	-01092	-03496	0375	0687	1000	0625	0312	0000	0000	%0167	S06 \$	005735	-003519	-02015	0687	0375	1000	0312	0625	0000	0000	%0491	S15 \$	006630	004306	001329	1000	0375	0687	0000	0625	0312	0000	%0815	S24 \$
005518	-01477	-04260	0250	0625	1000	0750	0375	0000	0000	%0168	S07 \$	004847	-004107	-02421	0625	0250	1000	0375	0750	0000	0000	%0492	S16 \$	005801	005698	001688	1000	0250	0625	0000	0750	0375	0000	%0816	S25 \$
004937	-01847	-04823	0125	0562	1000	0875	0507	0000	0000	%0169	S08 \$	004111	-005784	-02478	0562	025	1000	0875	0500	0000	0000	%0493	S17 \$	005124	006881	001903	1000	0125	0562	0000	0875	0437	0000	%0817	S26 \$
004517	-01943	-05169	0000	0500	1000	1000	0507	0000	0000	%0170	S09 \$	003705	-005008	-02347	0500	0000	1000	0500	1000	0000	0000	%0494	S18 \$	004609	006505	001730	1000	0000	0500	0000	1000	0500	0000	%0818	S27 \$
003452	-000609	-001264	1000	0937	0875	0000	0062	0125	0000	%0171	T01 \$	009550	-00467	-001127	0937	1000	0875	0062	0000	0125	0000	%0495	T10 \$	009312	-00575	-001225	0875	1000	0937	0125	0000	0062	0000	%0819	T19 \$
003355	-000907	-000017	0875	0875	0875	0125	0125	0125	0000	%0172	T02 \$	009475	-000006	-000017	0875	0875	0875	0125	0125	0125	0000	%0496	T11 \$	009427	000011	000001	0875	0875	0875	0125	0125	0125	0000	%0820	T20 \$
008839	-00223	-00888	0750	0812	0875	0250	0187	0125	0000	%0173	T03 \$	008749	-000713	-00704	0812	0750	0875	0187	0250	0125	0000	%0497	T12 \$	008622	000971	000138	0875	0750	0812	0125	0250	0187	0000	%0821	T21 \$
008212	-00431	-01628	0625	0750	0875	0375	0250	0125	0000	%0174	T04 \$	008029	-001319	-01132	0750	0625	0875	0250	0375	0125	0000	%0498	T13 \$	008080	001707	000439	0875	0625	0750	0125	0375	0250	0000	%0822	T22 \$
007452	-00770	-02439	0500	0687	0875	0500	0312	0125	0000	%0175	T05 \$	007056	-002216	-01560	0687	0500	0875	0312	0500	0125	0000	%0499	T14 \$	007429	002668	000658	0875	0500	0687	0125	0500	0312	0000	%0823	T23 \$
006606	-00972	-03193	0375	0625	0875	0625	0375	0125	0000	%0176	T06 \$	006011	-003145	-01968	0625	0375	0875	0375	0625	0125	0000	%0500	T15 \$	006739	003819	001246	0875	0375	0625	0125	0625	0375	0000	%0824	T24 \$
005701	-01396	-04076	0250	0562	0875	0750	0437	0125	0000	%0177	T07 \$	004909	-003869	-02470	0562	0250	0875	0437	0750	0125	0000	%0501	T16 \$	005965	005064	001605	0875	0250	0562	0125	0750	0437	0000	%0825	T25 \$
005007	-01603	-04670	0125	0500	0875	0875	0500	0125	0000	%0178	T08 \$	004051	-004622	-02541	0500	0125	0875	0500	0875	0125	0000	%0502	T17 \$	005128	006504	001937	0875	0125	0500	0125	0875	0500	0000	%0826	T26 \$
004345	-00165	-05170	0000	0437	0875	1000	0562	0125	0000	%0179	T09 \$	003522	-004774	-02377	0437	0000	0875	0562	1000	0125	0000	%0503	T18 \$	004343	006131	001651	0875	0000	0437	0125	1000	0562	0000	%0827	T27 \$
009191	-00025	-002227	1000	0875	0750	0000	0125	0250	0000	%0180	T01 \$	009372	-00864	-002095	0875	1000	0750	0125	0000	0250	0000	%0504	T19 \$	008862	-01106	-00044	0750	1000	0875	0250	0000	0125	0000	%0828	T28 \$
009005	-000285	-001188	0875	0812	0750	0125	0187	0250	0000	%0181	T02 \$	009223	-00517	-001885	0812	0875	0750	0187	0125	0250	0000	%0505	T11 \$	009134	-00833	-000101	0750	0875	0812	0250	0125	0187	0000	%0829	T29 \$
008590	-000012	-00001	0750	0750	0750	0250	0250	0250	0000	%0182	T03 \$	008710	-000012	-000013	0750	0750	0750	0250	0250	0250	0000	%0506	T12 \$	008613	000015	000001	0750	0750	0750	0250	0250	0250	0000	%0830	T30 \$
007979	-00185	-00952	0625	0687	0750	0375	0312	0250	0000	%0183	T04 \$	007895	-000811	-00762	0687	0625	0750	0312	0375	0250	0000	%0507	T13 \$	007836	001033	000090	0750	0625	0687	0250	0375	0312	0000	%0831	T31 \$
007262	-00348	-01655	0500	0625	0750	0500	0375	0250	0000	%0184	T05 \$	007043	-001532	-01237	0625	0500	0750	0375	0500	0250	0000	%0508	T14 \$	007147	001791	000432	0750	0500	0625	0250	0500	0375	0000	%0832	T32 \$
006384	-00757	-02506	0375	0562	0750	0625	0437	0250	0000	%0185	T06 \$	006165	-002309	-01647	0562	0375	0750	0437	0625	0250	0000	%0509	T15 \$	006411	002678	000713	0750	0375	0562	0250	0625	0437	0000	%0833	T33 \$
005644	-01034	-03186	0250	0500	0750	0750	0500	0250	0000	%0186	T07 \$	005209	-003229	-02094	0500	0250	0750	0500	0750	0250	0000	%0510	T16 \$	005565	003802	001140	0750	0250	0500	0250	0750	0500	0000	%0834	T34 \$
005028	-01380	-03882	0125	0437	0750	0875	0562	0250	0000	%0187	T08 \$	004191	-004486	-02417	0437	0125	0750	0562	0875	0250	0000	%0511	T17 \$	004703	005144	001526	0750	0125	0437	0250	0875	0562	0000	%0835	T35 \$
004268	-01485	-05138	0000	0375	0750	1000	0625	0250	0000	%0188	T09 \$	003310	-004428	-02312	0375	0000	0750	0625	1000	0250	0000	%0512	T18 \$	004008	005574	001524	0750	0000	0375	0250	1000	0625	0000	%0836	T36 \$
008744	-000620	-002964	1000	0812	0625	0000	0187	0375	0000	%0189	T01 \$	009148	-01215	-002877	0812	1000	0625	0187	0000	0375	0000	%0513	T19 \$	004856	-01460	-00374	0625	1000	0812	0375	0000	0187	0000	%0837	T37 \$
008586	-000468	-002345	0875	0750	0625	0125	0250	0375	0000	%0190	T02 \$	009145	-00999	-002327	0750	0875	0625	0250	0125	0375	0000	%0514	T11 \$	008595	-01378	-00957	0625	0875	0750	0375	0125	0250	0000	%0838	T38 \$
008307	-000238	-001009	0750	0687	0625	0250	0312	0375	0000	%0191	T03 \$	008599	-00569	-000903	0687	0750	0625	0312	0250	0375	0000	%0515	T12 \$	008435	-00937	-000109	0625	0750	0687	0375	0250	0312	0000	%0839	T39 \$
007788	-000006	-00032	0625	0625	0625	0375	0375	0375	0000	%0192	T04 \$	007906	-000907	-00063	0625	0625	0625	0375	0375	0375	0000	%0516	T13 \$	007824	-000011	-00093	0625	0625	0625	0375	0375	0375	0000	%0840	T40 \$
007123	-00208	-01114	0500	0812	0625	0500	0437	0375	0000	%0193	T05 \$	006980	-000811	-00905	0562	0500	0625	0437	0500	0375	0000	%0517	T14 \$	007046	-001055	-000111	0625	0500	0562	0375	0500	0437	0000	%0841	T41 \$
006302	-00384	-01928	0375	0562	0625	0625	0625	0375	0000	%0194	T06 \$	006116	-001589	-01336	0500	0375	0625	0500	0625	0375	0000	%0518	T15 \$	006298	-001928	-000512	0625	0375	0500	0375	0625	0500	0000	%0842	T42 \$
005525	-00809	-02741	0250	0437	0625	0750	0562	0375	0000	%0195	T07 \$	005711	-002813	-01759	0437	0250	0625	0562	0750	0375	0000	%0519	T16 \$	005346	003003	000887	0625	0500	0437	0375	0750	0562	0000	%0843	T43 \$
004904	-01096	-03378	0125	0375	0625	0875	0625	0375	0000	%0196	T08 \$	004174	-003590	-02148	0375	0125	0625	0625	0875	0375	0000	%0520	T17 \$	004327	-004316	-001273	0625	0125	0375	0375	0875	0625	0000	%0844	T44 \$
003911	-01314	-04788	0000	0312	0625	1000	0687	0375	0000	%0197	T09 \$	003061	-004143	-02088	0312	0000	0625	0687	1000	0375	0000	%0521	T18 \$	003601	-004075	-001386	0625	0000</							

See original or copy: <http://web.me.com/klaus.richter/JE73/JE73L0NA.TXT> /.PS
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

```
%BEG JE73_22_REM.TXT, Separation cmyn62*, D50, adapted S
%100 x LAB*a      %1000 x (r g b c m y o)      %nr.   pos $
%Z004748 006507 004175 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %01 0 $
%Z009202 -00757 008256 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y1 1 $
%Z005739 -05664 003262 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L1 2 $
%Z005272 -03853 -04355 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C1 3 $
%Z003146 002242 -04185 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V1 4 $
%Z004805 007250 -00580 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M1 5 $
%Z001577 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N1 6 $
%Z009686 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W1 7 $
%S
%Z004748 006507 004175 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %02 0 $
%Z009202 -00757 008256 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y2 1 $
%Z005739 -05664 003262 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L2 2 $
%Z005272 -03853 -04355 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C2 3 $
%Z003146 002242 -04185 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V2 4 $
%Z004805 007250 -00580 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M2 5 $
%Z001577 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N2 6 $
%Z009686 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W2 7 $
%S
%Z004748 006507 004175 %1000 0000 0000 0000 1000 1000 0000 %0072 I01 %000Y 0 $
%Z009202 -00757 008256 %1000 1000 0000 0000 0000 1000 0000 %0396 I10 %Y00L 1 $
%Z005739 -05664 003262 %0000 1000 0000 1000 0000 1000 0000 %0720 I19 %L00C 2 $
%Z005272 -03853 -04355 %0000 1000 1000 1000 0000 0000 0000 %0008 A09 %C00V 3 $
%Z003146 002242 -04185 %0000 0000 1000 1000 1000 0000 0000 %0332 A18 %V00M 4 $
%Z004805 007250 -00580 %1000 0000 1000 0000 1000 0000 0000 %0656 A27 %M000 5 $
%Z001577 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0080 I09 %N001 6 $
%Z009686 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0000 A01 %W001 7 $
%S
%Z006049 004811 006025 %1000 0250 0000 0000 0750 1000 0000 %0153 R01 %025Y 0 $
%Z009042 -01480 008455 %0750 1000 0000 0250 0000 1000 0000 %0477 R10 %Y25L 1 $
%Z005782 -05234 001054 %0000 1000 0250 1000 0000 0750 0000 %0801 R19 %L25C 2 $
%Z005193 -03410 -05047 %0000 0750 1000 1000 0250 0000 0000 %0089 J09 %C25V 3 $
%Z003202 003922 -03222 %0250 0000 1000 0750 1000 0000 0000 %0413 J18 %V25M 4 $
%Z004655 006925 000280 %1000 0000 0750 0000 1000 0250 0000 %0737 J27 %M250 5 $
%Z001685 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0161 R09 %N251 6 $
%Z009692 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0081 J01 %W251 7 $
%S
%Z007180 002677 006984 %1000 0500 0000 0000 0500 1000 0000 %0234 a01 %050Y 0 $
%Z007667 -02939 006295 %0500 1000 0000 0500 0000 1000 0000 %0558 a10 %Y50L 1 $
%Z005882 -04675 -00548 %0000 1000 0500 1000 0000 0500 0000 %0882 a19 %L50C 2 $
%Z004517 -01943 -05169 %0000 0500 1000 1000 0500 0000 0000 %0170 S09 %C50V 3 $
%Z003705 005008 -02347 %0500 0000 1000 0500 1000 0000 0000 %0494 S18 %V50M 4 $
%Z004609 006505 001780 %1000 0000 0500 0000 1000 0500 0000 %0818 S27 %M500 5 $
%Z001789 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0242 a09 %N501 6 $
%Z009709 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0162 S01 %W501 7 $
%S
%Z008314 000713 007715 %1000 0750 0000 0000 0250 1000 0000 %0315 j01 %075Y 0 $
%Z006611 -04250 004647 %0250 1000 0000 0750 0000 1000 0000 %0639 j10 %Y75L 1 $
%Z005873 -04260 -02019 %0000 1000 0750 1000 0000 0250 0000 %0963 j19 %L75C 2 $
%Z003550 000048 -04848 %0000 0250 1000 1000 0750 0000 0000 %0251 b09 %C75V 3 $
%Z004276 006102 -01400 %0750 0000 1000 0250 1000 0000 0000 %0575 b18 %V75M 4 $
%Z004666 006346 002960 %1000 0000 0250 0000 1000 0750 0000 %0899 b27 %M750 5 $
%Z001762 000000 000000 %0000 0000 0000 1000 1000 1000 0000 %0323 j09 %N751 6 $
%Z009704 000000 000000 %1000 1000 1000 0000 0000 0000 0000 %0243 b01 %W751 7 $
%S
```


See original or copy: <http://web.me.com/klaus.richter/JE73/JE73L0NA.TXT/.PS>
Technical information: <http://www.ps.bam.de> V 2.1, io=1,1, Cx=0; cfi=1.00; nt=0.01; nx=1.3

%BEG JE73_22.REM.TXT, Separation cmyn62*, D50, adapted S																									
%100 x LAB*a					1000 x (r g b c m y θ)					%xnr.					pos \$										
001529	-00010	000021	0000	0000	0000	1000	1000	1000	0000	%0972	k01	\$	009335	000009	000016	0866	0866	0866	0133	0133	0133	0000	%1053	m23	\$
002675	-00028	-00062	0125	0125	0125	0875	0875	0875	0000	%0973	k02	\$	009677	-00003	000011	0933	0933	0933	0066	0066	0066	0000	%1054	m24	\$
004586	-00026	-00106	0250	0250	0250	0750	0750	0750	0000	%0974	k03	\$	009710	-00006	000013	1000	1000	1000	0000	0000	0000	0000	%1055	m25	\$
005472	-00015	-00090	0375	0375	0375	0625	0625	0625	0000	%0975	k04	\$	001537	000000	000020	0000	0000	0000	1000	1000	1000	0000	%1056	n10	\$
006965	-00007	-00083	0500	0500	0500	0500	0500	0500	0000	%0976	k05	\$	001917	000009	000002	0066	0066	0066	0933	0933	0933	0000	%1057	n11	\$
007933	-00006	-00038	0625	0625	0625	0375	0375	0375	0000	%0977	k06	\$	002959	-00015	-000072	0133	0133	0133	0866	0866	0866	0000	%1058	n12	\$
008726	-00013	-00005	0750	0750	0750	0250	0250	0250	0000	%0978	k07	\$	004067	-00005	-000087	0200	0200	0200	0800	0800	0800	0000	%1059	n13	\$
009474	000004	000006	0875	0875	0875	0125	0125	0125	0000	%0979	k08	\$	004779	000001	-000057	0266	0266	0266	0733	0733	0733	0000	%1060	n14	\$
009727	-00004	000005	1000	1000	1000	0000	0000	0000	0000	%0980	k09	\$	005516	-00001	-000072	0333	0333	0333	0666	0666	0666	0000	%1061	n15	\$
001500	-00007	000023	0000	0000	0000	1000	1000	1000	0000	%0981	l01	\$	006184	000004	-000065	0400	0400	0400	0600	0600	0600	0000	%1062	n16	\$
002625	-00024	-00068	0125	0125	0125	0875	0875	0875	0000	%0982	l02	\$	006747	000002	-000050	0466	0466	0466	0533	0533	0533	0000	%1063	n17	\$
004510	-00020	-00108	0250	0250	0250	0750	0750	0750	0000	%0983	l03	\$	007267	000004	-000044	0533	0533	0533	0466	0466	0466	0000	%1064	n18	\$
005677	-00014	-00096	0375	0375	0375	0625	0625	0625	0000	%0984	l04	\$	007722	000009	-000020	0600	0600	0600	0399	0399	0399	0000	%1065	n19	\$
006939	-00006	-00086	0500	0500	0500	0500	0500	0500	0000	%0985	l05	\$	008100	000016	-000005	0666	0666	0666	0333	0333	0333	0000	%1066	n20	\$
007932	000006	-00036	0625	0625	0625	0375	0375	0375	0000	%0986	l06	\$	008528	000017	000001	0733	0733	0733	0266	0266	0266	0000	%1067	n21	\$
008688	-00012	000000	0750	0750	0750	0250	0250	0250	0000	%0987	l07	\$	008996	000016	000011	0800	0800	0800	0199	0199	0199	0000	%1068	n22	\$
009470	000004	000011	0875	0875	0875	0125	0125	0125	0000	%0988	l08	\$	009308	000011	000022	0866	0866	0866	0133	0133	0133	0000	%1069	n23	\$
009729	-00002	000004	1000	1000	1000	0000	0000	0000	0000	%0989	l09	\$	009662	000002	-000006	0933	0933	0933	0066	0066	0066	0000	%1070	n24	\$
001365	-00006	000027	0000	0000	0000	1000	1000	1000	0000	%0990	m01	\$	009716	000000	-000003	1000	1000	1000	0000	0000	0000	0000	%1071	n25	\$
002553	-00021	-00042	0125	0125	0125	0875	0875	0875	0000	%0991	m02	\$	001615	000000	-000008	0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$
005788	-00008	-00050	0250	0250	0250	0750	0750	0750	0000	%0992	m03	\$	009706	000000	000000	1000	1000	1000	0000	0000	0000	0000	%1073	k27	\$
005744	-00009	-00077	0375	0375	0375	0625	0625	0625	0000	%0993	m04	\$	004729	006434	004027	1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
006924	-00003	-00068	0500	0500	0500	0500	0500	0500	0000	%0994	m05	\$	005325	-04092	-04090	0000	1000	1000	1000	0000	0000	0000	%1075	l27	\$
007897	-00005	-00025	0625	0625	0625	0375	0375	0375	0000	%0995	m06	\$	009199	-00729	008473	1000	1000	0000	0000	0000	1000	0000	%1076	m26	\$
008703	000013	000003	0750	0750	0750	0250	0250	0250	0000	%0996	m07	\$	008131	002270	-04271	0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$
009468	000003	000017	0875	0875	0875	0125	0125	0125	0000	%0997	m08	\$	005664	-05916	003400	0000	1000	0000	0000	0000	1000	0000	%1078	n26	\$
009718	-00006	000022	1000	1000	1000	0000	0000	0000	0000	%0998	m09	\$	004747	007302	-00668	1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$
001324	-00011	000016	0100	0000	0000	1000	1000	1000	0000	%0999	n01	\$													
002579	-00021	-00042	0125	0125	0125	0875	0875	0875	0000	%1000	n02	\$	%004729	006434	004027	##1000	0000	0000	0000	1000	1000	0000	%1074	l26	\$
004468	-00014	-00078	0250	0250	0250	0750	0750	0750	0000	%1001	n03	\$	%009199	-00729	008473	##1000	1000	0000	0000	0000	1000	0000	%1076	m26	\$
005737	-00007	-00062	0375	0375	0375	0625	0625	0625	0000	%1002	n04	\$	%005664	-05916	003400	##0000	1000	0000	0000	0000	1000	0000	%1078	n26	\$
006906	-00002	-00071	0500	0500	0500	0500	0500	0500	0000	%1003	n05	\$	%005325	-04092	-04090	##0000	1000	1000	1000	0000	0000	0000	%1075	l26	\$
007867	000011	-00030	0625	0625	0625	0375	0375	0375	0000	%1004	n06	\$	%003131	002270	-04271	##0000	0000	1000	1000	1000	0000	0000	%1077	m27	\$
008692	000015	000005	0750	0750	0750	0250	0250	0250	0000	%1005	n07	\$	%004747	007302	-00668	##1000	0000	1000	0000	1000	0000	0000	%1079	n27	\$
009473	000003	000020	0875	0875	0875	0125	0125	0125	0000	%1006	n08	\$	%001615	000000	000000	##0000	0000	0000	1000	1000	1000	0000	%1072	k26	\$
009721	000001	-00003	1000	1000	1000	0000	0000	0000	0000	%1007	n09	\$	%009706	000000	000000	##1000	1000	1000	0000	0000	0000	0000	%1073	k26	\$
001908	000005	-00001	0000	0000	0000	1000	1000	1000	0000	%1008	k10	\$													
002121	000002	-00021	0066	0066	0066	0933	0933	0933	0000	%1009	k11	\$	%001529	-00010	000021	##0000	0000	0000	1000	1000	1000	0000	%0972	k26	\$
003057	-00019	-00098	0133	0133	0133	0866	0866	0866	0000	%1010	k12	\$	%009727	-00004	000005	##1000	1000	1000	0000	0000	0000	0000	%0998	l26	\$
004075	-00015	-00119	0200	0200	0200	0800	0800	0800	0000	%1011	k13	\$													
004799	-00009	-00095	0266	0266	0266	0733	0733	0733	0000	%1012	k14	\$	%001500	-00007	000023	##0000	0000	0000	1000	1000	1000	0000	%0981	l26	\$
005538	-00008	-00104	0333	0333	0333	0666	0666	0666	0000	%1013	k15	\$	%009729	-00002	000004	##1000	1000	1000	0000	0000	0000	0000	%0989	l26	\$
006236	-00002	-00091	0400	0400	0400	0600	0600	0600	0000	%1014	k16	\$													
006854	-00004	-00080	0466	0466	0466	0533	0533	0533	0000	%1015	k17	\$	%001365	-00006	000027	##0000	0000	0000	1000	1000	1000	0000	%0990	m26	\$
007298	-00003	-00056	0533	0533	0533	0466	0466	0466	0000	%1016	k18	\$	%009718	-00006	000022	##1000	1000	1000	0000	0000	0000	0000	%0998	l26	\$
007900	000001	-00028	0600	0600	0600	0399	0399	0399	0000	%1017	k19	\$													
008209	000009	000006	0666	0666	0666	0333	0333	0333	0000	%1018	k20	\$	%001324	-00011	000016	##0000	0000	0000	1000	1000	1000	0000	%0999	n26	\$
008631	000016	000003	0733	0733	0733	0266	0266	0266	0000	%1019	k21	\$	%009721	000001	-00003	##1000	1000	1000	0000	0000	0000	0000	%1007	n26	\$
009032	000013	000010	0800	0800	0800	0800	0199	0199	0199	%1020	k22	\$													
009329	000010	000006	0866	0866	0866	0133	0133	0133	0000	%1021	k23	\$													
009678	000000	-00007	0933	0933	0933	0066	0066	0066	0000	%1022	k24	\$													
009701	000000	-00005	1000	1000	1000	0000	0000	0000	0000	%1023	k25	\$													
001869	000006	000007	0000	0000	0000	1000	1000	1000	0000	%1024	l10	\$													
002056	000004	-00007	0066	0066	0066	0933	0933	0933	0000	%1025	l11	\$													
003015	-00017	-00087	0133	0133	0133	0866	0866	0866	0000	%1026	l12	\$													
004071	-00016	-001																							