

% LE190-7R, Test chart with 1080 standard colours; digital equidistant 9 step hue and achromatic scales;; luminance factor measured: Y_m and normalized: $Y_n = Y_w = 89$; for standard sRGB display, Page 1/14; display type: sRGB_IEC_61966_2_1 % LE19_sRGB display 0%_Fadin

















% LE190-7R, Test chart with 1080 standard colours; digital equidistant 9 step hue and achromatic scales;; luminance factor measured: Y_m and normalized: $Y_n = Y_w = 89$; for standard sRGB display, Page 2/14; display type: sRGB_IEC_61966_2_1 % LE19_sRGB display 0%_Fadin

000	255	223	%3	0 0079 #	031	255	223	%3	0 0160 #	063	255	223	%3	0 0241 #	095	255	223	%3	0 0322 #	127	255	223	%3	0 0403 #	159	255	223	%3	0 0484 #	191	255	223	%3	0 0565 #
000	255	255	%3	0 0080 #	031	255	255	%3	0 0161 #	063	255	255	%3	0 0242 #	095	255	255	%3	0 0323 #	127	255	255	%3	0 0404 #	159	255	255	%3	0 0485 #	191	255	255	%3	0 0566 #

% LE190-7R, Test chart with 1080 standard colours; digital equidistant 9 step hue and achromatic scales;; luminance factor measured: Y_m and normalized: $Y_n = Y_w = 89$; for standard sRGB display, Page 4/14; display type: sRGB_IEC_61966_2_1 % LE19_sRGB display 0%_Fadin

% LE190-7R, Test chart with 1080 standard colours; digital equidistant 9 step hue and achromatic scales;; luminance factor measured: Y_m and normalized: $Y_n = Y_w = 89$; for standard sRGB display, Page 5/14; display type: sRGB_IEC_61966_2_1 % LE19_sRGB display 0%_Fadin

% LE19 -7R, Test chart with 1080 standard colours; digital equidistant 9 step hue and achromatic scales;; luminance factor measured: Ym and normalized: Yn = Yw = 89; for standard sRGB display, Page 6/14; display type: sRGB IEC 61966 2_1 % LE19_sRGB display 0% Fadin



0000	0999	1000	%3 1 0080 #	0125	0999	1000	%3 0161 #	0250	0999	1000	%3 01242 #	0375	0999	1000	%3 1 0323 #	0500	0999	1000	%3 1 0404 #	0625	0999	1000	%3 1 0485 #	0750	0999	1000	%3 1 0566 #
------	------	------	-------------	------	------	------	-----------	------	------	------	------------	------	------	------	-------------	------	------	------	-------------	------	------	------	-------------	------	------	------	-------------

0003	1000	0875	%3	1 0646 #	1000	0999	0875	%3	1 0727 #	0125	0000	0000	%3	1 0808 #	0125	0124	0000	0000	%3	1 0889 #	0000	0125	0000	0000	%3	1 0970 #	0734	0734	0734	%3	1 1051 #
0875	0999	1000	%3	1 0647 #	1000	1000	1000	%3	1 0728 #	0000	0000	0000	%3	1 0809 #	0000	0000	0000	0000	%3	1 0890 #	0000	0000	0000	0000	%3	1 0971 #	0830	0830	0830	%3	1 1052 #

000	154	254	255	%3	1 0080 #	031	254	255	%3	0161 #	063	254	255	%3	01242 #	095	254	255	%3	1 0323 #	127	254	255	%3	1 0404 #	159	254	255	%3	1 0485 #	191	254	255	%3	1 0566 #
-----	-----	-----	-----	----	----------	-----	-----	-----	----	--------	-----	-----	-----	----	---------	-----	-----	-----	----	----------	-----	-----	-----	----	----------	-----	-----	-----	----	----------	-----	-----	-----	----	----------

%100[L*,a*,b*] Fadit										i s no.																																
										%	i	s	no.																													
000000	000000	000000	%	1	0000	000631	000961	000806	%	1	0081	001262	001923	001613	%	1	0162	001893	002885	002420	%	1	0243	002524	003846	003227	%	1	0324	003155	004808	004034	%	1	0405	003786	005770	004841	%	1	0486	#
000380	000950	-01294	%	1	0001	000716	001179	-00729	%	1	0082	001299	002028	000146	%	1	0163	001922	002974	000917	%	1	0244	002550	003937	001701	%	1	0325	003179	004474	002480	%	1	0406	003809	005854	003285	%	1	0487	#
000740	002852	-03884	%	1	0002	001066	001524	-00354	%	1	0083	001372	002358	-00252	%	1	0164	002198	003587	-00002	%	1	0245	002691	004093	-01164	%	1	0326	003221	005087	002064	%	1	0407	003845	005949	001835	%	1	0488	#
001040	003823	-05884	%	1	0003	001254	003046	-02324	%	1	0084	001672	003034	-02652	%	1	0165	002148	003538	-02190	%	1	0246	002691	004093	-01164	%	1	0327	003288	005189	-00240	%	1	0408	003809	005949	001835	%	1	0489	#
001519	003803	-05178	%	1	0004	001908	003982	-04520	%	1	0085	002273	004230	-03908	%	1	0166	002599	004486	-03362	%	1	0247	002864	004718	-02920	%	1	0328	003393	005347	-01843	%	1	0409	003879	006285	-00985	%	1	0490	#
001899	004754	-06473	%	1	0005	002289	004629	-05814	%	1	0086	002665	005154	-05180	%	1	0167	003012	005418	-04599	%	1	0248	003321	005673	-04084	%	1	0329	003581	005897	-03650	%	1	0410	004104	006623	-02550	%	1	0491	#
002279	005704	-07768	%	1	0006	002672	005869	-07104	%	1	0087	003048	006092	-06470	%	1	0168	003409	006346	-05863	%	1	0249	003744	006609	-05304	%	1	0330	004041	007895	-04809	%	1	0411	004297	007077	-04381	%	1	0492	#
002659	006655	-09063	%	1	0007	003054	006814	-08395	%	1	0088	003433	007026	-07754	%	1	0169	003681	007271	-07135	%	1	0250	004152	007528	-06546	%	1	0331	004472	007993	-06013	%	1	0412	004760	008043	-05536	%	1	0493	#
003039	007606	-10398	%	1	0008	003433	007763	-09690	%	1	0089	003817	007964	-09042	%	1	0170	004188	008201	-08416	%	1	0251	004546	008461	-07817	%	1	0332	004885	008723	-07251	%	1	0413	005199	008973	-06724	%	1	0494	#
001045	-01034	000998	%	1	0009	001157	-00257	0001134	%	1	0090	001758	006632	001881	%	1	0171	002392	005140	002668	%	1	0252	003024	002477	003479	%	1	0333	003661	003406	004267	%	1	0414	004293	004354	005075	%	1	0495	#
001085	-00577	-00170	%	1	0010	001192	000000	000000	%	1	0091	001823	000961	000806	%	1	0172	002454	001923	001613	%	1	0253	003086	002885	002420	%	1	0334	003717	003846	003227	%	1	0415	004348	004808	004034	%	1	0496	#
001687	-00367	-01091	%	1	0011	001572	000950	-01294	%	1	0092	001908	001179	-00729	%	1	0173	002492	002028	000146	%	1	0254	003115	002974	000917	%	1	0335	003743	003937	001701	%	1	0416	004371	004874	002480	%	1	0497	#
002230	000048	-02106	%	1	0012	001952	001901	-02589	%	1	0093	002329	002115	-01954	%	1	0174	002624	002358	-01459	%	1	0255	003182	003142	-00492	%	1	0336	003792	004003	000292	%	1	0417	004414	005009	001064	%	1	0498	#
002706	006624	-03256	%	1	0013	002332	002852	-03884	%	1	0094	002716	003046	-02324	%	1	0175	003064	003634	002652	%	1	0256	003341	003538	-02190	%	1	0337	003883	004305	-001294	%	1	0418	004481	005189	-00340	%	1	0499	#
003170	001289	-04393	%	1	0014	002712	003803	-05178	%	1	0095	003101	003982	-04520	%	1	0176	003465	004230	-03908	%	1	0257	003792	004486	-03362	%	1	0338	004057	004718	-02920	%	1	0419	004585	005437	-01843	%	1	0500	#
003589	002044	-05645	%	1	0015	003092	004754	-06473	%	1	0096	003482	004926	-05814	%	1	0177	003858	005154	-05180	%	1	0258	004205	005418	-04599	%	1	0339	004514	005673	-04084	%	1	0420	004773	005897	-03650	%	1	0501	#
004013	002827	-06861	%	1	0016	003472	005704	-07768	%	1	0097	003864	005869	-07104	%	1	0178	004240	006092	-06470	%	1	0259	004602	006346	-05863	%	1	0340	004936	006609	-05304	%	1	0421	005234	006859	-04809	%	1	0502	#
004438	003624	-08053	%	1	0017	003852	006055	-09063	%	1	0098	004246	006814	-08395	%	1	0179	004626	007026	-07754	%	1	0260	004994	007271	-07135	%	1	0341	005345	007528	-06546	%	1	0422	005665	007793	-06013	%	1	0503	#
002090	-02069	001997	%	1	0018	002201	-01204	0021235	%	1	0099	002315	-00516	0022668	%	1	0180	002893	000376	002991	%	1	0261	003517	001265	003762	%	1	0342	004148	002178	004570	%	1	0423	004784	003079	005336	%	1	0504	#
002134	-01545	000379	%	1	0019	002238	-01034	000998	%	1	0100	002350	-00257	001134	%	1	0181	002951	000632	001881	%	1	0262	003584	001540	002668	%	1	0343	004217	002477	003479	%	1	0424	004854	003406	004267	%	1	0505	#
002171	-01154	-00339	%	1	0020	002278	-00577	-00170	%	1	0101	002385	000000	000000	%	1	0182	003016	000991	000806	%	1	0263	003647	001923	001613	%	1	0344	004278	002885	002420	%	1	0425	004909	003846	003227	%	1	0506	#
002784	-01006	-01260	%	1	0021	002880	-03667	-01091	%	1	0102	002765	000950	-01294	%	1	0183	003101	001179	-00729	%	1	0264	003685	002028	000146	%	1	0345	004308	002974	000917	%	1	0426	004935	003937	001701	%	1	0507	#
003376	-00736	-02182	%	1	0022	003423	000048	-02106	%	1	0103	003145	001901	-02589	%	1	0184	003521	002115	-01954	%	1	0265	003817	002358	-01459	%	1	0346	004374	003142	-00492	%	1	0427	004985	004057	002092	%	1	0508	#
003926	-00370	-03207	%	1	0023	003899	000624	-03256	%	1	0104	003525	002852	-03884	%	1	0185	003909	003046	-03234	%	1	0266	004257	003304	-02652	%	1	0347	004533	003538	-02190	%	1	0428	005076	004303	-01164	%	1	0509	#
004462	000095	-04211	%	1	0024	004363	001289	-04393	%	1	0105	003905	003803	-05178	%	1	0186	004294	003982	-04520	%	1	0267	004658	004230	-03908	%	1	0348	004985	004486	-03362	%	1	0429	005250	004718	-02920	%	1	0510	#
004935	006642	-05387	%	1	0025	004782	002044	-05645	%	1	0106	004285	004754	-06473	%	1	0187	004674	002926	-05814	%	1	0268	005050	005154	-05180	%	1	0349	005398	005418	-04599	%	1	0430	005707	006623	-04084	%	1	0511	#
005414	001246	-06511	%	1	0026	005205	002827	-06861	%	1	0107	004664	005704	-07768	%	1	0188	005057	005869	-07104	%	1	0269	005433	006092	-06470	%	1	0350	005794	006346	-05863	%	1	0431	006129	006609	-05304	%	1		

009434	-00577	-00170	%3	1	0647	#	009540	000000	000000	%3	0728	#	000000	000000	000000	%3	1	0809	#	000000	000000	000000	%3	1	0971	#	007632	000000	000000	%3	1	1052	#	% LE19	sRGB display	0%	Fadit
--------	--------	--------	----	---	------	---	--------	--------	--------	----	------	---	--------	--------	--------	----	---	------	---	--------	--------	--------	----	---	------	---	--------	--------	--------	----	---	------	---	--------	--------------	----	-------

