See original or copy: http://web.me.com/klaus.richter/HE73/HE73L0N1.TXT/.PS
Technical information: http://www.ps.bam.de V 2.1, io=1,1, Cx=0; cf1=0.90; nt=0.18; nx=1.0

TUB registration: 20091101-HE73/HE73L0N1.TXT/.PS
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4ta

http://130.149.60.45/~farbmetrik/HE73/HE73L0N1.TXT /.PS, Page 1/24; FRS09_92, L*=09_92
N: No Output Linerization (OL) Same File (F) Startup (S) or Device (D)

```
%BEG HE73.ps, Separation cmyn4*, cf1=0.90, D65, not adapted $
%100 x LAB*          1000 x (r g b c m y 0)          nr*      pos $
001313 000032 000119 0000 0000 0000 1000 1000 1000 0000 A01 $
002245 000142 000337 0125 0000 0000 0875 1000 1000 0000 %0081 J01 $
002819 000293 000480 0250 0000 0000 0750 1000 1000 0000 %0162 S01 $
002966 000513 -00062 0250 0000 0125 0750 1000 0875 0000 %0163 S02 $
003467 000244 000431 0250 0000 0250 0750 1000 0750 0000 %0164 S03 $
003206 000289 -01258 0250 0000 0375 0750 1000 0625 0000 %0165 S04 $
003386 000269 -01239 0250 0000 0500 0750 1000 0500 0000 %0166 S05 $
003702 000385 -01019 0250 0000 0625 0750 1000 0375 0000 %0167 S06 $
004026 001214 -02873 0250 0000 0750 0750 1000 0250 0000 %0168 S07 $
004449 001224 -02850 0250 0000 0875 0750 1000 0125 0000 %0169 S08 $
003679 001426 -04405 0250 0000 1000 0750 1000 0000 0000 %0170 S09 $
003950 000987 -03349 0250 0000 1000 0875 1000 0000 0000 %0171 S10 $
003006 000406 000393 0250 0125 0125 0750 0875 0875 0000 %0172 T02 $
002828 000000 000480 0250 0125 0250 0750 0750 0750 0000 %0173 T03 $
003286 000419 -00976 0250 0125 0375 0750 0875 0625 0000 %0174 T04 $
003443 000384 -01402 0250 0125 0500 0750 0875 0500 0000 %0175 T05 $
003786 000374 -01754 0250 0125 0625 0750 0875 0375 0000 %0176 T06 $
004018 000652 -02285 0250 0125 0750 0750 0875 0250 0000 %0177 T07 $
004283 000978 -02816 0250 0125 0875 0750 0875 0125 0000 %0178 T08 $
004547 000473 -03302 0250 0125 1000 0750 0875 0000 0000 %0179 T09 $
003617 -00127 000919 0250 0250 0250 0750 0750 0750 0000 %0180 U03 $
003429 000072 000779 0250 0250 0375 0750 0750 0625 0000 %0181 U02 $
003477 000000 000779 0250 0250 0500 0750 0750 0500 0000 %0182 U01 $
004052 000023 -00368 0250 0250 0375 0750 0750 0625 0000 %0183 U04 $
004397 -00001 -00898 0250 0250 0500 0750 0750 0500 0000 %0184 U05 $
004507 -00037 -01415 0250 0250 0625 0750 0750 0375 0000 %0185 U06 $
004758 000055 -01881 0250 0250 0750 0750 0750 0250 0000 %0186 U07 $
005000 000080 -02348 0250 0250 0875 0750 0750 0125 0000 %0187 U08 $
005429 -00007 -02551 0250 0250 1000 0750 0750 0000 0000 %0188 U09 $
004517 -00058 000750 0250 0375 0250 0750 0625 0750 0000 %0189 V01 $
003948 -00771 000833 0250 0375 0125 0750 0625 0875 0000 %0190 V02 $
004104 -00771 000919 0250 0375 0000 0750 0625 1000 0000 %0191 V03 $
004073 -00375 -00298 0250 0375 0375 0750 0625 0625 0000 %0192 V04 $
004389 -00375 -00298 0250 0375 0500 0750 0625 0500 0000 %0193 V05 $
004694 -00445 -01390 0250 0375 0625 0750 0625 0375 0000 %0194 V06 $
004912 -00445 -01839 0250 0375 0750 0750 0625 0250 0000 %0195 V07 $
005242 -00425 -02229 0250 0375 0875 0750 0625 0125 0000 %0196 V08 $
005569 -00428 -02533 0250 0375 1000 0750 0625 0000 0000 %0197 V09 $
005641 -00000 -02732 0250 0500 0000 0750 0500 1000 0000 %0198 W01 $
004521 -01274 001243 0250 0500 0125 0750 0500 0875 0000 %0199 W02 $
004548 -00950 000943 0250 0500 0250 0750 0500 0750 0000 %0200 W03 $
004533 -01066 -00162 0250 0500 0375 0750 0500 0625 0000 %0201 W04 $
004541 -00950 -00610 0250 0500 0500 0750 0500 0500 0000 %0202 W05 $
004874 -00919 -01415 0250 0500 0625 0750 0500 0375 0000 %0203 W06 $
005365 -00849 -02229 0250 0500 0750 0750 0500 0250 0000 %0204 W07 $
005365 -00849 -02229 0250 0500 0875 0750 0500 0125 0000 %0205 W08 $
005689 -00811 -02666 0250 0500 1000 0750 0500 0000 0000 %0206 W09 $
004905 -00000 -00000 0250 0625 0000 0750 0375 1000 0000 %0207 X01 $
004905 -02473 001267 0250 0625 0125 0750 0375 0875 0000 %0208 X02 $
004976 -02473 001267 0250 0625 0250 0750 0375 0750 0000 %0209 X03 $
004991 -01703 000828 0250 0625 0375 0750 0375 0625 0000 %0210 X04 $
004974 -01703 000828 0250 0625 0500 0750 0375 0500 0000 %0211 X05 $
005038 -01357 -00960 0250 0625 0625 0750 0375 0375 0000 %0212 X06 $
005281 -01357 -01704 0250 0625 0750 0750 0375 0250 0000 %0213 X07 $
005581 -01390 -02083 0250 0625 0875 0750 0375 0125 0000 %0214 X08 $
005881 -01390 -02083 0250 0625 1000 0750 0375 0000 0000 %0215 X09 $
005818 -03794 002794 0250 0750 0000 0750 0250 1000 0000 %0216 Y01 $
005213 -03324 001693 0250 0750 0125 0750 0250 0875 0000 %0217 Y02 $
005446 -02299 000140 0250 0750 0250 0750 0250 0750 0000 %0218 Y03 $
005446 -02299 000140 0250 0750 0375 0750 0250 0625 0000 %0219 Y04 $
005446 -02299 000140 0250 0750 0500 0750 0250 0500 0000 %0220 Y05 $
005444 -01827 -00873 0250 0750 0625 0750 0250 0375 0000 %0221 Y06 $
005459 -01827 -00873 0250 0750 0750 0750 0250 0250 0000 %0222 Y07 $
005779 -01890 -01238 0250 0750 0875 0750 0250 0125 0000 %0223 Y08 $
006065 -01838 -01238 0250 0750 1000 0750 0250 0000 0000 %0224 Y09 $
005816 -03981 002892 0250 0875 0000 0750 0125 1000 0000 %0225 Z01 $
005816 -03981 002892 0250 0875 0125 0750 0125 0875 0000 %0226 Z02 $
005876 -03452 001107 0250 0875 0250 0750 0125 0750 0000 %0227 Z03 $
005865 -03059 000101 0250 0875 0375 0750 0125 0625 0000 %0228 Z04 $
005935 -02745 -00000 0250 0875 0500 0750 0125 0500 0000 %0229 Z05 $
005865 -02528 -00728 0250 0875 0625 0750 0125 0375 0000 %0230 Z06 $
006077 -02312 -01456 0250 0875 0750 0750 0125 0250 0000 %0231 Z07 $
005823 -02116 -01663 0250 0875 0875 0750 0125 0125 0000 %0232 Z08 $
005823 -02116 -01663 0250 0875 1000 0750 0125 0000 0000 %0233 Z09 $
005269 -05566 004097 0250 1000 0000 0750 0000 1000 0000 %0234 a01 $
005942 -05269 003496 0250 1000 0125 0750 0000 0875 0000 %0235 a02 $
006382 -04035 001348 0250 1000 0250 0750 0000 0750 0000 %0236 a03 $
006315 -03692 000624 0250 1000 0375 0750 0000 0625 0000 %0237 a04 $
006267 -03257 -00072 0250 1000 0500 0750 0000 0500 0000 %0238 a05 $
006289 -03134 -00486 0250 1000 0625 0750 0000 0375 0000 %0239 a06 $
006210 -03023 -00900 0250 1000 0750 0750 0000 0250 0000 %0240 a07 $
006184 -02872 -01301 0250 1000 0875 0750 0000 0125 0000 %0241 a08 $
006243 02640 -01915 0250 1000 1000 0750 0000 0000 0000 %0242 a09 $
```

TUB-test chart HE73; Relative Elementary Colour System G
1080 spectral reflexions R -> LAB* for D65 and D50

input: *w setgray*
output: no change compared to input