See original or copy: http://web.me.com/klaus.richter/JE81/JE81L0N1.TXT /.PS
Technical information: http://www.ps-bam.de or http://130.149.60.45/~farbmetrik

TUB registration: 20100301-JE81/JE81L0N1.TXT /.PS
application for evaluation and measurement of printer or monitor systems

TUB material: code=rha4a

http://130.149.60.45/~farbmetrik/JE81/JE81L0N1.TXT /.PS; ORS18_95, L*=18_95
N: No Output Linerization (OL) Data in File (F), Startup (S) or Device (D), Page 1/24

```
%REM_OFF504_080929_3_TXT, 1080 colours, 20080929, Separation cmyn*, D65, not adapted S
%100 x LAB*          1000 x (r g b c m y 0)          nr     pos S
002201 000028 000065 0000 0000 0000 1000 1000 1000 0000 A01 s
002258 000038 000040 0000 0000 0125 1000 1000 0875 0000 A02 s
002273 000051 000054 0000 0000 0250 1000 1000 0750 0000 A03 s
002451 001086 -02254 0000 0000 0375 1000 1000 0625 0000 A003 A04 s
002485 001466 -02908 0000 0000 0500 1000 1000 0500 0000 A005 A05 s
002490 001789 -03408 0000 0000 0625 1000 1000 0375 0000 A006 A06 s
002611 001963 -03855 0000 0000 0750 1000 1000 0250 0000 A007 A07 s
002601 002150 -04250 0000 0000 0875 1000 1000 0125 0000 A008 A08 s
002753 002615 -04661 0000 0000 1000 1000 1000 0000 0000 A008 A09 S
002624 -00443 00403 0125 0125 0000 0875 0875 1000 0000 A009 B01 s
002733 -00546 -00658 0000 0125 0125 1000 0875 0875 0000 A010 B02 s
002843 -00650 -01553 0000 0125 0250 1000 0875 0750 0000 A011 B03 s
003063 000000 -02153 0000 0125 0375 1000 0875 0625 0000 A012 B04 s
003064 000414 -02820 0000 0125 0500 1000 0875 0500 0000 A013 B05 s
003033 000778 -03124 0000 0125 0625 1000 0875 0375 0000 A014 B06 s
003092 001050 -03765 0000 0125 0750 1000 0875 0250 0000 A015 B07 s
003128 001420 -04249 0000 0125 0875 1000 0875 0125 0000 A016 B08 s
003244 001690 -04580 0000 0125 1000 1000 0875 0000 0000 A017 B09 S
003231 -00234 00404 0000 0250 0125 1000 0750 0875 0000 B001 C01 s
003375 -01589 -00324 0000 0250 0125 1000 0750 0875 0000 C02 S
003485 -01688 -00426 0000 0250 0250 1000 0750 0750 0000 C03 s
003632 -00888 -02079 0000 0250 0375 1000 0750 0625 0000 A021 C04 s
003661 -00947 -02706 0000 0250 0500 1000 0750 0500 0000 A022 C05 s
003619 -00194 -03236 0000 0250 0625 1000 0750 0375 0000 A023 C06 s
003560 00230 -03708 0000 0250 0750 1000 0750 0250 0000 A024 C07 s
003586 000740 -04160 0000 0250 0875 1000 0750 0125 0000 A025 C08 s
003662 000923 -04506 0000 0250 1000 1000 0750 0000 0000 A026 C09 S
003634 -02908 00161 0000 0375 0125 1000 0625 0875 0000 A027 D01 s
003791 -02558 00171 0000 0375 0125 1000 0625 0875 0000 A028 D02 s
003891 -02075 01048 0000 0375 0250 1000 0625 0750 0000 A029 D03 s
003949 -01581 -01995 0000 0375 0375 1000 0625 0625 0000 A030 D04 s
004131 -01332 -02597 0000 0375 0500 1000 0625 0500 0000 A031 D05 s
004113 -01027 -03145 0000 0375 0625 1000 0625 0375 0000 A032 D06 s
004101 -00621 -03652 0000 0375 0750 1000 0625 0250 0000 A033 D07 s
003990 -00196 -04093 0000 0375 0875 1000 0625 0125 0000 A034 D08 s
004073 000222 -04407 0000 0375 1000 1000 0625 0000 0000 A035 D09 S
004054 -01853 00403 0000 0500 0125 1000 0500 0875 0000 A036 E01 s
004170 -03465 000700 0000 0500 0125 1000 0500 0875 0000 A037 E02 s
004310 -03465 -00547 0000 0500 0250 1000 0500 0750 0000 A038 E03 s
004439 -02494 -01572 0000 0500 0375 1000 0500 0625 0000 A039 E04 s
004541 -01572 -02494 0000 0500 0500 1000 0500 0500 0000 A040 E05 s
004541 -01672 -03032 0000 0500 0625 1000 0500 0375 0000 A041 E06 s
004570 -01672 -03528 0000 0500 0750 1000 0500 0250 0000 A042 E07 s
004524 -01039 -04014 0000 0500 0875 1000 0500 0125 0000 A043 E08 s
004572 -00583 -04354 0000 0500 1000 1000 0500 0000 0000 A044 E09 S
004518 -03465 -01047 0000 0625 0125 1000 0375 0875 0000 A045 F01 s
004518 -04295 -01241 0000 0625 0125 1000 0375 0875 0000 A046 F02 s
004628 -03894 -01944 0000 0625 0250 1000 0375 0750 0000 A047 F03 s
004757 -03398 -01128 0000 0625 0375 1000 0375 0625 0000 A048 F04 s
004834 -03398 -00194 0000 0625 0500 1000 0375 0500 0000 A049 F05 s
004926 -02318 -02950 0000 0625 0625 1000 0375 0375 0000 A050 F06 s
004961 -01895 -03465 0000 0625 0750 1000 0375 0250 0000 A051 F07 s
004981 -01761 -03940 0000 0625 0875 1000 0375 0125 0000 A052 F08 s
005040 -01761 -04274 0000 0625 1000 1000 0375 0000 0000 A053 F09 S
004810 -05302 002925 0000 0750 0000 1000 0250 1000 0000 A054 G01 s
004914 -04965 001658 0000 0750 0125 1000 0250 0875 0000 A055 G02 s
005204 -04965 -00414 0000 0750 0250 1000 0250 0750 0000 A056 G03 s
005124 -04064 -00685 0000 0750 0375 1000 0250 0625 0000 A057 G04 s
005204 -03596 -01157 0000 0750 0500 1000 0250 0500 0000 A058 G05 s
005277 -03146 -02463 0000 0750 0625 1000 0250 0375 0000 A059 G06 s
005294 -02463 -03146 0000 0750 0750 1000 0250 0250 0000 A060 G07 s
005367 -02316 -03854 0000 0750 0875 1000 0250 0125 0000 A061 G08 s
005346 -01895 -04274 0000 0750 1000 1000 0250 0000 0000 A062 G09 S
005134 -06006 003020 0000 0875 0000 1000 0125 1000 0000 A063 H01 s
005204 -05748 002442 0000 0875 0125 1000 0125 0875 0000 A064 H02 s
005292 -05323 000840 0000 0875 0250 1000 0125 0750 0000 A065 H03 s
005408 -04871 -00243 0000 0875 0375 1000 0125 0625 0000 A066 H04 s
005495 -04871 -01277 0000 0875 0500 1000 0125 0500 0000 A067 H05 s
005585 -03907 -02186 0000 0875 0625 1000 0125 0375 0000 A068 H06 s
005568 -03434 -02974 0000 0875 0750 1000 0125 0250 0000 A069 H07 s
005766 -02901 -03735 0000 0875 0875 1000 0125 0125 0000 A070 H08 s
005582 -02318 -04131 0000 0875 1000 1000 0125 0000 0000 A071 H09 S
005582 -06551 003522 0000 1000 0000 1000 0000 1000 0000 A072 I01 s
005670 -06551 002442 0000 1000 0125 1000 0000 0875 0000 A073 I02 s
005751 -05946 001401 0000 1000 0250 1000 0000 0750 0000 A074 I03 s
005856 -05485 000219 0000 1000 0375 1000 0000 0625 0000 A075 I04 s
005935 -05485 -00705 0000 1000 0500 1000 0000 0500 0000 A076 I05 s
006011 -04619 -01668 0000 1000 0625 1000 0000 0375 0000 A077 I06 s
006105 -04114 -02541 0000 1000 0750 1000 0000 0250 0000 A078 I07 s
006199 -03649 -03268 0000 1000 0875 1000 0000 0125 0000 A079 I08 s
006303 -03085 -04054 0000 1000 1000 1000 0000 0000 0000 A080 I09 S
002482 000693 000674 0125 0000 0000 0875 1000 1000 0000 B081 J01 S
002593 000966 -00215 0125 0000 0125 0875 1000 0875 0000 B082 J02 s
002800 001259 -01000 0125 0000 0250 0875 1000 0750 0000 B083 J03 s
002864 001925 -01631 0125 0000 0375 0875 1000 0625 0000 B084 J04 s
002864 002281 -02272 0125 0000 0500 0875 1000 0500 0000 B085 J05 s
002850 002934 -02832 0125 0000 0625 0875 1000 0375 0000 B086 J06 s
002871 002828 -03342 0125 0000 0750 0875 1000 0250 0000 B087 J07 s
002857 002828 -03851 0125 0000 0875 0875 1000 0125 0000 B088 J08 s
002969 003412 -04200 0125 0000 1000 0875 1000 0000 0000 B089 J09 S
003130 -00453 00403 0250 0125 0000 0750 0875 1000 0000 B090 K01 s
003264 -00016 -00011 0125 0125 0125 0875 0875 0875 0000 B091 K02 s
003307 000000 -00511 0125 0125 0250 0875 0875 0750 0000 B092 K03 s
003405 000771 -01607 0125 0125 0375 0875 0875 0625 0000 B093 K04 s
003449 001156 -02237 0125 0125 0500 0875 0875 0500 0000 B094 K05 s
003449 001278 -02749 0125 0125 0625 0875 0875 0375 0000 B095 K06 s
003405 001736 -03238 0125 0125 0750 0875 0875 0250 0000 B096 K07 s
003460 002213 -03576 0125 0125 0875 0875 0875 0125 0000 B097 K08 s
003487 002396 -04100 0125 0125 1000 0875 0875 0000 0000 B098 K09 S
003389 000551 -00556 0125 0250 0125 0750 0875 0875 0000 B099 L01 s
003389 -01051 000556 0125 0250 0250 0750 0875 0750 0000 B100 L02 s
003411 -01156 -00749 0125 0250 0375 0750 0875 0625 0000 B101 L03 s
004116 -00288 -01454 0125 0250 0500 0750 0875 0500 0000 B102 L04 s
004096 000672 -02110 0125 0250 0625 0750 0875 0375 0000 B103 L05 s
004017 000442 -02616 0125 0250 0750 0750 0875 0250 0000 B104 L06 s
003951 000798 -03154 0125 0250 0875 0750 0875 0125 0000 B105 L07 s
003951 001347 -03588 0125 0250 1000 0750 0875 0000 0000 B106 L08 s
003945 001523 -04027 0125 0250 1000 0875 0750 0000 0000 B107 L09 s
004270 -01023 000000 0125 0375 0125 0625 0875 0875 0000 B108 M01 s
004302 -01861 001002 0125 0375 0125 0875 0625 0875 0000 B109 M02 s
004431 -01452 -00316 0125 0375 0250 0875 0625 0750 0000 B110 M03 s
004661 -01858 -01339 0125 0375 0375 0875 0625 0625 0000 B111 M04 s
004653 -02268 -01851 0125 0375 0500 0875 0625 0500 0000 B112 M05 s
004593 -00494 -02508 0125 0375 0625 0875 0625 0375 0000 B113 M06 s
004593 -00994 -02994 0125 0375 0750 0875 0625 0250 0000 B114 M07 s
004479 000265 -03486 0125 0375 0875 0875 0625 0125 0000 B115 M08 s
004414 000709 -03939 0125 0375 1000 0875 0625 0000 0000 B116 M09 s
004567 -01277 -01003 0125 0500 0125 0875 0500 0875 0000 B117 N01 s
004716 -02558 001393 0125 0500 0250 0875 0500 0750 0000 B118 N02 s
004844 -02558 000000 0125 0500 0375 0875 0500 0625 0000 B119 N03 s
005008 -01875 -00927 0125 0500 0375 0875 0500 0625 0000 B120 N04 s
005030 -01353 -01853 0125 0500 0500 0875 0500 0500 0000 B121 N05 s
005030 -01153 -02432 0125 0500 0625 0875 0500 0375 0000 B122 N06 s
005000 -01153 -02928 0125 0500 0750 0875 0500 0250 0000 B123 N07 s
004992 -00543 -03417 0125 0500 0875 0875 0500 0125 0000 B124 N08 s
004937 -00177 -03873 0125 0500 1000 0875 0500 0000 0000 B125 N09 s
004800 -01277 -00556 0125 0625 0125 0875 0375 0875 0000 B126 O01 s
005049 -03389 001904 0125 0625 0125 0875 0375 0875 0000 B127 O02 s
005049 -03889 001401 0125 0625 0250 0875 0375 0750 0000 B128 O03 s
005291 -02817 -00535 0125 0625 0375 0875 0375 0625 0000 B129 O04 s
005374 -02817 -01047 0125 0625 0500 0875 0375 0500 0000 B130 O05 s
005465 -01816 -02336 0125 0625 0625 0875 0375 0375 0000 B131 O06 s
005465 -01316 -02848 0125 0625 0750 0875 0375 0250 0000 B132 O07 s
005435 -01268 -03333 0125 0625 0875 0875 0375 0125 0000 B133 O08 s
005400 -01268 -03821 0125 0625 1000 0875 0375 0000 0000 B134 O09 s
005306 -04312 003479 0125 0750 0000 0875 0250 1000 0000 B135 P01 s
005372 -04096 002220 0125 0750 0125 0875 0250 0875 0000 B136 P02 s
005456 -03596 001040 0125 0750 0250 0875 0250 0750 0000 B137 P03 s
005583 -03366 -00172 0125 0750 0375 0875 0250 0625 0000 B138 P04 s
005583 -03366 -00672 0125 0750 0500 0875 0250 0500 0000 B139 P05 s
005730 -02614 -01942 0125 0750 0625 0875 0250 0375 0000 B140 P06 s
005814 -02614 -02442 0125 0750 0750 0875 0250 0250 0000 B141 P07 s
005845 -01860 -03257 0125 0750 0875 0875 0250 0125 0000 B142 P08 s
005845 -01360 -03757 0125 0750 1000 0875 0250 0000 0000 B143 P09 s
005635 -04972 003090 0125 0875 0000 0875 0125 1000 0000 B144 Q01 s
005635 -04472 002590 0125 0875 0125 0875 0125 0875 0000 B145 Q02 s
005778 -04448 001340 0125 0875 0250 0875 0125 0750 0000 B146 Q03 s
005916 -04030 000287 0125 0875 0375 0875 0125 0625 0000 B147 Q04 s
005908 -03530 -00214 0125 0875 0500 0875 0125 0500 0000 B148 Q05 s
006085 -03247 -01654 0125 0875 0625 0875 0125 0375 0000 B149 Q06 s
006153 -03247 -02154 0125 0875 0750 0875 0125 0250 0000 B150 Q07 s
006257 -02436 -03183 0125 0875 0875 0875 0125 0125 0000 B151 Q08 s
006289 -02436 -03683 0125 0875 1000 0875 0125 0000 0000 B152 Q09 s
005933 -05687 004031 0125 1000 0000 0875 0000 1000 0000 B153 R01 s
005933 -05187 003531 0125 1000 0125 0875 0000 0875 0000 B154 R02 s
006096 -05153 001753 0125 1000 0250 0875 0000 0750 0000 B155 R03 s
006214 -04731 000517 0125 1000 0375 0875 0000 0625 0000 B156 R04 s
006293 -04374 -00417 0125 1000 0500 0875 0000 0500 0000 B157 R05 s
006371 -04007 -01292 0125 1000 0625 0875 0000 0375 0000 B158 R06 s
006461 -03598 -02141 0125 1000 0750 0875 0000 0250 0000 B159 R07 s
006544 -03290 -02854 0125 1000 0875 0875 0000 0125 0000 B160 R08 s
006655 -02715 -03603 0125 1000 1000 0875 0000 0000 0000 B161 R09 s
003047 001731 001379 0250 0000 0000 0750 1000 1000 0000 A162 S01 s
003117 001963 000328 0250 0000 0125 0750 1000 0875 0000 A163 S02 s
003177 001963 -00314 0250 0000 0250 0750 1000 0750 0000 A164 S03 s
003243 002628 -01084 0250 0000 0375 0750 1000 0625 0000 A165 S04 s
003283 003082 -01731 0250 0000 0500 0750 1000 0500 0000 A166 S05 s
003283 003454 -02432 0250 0000 0625 0750 1000 0375 0000 A167 S06 s
003110 003580 -02834 0250 0000 0750 0750 1000 0250 0000 A168 S07 s
003164 003758 -03341 0250 0000 0875 0750 1000 0125 0000 A169 S08 s
003130 004092 -03701 0250 0000 1000 0750 1000 0000 0000 A170 S09 s
003841 000000 -03701 0250 0125 0000 0625 0875 1000 0000 B171 T01 s
003730 000841 000088 0250 0125 0125 0750 0875 0875 0000 B172 T02 s
003855 000841 -00088 0250 0125 0250 0750 0875 0750 0000 B173 T03 s
003960 001503 -01028 0250 0125 0375 0750 0875 0625 0000 B174 T04 s
003824 001866 -01707 0250 0125 0500 0750 0875 0500 0000 B175 T05 s
003824 002228 -02156 0250 0125 0625 0750 0875 0375 0000 B176 T06 s
003650 002458 -02759 0250 0125 0750 0750 0875 0250 0000 B177 T07 s
003659 002458 -03259 0250 0125 0875 0750 0875 0125 0000 B178 T08 s
003660 003020 -03686 0250 0125 1000 0750 0875 0000 0000 B179 T09 s
004445 -00000 -00000 0250 0250 0125 0625 0875 0875 0000 B180 U01 s
004545 -00370 001305 0250 0250 0125 0750 0875 0750 0000 B181 U02 s
004771 -00370 000000 0250 0250 0250 0750 0875 0625 0000 B182 U03 s
004571 000372 -00897 0250 0250 0375 0750 0875 0500 0000 B183 U04 s
004459 000759 -01401 0250 0250 0500 0750 0875 0375 0000 B184 U05 s
004333 001097 -01243 0250 0250 0625 0750 0875 0250 0000 B185 U06 s
004215 001464 -02688 0250 0250 0750 0750 0875 0125 0000 B186 U07 s
004136 001751 -03150 0250 0250 0875 0750 0875 0000 0000 B187 U08 s
004136 002094 -03618 0250 0250 1000 0750 0875 0000 0000 B188 U09 s
004925 -01275 000000 0250 0375 0125 0625 0875 0875 0000 B189 V01 s
005010 -01105 001743 0250 0375 0125 0750 0625 0875 0000 B190 V02 s
005095 -00852 000488 0250 0375 0250 0750 0625 0750 0000 B191 V03 s
005259 -00547 -00677 0250 0375 0375 0750 0625 0625 0000 B192 V04 s
005159 -00547 -01177 0250 0375 0500 0750 0625 0500 0000 B193 V05 s
004988 000002 -02026 0250 0375 0625 0750 0625 0375 0000 B194 V06 s
004837 000002 -02526 0250 0375 0750 0750 0625 0250 0000 B195 V07 s
004743 000806 -03061 0250 0375 0875 0750 0625 0125 0000 B196 V08 s
004643 001238 -03518 0250 0375 1000 0750 0625 0000 0000 B197 V09 s
005336 -01856 001743 0250 0500 0125 0750 0500 0875 0000 B198 W01 s
005336 -01856 000820 0250 0500 0125 0750 0500 0875 0000 B199 W02 s
005418 -01856 000000 0250 0500 0250 0750 0500 0750 0000 B200 W03 s
005562 -01316 -00308 0250 0500 0375 0750 0500 0625 0000 B201 W04 s
005676 -00816 -00808 0250 0500 0500 0750 0500 0500 0000 B202 W05 s
005581 -00664 -01890 0250 0500 0625 0750 0500 0375 0000 B203 W06 s
005581 -00164 -02390 0250 0500 0750 0750 0500 0250 0000 B204 W07 s
005269 -00033 -02951 0250 0500 0875 0750 0500 0125 0000 B205 W08 s
005202 000386 -03449 0250 0500 1000 0750 0500 0000 0000 B206 W09 s
005493 -02581 000000 0250 0625 0125 0750 0375 0875 0000 B207 X01 s
005583 -02581 002496 0250 0625 0125 0750 0375 0875 0000 B208 X02 s
005648 -02581 001150 0250 0625 0250 0750 0375 0750 0000 B209 X03 s
005786 -02008 000108 0250 0625 0375 0750 0375 0625 0000 B210 X04 s
005880 -02008 -00392 0250 0625 0500 0750 0375 0500 0000 B211 X05 s
005997 -01334 -01736 0250 0625 0625 0750 0375 0375 0000 B212 X06 s
005839 -01334 -02367 0250 0625 0750 0750 0375 0250 0000 B213 X07 s
005795 -00806 -02869 0250 0625 0875 0750 0375 0125 0000 B214 X08 s
005711 -00806 -03369 0250 0625 1000 0750 0375 0000 0000 B215 X09 s
005734 -03476 004149 0250 0750 0000 0750 0250 1000 0000 B216 Y01 s
005803 -03290 002765 0250 0750 0125 0750 0250 0875 0000 B217 Y02 s
005803 -03290 002265 0250 0750 0250 0750 0250 0750 0000 B218 Y03 s
005999 -02724 000379 0250 0750 0375 0750 0250 0625 0000 B219 Y04 s
006149 -02724 -00121 0250 0750 0500 0750 0250 0500 0000 B220 Y05 s
006199 -02068 -01386 0250 0750 0625 0750 0250 0375 0000 B221 Y06 s
006261 -02068 -01886 0250 0750 0750 0750 0250 0250 0000 B222 Y07 s
006189 -01436 -02806 0250 0750 0875 0750 0250 0125 0000 B223 Y08 s
006171 -01436 -03306 0250 0750 1000 0750 0250 0000 0000 B224 Y09 s
005977 -04145 004211 0250 0875 0000 0750 0125 1000 0000 B225 Z01 s
006063 -04145 003711 0250 0875 0125 0750 0125 0875 0000 B226 Z02 s
006157 -03703 001822 0250 0875 0250 0750 0125 0750 0000 B227 Z03 s
006272 -03368 000770 0250 0875 0375 0750 0125 0625 0000 B228 Z04 s
006353 -03074 -00000 0250 0875 0500 0750 0125 0500 0000 B229 Z05 s
006437 -02711 -01125 0250 0875 0625 0750 0125 0375 0000 B230 Z06 s
006553 -02404 -01810 0250 0875 0750 0750 0125 0250 0000 B231 Z07 s
006589 -02028 -02499 0250 0875 0875 0750 0125 0125 0000 B232 Z08 s
006683 -01743 -03229 0250 0875 1000 0750 0125 0000 0000 B233 Z09 s
006247 -04899 004533 0250 1000 0000 0750 0000 1000 0000 B234 a01 s
006247 -04399 004033 0250 1000 0125 0750 0000 0875 0000 B235 a02 s
006435 -04418 002281 0250 1000 0250 0750 0000 0750 0000 B236 a03 s
006540 -04050 001005 0250 1000 0375 0750 0000 0625 0000 B237 a04 s
006669 -03772 -00000 0250 1000 0500 0750 0000 0500 0000 B238 a05 s
006691 -03443 -00811 0250 1000 0625 0750 0000 0375 0000 B239 a06 s
006754 -03116 -01650 0250 1000 0750 0750 0000 0250 0000 B240 a07 s
006840 -02769 -02402 0250 1000 0875 0750 0000 0125 0000 B241 a08 s
006965 -02316 -03142 0250 1000 1000 0750 0000 0000 0000 B242 a09 S
```

TUB-test chart JE81; Relative Device Colour System G
1080 spectral reflexions R -> LAB* & LAB*a; D65 & D50

input: *w setgray*
output: no change compared to input