TUB registration: 20100301-JE85/JE85L0N1.TXT / .PS
application for evaluation and measurement of printer or monitor systems
TUB material: code=rha4ta

See original or copy: http://web.me.com/klaus.richter/JE85/JE85L0N1.TXT / .PS
Technical information: http://www.ps-bam.de or http://130.149.60.45/~farbmetrik

http://130.149.60.45/~farbmetrik/JE85/JE85L0N1.TXT /.PS; ORS18_95, L*=18_95
N: No Output Linerization (OL) Same As File (F) Startup (S) or Device (D), Page 1/24

```
%REM_OFF542_081006_3.TXT, 1080 colours, Separation cmyn6*, DES, not adapted $
%100 x LAB*          1000 x (r g b c m y 0)          *r*   pos $
002171 000031 000060 0000 0000 0000 1000 1000 0000 \0000 A01 $
002210 000037 00751 0000 0000 0125 1000 1000 0875 0000\A02 $
002365 000042 00846 0000 0000 0250 1000 1000 0750 0000\A03 $
002417 001130 -02266 0000 0000 0375 1000 1000 0625 0000\A03 A04 $
002438 001523 -02908 0000 0000 0500 1000 1000 0500 0000\A04 A05 $
002445 001845 -03419 0000 0000 0625 1000 1000 0375 0000\A05 A06 $
002581 002037 -03861 0000 0000 0750 1000 1000 0250 0000\A06 A07 $
002672 002213 -04255 0000 0000 0875 1000 1000 0125 0000\A07 A08 $
002727 002347 -04599 0000 0000 1000 1000 1000 0000 0000\A08 A09 $
002618 -00460 00460 0000 0125 0125 1000 0875 0875 0000\A09 B01 $
002709 -00549 -00670 0000 0125 0125 1000 0875 0875 0000\B01 B02 $
002906 -00633 -01341 0000 0125 0125 1000 0875 0875 0000\B02 B03 $
003036 000016 -02173 0000 0125 0375 1000 0875 0625 0000\B02 B04 $
003032 000464 -02828 0000 0125 0500 1000 0875 0500 0000\B03 B05 $
003050 001029 -03332 0000 0125 0625 1000 0875 0375 0000\B04 B06 $
003044 001096 -03772 0000 0125 0750 1000 0875 0250 0000\B05 B07 $
003044 001266 -04266 0000 0125 0875 1000 0875 0125 0000\B06 B08 $
003187 001755 -04578 0000 0125 1000 1000 0875 0000 0000\B07 B09 $
003222 -00203 00182 0000 0250 0125 1000 0750 0875 0000\B09 C01 $
003371 -01601 -00319 0000 0250 0125 1000 0750 0875 0000\C01 C02 $
003450 -02427 -00847 0000 0250 0250 1000 0750 0750 0000\C02 C03 $
003618 -00874 -02098 0000 0250 0375 1000 0750 0625 0000\C02 C04 $
003627 -00409 -02713 0000 0250 0500 1000 0750 0500 0000\C03 C05 $
003579 -00155 -03238 0000 0250 0625 1000 0750 0375 0000\C03 C06 $
003543 000266 -03708 0000 0250 0750 1000 0750 0250 0000\C04 C07 $
003558 000547 -04178 0000 0250 0875 1000 0750 0125 0000\C05 C08 $
003638 000965 -04492 0000 0250 1000 1000 0750 0000 0000\C06 C09 $
003640 -03001 001638 0000 0375 0000 1000 0625 0000 0000\D01 D02 $
003779 -02570 000170 0000 0375 0125 1000 0625 0875 0000\D02 D02 $
003900 -02085 000848 0000 0375 0250 1000 0625 0750 0000\D02 D03 $
004034 -01584 -02007 0000 0375 0375 1000 0625 0625 0000\D03 D04 $
004124 -01292 -02624 0000 0375 0500 1000 0625 0500 0000\D04 D05 $
004094 -01005 -03158 0000 0375 0625 1000 0625 0375 0000\D04 D06 $
003627 -00492 -03692 0000 0375 0750 1000 0625 0250 0000\D05 D07 $
003976 -00188 -04104 0000 0375 0875 1000 0625 0125 0000\D06 D08 $
004063 000239 -04398 0000 0375 1000 1000 0625 0000 0000\D06 D09 $
004087 -03844 -00182 0000 0500 0125 1000 0500 0875 0000\D09 E01 $
004244 -03309 000689 0000 0500 0125 1000 0500 0875 0000\D09 E02 $
004316 -02543 000904 0000 0500 0250 1000 0500 0750 0000\E01 E03 $
004440 -02497 -01556 0000 0500 0375 1000 0500 0625 0000\E03 E04 $
004530 -01968 -01846 0000 0500 0500 1000 0500 0500 0000\E03 E05 $
004530 -01642 -03036 0000 0500 0625 1000 0500 0375 0000\E04 E06 $
004552 -01335 -03535 0000 0500 0750 1000 0500 0250 0000\E05 E07 $
004498 -01002 -04022 0000 0500 0875 1000 0500 0125 0000\E05 E08 $
004553 -00574 -04361 0000 0500 1000 1000 0500 0000 0000\E06 E09 $
004531 -04294 -00252 0000 0625 0125 1000 0375 0875 0000\E09 F01 $
004531 -04294 001250 0000 0625 0125 1000 0375 0875 0000\E09 F02 $
004530 -03819 -00495 0000 0625 0250 1000 0375 0750 0000\F01 F03 $
004760 -03318 -01118 0000 0625 0375 1000 0375 0625 0000\F02 F04 $
004850 -02827 -01627 0000 0625 0500 1000 0375 0500 0000\F03 F05 $
004935 -02309 -02950 0000 0625 0625 1000 0375 0375 0000\F04 F06 $
004962 -01878 -03446 0000 0625 0750 1000 0375 0250 0000\F05 F07 $
004963 -01723 -03939 0000 0625 0875 1000 0375 0125 0000\F05 F08 $
004963 -01723 -04277 0000 0625 1000 1000 0375 0000 0000\F06 F09 $
004829 -05290 002954 0000 0750 0000 1000 0250 1000 0000\G04 G01 $
004922 -04968 001679 0000 0750 0125 1000 0250 0875 0000\G05 G02 $
005237 -04968 -00460 0000 0750 0250 1000 0250 0750 0000\G05 G03 $
005137 -04045 -00680 0000 0750 0375 1000 0250 0625 0000\G05 G04 $
005264 -03582 -01158 0000 0750 0500 1000 0250 0500 0000\G06 G05 $
005277 -03141 -02457 0000 0750 0625 1000 0250 0375 0000\G06 G06 $
005562 -02609 -03134 0000 0750 0750 1000 0250 0250 0000\G07 G07 $
005365 -02303 -03858 0000 0750 0875 1000 0250 0125 0000\G08 G08 $
005516 -01954 -04134 0000 0750 1000 1000 0250 0000 0000\G08 G09 $
005143 -06009 003071 0000 0875 0000 1000 0125 1000 0000\H03 H01 $
005222 -05708 002520 0000 0875 0125 1000 0125 0875 0000\H03 H02 $
005317 -05294 000829 0000 0875 0250 1000 0125 0750 0000\H05 H03 $
005421 -04845 -00244 0000 0875 0375 1000 0125 0625 0000\H06 H04 $
005515 -04362 -01281 0000 0875 0500 1000 0125 0500 0000\H06 H05 $
005591 -03884 -02197 0000 0875 0625 1000 0125 0375 0000\H06 H06 $
005591 -03419 -02973 0000 0875 0750 1000 0125 0250 0000\H07 H07 $
005770 -02885 -03738 0000 0875 0875 1000 0125 0125 0000\H08 H08 $
005804 -02496 -04134 0000 0875 1000 1000 0125 0000 0000\H08 H09 $
005600 -06521 003551 0000 1000 0000 1000 0000 1000 0000\I72 I01 $
005676 -06280 002503 0000 1000 0125 1000 0000 0875 0000\I73 I02 $
005763 -05928 001434 0000 1000 0250 1000 0000 0750 0000\I74 I03 $
005866 -05445 000203 0000 1000 0375 1000 0000 0625 0000\I75 I04 $
005952 -05037 -00735 0000 1000 0500 1000 0000 0500 0000\I76 I05 $
006012 -04590 -01677 0000 1000 0625 1000 0000 0375 0000\I77 I06 $
006100 -04097 -02546 0000 1000 0750 1000 0000 0250 0000\I78 I07 $
006202 -03627 -03270 0000 1000 0875 1000 0000 0125 0000\I79 I08 $
006291 -03074 -04064 0000 1000 1000 1000 0000 0000 0000\I80 I09 $
002510 000698 000702 0125 0000 0000 0875 1000 1000 0000 \0081 J01 $
002571 000979 -00213 0125 0000 0125 0875 1000 0875 0000 \0082 J02 $
002820 001194 -00946 0125 0000 0250 0875 1000 0750 0000 \0083 J03 $
002842 001941 -01622 0125 0000 0375 0875 1000 0625 0000 \0084 J04 $
002857 002313 -02260 0125 0000 0500 0875 1000 0500 0000 \0085 J05 $
002820 002500 -02805 0125 0000 0625 0875 1000 0375 0000 \0086 J06 $
002832 002877 -03328 0125 0000 0750 0875 1000 0250 0000 \0087 J07 $
002917 003136 -03783 0125 0000 0875 0875 1000 0125 0000 \0088 J08 $
002938 003445 -04163 0125 0000 1000 0875 1000 0000 0000 \0089 J09 $
003125 -00187 00187 0125 0125 0125 0875 0875 0875 0000 \0090 K01 $
003261 -00015 -00004 0125 0125 0125 0875 0875 0875 0000 \0091 K02 $
003306 -00154 -00341 0125 0125 0250 0875 0875 0750 0000 \0092 K03 $
003417 000777 -00233 0125 0125 0375 0875 0875 0625 0000 \0093 K04 $
003445 001190 -00233 0125 0125 0500 0875 0875 0500 0000 \0094 K05 $
003500 001519 -00247 0125 0125 0625 0875 0875 0375 0000 \0095 K06 $
003378 001743 -00244 0125 0125 0750 0875 0875 0250 0000 \0096 K07 $
003443 002014 -00473 0125 0125 0875 0875 0875 0125 0000 \0097 K08 $
003463 002405 -04104 0125 0125 1000 0875 0875 0000 0000 \0098 K09 $
003463 002405 -04104 0125 0125 1000 0875 0875 0000 0000 \0098 K09 $
003893 -01062 000566 0125 0250 0125 0875 0750 0875 0000 \0100 L02 $
003827 -01062 -00142 0125 0250 0250 0875 0750 0750 0000 \0101 L03 $
004102 -00280 -01464 0125 0250 0375 0875 0750 0625 0000 \0102 L04 $
004192 000098 -02180 0125 0250 0500 0875 0750 0500 0000 \0103 L05 $
004014 000454 -02608 0125 0250 0625 0875 0750 0375 0000 \0104 L06 $
003936 000800 -03152 0125 0250 0750 0875 0750 0250 0000 \0105 L07 $
004000 001147 -03588 0125 0250 0875 0875 0750 0125 0000 \0106 L08 $
003909 001549 -04039 0125 0250 1000 0875 0750 0000 0000 \0107 L09 $
004299 -01062 -00424 0125 0375 0125 0875 0625 0875 0000 \0108 M02 $
004323 -01867 001047 0125 0375 0125 0875 0625 0875 0000 \0109 M02 $
004430 -01451 -00424 0125 0375 0250 0875 0625 0750 0000 \0110 M03 $
004589 -01051 -01344 0125 0375 0375 0875 0625 0625 0000 \0111 M04 $
004450 -00697 -01764 0125 0375 0500 0875 0625 0500 0000 \0112 M05 $
004586 -00456 -02508 0125 0375 0625 0875 0625 0375 0000 \0113 M05 $
004581 -00456 -03252 0125 0375 0750 0875 0625 0250 0000 \0114 M06 $
004466 000295 -03484 0125 0375 0875 0875 0625 0125 0000 \0115 M08 $
004380 000743 -03944 0125 0375 1000 0875 0625 0000 0000 \0116 M09 $
004602 -01867 001818 0125 0500 0125 0875 0500 0875 0000 \0117 N02 $
004741 -02656 001441 0125 0500 0250 0875 0500 0750 0000 \0118 N02 $
004855 -02656 000704 0125 0500 0375 0875 0500 0625 0000 \0119 N03 $
005022 -01873 -00916 0125 0500 0375 0875 0500 0625 0000 \0120 N04 $
005027 -01873 -01344 0125 0500 0500 0875 0500 0500 0000 \0121 N05 $
005027 -01128 -02433 0125 0500 0625 0875 0500 0375 0000 \0122 N05 $
004990 -00383 -02433 0125 0500 0750 0875 0500 0250 0000 \0123 N06 $
004961 -00499 -02433 0125 0500 0875 0875 0500 0125 0000 \0124 N08 $
004913 -00121 -03862 0125 0500 1000 0875 0500 0000 0000 \0125 N09 $
005025 -03862 -00121 0125 0625 0125 0875 0375 0875 0000 \0126 O01 $
005073 -03378 001924 0125 0625 0125 0875 0375 0875 0000 \0127 O02 $
005187 -03378 001441 0125 0625 0250 0875 0375 0750 0000 \0128 O03 $
005294 -02823 -00511 0125 0625 0375 0875 0375 0625 0000 \0129 O04 $
005294 -02823 -01344 0125 0625 0500 0875 0375 0500 0000 \0130 O05 $
005489 -01803 -02321 0125 0625 0625 0875 0375 0375 0000 \0131 O05 $
005489 -01803 -02321 0125 0625 0750 0875 0375 0250 0000 \0132 O06 $
005438 -01230 -03318 0125 0625 0875 0875 0375 0125 0000 \0133 O08 $
005393 -01230 -03862 0125 0625 1000 0875 0375 0000 0000 \0134 O09 $
005341 -04292 003526 0125 0750 0000 0875 0250 1000 0000 \0135 P01 $
005393 -04887 002243 0125 0750 0125 0875 0250 0875 0000 \0136 P02 $
005487 -04887 001160 0125 0750 0250 0875 0250 0750 0000 \0137 P03 $
005595 -03358 -00159 0125 0750 0375 0875 0250 0625 0000 \0138 P04 $
005675 -03358 -00511 0125 0750 0500 0875 0250 0500 0000 \0139 P05 $
005756 -02600 -01915 0125 0750 0625 0875 0250 0375 0000 \0140 P06 $
005830 -02600 -02321 0125 0750 0750 0875 0250 0250 0000 \0141 P07 $
005852 -01824 -03247 0125 0750 0875 0875 0250 0125 0000 \0142 P08 $
005855 -01824 -03862 0125 0750 1000 0875 0250 0000 0000 \0143 P09 $
005654 -04960 003097 0125 0875 0000 0875 0125 1000 0000 \0144 Q01 $
005654 -04960 002314 0125 0875 0125 0875 0125 0875 0000 \0145 Q02 $
005812 -04418 001363 0125 0875 0250 0875 0125 0750 0000 \0146 Q03 $
005934 -03997 000287 0125 0875 0375 0875 0125 0625 0000 \0147 Q04 $
005922 -03581 -00511 0125 0875 0500 0875 0125 0500 0000 \0148 Q05 $
006100 -03231 -01640 0125 0875 0625 0875 0125 0375 0000 \0149 Q05 $
006175 -03231 -02321 0125 0875 0750 0875 0125 0250 0000 \0150 Q06 $
006250 -02437 -03176 0125 0875 0875 0875 0125 0125 0000 \0151 Q08 $
006277 -02437 -03862 0125 0875 1000 0875 0125 0000 0000 \0152 Q09 $
005957 -05668 004084 0125 1000 0000 0875 0000 1000 0000 \0153 R01 $
006037 -05668 003201 0125 1000 0125 0875 0000 0875 0000 \0154 R02 $
006119 -05130 001776 0125 1000 0250 0875 0000 0750 0000 \0155 R03 $
006235 -04707 000541 0125 1000 0375 0875 0000 0625 0000 \0156 R04 $
006319 -04369 -00381 0125 1000 0500 0875 0000 0500 0000 \0157 R05 $
006395 -03986 -01281 0125 1000 0625 0875 0000 0375 0000 \0158 R05 $
006461 -03572 -02131 0125 1000 0750 0875 0000 0250 0000 \0159 R07 $
006553 -03181 -02862 0125 1000 0875 0875 0000 0125 0000 \0160 R08 $
006655 -02788 -03599 0125 1000 1000 0875 0000 0000 0000 \0161 R09 $
003060 001738 001387 0250 0000 0000 0750 1000 1000 0000 \0162 S01 $
003184 001967 000322 0250 0000 0125 0750 1000 0875 0000 \0163 S02 $
003194 002205 -00511 0250 0000 0250 0750 1000 0750 0000 \0164 S03 $
003215 002662 -01091 0250 0000 0375 0750 1000 0625 0000 \0165 S04 $
003197 003110 -01739 0250 0000 0500 0750 1000 0500 0000 \0166 S05 $
003067 003433 -02326 0250 0000 0625 0750 1000 0375 0000 \0167 S05 $
003184 003591 -02826 0250 0000 0750 0750 1000 0250 0000 \0168 S07 $
003159 003792 -03292 0250 0000 0875 0750 1000 0125 0000 \0169 S08 $
003121 004074 -03688 0250 0000 1000 0750 1000 0000 0000 \0170 S09 $
003060 000000 -03688 0250 0125 0000 0750 0875 1000 0000 \0171 T01 $
003726 000834 000827 0250 0125 0125 0750 0875 0875 0000 \0172 T02 $
003904 001353 000827 0250 0125 0250 0750 0875 0750 0000 \0173 T03 $
003883 001537 -01025 0250 0125 0375 0750 0875 0625 0000 \0174 T04 $
003823 001889 -01703 0250 0125 0500 0750 0875 0500 0000 \0175 T05 $
003823 002144 -02150 0250 0125 0625 0750 0875 0375 0000 \0176 T05 $
003667 002472 -02747 0250 0125 0750 0750 0875 0250 0000 \0177 T07 $
003644 002472 -03344 0250 0125 0875 0750 0875 0125 0000 \0178 T08 $
003637 003048 -03686 0250 0125 1000 0750 0875 0000 0000 \0179 T09 $
004456 -00368 -00368 0250 0250 0125 0750 0750 0875 0000 \0180 U01 $
004576 -00368 001304 0250 0250 0125 0750 0750 0875 0000 \0181 U02 $
004774 -00368 002167 0250 0250 0250 0750 0750 0750 0000 \0182 U03 $
004576 000393 -00898 0250 0250 0375 0750 0750 0625 0000 \0183 U04 $
004469 000756 -01697 0250 0250 0500 0750 0750 0500 0000 \0184 U05 $
004338 001125 -02131 0250 0250 0625 0750 0750 0375 0000 \0185 U06 $
004240 001476 -02662 0250 0250 0750 0750 0750 0250 0000 \0186 U07 $
004240 001827 -03192 0250 0250 0875 0750 0750 0125 0000 \0187 U08 $
004134 002118 -03611 0250 0250 1000 0750 0750 0000 0000 \0188 U09 $
004960 -01867 001710 0250 0375 0125 0750 0625 0875 0000 \0189 V01 $
004987 -01113 001732 0250 0375 0125 0750 0625 0875 0000 \0190 V02 $
005000 -00899 004461 0250 0375 0250 0750 0625 0750 0000 \0191 V03 $
005282 -00544 -00668 0250 0375 0375 0750 0625 0625 0000 \0192 V04 $
005178 -00544 -01344 0250 0375 0500 0750 0625 0500 0000 \0193 V05 $
004997 000112 -02014 0250 0375 0625 0750 0625 0375 0000 \0194 V06 $
004837 000756 -02573 0250 0375 0750 0750 0625 0250 0000 \0195 V07 $
004750 000834 -03052 0250 0375 0875 0750 0625 0125 0000 \0196 V08 $
004629 001277 -03522 0250 0375 1000 0750 0625 0000 0000 \0197 V09 $
005353 -01848 002045 0250 0500 0125 0750 0500 0875 0000 \0198 W02 $
005353 -01848 002045 0250 0500 0125 0750 0500 0875 0000 \0199 W02 $
005434 -01848 001363 0250 0500 0250 0750 0500 0750 0000 \0200 W03 $
005576 -01311 -00293 0250 0500 0375 0750 0500 0625 0000 \0201 W04 $
005576 -01311 -00293 0250 0500 0375 0750 0500 0625 0000 \0201 W04 $
005496 -00652 -01894 0250 0500 0625 0750 0500 0375 0000 \0202 W06 $
005496 -00652 -01894 0250 0500 0625 0750 0500 0375 0000 \0202 W06 $
005283 -00003 -02974 0250 0500 0875 0750 0500 0125 0000 \0203 W08 $
005283 -00003 -02974 0250 0500 0875 0750 0500 0125 0000 \0203 W08 $
005199 000331 -03450 0250 0500 1000 0750 0500 0000 0000 \0204 W09 $
005575 -02573 002486 0250 0625 0125 0750 0375 0875 0000 \0205 X01 $
005606 -02573 002486 0250 0625 0125 0750 0375 0875 0000 \0206 X02 $
005815 -02573 001127 0250 0625 0250 0750 0375 0750 0000 \0207 X03 $
005815 -02003 000100 0250 0625 0375 0750 0375 0625 0000 \0208 X04 $
005925 -01433 -00511 0250 0625 0500 0750 0375 0500 0000 \0209 X05 $
006013 -01332 -01726 0250 0625 0625 0750 0375 0375 0000 \0210 X06 $
005876 -01433 -02352 0250 0625 0750 0750 0375 0250 0000 \0211 X07 $
005807 -00766 -02850 0250 0625 0875 0750 0375 0125 0000 \0212 X08 $
005807 -00766 -03347 0250 0625 1000 0750 0375 0000 0000 \0213 X09 $
005768 -03457 001465 0250 0750 0000 0750 0250 1000 0000 \0214 Y01 $
005843 -03269 002799 0250 0750 0125 0750 0250 0875 0000 \0215 Y02 $
005966 -03173 -03223 0250 0750 0375 0750 0250 0625 0000 \0216 Y04 $
005969 -02683 000398 0250 0750 0375 0750 0250 0625 0000 \0217 Y04 $
006221 -01399 -02784 0250 0750 0500 0750 0250 0500 0000 \0218 Y05 $
006221 -01399 -02784 0250 0750 0875 0750 0250 0125 0000 \0219 Y08 $
006221 -01399 -02784 0250 0750 0875 0750 0250 0125 0000 \0219 Y08 $
006218 -04137 004256 0250 0875 0000 0750 0125 1000 0000 \0220 Z01 $
006218 -04137 004256 0250 0875 0000 0750 0125 1000 0000 \0220 Z01 $
006205 -03689 001885 0250 0875 0250 0750 0125 0750 0000 \0221 Z03 $
006364 -03368 000796 0250 0875 0375 0750 0125 0625 0000 \0222 Z04 $
006543 -03041 -00511 0250 0875 0500 0750 0125 0500 0000 \0223 Z05 $
006469 -02705 -01115 0250 0875 0625 0750 0125 0375 0000 \0224 Z06 $
006547 -02390 -01894 0250 0875 0750 0750 0125 0250 0000 \0225 Z07 $
006634 -02009 -02669 0250 0875 0875 0750 0125 0125 0000 \0226 Z08 $
006589 -01733 -03223 0250 0875 1000 0750 0125 0000 0000 \0227 Z09 $
006285 -04882 004605 0250 1000 0000 0750 0000 1000 0000 \0228 A01 $
006387 -04882 003722 0250 1000 0125 0750 0000 0875 0000 \0229 A02 $
006475 -04407 002302 0250 1000 0250 0750 0000 0750 0000 \0230 A03 $
006576 -04050 001016 0250 1000 0375 0750 0000 0625 0000 \0231 A04 $
006666 -03748 000000 0250 1000 0500 0750 0000 0500 0000 \0232 A05 $
006732 -03437 -00797 0250 1000 0625 0750 0000 0375 0000 \0233 A06 $
006798 -03099 -01646 0250 1000 0750 0750 0000 0250 0000 \0234 A07 $
006892 -02751 -02375 0250 1000 0875 0750 0000 0125 0000 \0235 A08 $
006995 -02314 -03132 0250 1000 1000 0750 0000 0000 0000 \0236 A09 $
```

TUB-test chart JE85; Relative Device Colour System G
1080 spectral reflexions R -> LAB* & LAB*a; D65 & D50

input: *w setgray*
output: no change compared to input